

DEVICE LIST 4/30/2009

Total Manufacturers 161

Total Devices 24079

ACT	ACTRANS	ADVANCE GROUP	ALI
(Acer)			
ALL 24 SERIES(ISP)		ALLIANCE	
ALTERA			
AMD	AMI SEMICONDUCTOR		
AMIC			
ANACHIP	APLUS FLASH	ARTSCHIP	ASAHI KASEI
(AKM)			
ASD	ASI	ASP	
ATC			
ATMEL	ATMEL W&M	ATMEL-CUSTOMER	
AUSTIN			
BELLING-SYSTRON	BENCHMARQ	BRIGHT	
CATALYST			
CELESTICA	CERAMATE	CHINA CORE	
CHINGIS			
CHIPCON	CHIPSWINNER	CORERIVER	
CWI			
CYGNAL	CYPRESS	DALLAS	DENSE-
PAC			
DEUTRON	EFST	ELECTRONIC	
ARRAYS			
EM	EMTC	EON	
ESMT			
EXCELSEMI	EXEL	FAIRCHILD	
FORCE TECHNOLOGIES		FORWARD	
Fremont Micro Devices		FUJITSU	
GENCORE			
GENERAL(GI)	GENERIC	GIGADEVICE	

[GOAL](#)

[GREENWICH](#)

[HAIER](#)

[HARRIS](#)

[HITACHI](#)

[HOLTEK](#)

[HONGKONG](#)

[HYNIX](#)

[HYUNDAI](#)

[ICE](#)

[ICMIC](#)

[ICSI](#)

[ICT](#)

[IDT](#)

[IMT](#)

[INTEL](#)

[INTELSIL](#)

[ISSI](#)

[LATTICE](#)

[LG Semicon](#)

[LINKSMART](#)

[MACRONIX](#)

[MAXIM](#)

[MAXWELL](#)

[MEGAWIN](#)

[MICON](#)

[MICROCHIP](#)

[MICRON](#)

[MICRONAS](#)

[MITSUBISHI](#)

[MOSEL-VITELIC](#)

[MOSTEK](#)

[MOTOROLA](#)

[NEC](#)

[NEXFLASH](#)

[NJRC](#)

[NSC](#)

[NTE](#)

[NUMONYX](#)

[NUVOTON](#)

[NXP](#)

[OKI](#)

[ON Semiconductor](#)

[PFLASH\(MSTAR\)](#)

[PHILIPS](#)

[PJ](#)

[PMC](#)

[PSS](#)

[PTC](#)

[QIXIN](#)

[Quick Pulse](#)

[RAMTRON](#)

[RATO](#)

[RAYDIUM](#)

[RENESAS](#)

[RICOH](#)

[ROCKWELL](#)

[ROHM](#)

[SAIFUN](#)

[SAMSUNG](#)

[SANYO](#)

[SEEQ](#)

[SEIKO](#)

[SGS-THOMSON](#)

[SHARP](#)

[SIEMENS](#)

[SIGNETICS](#)

[Silicon](#)

[Laboratories](#)

[SIMTEK](#)

[SMOS](#)

[SONY](#)

[SPACE ELECTRONICS\[SEI\]](#)

[SPANSION](#)

[SSSC](#)

SST	ST	STC	
SUMMIT			
SUNPLUS	SYNCMOS	SYNERTEK	
SYNTEK			
TECHCODE	TEKMOS	TEMIC	
TI			
TMC	TOPRO	TOSHIBA	TURBO
IC			
UMC	UTRON	VLSI	
WELTREND			
WHITE ELECTRONIC DESIGNS		WINBOND	
WSI			
XELTEK	XICOR	XILINX	XILINX-
CUSTOMER			
YMC	YSS	ZILOG	
ZMD			

ACT

E (E) PROM / FRAM / NVRAM

93LC46 (08bit) [(SA602A)]	93LC46 (08bit) @ SOIC8
93LC46 (16bit) [(SA602A)]	93LC46 (16bit) @ SOIC8
93LC56 (08bit) [(SA602A)]	93LC56 (08bit) @ SOIC8
93LC56 (16bit) [(SA602A)]	93LC56 (16bit) @ SOIC8
93LC66 (08bit) [(SA602A)]	93LC66 (08bit) @ SOIC8
93LC66 (16bit) [(SA602A)]	93LC66 (16bit) @ SOIC8
93LC86 (08bit) [(SA602A)]	93LC86 (08bit) @ SOIC8
93LC86 (16bit) [(SA602A)]	93LC86 (16bit) @ SOIC8

ACTRANS

E (E) PROM / FRAM / NVRAM

AC25010@SOIC8 [(SA602A)] [(SA602A)]	AC25512@SOIC8
AC25LC010@SOIC8 [(SA602A)] [(SA602A)]	AC25LC512@SOIC8
AC39LV010@PLCC32 [(SA015A1T)] [(SA620)]	AC39LV010@VSOP32
AC39LV020@PLCC32 [(SA015A1T)] [(SA620)]	AC39LV020@VSOP32
AC39LV040@PLCC32 [(SA015A1T)] [(SA620)]	AC39LV040@VSOP32
AC39LV080@TSOP40 [(SA409T)] B005]	AC39LV088@TSOP48 [(SA247-
AC39LV512@PLCC32 [(SA015A1T)] [(SA620)]	AC39LV512@VSOP32
AC39VF800@TSOP48 [(SA247-B005)]	

ADVANCE GROUP

E (E) PROM / FRAM / NVRAM

AF24BC01 [(SA602A)]	AF24BC01@SOIC8
AF24BC01@TSOP8 [(SA026)]	
AF24BC02 AF24BC02@SOIC8 [(SA602A)] [(SA026)]	AF24BC02@TSOP8
AF24BC04 [(SA602A)]	AF24BC04@SOIC8
AF24BC04@TSOP8 [(SA026)]	
AF24BC08 AF24BC08@SOIC8 [(SA602A)] [(SA026)]	AF24BC08@TSOP8
AF24BC16 [(SA602A)]	AF24BC16@SOIC8
AF24BC16@TSOP8 [(SA026)]	
AF24C128	

AF24C128@SOIC8 [(SA602A)]	AF24C128@TSOP8
[(SA026)]	
AF24C256	AF24C256@SOIC8
[(SA602A)]	
AF24C256@TSOP8 [(SA026)]	
AF24C32	
AF24C32@SOIC8 [(SA602A)]	AF24C32@TSOP8
[(SA026)]	
AF24C64	AF24C64@SOIC8
[(SA602A)]	
AF24C64@TSOP8 [(SA026)]	AF93C46
(08bit)	
AF93C46(08bit)@SOIC8 [(SA602A)]	AF93C46(08bit)@TSOP8
[(SA026)]	
AF93C46(16bit)	AF93C46(16bit)@SOIC8
[(SA602A)]	
AF93C46(16bit)@TSOP8 [(SA026)]	AF93C56
(08bit)	
AF93C56(08bit)@SOIC8 [(SA602A)]	AF93C56(08bit)@TSOP8
[(SA026)]	
AF93C56(16bit)	AF93C56(16bit)@SOIC8
[(SA602A)]	
AF93C56(16bit)@TSOP8 [(SA026)]	AF93C66
(08bit)	
AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8
[(SA026)]	
AF93C66(16bit)	AF93C66(16bit)@SOIC8
[(SA602A)]	
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86
(08bit)	
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8
[(SA026)]	
AF93C86(16bit)	AF93C86(16bit)@SOIC8
[(SA602A)]	
AF93C86(16bit)@TSOP8 [(SA026)]	

MICROCONTROLLER

A1000A2	A1000A2@PLCC44
[(SA244)]	
A1000A2@PQFP44 [(SA245A)]	
A1000A3	

A1000A3@PLCC44 [(SA244)] [(SA245A)]	A1000A3@PQFP44
AG1001@SDIP42 [(SA028)]	
AG89F516	
AG89F516@PLCC44 [(SA244)] [(SA245A)]	AG89F516@PQFP44
AG89F54 [(SA244)]	AG89F54@PLCC44
AG89F54@PQFP44 [(SA245A)]	
AG89P51	
AG89P51@PLCC44 [(SA244)] [(SA675)]	AG89P51@PQFP44
AG89P516 [(SA244)]	AG89P516@PLCC44
AG89P516@PQFP44 [(SA675)]	
AG89P51A	
AG89P51A@PLCC44 [(SA244)] [(SA675)]	AG89P51A@PQFP44
AG89P52 [(SA244)]	AG89P52@PLCC44
AG89P52@PQFP44 [(SA675)]	

ALI(Acer)

E (E) PROM / FRAM / NVRAM

M8720 [(SA015A1T)]	M8720@PLCC32
-------------------------	--------------

MICROCONTROLLER

M6759 [(SA244)]	M6759@PLCC44
M6759@TQFP44 [(SA245A)]	

ALL 24 SERIES(ISP)

E (E) PROM / FRAM / NVRAM

24C01 (ISP) [ISP-HEADER01] HEADER01]	24C02 (ISP) [ISP-
24C04 (ISP) [ISP-HEADER01] HEADER01]	24C08 (ISP) [ISP-
24C128 (ISP) [ISP-HEADER01] HEADER01]	24C16 (ISP) [ISP-
24C256 (ISP) [ISP-HEADER01] HEADER01]	24C32 (ISP) [ISP-
24C64 (ISP) [ISP-HEADER01]	

ALLIANCE

E (E) PROM/FRAM/NVRAM

AS29F200@PSOP44 [(SA638-B006)] B005]	AS29F200@TSOP48 [(SA247-
AS29F200B@PSOP44 [(SA638-B006)] B005]	AS29F200B@TSOP48 [(SA247-
AS29F200T@PSOP44 [(SA638-B006)] B005]	AS29F200T@TSOP48 [(SA247-

ALTERA

E (E) PROM/FRAM/NVRAM

EPC1(LC)@PLCC20 [(SA001A)] [(SA001A)]	EPC1(LI)@PLCC20
EPC1(PC) (PI)	EPC1
EPC1441(LC)@PLCC20 [(SA001A)] [(SA001A)]	EPC1441(LI)@PLCC20
EPC1441(PC) (PI)	EPC1441
EPC1441(TC)@TQFP32 [(SA663)] [(SA663)]	EPC1441(TI)@TQFP32
EPC2(LC)@PLCC20 [(SA001A)] [(SA001A)]	EPC2(LI)@PLCC20
EPC2(TC)@TQFP32 [(SA663)] [(SA663)]	EPC2(TI)@TQFP32
EPCS16SI16@SOIC16 [(SA404)]	EPCS16SI8N@SOIC8

```
[ (SA602A) ]
EPCS1SI8@SOIC8 [ (SA602A) ]          EPCS4SI8@SOIC8
[ (SA602A) ]
EPCS64SI16@SOIC16 [ (SA404) ]
```

PLD

```
EP310                                EP310@PLCC20
[ (SA001A) ]
EP320                                EP320@PLCC20
[ (SA001A) ]
EP330                                EP330@PLCC20
[ (SA001A) ]
EP600                                EP600@PLCC28
[ (SA008A) ]
EP600@SOIC24 [ (SA404) ]
EP600I
EP600I@PLCC28 [ (SA008A) ]          EP600I@SOIC24
[ (SA404) ]
EP610                                EP610@PLCC28
[ (SA008A) ]
EP610@SOIC24 [ (SA404) ]
EP610A
EP610A@PLCC28 [ (SA008A) ]          EP610A@SOIC24
[ (SA404) ]
EP610I                                EP610I@PLCC28
[ (SA008A) ]
EP610I@SOIC24 [ (SA404) ]
EP610T
EP610T@PLCC28 [ (SA008A) ]          EP610T@SOIC24
[ (SA404) ]
EP630                                EP630@PLCC28
[ (SA008A) ]
EP630@SOIC24 [ (SA404) ]
EP900
EP900@PLCC44 [ (SA244) ]
EP900I
EP900I@PLC44 [ (SA244) ]
EP910
EP910@PLCC44 [ (SA244) ]
EP910A
EP910A@PLCC44 [ (SA244) ]
```


EP910I
 EP910I@PLCC44 [(SA244)]
 EP910T
 EP910T@PLCC44 [(SA244)]

AMD

E (E) PROM / FRAM / NVRAM

1736 [(SA602A)]	1736@SOIC8
1765 [(SA602A)]	1765@SOIC8
AM25FL005D@SOIC8 [(SA602A)] [(SA683)]	AM25FL005D@USON8
AM25FL010D@SOIC8 [(SA602A)] [(SA683)]	AM25FL010D@USON8
AM25FL016A@SOIC16 [(SA404)]	
AM25FL016A@SOIC16 (ISP) [ISP-HEADER01]	
AM25FL016A@WSON8 [(SA684)]	
AM25FL016A@WSON8 (ISP) [ISP-HEADER01]	
AM25FL020D@SOIC8 [(SA602A)] [(SA683)]	AM25FL020D@USON8
AM25FL032A@SOIC16 [(SA404)]	
AM25FL032A@SOIC16 (ISP) [ISP-HEADER01]	
AM25FL032A@WSON8 [(SA684)]	
AM25FL032A@WSON8 (ISP) [ISP-HEADER01]	
AM25FL040D@SOIC8 [(SA602A)] [(SA683)]	AM25FL040D@USON8
AM25FL080D@SOIC8 [(SA602A)] [(SA683)]	AM25FL080D@USON8
AM27128 (DC)	AM27128
AM27128 (DC)@PLCC32 [(SA015A1T)] [(SA015A1T)]	AM27128@PLCC32
AM27128A (F)	AM27128A
AM27128A (F)@PLCC32 [(SA015A1T)] (PC)	AM27128A
AM27128A (PC)@PLCC32 [(SA015A1T)] [(SA015A1T)]	AM27128A@PLCC32
AM2716	

AM2716B	
AM27256	AM27256@PLCC32
[(SA015A1T)]	
AM27256AP	AM27256AP@PLCC32
[(SA015A1T)]	
AM27256F	AM27256F@PLCC32
[(SA015A1T)]	
AM27256PC	AM27256PC@PLCC32
[(SA015A1T)]	
AM2732	
AM2732A	
AM2732B	
AM27512	
AM27512@PLCC32 [(SA015A1T)]	
AM27512DC	
AM27512DC@PLCC32 [(SA015A1T)]	
AM27512F	
AM27512F@PLCC32 [(SA015A1T)]	
AM27512PC	
AM27512PC@PLCC32 [(SA015A1T)]	
AM27513	
AM2764	AM2764@PLCC32
[(SA015A1T)]	
AM2764A	AM2764A
(DC)	
AM2764A(DC)@PLCC32 [(SA015A1T)]	AM2764A
(DCB)	
AM2764A(DI)	AM2764A
(DIB)	
AM2764A(F)	AM2764A(F)@PLCC32
[(SA015A1T)]	
AM2764A(JC)	AM2764A
(LC)	
AM2764A(LCB)	AM2764A
(LE)	
AM2764A(LEB)	AM2764A
(PC)	
AM2764A(PC)@PLCC32 [(SA015A1T)]	AM2764A@PLCC32
[(SA015A1T)]	
AM27C010	AM27C010@PLCC32
[(SA015A1T)]	
AM27C010@TSOP32 [(SA410T)]	
AM27C020	

AM27C020@PLCC32 [(SA015A1T)]	AM27C020@TSOP32
[(SA410T)]	
AM27C040	AM27C040@PLCC32
[(SA015A1T)]	
AM27C040@TSOP32 [(SA410T)]	
AM27C080	
AM27C080@PLCC32 [(SA015A1T)]	AM27C080@TSOP32
[(SA410T)]	
AM27C100	AM27C100@PLCC32
[(SA015A1T)]	
AM27C100@TSOP32 [(SA410T)]	
AM27C1024	
AM27C1024@PLCC44 [(SA244)]	
AM27C128	
AM27C128@PLCC32 [(SA015A1T)]	
AM27C2048	
AM27C2048@PLCC44 [(SA244)]	AM27C2048@TSOP40
[(SA409T)]	
AM27C256	AM27C256
(F)	
AM27C256(F)@PLCC32 [(SA015A1T)]	AM27C256
(PC)	
AM27C256(PC)@PLCC32 [(SA015A1T)]	AM27C256@PLCC32
[(SA015A1T)]	
AM27C400	AM27C400@PLCC44
[(SA244)]	
AM27C4096	AM27C4096@PLCC44
[(SA244)]	
AM27C512	AM27C512
(P)	
AM27C512(P)@PLCC32 [(SA015A1T)]	AM27C512@PLCC32
[(SA015A1T)]	
AM27C64	AM27C64@PLCC32
[(SA015A1T)]	
AM27H010	AM27H010@PLCC32
[(SA015A1T)]	
AM27H010@TSOP32 [(SA410T)]	
AM27H256	
AM27H256@PLCC32 [(SA015A1T)]	
AM27HB010	
AM27HB010@PLCC32 [(SA015A1T)]	AM27HB010@TSOP32
[(SA410T)]	
AM27LV010	AM27LV010@PLCC32

[(SA015A1T)]	
AM27LV010@TSOP32 [(SA410T)]	
AM27LV010B	
AM27LV010B@PLCC32 [(SA015A1T)]	AM27LV010B@TSOP32
[(SA410T)]	
AM27LV020	
[(SA015A1T)]	
AM27LV020@TSOP32 [(SA410T)]	AM27LV020@PLCC32
AM27LV020B	
AM27LV020B@PLCC32 [(SA015A1T)]	AM27LV020B@TSOP32
[(SA410T)]	
AM2816A	
AM2817A	
AM2817A@PLCC32 [(SA015A1T)]	AM2817A@SOIC28
[(SA404)]	
AM2864A	
(E)	
AM2864A(E)@PLCC32 [(SA015A1T)]	AM2864A
[(SA015A1T)]	
AM2864B	AM2864A@PLCC32
(E)	
AM2864B(E)@PLCC32 [(SA015A1T)]	AM2864B
[(SA015A1T)]	
AM28F001	AM2864B@PLCC32
[(SA015A1T)]	
AM28F001@TSOP32 [(SA410T)]	AM28F001@PLCC32
AM28F010	
AM28F010@PLCC32 [(SA015A1T)]	AM28F010@TSOP32
[(SA410T)]	
AM28F010A	AM28F010A@PLCC32
[(SA015A1T)]	
AM28F010A@TSOP32 [(SA410T)]	
AM28F020	
AM28F020@PLCC32 [(SA015A1T)]	AM28F020@TSOP32
[(SA410T)]	
AM28F020A	AM28F020A@PLCC32
[(SA015A1T)]	
AM28F020A@TSOP32 [(SA410T)]	
AM28F256	
AM28F256@PLCC32 [(SA015A1T)]	AM28F256@TSOP32
[(SA410T)]	
AM28F256A	AM28F256A@PLCC32
[(SA015A1T)]	

AM28F256A@TSOP32 [(SA410T)]
 AM28F512
 AM28F512(F) AM28F512(F)@PLCC32
 [(SA015A1T)]
 AM28F512(F)@TSOP32 [(SA410T)] AM28F512@PLCC32
 [(SA015A1T)]
 AM28F512@TSOP32 [(SA410T)]
 AM28F512A
 AM28F512A(F) AM28F512A(F)@PLCC32
 [(SA015A1T)]
 AM28F512A(F)@TSOP32 [(SA410T)] AM28F512A@PLCC32
 [(SA015A1T)]
 AM28F512A@TSOP32 [(SA410T)]
 AM29DL400BB@PSOP44 [(SA638-B006)]
 AM29DL400BB@TSOP48 [(SA247-B005)]
 AM29DL400BT@PLCC44 [(SA638-B006)]
 AM29DL400BT@TSOP48 [(SA247-B005)]
 AM29DL800B@PSOP44 [(SA638-B006)] AM29DL800B@TSOP48 [(SA247-B005)]
 AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
 AM29DL800BB@PSOP44 [(SA638)]
 AM29DL800BB@TSOP48 [(SA247-B005)]
 AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]
 AM29DL800BT@PSOP44 [(SA638)]
 AM29DL800BT@TSOP48 [(SA247-B005)]
 AM29DL800T@PSOP44 [(SA638-B006)] AM29DL800T@TSOP48 [(SA247-B005)]
 AM29F002B AM29F002B@PLCC32
 [(SA015A1T)]
 AM29F002B@TSOP32 [(SA410T)]
 AM29F002BB
 AM29F002BB@PLCC32 [(SA015A1T)] AM29F002BB@TSOP32
 [(SA410T)]
 AM29F002BT AM29F002BT@PLCC32
 [(SA015A1T)]
 AM29F002BT@TSOP32 [(SA410T)]
 AM29F002NB
 AM29F002NB@PLCC32 [(SA015A1T)] AM29F002NB@TSOP32
 [(SA410T)]
 AM29F002NBB AM29F002NBB@PLCC32
 [(SA015A1T)]
 AM29F002NBB@TSOP32 [(SA410T)]
 AM29F002NBT

AM29F002NBT@PLCC32 [(SA015A1T)]	AM29F002NBT@TSOP32
[(SA410T)]	
AM29F002NT	AM29F002NT@PLCC32
[(SA015A1T)]	
AM29F002NT@TSOP32 [(SA410T)]	
AM29F002T	
AM29F002T@PLCC32 [(SA015A1T)]	AM29F002T@TSOP32
[(SA410T)]	
AM29F004BB@PLCC32 [(SA015A1T)]	AM29F004BB@TSOP32
[(SA410T)]	
AM29F004BT@PLCC32 [(SA015A1T)]	AM29F004BT@TSOP32
[(SA410T)]	
AM29F010	AM29F010@PLCC32
[(SA015A1T)]	
AM29F010@TSOP32 [(SA410T)]	
AM29F010A	
AM29F010A@PLCC32 [(SA015A1T)]	AM29F010A@TSOP32
[(SA410T)]	
AM29F010B	AM29F010B@PLCC32
[(SA015A1T)]	
AM29F010B@TSOP32 [(SA410T)]	AM29F016@PSOP44
[(SA638)]	
AM29F016@TSOP40 [(SA409T)]	AM29F016@TSOP48 [(SA247-
B005)]	
AM29F016B(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016B@PSOP44 [(SA638)]	AM29F016B@TSOP40
[(SA409T)]	
AM29F016B@TSOP48 [(SA247-B005)]	
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016D@PSOP44 [(SA638)]	AM29F016D@TSOP40
[(SA409T)]	
AM29F016D@TSOP48 [(SA247-B005)]	AM29F017B@TSOP48 [(SA247-
B005)]	
AM29F017D@TSOP40 [(SA409T)]	AM29F017D@TSOP48 [(SA247-
B005)]	
AM29F032B@PSOP44 [(SA638)]	AM29F032B@TSOP40
[(SA409T)]	
AM29F040	AM29F040@PLCC32
[(SA015A1T)]	
AM29F040@TSOP32 [(SA410T)]	
AM29F040A	
AM29F040A@PLCC32 [(SA015A1T)]	AM29F040A@TSOP32
[(SA410T)]	

AM29F040B	
AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)]	AM29F040B@TSOP32
[(SA410T)]	
AM29F080@PSOP44 [(SA638)]	AM29F080@TSOP40
[(SA409T)]	
AM29F080B@PSOP44 [(SA638)]	AM29F080B@TSOP40
[(SA409T)]	
AM29F100BE@PSOP44 [(SA638-B006)]	AM29F100BE@TSOP48 [(SA247-
B005)]	
AM29F100BS@PSOP44 [(SA638-B006)]	AM29F100BS@TSOP48 [(SA247-
B005)]	
AM29F100TE@PSOP44 [(SA638-B006)]	AM29F100TE@TSOP48 [(SA247-
B005)]	
AM29F100TS@PSOP44 [(SA638-B006)]	AM29F100TS@TSOP48 [(SA247-
B005)]	
AM29F160DB@TSOP48 [(SA247-B005)]	AM29F160DT@TSOP48 [(SA247-
B005)]	
AM29F200AB@PSOP44 [(SA638-B006)]	AM29F200AB@TSOP48 [(SA247-
B005)]	
AM29F200AT@PSOP44 [(SA638-B006)]	AM29F200AT@TSOP48 [(SA247-
B005)]	
AM29F200BB@PSOP44 [(SA638-B006)]	AM29F200BB@TSOP48 [(SA247-
B005)]	
AM29F200BE@PSOP44 [(SA638-B006)]	AM29F200BE@TSOP48 [(SA247-
B005)]	
AM29F200BS@PSOP44 [(SA638-B006)]	AM29F200BS@TSOP48 [(SA247-
B005)]	
AM29F200BT@PSOP44 [(SA638-B006)]	AM29F200BT@TSOP48 [(SA247-
B005)]	
AM29F200TE@PSOP44 [(SA638-B006)]	AM29F200TE@TSOP48 [(SA247-
B005)]	
AM29F200TS@PSOP44 [(SA638-B006)]	AM29F200TS@TSOP48 [(SA247-
B005)]	
AM29F400AB@PSOP44 [(SA638-B006)]	AM29F400AB@TSOP48 [(SA247-
B005)]	
AM29F400AT@PSOP44 [(SA638-B006)]	AM29F400AT@TSOP48 [(SA247-
B005)]	
AM29F400BB@PSOP44 [(SA638-B006)]	AM29F400BB@TSOP48 [(SA247-
B005)]	
AM29F400BBE@PSOP44 [(SA638-B006)]	
AM29F400BBE@TSOP48 [(SA247-B005)]	
AM29F400BBF@PSOP44 [(SA638-B006)]	

AM29F400BBF@TSOP48 [(SA247-B005)]	
AM29F400BBS@PSOP44 [(SA638-B006)]	
AM29F400BBS@TSOP48 [(SA247-B005)]	
AM29F400BE@PSOP44 [(SA638-B006)]	AM29F400BE@TSOP48 [(SA247-B005)]
AM29F400BF@PSOP44 [(SA638-B006)]	AM29F400BF@TSOP48 [(SA247-B005)]
AM29F400BS@PSOP44 [(SA638-B006)]	AM29F400BS@TSOP48 [(SA247-B005)]
AM29F400BT@PSOP44 [(SA638-B006)]	AM29F400BT@TSOP48 [(SA247-B005)]
AM29F400BTE@PSOP44 [(SA638-B006)]	
AM29F400BTE@TSOP48 [(SA247-B005)]	
AM29F400BTF@PSOP44 [(SA638-B006)]	
AM29F400BTF@TSOP48 [(SA247-B005)]	
AM29F400BTS@PSOP44 [(SA638-B006)]	
AM29F400BTS@TSOP48 [(SA247-B005)]	
AM29F800B@PSOP44 [(SA638-B006)]	AM29F800B@TSOP48 [(SA247-B005)]
AM29F800BB@PSOP44 [(SA638-B006)]	AM29F800BB@TSOP48 [(SA247-B005)]
AM29F800BBF@PSOP44 [(SA638-B006)]	
AM29F800BBF@TSOP48 [(SA247-B005)]	
AM29F800BF@PSOP44 [(SA638-B006)]	AM29F800BF@TSOP48 [(SA247-B005)]
AM29F800BT@PSOP44 [(SA638-B006)]	AM29F800BT@TSOP48 [(SA247-B005)]
AM29F800BTF@PSOP44 [(SA638-B006)]	
AM29F800BTF@TSOP48 [(SA247-B005)]	
AM29F800T@PSOP44 [(SA638-B006)]	AM29F800T@TSOP48 [(SA247-B005)]
AM29F800TB@PSOP44 [(SA638-B006)]	AM29F800TB@TSOP48 [(SA247-B005)]
AM29F800TF@PSOP44 [(SA638-B006)]	AM29F800TF@TSOP48 [(SA247-B005)]
AM29LL800B@TSOP48 [(SA247-B005)]	
AM29LL800BB@TSOP48 [(SA247-B005)]	
AM29LL800BT@TSOP48 [(SA247-B005)]	
AM29LL800T@TSOP48 [(SA247-B005)]	AM29LV001BB@PLCC32 [(SA015A1T)]
AM29LV001BB@TSOP32 [(SA410T)]	AM29LV001BT@PLCC32 [(SA015A1T)]
AM29LV001BT@TSOP32 [(SA410T)]	AM29LV002@TSOP40

[(SA409T)]	
AM29LV002B@TSOP40 [(SA409T)]	AM29LV002BB@TSOP40
[(SA409T)]	
AM29LV002BT@TSOP40 [(SA409T)]	AM29LV004B@PSOP44
[(SA638)]	
AM29LV004B@TSOP40 [(SA409T)]	AM29LV004BB@TSOP40
[(SA409T)]	
AM29LV004BT@TSOP40 [(SA409T)]	AM29LV004T@PSOP44
[(SA638)]	
AM29LV004T@TSOP40 [(SA409T)]	AM29LV008B@PSOP44
[(SA638)]	
AM29LV008B@TSOP40 [(SA409T)]	AM29LV008BB@TSOP40
[(SA409T)]	
AM29LV008BT@TSOP40 [(SA409T)]	AM29LV008T@PSOP44
[(SA638)]	
AM29LV008T@TSOP40 [(SA409T)]	AM29LV010B@PLCC32
[(SA015A1T)]	
AM29LV010B@TSOP32 [(SA410T)]	AM29LV017B@TSOP40
[(SA409T)]	
AM29LV020B@PLCC32 [(SA015A1T)]	AM29LV020B@TSOP32
[(SA410T)]	
AM29LV033C@TSOP40 [(SA409T)]	AM29LV033MU@TSOP40
[(SA409T)]	
AM29LV040B@PLCC32 [(SA015A1T)]	AM29LV040B@TSOP32
[(SA410T)]	
AM29LV040E@PLCC32 [(SA015A1T)]	AM29LV040E@TSOP32
[(SA410T)]	
AM29LV040J@PLCC32 [(SA015A1T)]	AM29LV040J@TSOP32
[(SA410T)]	
AM29LV081@TSOP40 [(SA409T)]	AM29LV081B@TSOP40
[(SA409T)]	
AM29LV116BB@TSOP40 [(SA409T)]	AM29LV116BT@TSOP40
[(SA409T)]	
AM29LV116DB@TSOP40 [(SA409T)]	AM29LV116DT@TSOP40
[(SA409T)]	
AM29LV200B@PSOP44 [(SA638-B006)]	AM29LV200B@TSOP48 [(SA247-
B005)]	
AM29LV200BB@PSOP44 [(SA638-B006)]	
AM29LV200BB@TSOP48 [(SA247-B005)]	
AM29LV200BE@PSOP44 [(SA638-B006)]	
AM29LV200BE@TSOP48 [(SA247-B005)]	
AM29LV200BF@PSOP44 [(SA638-B006)]	
AM29LV200BF@TSOP48 [(SA247-B005)]	

AM29LV200BS@PSOP44 [(SA638-B006)]
AM29LV200BS@TSOP48 [(SA247-B005)]
AM29LV200BT@PSOP44 [(SA638-B006)]
AM29LV200BT@TSOP48 [(SA247-B005)]
AM29LV200T@PSOP44 [(SA638-B006)] AM29LV200T@TSOP48 [(SA247-B005)]
AM29LV200TE@PSOP44 [(SA638-B006)]
AM29LV200TE@TSOP48 [(SA247-B005)]
AM29LV200TF@PSOP44 [(SA638-B006)]
AM29LV200TF@TSOP48 [(SA247-B005)]
AM29LV200TS@PSOP44 [(SA638-B006)]
AM29LV200TS@TSOP48 [(SA247-B005)]
AM29LV400B@PSOP44 [(SA638-B006)] AM29LV400B@TSOP48 [(SA247-B005)]
AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BB@PSOP44 [(SA638-B006)]
AM29LV400BB@TSOP48 [(SA247-B005)]
AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BT@PSOP44 [(SA638-B006)]
AM29LV400BT@TSOP48 [(SA247-B005)]
AM29LV400T@PSOP44 [(SA638-B006)] AM29LV400T@TSOP48 [(SA247-B005)]
AM29LV800B@PSOP44 [(SA638-B006)] AM29LV800B@TSOP48 [(SA247-B005)]
AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BB@PSOP44 [(SA638-B006)]
AM29LV800BB@TSOP48 [(SA247-B005)]
AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BT@PSOP44 [(SA638-B006)]
AM29LV800BT@TSOP48 [(SA247-B005)]
AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29LV800DB@PSOP44 [(SA638)]
AM29LV800DB@TSOP48 [(SA247-B005)]
AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29LV800DT@PSOP44 [(SA638)]
AM29LV800DT@TSOP48 [(SA247-B005)]
AM29LV800T@PSOP44 [(SA638-B006)] AM29LV800T@TSOP48 [(SA247-B005)]
AM9716
AM9732
AM9732A

AM9764
 AM9764@PLCC32 [(SA015A1T)]

PLD

PALC16L8Q [(SA001A)]	PALC16L8Q@PLCC20
PALC16L8Z [(SA001A)]	PALC16L8Z@PLCC20
PALC16R4Q [(SA001A)]	PALC16R4Q@PLCC20
PALC16R4Z [(SA001A)]	PALC16R4Z@PLCC20
PALC16R6Q [(SA001A)]	PALC16R6Q@PLCC20
PALC16R6Z [(SA001A)]	PALC16R6Z@PLCC20
PALC16R8Q [(SA001A)]	PALC16R8Q@PLCC20
PALC16R8Z [(SA001A)]	PALC16R8Z@PLCC20
PALCE16V8H [(SA001A)]	PALCE16V8H@PLCC20
PALCE16V8H@SOIC20 [(SA404)]	
PALCE16V8Q PALCE16V8Q@PLCC20 [(SA001A)] [(SA404)]	PALCE16V8Q@SOIC20
PALCE16V8Z [(SA001A)]	PALCE16V8Z@PLCC20
PALCE16V8Z@SOIC20 [(SA404)]	
PALCE20V8H PALCE20V8H@PLCC28 [(SA008A)] [(SA404)]	PALCE20V8H@SOIC24
PALCE20V8Q [(SA008A)]	PALCE20V8Q@PLCC28
PALCE20V8Q@SOIC24 [(SA404)]	
PALLV16V8 PALLV16V8@PLCC20 [(SA001A)] [(SA404)]	PALLV16V8@SOIC20
PALLV16V8Z [(SA001A)]	PALLV16V8Z@PLCC20
PALLV16V8Z@SOIC20 [(SA404)]	

MICROCONTROLLER

AM87C51 [(SA244)] AM87C51@TQFP44 [(SA245A)] AM87C521 AM87C521@PLCC44 [(SA244)] [(SA245A)] AM87C541 [(SA244)] AM87C541@TQFP44 [(SA245A)]	AM87C51@PLCC44 AM87C521@TQFP44 AM87C541@PLCC44
---	--

AMI SEMICONDUCTOR

E (E) PROM/FRAM/NVRAM

N256S0818HDA [(SA602A)] N256S0818HDA@TSSOP8 [(SA026)] N256S0830HDA N256S0830HDA@SOIC8 [(SA602A)] [(SA026)] N64S0818HDA [(SA602A)] N64S0818HDA@TSSOP8 [(SA026)] N64S0830HDA N64S0830HDA@SOIC8 [(SA602A)] [(SA026)]	N256S0818HDA@SOIC8 N256S0830HDA@TSSOP8 N64S0818HDA@SOIC8 N64S0830HDA@TSSOP8
--	--

AMIC

E (E) PROM/FRAM/NVRAM

A25L010 [(SA602A)] A25L010[209mil]@SOP8 [(SA605A)] A25L016 A25L016@SOP8 [(SA023A)]	A25L010[150mil]@SOP8
--	----------------------

A25L020	
A25L020[150mil]@SOP8 [(SA602A)]	A25L020[209mil]@SOP8
[(SA605A)]	
A25L032	A25L032@SOP8
[(SA023A)]	
A25L040	A25L040@QFN8
[(SA683)]	
A25L040@SOP16 [(SA404)]	A25L040@SOP8
[(SA602A)]	
A25L05P(Bottom)	A25L05P(Bottom)@QFN8
[(SA683)]	
A25L05P(Bottom)[150mil]@SOP8 [(SA602A)]	
A25L05P(Bottom)[209mil]@SOP8 [(SA605A)]	
A25L05P(Top)	A25L05P(Top)@QFN8
[(SA683)]	
A25L05P(Top)[150mil]@SOP8 [(SA602A)]	
A25L05P(Top)[209mil]@SOP8 [(SA605A)]	
A25L080	A25L080@QFN8
[(SA683)]	
A25L080@SOP16 [(SA404)]	A25L080@SOP8
[(SA023A)]	
A25L10P(Bottom)	A25L10P(Bottom)@QFN8
[(SA683)]	
A25L10P(Bottom)[150mil]@SOP8 [(SA602A)]	
A25L10P(Bottom)[209mil]@SOP8 [(SA605A)]	
A25L10P(Top)	A25L10P(Top)@QFN8
[(SA683)]	
A25L10P(Top)[150mil]@SOP8 [(SA602A)]	
A25L10P(Top)[209mil]@SOP8 [(SA605A)]	
A25L16P(Bottom)@QFN8 [(SA683)]	
A25L16P(Bottom)@QFN8(ISP) [ISP-HEADER01]	
A25L16P(Bottom)@SOP16 [(SA404)]	
A25L16P(Bottom)@SOP16(ISP) [ISP-HEADER01]	
A25L16P(Bottom)@SOP8 [(SA023A)]	
A25L16P(Bottom)@SOP8(ISP) [ISP-HEADER01]	
A25L16P(Top)@QFN8 [(SA683)]	
A25L16P(Top)@QFN8(ISP) [ISP-HEADER01]	
A25L16P(Top)@SOP16 [(SA404)]	
A25L16P(Top)@SOP16(ISP) [ISP-HEADER01]	
A25L16P(Top)@SOP8 [(SA023A)]	
A25L16P(Top)@SOP8(ISP) [ISP-HEADER01]	
A25L20P(Bottom)	A25L20P(Bottom)@QFN8
[(SA683)]	

A25L20P(Bottom)[150mil]@SOP8 [(SA602A)]
A25L20P(Bottom)[209mil]@SOP8 [(SA605A)]
A25L20P(Top) A25L20P(Top)@QFN8
[(SA683)]
A25L20P(Top)[150mil]@SOP8 [(SA602A)]
A25L20P(Top)[209mil]@SOP8 [(SA605A)]
A25L40P(Bottom Boot)
A25L40P(Bottom Boot)@QFN8 [(SA683)]
A25L40P(Bottom Boot)@SOP16 [(SA404)]
A25L40P(Bottom Boot)@SOP8 [(SA602A)]
A25L40P(Top Boot) A25L40P(Top Boot)@QFN8
[(SA683)]
A25L40P(Top Boot)@SOP16 [(SA404)]
A25L40P(Top Boot)@SOP8 [(SA602A)]
A25L42P(Bottom Boot)
A25L42P(Bottom Boot)@QFN8 [(SA683)]
A25L42P(Bottom Boot)@SOP16 [(SA404)]
A25L42P(Bottom Boot)@SOP8 [(SA602A)]
A25L42P(Top Boot) A25L42P(Top Boot)@QFN8
[(SA683)]
A25L42P(Top Boot)@SOP16 [(SA404)]
A25L42P(Top Boot)@SOP8 [(SA602A)]
A25L512 A25L512[150mil]@SOP8
[(SA602A)]
A25L512[209mil]@SOP8 [(SA605A)]
A25L80P
A25L80P@QFN8 [(SA683)] A25L80P@SOP16
[(SA404)]
A25L80P@SOP8 [(SA023A)] A25L82P(Bottom
Boot)
A25L82P(Bottom Boot)@QFN8 [(SA683)]
A25L82P(Bottom Boot)@SOP16 [(SA404)]
A25L82P(Bottom Boot)@SOP8 [(SA023A)]
A25L82P(Top Boot) A25L82P(Top Boot)@QFN8
[(SA683)]
A25L82P(Top Boot)@SOP16 [(SA404)]
A25L82P(Top Boot)@SOP8 [(SA023A)]
A25LS080 A25LS080@QFN8
[(SA683)]
A25LS080@SOP16 [(SA404)] A25LS080@SOP8
[(SA023A)]
A27020 A27020@PLCC32
[(SA015A1T)]

A27020@TSOP32 [(SA410T)]	
A27020L	
A27020L@PLCC32 [(SA015A1T)]	A27020L@TSOP32
[(SA410T)]	
A275308	A275308@PLCC32
[(SA015A1T)]	
A276308	A276308
(E)	
A276308(E)@PLCC32 [(SA015A1T)]	A276308(E)@SOIC28
[(SA404)]	
A276308@PLCC32 [(SA015A1T)]	A276308@SOIC28
[(SA404)]	
A276308A	A276308A
(L)	
A276308A(L)@PLCC32 [(SA015A1T)]	A276308A(L)@SOIC28
[(SA404)]	
A276308A@PLCC32 [(SA015A1T)]	A276308A@SOIC28
[(SA404)]	
A277308	A277308@PLCC32
[(SA015A1T)]	
A277308A	A277308A@PLCC32
[(SA015A1T)]	
A278308	A278308@PLCC32
[(SA015A1T)]	
A278308A	A278308A
(L)	
A278308A(L)@PLCC32 [(SA015A1T)]	A278308A@PLCC32
[(SA015A1T)]	
A279308	A279308@PLCC32
[(SA015A1T)]	
A290011T	A290011T@PLCC32
[(SA015A1T)]	
A290011T@TSOP32 [(SA410T)]	
A290011U	
A290011U@PLCC32 [(SA015A1T)]	A290011U@TSOP32
[(SA410T)]	
A29001T	A29001T@PLCC32
[(SA015A1T)]	
A29001T@TSOP32 [(SA410T)]	
A29001U	
A29001U@PLCC32 [(SA015A1T)]	A29001U@TSOP32
[(SA410T)]	
A290021T	A290021T@PLCC32

[(SA015A1T)]	
A290021T@TSOP32 [(SA410T)]	
A290021U	
A290021U@PLCC32 [(SA015A1T)]	A290021U@TSOP32
[(SA410T)]	
A29002T	
A29002T@TSOP32 [(SA410T)]	A29002T@PLCC32
[(SA015A1T)]	
A29002T@TSOP32 [(SA410T)]	
A29002U	
A29002U@PLCC32 [(SA015A1T)]	A29002U@TSOP32
[(SA410T)]	
A29010	
A29010@PLCC32 [(SA015A1T)]	A29010@PLCC32
[(SA410T)]	
A29010@TSOP32 [(SA410T)]	
A29040	
A29040@PLCC32 [(SA015A1T)]	A29040@TSOP32
[(SA410T)]	
A29040A	
A29040A@PLCC32 [(SA015A1T)]	A29040A@PLCC32
[(SA410T)]	
A29040A@TSOP32 [(SA410T)]	
A29040B	
A29040B@PLCC32 [(SA015A1T)]	A29040B@TSOP32
[(SA410T)]	
A29400TM@PSOP44 [(SA638)]	A29400TV@TSOP48 [(SA247-
B005)]	
A29400UM@PSOP44 [(SA638)]	A29400UV@TSOP48 [(SA247-
B005)]	
A29512	
A29512@PLCC32 [(SA015A1T)]	A29512@PLCC32
[(SA410T)]	
A29512@TSOP32 [(SA410T)]	
A29512A	
A29512A@PLCC32 [(SA015A1T)]	A29512A@TSOP32
[(SA410T)]	
A29800TM@PSOP44 [(SA638)]	A29800TV@TSOP48 [(SA247-
B005)]	
A29800UM@PSOP44 [(SA638)]	A29800UV@TSOP48 [(SA247-
B005)]	
A29L004ATL@PLCC32 [(SA015A1T)]	A29L004ATV@TSOP32
[(SA410T)]	
A29L004ATW@TSOP40 [(SA409T)]	A29L004ATY@VSOP32
[(SA620)]	
A29L004AUL@PLCC32 [(SA015A1T)]	A29L004AUV@TSOP32
[(SA410T)]	

A29L004AUW@TSOP40 [(SA409T)] [(SA620)]	A29L004AUY@VSOP32
A29L004T@PLCC32 [(SA015A1T)] [(SA410T)]	A29L004T@TSOP32
A29L004T@TSOP40 [(SA409T)] [(SA620)]	A29L004T@VSOP32
A29L004U@PLCC32 [(SA015A1T)] [(SA410T)]	A29L004U@TSOP32
A29L004U@TSOP40 [(SA409T)] [(SA620)]	A29L004U@VSOP32
A29L008ATV@TSOP40 [(SA409T)] [(SA409T)]	A29L008AUV@TSOP40
A29L008T@TSOP40 [(SA409T)] [(SA409T)]	A29L008U@TSOP40
A29L040 [(SA015A1T)]	A29L040@PLCC32
A29L040@TSOP32 [(SA410T)] [(SA620)]	A29L040@VSOP32
A49LF004@PLCC32 [(SA015A1T)] [(SA620)]	A49LF004@VSOP32
A49LF004M@PLCC32 [(SA015A1T)] [(SA620)]	A49LF004M@VSOP32
A49LF040ATL@PLCC32 [(SA015A1T)] [(SA620)]	A49LF040ATX@VSOP32
A49LF040ATY@VSOP32 [(SA620)] [(SA015A1T)]	A49LF040TL@PLCC32
A49LF040TX@VSOP32 [(SA620)] [(SA015A1T)]	A50FW040@PLCC32
A50FW040@VSOP32 [(SA620)] [(SA015A1T)]	A50FW040M@PLCC32
A50FW040M@VSOP32 [(SA620)] [(SA015A1T)]	A50LPW040@PLCC32
A50LPW040@TSOP32 [(SA410T)]	
A617308	
A617308@TSOP32 [(SA410T)]	
A61L5308	
A61L5308@TSOP28 [(SA430T)] (M)	A623308
A623308(R)@TSOP28 [(SA430T)] [(SA430T)]	A623308(V)@TSOP28
A625308(M) [(SA430T)]	A625308(R)@TSOP28
A625308(V)@TSOP28 [(SA430T)]	

A62L256	
A62L256 (M)	A62L256 (R)@TSOP28
[(SA430T)]	
A62L256 (V)@TSOP28 [(SA430T)]	A62S6308
(M)	
A62S6308 (X)@TSOP32 [(SA410T)]	A62S7308A
(M)	
A62S7308A (X)@TSOP32 [(SA410T)]	A62S8308A
(M)	
A62S8308A (X)@TSOP32 [(SA410T)]	A62W5308
(M)	
A62W5308 (R)@TSOP28 [(SA430T)]	A62W5308 (V)@TSOP28
[(SA430T)]	

ANACHIP

E (E) PROM / FRAM / NVRAM

27CX010	27CX010@PLCC32
[(SA015A1T)]	
27CX010@TSOP32 [(SA410T)]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[(SA602A)]	
93C46A	93C46A@SOIC8
[(SA602A)]	
93C56A	93C56A@SOIC8
[(SA602A)]	
93C66A	93C66A@SOIC8
[(SA602A)]	
93CX46	93CX46@SOIC8
[(SA602A)]	
93CX56	93CX56@SOIC8
[(SA602A)]	
93CX66	93CX66@SOIC8
[(SA602A)]	

AM24LC02 [(SA602A)]	AM24LC02@SOIC8
AM24LC02@TSSOP8 [(SA026)]	
AM24LC04	
AM24LC04@SOIC8 [(SA602A)]	AM24LC04@TSSOP8
[(SA026)]	
AM24LC08	
[(SA602A)]	AM24LC08@SOIC8
AM24LC08@TSSOP8 [(SA026)]	
AM24LC16	
AM24LC16@SOIC8 [(SA602A)]	AM24LC16@TSSOP8
[(SA026)]	
AM24LC21	
[(SA602A)]	AM24LC21@SOIC8
AM24LC21@TSSOP8 [(SA026)]	
AM24LC21B	
AM24LC21B@SOIC8 [(SA602A)]	AM24LC21B@TSSOP8
[(SA026)]	
AM93LC46(08bit)	AM93LC46(08bit)@SOIC8
[(SA602A)]	
AM93LC46(08bit)@TSOP8 [(SA026)]	AM93LC46
(16bit)	
AM93LC46(16bit)@SOIC8 [(SA602A)]	AM93LC46(16bit)@TSOP8
[(SA026)]	
AM93LC56(08bit)	AM93LC56(08bit)@SOIC8
[(SA602A)]	
AM93LC56(08bit)@TSOP8 [(SA026)]	AM93LC56
(16bit)	
AM93LC56(16bit)@SOIC8 [(SA602A)]	AM93LC56(16bit)@TSOP8
[(SA026)]	
AM93LC66(08bit)	AM93LC66(08bit)@SOIC8
[(SA602A)]	
AM93LC66(08bit)@TSOP8 [(SA026)]	AM93LC66
(16bit)	
AM93LC66(16bit)@SOIC8 [(SA602A)]	AM93LC66(16bit)@TSOP8
[(SA026)]	
AM93LC86(08bit)	AM93LC86(08bit)@SOIC8
[(SA602A)]	
AM93LC86(08bit)@TSOP8 [(SA026)]	AM93LC86
(16bit)	
AM93LC86(16bit)@SOIC8 [(SA602A)]	AM93LC86(16bit)@TSOP8
[(SA026)]	

PLD

PEEL18CV8Z [(SA001A)]	PEEL18CV8Z@PLCC20
PEEL18CV8Z@SOIC20 [(SA404)] [(SA026)]	PEEL18CV8Z@TSOP20
PEEL18LV8Z [(SA001A)]	PEEL18LV8Z@PLCC20
PEEL18LV8Z@SOIC20 [(SA404)] [(SA026)]	PEEL18LV8Z@TSOP20
PEEL22CV10A [(SA008A)]	PEEL22CV10A@PLCC28
PEEL22CV10A@SOIC24 [(SA404)] [(SA026)]	PEEL22CV10A@TSOP24
PEEL22CV10A+ [(SA008A)]	PEEL22CV10A+@PLCC28
PEEL22CV10A+@SOIC24 [(SA404)] [(SA026)]	PEEL22CV10A+@TSOP24
PEEL22CV10A++ [(SA008A)]	PEEL22CV10A++@PLCC28
PEEL22CV10A++@SOIC24 [(SA404)] [(SA026)]	PEEL22CV10A++@TSOP24
PEEL22CV10AZ [(SA008A)]	PEEL22CV10AZ@PLCC28
PEEL22CV10AZ@SOIC24 [(SA404)] [(SA026)]	PEEL22CV10AZ@TSOP24
PEEL22CV10AZ+ [(SA008A)]	PEEL22CV10AZ+@PLCC28
PEEL22CV10AZ+@SOIC24 [(SA404)] [(SA026)]	PEEL22CV10AZ+@TSOP24
PEEL22CV10AZ++ [(SA008A)]	PEEL22CV10AZ++@PLCC28
PEEL22CV10AZ++@SOIC24 [(SA404)] [(SA026)]	PEEL22CV10AZ++@TSOP24
PEEL22LV10AZ [(SA008A)]	PEEL22LV10AZ@PLCC28
PEEL22LV10AZ@SOIC24 [(SA404)] [(SA026)]	PEEL22LV10AZ@TSOP24
PEEL22LV10AZ+ [(SA008A)]	PEEL22LV10AZ+@PLCC28
PEEL22LV10AZ+@SOIC24 [(SA404)] [(SA026)]	PEEL22LV10AZ+@TSOP24

PEEL22LV10AZ++
[(SA008A)]
PEEL22LV10AZ++@SOIC24 [(SA404)]
[(SA026)]

PEEL22LV10AZ++@PLCC28

PEEL22LV10AZ++@TSOP24

APLUS FLASH

E (E) PROM / FRAM / NVRAM

AF24BC01
[(SA602A)]
AF24BC01@TSSOP8 [(SA026)]
AF24BC02
AF24BC02@SOIC8 [(SA602A)]
[(SA026)]
AF24BC04
[(SA602A)]
AF24BC04@TSSOP8 [(SA026)]
AF24BC08
AF24BC08@SOIC8 [(SA602A)]
[(SA026)]
AF24BC128
[(SA602A)]
AF24BC128@TSOP8 [(SA026)]
AF24BC16
AF24BC16@SOIC8 [(SA602A)]
[(SA026)]
AF24BC256
[(SA602A)]
AF24BC256@TSOP8 [(SA026)]
AF24BC32
AF24BC32@SOIC8 [(SA602A)]
[(SA026)]
AF24BC64
[(SA602A)]
AF24BC64@TSOP8 [(SA026)]
AF24C128
AF24C128@SOIC8 [(SA602A)]
[(SA026)]
AF24C256
[(SA602A)]
AF24C256@TSOP8 [(SA026)]

AF24BC01@SOIC8

AF24BC02@TSSOP8

AF24BC04@SOIC8

AF24BC08@TSSOP8

AF24BC128@SOIC8

AF24BC16@TSSOP8

AF24BC256@SOIC8

AF24BC32@TSOP8

AF24BC64@SOIC8

AF24C128@TSOP8

AF24C256@SOIC8

AF24C32	
AF24C32@SOIC8 [(SA602A)]	AF24C32@TSOP8
[(SA026)]	
AF24C64	AF24C64@SOIC8
[(SA602A)]	
AF24C64@TSOP8 [(SA026)]	
AF25BC128	
AF25BC128@SOIC8 [(SA602A)]	AF25BC128@TSOP8
[(SA026)]	
AF25BC256	AF25BC256@SOIC8
[(SA602A)]	
AF25BC256@TSOP8 [(SA026)]	AF93BC46
(08bit)	
AF93BC46(08bit)@SOIC8 [(SA602A)]	AF93BC46(08bit)@TSOP8
[(SA026)]	
AF93BC46(16bit)	AF93BC46(16bit)@SOIC8
[(SA602A)]	
AF93BC46(16bit)@TSOP8 [(SA026)]	AF93BC56
(08bit)	
AF93BC56(08bit)@SOIC8 [(SA602A)]	AF93BC56(08bit)@TSOP8
[(SA026)]	
AF93BC56(16bit)	AF93BC56(16bit)@SOIC8
[(SA602A)]	
AF93BC56(16bit)@TSOP8 [(SA026)]	AF93BC66
(08bit)	
AF93BC66(08bit)@SOIC8 [(SA602A)]	AF93BC66(08bit)@TSOP8
[(SA026)]	
AF93BC66(16bit)	AF93BC66(16bit)@SOIC8
[(SA602A)]	
AF93BC66(16bit)@TSOP8 [(SA026)]	AF93BC86
(08bit)	
AF93BC86(08bit)@SOIC8 [(SA602A)]	AF93BC86(08bit)@TSOP8
[(SA026)]	
AF93BC86(16bit)	AF93BC86(16bit)@SOIC8
[(SA602A)]	
AF93BC86(16bit)@TSOP8 [(SA026)]	AF93C46
(08bit)	
AF93C46(08bit)@SOIC8 [(SA602A)]	AF93C46(08bit)@TSOP8
[(SA026)]	
AF93C46(16bit)	AF93C46(16bit)@SOIC8
[(SA602A)]	
AF93C46(16bit)@TSOP8 [(SA026)]	AF93C56
(08bit)	

AF93C56(08bit)@SOIC8 [(SA602A)]	AF93C56(08bit)@TSOP8
[(SA026)]	
AF93C56(16bit)	AF93C56(16bit)@SOIC8
[(SA602A)]	
AF93C56(16bit)@TSOP8 [(SA026)]	AF93C66
(08bit)	
AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8
[(SA026)]	
AF93C66(16bit)	AF93C66(16bit)@SOIC8
[(SA602A)]	
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86
(08bit)	
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8
[(SA026)]	
AF93C86(16bit)	AF93C86(16bit)@SOIC8
[(SA602A)]	
AF93C86(16bit)@TSOP8 [(SA026)]	

ARTSCHIP

E (E) PROM/FRAM/NVRAM

24AA02	24AA02@MSOP8
[(SA666)]	
24AA02@SOIC8 [(SA602A)]	24AA02@SOT5
[(SA698)]	
24AA02@TSSOP8 [(SA026)]	
24LC01A	
24LC01A@SOIC8 [(SA602A)]	24LC01A@SOT5
[(SA698)]	
24LC01A@TSSOP8 [(SA026)]	
24LC01B	
24LC01B@SOIC8 [(SA602A)]	24LC01B@SOT5
[(SA698)]	
24LC01B@TSSOP8 [(SA026)]	
24LC02A	
24LC02A@SOIC8 [(SA602A)]	24LC02A@SOT5
[(SA698)]	
24LC02A@TSSOP8 [(SA026)]	
24LC02B	
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8
[(SA602A)]	

24LC02B@SOT5 [(SA698)]	24LC02B@TSSOP8
[(SA026)]	
24LC04A	24LC04A@SOIC8
[(SA602A)]	
24LC04A@SOT5 [(SA698)]	24LC04A@TSSOP8
[(SA026)]	
24LC04B	24LC04B@MSOP8
[(SA666)]	
24LC04B@SOIC8 [(SA602A)]	24LC04B@SOT5
[(SA698)]	
24LC04B@TSSOP8 [(SA026)]	
24LC08A	
24LC08A@SOIC8 [(SA602A)]	24LC08A@SOT5
[(SA698)]	
24LC08A@TSSOP8 [(SA026)]	
24LC08B	
24LC08B@MSOP8 [(SA666)]	24LC08B@SOIC8
[(SA602A)]	
24LC08B@SOT5 [(SA698)]	24LC08B@TSSOP8
[(SA026)]	
24LC16A	24LC16A@SOIC8
[(SA602A)]	
24LC16A@SOT5 [(SA698)]	24LC16A@TSSOP8
[(SA026)]	
24LC32	24LC32@SOIC14
[(SA026)]	
24LC32@SOIC8 [(SA602A)]	24LC32@TSSOP8
[(SA026)]	
24LC64	24LC64@SOIC14
[(SA026)]	
24LC64@SOIC8 [(SA602A)]	24LC64@TSSOP8
[(SA026)]	

ASAHI KASEI(AKM)

E (E) PROM/FRAM/NVRAM

AK27CX161
 AK27CX162
 AK27CX321
 AK27CX322
 AK27CX641

AK27CX642

AK6002A(F)@SOP8 [(SA602A)]
[(SA026)]AK6003A(V)@TSSOP8 [(SA026)]
[(SA602A)]AK6004A(M)@SSOP8 [(SA605A)]
[(SA602A)]AK6010A(F)@SOP8 [(SA602A)]
[(SA602A)]AK6416A(M)@SSOP8 [(SA026)]
[(SA602A)]AK6420A(F)@SOP8 [(SA602A)]
[(SA605A)]AK6420B(H)@MSOP8 [(SA666)]
[(SA602A)]AK6440A(M)@SSOP8 [(SA605A)]
[(SA666)]AK6480A(F)@SOP8 [(SA602A)]
[(SA605A)]AK6480B(H)@MSOP8 [(SA666)]
[(SA602A)]AK6480C(H)@MSOP8 [(SA666)]
@SON8AK6480C(M)@SSOP8 [(SA605A)]
[(SA666)]AK6481C(M)@SSOP8 [(SA605A)]
[(SA666)]AK6508C(U)@USON8
@SONW8AK6510C(M)@SSOP8 [(SA026)]
@SONW8AK6512C(M)@SSOP8 [(SA026)]
[(SA602A)]AK6514C(N)@QFN20 [(SA692)]
[(SA602A)]AK93C10A(F)@SOP8 [(SA602A)]
[(SA026)]AK93C45
[(SA602A)]AK93C45A(F)@SOP8 [(SA602A)]
[(SA602A)]AK93C45A(V)@TSSOP8 [(SA026)]
[(SA666)]

AK6002A(V)@TSSOP8

AK6004A(F)@SOP8

AK6008A(F)@SOP8

AK6012A(F)@SOP8

AK6416C(F)@SOP8

AK6420A(M)@SSOP8

AK6440A(F)@SOP8

AK6440B(H)@MSOP8

AK6480A(M)@SSOP8

AK6480C(F)@SOP8

AK6480C(L)

AK6481C(H)@MSOP8

AK6508C(T)@MSOP8

AK6510C(L)

AK6512C(L)

AK6514C(F)@SOP8

AK6516C(F)@SOP8

AK93C41A(V)@TSSOP8

AK93C45(F)@SOP8

AK93C45A(NF)@SOP8

AK93C45B(H)@MSOP8

AK93C45B(L)@SON8 [(SA666)]	AK93C45C(T)@MSOP8
AK93C45C(U)@USON8	
AK93C45L	
AK93C45L(F)@SOP8 [(SA602A)]	
AK93C46	
AK93C46(F)@SOP8 [(SA602A)] [(SA602A)]	AK93C46A(F)@SOP8
AK93C46A(NF)@SOP8 [(SA602A)] [(SA026)]	AK93C46A(V)@TSSOP8
AK93C46B(H)@MSOP8 [(SA666)] @SON8	AK93C46B(L)
AK93C46C(T)@MSOP8 [(SA666)] @USON8	AK93C46C(U)
AK93C46L [(SA602A)]	AK93C46L(F)@SOP8
AK93C51A(V)@TSSOP8 [(SA026)]	
AK93C55	
AK93C55(F)@SOP8 [(SA602A)] [(SA602A)]	AK93C55A(F)@SOP8
AK93C55A(NF)@SOP8 [(SA602A)] [(SA026)]	AK93C55A(V)@TSSOP8
AK93C55B(H)@MSOP8 [(SA666)] @SON8	AK93C55B(L)
AK93C55C(T)@MSOP8 [(SA666)] @USON8	AK93C55C(U)
AK93C55L [(SA602A)]	AK93C55L(F)@SOP8
AK93C56	
AK93C56(F)@SOP8 [(SA602A)] [(SA602A)]	AK93C56(F)@SOP8
AK93C56A(V)@TSSOP8 [(SA026)] [(SA666)]	AK93C56A(NF)@SOP8
AK93C56B(L)@SON8 [(SA666)]	AK93C56B(H)@MSOP8
AK93C56C(U)@USON8	AK93C56C(T)@MSOP8
AK93C56L	
AK93C56L(F)@SOP8 [(SA602A)] [(SA026)]	AK93C61A(V)@TSSOP8
AK93C65	
AK93C65A(F)@SOP8 [(SA602A)]	AK93C65(F)@SOP8
	AK93C65A(NF)@SOP8

[(SA602A)]	
AK93C65A(V)@TSSOP8 [(SA026)]	AK93C65B(H)@MSOP8
[(SA666)]	
AK93C65B(L)@SON8	AK93C65C(T)@MSOP8
[(SA666)]	
AK93C65C(U)@USON8	
AK93C65L	
AK93C65L(F)@SOP8 [(SA602A)]	
AK93C66	
AK93C66(F)@SOP8 [(SA602A)]	AK93C66A(F)@SOP8
[(SA602A)]	
AK93C66A(NF)@SOP8 [(SA602A)]	AK93C66A(V)@TSSOP8
[(SA026)]	
AK93C66B(H)@MSOP8 [(SA666)]	AK93C66B(L)
@SON8	
AK93C66C(T)@MSOP8 [(SA666)]	AK93C66C(U)
@USON8	
AK93C66L	AK93C66L(F)@SOP8
[(SA602A)]	
AK93C75	AK93C75(F)@SOP8
[(SA602A)]	
AK93C75A(F)@SOP8 [(SA602A)]	AK93C75A(NF)@SOP8
[(SA602A)]	
AK93C75A(V)@TSSOP8 [(SA026)]	AK93C75B(H)@MSOP8
[(SA666)]	
AK93C75L	AK93C75L(F)@SOP8
[(SA602A)]	
AK93C85	AK93C85(F)@SOP8
[(SA602A)]	
AK93C85L	AK93C85L(F)@SOP8
[(SA602A)]	
AK93C95A(F)@SOP8 [(SA602A)]	AK9822(M)@SSOP8
[(SA026)]	
AK9824(M)@SSOP8 [(SA026)]	AK9844@SOIC14
[(SA602)]	

ASD

E(E) PROM/FRAM/NVRAM

AE29F1008
AE29F2008

ASI

E (E) PROM/FRAM/NVRAM

AS58C1001	AS58C1001@PLCC32
[(SA015A1T)]	
AS58C1001@SSOP32 [(SA438T)]	

ASP

MICROCONTROLLER

AP827C51	AP827C51@PLCC44
[(SA244)]	
AP827C52	AP827C52@PLCC44
[(SA244)]	
AP827C54	AP827C54@PLCC44
[(SA244)]	
AP827C58	AP827C58@PLCC44
[(SA244)]	

ATC

E (E) PROM/FRAM/NVRAM

ATC24C02	ATC24C02@SOIC8
[(SA602A)]	
ATC24C02@TSSOP8 [(SA026)]	
ATC24C04	ATC24C04@TSSOP8
ATC24C04@SOIC8 [(SA602A)]	
[(SA026)]	
ATC24C08	ATC24C08@SOIC8
[(SA602A)]	
ATC24C08@TSSOP8 [(SA026)]	
ATC24C16	ATC24C16@TSSOP8
ATC24C16@SOIC8 [(SA602A)]	
[(SA026)]	
ATC24LC02	ATC24LC02@SOIC8

[(SA602A)]	
ATC24LC02@TSSOP8 [(SA026)]	
ATC24LC02A	
ATC24LC02A@SOIC8 [(SA602A)]	ATC24LC02A@TSSOP8
[(SA026)]	
ATC24LC04	
[(SA602A)]	
ATC24LC04@TSSOP8 [(SA026)]	ATC24LC04@SOIC8
ATC24LC08	
ATC24LC08@SOIC8 [(SA602A)]	ATC24LC08@TSSOP8
[(SA026)]	
ATC24LC16	
[(SA602A)]	
ATC24LC16@TSSOP8 [(SA026)]	ATC93C46
(08bit)	
ATC93C46(08bit)@SOIC8 [(SA602A)]	ATC93C46
(16bit)	
ATC93C46(16bit)@SOIC8 [(SA602A)]	
ATC93C46R(08bit)@SOIC8 [(SA602A)]	
ATC93C46R(16bit)@SOIC8 [(SA602A)]	
ATC93C56(08bit)	ATC93C56(08bit)@SOIC8
[(SA602A)]	
ATC93C56(16bit)	ATC93C56(16bit)@SOIC8
[(SA602A)]	
ATC93C56R(08bit)@SOIC8 [(SA602A)]	
ATC93C56R(16bit)@SOIC8 [(SA602A)]	
ATC93C66(08bit)	ATC93C66(08bit)@SOIC8
[(SA602A)]	
ATC93C66(16bit)	ATC93C66(16bit)@SOIC8
[(SA602A)]	
ATC93C66R(08bit)@SOIC8 [(SA602A)]	
ATC93C66R(16bit)@SOIC8 [(SA602A)]	
ATC93LC46(08bit)	
ATC93LC46(08bit)@SOIC8 [(SA602A)]	
ATC93LC46(16bit)	
ATC93LC46(16bit)@SOIC8 [(SA602A)]	
ATC93LC46R(08bit)@SOIC8 [(SA602A)]	
ATC93LC46R(16bit)@SOIC8 [(SA602A)]	
ATC93LC56(08bit)	
ATC93LC56(08bit)@SOIC8 [(SA602A)]	
ATC93LC56(16bit)	
ATC93LC56(16bit)@SOIC8 [(SA602A)]	
ATC93LC56R(08bit)@SOIC8 [(SA602A)]	

ATC93LC56R(16bit)@SOIC8 [(SA602A)]
 ATC93LC66(08bit)
 ATC93LC66(08bit)@SOIC8 [(SA602A)]
 ATC93LC66(16bit)
 ATC93LC66(16bit)@SOIC8 [(SA602A)]
 ATC93LC66R(08bit)@SOIC8 [(SA602A)]
 ATC93LC66R(16bit)@SOIC8 [(SA602A)]

ATMEL

E(E) PROM/FRAM/NVRAM

AT17C002@PLCC20 [(SA001A)]	AT17C002@PLCC44
[(SA244)]	
AT17C002@SOIC20 [(SA404)]	AT17C002@TQFP44
[(SA245A)]	
AT17C002A@PLCC20 [(SA001A)]	AT17C002A@TQFP32
[(SA663)]	
AT17C010	AT17C010@PLCC20
[(SA001A)]	
AT17C010A	AT17C010A@PLCC20
[(SA001A)]	
AT17C040@PLCC44 [(SA244)]	AT17C040@TQFP44
[(SA245A)]	
AT17C128	AT17C128@PLCC20
[(SA001A)]	
AT17C128@SOIC20 [(SA404)]	AT17C128@SOIC8
[(SA602A)]	
AT17C128A@PLCC20 [(SA001A)]	
AT17C256	
AT17C256@PLCC20 [(SA001A)]	AT17C256@SOIC20
[(SA404)]	
AT17C256@SOIC8 [(SA602A)]	AT17C256A@PLCC20
[(SA001A)]	
AT17C512	AT17C512@PLCC20
[(SA001A)]	
AT17C512A	AT17C512A@PLCC20
[(SA001A)]	
AT17C65	AT17C65@PLCC20
[(SA001A)]	
AT17C65@SOIC20 [(SA404)]	AT17C65@SOIC8
[(SA602A)]	

AT17C65A@PLCC20 [(SA001A)]	AT17F040@LAP8
[(SA760)]	
AT17F040@PLCC20 [(SA001A)]	
AT17F040@PLCC20(Virtex Pinout) [(SA001A)]	
AT17F040A@LAP8 [(SA760)]	AT17F040A@PLCC20
[(SA001A)]	
AT17F040A@TQFP32 [(SA663)]	AT17F080@LAP8
[(SA760)]	
AT17F080@PLCC20 [(SA001A)]	AT17F080@PLCC44
[(SA244)]	
AT17F080@TQFP44 [(SA245A)]	AT17F080A@LAP8
[(SA760)]	
AT17F080A@PLCC20 [(SA001A)]	AT17F080A@TQFP32
[(SA001A)]	
AT17F16@LAP8 [(SA760)]	AT17F16@PLCC20
[(SA001A)]	
AT17F16@PLCC44 [(SA244)]	AT17F16@TQFP44
[(SA245A)]	
AT17F16A@LAP8 [(SA760)]	AT17F16A@PLCC20
[(SA001A)]	
AT17F32@PLCC44 [(SA244)]	AT17F32A@PLCC44
[(SA244)]	
AT17LV002@PLCC20 [(SA001A)]	AT17LV002@PLCC44
[(SA244)]	
AT17LV002@SOIC20 [(SA404)]	AT17LV002@TQFP44
[(SA245A)]	
AT17LV002A@PLCC20 [(SA001A)]	AT17LV002A@TQFP32
[(SA663)]	
AT17LV010	AT17LV010@PLCC20
[(SA001A)]	
AT17LV010A	AT17LV010A@PLCC20
[(SA001A)]	
AT17LV040@PLCC44 [(SA244)]	AT17LV040@TQFP44
[(SA245A)]	
AT17LV128	AT17LV128@PLCC20
[(SA001A)]	
AT17LV128@SOIC20 [(SA404)]	AT17LV128@SOIC8
[(SA602A)]	
AT17LV128A@PLCC20 [(SA001A)]	
AT17LV256	
AT17LV256@PLCC20 [(SA001A)]	AT17LV256@SOIC20
[(SA404)]	
AT17LV256@SOIC8 [(SA602A)]	AT17LV256A@PLCC20

[(SA001A)]	
AT17LV512	AT17LV512@PLCC20
[(SA001A)]	
AT17LV512A	AT17LV512A@PLCC20
[(SA001A)]	
AT17LV65	AT17LV65@PLCC20
[(SA001A)]	
AT17LV65@SOIC20 [(SA404)]	AT17LV65@SOIC8
[(SA602A)]	
AT17LV65A@PLCC20 [(SA001A)]	AT17N002@SOIC20
[(SA404)]	
AT17N002@TQFP44 [(SA245A)]	
AT17N010	
AT17N010@SOIC20 [(SA404)]	AT17N040@TQFP44
[(SA245A)]	
AT17N256	AT17N256@SOIC20
[(SA404)]	
AT17N256@SOIC8 [(SA602A)]	
AT17N512	
AT17N512@SOIC20 [(SA404)]	
AT24C01	
AT24C01@MSOP8 [(SA666)]	AT24C01@SOIC8
[(SA602A)]	
AT24C01@TSSOP8 [(SA026)]	
AT24C01A	
AT24C01A@MAP8 [(SA724)]	AT24C01A@SOIC8
[(SA602A)]	
AT24C01A@SOT23-5 [(SA717)]	AT24C01A@TSSOP8
[(SA026)]	
AT24C01B	
AT24C01B@dBGA2	
AT24C01B@MAP8 [(SA724)]	AT24C01B@SOIC8
[(SA602A)]	
AT24C01B@SOT23 [(SA717)]	AT24C01B@TSSOP8
[(SA026)]	
AT24C02	AT24C02@SOIC8
[(SA602A)]	
AT24C02@TSSOP8 [(SA026)]	
AT24C02A	
AT24C02A@SOIC8 [(SA602A)]	AT24C02A@TSSOP8
[(SA026)]	
AT24C02B	
AT24C02B@dBGA2	

AT24C02B@MAP8 [(SA724)]	AT24C02B@SOIC8
[(SA602A)]	
AT24C02B@SOT23 [(SA717)]	AT24C02B@TSSOP8
[(SA026)]	
AT24C04	AT24C04@MAP8
[(SA724)]	
AT24C04@SOIC8 [(SA602A)]	AT24C04@SOT23-5
[(SA717)]	
AT24C04@TSSOP8 [(SA026)]	
AT24C04A	
AT24C04A@MAP8 [(SA724)]	AT24C04A@SOIC8
[(SA602A)]	
AT24C04A@TSSOP8 [(SA026)]	
AT24C08	
AT24C08@MAP8 [(SA724)]	AT24C08@SOIC8
[(SA602A)]	
AT24C08@TSSOP8 [(SA026)]	
AT24C08A	
AT24C08A@MAP8 [(SA724)]	AT24C08A@SOIC8
[(SA602A)]	
AT24C08A@TSSOP8 [(SA026)]	
AT24C1024	
AT24C1024@LAP8 [(SA724)]	AT24C1024@SAP8
[(SA684)]	
AT24C1024@SOIC8 [(SA023A)]	AT24C1024B
(1.8V)	
AT24C1024B(1.8V)@LAP8 [(SA724)]	AT24C1024B(1.8V)@SAP8
[(SA684)]	
AT24C1024B(1.8V)@SOIC8 [(SA023A)]	
AT24C1024B(1.8V)@TSSOP8 [(SA026)]	
AT24C1024B(2.5V)	AT24C1024B(2.5V)@LAP8
[(SA724)]	
AT24C1024B(2.5V)@SAP8 [(SA684)]	
AT24C1024B(2.5V)@SOIC8 [(SA023A)]	
AT24C1024B(2.5V)@TSSOP8 [(SA026)]	
AT24C11	AT24C11@SOIC8
[(SA602A)]	
AT24C11@TSSOP8 [(SA026)]	AT24C128
(1.8V)	
AT24C128(1.8V)@MAP8 [(SA724)]	AT24C128(1.8V)@SAP8
[(SA683)]	
AT24C128(1.8V)@SOIC8 [(SA602A)]	AT24C128(1.8V)@TSSOP8
[(SA026)]	

AT24C128(2.7V)	AT24C128(2.7V)@MAP8
[(SA724)]	
AT24C128(2.7V)@SAP8 [(SA683)]	AT24C128(2.7V)@SOIC8
[(SA602A)]	
AT24C128(2.7V)@TSSOP8 [(SA026)]	
AT24C128B	
AT24C128B@MAP8 [(SA724)]	AT24C128B@SAP8
[(SA683)]	
AT24C128B@SOIC8 [(SA602A)]	AT24C128B@TSSOP8
[(SA026)]	
AT24C16	AT24C16@SOIC8
[(SA602A)]	
AT24C16@TSSOP8 [(SA026)]	
AT24C164	
AT24C164@SOIC8 [(SA602A)]	
AT24C16A	
AT24C16A@MAP8 [(SA724)]	AT24C16A@SOIC8
[(SA602A)]	
AT24C16A@TSSOP8 [(SA026)]	
AT24C16B	
AT24C16B@MAP8 [(SA724)]	AT24C16B@SOIC8
[(SA602A)]	
AT24C16B@TSSOP8 [(SA026)]	
AT24C21	
AT24C21@SOIC8 [(SA602A)]	AT24C256
(1.8V)	
AT24C256(1.8V)@MAP8 [(SA724)]	AT24C256(1.8V)@SAP8
[(SA683)]	
AT24C256(1.8V)@SOIC8 [(SA602A)]	AT24C256(1.8V)@TSSOP8
[(SA026)]	
AT24C256(2.7V)	AT24C256(2.7V)@MAP8
[(SA724)]	
AT24C256(2.7V)@SAP8 [(SA683)]	AT24C256(2.7V)@SOIC8
[(SA602A)]	
AT24C256(2.7V)@TSSOP8 [(SA026)]	
AT24C256B	
AT24C256B@MAP8 [(SA724)]	AT24C256B@SAP8
[(SA683)]	
AT24C256B@SOIC8 [(SA602A)]	AT24C256B@TSSOP8
[(SA026)]	
AT24C32	AT24C32@SOIC8
[(SA602A)]	
AT24C32@TSSOP8 [(SA026)]	

AT24C32A	
AT24C32A@MAP8 [(SA724)]	AT24C32A@SOIC8
[(SA602A)]	
AT24C32A@TSSOP8 [(SA026)]	
AT24C32C	
AT24C32C@dBGA8 [(BBBB)]	AT24C32C@MAP8
[(SA724)]	
AT24C32C@SAP8 [(SA683)]	AT24C32C@SOIC8
[(SA602A)]	
AT24C32C@TSSOP8 [(SA026)]	AT24C512
(1.8V)	
AT24C512(1.8V)@LAP8 [(SA684)]	AT24C512(1.8V)@SAP8
[(SA683)]	
AT24C512(1.8V)@SOIC8 [(SA602A)]	AT24C512(1.8V)@TSSOP8
[(SA026)]	
AT24C512(2.7V)	AT24C512(2.7V)@LAP8
[(SA684)]	
AT24C512(2.7V)@SAP8 [(SA683)]	AT24C512(2.7V)@SOIC8
[(SA602A)]	
AT24C512(2.7V)@TSSOP8 [(SA026)]	
AT24C512B	
AT24C512B@LAP8 [(SA684)]	AT24C512B@SAP8
[(SA683)]	
AT24C512B@SOIC8 [(SA602A)]	AT24C512B@TSSOP8
[(SA026)]	
AT24C64	AT24C64@SOIC8
[(SA602A)]	
AT24C64@TSSOP8 [(SA026)]	
AT24C64A	
AT24C64A@MAP8 [(SA724)]	AT24C64A@SOIC8
[(SA602A)]	
AT24C64A@TSSOP8 [(SA026)]	
AT24C64B	
AT24C64B@SOIC8 [(SA602A)]	AT24C64B@TSSOP8
[(SA026)]	
AT24C64C	AT24C64C@dBGA8
[(BBBB)]	
AT24C64C@MAP8 [(SA724)]	AT24C64C@SAP8
[(SA683)]	
AT24C64C@SOIC8 [(SA602A)]	AT24C64C@TSSOP8
[(SA026)]	
AT24CS128	AT24CS128@SOIC8
[(SA602A)]	

AT24HC02B [(SA602A)]	AT24HC02B@SOIC8
AT24HC02B@TSSOP8 [(SA026)] [(SA602A)]	AT24RF08AN@SOIC8
AT24RF08AT@TSSOP14 [(SA026)] [(SA602A)]	AT24RF08BN@SOIC8
AT24RF08BT@TSSOP14 [(SA026)] [(SA602A)]	AT24RF08CN@SOIC8
AT24RF08CT@TSSOP14 [(SA026)]	
AT25010 AT25010@SOIC8 [(SA602A)]	
AT25010A AT25010A@SOIC8 [(SA602A)]	AT25010A@TSSOP8
[(SA026)]	
AT25020 [(SA602A)]	AT25020@SOIC8
AT25020A [(SA602A)]	AT25020A@SOIC8
AT25020A@TSSOP8 [(SA026)]	
AT25040 AT25040(ISP) [ISP-HEADER01] [(SA602A)]	AT25040@SOIC8
AT25040@SOIC8(ISP) [ISP-HEADER01]	
AT25040A HEADER01]	AT25040A(ISP) [ISP-
AT25040A@SOIC8 [(SA602A)]	
AT25040A@SOIC8(ISP) [ISP-HEADER01]	
AT25080 [(SA602A)]	AT25080@SOIC8
AT25080@TSSOP14 [(SA026)]	AT25080@TSSOP20
[(SA026)]	
AT25080A [(SA602A)]	AT25080A@SOIC8
AT25080A@TSSOP14 [(SA026)]	
AT25080B AT25080B@dBGA8 [(BBBB)]	AT25080B@MAP8
[(SA724)]	
AT25080B@SOIC8 [(SA602A)]	AT25080B@TSSOP8
[(SA026)]	
AT25128 [(SA602)]	AT25128@SOIC16
AT25128@SOIC8 [(SA602A)]	AT25128@TSSOP14
[(SA026)]	

AT25128@TSSOP20 [(SA026)]	
AT25128A	
AT25128A@dBGA8 [(BBBB)]	AT25128A@SAP8
[(SA683)]	
AT25128A@SOIC8(4.0) [(SA602A)]	AT25128A@SOIC8(5.4)
[(SA605A)]	
AT25128A@TSSOP14 [(SA026)]	AT25128A@TSSOP8
[(SA026)]	
AT25160	AT25160@SOIC8
[(SA602A)]	
AT25160@TSSOP14 [(SA026)]	AT25160@TSSOP20
[(SA026)]	
AT25160A	AT25160A@SOIC8
[(SA602A)]	
AT25160A@TSSOP14 [(SA026)]	
AT25160B	
AT25160B@dBGA8 [(BBBB)]	AT25160B@MAP8
[(SA724)]	
AT25160B@SOIC8 [(SA602A)]	AT25160B@TSSOP8
[(SA026)]	
AT25256	AT25256@SOIC16
[(SA602)]	
AT25256@SOIC8 [(SA602A)]	AT25256@TSSOP14
[(SA026)]	
AT25256@TSSOP20 [(SA026)]	
AT25256A	
AT25256A@dBGA8 [(BBBB)]	AT25256A@SAP8
[(SA683)]	
AT25256A@SOIC8(4.0) [(SA602A)]	AT25256A@SOIC8(5.4)
[(SA605A)]	
AT25256A@TSSOP14 [(SA026)]	AT25256A@TSSOP8
[(SA026)]	
AT25320	AT25320@SOIC8
[(SA602A)]	
AT25320@TSSOP14 [(SA026)]	AT25320@TSSOP20
[(SA026)]	
AT25320A	AT25320A@SOIC8
[(SA602A)]	
AT25320A@TSSOP14 [(SA026)]	
AT25320B	
AT25320B@dBGA8 [(BBBB)]	AT25320B@MAP8
[(SA724)]	
AT25320B@SOIC8 [(SA602A)]	AT25320B@TSSOP8

[(SA026)]	
AT25640	AT25640@SOIC8
[(SA602A)]	
AT25640@TSSOP14 [(SA026)]	AT25640@TSSOP20
[(SA026)]	
AT25640A	AT25640A@SOIC8
[(SA602A)]	
AT25640A@TSSOP14 [(SA026)]	
AT25640B	
AT25640B@dBGA8 [(BBBB)]	AT25640B@MAP8
[(SA724)]	
AT25640B@SOIC8 [(SA602A)]	AT25640B@TSSOP8
[(SA026)]	
AT25DF021@SOIC8 [(SA602A)]	AT25DF021@UDFN8
[(SA683)]	
AT25DF041A@MLF8 [(SA683)]	AT25DF041A@SOIC8(4.0)
[(SA602A)]	
AT25DF041A@SOIC8(5.4) [(SA605A)]	AT25DF081@SOIC8
[(SA602A)]	
AT25DF081@UDFN8 [(SA683)]	AT25DF161@MLF8
[(SA683)]	
AT25DF161@SOIC8(4.0) [(SA602A)]	AT25DF161@SOIC8(5.4)
[(SA605A)]	
AT25DF321@SOIC16 [(SA404)]	AT25DF321@SOIC8
[(SA605A)]	
AT25DF641@SOIC16 [(SA404)]	AT25DF641@VDFN8
[(SA683)]	
AT25F1024	AT25F1024(W)@SOIC8
[(SA605A)]	
AT25F1024(W)@VQFPN8 [(SA684)]	AT25F1024@SOIC8
[(SA602A)]	
AT25F1024@VQFPN8 [(SA683)]	
AT25F1024A	
AT25F1024A(W)@SOIC8 [(SA605A)]	AT25F1024A(W)@VQFPN8
[(SA684)]	
AT25F1024A@SOIC8 [(SA602A)]	AT25F1024A@VQFPN8
[(SA683)]	
AT25F2048	AT25F2048(W)@SOIC8
[(SA605A)]	
AT25F2048(W)@VQFPN8 [(SA684)]	AT25F2048@SOIC8
[(SA602A)]	
AT25F2048@VQFPN8 [(SA683)]	
AT25F2048A	

AT25F2048A(W)@SOIC8 [(SA605A)]	AT25F2048A(W)@VQFPN8
[(SA684)]	
AT25F2048A@SOIC8 [(SA602A)]	AT25F2048A@VQFPN8
[(SA683)]	
AT25F4096	AT25F4096(W)@SOIC8
[(SA605A)]	
AT25F4096(W)@VQFPN8 [(SA684)]	AT25F4096@SOIC8
[(SA602A)]	
AT25F4096@VQFPN8 [(SA683)]	
AT25F4096A	AT25F4096A(W)@VQFPN8
AT25F4096A(W)@SOIC8 [(SA605A)]	
[(SA684)]	
AT25F4096A@SOIC8 [(SA602A)]	AT25F4096A@VQFPN8
[(SA683)]	
AT25F512	AT25F512(W)@SOIC8
[(SA605A)]	
AT25F512(W)@VQFPN8 [(SA684)]	AT25F512@SOIC8
[(SA602A)]	
AT25F512@VQFPN8 [(SA683)]	
AT25F512A	AT25F512A(W)@VQFPN8
AT25F512A(W)@SOIC8 [(SA605A)]	
[(SA684)]	
AT25F512A@SOIC8 [(SA602A)]	AT25F512A@VQFPN8
[(SA683)]	
AT25FS010@SAP8 [(SA683)]	AT25FS010@SOIC8
[(SA602A)]	
AT25FS040@SAP8 [(SA683)]	AT25FS040@SOIC8
[(SA602A)]	
AT25HP256	AT25HP256(W)@VQFPN8
[(SA684)]	
AT25HP256@SOIC16 [(SA404)]	AT25HP256@SOIC8
[(SA602A)]	
AT25HP256@VQFPN8 [(SA683)]	
AT25HP512	AT25HP512@SOIC16
AT25HP512(W)@VQFPN8 [(SA684)]	
[(SA404)]	
AT25HP512@SOIC8 [(SA602A)]	AT25HP512@VQFPN8
[(SA683)]	
AT25P1024@SOIC20 [(SA404)]	AT25P1024@VQFPN8
[(SA684)]	
AT26DF041@MLF8 [(SA683)]	AT26DF041@SOIC8(4.0)
[(SA602A)]	
AT26DF041@SOIC8(5.4) [(SA605A)]	AT26DF081@SOIC8(4.0)

[(SA602A)]	
AT26DF081@SOIC8(5.4) [(SA605A)]	AT26DF081A@SOIC8(4.0)
[(SA602A)]	
AT26DF081A@SOIC8(5.4) [(SA605A)]	AT26DF161@MLF8
[(SA683)]	
AT26DF161@SOIC8 [(SA605A)]	AT26DF161A@MLF8
[(SA683)]	
AT26DF161A@SOIC8 [(SA605A)]	AT26DF321@MLF8(5*6mm)
[(SA683)]	
AT26DF321@MLF8(6*8mm) [(SA684)]	AT26DF321@SOIC16
[(SA404)]	
AT26DF321@SOIC8 [(SA605A)]	AT26F004@MLF8
[(SA683)]	
AT26F004@SOIC8(4.0) [(SA602A)]	AT26F004@SOIC8(5.4)
[(SA605A)]	
AT27011	AT27011@PLCC32
[(SA015A1T)]	
AT27256	
AT2732A	
AT27BV010	AT27BV010@PLCC32
[(SA015A1T)]	
AT27BV010@TSOP32 [(SA620)]	
AT27BV020	
AT27BV020@PLCC32 [(SA015A1T)]	AT27BV020@TSOP32
[(SA620)]	
AT27BV040	AT27BV040@PLCC32
[(SA015A1T)]	
AT27BV040@TSOP32 [(SA620)]	AT27BV1024@PLCC44
[(SA244)]	
AT27BV1024@TSOP40 [(SA623)]	
AT27BV256	
AT27BV256@PLCC32 [(SA015A1T)]	AT27BV256@TSOP28
[(SA430T)]	
AT27BV4096	AT27BV4096@PLCC44
[(SA244)]	
AT27BV4096@TSOP40 [(SA623)]	
AT27BV512	
AT27BV512@PLCC32 [(SA015A1T)]	AT27BV512@SOIC28
[(SA630)]	
AT27BV512@TSOP28 [(SA430T)]	AT27BV520@SOIC20
[(SA404)]	
AT27BV520@TSOP28 [(SA430T)]	AT27BV520@TSSOP20
[(SA026)]	

AT27C010 [(SA015A1T)]	AT27C010@PLCC32
AT27C010@TSOP32 [(SA410T)]	
AT27C010L	
AT27C010L@PLCC32 [(SA015A1T)]	AT27C010L@TSOP32
[(SA410T)]	
AT27C020 [(SA015A1T)]	AT27C020@PLCC32
AT27C020@TSOP32 [(SA410T)]	
AT27C040	
AT27C040@PLCC32 [(SA015A1T)]	AT27C040@TSOP32
[(SA410T)]	
AT27C080 [(SA015A1T)]	AT27C080@PLCC32
AT27C080@TSOP32 [(SA410T)]	
AT27C1024	
AT27C1024@PLCC44 [(SA244)]	AT27C1024@TSOP40
[(SA623)]	
AT27C1024L	AT27C1024L@PLCC44
[(SA244)]	
AT27C128 [(SA015A1T)]	AT27C128@PLCC32
AT27C2048 [(SA244)]	AT27C2048@PLCC44
AT27C2048@TSOP40 [(SA623)]	
AT27C256	
AT27C256@PLCC32 [(SA015A1T)]	
AT27C256R	
AT27C256R@PLCC32 [(SA015A1T)]	AT27C256R@SOIC28
[(SA630)]	
AT27C256R@TSOP28 [(SA430T)]	
AT27C4096	
AT27C4096@PLCC44 [(SA244)]	AT27C4096@TSOP40
[(SA623)]	
AT27C512 [(SA015A1T)]	AT27C512@PLCC32
AT27C512R	AT27C512R@PLCC32
[(SA015A1T)]	
AT27C512R@SOIC28 [(SA630)]	AT27C512R@TSOP28
[(SA430T)]	
AT27C513 [(SA015A1T)]	AT27C513@PLCC32
AT27C513@SOIC28 [(SA630)]	

AT27C513R	
AT27C513R@PLCC32 [(SA015A1T)]	AT27C513R@SOIC28
[(SA630)]	
AT27C515	AT27C515@PLCC32
[(SA015A1T)]	
AT27C516	AT27C516@PLCC44
[(SA244)]	
AT27C516@TSOP40 [(SA623)]	AT27C520@SOIC20
[(SA404)]	
AT27C520@TSOP28 [(SA430T)]	AT27C520@TSSOP20
[(SA026)]	
AT27C64	
AT27C800	
AT27C800@PLCC44 [(SA244)]	AT27C800@PSOP44
[(SA638)]	
AT27HC1024	AT27HC1024@PLCC44
[(SA244)]	
AT27HC256	AT27HC256@PLCC32
[(SA015A1T)]	
AT27HC256L	AT27HC256L@PLCC32
[(SA015A1T)]	
AT27HC256R	AT27HC256R@PLCC32
[(SA015A1T)]	
AT27HC256RL	AT27HC256RL@PLCC32
[(SA015A1T)]	
AT27HC64	AT27HC64@PLCC32
[(SA015A1T)]	
AT27HC641	AT27HC641@PLCC28
[(SA008A)]	
AT27HC641R	AT27HC641R@PLCC28
[(SA008A)]	
AT27HC642	AT27HC642@PLCC28
[(SA008A)]	
AT27HC642R	AT27HC642R@PLCC28
[(SA008A)]	
AT27HC64L	AT27HC64L@PLCC32
[(SA015A1T)]	
AT27LV010	AT27LV010@PLCC32
[(SA015A1T)]	
AT27LV010@TSOP32 [(SA620)]	
AT27LV010A	
AT27LV010A@PLCC32 [(SA015A1T)]	AT27LV010A@TSOP32
[(SA620)]	

AT27LV020A [(SA015A1T)]	AT27LV020A@PLCC32
AT27LV020A@TSOP32 [(SA620)]	
AT27LV040 AT27LV040@PLCC32 [(SA015A1T)]	AT27LV040@TSOP32
[(SA620)]	
AT27LV040A [(SA015A1T)]	AT27LV040A@PLCC32
AT27LV040A@TSOP32 [(SA620)]	
AT27LV1024 AT27LV1024@PLCC44 [(SA244)]	
AT27LV256A AT27LV256A@PLCC32 [(SA015A1T)]	AT27LV256A@SOIC28
[(SA630)]	
AT27LV256A@TSOP28 [(SA430T)]	
AT27LV256R AT27LV256R@PLCC32 [(SA015A1T)]	AT27LV256R@SOIC28
[(SA630)]	
AT27LV256R@TSOP28 [(SA430T)]	
AT27LV4096 AT27LV4096@PLCC44 [(SA244)]	
AT27LV512A AT27LV512A@PLCC32 [(SA015A1T)]	AT27LV512A@SOIC28
[(SA630)]	
AT27LV512A@TSOP28 [(SA430T)]	
AT27LV512R AT27LV512R@PLCC32 [(SA015A1T)]	AT27LV512R@TSOP28
[(SA430T)]	
AT27LV520@SOIC20 [(SA404)]	AT27LV520@TSOP28
[(SA430T)]	
AT27LV520@TSSOP20 [(SA026)]	
AT27LV800 AT27LV800@PSOP44 [(SA638)]	
AT28BV16 AT28BV16@PLCC32 [(SA015A1T)]	AT28BV16@SOIC24
[(SA404)]	
AT28BV16@TSOP28 [(SA430T)]	
AT28BV256 AT28BV256@PLCC32 [(SA015A1T)]	AT28BV256@SOIC28
[(SA404)]	
AT28BV256@TSOP28 [(SA430T)]	
AT28BV64 AT28BV64@PLCC32 [(SA015A1T)]	AT28BV64@SOIC28

[(SA404)]	
AT28BV64@TSOP28 [(SA430T)]	
AT28BV64B	
AT28BV64B@PLCC32 [(SA015A1T)]	AT28BV64B@SOIC28
[(SA404)]	
AT28BV64B@TSOP28 [(SA430T)]	
AT28C010	
AT28C010@PLCC32 [(SA015A1T)]	AT28C010@PLCC44
[(SA244)]	
AT28C010@TSOP32 [(SA410T)]	
AT28C010E	
AT28C010E@PLCC32 [(SA015A1T)]	AT28C010E@PLCC44
[(SA244)]	
AT28C010E@TSOP32 [(SA410T)]	
AT28C04	
AT28C04@PLCC32 [(SA015A1T)]	
AT28C040	
AT28C040@PLCC32 [(SA015A1T)]	
AT28C04E	
AT28C04E@PLCC32 [(SA015A1T)]	
AT28C04F	
AT28C04F@PLCC32 [(SA015A1T)]	
AT28C16	
AT28C16@PLCC32 [(SA015A1T)]	AT28C16@SOIC24
[(SA404)]	
AT28C16@TSOP28 [(SA430T)]	
AT28C16E	
AT28C16E@PLCC32 [(SA015A1T)]	
AT28C16F	
AT28C16F@PLCC32 [(SA015A1T)]	
AT28C17	
AT28C17@PLCC32 [(SA015A1T)]	AT28C17@SOIC28
[(SA404)]	
AT28C17E	AT28C17E@PLCC32
[(SA015A1T)]	
AT28C17F	AT28C17F@PLCC32
[(SA015A1T)]	
AT28C256	AT28C256@PLCC32
[(SA015A1T)]	
AT28C256@SOIC28 [(SA404)]	AT28C256@TSOP28
[(SA430T)]	
AT28C256E	AT28C256E@PLCC32
[(SA015A1T)]	

AT28C256F [(SA015A1T)]	AT28C256F@PLCC32
AT28C64 [(SA015A1T)]	AT28C64@PLCC32
AT28C64@SOIC28 [(SA404)] [(SA430T)]	AT28C64@TSOP28
AT28C64B [(SA015A1T)]	AT28C64B@PLCC32
AT28C64B@SOIC28 [(SA404)] [(SA430T)]	AT28C64B@TSOP28
AT28C64E [(SA015A1T)]	AT28C64E@PLCC32
AT28C64E@TSOP28 [(SA430T)]	
AT28C64F AT28C64F@PLCC32 [(SA015A1T)] [(SA430T)]	AT28C64F@TSOP28
AT28C64X [(SA015A1T)]	AT28C64X@PLCC32
AT28C64X@SOIC28 [(SA404)] [(SA430T)]	AT28C64X@TSOP28
AT28HC04	
AT28HC16	
AT28HC16L	
AT28HC191	
AT28HC191L	
AT28HC256 AT28HC256@PLCC32 [(SA015A1T)] [(SA430T)]	AT28HC256@TSOP28
AT28HC256E [(SA015A1T)]	AT28HC256E@PLCC32
AT28HC256F [(SA015A1T)]	AT28HC256F@PLCC32
AT28HC256L [(SA015A1T)]	AT28HC256L@PLCC32
AT28HC256LE [(SA015A1T)]	AT28HC256LE@PLCC32
AT28HC291 [(SA008A)]	AT28HC291@PLCC28
AT28HC291L [(SA008A)]	AT28HC291L@PLCC28
AT28HC64 [(SA015A1T)]	AT28HC64@PLCC32
AT28HC64@TSOP28 [(SA430T)]	

AT28HC64B	
AT28HC64B@PLCC32 [(SA015A1T)]	AT28HC64B@SOIC28
[(SA404)]	
AT28HC64B@TSOP28 [(SA430T)]	
AT28HC64BF	
AT28HC64BF@PLCC32 [(SA015A1T)]	AT28HC64BF@SOIC28
[(SA404)]	
AT28HC64BF@TSOP28 [(SA430T)]	
AT28HC64L	
AT28HC64L@PLCC32 [(SA015A1T)]	AT28HC64L@TSOP28
[(SA430T)]	
AT28LV010	AT28LV010@PLCC32
[(SA015A1T)]	
AT28LV010@TSOP32 [(SA410T)]	
AT28LV256	
AT28LV256@PLCC32 [(SA015A1T)]	AT28LV256@TSOP28
[(SA430T)]	
AT28LV64	AT28LV64@PLCC32
[(SA015A1T)]	
AT28LV64B	AT28LV64B@PLCC32
[(SA015A1T)]	
AT28LV64B@SOIC28 [(SA404)]	AT28LV64B@TSOP28
[(SA430T)]	
AT28MC010	AT28MC010@PLCC32
[(SA015A1T)]	
AT28MC010@PLCC44 [(SA244)]	AT28MC010@TSOP32
[(SA410T)]	
AT28MC020	AT28MC020@PLCC32
[(SA015A1T)]	
AT28MC020@PLCC44 [(SA244)]	AT28MC020@TSOP32
[(SA410T)]	
AT28MC040	AT28MC040@PLCC32
[(SA015A1T)]	
AT28MC040@PLCC44 [(SA244)]	AT28MC040@TSOP32
[(SA410T)]	
AT28PC64	AT28PC64@PLCC32
[(SA015A1T)]	
AT28PC64@TSOP28 [(SA430T)]	
AT28PC64E	
AT28PC64E@PLCC32 [(SA015A1T)]	AT28PC64E@TSOP28
[(SA430T)]	
AT29BV010A@PLCC32 [(SA015A1T)]	AT29BV010A@TSOP32
[(SA410T)]	

AT29BV020@PLCC32 [(SA015A1T)]	AT29BV020@TSOP32
[(SA410T)]	
AT29BV040A@TSOP32 [(SA410T)]	
AT29C010	
AT29C010@PLCC32 [(SA015A1T)]	AT29C010@TSOP32
[(SA410T)]	
AT29C010A	AT29C010A@PLCC32
[(SA015A1T)]	
AT29C010A@TSOP32 [(SA410T)]	
AT29C020	
AT29C020@PLCC32 [(SA015A1T)]	AT29C020@TSOP32
[(SA410T)]	
AT29C040	AT29C040@PLCC32
[(SA015A1T)]	
AT29C040@TSOP32 [(SA410T)]	
AT29C040A	
AT29C040A@PLCC32 [(SA015A1T)]	AT29C040A@TSOP32
[(SA410T)]	
AT29C1024@PLCC44 [(SA244)]	AT29C1024@TSOP48 [(SA247-
B005)]	
AT29C256	AT29C256@PLCC32
[(SA015A1T)]	
AT29C256@TSOP28 [(SA430T)]	
AT29C257	
AT29C257@PLCC32 [(SA015A1T)]	
AT29C512	
AT29C512@PLCC32 [(SA015A1T)]	AT29C512@TSOP32
[(SA410T)]	
AT29LV010	AT29LV010@PLCC32
[(SA015A1T)]	
AT29LV010@TSOP32 [(SA410T)]	AT29LV010A@PLCC32
[(SA015A1T)]	
AT29LV010A@TSOP32 [(SA410T)]	
AT29LV020	
AT29LV020@PLCC32 [(SA015A1T)]	AT29LV020@TSOP32
[(SA410T)]	
AT29LV040@TSOP32 [(SA410T)]	
AT29LV040A	
AT29LV040A@PLCC32 [(SA015A1T)]	AT29LV040A@TSOP32
[(SA410T)]	
AT29LV1024@PLCC44 [(SA244)]	AT29LV1024@TSOP48 [(SA247-
B005)]	
AT29LV256	AT29LV256@PLCC32

[(SA015A1T)]	
AT29LV256@TSOP28 [(SA430T)]	
AT29LV512	
AT29LV512@PLCC32 [(SA015A1T)]	AT29LV512@TSOP32
[(SA410T)]	
AT32C16	AT32C16@PLCC44
[(SA244)]	
AT34C02	AT34C02@SOIC8
[(SA602A)]	
AT34C02@TSSOP8 [(SA026)]	
AT34C02B	
AT34C02B@SOIC8 [(SA602A)]	AT34C02B@TSSOP8
[(SA026)]	
AT34C02C	AT34C02C@dBGA8
[(BBBB)]	
AT34C02C@MAP8 [(SA724)]	AT34C02C@SOIC8
[(SA602A)]	
AT34C02C@TSSOP8 [(SA026)]	
AT45BCM021D(page256)@SOIC8 [(SA605A)]	
AT45BCM021D(page256)@SOIC8(ISP) [ISP-HEADER01]	
AT45BCM021D(page264)@SOIC8 [(SA605A)]	
AT45BCM021D(page264)@SOIC8(ISP) [ISP-HEADER01]	
AT45D011@PLCC32 [(SA015A1T)]	AT45D011@SOIC8
[(SA605A)]	
AT45D011@TSSOP14 [(SA026)]	AT45D021@PLCC32
[(SA015A1T)]	
AT45D021@SOIC28 [(SA630)]	AT45D021@TSOP28
[(SA430T)]	
AT45D041@PLCC32 [(SA015A1T)]	AT45D041@SOIC28
[(SA630)]	
AT45D041@TSOP28 [(SA430T)]	AT45D081@SOIC28
[(SA630)]	
AT45D081@TSOP32 [(SA410T)]	AT45D161@PLCC32
[(SA015A1T)]	
AT45D161@SOIC28 [(SA630)]	AT45D161@TSOP28
[(SA430T)]	
AT45DB011@PLCC32 [(SA015A1T)]	AT45DB011@SOIC8
[(SA605A)]	
AT45DB011@TSSOP14 [(SA026)]	AT45DB011B@PLCC32
[(SA015A1T)]	
AT45DB011B@PLCC32(ISP) [ISP-HEADER01]	
AT45DB011B@SOIC8 [(SA605A)]	
AT45DB011B@SOIC8(ISP) [ISP-HEADER01]	

AT45DB011B@TSSOP14 [(SA026)]
 AT45DB011B@TSSOP14(ISP) [ISP-HEADER01]
 AT45DB011D(page264)@QFN8 [(SA683)]
 AT45DB011D(page264)@QFN8(ISP) [ISP-HEADER01]
 AT45DB011D(page264)@SOIC8 [(SA023A)]
 AT45DB011D(page264)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB021@PLCC32 [(SA015A1T)] AT45DB021@SOIC28
 [(SA630)]
 AT45DB021@TSOP28 [(SA430T)] AT45DB021A@PLCC32
 [(SA015A1T)]
 AT45DB021A@PLCC32(ISP) [ISP-HEADER01]
 AT45DB021A@SOIC28 [(SA630)]
 AT45DB021A@SOIC28(ISP) [ISP-HEADER01]
 AT45DB021A@TSOP28 [(SA430T)]
 AT45DB021A@TSOP28(ISP) [ISP-HEADER01]
 AT45DB021B@CBGA9 [(SA677A-B089A-K080F001N)]
 AT45DB021B@CBGA9(ISP) [ISP-HEADER01]
 AT45DB021B@SOIC28 [(SA630)]
 AT45DB021B@SOIC28(ISP) [ISP-HEADER01]
 AT45DB021B@SOIC8 [(SA023A)]
 AT45DB021B@SOIC8(ISP) [ISP-HEADER01]
 AT45DB021B@TSOP28 [(SA430T)]
 AT45DB021B@TSOP28(ISP) [ISP-HEADER01]
 AT45DB021D6(page264)@CASON8 [(SA683)]
 AT45DB021D6(page264)@CASON8(ISP) [ISP-HEADER01]
 AT45DB021D6(page264)@SOIC8 [(SA023A)]
 AT45DB021D6(page264)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB041@PLCC32 [(SA015A1T)] AT45DB041@SOIC28
 [(SA630)]
 AT45DB041@TSOP28 [(SA430T)] AT45DB041A@PLCC32
 [(SA015A1T)]
 AT45DB041A@PLCC32(ISP) [ISP-HEADER01]
 AT45DB041A@SOIC28 [(SA630)]
 AT45DB041A@SOIC28(ISP) [ISP-HEADER01]
 AT45DB041A@TSOP28 [(SA430T)]
 AT45DB041A@TSOP28(ISP) [ISP-HEADER01]
 AT45DB041B@CASON8 [(SA684)] AT45DB041B@CASON8(ISP)
 [(SA684)]
 AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]
 AT45DB041B@CBGA14(ISP) [ISP-HEADER01]
 AT45DB041B@SOIC28 [(SA630)]
 AT45DB041B@SOIC28(ISP) [ISP-HEADER01]
 AT45DB041B@SOIC8 [(SA605A)]

AT45DB041B@SOIC8(ISP) [ISP-HEADER01]
AT45DB041B@TSOP28 [(SA430T)]
AT45DB041B@TSOP28(ISP) [ISP-HEADER01]
AT45DB041D(page256)@QFN8 [(SA683)]
AT45DB041D(page256)@QFN8(ISP) [ISP-HEADER01]
AT45DB041D(page256)@SOIC8 [(SA605A)]
AT45DB041D(page256)@SOIC8(ISP) [ISP-HEADER01]
AT45DB041D(page264)@QFN8 [(SA683)]
AT45DB041D(page264)@QFN8(ISP) [ISP-HEADER01]
AT45DB041D(page264)@SOIC8 [(SA605A)]
AT45DB041D(page264)@SOIC8(ISP) [ISP-HEADER01]
AT45DB081@SOIC28 [(SA630)] AT45DB081@TSOP32
[(SA410T)]
AT45DB081A@PLCC32 [(SA015A1T)]
AT45DB081A@PLCC32(ISP) [ISP-HEADER01]
AT45DB081A@SOIC28 [(SA630)]
AT45DB081A@SOIC28(ISP) [ISP-HEADER01]
AT45DB081A@TSOP28 [(SA430T)]
AT45DB081A@TSOP28(ISP) [ISP-HEADER01]
AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8(ISP)
[(SA684)]
AT45DB081B@CBGA14 [(SA677A-B089A-K080F001N)]
AT45DB081B@CBGA14(ISP) [ISP-HEADER01]
AT45DB081B@SOIC28 [(SA630)]
AT45DB081B@SOIC28(ISP) [ISP-HEADER01]
AT45DB081B@SOIC8 [(SA605A)]
AT45DB081B@SOIC8(ISP) [ISP-HEADER01]
AT45DB081B@TSOP28 [(SA430T)]
AT45DB081B@TSOP28(ISP) [ISP-HEADER01]
AT45DB081D(page256)@MLF8 [(SA683)]
AT45DB081D(page256)@QFN8(ISP) [ISP-HEADER01]
AT45DB081D(page256)@SOIC8 [(SA023A)]
AT45DB081D(page256)@SOIC8(ISP) [ISP-HEADER01]
AT45DB081D(page264)@MLF8 [(SA683)]
AT45DB081D(page264)@QFN8(ISP) [ISP-HEADER01]
AT45DB081D(page264)@SOIC8 [(SA023A)]
AT45DB081D(page264)@SOIC8(ISP) [ISP-HEADER01]
AT45DB161@PLCC32 [(SA015A1T)] AT45DB161@SOIC28
[(SA630)]
AT45DB161@TSOP28 [(SA430T)]
AT45DB161B@CASON8(ISP) [ISP-HEADER01]
AT45DB161B@CASON8 [(SA684)] AT45DB161B@SOIC28
[(SA630)]

AT45DB161B@SOIC28 (ISP) [ISP-HEADER01]
AT45DB161B@TSOP28 [(SA430T)]
AT45DB161B@TSOP28 (ISP) [ISP-HEADER01]
AT45DB161D(page512)@QFN8 [(SA683)]
AT45DB161D(page512)@QFN8 (ISP) [ISP-HEADER01]
AT45DB161D(page512)@SOIC8 [(SA605A)]
AT45DB161D(page512)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB161D(page512)@TSOP28 [(SA430T)]
AT45DB161D(page512)@TSOP28 (ISP) [ISP-HEADER01]
AT45DB161D(page528)@QFN8 [(SA683)]
AT45DB161D(page528)@QFN8 (ISP) [ISP-HEADER01]
AT45DB161D(page528)@SOIC8 [(SA605A)]
AT45DB161D(page528)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB161D(page528)@TSOP28 [(SA430T)]
AT45DB161D(page528)@TSOP28 (ISP) [ISP-HEADER01]
AT45DB321@TSOP32 [(SA410T)] AT45DB321B@SOIC28
[(SA630)]
AT45DB321B@SOIC28 (ISP) [ISP-HEADER01]
AT45DB321B@TSOP32 [(SA410T)]
AT45DB321B@TSOP32 (ISP) [ISP-HEADER01]
AT45DB321C@CAS0N8 [(SA684)]
AT45DB321C@CAS0N8 (ISP) [ISP-HEADER01]
AT45DB321C@SOIC28 [(SA630)]
AT45DB321C@SOIC28 (ISP) [ISP-HEADER01]
AT45DB321C@TSOP28 [(SA430T)]
AT45DB321C@TSOP28 (ISP) [ISP-HEADER01]
AT45DB321D(page512)@QFN8 [(SA683)]
AT45DB321D(page512)@QFN8 (ISP) [ISP-HEADER01]
AT45DB321D(page512)@SOIC8 [(SA023A)]
AT45DB321D(page512)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB321D(page512)@TSOP28 [(SA430T)]
AT45DB321D(page512)@TSOP28 (ISP) [ISP-HEADER01]
AT45DB321D(page528)@QFN8 [(SA683)]
AT45DB321D(page528)@QFN8 (ISP) [ISP-HEADER01]
AT45DB321D(page528)@SOIC8 [(SA023A)]
AT45DB321D(page528)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB321D(page528)@TSOP28 [(SA430T)]
AT45DB321D(page528)@TSOP28 (ISP) [ISP-HEADER01]
AT45DB642@TSOP40 [(SA409T)]
AT45DB642@TSOP40 (ISP) [ISP-HEADER01]
AT45DB642D(page1024)@CAS0N8 [(SA684)]
AT45DB642D(page1024)@CAS0N8 (ISP) [(ISP-HEADER01)]
AT45DB642D(page1024)@TSOP28 [(SA430)]

```

AT45DB642D(page1024)@TSOP28(ISP) [(ISP-HEADER01)]
AT45DB642D(page1056)@CAS0N8 [(SA684)]
AT45DB642D(page1056)@CAS0N8(ISP) [(ISP-HEADER01)]
AT45DB642D(page1056)@TSOP28 [(SA430)]
AT45DB642D(page1056)@TSOP28(ISP) [(ISP-HEADER01)]
AT45DCB008D4(page1024) [(CARD005-B005)]
AT45DCB008D4(page1024)(ISP) [(ISP-HEADER01)]
AT45DCB008D6(page1056) [(CARD005-B005)]
AT45DCB008D6(page1056)(ISP) [(ISP-HEADER01)]
AT49BV001 AT49BV001@PLCC32
[(SA015A1T)]
AT49BV001@TSOP32 [(SA410T)] AT49BV001@VSOP32
[(SA620)]
AT49BV001A AT49BV001A@PLCC32
[(SA015A1T)]
AT49BV001A@TSOP32 [(SA410T)] AT49BV001A@VSOP32
[(SA620)]
AT49BV001AN AT49BV001AN@PLCC32
[(SA015A1T)]
AT49BV001AN@TSOP32 [(SA410T)] AT49BV001AN@VSOP32
[(SA620)]
AT49BV001ANT AT49BV001ANT@PLCC32
[(SA015A1T)]
AT49BV001ANT@TSOP32 [(SA410T)] AT49BV001ANT@VSOP32
[(SA620)]
AT49BV001AT AT49BV001AT@PLCC32
[(SA015A1T)]
AT49BV001AT@TSOP32 [(SA410T)] AT49BV001AT@VSOP32
[(SA620)]
AT49BV001N AT49BV001N@PLCC32
[(SA015A1T)]
AT49BV001N@TSOP32 [(SA410T)] AT49BV001N@VSOP32
[(SA620)]
AT49BV001NT AT49BV001NT@PLCC32
[(SA015A1T)]
AT49BV001NT@TSOP32 [(SA410T)] AT49BV001NT@VSOP32
[(SA620)]
AT49BV001T AT49BV001T@PLCC32
[(SA015A1T)]
AT49BV001T@TSOP32 [(SA410T)] AT49BV001T@VSOP32
[(SA620)]
AT49BV002 AT49BV002@PLCC32
[(SA015A1T)]

```

AT49BV002@TSOP32 [(SA410T)]	AT49BV002@VSOP32
[(SA620)]	
AT49BV002A	AT49BV002A@PLCC32
[(SA015A1T)]	
AT49BV002A@TSOP32 [(SA410T)]	AT49BV002A@VSOP32
[(SA620)]	
AT49BV002AN	AT49BV002AN@PLCC32
[(SA015A1T)]	
AT49BV002AN@TSOP32 [(SA410T)]	AT49BV002AN@VSOP32
[(SA620)]	
AT49BV002ANT	AT49BV002ANT@PLCC32
[(SA015A1T)]	
AT49BV002ANT@TSOP32 [(SA410T)]	AT49BV002ANT@VSOP32
[(SA620)]	
AT49BV002AT	AT49BV002AT@PLCC32
[(SA015A1T)]	
AT49BV002AT@TSOP32 [(SA410T)]	AT49BV002AT@VSOP32
[(SA620)]	
AT49BV002N	AT49BV002N@PLCC32
[(SA015A1T)]	
AT49BV002N@TSOP32 [(SA410T)]	AT49BV002N@VSOP32
[(SA620)]	
AT49BV002NT	AT49BV002NT@PLCC32
[(SA015A1T)]	
AT49BV002NT@TSOP32 [(SA410T)]	AT49BV002NT@VSOP32
[(SA620)]	
AT49BV002T	AT49BV002T@PLCC32
[(SA015A1T)]	
AT49BV002T@TSOP32 [(SA410T)]	AT49BV002T@VSOP32
[(SA620)]	
AT49BV010	AT49BV010@PLCC32
[(SA015A1T)]	
AT49BV010@TSOP32 [(SA410T)]	
AT49BV020	AT49BV020@TSOP32
AT49BV020@PLCC32 [(SA015A1T)]	
[(SA410T)]	
AT49BV040	AT49BV040@PLCC32
[(SA015A1T)]	
AT49BV040@TSOP32 [(SA410T)]	AT49BV040A@PLCC32
[(SA015A1T)]	
AT49BV040A@TSOP32 [(SA410T)]	AT49BV040A@VSOP32
[(SA620)]	
AT49BV040B@PLCC32 [(SA015A1T-B001)]	

AT49BV040B@TSOP32 [(SA410T-B003)]	
AT49BV040B@VSOP32 [(SA620-B005)]	
AT49BV040T	
AT49BV040T@PLCC32 [(SA015A1T)]	AT49BV040T@TSOP32
[(SA410T)]	
AT49BV080@PSOP44 [(SA638)]	AT49BV080@TSOP40
[(SA409T)]	
AT49BV080T@PSOP44 [(SA638)]	AT49BV080T@TSOP40
[(SA409T)]	
AT49BV1024A@TSOP40 [(SA623)]	AT49BV1614@TSOP48 [(SA247-
B005)]	
AT49BV1614A@TSOP48 [(SA247-B005)]	
AT49BV1614AT@TSOP48 [(SA247-B005)]	
AT49BV1614T@TSOP48 [(SA247-B005)]	
AT49BV2048@PSOP44 [(SA638)]	AT49BV2048@TSOP48 [(SA247-
B005)]	
AT49BV2048A@PSOP44 [(SA638)]	
AT49BV2048A@TSOP48 [(SA247-B005)]	
AT49BV2048B@TSOP48 [(SA247-B005)]	
AT49BV512	AT49BV512@PLCC32
[(SA015A1T)]	
AT49BV512@TSOP32 [(SA410T)]	AT49BV512@VSOP32
[(SA620)]	
AT49F001	AT49F001@PLCC32
[(SA015A1T)]	
AT49F001@TSOP32 [(SA410T)]	AT49F001@VSOP32
[(SA620)]	
AT49F001A	AT49F001A@PLCC32
[(SA015A1T)]	
AT49F001A@TSOP32 [(SA410T)]	AT49F001A@VSOP32
[(SA620)]	
AT49F001AN	AT49F001AN@PLCC32
[(SA015A1T)]	
AT49F001AN@TSOP32 [(SA410T)]	AT49F001AN@VSOP32
[(SA620)]	
AT49F001ANT	AT49F001ANT@PLCC32
[(SA015A1T)]	
AT49F001ANT@TSOP32 [(SA410T)]	AT49F001ANT@VSOP32
[(SA620)]	
AT49F001AT	AT49F001AT@PLCC32
[(SA015A1T)]	
AT49F001AT@TSOP32 [(SA410T)]	AT49F001AT@VSOP32
[(SA620)]	

AT49F001N [(SA015A1T)]	AT49F001N@PLCC32
AT49F001N@TSOP32 [(SA410T)] [(SA620)]	AT49F001N@VSOP32
AT49F001NT [(SA015A1T)]	AT49F001NT@PLCC32
AT49F001NT@TSOP32 [(SA410T)] [(SA620)]	AT49F001NT@VSOP32
AT49F001T [(SA015A1T)]	AT49F001T@PLCC32
AT49F001T@TSOP32 [(SA410T)] [(SA620)]	AT49F001T@VSOP32
AT49F002 [(SA015A1T)]	AT49F002@PLCC32
AT49F002@TSOP32 [(SA410T)] [(SA620)]	AT49F002@VSOP32
AT49F002A [(SA015A1T)]	AT49F002A@PLCC32
AT49F002A@TSOP32 [(SA410T)] [(SA620)]	AT49F002A@VSOP32
AT49F002AN [(SA015A1T)]	AT49F002AN@PLCC32
AT49F002AN@TSOP32 [(SA410T)] [(SA620)]	AT49F002AN@VSOP32
AT49F002ANT [(SA015A1T)]	AT49F002ANT@PLCC32
AT49F002ANT@TSOP32 [(SA410T)] [(SA620)]	AT49F002ANT@VSOP32
AT49F002AT [(SA015A1T)]	AT49F002AT@PLCC32
AT49F002AT@TSOP32 [(SA410T)] [(SA620)]	AT49F002AT@VSOP32
AT49F002N [(SA015A1T)]	AT49F002N@PLCC32
AT49F002N@TSOP32 [(SA410T)] [(SA620)]	AT49F002N@VSOP32
AT49F002NT [(SA015A1T)]	AT49F002NT@PLCC32
AT49F002NT@TSOP32 [(SA410T)] [(SA620)]	AT49F002NT@VSOP32
AT49F002T [(SA015A1T)]	AT49F002T@PLCC32
AT49F002T@TSOP32 [(SA410T)]	AT49F002T@VSOP32

[(SA620)]	
AT49F008@TSOP40 [(SA409T)]	AT49F008A@TSOP40
[(SA409T)]	
AT49F008AT@TSOP40 [(SA409T)]	
AT49F010	
AT49F010@PLCC32 [(SA015A1T)]	AT49F010@TSOP32
[(SA410T)]	
AT49F020	AT49F020@PLCC32
[(SA015A1T)]	
AT49F020@TSOP32 [(SA410T)]	
AT49F040	
AT49F040@PLCC32 [(SA015A1T)]	AT49F040@TSOP32
[(SA410T)]	
AT49F040A	AT49F040A@PLCC32
[(SA015A1T)]	
AT49F040A@TSOP32 [(SA410T)]	AT49F080@PSOP44
[(SA638)]	
AT49F080@TSOP40 [(SA409T)]	AT49F080T@PSOP44
[(SA638)]	
AT49F080T@TSOP40 [(SA409T)]	AT49F1024@TSOP40
[(SA623)]	
AT49F1024A@TSOP40 [(SA623)]	AT49F1025@PLCC44
[(SA244)]	
AT49F1614@TSOP48 [(SA247-B005)]	AT49F1614T@TSOP48 [(SA247-B005)]
AT49F2048@PSOP44 [(SA638)]	AT49F2048@TSOP48 [(SA247-B005)]
AT49F2048A@PSOP44 [(SA638)]	AT49F2048A@TSOP48 [(SA247-B005)]
AT49F4096@PSOP44 [(SA638)]	AT49F4096@TSOP48 [(SA247-B005)]
AT49F4096A@PSOP44 [(SA638)]	AT49F4096A@TSOP48 [(SA247-B005)]
AT49F512	AT49F512@PLCC32
[(SA015A1T)]	
AT49F512@TSOP32 [(SA410T)]	AT49F512@VSOP32
[(SA620)]	
AT49F516@PLCC44 [(SA244)]	AT49F516@TSOP40
[(SA623)]	
AT49F8192@PSOP44 [(SA638)]	AT49F8192@TSOP48 [(SA247-B005)]
AT49F8192A@PSOP44 [(SA638)]	AT49F8192A@TSOP48 [(SA247-B005)]

AT49F8192AT@PSOP44 [(SA638)]	
AT49F8192AT@TSOP48 [(SA247-B005)]	
AT49F8192T@PSOP44 [(SA638)]	AT49F8192T@TSOP48 [(SA247-
B005)]	
AT49HBV010	AT49HBV010@PLCC32
[(SA015A1T)]	
AT49HBV010@TSOP32 [(SA410T)]	
AT49HF010	
AT49HF010@PLCC32 [(SA015A1T)]	AT49HF010@TSOP32
[(SA410T)]	
AT49HLV010	AT49HLV010@PLCC32
[(SA015A1T)]	
AT49HLV010@TSOP32 [(SA410T)]	AT49LH002@PLCC32
[(SA015A1T)]	
AT49LH002@TSOP40 [(SA409T)]	AT49LH004@PLCC32
[(SA015A1T)]	
AT49LH004@TSOP40 [(SA409T)]	AT49LH00B4@PLCC32
[(SA015A1T)]	
AT49LH00B4@TSOP40 [(SA409T)]	AT49LL020@PLCC32
[(SA015A1T)]	
AT49LL020@TSOP40 [(SA409T)]	AT49LL040@PLCC32
[(SA015A1T)]	
AT49LL040@TSOP40 [(SA409T)]	AT49LL080@PLCC32
[(SA015A1T)]	
AT49LL080@TSOP40 [(SA409T)]	
AT49LV001	
AT49LV001@PLCC32 [(SA015A1T)]	AT49LV001@TSOP32
[(SA410T)]	
AT49LV001@VSOP32 [(SA620)]	
AT49LV001N	
AT49LV001N@PLCC32 [(SA015A1T)]	AT49LV001N@TSOP32
[(SA410T)]	
AT49LV001N@VSOP32 [(SA620)]	
AT49LV001NT	
AT49LV001NT@PLCC32 [(SA015A1T)]	AT49LV001NT@TSOP32
[(SA410T)]	
AT49LV001NT@VSOP32 [(SA620)]	
AT49LV001T	
AT49LV001T@PLCC32 [(SA015A1T)]	AT49LV001T@TSOP32
[(SA410T)]	
AT49LV001T@VSOP32 [(SA620)]	
AT49LV002	
AT49LV002@PLCC32 [(SA015A1T)]	AT49LV002@TSOP32

[(SA410T)]	
AT49LV002@VSOP32 [(SA620)]	
AT49LV002N	
AT49LV002N@PLCC32 [(SA015A1T)]	AT49LV002N@TSOP32
[(SA410T)]	
AT49LV002N@VSOP32 [(SA620)]	
AT49LV002NT	
AT49LV002NT@PLCC32 [(SA015A1T)]	AT49LV002NT@TSOP32
[(SA410T)]	
AT49LV002NT@VSOP32 [(SA620)]	
AT49LV002T	
AT49LV002T@PLCC32 [(SA015A1T)]	AT49LV002T@TSOP32
[(SA410T)]	
AT49LV002T@VSOP32 [(SA620)]	
AT49LV010	
AT49LV010@PLCC32 [(SA015A1T)]	AT49LV010@TSOP32
[(SA410T)]	
AT49LV020	AT49LV020@PLCC32
[(SA015A1T)]	
AT49LV020@TSOP32 [(SA410T)]	
AT49LV040	
AT49LV040@PLCC32 [(SA015A1T)]	AT49LV040@TSOP32
[(SA410T)]	
AT49LV040T	AT49LV040T@PLCC32
[(SA015A1T)]	
AT49LV040T@TSOP32 [(SA410T)]	AT49LV080@PSOP44
[(SA638)]	
AT49LV080@TSOP40 [(SA409T)]	AT49LV080T@PSOP44
[(SA638)]	
AT49LV080T@TSOP40 [(SA409T)]	AT49LV1024@TSOP40
[(SA623)]	
AT49LV1024A@TSOP40 [(SA623)]	AT49LV1025@PLCC44
[(SA244)]	
AT49LV1614@TSOP48 [(SA247-B005)]	
AT49LV1614A@TSOP48 [(SA247-B005)]	
AT49LV1614AT@TSOP48 [(SA247-B005)]	
AT49LV1614T@TSOP48 [(SA247-B005)]	
AT49LV2048@PSOP44 [(SA638)]	AT49LV2048@TSOP48 [(SA247-
B005)]	
AT49LV2048A@PSOP44 [(SA638)]	
AT49LV2048A@TSOP48 [(SA247-B005)]	
AT49LV2048B@TSOP48 [(SA247-B005)]	
AT49LW040@PLCC32 [(SA015A1T)]	AT49LW040@TSOP40

[(SA409T)]	
AT49LW080@PLCC32 [(SA015A1T)]	AT49LW080@TSOP40
[(SA409T)]	
AT59C11	AT59C11@SOIC8
[(SA602A)]	
AT59C12	AT59C12@SOIC8
[(SA602A)]	
AT59C13	AT59C13@SOIC8
[(SA602A)]	
AT59C22	AT59C22@SOIC8
[(SA602A)]	
AT93C46(08bit)	AT93C46(08bit)@SOIC8
[(SA602A)]	
AT93C46(08bit)@TSSOP8 [(SA026)]	AT93C46
(16bit)	
AT93C46(16bit)@SOIC8 [(SA602A)]	AT93C46(16bit)@TSSOP8
[(SA026)]	
AT93C46A	AT93C46A@SOIC8
[(SA602A)]	
AT93C46A@TSSOP8 [(SA026)]	
AT93C46C	
AT93C46C@SOIC8 [(SA602A)]	AT93C46C@TSSOP8
[(SA026)]	
AT93C46D(08bit)	AT93C46D(08bit)@dBGA8
[(BBBB)]	
AT93C46D(08bit)@MAP8 [(SA724)]	AT93C46D(08bit)@SOIC8
[(SA602A)]	
AT93C46D(08bit)@TSSOP8 [(SA026)]	AT93C46D
(16bit)	
AT93C46D(16bit)@dBGA8 [(BBBB)]	AT93C46D(16bit)@MAP8
[(SA724)]	
AT93C46D(16bit)@SOIC8 [(SA602A)]	AT93C46D(16bit)@TSSOP8
[(SA026)]	
AT93C46E	AT93C46E@SOIC8
[(SA602A)]	
AT93C46E@TSSOP8 [(SA026)]	AT93C56
(08bit)	
AT93C56(08bit)@SOIC8 [(SA602A)]	AT93C56
(16bit)	
AT93C56(16bit)@SOIC8 [(SA602A)]	AT93C56A
(08bit)	
AT93C56A(08bit)@SOIC8 [(SA602A)]	AT93C56A(08bit)@TSSOP8
[(SA026)]	

AT93C56A(16bit) [(SA602A)]	AT93C56A(16bit)@SOIC8
AT93C56A(16bit)@TSSOP8 [(SA026)]	
AT93C57	
AT93C57@SOIC8 [(SA602A)] (08bit)	AT93C66
AT93C66(08bit)@SOIC8 [(SA602A)] (16bit)	AT93C66
AT93C66(16bit)@SOIC8 [(SA602A)] (08bit)	AT93C66A
AT93C66A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C66A(08bit)@TSSOP8
AT93C66A(16bit) [(SA602A)]	AT93C66A(16bit)@SOIC8
AT93C66A(16bit)@TSSOP8 [(SA026)] (08bit)	AT93C86
AT93C86(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C86(08bit)@TSSOP8
AT93C86(16bit) [(SA602A)]	AT93C86(16bit)@SOIC8
AT93C86(16bit)@TSSOP8 [(SA026)] (08bit)	AT93C86A
AT93C86A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C86A(08bit)@TSSOP8
AT93C86A(16bit) [(SA602A)]	AT93C86A(16bit)@SOIC8
AT93C86A(16bit)@TSSOP8 [(SA026)]	

DRAM & SRAM

AT3864L [(SA643)]	AT3864L@TSOP28
AT38H256 [(SA643)]	AT38H256@TSOP28

PLD

ATF16LV8C [(SA001A)]	ATF16LV8C@PLCC20
ATF16LV8C@SOIC20 [(SA404)] [(SA026)]	ATF16LV8C@TSOP20

ATF16LV8CEXT [(SA001A)]	ATF16LV8CEXT@PLCC20
ATF16LV8CEXT@SOIC20 [(SA404)] [(SA026)]	ATF16LV8CEXT@TSOP20
ATF16V8B [(SA001A)]	ATF16V8B@PLCC20
ATF16V8B@SOIC20 [(SA404)] [(SA026)]	ATF16V8B@TSOP20
ATF16V8BL [(SA001A)]	ATF16V8BL@PLCC20
ATF16V8BL@SOIC20 [(SA404)] [(SA026)]	ATF16V8BL@TSOP20
ATF16V8BQ [(SA001A)]	ATF16V8BQ@PLCC20
ATF16V8BQ@SOIC20 [(SA404)] [(SA026)]	ATF16V8BQ@TSOP20
ATF16V8BQL [(SA001A)]	ATF16V8BQL@PLCC20
ATF16V8BQL@SOIC20 [(SA404)] [(SA026)]	ATF16V8BQL@TSOP20
ATF16V8C [(SA001A)]	ATF16V8C@PLCC20
ATF16V8C@SOIC20 [(SA404)] [(SA026)]	ATF16V8C@TSOP20
ATF16V8CEXT [(SA001A)]	ATF16V8CEXT@PLCC20
ATF16V8CEXT@SOIC20 [(SA404)] [(SA026)]	ATF16V8CEXT@TSOP20
ATF16V8CZ [(SA001A)]	ATF16V8CZ@PLCC20
ATF16V8CZ@SOIC20 [(SA404)] [(SA026)]	ATF16V8CZ@TSOP20
ATF20V8B [(SA008A)]	ATF20V8B@PLCC28
ATF20V8B@SOIC24 [(SA404)]	
ATF20V8BL ATF20V8BL@PLCC28 [(SA008A)] [(SA404)]	ATF20V8BL@SOIC24
ATF20V8BQ [(SA008A)]	ATF20V8BQ@PLCC28
ATF20V8BQ@SOIC24 [(SA404)]	
ATF20V8BQL ATF20V8BQL@PLCC28 [(SA008A)]	ATF20V8BQL@SOIC24

[(SA404)]	
ATF22LV10C	ATF22LV10C
(UES)	
ATF22LV10C(UES)@PLCC28 [(SA008A)]	
ATF22LV10C(UES)@SOIC24 [(SA404)]	
ATF22LV10C(UES)@TSSOP24 [(SA643)]	
ATF22LV10C@PLCC28 [(SA008A)]	ATF22LV10C@SOIC24
[(SA404)]	
ATF22LV10C@TSSOP24 [(SA643)]	
ATF22LV10CEXT	
ATF22LV10CEXT@PLCC28 [(SA008A)]	ATF22LV10CEXT@SOIC24
[(SA404)]	
ATF22LV10CEXT@TSSOP24 [(SA643)]	
ATF22LV10CQ	
ATF22LV10CQ(UES)	
ATF22LV10CQ(UES)@PLCC28 [(SA008A)]	
ATF22LV10CQ(UES)@SOIC24 [(SA404)]	
ATF22LV10CQ(UES)@TSSOP24 [(SA643)]	
ATF22LV10CQ@PLCC28 [(SA008A)]	ATF22LV10CQ@SOIC24
[(SA404)]	
ATF22LV10CQ@TSSOP24 [(SA643)]	
ATF22LV10CQZ	
ATF22LV10CQZ(UES)	
ATF22LV10CQZ(UES)@PLCC28 [(SA008A)]	
ATF22LV10CQZ(UES)@SOIC24 [(SA404)]	
ATF22LV10CQZ(UES)@TSSOP24 [(SA643)]	
ATF22LV10CQZ@PLCC28 [(SA008A)]	ATF22LV10CQZ@SOIC24
[(SA404)]	
ATF22LV10CQZ@TSSOP24 [(SA643)]	
ATF22LV10CZ	
ATF22LV10CZ(UES)	
ATF22LV10CZ(UES)@PLCC28 [(SA008A)]	
ATF22LV10CZ(UES)@SOIC24 [(SA404)]	
ATF22LV10CZ(UES)@TSSOP24 [(SA643)]	
ATF22LV10CZ@PLCC28 [(SA008A)]	ATF22LV10CZ@SOIC24
[(SA404)]	
ATF22LV10CZ@TSSOP24 [(SA643)]	
ATF22V10B	
ATF22V10B(UES)	ATF22V10B(UES)@PLCC28
[(SA008A)]	
ATF22V10B(UES)@SOIC24 [(SA404)]	ATF22V10B@PLCC28
[(SA008A)]	
ATF22V10B@SOIC24 [(SA404)]	

ATF22V10BL	
ATF22V10BL(UES)	
ATF22V10BL(UES)@PLCC28 [(SA008A)]	
ATF22V10BL(UES)@SOIC24 [(SA404)]	ATF22V10BL@PLCC28
[(SA008A)]	
ATF22V10BL@SOIC24 [(SA404)]	
ATF22V10BQ	
ATF22V10BQ(UES)	
ATF22V10BQ(UES)@PLCC28 [(SA008A)]	
ATF22V10BQ(UES)@SOIC24 [(SA404)]	ATF22V10BQ@PLCC28
[(SA008A)]	
ATF22V10BQ@SOIC24 [(SA404)]	
ATF22V10BQL	
ATF22V10BQL(UES)	
ATF22V10BQL(UES)@PLCC28 [(SA008A)]	
ATF22V10BQL(UES)@SOIC24 [(SA404)]	
ATF22V10BQL@PLCC28 [(SA008A)]	ATF22V10BQL@SOIC24
[(SA404)]	
ATF22V10C	ATF22V10C
(UES)	
ATF22V10C(UES)@PLCC28 [(SA008A)]	ATF22V10C(UES)@SOIC24
[(SA404)]	
ATF22V10C(UES)@TSSOP24 [(SA643)]	ATF22V10C@PLCC28
[(SA008A)]	
ATF22V10C@SOIC24 [(SA404)]	ATF22V10C@TSSOP24
[(SA643)]	
ATF22V10CEXT	ATF22V10CEXT@PLCC28
[(SA008A)]	
ATF22V10CEXT@SOIC24 [(SA404)]	ATF22V10CEXT@TSSOP24
[(SA643)]	
ATF22V10CQ	ATF22V10CQ
(UES)	
ATF22V10CQ(UES)@PLCC28 [(SA008A)]	
ATF22V10CQ(UES)@SOIC24 [(SA404)]	
ATF22V10CQ(UES)@TSSOP24 [(SA643)]	
ATF22V10CQ@PLCC28 [(SA008A)]	ATF22V10CQ@SOIC24
[(SA404)]	
ATF22V10CQ@TSSOP24 [(SA643)]	
ATF22V10CQZ	
ATF22V10CQZ(UES)	
ATF22V10CQZ(UES)@PLCC28 [(SA008A)]	
ATF22V10CQZ(UES)@SOIC24 [(SA404)]	
ATF22V10CQZ(UES)@TSSOP24 [(SA643)]	

ATF22V10CQZ@PLCC28 [(SA008A)]		ATF22V10CQZ@SOIC24	
[(SA404)]			
ATF22V10CQZ@TSSOP24 [(SA643)]			
ATF22V10CZ			
ATF22V10CZ(UES)			
ATF22V10CZ(UES)@PLCC28 [(SA008A)]			
ATF22V10CZ(UES)@SOIC24 [(SA404)]			
ATF22V10CZ(UES)@TSSOP24 [(SA643)]			
ATF22V10CZ@PLCC28 [(SA008A)]		ATF22V10CZ@SOIC24	
[(SA404)]			
ATF22V10CZ@TSSOP24 [(SA643)]		ATF750C	(ATF750C
mode)			
ATF750C	(ATV750 mode)	ATF750C	(ATV750B
mode)			
ATF750C@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750C@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750C@PLCC28	(ATV750B mode) [(SA008A)]		
ATF750C@SOIC24	(ATF750C mode) [(SA404)]		
ATF750C@SOIC24	(ATV750 mode) [(SA404)]		
ATF750C@SOIC24	(ATV750B mode) [(SA404)]		
ATF750CEXT	(ATF750C mode)		
ATF750CEXT@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750CEXT@SOIC24	(ATF750C mode) [(SA404)]		
ATF750CL	(ATV750 mode)	ATF750CL	(ATV750B
mode)			
ATF750CL@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750CL@PLCC28	(ATV750B mode) [(SA008A)]		
ATF750CL@SOIC24	(ATV750 mode) [(SA404)]		
ATF750CL@SOIC24	(ATV750B mode) [(SA404)]		
ATF750LVC	(ATF750C mode)	ATF750LVC	(ATV750
mode)			
ATF750LVC	(ATV750B mode)		
ATF750LVC@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750LVC@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750LVC@PLCC28	(ATV750B mode) [(SA008A)]		
ATF750LVC@SOIC24	(ATF750C mode) [(SA404)]		
ATF750LVC@SOIC24	(ATV750 mode) [(SA404)]		
ATF750LVC@SOIC24	(ATV750B mode) [(SA404)]		
ATF750LVCEXT	(ATF750C mode)		
ATF750LVCEXT@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750LVCEXT@SOIC24	(ATF750C mode) [(SA404)]		
ATF750LVCL	(ATF750C mode)	ATF750LVCL	(ATV750
mode)			

ATF750LVCL	(ATV750B mode)	
ATF750LVCL@PLCC28	(ATF750C mode)	[(SA008A)]
ATF750LVCL@PLCC28	(ATV750 mode)	[(SA008A)]
ATF750LVCL@PLCC28	(ATV750B mode)	[(SA008A)]
ATF750LVCL@SOIC24	(ATF750C mode)	[(SA404)]
ATF750LVCL@SOIC24	(ATV750 mode)	[(SA404)]
ATF750LVCL@SOIC24	(ATV750B mode)	[(SA404)]
ATV750		ATV750@PLCC28
[(SA008A)]		
ATV750@SOIC24	[(SA404)]	
ATV750B		
ATV750B@PLCC28	[(SA008A)]	ATV750B@SOIC24
[(SA404)]		
ATV750BL		ATV750BL@PLCC28
[(SA008A)]		
ATV750BL@SOIC24	[(SA404)]	
ATV750L		
ATV750L@PLCC28	[(SA008A)]	ATV750L@SOIC24
[(SA404)]		

MICROCONTROLLER

AT80F51		AT80F51@PLCC44
[(SA244)]		
AT80F51@TQFP44	[(SA245A)]	
AT80F52		
AT80F52@PLCC44	[(SA244)]	AT80F52@TQFP44
[(SA245A)]		
AT87F51		AT87F51@PLCC44
[(SA244)]		
AT87F51@TQFP44	[(SA245A)]	
AT87F51RC		
AT87F51RC@PLCC44	[(SA244)]	AT87F51RC@TQFP44
[(SA245A)]		
AT87F52		AT87F52@PLCC44
[(SA244)]		
AT87F52@TQFP44	[(SA245A)]	
AT87F55		
AT87F55@PLCC44	[(SA244)]	AT87F55@TQFP44
[(SA245A)]		
AT87F55WD		AT87F55WD@PLCC44
[(SA244)]		

AT87F55WD@TQFP44 [(SA245A)]	
AT87LV51	
AT87LV51@PLCC44 [(SA244)]	AT87LV51@TQFP44
[(SA245A)]	
AT87LV52	
[(SA244)]	AT87LV52@PLCC44
AT87LV52@TQFP44 [(SA245A)]	
AT89C1051	
AT89C1051@SOIC20 [(SA404)]	
AT89C1051U	
AT89C1051U@SOIC20 [(SA404)]	
AT89C2051	
AT89C2051@SOIC20 [(SA404)]	
AT89C2051X2	
AT89C2051X2@SOIC20 [(SA404)]	
AT89C4051	
AT89C4051@SOIC20 [(SA404)]	
AT89C51	
AT89C51@PLCC44 [(SA244)]	AT89C51@TQFP44
[(SA245A)]	
AT89C5130A@QFN32 [(SA686)]	AT89C5130A@SOIC28
[(SA404)]	
AT89C5130AM@QFN32 [(SA686)]	AT89C5130AM@SOIC28
[(SA404)]	
AT89C5131@MLF48 [(SA696)]	AT89C5131@SOIC28
[(SA404)]	
AT89C5131A@QFN32 [(SA701)]	AT89C5131A@SOIC28
[(SA404)]	
AT89C5131AL@QFN32 [(SA701)]	AT89C5131AL@SOIC28
[(SA404)]	
AT89C5131AM@QFN32 [(SA701)]	AT89C5131AM@SOIC28
[(SA404)]	
AT89C51AC2@PLCC44 [(SA244)]	AT89C51AC2@TQFP44
[(SA245A)]	
AT89C51AC3@PLCC44 [(SA244)]	AT89C51AC3@TQFP44
[(SA245A)]	
AT89C51CC01@PLCC44 [(SA244)]	AT89C51CC01@TQFP44
[(SA245A)]	
AT89C51CC03C@PLCC44 [(SA244)]	AT89C51CC03C@TQFP44
[(SA245A)]	
AT89C51CC03U@PLCC44 [(SA244)]	AT89C51CC03U@TQFP44
[(SA245A)]	
AT89C51ED2	AT89C51ED2@PLCC44

[(SA244)]	
AT89C51ED2@TQFP44 [(SA245A)]	AT89C51IC2@PLCC44
[(SA244)]	
AT89C51IC2@TQFP44 [(SA245A)]	
AT89C51ID2	
AT89C51ID2@PLCC44 [(SA244)]	AT89C51ID2@TQFP44
[(SA245A)]	
AT89C51RB2	AT89C51RB2@PLCC44
[(SA244)]	
AT89C51RB2@TQFP44 [(SA245A)]	
AT89C51RC	
AT89C51RC@PLCC44 [(SA244)]	AT89C51RC@TQFP44
[(SA245A)]	
AT89C51RC2	AT89C51RC2@PLCC44
[(SA244)]	
AT89C51RC2@TQFP44 [(SA245A)]	
AT89C51RD2	
AT89C51RD2@PLCC44 [(SA244)]	AT89C51RD2@TQFP44
[(SA245A)]	
AT89C51RE2@PLCC44 [(SA244)]	AT89C51RE2@TQFP44
[(SA675)]	
AT89C52	AT89C52@PLCC44
[(SA244)]	
AT89C52@TQFP44 [(SA245A)]	
AT89C55	
AT89C55@PLCC44 [(SA244)]	AT89C55@TQFP44
[(SA245A)]	
AT89C55WD	AT89C55WD@PLCC44
[(SA244)]	
AT89C55WD@TQFP44 [(SA245A)]	
AT89LP2051	
AT89LP2051@SOIC20 [(SA404)]	AT89LP2051@TSSOP20
[(SA026)]	
AT89LP2052	AT89LP2052 (ISP) [ISP-
HEADER01]	
AT89LP2052@SOIC20 [(SA404)]	
AT89LP2052@SOIC20 (ISP) [ISP-HEADER01]	
AT89LP2052@TSSOP20 [(SA026)]	
AT89LP2052@TSSOP20 (ISP) [ISP-HEADER01]	
AT89LP213	AT89LP213 (ISP) [ISP-
HEADER01]	
AT89LP213@TSSOP14 [(SA026)]	
AT89LP213@TSSOP14 (ISP) [ISP-HEADER01]	


```

AT89LS53@PLCC44 [(SA244)]
AT89LS53@PLCC44(ISP) [ISP-HEADER01]
AT89LS53@TQFP44 [(SA245A)]
AT89LS53@TQFP44(ISP) [ISP-HEADER01]
AT89LS8252 AT89LS8252(ISP) [ISP-
HEADER01]
AT89LS8252@PLCC44 [(SA244)]
AT89LS8252@PLCC44(ISP) [ISP-HEADER01]
AT89LS8252@TQFP44 [(SA245A)]
AT89LS8252@TQFP44(ISP) [ISP-HEADER01]
AT89LV51 AT89LV51@PLCC44
[(SA244)]
AT89LV51@TQFP44 [(SA245A)]
AT89LV52
AT89LV52@PLCC44 [(SA244)] AT89LV52@TQFP44
[(SA245A)]
AT89LV55 AT89LV55@PLCC44
[(SA244)]
AT89LV55@TQFP44 [(SA245A)]
AT89S2051
AT89S2051@SOIC20 [(SA404)]
AT89S4051
AT89S4051@SOIC20 [(SA404)]
AT89S51
AT89S51(ISP) [ISP-HEADER01] AT89S51@PLCC44
[(SA244)]
AT89S51@PLCC44(ISP) [ISP-HEADER01]
AT89S51@TQFP44 [(SA245A)]
AT89S51@TQFP44(ISP) [ISP-HEADER01]
AT89S52 AT89S52(ISP) [ISP-
HEADER01]
AT89S52@PLCC44 [(SA244)]
AT89S52@PLCC44(ISP) [ISP-HEADER01]
AT89S52@TQFP44 [(SA245A)]
AT89S52@TQFP44(ISP) [ISP-HEADER01]
AT89S53 AT89S53(ISP) [ISP-
HEADER01]
AT89S53@PLCC44 [(SA244)]
AT89S53@PLCC44(ISP) [ISP-HEADER01]
AT89S53@TQFP44 [(SA245A)]
AT89S53@TQFP44(ISP) [ISP-HEADER01]
AT89S54 AT89S54@PLCC44
[(SA244)]

```

AT89S54@TQFP44 [(SA245A)]
 AT89S58
 AT89S58@PLCC44 [(SA244)] AT89S58@TQFP44
 [(SA245A)]
 AT89S64 AT89S64@PLCC44
 [(SA244)]
 AT89S64@TQFP44 [(SA245A)]
 AT89S8252
 AT89S8252(ISP) [ISP-HEADER01] AT89S8252@PLCC44
 [(SA244)]
 AT89S8252@PLCC44(ISP) [ISP-HEADER01]
 AT89S8252@TQFP44 [(SA245A)]
 AT89S8252@TQFP44(ISP) [ISP-HEADER01]
 AT89S8253 AT89S8253(ISP) [ISP-
 HEADER01]
 AT89S8253@PLCC44 [(SA244)]
 AT89S8253@PLCC44(ISP) [ISP-HEADER01]
 AT89S8253@TQFP44 [(SA245A)]
 AT89S8253@TQFP44(ISP) [ISP-HEADER01]
 AT90CAN128@QFN64(ISP) [ISP-HEADER01]
 AT90CAN128@TQFP64(ISP) [ISP-HEADER01]
 AT90CAN32@QFN64(ISP) [ISP-HEADER01]
 AT90CAN32@TQFP64(ISP) [ISP-HEADER01]
 AT90CAN64@QFN64(ISP) [ISP-HEADER01]
 AT90CAN64@TQFP64(ISP) [ISP-HEADER01]
 AT90LS2323 AT90LS2323(ISP) [ISP-
 HEADER01]
 AT90LS2323@SOIC8 [(SA605A)]
 AT90LS2323@SOIC8(ISP) [ISP-HEADER01]
 AT90LS2333 AT90LS2333(ISP) [ISP-
 HEADER01]
 AT90LS2333@TQFP32 [(SA663)]
 AT90LS2333@TQFP32(ISP) [ISP-HEADER01]
 AT90LS2343 AT90LS2343(ISP) [ISP-
 HEADER01]
 AT90LS2343@SOIC8 [(SA605A)]
 AT90LS2343@SOIC8(ISP) [ISP-HEADER01]
 AT90LS4433 AT90LS4433(ISP) [ISP-
 HEADER01]
 AT90LS4433@TQFP32 [(SA663)]
 AT90LS4433@TQFP32(ISP) [ISP-HEADER01]
 AT90LS4434 AT90LS4434(ISP) [ISP-
 HEADER01]

```
AT90LS4434@PLCC44 [(SA244)]
AT90LS4434@PLCC44(ISP) [ISP-HEADER01]
AT90LS4434@TQFP44 [(SA245A)]
AT90LS4434@TQFP44(ISP) [ISP-HEADER01]
AT90LS8535 AT90LS8535(ISP) [ISP-
HEADER01]
AT90LS8535@PLCC44 [(SA244)]
AT90LS8535@PLCC44(ISP) [ISP-HEADER01]
AT90LS8535@TQFP44 [(SA245A)]
AT90LS8535@TQFP44(ISP) [ISP-HEADER01]
AT90PWM1@SOIC24 [(SA404)] AT90PWM2@SOIC24
[(SA404)]
AT90PWM2@SOIC24(ISP) [ISP-HEADER01]
AT90PWM216@SOIC24 [(SA404)] AT90PWM2B@SOIC24
[(SA404)]
AT90PWM2B@SOIC24(ISP) [ISP-HEADER01]
AT90PWM3@QFN32 [(SA701)]
AT90PWM3@QFN32(ISP) [ISP-HEADER01]
AT90PWM3@SOIC32 [(SA715)]
AT90PWM3@SOIC32(ISP) [ISP-HEADER01]
AT90PWM316@QFN32 [(SA701)] AT90PWM316@SOIC32
[(SA715)]
AT90PWM3B@QFN32 [(SA701)]
AT90PWM3B@QFN32(ISP) [ISP-HEADER01]
AT90PWM3B@SOIC32 [(SA715)]
AT90PWM3B@SOIC32(ISP) [ISP-HEADER01]
AT90S1200 AT90S1200(ISP) [ISP-
HEADER01]
AT90S1200@SOIC20 [(SA404)]
AT90S1200@SOIC20(ISP) [ISP-HEADER01]
AT90S1200@SSOP20 [(SA626A)]
AT90S1200@SSOP20(ISP) [ISP-HEADER01]
AT90S1200A AT90S1200A(ISP) [ISP-
HEADER01]
AT90S1200A@SOIC20 [(SA404)]
AT90S1200A@SOIC20(ISP) [ISP-HEADER01]
AT90S1200A@SSOP20 [(SA626A)]
AT90S1200A@SSOP20(ISP) [ISP-HEADER01]
AT90S2313 AT90S2313(ISP) [ISP-
HEADER01]
AT90S2313@SOIC20 [(SA404)]
AT90S2313@SOIC20(ISP) [ISP-HEADER01]
AT90S2323 AT90S2323(ISP) [ISP-
```

```
HEADER01 ]
AT90S2323@SOIC8 [ (SA605A) ]
AT90S2323@SOIC8(ISP) [ ISP-HEADER01 ]
AT90S2333 AT90S2333(ISP) [ ISP-
HEADER01 ]
AT90S2333@TQFP32 [ (SA663) ]
AT90S2333@TQFP32(ISP) [ ISP-HEADER01 ]
AT90S2343 AT90S2343(ISP) [ ISP-
HEADER01 ]
AT90S2343@SOIC8 [ (SA605A) ]
AT90S2343@SOIC8(ISP) [ ISP-HEADER01 ]
AT90S4414 AT90S4414(ISP) [ ISP-
HEADER01 ]
AT90S4414@PLCC44 [ (SA244) ]
AT90S4414@PLCC44(ISP) [ ISP-HEADER01 ]
AT90S4414@TQFP44 [ (SA245A) ]
AT90S4414@TQFP44(ISP) [ ISP-HEADER01 ]
AT90S4433 AT90S4433(ISP) [ ISP-
HEADER01 ]
AT90S4433@TQFP32 [ (SA663) ]
AT90S4433@TQFP32(ISP) [ ISP-HEADER01 ]
AT90S4434 AT90S4434(ISP) [ ISP-
HEADER01 ]
AT90S4434@PLCC44 [ (SA244) ]
AT90S4434@PLCC44(ISP) [ ISP-HEADER01 ]
AT90S4434@TQFP44 [ (SA245A) ]
AT90S4434@TQFP44(ISP) [ ISP-HEADER01 ]
AT90S8515 AT90S8515(ISP) [ ISP-
HEADER01 ]
AT90S8515@PLCC44 [ (SA244) ]
AT90S8515@PLCC44(ISP) [ ISP-HEADER01 ]
AT90S8515@TQFP44 [ (SA245A) ]
AT90S8515@TQFP44(ISP) [ ISP-HEADER01 ]
AT90S8535 AT90S8535(ISP) [ ISP-
HEADER01 ]
AT90S8535@PLCC44 [ (SA244) ]
AT90S8535@PLCC44(ISP) [ ISP-HEADER01 ]
AT90S8535@TQFP44 [ (SA245A) ]
AT90S8535@TQFP44(ISP) [ ISP-HEADER01 ]
AT90USB1286@QFN64(ISP) [ ISP-HEADER01 ]
AT90USB1286@TQFP64(ISP) [ ISP-HEADER01 ]
AT90USB1287@QFN64(ISP) [ ISP-HEADER01 ]
AT90USB1287@TQFP64(ISP) [ ISP-HEADER01 ]
```



```

AT90USB646@QFN64(ISP) [ISP-HEADER01]
AT90USB646@TQFP64(ISP) [ISP-HEADER01]
AT90USB647@QFN64(ISP) [ISP-HEADER01]
AT90USB647@TQFP64(ISP) [ISP-HEADER01]
ATAM862@SSO24 [(SA026)] ATAM893@SSO20
[(SA026)]
ATAM894@SSO24 [(SA026)]
ATMEGA128@QFN64(ISP) [ISP-HEADER01]
ATMEGA128@TQFP64(ISP) [ISP-HEADER01]
ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]
ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]
ATMEGA128L@QFN64(ISP) [ISP-HEADER01]
ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]
ATMEGA16 ATMEGA16
(fast)
ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44
[(SA245A)]
ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16@MLF44
[(SA712)]
ATMEGA16@MLF44(ISP) [ISP-HEADER01]
ATMEGA16@TQFP44 [(SA245A)]
ATMEGA16@TQFP44(ISP) [ISP-HEADER01]
ATMEGA161 ATMEGA161@TQFP44
[(SA245A)]
ATMEGA161L ATMEGA161L@TQFP44
[(SA245A)]
ATMEGA162 ATMEGA162(ISP) [ISP-
HEADER01]
ATMEGA162@MLF44 [(SA712)]
ATMEGA162@PLCC44(ISP) [ISP-HEADER01]
ATMEGA162@TQFP44 [(SA245A)]
ATMEGA162@TQFP44(ISP) [ISP-HEADER01]
ATMEGA162V ATMEGA162V@MLF44
[(SA712)]
ATMEGA162V@TQFP44 [(SA245A)]
ATMEGA163
ATMEGA163@TQFP44 [(SA245A)]
ATMEGA163L
ATMEGA163L@TQFP44 [(SA245A)]
ATMEGA164P
ATMEGA164P@MLP44 [(SA712)] ATMEGA164P@TQFP44
[(SA245A)]
ATMEGA164PL ATMEGA164PL@MLP44

```

```

[ (SA712) ]
ATMEGA164PL@TQFP44 [ (SA245A) ]
ATMEGA165@QFN64 (ISP) [ ISP-HEADER01 ]
ATMEGA165@TQFP64 (ISP) [ ISP-HEADER01 ]
ATMEGA168 ATMEGA168 (ISP) [ ISP-
HEADER01 ]
ATMEGA168@MLP32 [ (SA686) ]
ATMEGA168@MLP32 (ISP) [ ISP-HEADER01 ]
ATMEGA168@TQFP32 [ (SA663) ]
ATMEGA168@TQFP32 (ISP) [ ISP-HEADER01 ]
ATMEGA168P ATMEGA168P (ISP) [ ISP-
HEADER01 ]
ATMEGA168P@MLP32 [ (SA686) ]
ATMEGA168P@MLP32 (ISP) [ ISP-HEADER01 ]
ATMEGA168P@TQFP32 [ (SA663) ]
ATMEGA168P@TQFP32 (ISP) [ ISP-HEADER01 ]
ATMEGA168PV ATMEGA168PV (ISP) [ ISP-
HEADER01 ]
ATMEGA168PV@MLP32 [ (SA686) ]
ATMEGA168PV@MLP32 (ISP) [ ISP-HEADER01 ]
ATMEGA168PV@TQFP32 [ (SA663) ]
ATMEGA168PV@TQFP32 (ISP) [ ISP-HEADER01 ]
ATMEGA168V ATMEGA168V (ISP) [ ISP-
HEADER01 ]
ATMEGA168V@MLP32 [ (SA686) ]
ATMEGA168V@MLP32 (ISP) [ ISP-HEADER01 ]
ATMEGA168V@TQFP32 [ (SA663) ]
ATMEGA168V@TQFP32 (ISP) [ ISP-HEADER01 ]
ATMEGA169@MLF64 (ISP) [ ISP-HEADER01 ]
ATMEGA169@TQFP64 (ISP) [ ISP-HEADER01 ]
ATMEGA169PV@MLF64 (ISP) [ ISP-HEADER01 ]
ATMEGA169PV@TQFP64 (ISP) [ ISP-HEADER01 ]
ATMEGA16L ATMEGA16L
(fast)
ATMEGA16L(fast)@MLF44 [ (SA712) ]
ATMEGA16L(fast)@TQFP44 [ (SA245A) ]
ATMEGA16L (ISP) [ ISP-HEADER01 ] ATMEGA16L@MLF44
[ (SA712) ]
ATMEGA16L@MLF44 (ISP) [ ISP-HEADER01 ]
ATMEGA16L@TQFP44 [ (SA245A) ]
ATMEGA16L@TQFP44 (ISP) [ ISP-HEADER01 ]
ATMEGA2560@TQFP100 (ISP) [ ISP-HEADER01 ]
ATMEGA2560V@TQFP100 (ISP) [ ISP-HEADER01 ]

```

ATMEGA2561@QFN64(ISP) [ISP-HEADER01]
 ATMEGA2561@TQFP64(ISP) [ISP-HEADER01]
 ATMEGA2561V@QFN64(ISP) [ISP-HEADER01]
 ATMEGA2561V@TQFP64(ISP) [ISP-HEADER01]
 ATMEGA32 ATMEGA32(ISP) [ISP-
 HEADER01]
 ATMEGA32(new) ATMEGA32(new)
 (fast)
 ATMEGA32(new)(fast)@MLF44 [(SA712)]
 ATMEGA32(new)(fast)@PLCC44 [(SA244)]
 ATMEGA32(new)(fast)@TQFP44 [(SA245A)]
 ATMEGA32(new)@MLF44 [(SA712)] ATMEGA32(new)@PLCC44
 [(SA244)]
 ATMEGA32(new)@TQFP44 [(SA245A)] ATMEGA32@MLF44
 [(SA712)]
 ATMEGA32@MLF44(ISP) [ISP-HEADER01]
 ATMEGA32@PLCC44 [(SA244)] ATMEGA32@TQFP44
 [(SA245A)]
 ATMEGA32@TQFP44(ISP) [ISP-HEADER01]
 ATMEGA323 ATMEGA323@TQFP44
 [(SA245A)]
 ATMEGA323L ATMEGA323L@TQFP44
 [(SA245A)]
 ATMEGA324P ATMEGA324P@MLP44
 [(SA712)]
 ATMEGA324P@TQFP44 [(SA245A)]
 ATMEGA324PL ATMEGA324PL@TQFP44
 ATMEGA324PL@MLP44 [(SA712)]
 [(SA245A)]
 ATMEGA3250@TQFP100(ISP) [ISP-HEADER01]
 ATMEGA325P@TQFP64(ISP) [ISP-HEADER01]
 ATMEGA325V@QFN64(ISP) [ISP-HEADER01]
 ATMEGA328P ATMEGA328P(ISP) [ISP-
 HEADER01]
 ATMEGA328P@MLP32 [(SA686)]
 ATMEGA328P@MLP32(ISP) [ISP-HEADER01]
 ATMEGA328P@TQFP32 [(SA663)]
 ATMEGA328P@TQFP32(ISP) [ISP-HEADER01]
 ATMEGA328PV ATMEGA328PV(ISP) [ISP-
 HEADER01]
 ATMEGA328PV@MLP32 [(SA686)]
 ATMEGA328PV@MLP32(ISP) [ISP-HEADER01]
 ATMEGA328PV@TQFP32 [(SA663)]

ATMEGA328PV@TQFP32(ISP) [ISP-HEADER01]
 ATMEGA329@QFN64(ISP) [ISP-HEADER01]
 ATMEGA3290@TQFP100(ISP) [ISP-HEADER01]
 ATMEGA329P@TQFP64(ISP) [ISP-HEADER01]
 ATMEGA32L ATMEGA32L(ISP) [ISP-
 HEADER01]
 ATMEGA32L(new) ATMEGA32L(new)
 (fast)
 ATMEGA32L(new) (fast)@MLF44 [(SA712)]
 ATMEGA32L(new) (fast)@PLCC44 [(SA244)]
 ATMEGA32L(new) (fast)@TQFP44 [(SA245A)]
 ATMEGA32L(new)@MLF44 [(SA712)] ATMEGA32L(new)@PLCC44
 [(SA244)]
 ATMEGA32L(new)@TQFP44 [(SA245A)] ATMEGA32L@MLF44
 [(SA712)]
 ATMEGA32L@MLF44(ISP) [ISP-HEADER01]
 ATMEGA32L@PLCC44 [(SA244)] ATMEGA32L@TQFP44
 [(SA245A)]
 ATMEGA32L@TQFP44(ISP) [ISP-HEADER01]
 ATMEGA406@LQFP48 [(SA248)]
 ATMEGA48
 ATMEGA48(ISP) [ISP-HEADER01] ATMEGA48@MLP32
 [(SA686)]
 ATMEGA48@MLP32(ISP) [ISP-HEADER01]
 ATMEGA48@TQFP32 [(SA663)]
 ATMEGA48@TQFP32(ISP) [ISP-HEADER01]
 ATMEGA48P ATMEGA48P@MLP32
 [(SA686)]
 ATMEGA48P@TQFP32 [(SA663)]
 ATMEGA48PV
 ATMEGA48PV@MLP32 [(SA686)] ATMEGA48PV@TQFP32
 [(SA663)]
 ATMEGA48V ATMEGA48V(ISP) [ISP-
 HEADER01]
 ATMEGA48V@MLP32 [(SA686)]
 ATMEGA48V@MLP32(ISP) [ISP-HEADER01]
 ATMEGA48V@TQFP32 [(SA663)]
 ATMEGA48V@TQFP32(ISP) [ISP-HEADER01]
 ATMEGA64@QFN64(ISP) [ISP-HEADER01]
 ATMEGA64@TQFP64(ISP) [ISP-HEADER01]
 ATMEGA644 ATMEGA644(ISP) [ISP-
 HEADER01]
 ATMEGA644@MLF44 [(SA712)]

```

ATMEGA644@MLF44 (ISP) [ISP-HEADER01]
ATMEGA644@TQFP44 [(SA245A)]
ATMEGA644@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA644P ATMEGA644P (ISP) [ISP-
HEADER01]
ATMEGA644P@MLF44 [(SA712)]
ATMEGA644P@MLF44 (ISP) [ISP-HEADER01]
ATMEGA644P@TQFP44 [(SA245A)]
ATMEGA644P@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA644PV ATMEGA644PV (ISP) [ISP-
HEADER01]
ATMEGA644PV@MLF44 [(SA712)]
ATMEGA644PV@MLF44 (ISP) [ISP-HEADER01]
ATMEGA644PV@TQFP44 [(SA245A)]
ATMEGA644PV@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA644V ATMEGA644V (ISP) [ISP-
HEADER01]
ATMEGA644V@MLF44 [(SA712)]
ATMEGA644V@MLF44 (ISP) [ISP-HEADER01]
ATMEGA644V@TQFP44 [(SA245A)]
ATMEGA644V@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA645@QFN64 (ISP) [ISP-HEADER01]
ATMEGA645@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA6450@TQFP100 (ISP) [ISP-HEADER01]
ATMEGA649@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA6490@TQFP100 (ISP) [ISP-HEADER01]
ATMEGA649V@QFN64 (ISP) [ISP-HEADER01]
ATMEGA64L@QFN64 (ISP) [ISP-HEADER01]
ATMEGA64L@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA8 ATMEGA8
(fast)
ATMEGA8 (fast)@TQFP32 [(SA663)] ATMEGA8 (ISP) [ISP-
HEADER01]
ATMEGA8@MLF32 [(SA686)]
ATMEGA8@MLF32 (ISP) [ISP-HEADER01]
ATMEGA8@TQFP32 [(SA663)]
ATMEGA8@TQFP32 (ISP) [ISP-HEADER01]
ATMEGA8515 ATMEGA8515
(fast)
ATMEGA8515 (fast)@PLCC44 [(SA244)]
ATMEGA8515 (fast)@TQFP44 [(SA245A)]
ATMEGA8515 (ISP) [ISP-HEADER01] ATMEGA8515@PLCC44
[(SA244)]

```

```

ATMEGA8515@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515@TQFP44 [(SA245A)]
ATMEGA8515@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8515L                                ATMEGA8515L
(fast)
ATMEGA8515L(fast)@PLCC44 [(SA244)]
ATMEGA8515L(fast)@TQFP44 [(SA245A)]
ATMEGA8515L(ISP) [ISP-HEADER01]          ATMEGA8515L@PLCC44
[(SA244)]
ATMEGA8515L@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515L@TQFP44 [(SA245A)]
ATMEGA8515L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8535                                ATMEGA8535
(fast)
ATMEGA8535(fast)@MLF44 [(SA712)]
ATMEGA8535(fast)@PLCC44 [(SA244)]
ATMEGA8535(fast)@TQFP44 [(SA245A)]
ATMEGA8535(ISP) [ISP-HEADER01]          ATMEGA8535@PLCC44
[(SA244)]
ATMEGA8535@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8535@TQFP44 [(SA245A)]
ATMEGA8535@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8535L                                ATMEGA8535L
(fast)
ATMEGA8535L(fast)@MLF44 [(SA712)]
ATMEGA8535L(fast)@PLCC44 [(SA244)]
ATMEGA8535L(fast)@TQFP44 [(SA245A)]
ATMEGA8535L(ISP) [ISP-HEADER01]          ATMEGA8535L@PLCC44
[(SA244)]
ATMEGA8535L@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8535L@TQFP44 [(SA245A)]
ATMEGA8535L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA88                                ATMEGA88(ISP) [ISP-
HEADER01]
ATMEGA88@MLP32 [(SA686)]
ATMEGA88@MLP32(ISP) [ISP-HEADER01]
ATMEGA88@TQFP32 [(SA663)]
ATMEGA88@TQFP32(ISP) [ISP-HEADER01]
ATMEGA88P                                ATMEGA88P@MLP32
[(SA686)]
ATMEGA88P@TQFP32 [(SA663)]
ATMEGA88PV
ATMEGA88PV@MLP32 [(SA686)]          ATMEGA88PV@TQFP32

```

```

[ (SA663) ]
ATMEGA88V                                ATMEGA88V( ISP) [ ISP-
HEADER01 ]
ATMEGA88V@MLP32 [ (SA686) ]
ATMEGA88V@MLP32( ISP) [ ISP-HEADER01 ]
ATMEGA88V@TQFP32 [ (SA663) ]
ATMEGA88V@TQFP32( ISP) [ ISP-HEADER01 ]
ATMEGA8L                                  ATMEGA8L
(fast)
ATMEGA8L(fast)@TQFP32 [ (SA663) ]      ATMEGA8L( ISP) [ ISP-
HEADER01 ]
ATMEGA8L@MLF32 [ (SA686) ]
ATMEGA8L@MLF32( ISP) [ ISP-HEADER01 ]
ATMEGA8L@TQFP32 [ (SA663) ]
ATMEGA8L@TQFP32( ISP) [ ISP-HEADER01 ]
ATtiny10                                  ATtiny10( ISP) [ ISP-
HEADER01 ]
ATtiny10@SOIC8 [ (SA605A) ]
ATtiny10@SOIC8( ISP) [ ISP-HEADER01 ]
ATtiny11                                  ATtiny11( ISP) [ ISP-
HEADER01 ]
ATtiny11@SOIC8 [ (SA605A) ]
ATtiny11@SOIC8( ISP) [ ISP-HEADER01 ]
ATtiny11L                                  ATtiny11L( ISP) [ ISP-
HEADER01 ]
ATtiny11L@SOIC8 [ (SA605A) ]
ATtiny11L@SOIC8( ISP) [ ISP-HEADER01 ]
ATtiny12                                  ATtiny12( ISP) [ ISP-
HEADER01 ]
ATtiny12@SOIC8 [ (SA605A) ]
ATtiny12@SOIC8( ISP) [ ISP-HEADER01 ]
ATtiny12L                                  ATtiny12L( ISP) [ ISP-
HEADER01 ]
ATtiny12L@SOIC8 [ (SA605A) ]
ATtiny12L@SOIC8( ISP) [ ISP-HEADER01 ]
ATtiny12V                                  ATtiny12V( ISP) [ ISP-
HEADER01 ]
ATtiny12V@SOIC8 [ (SA605A) ]
ATtiny12V@SOIC8( ISP) [ ISP-HEADER01 ]
ATtiny13                                  ATtiny13
(Fuse)
ATtiny13(Fuse)@QFN10 [ (SA695A) ]      ATtiny13(Fuse)@QFN20
[ (SA692) ]

```

ATtiny13(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
 ATtiny13(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
 ATtiny13(ISP) [ISP-HEADER01] ATtiny13@QFN10
 [(SA695A)]
 ATtiny13@QFN10(ISP) [ISP-HEADER01]
 ATtiny13@QFN20 [(SA692)]
 ATtiny13@QFN20(ISP) [ISP-HEADER01]
 ATtiny13@SOIC8(3.9*6.2) [(SA602A)]
 ATtiny13@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
 ATtiny13@SOIC8(5.5*8.0) [(SA605A)]
 ATtiny13@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
 ATtiny13V ATtiny13V
 (Fuse)
 ATtiny13V(Fuse)@QFN10 [(SA695A)] ATtiny13V(Fuse)@QFN20
 [(SA692)]
 ATtiny13V(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
 ATtiny13V(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
 ATtiny13V(ISP) [ISP-HEADER01] ATtiny13V@QFN10
 [(SA695A)]
 ATtiny13V@QFN10(ISP) [ISP-HEADER01]
 ATtiny13V@QFN20 [(SA692)]
 ATtiny13V@QFN20(ISP) [ISP-HEADER01]
 ATtiny13V@SOIC8(3.9*6.2) [(SA602A)]
 ATtiny13V@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
 ATtiny13V@SOIC8(5.5*8.0) [(SA605A)]
 ATtiny13V@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
 ATtiny15 ATtiny15(ISP) [ISP-
 HEADER01]
 ATtiny15@SOIC8 [(SA605A)]
 ATtiny15@SOIC8(ISP) [ISP-HEADER01]
 ATtiny15L ATtiny15L(ISP) [ISP-
 HEADER01]
 ATtiny15L@SOIC8 [(SA605A)]
 ATtiny15L@SOIC8(ISP) [ISP-HEADER01]
 ATtiny2313 ATtiny2313(ISP) [ISP-
 HEADER01]
 ATtiny2313@MLF20 [(SA692)]
 ATtiny2313@MLF20(ISP) [ISP-HEADER01]
 ATtiny2313@SOIC20 [(SA404)]
 ATtiny2313@SOIC20(ISP) [ISP-HEADER01]
 ATtiny2313V ATtiny2313V(ISP) [ISP-
 HEADER01]
 ATtiny2313V@MLF20 [(SA692)]


```

ATtiny2313V@MLF20(ISP) [ISP-HEADER01]
ATtiny2313V@SOIC20 [(SA404)]
ATtiny2313V@SOIC20(ISP) [ISP-HEADER01]
ATtiny24
(Fuse)
ATtiny24(Fuse)@QFN20 [(SA692)]
[(SA602)]
ATtiny24(ISP) [ISP-HEADER01]
[(SA692)]
ATtiny24@QFN20(ISP) [ISP-HEADER01]
ATtiny24@SOIC14 [(SA602)]
ATtiny24@SOIC14(ISP) [ISP-HEADER01]
ATtiny24V
(Fuse)
ATtiny24V(Fuse)@QFN20 [(SA692)]
[(SA602)]
ATtiny24V(ISP) [ISP-HEADER01]
[(SA692)]
ATtiny24V@QFN20(ISP) [ISP-HEADER01]
ATtiny24V@SOIC14 [(SA602)]
ATtiny24V@SOIC14(ISP) [ISP-HEADER01]
ATtiny25
HEADER01]
ATtiny25@QFN20 [(SA692)]
ATtiny25@QFN20(ISP) [ISP-HEADER01]
ATtiny25@SOIC8 [(SA023A)]
ATtiny25@SOIC8(ISP) [ISP-HEADER01]
ATtiny26
HEADER01]
ATtiny26(new)
ATtiny26(new)(ISP) [ISP-HEADER01]
ATtiny26(new)@QFN32 [(SA686)]
[(SA404)]
ATtiny26(new)@SOIC20(ISP) [ISP-HEADER01]
ATtiny26(new)@TSSOP20 [(SA026)]
ATtiny26(new)@TSSOP20(ISP) [ISP-HEADER01]
ATtiny26@QFN32 [(SA686)]
[(SA404)]
ATtiny26@SOIC20(ISP) [ISP-HEADER01]
ATtiny26@TSSOP20 [(SA026)]
ATtiny26@TSSOP20(ISP) [ISP-HEADER01]
ATtiny261
HEADER01]

```

ATtiny261@MLP32 [(SA686)]
 ATtiny261@MLP32(ISP) [ISP-HEADER01]
 ATtiny261@SOIC20 [(SA404)]
 ATtiny261@SOIC20(ISP) [ISP-HEADER01]
 ATtiny261V ATtiny261V(ISP) [ISP-
 HEADER01]
 ATtiny261V@MLP32 [(SA686)]
 ATtiny261V@MLP32(ISP) [ISP-HEADER01]
 ATtiny261V@SOIC20 [(SA404)]
 ATtiny261V@SOIC20(ISP) [ISP-HEADER01]
 ATtiny26L ATtiny26L(ISP) [ISP-
 HEADER01]
 ATtiny26L(new)
 ATtiny26L(new)(ISP) [ISP-HEADER01]
 ATtiny26L(new)@QFN32 [(SA686)] ATtiny26L(new)@SOIC20
 [(SA404)]
 ATtiny26L(new)@SOIC20(ISP) [ISP-HEADER01]
 ATtiny26L(new)@TSSOP20 [(SA026)]
 ATtiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]
 ATtiny26L@QFN32 [(SA686)] ATtiny26L@SOIC20
 [(SA404)]
 ATtiny26L@SOIC20(ISP) [ISP-HEADER01]
 ATtiny26L@TSSOP20 [(SA026)]
 ATtiny26L@TSSOP20(ISP) [ISP-HEADER01]
 ATtiny28L ATtiny28L@TQFP32
 [(SA663)]
 ATtiny28V ATtiny28V@TQFP32
 [(SA663)]
 ATtiny44 ATtiny44(ISP) [ISP-
 HEADER01]
 ATtiny44@QFN20 [(SA692)]
 ATtiny44@QFN20(ISP) [ISP-HEADER01]
 ATtiny44@SOIC14 [(SA602)]
 ATtiny44@SOIC14(ISP) [ISP-HEADER01]
 ATtiny45
 ATtiny45(ISP)(12V) [ISP-HEADER01]
 ATtiny45(ISP)(5V) [ISP-HEADER01] ATtiny45@QFN20
 [(SA692)]
 ATtiny45@QFN20(ISP)(12V) [ISP-HEADER01]
 ATtiny45@QFN20(ISP)(5V) [ISP-HEADER01]
 ATtiny45@SOIC8 [(S605)]
 ATtiny45@SOIC8(ISP)(12V) [ISP-HEADER01]
 ATtiny45@SOIC8(ISP)(5V) [ISP-HEADER01]

```

ATtiny461                                ATtiny461(ISP) [ISP-
HEADER01]
ATtiny461@MLP32 [(SA686)]
ATtiny461@MLP32(ISP) [ISP-HEADER01]
ATtiny461@SOIC20 [(SA404)]
ATtiny461@SOIC20(ISP) [ISP-HEADER01]
ATtiny461V                                ATtiny461V(ISP) [ISP-
HEADER01]
ATtiny461V@MLP32 [(SA686)]
ATtiny461V@MLP32(ISP) [ISP-HEADER01]
ATtiny461V@SOIC20 [(SA404)]
ATtiny461V@SOIC20(ISP) [ISP-HEADER01]
ATtiny48                                ATtiny48@MLF32
[(SA686)]
ATtiny48@TQFP32 [(SA663)]
ATtiny48V                                ATtiny48V@TQFP32
[(SA663)]
ATtiny84                                ATtiny84(ISP) [ISP-
HEADER01]
ATtiny84@QFN20 [(SA692)]
ATtiny84@QFN20(ISP) [ISP-HEADER01]
ATtiny84@SOIC14 [(SA602)]
ATtiny84@SOIC14(ISP) [ISP-HEADER01]
ATtiny85
ATtiny85(ISP)(12V) [ISP-HEADER01]
ATtiny85(ISP)(5V) [ISP-HEADER01]    ATtiny85@QFN20
[(SA692)]
ATtiny85@QFN20(ISP)(12V) [ISP-HEADER01]
ATtiny85@QFN20(ISP)(5V) [ISP-HEADER01]
ATtiny85@SOIC8 [(S605)]
ATtiny85@SOIC8(ISP)(12V) [ISP-HEADER01]
ATtiny85@SOIC8(ISP)(5V) [ISP-HEADER01]
ATtiny861                                ATtiny861(ISP) [ISP-
HEADER01]
ATtiny861@MLP32 [(SA686)]
ATtiny861@MLP32(ISP) [ISP-HEADER01]
ATtiny861@SOIC20 [(SA404)]
ATtiny861@SOIC20(ISP) [ISP-HEADER01]
ATtiny861V                                ATtiny861V(ISP) [ISP-
HEADER01]
ATtiny861V@MLP32 [(SA686)]
ATtiny861V@MLP32(ISP) [ISP-HEADER01]

```

ATtiny861V@SOIC20 [(SA404)]	
ATtiny861V@SOIC20(ISP) [ISP-HEADER01]	
ATtiny88 [(SA686)]	ATtiny88@MLF32
ATtiny88@TQFP32 [(SA663)]	
ATtiny88V [(SA686)]	ATtiny88V@TQFP32
ATtiny88V@MLF32 [(SA663)]	
T89F64 [(SA244)]	T89F64@PLCC44
T89F64@TQFP44 [(SA245A)]	

ATMEL W&M

MICROCONTROLLER

AT89C5115@PLCC28 [(SA008A)] [(SA404)]	AT89C5115@SOIC28
AT89C5115@TQFP32 [(SA663)] [(SA008A)]	AT89C51CC02@PLCC28
AT89C51CC02@SOIC28 [(SA404)] [(SA663)]	AT89C51CC02@TQFP32
T89C5115@PLCC28 [(SA008A)] [(SA404)]	T89C5115@SOIC28
T89C5115@TQFP32 [(SA663)] [(SA244)]	T89C51AC2@PLCC44
T89C51AC2@TQFP44 [(SA245A)] [(SA244)]	T89C51CC01@PLCC44
T89C51CC01@TQFP44 [(SA245A)] [(SA008A)]	T89C51CC02@PLCC28
T89C51CC02@SOIC24 [(SA404)] [(SA404)]	T89C51CC02@SOIC28
T89C51CC02@TQFP32 [(SA663)] [(SA244)]	T89C51IB2@PLCC44
T89C51IB2@TQFP44 [(SA245A)] [(SA244)]	T89C51IC2@PLCC44
T89C51IC2@TQFP44 [(SA245A)]	
T89C51RB2	
T89C51RB2@PLCC44 [(SA244)] [(SA245A)]	T89C51RB2@TQFP44
T89C51RC2 [(SA244)]	T89C51RC2@PLCC44

T89C51RC2@TQFP44 [(SA245A)]	
T89C51RD2	
T89C51RD2@PLCC44 [(SA244)]	T89C51RD2@TQFP44
[(SA245A)]	
T89F64	
[(SA244)]	T89F64@PLCC44
T89F64@TQFP44 [(SA245A)]	
TS87C51RB2	
TS87C51RB2@PLCC44 [(SA244)]	TS87C51RB2@TQFP44
[(SA245A)]	
TS87C51RC2	
[(SA244)]	TS87C51RC2@PLCC44
TS87C51RC2@TQFP44 [(SA245A)]	
TS87C51RD2	
TS87C51RD2@PLCC44 [(SA244)]	TS87C51RD2@TQFP44
[(SA245A)]	
TS87C51U2	
[(SA244)]	TS87C51U2@PLCC44
TS87C51U2@TQFP44 [(SA245A)]	
TS87C52X2	
TS87C52X2@PLCC44 [(SA244)]	TS87C52X2@TQFP44
[(SA245A)]	
TS87C54X2	
[(SA244)]	TS87C54X2@PLCC44
TS87C54X2@TQFP44 [(SA245A)]	
TS87C58X2	
TS87C58X2@PLCC44 [(SA244)]	TS87C58X2@TQFP44
[(SA245A)]	
TSC87251A1@PLCC44 [(SA244)]	
TSC87251G1	
TSC87251G1@PLCC44 [(SA244)]	
TSC87251G1A	
TSC87251G1A@PLCC44 [(SA244)]	
TSC87251G2D	
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44
[(SA245A)]	
TSC87C51	
[(SA244)]	TSC87C51@PLCC44
TSC87C51@TQFP44 [(SA245A)]	

ATMEL-CUSTOMER

E (E) PROM / FRAM / NVRAM

AT24C01
AT24C02
AT24C04
AT24C08
AT24C16

AUSTIN

E (E) PROM / FRAM / NVRAM

AS8E512K8
[(SA661)]

AS8E512K8@SOJ32

BELLING-SYSTRON

MICROCONTROLLER

CM5001

BENCHMARK

E (E) PROM / FRAM / NVRAM

BQ4010
BQ4010Y
BQ4011
BQ4011Y
BQ4013
BQ4013Y
BQ4014
BQ4014Y
BQ4015
BQ4015Y
BQ4832Y
BQ4842Y

BRIGHT

E (E) PROM / FRAM / NVRAM

BM29F040 [(SA015A1T)]	BM29F040@PLCC32
BM29F040@TSOP32 [(SA410T)] B006)]	BM29F400B@PSOP44 [(SA638-
BM29F400B@TSOP48 [(SA247-B005)] B006)]	BM29F400T@PSOP44 [(SA638-
BM29F400T@TSOP48 [(SA247-B005)]	

CATALYST

E (E) PROM / FRAM / NVRAM

CAT1021 (L) (P)	CAT1021
CAT1021 (R) @ MSOP8 [(SA026)] [(SA602A)]	CAT1021 (S) @ SOIC8
CAT1021 (U) @ TSSOP8 [(SA026)] [(SA602A)]	CAT1021 (V) @ SOIC8
CAT1021 (Y) @ TSSOP8 [(SA026)] [(SA026)]	CAT1021 (Z) @ MSOP8
CAT1022 (L) (P)	CAT1022
CAT1022 (R) @ MSOP8 [(SA026)] [(SA602A)]	CAT1022 (S) @ SOIC8
CAT1022 (U) @ TSSOP8 [(SA026)] [(SA602A)]	CAT1022 (V) @ SOIC8
CAT1022 (Y) @ TSSOP8 [(SA026)] [(SA026)]	CAT1022 (Z) @ MSOP8
CAT1023 (L) (P)	CAT1023
CAT1023 (R) @ MSOP8 [(SA026)] [(SA602A)]	CAT1023 (S) @ SOIC8
CAT1023 (U) @ TSSOP8 [(SA026)] [(SA602A)]	CAT1023 (V) @ SOIC8
CAT1023 (Y) @ TSSOP8 [(SA026)] [(SA026)]	CAT1023 (Z) @ MSOP8
CAT1024 (L)	CAT1024

(P)	
CAT1024(R)@MSOP8 [(SA026)]	CAT1024(S)@SOIC8
[(SA602A)]	
CAT1024(U)@TSSOP8 [(SA026)]	CAT1024(V)@SOIC8
[(SA602A)]	
CAT1024(Y)@TSSOP8 [(SA026)]	CAT1024(Z)@MSOP8
[(SA026)]	
CAT1025(L)	CAT1025
(P)	
CAT1025(R)@MSOP8 [(SA026)]	CAT1025(S)@SOIC8
[(SA602A)]	
CAT1025(U)@TSSOP8 [(SA026)]	CAT1025(V)@SOIC8
[(SA602A)]	
CAT1025(Y)@TSSOP8 [(SA026)]	CAT1025(Z)@MSOP8
[(SA026)]	
CAT1026(L)	CAT1026
(P)	
CAT1026(R)@MSOP8 [(SA026)]	CAT1026(S)@SOIC8
[(SA602A)]	
CAT1026(U)@TSSOP8 [(SA026)]	CAT1026(V)@SOIC8
[(SA602A)]	
CAT1026(Y)@TSSOP8 [(SA026)]	CAT1026(Z)@MSOP8
[(SA026)]	
CAT1027(L)	CAT1027
(P)	
CAT1027(R)@MSOP8 [(SA026)]	CAT1027(S)@SOIC8
[(SA602A)]	
CAT1027(U)@TSSOP8 [(SA026)]	CAT1027(V)@SOIC8
[(SA602A)]	
CAT1027(Y)@TSSOP8 [(SA026)]	CAT1027(Z)@MSOP8
[(SA026)]	
CAT1161(J)@SOIC8 [(SA602A)]	CAT1161
(P)	
CAT1162(J)@SOIC8 [(SA602A)]	CAT1162
(P)	
CAT1163(J)@SOIC8 [(SA602A)]	CAT1163
(P)	
CAT1320	CAT1320@SOIC8
[(SA602A)]	
CAT1320@TDFN8	CAT1320@TSSOP8
[(SA026)]	
CAT1321	CAT1321@SOIC8
[(SA602A)]	

CAT1321@TDFN8 [(SA026)]	CAT1321@TSSOP8
CAT14002@SOIC8 [(SA602A)] [(SA602A)]	CAT14004@SOIC8
CAT14008@SOIC8 [(SA602A)] [(SA602A)]	CAT14016@SOIC8
CAT15002@SOIC8 [(SA602A)] [(SA602A)]	CAT15004@SOIC8
CAT15008@SOIC8 [(SA602A)] [(SA602A)]	CAT15016@SOIC8
CAT1640 [(SA602A)]	CAT1640@SOIC8
CAT1640@TDFN8 [(SA026)]	CAT1640@TSSOP8
CAT1641 [(SA602A)]	CAT1641@SOIC8
CAT1641@TDFN8 [(SA026)]	CAT1641@TSSOP8
CAT2210 [(SA404)]	CAT2210@SOIC16
CAT2210I [(SA404)]	CAT2210I@SOIC16
CAT2212 [(SA404)]	CAT2212@SOIC20
CAT2212I [(SA404)]	CAT2212I@SOIC20
CAT22C10 [(SA404)]	CAT22C10@SOIC16
CAT22C10I [(SA404)]	CAT22C10I@SOIC16
CAT22C12 [(SA404)]	CAT22C12@SOIC20
CAT22C12I [(SA404)]	CAT22C12I@SOIC20
CAT24AC128 [(SA602A)]	CAT24AC128@SOIC8
CAT24AC128@TSSOP14 [(SA026)] [(SA724)]	CAT24AC128@UDFN8
CAT24C00 [(SA602A)]	CAT24C00@SOIC8
CAT24C00@TSSOP8 [(SA026)]	
CAT24C01 [(SA602)]	CAT24C01@SOIC8

[(SA602A)]	
CAT24C01@TSSOP8 [(SA026)]	CAT24C01B(J)@SOIC8
[(SA602A)]	
CAT24C01B(L)	CAT24C01B
(P)	
CAT24C01B(R)@MSOP8 [(SA026)]	CAT24C01B(U)@TSSOP8
[(SA026)]	
CAT24C01B(W)@SOIC8 [(SA602A)]	CAT24C01B(Y)@TSSOP8
[(SA026)]	
CAT24C01B(Z)@MSOP8 [(SA026)]	
CAT24C02	
CAT24C02@SOIC14 [(SA602)]	CAT24C02@SOIC8
[(SA602A)]	
CAT24C02@TSSOP8 [(SA026)]	
CAT24C021	
CAT24C022	
CAT24C023	
CAT24C03	CAT24C03@SOIC8
[(SA602A)]	
CAT24C03@TSSOP8 [(SA026)]	
CAT24C04	
CAT24C04@SOIC14 [(SA602)]	CAT24C04@SOIC8
[(SA602A)]	
CAT24C04@TSSOP8 [(SA026)]	
CAT24C041	
CAT24C042	
CAT24C043	
CAT24C05	CAT24C05@SOIC8
[(SA602A)]	
CAT24C05@TSSOP8 [(SA026)]	
CAT24C08	
CAT24C08@SOIC14 [(SA602)]	CAT24C08@SOIC8
[(SA602A)]	
CAT24C08@TSSOP8 [(SA026)]	
CAT24C081	
CAT24C082	
CAT24C083	
CAT24C08I	CAT24C08I@SOIC8
[(SA602A)]	
CAT24C09	CAT24C09@SOIC8
[(SA602A)]	
CAT24C09@TSSOP8 [(SA026)]	
CAT24C128	

CAT24C128@SOIC8 [(SA602A)]	CAT24C128@UDFN8
[(SA724)]	
CAT24C16	CAT24C16@SOIC14
[(SA602)]	
CAT24C16@SOIC8 [(SA602A)]	CAT24C16@TSSOP8
[(SA026)]	
CAT24C161	
CAT24C162	
CAT24C163	
CAT24C164	
CAT24C164@SOIC8 [(SA602A)]	CAT24C164@TSSOP8
[(SA026)]	
CAT24C16I	CAT24C16I@SOIC8
[(SA602A)]	
CAT24C208(J)@SOIC8 [(SA602A)]	CAT24C208
(L)	
CAT24C208(P)	CAT24C208(R)@MSOP8
[(SA666)]	
CAT24C208(U)@TSSOP8 [(SA026)]	CAT24C208(W)@SOIC8
[(SA602A)]	
CAT24C208(Y)@TSSOP8 [(SA026)]	CAT24C208(Z)@MSOP8
[(SA666)]	
CAT24C21	CAT24C21@SOIC8
[(SA602A)]	
CAT24C21@TSSOP8 [(SA026)]	
CAT24C256	
CAT24C256@SOIC8 [(SA602A)]	CAT24C256@TDFN8
[(SA683)]	
CAT24C256@TSSOP8 [(SA026)]	
CAT24C32	
CAT24C32@SOIC8 [(SA602A)]	
CAT24C44	
CAT24C44@SOIC8 [(SA602A)]	
CAT24C64	
CAT24C64@SOIC8 [(SA602A)]	
CAT24F32	
CAT24F32@SOIC8 [(SA602A)]	CAT24F32@TSSOP8
[(SA026)]	
CAT24F32A	CAT24F32A@SOIC8
[(SA602A)]	
CAT24F32A@TSSOP8 [(SA026)]	
CAT24FC01	
CAT24FC01@SOIC14 [(SA602)]	CAT24FC01@SOIC8

[(SA602A)]	
CAT24FC01@TSSOP8 [(SA026)]	
CAT24FC02	
CAT24FC02@SOIC14 [(SA602)]	CAT24FC02@SOIC8
[(SA602A)]	
CAT24FC02@TSSOP8 [(SA026)]	
CAT24FC16	
CAT24FC16@SOIC14 [(SA602)]	CAT24FC16@SOIC8
[(SA602A)]	
CAT24FC16@TSSOP8 [(SA026)]	
CAT24FC17	
CAT24FC17@SOIC8 [(SA602A)]	CAT24FC17@TSSOP8
[(SA026)]	
CAT24FC256	CAT24FC256@SOIC8
[(SA602A)]	
CAT24FC256@TDFN8 [(SA683)]	CAT24FC256@TSSOP8
[(SA026)]	
CAT24FC32	CAT24FC32@SOIC8
[(SA602A)]	
CAT24FC32@TDFN8 [(SA683)]	CAT24FC32@TSSOP8
[(SA026)]	
CAT24FC64	CAT24FC64@SOIC8
[(SA602A)]	
CAT24FC64@TDFN8 [(SA683)]	CAT24FC64@TSSOP8
[(SA026)]	
CAT24FC65	CAT24FC65@SOIC8
[(SA602A)]	
CAT24FC65@TDFN8 [(SA683)]	CAT24FC65@TSSOP8
[(SA026)]	
CAT24FC66	CAT24FC66@SOIC8
[(SA602A)]	
CAT24FC66@TDFN8 [(SA683)]	CAT24FC66@TSSOP8
[(SA026)]	
CAT24LC02	CAT24LC02@SOIC8
[(SA602A)]	
CAT24LC02@TSSOP8 [(SA026)]	
CAT24WC01	
CAT24WC01@SOIC8 [(SA602A)]	CAT24WC01@TSSOP8
[(SA026)]	
CAT24WC02	CAT24WC02@SOIC8
[(SA602A)]	
CAT24WC02@TSSOP8 [(SA026)]	
CAT24WC03	

CAT24WC03@SOIC8 [(SA602A)]	CAT24WC03@TSSOP8
[(SA026)]	
CAT24WC04	CAT24WC04@SOIC8
[(SA602A)]	
CAT24WC04@TSSOP8 [(SA026)]	
CAT24WC05	
CAT24WC05@SOIC8 [(SA602A)]	CAT24WC05@TSSOP8
[(SA026)]	
CAT24WC08	CAT24WC08@SOIC8
[(SA602A)]	
CAT24WC08@TSSOP8 [(SA026)]	
CAT24WC09	
CAT24WC09@SOIC8 [(SA602A)]	CAT24WC09@TSSOP8
[(SA026)]	
CAT24WC128	CAT24WC128@SOIC8
[(SA602A)]	
CAT24WC129	CAT24WC129@SOIC8
[(SA602A)]	
CAT24WC16	CAT24WC16@SOIC8
[(SA602A)]	
CAT24WC16@TSSOP8 [(SA026)]	
CAT24WC164	
CAT24WC164@SOIC8 [(SA602A)]	CAT24WC164@TSSOP8
[(SA026)]	
CAT24WC17	CAT24WC17@SOIC8
[(SA602A)]	
CAT24WC17@TSSOP8 [(SA026)]	
CAT24WC256	
CAT24WC256@SOIC8 [(SA602A)]	CAT24WC256@TDFN8
[(SA683)]	
CAT24WC256@TSSOP8 [(SA026)]	
CAT24WC257	
CAT24WC257@SOIC8 [(SA605A)]	
CAT24WC32	
CAT24WC32@SOIC8 [(SA602A)]	
CAT24WC33	
CAT24WC33@SOIC8 [(SA602A)]	
CAT24WC64	
CAT24WC64@SOIC8 [(SA602A)]	
CAT24WC65	
CAT24WC65@SOIC8 [(SA602A)]	
CAT24WC66	
CAT24WC66@SOIC8 [(SA602A)]	

CAT25010	
CAT25010(S)@SOIC8 [(SA605A)]	CAT25010(U)@TSSOP8
[(SA602A)]	
CAT25020	CAT25020(S)@SOIC8
[(SA605A)]	
CAT25020(U)@TSSOP8 [(SA602A)]	
CAT25040	
CAT25040(S)@SOIC8 [(SA605A)]	CAT25040(U)@TSSOP8
[(SA602A)]	
CAT25080	CAT25080@SOIC8
[(SA602A)]	
CAT25080@TDFN8 [(SA724)]	CAT25080@TSSOP8
[(SA026)]	
CAT25080@UDFN8 [(BBBB)]	
CAT25128	
CAT25128@SOIC8[150 mil] [(SA602A)]	
CAT25128@SOIC8[208 mil] [(SA605A)]	
CAT25128@TDFN8 [(SA724)]	CAT25128@TSSOP8
[(SA026)]	
CAT25160	CAT25160@SOIC8
[(SA602A)]	
CAT25160@TDFN8 [(SA724)]	CAT25160@TSSOP8
[(SA026)]	
CAT25160@UDFN8 [(BBBB)]	
CAT25256	
CAT25256@SOIC8[150 mil] [(SA602A)]	
CAT25256@SOIC8[208 mil] [(SA605A)]	
CAT25256@TDFN8 [(SA602A)]	CAT25256@TSSOP8
[(SA026)]	
CAT25320	CAT25320@SOIC8
[(SA602A)]	
CAT25320@TDFN8 [(SA724)]	CAT25320@TSSOP8
[(SA026)]	
CAT25640	CAT25640@SOIC8
[(SA602A)]	
CAT25640@TDFN8 [(SA724)]	CAT25640@TSSOP8
[(SA026)]	
CAT25C01	CAT25C01@SOIC16
[(SA602)]	
CAT25C01@SOIC8 [(SA602A)]	CAT25C01@TSSOP14
[(SA026)]	
CAT25C01@TSSOP8 [(SA026)]	
CAT25C02	

CAT25C02@SOIC16 [(SA602)]	CAT25C02@SOIC8
[(SA602A)]	
CAT25C02@TSSOP14 [(SA026)]	CAT25C02@TSSOP8
[(SA026)]	
CAT25C03	CAT25C03@SOIC8
[(SA602A)]	
CAT25C03@TSSOP14 [(SA026)]	CAT25C03@TSSOP8
[(SA026)]	
CAT25C04	CAT25C04@SOIC16
[(SA602)]	
CAT25C04@SOIC8 [(SA602A)]	CAT25C04@TSSOP14
[(SA026)]	
CAT25C04@TSSOP8 [(SA026)]	
CAT25C05	
CAT25C05@SOIC8 [(SA602A)]	CAT25C05@TSSOP14
[(SA026)]	
CAT25C05@TSSOP8 [(SA026)]	
CAT25C08	
CAT25C08@SOIC16 [(SA602)]	CAT25C08@SOIC8
[(SA602A)]	
CAT25C08@TSSOP14 [(SA026)]	CAT25C08@TSSOP8
[(SA026)]	
CAT25C09	CAT25C09@SOIC8
[(SA602A)]	
CAT25C09@TSSOP14 [(SA026)]	CAT25C09@TSSOP8
[(SA026)]	
CAT25C11	CAT25C11@SOIC8
[(SA602A)]	
CAT25C11@TSSOP14 [(SA026)]	CAT25C11@TSSOP8
[(SA026)]	
CAT25C128	CAT25C128@SOIC16
[(SA602)]	
CAT25C128@SOIC8[150 mil] [(SA602A)]	
CAT25C128@SOIC8[208 mil] [(SA605A)]	
CAT25C128@TSSOP14 [(SA026)]	CAT25C128@TSSOP20
[(SA026)]	
CAT25C16	CAT25C16@SOIC16
[(SA602)]	
CAT25C16@SOIC8 [(SA602A)]	CAT25C16@TSSOP14
[(SA026)]	
CAT25C16@TSSOP8 [(SA026)]	
CAT25C17	
CAT25C17@SOIC8 [(SA602A)]	CAT25C17@TSSOP14

[(SA026)]	
CAT25C17@TSSOP8 [(SA026)]	
CAT25C256	
CAT25C256@SOIC16 [(SA602)]	
CAT25C256@SOIC8[150 mil] [(SA602A)]	
CAT25C256@SOIC8[208 mil] [(SA605A)]	
CAT25C256@TSSOP14 [(SA026)]	CAT25C256@TSSOP20
[(SA026)]	
CAT25C32	CAT25C32@SOIC8
[(SA602A)]	
CAT25C32@TSSOP14 [(SA026)]	CAT25C32@TSSOP20
[(SA026)]	
CAT25C33	CAT25C33@SOIC8
[(SA602A)]	
CAT25C33@TSSOP14 [(SA026)]	
CAT25C64	
CAT25C64@SOIC8 [(SA602A)]	CAT25C64@TSSOP14
[(SA026)]	
CAT25C64@TSSOP20 [(SA026)]	
CAT25C65	
CAT25C65@SOIC8 [(SA602A)]	CAT25C65@TSSOP14
[(SA026)]	
CAT27010	CAT27010@PLCC32
[(SA015A1T)]	
CAT27010@TSOP32 [(SA410T)]	
CAT27128A	
CAT27256	
CAT27512	
CAT27512@PLCC32 [(SA015A1T)]	
CAT2764A	
CAT27C16A	
CAT27C210	
CAT27C210@PLCC44 [(SA244)]	
CAT27HC256	
CAT27HC256@PLCC32 [(SA015A1T)]	
CAT27HC256I	
CAT27HC256I@PLCC32 [(SA015A1T)]	
CAT28C16A	
CAT28C16A@PLCC32 [(SA015A1T)]	CAT28C16A@SOIC24
[(SA404)]	
CAT28C16AI	CAT28C16AI@PLCC32
[(SA015A1T)]	
CAT28C16AI@SOIC24 [(SA404)]	

CAT28C17A	
CAT28C17A@PLCC32 [(SA015A1T)]	
CAT28C17AI	
CAT28C17AI@PLCC32 [(SA015A1T)]	
CAT28C256	
CAT28C256@PLCC32 [(SA015A1T)]	CAT28C256@TSOP28
[(SA430T)]	
CAT28C256I	CAT28C256I@PLCC32
[(SA015A1T)]	
CAT28C256I@TSOP28 [(SA430T)]	
CAT28C257	
CAT28C257@PLCC32 [(SA015A1T)]	CAT28C257@TSOP28
[(SA430T)]	
CAT28C512	CAT28C512@PLCC32
[(SA015A1T)]	
CAT28C512@TSOP32 [(SA410T)]	CAT28C512@TSOP40
[(SA409T)]	
CAT28C513@PLCC32 [(SA015A1T)]	
CAT28C64A	
CAT28C64A@PLCC32 [(SA015A1T)]	CAT28C64A@SOIC28
[(SA404)]	
CAT28C64AI	CAT28C64AI@PLCC32
[(SA015A1T)]	
CAT28C64AI@SOIC28 [(SA404)]	
CAT28C64B	
CAT28C64B@PLCC32 [(SA015A1T)]	CAT28C64B@TSOP28
[(SA430T)]	
CAT28C64BI	CAT28C64BI@PLCC32
[(SA015A1T)]	
CAT28C64BI@TSOP28 [(SA430T)]	
CAT28C65B	
CAT28C65B@PLCC32 [(SA015A1T)]	CAT28C65B@TSOP28
[(SA430T)]	
CAT28C65BI	CAT28C65BI@PLCC32
[(SA015A1T)]	
CAT28C65BI@TSOP28 [(SA430T)]	CAT28F001N-B@PLCC32
[(SA015A1T)]	
CAT28F001N-T@PLCC32 [(SA015A1T)]	CAT28F001P-
B	
CAT28F001P-T	CAT28F001T-B@TSOP32
[(SA410T)]	
CAT28F001T-T@TSOP32 [(SA410T)]	
CAT28F002	

CAT28F002@TSOP40 [(SA409T)]	
CAT28F010	
CAT28F010@PLCC32 [(SA015A1T)]	CAT28F010@TSOP32
[(SA410T)]	
CAT28F010I	CAT28F010I@PLCC32
[(SA015A1T)]	
CAT28F010I@TSOP32 [(SA410T)]	
CAT28F020	
CAT28F020(REVERSE)@TSOP32 [(SA410T)]	
CAT28F020@PLCC32 [(SA015A1T)]	CAT28F020@TSOP32
[(SA410T)]	
CAT28F020I	CAT28F020I@PLCC32
[(SA015A1T)]	
CAT28F020I@TSOP32 [(SA410T)]	
CAT28F102	
CAT28F102@PLCC44 [(SA244)]	CAT28F102@TSOP40
[(SA409T)]	
CAT28F512	CAT28F512@PLCC32
[(SA015A1T)]	
CAT28F512@TSOP32 [(SA410T)]	
CAT28F512I	
CAT28F512I@PLCC32 [(SA015A1T)]	CAT28F512I@TSOP32
[(SA410T)]	
CAT28LV256	CAT28LV256@PLCC32
[(SA015A1T)]	
CAT28LV256@TSOP28 [(SA430T)]	
CAT28LV64	
CAT28LV64@PLCC32 [(SA015A1T)]	CAT28LV64@TSOP28
[(SA430T)]	
CAT28LV65	CAT28LV65@PLCC32
[(SA015A1T)]	
CAT28LV65@TSOP28 [(SA430T)]	CAT33C101
(08bit)	
CAT33C101(08bit)@SOIC8 [(SA602A)]	
CAT33C101(16bit)	
CAT33C101(16bit)@SOIC8 [(SA602A)]	
CAT33C101H(08bit)	
CAT33C101H(08bit)@SOIC8 [(SA602A)]	
CAT33C101H(16bit)	
CAT33C101H(16bit)@SOIC8 [(SA602A)]	
CAT33C101I(08bit)	
CAT33C101I(08bit)@SOIC8 [(SA602A)]	
CAT33C101I(16bit)	

CAT33C101I(16bit)@SOIC8 [(SA602A)]	
CAT33C104(08bit)	
CAT33C104(08bit)@SOIC8 [(SA602A)]	
CAT33C104(16bit)	
CAT33C104(16bit)@SOIC8 [(SA602A)]	
CAT33C104I(08bit)	
CAT33C104I(08bit)@SOIC8 [(SA602A)]	
CAT33C104I(16bit)	
CAT33C104I(16bit)@SOIC8 [(SA602A)]	
CAT34AC02	CAT34AC02@SOIC8
[(SA602A)]	
CAT34AC02@TSSOP8 [(SA026)]	
CAT34C02	
CAT34C02@SOIC8 [(SA602A)]	CAT34C02@TDFN8
[(SA694)]	
CAT34C02@TSSOP8 [(SA026)]	
CAT34FC02	
CAT34FC02@SOIC8 [(SA602A)]	CAT34FC02@TDFN8
[(SA694)]	
CAT34FC02@TSSOP8 [(SA026)]	
CAT34RC02	
CAT34RC02@SOIC8 [(SA602A)]	CAT34RC02@TDFN8
[(SA694)]	
CAT34RC02@TSSOP8 [(SA026)]	
CAT34WC02	
CAT34WC02@SOIC8 [(SA602A)]	CAT34WC02@TDFN8
[(SA694)]	
CAT34WC02@TSSOP8 [(SA026)]	
CAT35C102	
CAT35C102H	
CAT35C102I	
CAT35C104(08bit)	
CAT35C104(08bit)@SOIC8 [(SA602A)]	
CAT35C104(16bit)	
CAT35C104(16bit)@SOIC8 [(SA602A)]	
CAT35C104H(08bit)	
CAT35C104H(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(08bit)	
CAT35C104I(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(16bit)	
CAT35C104I(16bit)@SOIC8 [(SA602A)]	
CAT59C11	CAT59C11@SOIC8
[(SA602A)]	

CAT59C11A [(SA602A)]	CAT59C11A@SOIC8
CAT59C11H [(SA602A)]	CAT59C11H@SOIC8
CAT59C11I [(SA602A)]	CAT59C11I@SOIC8
CAT64LC10(J)@SOIC8 [(SA602A)] (P)	CAT64LC10
CAT64LC10(S)@SOIC8 [(SA602A)] [(SA026)]	CAT64LC10(U)@TSSOP8
CAT64LC10(UR)@TSSOP8 [(SA026)] [(SA602A)]	CAT64LC20(J)@SOIC8
CAT64LC20(P) [(SA602A)]	CAT64LC20(S)@SOIC8
CAT64LC20(U)@TSSOP8 [(SA026)] [(SA026)]	CAT64LC20(UR)@TSSOP8
CAT64LC40(J)@SOIC8 [(SA602A)] (P)	CAT64LC40
CAT64LC40(S)@SOIC8 [(SA602A)] [(SA026)]	CAT64LC40(U)@TSSOP8
CAT64LC40(UR)@TSSOP8 [(SA026)] (08bit)	CAT93C46
CAT93C46(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C46(16bit)	
CAT93C46(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(16bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(U)@TSSOP8 [(SA026)]	
CAT93C46A (08bit)	CAT93C56
CAT93C56(08bit)@SOIC8 [(SA602A)] (16bit)	CAT93C56
CAT93C56(16bit)@SOIC8 [(SA602A)]	
CAT93C56A	
CAT93C57 (08bit)	CAT93C66
CAT93C66(08bit)@SOIC8 [(SA602A)] [(SA026)]	CAT93C66(08bit)@TSSOP8
CAT93C66(16bit) [(SA602A)]	CAT93C66(16bit)@SOIC8

CAT93C66(16bit)@TSSOP8 [(SA026)]
CAT93C66A
CAT93C76(08bit)
CAT93C76(08bit)(J)@SOIC8 [(SA602A)]
CAT93C76(08bit)(K)@SOIC8 [(SA605A)]
CAT93C76(08bit)(S)@SOIC8 [(SA602A)]
CAT93C76(08bit)(U)@TSSOP8 [(SA026)]
CAT93C76(16bit)
CAT93C76(16bit)(J)@SOIC8 [(SA602A)]
CAT93C76(16bit)(K)@SOIC8 [(SA605A)]
CAT93C76(16bit)(S)@SOIC8 [(SA602A)]
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]
CAT93C86(08bit)
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]
CAT93C86(08bit)(K)@SOIC8 [(SA605A)]
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]
CAT93C86(16bit)
CAT93C86(16bit)(J)@SOIC8 [(SA602A)]
CAT93C86(16bit)(K)@SOIC8 [(SA605A)]
CAT93C86(16bit)(S)@SOIC8 [(SA602A)]
CAT93C86(16bit)(U)@TSSOP8 [(SA026)]
CAT93H46(08bit)
CAT93H46(08bit)(J)@SOIC8 [(SA602A)]
CAT93H46(08bit)(K)@SOIC8 [(SA605A)]
CAT93H46(08bit)(S)@SOIC8 [(SA602A)]
CAT93H46(08bit)(U)@TSSOP8 [(SA026)]
CAT93H46(16bit)
CAT93H46(16bit)(J)@SOIC8 [(SA602A)]
CAT93H46(16bit)(K)@SOIC8 [(SA605A)]
CAT93H46(16bit)(S)@SOIC8 [(SA602A)]
CAT93H46(16bit)(U)@TSSOP8 [(SA026)]
CAT93HC46(08bit)
CAT93HC46(08bit)(J)@SOIC8 [(SA602A)]
CAT93HC46(08bit)(K)@SOIC8 [(SA605A)]
CAT93HC46(08bit)(S)@SOIC8 [(SA602A)]
CAT93HC46(08bit)(U)@TSSOP8 [(SA026)]
CAT93HC46(16bit)
CAT93HC46(16bit)(J)@SOIC8 [(SA602A)]
CAT93HC46(16bit)(K)@SOIC8 [(SA605A)]
CAT93HC46(16bit)(S)@SOIC8 [(SA602A)]
CAT93HC46(16bit)(U)@TSSOP8 [(SA026)]

DRAM & SRAM

CAT71C256

[(SA643)]

CAT71C256L

[(SA643)]

CAT71C256@TSOP28

CAT71C256L@TSOP28

CELESTICA

E (E) PROM / FRAM / NVRAM

SST49LF160C@TSOP40 [(SA409T)]

CERAMATE

E (E) PROM / FRAM / NVRAM

24LC02

[(SA602A)]

24LC02@TSSOP8 [(SA026)]

24LC08

24LC08@SOIC8 [(SA602A)]

[(SA026)]

24LC16

[(SA602A)]

24LC16@TSSOP8 [(SA026)]

24LLC02

24LLC02@SOIC8 [(SA602A)]

[(SA026)]

24LLC08

[(SA602A)]

24LLC08@TSSOP8 [(SA026)]

93LC46

93LC46@SOIC8 [(SA602A)]

93LC46R

93LC46R@SOIC8 [(SA602A)]

93LC56

93LC56@SOIC8 [(SA602A)]

93LC66

93LC66@SOIC8 [(SA602A)]

24LC02@SOIC8

24LC08@TSSOP8

24LC16@SOIC8

24LLC02@TSSOP8

24LLC08@SOIC8

CHINA CORE

MICROCONTROLLER

CCM89C51 [(SA244)]	CCM89C51@PLCC44
CCM89C51@TQFP44 [(SA245A)]	
CCM89C52 CCM89C52@PLCC44 [(SA244)] [(SA245A)]	CCM89C52@TQFP44

CHINGIS

E (E) PROM / FRAM / NVRAM

PM24C64 [(SA602A)]	PM24C64@SOIC8
PM24C64@TSOP8 [(SA026)] [(SA023A)]	PM25LV010 (B) @SOIC8
PM25LV010 (Q) @WSON8 [(SA683)] [(SA602A)]	PM25LV010 (S) @SOIC8
PM25LV010A@SOIC8 [(SA602A)] [(SA683)]	PM25LV010A@WSON8
PM25LV016@SOIC8 [(SA605A)] [(SA683)]	PM25LV016@WSON8
PM25LV016A@SOIC8 [(SA605A)] [(SA683)]	PM25LV016A@WSON8
PM25LV020 (B) @SOIC8 [(SA023A)] [(SA683)]	PM25LV020 (Q) @WSON8
PM25LV020 (S) @SOIC8 [(SA602A)] [(SA023A)]	PM25LV040 (B) @SOIC8
PM25LV040 (Q) @WSON8 [(SA683)] [(SA602A)]	PM25LV040 (S) @SOIC8
PM25LV080@SOIC8 [(SA605A)] [(SA683)]	PM25LV080@WSON8
PM25LV080A@SOIC8 [(SA605A)] [(SA683)]	PM25LV080A@WSON8
PM25LV512 (B) @SOIC8 [(SA023A)] [(SA683)]	PM25LV512 (Q) @WSON8

PM25LV512(S)@SOIC8 [(SA602A)]	
PM29F002B	
PM29F002B@PLCC32 [(SA015A1T)]	
PM29F002T	
PM29F002T@PLCC32 [(SA015A1T)]	
PM29F004B	
PM29F004B@PLCC32 [(SA015A1T)]	
PM29F004T	
PM29F004T@PLCC32 [(SA015A1T)]	
PM29LV002B	
PM29LV002B@PLCC32 [(SA015A1T)]	PM29LV002B@VSOP32
[(SA620)]	
PM29LV002T	PM29LV002T@PLCC32
[(SA015A1T)]	
PM29LV002T@VSOP32 [(SA620)]	PM29LV004B@PLCC32
[(SA015A1T)]	
PM29LV004B@VSOP32 [(SA620)]	PM29LV004T@PLCC32
[(SA015A1T)]	
PM29LV004T@VSOP32 [(SA620)]	PM29LV104RB@PLCC32
[(SA015A1T)]	
PM29LV104RB@VSOP32 [(SA620)]	PM29LV104RT@PLCC32
[(SA015A1T)]	
PM29LV104RT@VSOP32 [(SA620)]	
PM37LV512	
PM37LV512@PLCC32 [(SA015A1T)]	PM37LV512@VSOP32
[(SA620)]	
PM39F010	PM39F010@PLCC32
[(SA015A1T)]	
PM39F010@VSOP32 [(SA620)]	
PM39F020	
PM39F020@PLCC32 [(SA015A1T)]	PM39F020@VSOP32
[(SA620)]	
PM39F040	PM39F040@PLCC32
[(SA015A1T)]	
PM39F040@VSOP32 [(SA620)]	PM39LV010@PLCC32
[(SA015A1T)]	
PM39LV010@VSOP32 [(SA620)]	PM39LV010R@PLCC32
[(SA015A1T)]	
PM39LV010R@VSOP32 [(SA620)]	PM39LV020@PLCC32
[(SA015A1T)]	
PM39LV020@VSOP32 [(SA620)]	PM39LV040@PLCC32
[(SA015A1T)]	
PM39LV040@VSOP32 [(SA620)]	PM39LV512@PLCC32

[(SA015A1T)]	
PM39LV512@VSOP32 [(SA620)]	PM39LV512R@PLCC32
[(SA015A1T)]	
PM39LV512R@VSOP32 [(SA620)]	PM49FL002T@PLCC32
[(SA015A1T)]	
PM49FL002T@VSOP32 [(SA620)]	
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)]	PM49FL004T@VSOP32
[(SA620)]	
PM49FL008T@PLCC32 [(SA015A1T)]	PM49FL008T@VSOP32
[(SA620)]	
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32
[(SA620)]	

CHIPCON

MICROCONTROLLER

CC1010@TQFP64(ISP) [ISP-HEADER01]

CHIPSWINNER

E(E) PROM/FRAM/NVRAM

CW24C02	CW24C02@SOIC8
[(SA602A)]	
CW24C04	CW24C04@SOIC8
[(SA602A)]	
CW24C08	CW24C08@SOIC8
[(SA602A)]	
CW24C16	CW24C16@SOIC8
[(SA602A)]	
CW24C32	CW24C32@SOIC8
[(SA602A)]	
CW24C64	CW24C64@SOIC8
[(SA602A)]	

MICROCONTROLLER

CW88CS028@SDIP28 [(SA653)]
[(SA653)]
CW88CS128@SDIP28 [(SA653)]
[(SA653)]
CW89F1050
CW89F2050
CW89F4050@SDIP28 [(SA653)]
[(SA404)]
CW89F52
[(SA675)]
CW89F54
[(SA675)]

CW88CS032@SDIP32
CW88CS132@SDIP32
CW89F4050@SOP28
CW89F52@LQFP44
CW89F54@LQFP44

CORERIVER

E (E) PROM / FRAM / NVRAM

CR24C02LI
[(SA602)]
CR24C08LI
[(SA602)]
CR24C16LI
[(SA602)]
CR24C256LI
[(SA602)]
CR24C32LI
[(SA602)]
CR24C64LI
[(SA602)]

CR24C02WI@SOIC8
CR24C08WI@SOIC8
CR24C16WI@SOIC8
CR24C256WI@SOIC8
CR24C32WI@SOIC8
CR24C64WI@SOIC8

CWI

E (E) PROM / FRAM / NVRAM

39LV040@VSOP32 [(SA620)]

CYGNAL

MICROCONTROLLER

C8051F000@TQFP64(ISP) [(PEP+S616)]
C8051F001@TQFP48(ISP) [(SA248)] C8051F002@TQFP32(ISP)
[(SA663)]
C8051F005@TQFP64(ISP) [(PEP+S616)]
C8051F006@TQFP48(ISP) [(SA248)] C8051F007@TQFP32(ISP)
[(SA663)]
C8051F010@TQFP64(ISP) [(PEP+S616)]
C8051F011@TQFP48(ISP) [(SA248)] C8051F012@TQFP32(ISP)
[(SA663)]
C8051F015@TQFP64(ISP) [(PEP+S616)]
C8051F016@TQFP48(ISP) [(SA248)] C8051F017@TQFP32(ISP)
[(SA663)]
C8051F018@TQFP64(ISP) [(PEP+S616)]
C8051F019@TQFP48(ISP) [(SA248)]
C8051F020@TQFP100(ISP) [ISP-HEADER01]
C8051F021@TQFP64(ISP) [ISP-HEADER01]
C8051F022@TQFP100(ISP) [ISP-HEADER01]
C8051F023@TQFP64(ISP) [ISP-HEADER01]
C8051F040@TQFP100(ISP) [ISP-HEADER01]
C8051F041@TQFP64(ISP) [ISP-HEADER01]
C8051F042@TQFP100(ISP) [ISP-HEADER01]
C8051F043@TQFP64(ISP) [ISP-HEADER01]
C8051F044@TQFP100(ISP) [ISP-HEADER01]
C8051F045@TQFP64(ISP) [ISP-HEADER01]
C8051F046@TQFP100(ISP) [ISP-HEADER01]
C8051F047@TQFP64(ISP) [ISP-HEADER01]
C8051F206@TQFP48 [(SA248)] C8051F220@TQFP48
[(SA248)]
C8051F221@TQFP32 [(SA663)] C8051F226@TQFP48
[(SA248)]
C8051F230@TQFP48 [(SA248)] C8051F231@TQFP32
[(SA663)]
C8051F236@TQFP48 [(SA248)] C8051F300
[(SA695A)]
C8051F301 [(SA695A)] C8051F302
[(SA695A)]
C8051F303 [(SA695A)] C8051F304
[(SA695A)]
C8051F305 [(SA695A)] C8051F310@TQFP32
[(SA663)]
C8051F310-GQ@TQFP32 [(SA663)] C8051F311@QFN28 [(SA697-
B006)]

C8051F311-GM@QFN28 [(SA697-B006)]	
C8051F312@TQFP32 [(SA663)]	C8051F312-GQ@TQFP32
[(SA663)]	
C8051F313@QFN28 [(SA697-B006)]	
C8051F313-GM@QFN28 [(SA697-B006)]	
C8051F314@TQFP32 [(SA663)]	C8051F314-GQ@TQFP32
[(SA663)]	
C8051F315@QFN28 [(SA697-B006)]	
C8051F315-GM@QFN28 [(SA697-B006)]	
C8051F316-GM@QFN24 [(SA710-B006)]	
C8051F317-GM@QFN24 [(SA710-B006)]	
C8051F320@TQFP32 [(SA663)]	C8051F321@QFN28 [(SA697-
B006)]	
C8051F326@QFN28 [(SA697-B006)]	
C8051F326-GQ@QFN28 [(SA697-B006)]	
C8051F327@QFN28 [(SA697-B006)]	
C8051F327-GQ@QFN28 [(SA697-B006)]	
C8051F330@MLP20 [(SA692)]	
C8051F330D	
C8051F331@MLP20 [(SA692)]	C8051F332-GM@MLP20
[(SA692)]	
C8051F333-GM@MLP20 [(SA692)]	C8051F334-GM@MLP20
[(SA692)]	
C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20
[(SA692)]	
C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24
[(SA710)]	
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48
[(SA248)]	
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32
[(SA663)]	
C8051F343-GQ@LQFP32 [(SA663)]	C8051F344-GQ@TQFP48
[(SA248)]	
C8051F345-GQ@TQFP48 [(SA248)]	C8051F346-GQ@LQFP32
[(SA663)]	
C8051F347-GQ@LQFP32 [(SA663)]	C8051F350-GQ@LQFP32
[(SA663)]	
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F410-GQ@LQFP32 [(SA663)]	C8051F411-GM@QFN28
[(SA697)]	
C8051F412-GQ@LQFP32 [(SA663)]	C8051F413-GM@QFN28

[(SA697)]	
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10
[(SA695A)]	
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10
[(SA695A)]	
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10
[(SA695A)]	
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20
[(SA026)]	
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20
[(SA026)]	
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20
[(SA026)]	
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20
[(SA026)]	
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20
[(SA026)]	
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20
[(SA026)]	
C8051F610-GQ@QFP32 [(SA663)]	
C8051F611-GM@QFN28 [(SA697-B006)]	
C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	
SI8250@LQFP32 [(SA663)]	SI8250@QFN28
[(SA697)]	
SI8251@LQFP32 [(SA663)]	SI8251@QFN28
[(SA697)]	
SI8252@LQFP32 [(SA663)]	SI8252@QFN28
[(SA697)]	

CYPRESS

E (E) PROM / FRAM / NVRAM

CY14B256L@SOIC32 [(SA715)]	
CY27C010	
CY27C010@PLCC32 [(SA015A1T)]	CY27C010@TSOP32
[(SA410T)]	

CY27C020 [(SA015A1T)]	CY27C020@PLCC32
CY27C020@TSOP32 [(SA410T)]	
CY27C040 CY27C040@PLCC32 [(SA015A1T)]	CY27C040@TSOP32
[(SA410T)]	
CY27C128 [(SA015A1T)]	CY27C128@PLCC32
CY27C256 [(SA015A1T)]	CY27C256@PLCC32
CY27C256@TSOP28 [(SA430T)]	
CY27C512 CY27C512@PLCC32 [(SA015A1T)]	CY27C512@TSOP28
[(SA430T)]	
CY27H010 [(SA015A1T)]	CY27H010@PLCC32
CY27H010@TSOP32 [(SA410T)]	
CY27H256 CY27H256@PLCC32 [(SA015A1T)]	CY27H256@TSOP28
[(SA430T)]	
CY27H512 [(SA015A1T)]	CY27H512@PLCC32
CY27H512@TSOP28 [(SA430T)]	
CY7C225A CY7C225A@PLCC28 [(SA008A)]	
CY7C243 CY7C243@PLCC28 [(SA008A)]	
CY7C244 CY7C244@PLCC28 [(SA008A)]	
CY7C245 CY7C245@PLCC28 [(SA008A)]	
CY7C245A CY7C245A@PLCC28 [(SA008A)]	
CY7C251 CY7C251@PLCC32 [(SA015A1T)]	
CY7C254 CY7C254@PLCC32 [(SA015A1T)]	
CY7C256 CY7C256@PLCC32 [(SA015A1T)]	
CY7C261 CY7C261@PLCC28 [(SA008A)]	
CY7C263 CY7C263@PLCC28 [(SA008A)]	

CY7C264	
CY7C264@PLCC28 [(SA008A)]	
CY7C265	
CY7C265@PLCC28 [(SA008A)]	
CY7C266	
CY7C266@PLCC32 [(SA015A1T)]	
CY7C268	
CY7C268@PLCC32 [(SA015A1T)]	
CY7C271	
CY7C271@PLCC32 [(SA015A1T)]	
CY7C271A	
CY7C271A@PLCC32 [(SA015A1T)]	
CY7C274	
CY7C274@PLCC32 [(SA015A1T)]	CY7C276(25HC)@PLCC44
[(SA244)]	
CY7C276(25JC)@PLCC44 [(SA244)]	CY7C276(30JC)@PLCC44
[(SA244)]	
CY7C281	CY7C281@PLCC28
[(SA008A)]	
CY7C281A	CY7C281A@PLCC28
[(SA008A)]	
CY7C282	CY7C282@PLCC28
[(SA008A)]	
CY7C282A	CY7C282A@PLCC28
[(SA008A)]	
CY7C285	CY7C285@PLCC32
[(SA015A1T)]	
CY7C286	CY7C286@PLCC32
[(SA015A1T)]	
CY7C287	CY7C287@PLCC32
[(SA015A1T)]	
CY7C291	CY7C291@PLCC28
[(SA008A)]	
CY7C291A	CY7C291A@PLCC28
[(SA008A)]	
CY7C292	CY7C292@PLCC28
[(SA008A)]	
CY7C292A	CY7C292A@PLCC28
[(SA008A)]	
CY7C293A	CY7C293A@PLCC28
[(SA008A)]	
CY8C9520@SSOP28 [(SA626A)]	CY8C9540@SSOP48
[(SA669)]	

DRAM & SRAM

CY62128@SOIC32 [(SA687)]	CY62128@SOJ32
[(SA661)]	
CY62128@VSOP32 [(SA620)]	CY62128L@SOIC32
[(SA687)]	
CY62128L@SOJ32 [(SA661)]	CY62128L@VSOP32
[(SA620)]	
CY62128LL@SOIC32 [(SA687)]	CY62128LL@SOJ32
[(SA661)]	
CY62128LL@VSOP32 [(SA620)]	CY7C1011@TSOP44
[(SA645)]	
CY7C1020@TSOP44 [(SA645)]	CY7C1021@TSOP44
[(SA645)]	
CY7C1049@SOJ36 [(SA027)]	CY7C1049@TSOP44
[(SA645)]	
CY7C107	CY7C107@SOJ28
[(SA661)]	
CY7C147	
CY7C167	
CY7C167@PLCC20 [(SA001A)]	
CY7C167A	
CY7C167A@PLCC20 [(SA001A)]	
CY7C185	
CY7C185@SOIC28 [(SA404)]	CY7C185@SOJ28
[(SA646)]	
CY7C186	
CY7C187	
CY7C187@SOJ24 [(SA646)]	
CY7C187A	
CY7C187A@SOJ24 [(SA646)]	
CY7C193	
CY7C193@SOJ28 [(SA646)]	
CY7C199	
CY7C199@PLCC28 [(SA008A)]	CY7C199@SOJ28
[(SA646)]	
CY7C199@TSOP28 [(SA430T)]	

PLD

PALC16L8 [(SA001A)]	PALC16L8@PLCC20
PALC16L8L [(SA001A)]	PALC16L8L@PLCC20
PALC16R4 [(SA001A)]	PALC16R4@PLCC20
PALC16R4L [(SA001A)]	PALC16R4L@PLCC20
PALC16R6 [(SA001A)]	PALC16R6@PLCC20
PALC16R6L [(SA001A)]	PALC16R6L@PLCC20
PALC16R8 [(SA001A)]	PALC16R8@PLCC20
PALC16R8L [(SA001A)]	PALC16R8L@PLCC20
PALC22V10 [(SA008A)]	PALC22V10@PLCC28
PALC22V10A [(SA008A)]	PALC22V10A@PLCC28
PALC22V10B [(SA008A)]	PALC22V10B@PLCC28
PALC22V10D [(SA008A)]	PALC22V10D@PLCC28
PALC22V10L [(SA008A)]	PALC22V10L@PLCC28
PALCE16V8 [(SA001A)]	PALCE16V8@PLCC20
PALCE20V8 [(SA008A)]	PALCE20V8@PLCC28
PALCE20V8L [(SA008A)]	PALCE20V8L@PLCC28
PALCE22V10 [(SA008A)]	PALCE22V10@PLCC28

DALLAS

[E \(E \) PROM / FRAM / NVRAM](#)

DS1073M-100 60	DS1073M-
DS1073M-66	DS1073M-

80

DS1073Z-100@SOIC8 [(SA602A)]
[(SA602A)]
DS1073Z-66@SOIC8 [(SA602A)]
[(SA602A)]
DS1077LZ-40@SOIC8 [(SA602A)]
[(SA602A)]
DS1077LZ-60@SOIC8 [(SA602A)]
[(SA602A)]
DS1077Z-40@SOIC8 [(SA602A)]
[(SA602A)]
DS1077Z-60@SOIC8 [(SA602A)]
[(SA602A)]

DS1073Z-60@SOIC8
DS1073Z-80@SOIC8
DS1077LZ-50@SOIC8
DS1077LZ-66@SOIC8
DS1077Z-50@SOIC8
DS1077Z-66@SOIC8

DS1220AB
DS1220AD
DS1220Y
DS1225AB
DS1225AD
DS1225D
DS1225E
DS1225Y
DS1230AB
DS1230W
DS1230Y
DS1235AB
DS1235Y
DS1243Y
DS1244
DS1244Y
DS1245AB
DS1245EE
DS1245P
DS1245W
DS1245Y
DS1248P
DS1248W
DS1248Y
DS1249AB
DS1249W
DS1249Y
DS1250AB
DS1250W
DS1250Y

DS1251AB
DS1251W
DS1251Y
DS1256P
DS1256W
DS1256Y
DS1258AB
DS1258W
DS1258Y
DS1265AB
DS1265W
DS1265Y
DS1270AB
DS1270W
DS1270Y
DS1284
DS1284N
DS1284Q@PLCC28
[(SA008A)]
DS1284QN@PLCC28 [(SA008A)]
DS1286
DS1286I
DS1287
DS1287A
DS12887
DS12887A
DS12C887
DS12C887A
DS1330AB
DS1330WP
DS1330Y
DS1345AB
DS1345P
DS1345W
DS1345Y
DS1350AB
DS1350P
DS1350W
DS1350Y
DS1386 (32K)
DS1386 (8K)
DS14285
DS14287
DS1485
DS1386
DS1485@SOIC28

[(SA630)]

DS1486

DS1488

DS1553

DS1553W

DS1554

DS1554W

DS1556

DS1630AB

DS1630Y

DS1642

DS1643

DS1644

DS1644P

DS1645AB

DS1645EE

DS1645Y

DS1646

DS1647

DS1647LPM

DS1650AB

DS1650Y

DS1687-

3

DS1687-5

DS17287-

3

DS17287-5

DS1742

DS1742W

DS1743

DS1743P

DS1743W

DS1743WP

DS1744

DS1744P

DS1744W

DS1744WP

DS1746

DS1747

DS1747P

DS1747W

DS1747WP

DS17487-3

DS17487-

5

DS17887-3	DS17887-
5	
DS2406@TO-92	
DS2406P@TSOC6	
DS2430A@TO-92	DS2430AP@TSOC6
[(SA602A)]	
DS2431@TO-92	DS2431P@TSOC6
[(SA602A)]	
DS2432P@TSOC6 [(SA602A)]	DS2433@PR-
35	
DS2433S(3.9)@SOIC8 [(SA602A)]	DS2433S(5.5)@SOIC8
[(SA605A)]	
DS2502	DS2502P@TSOC6
[(SA602A)]	
DS2502S@SOIC8 [(SA602A)]	
DS2502UNW	
DS2502UNW@SOIC8 [(SA602A)]	DS2502UNW@TSOC6
[(SA602A)]	
DS2506	DS2506S@SOIC8
[(SA023A)]	
DS4510@uSOP10	DS4520@TSSOP16
[(SA026)]	
DS4550@TSSOP20 [(SA026)]	

MICROCONTROLLER

DS87C520	DS87C520@PLCC44
[(SA244)]	
DS87C520@TQFP44 [(SA245A)]	
DS89C420	
DS89C420(rev.A)	DS89C420(rev.A)@PLCC44
[(SA244)]	
DS89C420(rev.A)@TQFP44 [(SA245A)]	
DS89C420@PLCC44 [(SA244)]	DS89C420@TQFP44
[(SA245A)]	
DS89C430	DS89C430@PLCC44
[(SA244)]	
DS89C430@TQFP44 [(SA245A)]	
DS89C440	
DS89C440@PLCC44 [(SA244)]	DS89C440@TQFP44
[(SA245A)]	
DS89C450	DS89C450@PLCC44

[(SA244)]
DS89C450@TQFP44 [(SA245A)]

DENSE-PAC

E (E) PROM / FRAM / NVRAM

DPV27C101 [(SA015A1T)]	DPV27C101@PLCC32
DPV27C256 [(SA015A1T)]	DPV27C256@PLCC32
DPV27C512 [(SA015A1T)]	DPV27C512@PLCC32

DEUTRON

E (E) PROM / FRAM / NVRAM

AC25LV010 [(SA602A)]	AC25LV010@SOIC8
AC25LV512 [(SA602A)]	AC25LV512@SOIC8
P439LV010@PLCC32 [(SA015A1T)] [(SA620)]	P439LV010@VSOP32
P439LV040@PLCC32 [(SA015A1T)] [(SA620)]	P439LV040@VSOP32
P439LV088@TSOP48 [(SA247-B005)] B005)]	P439VF800@TSOP48 [(SA247-

EFST

E (E) PROM / FRAM / NVRAM

EM25LV010@SOIC8 [(SA602A)] [(SA684)]	EM25LV010@VFQFPN8
EM25LV512@SOIC8 [(SA602A)] [(SA684)]	EM25LV512@VFQFPN8
F25L004A@SOIC8 [(SA602A)]	
F49B002UA	

F49B002UA@PLCC32 [(SA015A1T)]
[(SA015A1T)]
F49L004BA@TSOP40 [(SA409T)]
[(SA015A1T)]
F49L004UA@TSOP40 [(SA409T)]
[(SA015A1T)]
F49L040A@VSOP32 [(SA620)]

F49L004BA@PLCC32
F49L004UA@PLCC32
F49L040A@PLCC32

ELECTRONIC ARRAYS

E (E) PROM/FRAM/NVRAM

EA2716

EM

MICROCONTROLLER

EM6503@SOIC24 (ISP) [ISP-HEADER01]
EM6504@SOIC24 (ISP) [ISP-HEADER01]
EM6505@SOIC24 (ISP) [ISP-HEADER01]
EM6517@SOIC28 (ISP) [ISP-HEADER01]
EM6520@TQFP44 (ISP) [ISP-HEADER01]
EM6521@TQFP52 (ISP) [ISP-HEADER01]
EM6522@TQFP64 (ISP) [ISP-HEADER01]
EM6540@SOIC18 (ISP) [ISP-HEADER01]
EM6580 (ISP) [ISP-HEADER01]
EM6580@SOIC14 (ISP) [ISP-HEADER01]
EM6580@SOIC8 (ISP) [ISP-HEADER01]
EM6580@TSSOP14 (ISP) [ISP-HEADER01]

EMTC

E (E) PROM/FRAM/NVRAM

EM24C02
[(SA602A)]
EM24C02@TSSOP8 [(SA026)]
EM24C04

EM24C02@SOIC8

EM24C04@SOIC8 [(SA602A)]	EM24C04@TSSOP8
[(SA026)]	
EM24C08	EM24C08@SOIC8
[(SA602A)]	
EM24C08@TSSOP8 [(SA026)]	
EM24C16	
EM24C16@SOIC8 [(SA602A)]	EM24C16@TSSOP8
[(SA026)]	
EM25SL512@SOIC8 [(SA602A)]	
EM29SF002AB	
EM29SF002AB@PLCC32 [(SA015A1T)]	EM29SF002AB@TSOP32
[(SA410T)]	
EM29SF002AT	EM29SF002AT@PLCC32
[(SA015A1T)]	
EM29SF002AT@TSOP32 [(SA410T)]	
EM29SF002NAB	
EM29SF002NAB@PLCC32 [(SA015A1T)]	EM29SF002NAB@TSOP32
[(SA410T)]	
EM29SF002NAT	EM29SF002NAT@PLCC32
[(SA015A1T)]	
EM29SF002NAT@TSOP32 [(SA410T)]	

EON

E(E) PROM/FRAM/NVRAM

EN25B05(Bottom Boot)@SOP8(4.0) [(SA602A)]
 EN25B05(Bottom Boot)@SOP8(5.4) [(SA605A)]
 EN25B05(Bottom Boot)@VDFN8 [(SA683)]
 EN25B05(Top Boot)@SOP8(4.0) [(SA602A)]
 EN25B05(Top Boot)@SOP8(5.4) [(SA605A)]
 EN25B05(Top Boot)@VDFN8 [(SA683)]
 EN25B10(Bottom Boot)@SOP8(4.0) [(SA602A)]
 EN25B10(Bottom Boot)@SOP8(5.4) [(SA605A)]
 EN25B10(Bottom Boot)@VDFN8 [(SA683)]
 EN25B10(Top Boot)@SOP8(4.0) [(SA602A)]
 EN25B10(Top Boot)@SOP8(5.4) [(SA605A)]
 EN25B10(Top Boot)@VDFN8 [(SA683)]
 EN25B16(Bottom Boot)@SOP8 [(SA605A)]
 EN25B16(Bottom Boot)@SOP8(ISP) [ISP-HEADER01]
 EN25B16(Bottom Boot)@VFQFN8(ISP) [ISP-HEADER01]
 EN25B16(Bottom Boot)@VFQFPN8 [(SA684)]

EN25B16(Top Boot)@SOP8 [(SA605A)]
EN25B16(Top Boot)@SOP8(ISP) [ISP-HEADER01]
EN25B16(Top Boot)@VFQFN8(ISP) [ISP-HEADER01]
EN25B16(Top Boot)@VFQFPN8 [(SA684)]
EN25B20(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B20(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B20(Bottom Boot)@VDFN8 [(SA683)]
EN25B20(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B20(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B20(Top Boot)@VDFN8 [(SA683)]
EN25B32(Bottom Boot)@SOIC16 [(SA404)]
EN25B32(Bottom Boot)@SOIC16(ISP) [(SA404)]
EN25B32(Bottom Boot)@SOP8 [(SA605A)]
EN25B32(Bottom Boot)@SOP8(ISP) [(SA605A)]
EN25B32(Bottom Boot)@VDFN8 [(SA684)]
EN25B32(Bottom Boot)@VDFN8(ISP) [(SA684)]
EN25B32(Top Boot)@SOIC16 [(SA404)]
EN25B32(Top Boot)@SOIC16(ISP) [(SA404)]
EN25B32(Top Boot)@SOP8 [(SA605A)]
EN25B32(Top Boot)@SOP8(ISP) [(SA605A)]
EN25B32(Top Boot)@VDFN8 [(SA684)]
EN25B32(Top Boot)@VDFN8(ISP) [(SA684)]
EN25B40(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B40(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B40(Bottom Boot)@VDFN8 [(SA683)]
EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B40(Top Boot)@VDFN8 [(SA683)]
EN25B64(Bottom Boot)@SOIC16 [(SA404)]
EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]
EN25B64(Bottom Boot)@VDFN8 [(SA683)]
EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]
EN25B64(Top Boot)@SOIC16 [(SA404)]
EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]
EN25B64(Top Boot)@VDFN8 [(SA683)]
EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]
EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B80(Bottom Boot)@VDFN8 [(SA683)]
EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B80(Top Boot)@VDFN8 [(SA683)]
EN25D16 EN25D16@SOP16

[(SA404)]	
EN25D16@SOP8 [(SA605A)]	EN25D16@VDFN8
[(SA684)]	
EN25D80	EN25D80@SOP8
[(SA605A)]	
EN25D80@VDFN8 [(SA683)]	EN25F05@SOP8(4.0)
[(SA602A)]	
EN25F05@SOP8(5.4) [(SA605A)]	EN25F05@VDFN8
[(SA683)]	
EN25F10@SOP8(4.0) [(SA602A)]	EN25F10@SOP8(5.4)
[(SA605A)]	
EN25F10@VDFN8 [(SA683)]	
EN25F16	
EN25F16@SOP16 [(SA404)]	EN25F16@SOP8
[(SA605A)]	
EN25F16@VDFN8 [(SA684)]	EN25F20@SOP8
[(SA605A)]	
EN25F20@VDFN8 [(SA683)]	
EN25F32	
EN25F32@SOIC16 [(SA404)]	EN25F32@SOP8
[(SA605A)]	
EN25F32@VDFN8 [(SA684)]	EN25F40@SOP8(150mil)
[(SA602A)]	
EN25F40@SOP8(209mil) [(SA605A)]	EN25F40@VDFN8
[(SA683)]	
EN25F80	EN25F80@SOP8
[(SA605A)]	
EN25F80@VDFN8 [(SA683)]	EN25LF05@SOP8(4.0)
[(SA602A)]	
EN25LF05@SOP8(5.4) [(SA605A)]	EN25LF05@VDFN8
[(SA683)]	
EN25LF10@SOP8(4.0) [(SA602A)]	EN25LF10@SOP8(5.4)
[(SA605A)]	
EN25LF10@VDFN8 [(SA683)]	EN25LV010@SOIC8
[(SA602A)]	
EN25LV010@VFQFPN8 [(SA684)]	EN25LV020@SOIC8
[(SA602A)]	
EN25LV020@VFQFPN8 [(SA684)]	EN25LV040@SOIC8
[(SA602A)]	
EN25LV040@VFQFPN8 [(SA684)]	EN25LV080@SOIC8
[(SA602A)]	
EN25LV080@VFQFPN8 [(SA684)]	EN25LV160@SOIC8
[(SA602A)]	

```

EN25LV160@SOIC8(ISP) [ISP-HEADER01]
EN25LV160@VFQFPN8 [(SA683)]
EN25LV160@VFQFPN8(ISP) [ISP-HEADER01]
EN25LV512@SOIC8 [(SA602A)]           EN25LV512@VFQFPN8
[(SA684)]
EN25P05@SOP8(4.0) [(SA602A)]         EN25P05@SOP8(5.4)
[(SA605A)]
EN25P05@VDFN8 [(SA683)]              EN25P10@SOP8(4.0)
[(SA602A)]
EN25P10@SOP8(5.4) [(SA605A)]         EN25P10@VDFN8
[(SA683)]
EN25P16@SOP8 [(SA605A)]              EN25P16@SOP8(ISP) [ISP-
HEADER01]
EN25P16@VFQFPN8 [(SA684)]
EN25P16@VFQFPN8(ISP) [ISP-HEADER01]
EN25P20@SOP8(4.0) [(SA602A)]         EN25P20@SOP8(5.4)
[(SA605A)]
EN25P20@VDFN8 [(SA683)]              EN25P32@SOIC16
[(SA404)]
EN25P32@SOIC16(ISP) [(SA404)]        EN25P32@SOP8
[(SA605A)]
EN25P32@SOP8(ISP) [(SA605A)]         EN25P32@VDFN8
[(SA684)]
EN25P32@VDFN8(ISP) [(SA684)]         EN25P40@SOP8(4.0)
[(SA602A)]
EN25P40@SOP8(5.4) [(SA605A)]         EN25P40@VDFN8
[(SA683)]
EN25P64@SOIC16 [(SA404)]
EN25P64@SOIC16(ISP) [ISP-HEADER01]
EN25P64@VDFN8 [(SA683)]
EN25P64@VDFN8(ISP) [ISP-HEADER01]
EN25P80@SOP8(4.0) [(SA602A)]         EN25P80@SOP8(5.4)
[(SA605A)]
EN25P80@VDFN8 [(SA683)]              EN25S16@SOP8
[(SA605A)]
EN25S16@VFQFPN8 [(SA684)]
EN25S32(Bottom Boot)@SOIC16 [(SA404)]
EN25S32(Bottom Boot)@SOIC16(ISP) [(SA404)]
EN25S32(Bottom Boot)@SOP8 [(SA605A)]
EN25S32(Bottom Boot)@SOP8(ISP) [(SA605A)]
EN25S32(Bottom Boot)@VDFN8 [(SA684)]
EN25S32(Bottom Boot)@VDFN8(ISP) [(SA684)]
EN25S32(Top Boot)@SOIC16 [(SA404)]

```

EN25S32(Top Boot)@SOIC16(ISP) [(SA404)]	
EN25S32(Top Boot)@SOP8 [(SA605A)]	
EN25S32(Top Boot)@SOP8(ISP) [(SA605A)]	
EN25S32(Top Boot)@VDFN8 [(SA684)]	
EN25S32(Top Boot)@VDFN8(ISP) [(SA684)]	
EN25T16@SOP8 [(SA605A)]	EN25T16@VFQFPN8
[(SA684)]	
EN25T80	EN25T80@SOP8
[(SA605A)]	
EN25T80@VDFN8 [(SA683)]	
EN27C010	
EN27C010@PLCC32 [(SA015A1T)]	
EN27C512	
EN27C512@PLCC32 [(SA015A1T)]	
EN29F002AB	
EN29F002AB@PLCC32 [(SA015A1T)]	EN29F002AB@TSOP32
[(SA410T)]	
EN29F002ANB	EN29F002ANB@PLCC32
[(SA015A1T)]	
EN29F002ANB@TSOP32 [(SA410T)]	
EN29F002ANT	
EN29F002ANT@PLCC32 [(SA015A1T)]	EN29F002ANT@TSOP32
[(SA410T)]	
EN29F002AT	EN29F002AT@PLCC32
[(SA015A1T)]	
EN29F002AT@TSOP32 [(SA410T)]	
EN29F002B	
EN29F002B@PLCC32 [(SA015A1T)]	EN29F002B@TSOP32
[(SA410T)]	
EN29F002NB	EN29F002NB@PLCC32
[(SA015A1T)]	
EN29F002NB@TSOP32 [(SA410T)]	
EN29F002NT	
EN29F002NT@PLCC32 [(SA015A1T)]	EN29F002NT@TSOP32
[(SA410T)]	
EN29F002T	EN29F002T@PLCC32
[(SA015A1T)]	
EN29F002T@TSOP32 [(SA410T)]	
EN29F010	
EN29F010@PLCC32 [(SA015A1T)]	EN29F010@TSOP32
[(SA410T)]	
EN29F010@VSOP32 [(SA620)]	
EN29F040	

EN29F040@PLCC32 [(SA015A1T)]	EN29F040@TSOP32
[(SA410T)]	
EN29F040A	EN29F040A@PLCC32
[(SA015A1T)]	
EN29F040A@TSOP32 [(SA410T)]	EN29F080@TSOP40
[(SA409T)]	
EN29F512	EN29F512@PLCC32
[(SA015A1T)]	
EN29F512@TSOP32 [(SA410T)]	EN29F512@VSOP32
[(SA620)]	
EN29F800B@TSOP48 [(SA247-B005)]	EN29F800T@TSOP48 [(SA247-
B005)]	
EN29LV010@PLCC32 [(SA015A1T)]	EN29LV010@TSOP32
[(SA410T)]	
EN29LV010@VSOP32 [(SA620)]	EN29LV040@PLCC32
[(SA015A1T)]	
EN29LV040@TSOP32 [(SA410T)]	EN29LV040@VSOP32
[(SA620)]	
EN29LV040A@PLCC32 [(SA015A1T)]	EN29LV040A@TSOP32
[(SA410T)]	
EN29LV040A@VSOP32 [(SA620)]	EN29LV512@PLCC32
[(SA015A1T)]	
EN29LV512@TSOP32 [(SA410T)]	EN29LV512@VSOP32
[(SA620)]	
EN29LV800B@TSOP48 [(SA247-B005)]	EN29LV800T@TSOP48 [(SA247-
B005)]	

ESMT

E(E) PROM/FRAM/NVRAM

EM25LV010@SOIC8 [(SA602A)]	EM25LV010@VFQFPN8
[(SA684)]	
EM25LV512@SOIC8 [(SA602A)]	EM25LV512@VFQFPN8
[(SA684)]	
F25L004AB	
F25L004AB@SOIC8(150mil) [(SA602A)]	
F25L004AB@SOIC8(200mil) [(SA605A)]	
F25L004AT	
F25L004AT@SOIC8(150mil) [(SA602A)]	
F25L004AT@SOIC8(200mil) [(SA605A)]	
F25L008AB@SOIC8 [(SA605A)]	F25L008AT@SOIC8

[(SA605A)]	
F25L016AB@SOIC8 [(SA605A)]	F25L016AT@SOIC8
[(SA605A)]	
F25L04UA@SOIC8 [(SA602A)]	
F25L08PA(AAI-PROGRAM)@SOIC8 [(SA605A)]	
F25L08PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]	
F25L16PA(AAI-PROGRAM)@SOIC8 [(SA605A)]	
F25L16PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]	
F25L32PA@SOIC16 [(SA404)]	F25L32PA@SOIC8
[(SA605A)]	
F49B002UA	F49B002UA@PLCC32
[(SA015A1T)]	
F49L004BA@PLCC32 [(SA015A1T)]	F49L004BA@TSOP40
[(SA409T)]	
F49L004UA@PLCC32 [(SA015A1T)]	F49L004UA@TSOP40
[(SA409T)]	
F49L040A@PLCC32 [(SA015A1T)]	F49L040A@VSOP32
[(SA620)]	

EXCELSEMI

E (E) PROM / FRAM / NVRAM

ES25M16	ES25M16@SOP16
[(SA404)]	
ES25M16@SOP8[150 mil] [(SA602A)]	ES25M16@SOP8[208 mil]
[(SA605A)]	
ES25M40	ES25M40@SOP16
[(SA404)]	
ES25M40@SOP8[150 mil] [(SA602A)]	ES25M40@SOP8[208 mil]
[(SA605A)]	
ES25M80	ES25M80@SOP16
[(SA404)]	
ES25M80@SOP8[150 mil] [(SA602A)]	ES25M80@SOP8[208 mil]
[(SA605A)]	
ES25P16@SOP8 [(SA605A)]	ES25P40@SOP8
[(SA605A)]	
ES25P80@SOP8 [(SA605A)]	

EXEL

E (E) PROM / FRAM / NVRAM

XL24C01A

XL24C02

XL24C04

XL24C16

XL24C16@SOIC8 [(SA602A)]

XL24C32

XL28C256

XL28C256@PLCC32

[(SA015A1T)]

XL28C256@TSOP28 [(SA430T)]

XL9010

XL9010(F) [(SA602A)]

XL9020

XL9020(F) [(SA602A)]

XL9040

XL9040(F) [(SA602A)]

XL9346

XL9346@SOIC8 [(SA602A)]

XL93CS56

XL93CS56@SOIC8 [(SA602A)]

XL93CS56@TSSOP8

[(SA026)]

XL93CS66

XL93CS66@SOIC8

[(SA602A)]

XL93CS66@TSSOP8 [(SA026)]

XL93LC46

XL93LC46@SOIC8 [(SA602A)]

XL93LC46A

XL93LC46A@SOIC8 [(SA602A)]

XL93LC56

XL93LC56@SOIC8 [(SA602A)]

XL93LC56A

XL93LC56A@SOIC8 [(SA602A)]

XL93LC66A

XL93LC66A@SOIC8 [(SA602A)]

XL9764

XLE28C16A

XLE28C16A@PLCC32

[(SA015A1T)]

XLE28C16B

XLE28C16B@PLCC32

[(SA015A1T)]

XLE28C16B@SOIC24 [(SA404)]

XLM28C16A

XLM28C16A@PLCC32 [(SA015A1T)]

XLM46C15	
XLM46P15	
XLS2804A	
XLS2816A	XLS2816A@PLCC32
[(SA015A1T)]	
XLS2817A	
XLS28C16A	
XLS28C16A@PLCC32 [(SA015A1T)]	
XLS28C16B	
XLS28C16B@PLCC32 [(SA015A1T)]	XLS28C16B@SOIC24
[(SA404)]	
XLS28C64B	XLS28C64B@PLCC32
[(SA015A1T)]	
XLS28C64B@SOIC28 [(SA404)]	
XLS46C15	
XLS46P15	
XLS93C46	
XLS93C46@SOIC8 [(SA602A)]	
XLS93C56	
XLS93C56@SOIC8 [(SA602A)]	
XLS93C66	
XLS93C66@SOIC8 [(SA602A)]	
XLS93CS46	
XLS93CS46@SOIC8 [(SA602A)]	XLS93CS46@TSSOP8
[(SA026)]	
XLS93LC06	XLS93LC06@SOIC8
[(SA602A)]	
XLS93LC66	XLS93LC66@SOIC8
[(SA602A)]	

FAIRCHILD

E (E) PROM / FRAM / NVRAM

FM24C02 (M8) @SOIC8 [(SA602A)]	FM24C02 (MT8) @TSSOP8
[(SA026)]	
FM24C02 (N)	FM24C03 (M8) @SOIC8
[(SA602A)]	
FM24C03 (MT8) @TSSOP8 [(SA026)]	FM24C03
(N)	
FM24C04 (M8) @SOIC8 [(SA602A)]	FM24C04 (MT8) @TSSOP8
[(SA026)]	

FM24C04(N) [(SA602A)]	FM24C05(M8)@SOIC8
FM24C05(MT8)@TSSOP8 [(SA026)] (N)	FM24C05
FM24C08(M8)@SOIC8 [(SA602A)] [(SA026)]	FM24C08(MT8)@TSSOP8
FM24C08(N) [(SA602A)]	FM24C09(M8)@SOIC8
FM24C09(MT8)@TSSOP8 [(SA026)] (N)	FM24C09
FM24C128(MT8)@TSSOP8 [(SA026)] [(SA602A)]	FM24C128(MW8)@SOIC8
FM24C128(N) [(SA602A)]	FM24C16(M8)@SOIC8
FM24C16(MT8)@TSSOP8 [(SA026)] (N)	FM24C16
FM24C17(M8)@SOIC8 [(SA602A)] [(SA026)]	FM24C17(MT8)@TSSOP8
FM24C17(N) [(SA602A)]	FM24C256(M8)@SOIC8
FM24C256(N) [(SA602A)]	FM24C32(M8)@SOIC8
FM24C32(N)	
FM27C010	
FM27C010@PLCC32 [(SA015A1T)] [(SA410T)]	FM27C010@TSOP32
FM27C040 [(SA015A1T)]	FM27C040@PLCC32
FM27C040@TSOP32 [(SA410T)]	
FM27C256	
FM27C256@PLCC32 [(SA015A1T)]	
FM27C256Q	
FM27C256Q@PLCC32 [(SA015A1T)]	
FM27C512	
FM27C512@PLCC32 [(SA015A1T)]	
FM93C06(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C06(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C06(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C06(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C06(N)(08bit) (16bit)	FM93C06(N)
FM93C14(16bit) [(SA602A)]	FM93C46(M8)@SOIC8

```

FM93C46(MT8)@TSSOP8 [(SA026)]          FM93C46
(N)
FM93C46A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C46A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C46A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C46A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C46A(N)(08bit)                    FM93C46A(N)
(16bit)
FM93C56(M8)@SOIC8 [(SA602A)]          FM93C56(MT8)@TSSOP8
[(SA026)]
FM93C56(N)
FM93C56A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C56A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C56A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C56A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C56A(N)(08bit)                    FM93C56A(N)
(16bit)
FM93C66(M8)@SOIC8 [(SA602A)]          FM93C66(MT8)@TSSOP8
[(SA026)]
FM93C66(N)
FM93C66A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C66A(N)(08bit)                    FM93C66A(N)
(16bit)
FM93C76(M8)(16bit)@SOIC8 [(SA602A)]
FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C76(N)(16bit)
FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C76A(N)(08bit)                    FM93C76A(N)
(16bit)
FM93C86(M8)(16bit)@SOIC8 [(SA602A)]
FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C86(N)(16bit)
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C86A(N)(08bit)                    FM93C86A(N)

```

(16bit)	
FM93CS06(M8)@SOIC8 [(SA602A)]	FM93CS06(MT8)@TSSOP8
[(SA026)]	
FM93CS06(N)	FM93CS46(M8)@SOIC8
[(SA602A)]	
FM93CS46(MT8)@TSSOP8 [(SA026)]	FM93CS46
(N)	
FM93CS56(M8)@SOIC8 [(SA602A)]	FM93CS56(MT8)@TSSOP8
[(SA026)]	
FM93CS56(N)	FM93CS66(M8)@SOIC8
[(SA602A)]	
FM93CS66(MT8)@TSSOP8 [(SA026)]	FM93CS66
(N)	
FM93S46(M8)@SOIC8 [(SA602A)]	FM93S46(MT8)@TSSOP8
[(SA026)]	
FM93S46(N)	FM93S56(M8)@SOIC8
[(SA602A)]	
FM93S56(MT8)@TSSOP8 [(SA026)]	FM93S56
(N)	
FM93S66(M8)@SOIC8 [(SA602A)]	FM93S66(MT8)@TSSOP8
[(SA026)]	
FM93S66(N)	
MM2716	
MM2716E	NM24C02(M8)@SOIC8
[(SA602A)]	
NM24C02(MT8)@TSSOP8 [(SA026)]	NM24C02
(N)	
NM24C02L(M8)@SOIC8 [(SA602A)]	NM24C02L(MT8)@TSSOP8
[(SA026)]	
NM24C02L(N)	NM24C03(M8)@SOIC8
[(SA602A)]	
NM24C03(MT8)@TSSOP8 [(SA026)]	NM24C03
(N)	
NM24C04(M8)@SOIC8 [(SA602A)]	NM24C04(MT8)@TSSOP8
[(SA026)]	
NM24C04(N)	NM24C05(M8)@SOIC8
[(SA602A)]	
NM24C05(MT8)@TSSOP8 [(SA026)]	NM24C05
(N)	
NM24C08(M8)@SOIC8 [(SA602A)]	NM24C08(MT8)@TSSOP8
[(SA026)]	
NM24C08(N)	NM24C09(M8)@SOIC8
[(SA602A)]	

NM24C09 (MT8)@TSSOP8 [(SA026)] (N)	NM24C09
NM24C16 (M8)@SOIC8 [(SA602A)] [(SA026)]	NM24C16 (MT8)@TSSOP8
NM24C16 (N) [(SA602A)]	NM24C17 (M8)@SOIC8
NM24C17 (MT8)@TSSOP8 [(SA026)] (N)	NM24C17
NM24C65 (M8)SOIC8 [(SA602A)] (N)	NM24C65
NM27C010 [(SA015A1T)]	NM27C010@PLCC32
NM27C010@TSOP32 [(SA410T)]	
NM27C020 NM27C020@PLCC32 [(SA015A1T)] [(SA410T)]	NM27C020@TSOP32
NM27C020Q [(SA015A1T)]	NM27C020Q@PLCC32
NM27C020Q@TSOP32 [(SA410T)]	
NM27C040 NM27C040@PLCC32 [(SA015A1T)] [(SA410T)]	NM27C040@TSOP32
NM27C128 [(SA015A1T)]	NM27C128@PLCC32
NM27C210 [(SA244)]	NM27C210@PLCC44
NM27C240 [(SA244)]	NM27C240@PLCC44
NM27C256 [(SA015A1T)]	NM27C256@PLCC32
NM27C512 [(SA015A1T)]	NM27C512@PLCC32
NM27C64Q [(SA015A1T)]	NM27C64Q@PLCC32
NM27LC256 [(SA015A1T)]	NM27LC256@PLCC32
NM27LC512 [(SA015A1T)]	NM27LC512@PLCC32
NM27LV010 [(SA015A1T)]	NM27LV010@PLCC32
NM27LV010@TSOP32 [(SA410T)]	
NM27LV210 NM27LV210@PLCC44 [(SA244)]	

NM27LV512	
NM27LV512@PLCC32 [(SA015A1T)]	
NM27P040	
NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32
[(SA410T)]	
NM27P210	NM27P210@PLCC44
[(SA244)]	
NM27P512	NM27P512@PLCC32
[(SA015A1T)]	
NM93C66(M8)(16bit)@SOIC8 [(SA602A)]	
NM93C66(MT8)(16bit)@TSSOP8 [(SA026)]	
NM93C66(N)(16bit)	NM93CS06(M8)@SOIC8
[(SA602A)]	
NM93CS06(MT8)@TSSOP8 [(SA026)]	NM93CS06
(N)	
NM93CS46(M8)@SOIC8 [(SA602A)]	NM93CS46(MT8)@TSSOP8
[(SA026)]	
NM93CS46(N)	NM93CS56(M8)@SOIC8
[(SA602A)]	
NM93CS56(MT8)@TSSOP8 [(SA026)]	NM93CS56
(N)	
NM93CS66(M8)@SOIC8 [(SA602A)]	NM93CS66(MT8)@TSSOP8
[(SA026)]	
NM93CS66(N)	
NMC2732	
NMC27C010	NMC27C010@PLCC32
[(SA015A1T)]	
NMC27C010@TSOP32 [(SA410T)]	
NMC27C1024	
NMC27C1024@PLCC44 [(SA244)]	
NMC27C128B	
NMC27C128B@PLCC32 [(SA015A1T)]	
NMC27C128BN	
NMC27C128BN@PLCC32 [(SA015A1T)]	
NMC27C128BQ	
NMC27C128BQ@PLCC32 [(SA015A1T)]	
NMC27C128CQ	
NMC27C16	
NMC27C16BQ	
NMC27C16BQE	
NMC27C16H	
NMC27C16HQ	
NMC27C16Q	

NMC27C256 [(SA015A1T)]	NMC27C256@PLCC32
NMC27C256B [(SA015A1T)]	NMC27C256B@PLCC32
NMC27C256Q [(SA015A1T)]	NMC27C256Q@PLCC32
NMC27C32	
NMC27C32B	
NMC27C32BQ	
NMC27C32E	
NMC27C32EH	
NMC27C32H	
NMC27C512 [(SA015A1T)]	NMC27C512@PLCC32
NMC27C512A [(SA015A1T)]	NMC27C512A@PLCC32
NMC27C512AN [(SA015A1T)]	NMC27C512AN@PLCC32
NMC27C64 (BN)	NMC27C64
NMC27C64(N)	
NMC27CP128	
NMC87C257Q [(SA015A1T)]	NMC87C257Q@PLCC32
NMC87C257V [(SA015A1T)]	NMC87C257V@PLCC32
NMC9346(M8)(16bit)@SOIC8 [(SA602A)]	
NMC9346(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC9346(N)(16bit)	
NMC93C46(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C46(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C46(N)(16bit)	
NMC93C46A(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C46A(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C46A(N)(16bit)	
NMC93C56(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C56(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C56(N)(16bit)	
NMC93C66(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C66(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C66(N)(16bit) [(SA602A)]	NMC93CS06(M8)@SOIC8
NMC93CS06(MT8)@TSSOP8 [(SA026)]	NMC93CS06

(N)

NMC93CS46(M8)@SOIC8 [(SA602A)]

[(SA026)]

NMC93CS46(N)

[(SA602A)]

NMC93CS56(MT8)@TSSOP8 [(SA026)]

(N)

NMC93CS66(M8)@SOIC8 [(SA602A)]

[(SA026)]

NMC93CS66(N)

NMC9817

NMC93CS46(MT8)@TSSOP8

NMC93CS56(M8)@SOIC8

NMC93CS56

NMC93CS66(MT8)@TSSOP8

DRAM & SRAM

F1600

[(SA646)]

F1601

[(SA646)]

F1620

F1621

F1600@SOJ24

F1601@SOJ24

MICROCONTROLLER

ACE1001(M8)@SOIC8 [(SA602A)]

[(SA602A)]

ACE1001(MT8)@TSSOP8 [(SA026)]

[(SA026)]

ACE1001E(M8)@SOIC8 [(SA602A)]

[(SA602A)]

ACE1001E(MT8)@TSSOP8 [(SA026)]

[(SA026)]

ACE1001L(M8)@SOIC8 [(SA602A)]

[(SA602A)]

ACE1001L(MT8)@TSSOP8 [(SA026)]

[(SA026)]

ACE1101(EMT8)@TSSOP8 [(SA026)]

[(SA026)]

ACE1101(EN)

(EN14)

ACE1101(LMT8)@TSSOP8 [(SA026)]

[(SA026)]

ACE1001(M8X)@SOIC8

ACE1001(MT8X)@TSSOP8

ACE1001E(M8X)@SOIC8

ACE1001E(MT8X)@TSSOP8

ACE1001L(M8X)@SOIC8

ACE1001L(MT8X)@TSSOP8

ACE1101(EMT8X)@TSSOP8

ACE1101

ACE1101(LMT8X)@TSSOP8

ACE1101(LN) (LN14)	ACE1101
ACE1101(MT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101(MT8X)@TSSOP8
ACE1101(N) (N14)	ACE1101
ACE1101(VMT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101(VMT8X)@TSSOP8
ACE1101(VN) (VN14)	ACE1101
ACE1101B(EMT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101B(EMT8X)@TSSOP8
ACE1101B(EN) (EN14)	ACE1101B
ACE1101B(MT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101B(MT8X)@TSSOP8
ACE1101B(N) (N14)	ACE1101B
ACE1101B(VMT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101B(VMT8X)@TSSOP8
ACE1101B(VN) (VN14)	ACE1101B
ACE1202(dip14) (dip8)	ACE1202
ACE1202(M14)@SOIC14 [(SA602)] [(SA602A)]	ACE1202(M8)@SOIC8
ACE12022(dip14) (dip8)	ACE12022
ACE12022(M14)@SOIC14 [(SA602)] [(SA602A)]	ACE12022(M8)@SOIC8
ACE12022B(dip14) (dip8)	ACE12022B
ACE12022B(M14)@SOIC14 [(SA602)] [(SA602A)]	ACE12022B(M8)@SOIC8
ACE12022BE(dip14) (dip8)	ACE12022BE
ACE12022BE(M14)@SOIC14 [(SA602)] [(SA602A)]	ACE12022BE(M8)@SOIC8
ACE12022BV(dip14) (dip8)	ACE12022BV
ACE12022BV(M14)@SOIC14 [(SA602)] [(SA602A)]	ACE12022BV(M8)@SOIC8
ACE12022E(dip14)	ACE12022E

(dip8)	
ACE12022E(M14)@SOIC14 [(SA602)]	ACE12022E(M8)@SOIC8
[(SA602A)]	
ACE1202B(dip14)	ACE1202B
(dip8)	
ACE1202B(M14)@SOIC14 [(SA602)]	ACE1202B(M8)@SOIC8
[(SA602A)]	
ACE1202BE(dip14)	ACE1202BE
(dip8)	
ACE1202BE(M14)@SOIC14 [(SA602)]	ACE1202BE(M8)@SOIC8
[(SA602A)]	
ACE1202BV(dip14)	ACE1202BV
(dip8)	
ACE1202BV(M14)@SOIC14 [(SA602)]	ACE1202BV(M8)@SOIC8
[(SA602A)]	
ACE1202E(dip14)	ACE1202E
(dip8)	
ACE1202E(M14)@SOIC14 [(SA602)]	ACE1202E(M8)@SOIC8
[(SA602A)]	
ACE1202L(dip14)	ACE1202L
(dip8)	
ACE1202L(M14)@SOIC14 [(SA602)]	ACE1202L(M8)@SOIC8
[(SA602A)]	
ACE1202V(dip8)	ACE1202V(M14)@SOIC14
[(SA602)]	
ACE1202V(M8)@SOIC8 [(SA602A)]	ACE1501(EM)@SOIC14
[(SA602)]	
ACE1501(EM8)@SOIC8 [(SA602A)]	ACE1501(EM8X)@SOIC8
[(SA602A)]	
ACE1501(EMT)@TSOP14 [(SA026)]	ACE1501(EMT8)@TSSOP8
[(SA026)]	
ACE1501(EMT8X)@TSSOP8 [(SA026)]	ACE1501(EMTX)@TSOP14
[(SA026)]	
ACE1501(EMX)@SOIC14 [(SA602)]	ACE1501
(EN)	
ACE1501(EN14)	ACE1501(VM)@SOIC14
[(SA602)]	
ACE1501(VM8)@SOIC8 [(SA602A)]	ACE1501(VM8X)@SOIC8
[(SA602A)]	
ACE1501(VMT)@TSOP14 [(SA026)]	ACE1501(VMT8)@TSSOP8
[(SA026)]	
ACE1501(VMT8X)@TSSOP8 [(SA026)]	ACE1501(VMTX)@TSOP14
[(SA026)]	

ACE1501(VMX)@SOIC14 [(SA602)] (VN)	ACE1501
ACE1501(VN14) [(SA602)]	ACE1502(EM)@SOIC14
ACE1502(EM8)@SOIC8 [(SA602A)] [(SA026)]	ACE1502(EMT)@TSOP14
ACE1502(EMT8)@TSSOP8 [(SA026)] (EN)	ACE1502
ACE1502(EN14) [(SA602)]	ACE1502(VM)@SOIC14
ACE1502(VM8)@SOIC8 [(SA602A)] [(SA026)]	ACE1502(VMT)@TSOP14
ACE1502(VMT8)@TSSOP8 [(SA026)] (VN)	ACE1502
ACE1502(VN14) [(SA602A)]	ACE8000(M8)@SOIC8
ACE8000(M8X)@SOIC8 [(SA602A)] [(SA602A)]	ACE8000E(M8)@SOIC8
ACE8000E(M8X)@SOIC8 [(SA602A)] [(SA602A)]	ACE8001(M8)@SOIC8
ACE8001(M8X)@SOIC8 [(SA602A)] [(SA026)]	ACE8001(MT8)@TSSOP8
ACE8001(MT8X)@TSSOP8 [(SA026)] [(SA602A)]	ACE8001E(M8)@SOIC8
ACE8001E(M8X)@SOIC8 [(SA602A)] [(SA026)]	ACE8001E(MT8)@TSSOP8
ACE8001E(MT8X)@TSSOP8 [(SA026)] [(SA602A)]	FMS7401L(EM8X)@SOIC8
FMS7401L(EMT8X)@TSSOP8 [(SA026)] [(SA026)]	FMS7401L(EMTX)@TSSOP14
FMS7401L(EMX)@SOIC14 [(SA602)] (EN)	FMS7401L
FMS7401L(EN14) (VN)	FMS7401L
FMS7401L(VN14)	

FORCE TECHNOLOGIES

E(E) PROM/FRAM/NVRAM

FT24C01 [(SA602A)]	FT24C01@SOIC8
-----------------------	---------------

FT24C01@TSOP8 [(SA026)]	
FT24C01A	
FT24C01A@SOIC8 [(SA602A)]	FT24C01A@TSOP8
[(SA026)]	
FT24C02	FT24C02@SOP8
[(SA602A)]	
FT24C02@TSSOP8 [(SA026)]	
FT24C02A	
FT24C02A@SOP8 [(SA602A)]	FT24C02A@TSSOP8
[(SA026)]	
FT24C04	FT24C04@SOP8
[(SA602A)]	
FT24C04@TSSOP8 [(SA026)]	
FT24C04A	
FT24C04A@SOP8 [(SA602A)]	FT24C04A@TSSOP8
[(SA026)]	
FT24C08	FT24C08@SOIC8
[(SA602A)]	
FT24C08@TSOP8 [(SA026)]	
FT24C08A	
FT24C08A@SOIC8 [(SA602A)]	FT24C08A@TSOP8
[(SA026)]	
FT24C128	FT24C128@SOIC8
[(SA602A)]	
FT24C128@TSOP8 [(SA026)]	
FT24C128A	
FT24C128A@SOIC8 [(SA602A)]	FT24C128A@TSOP8
[(SA026)]	
FT24C16	FT24C16@SOIC8
[(SA602A)]	
FT24C16@TSOP8 [(SA026)]	
FT24C16A	
FT24C16A@SOIC8 [(SA602A)]	FT24C16A@TSOP8
[(SA026)]	
FT24C256	FT24C256@SOIC8
[(SA602A)]	
FT24C256@TSOP8 [(SA026)]	
FT24C256A	
FT24C256A@SOIC8 [(SA602A)]	FT24C256A@TSOP8
[(SA026)]	
FT24C32	FT24C32@SOIC8
[(SA602A)]	
FT24C32@TSOP8 [(SA026)]	

FT24C32A	
FT24C32A@SOIC8 [(SA602A)]	FT24C32A@TSOP8
[(SA026)]	
FT24C64	FT24C64@SOIC8
[(SA602A)]	
FT24C64@TSOP8 [(SA026)]	
FT24C64A	
FT24C64A@SOIC8 [(SA602A)]	FT24C64A@TSOP8
[(SA026)]	
FT27C010	FT27C010@PLCC32
[(SA015A1T)]	
FT27C010@TSOP32 [(SA410T)]	
FT27C020	
FT27C020@PLCC32 [(SA015A1T)]	FT27C020@TSOP32
[(SA410T)]	
FT27C040	FT27C040@PLCC32
[(SA015A1T)]	
FT27C040@TSOP32 [(SA410T)]	
FT27C16	
FT27C256	FT27C256@PLCC32
[(SA015A1T)]	
FT27C64	FT27C64@PLCC32
[(SA015A1T)]	
FT27HC256	FT27HC256@PLCC32
[(SA015A1T)]	
FT27HC64	FT27HC64@PLCC32
[(SA015A1T)]	
FT28C010	FT28C010@JLCC32
[(SA412A)]	
FT28C010@PLCC32 [(SA015A1T)]	FT28C010@PLCC44
[(SA244)]	
FT28C010@TSOP32 [(SA410T)]	
FT28C010E	
FT28C010E@JLCC32 [(SA412A)]	FT28C010E@PLCC32
[(SA015A1T)]	
FT28C010E@PLCC44 [(SA244)]	FT28C010E@TSOP32
[(SA410T)]	
FT28C020	FT28C020@JLCC32
[(SA412A)]	
FT28C020@PLCC32 [(SA015A1T)]	FT28C020@PLCC44
[(SA244)]	
FT28C020@TSOP32 [(SA410T)]	
FT28C040	

FT28C040@JLCC32 [(SA412A)] [(SA015A1T)]	FT28C040@PLCC32
FT28C040@PLCC44 [(SA244)] [(SA410T)]	FT28C040@TSOP32
FT28C16 [(SA015A1T)]	FT28C16@PLCC32
FT28C256 [(SA412A)]	FT28C256@JLCC32
FT28C256@PLCC32 [(SA015A1T)] [(SA404)]	FT28C256@SOIC28
FT28C256@TSOP28 [(SA430T)] FT28C256B	
FT28C256B@JLCC32 [(SA412A)] [(SA015A1T)]	FT28C256B@PLCC32
FT28C256B@SOIC28 [(SA404)] [(SA430T)]	FT28C256B@TSOP28
FT28C64 [(SA015A1T)]	FT28C64@PLCC32
FT28C64@SOIC28 [(SA404)] [(SA430T)]	FT28C64@TSOP28
FT28C64B [(SA412A)]	FT28C64B@JLCC32
FT28C64B@PLCC32 [(SA015A1T)] [(SA404)]	FT28C64B@SOIC28
FT28C64B@TSOP28 [(SA430T)] FT28C64X	
FT28C64X@PLCC32 [(SA015A1T)] [(SA404)]	FT28C64X@SOIC28
FT28C64X@TSOP28 [(SA430T)] FT28HC64	
FT28HC64@PLCC32 [(SA015A1T)] [(SA430T)]	FT28HC64@TSOP28
FT58C1001 [(SA438T)]	FT58C1001@SSOP32
FT58C1001@VSOP32 [(SA620)]	

FORWARD

E (E) PROM/FRAM/NVRAM

24LC01 [(SA602A)]	24LC01@SOIC8
------------------------	--------------

24LC02 [(SA602A)]	24LC02@SOIC8
24LC04 [(SA602A)]	24LC04@SOIC8
24LC08 [(SA602A)]	24LC08@SOIC8
24LC16 [(SA602A)]	24LC16@SOIC8
24LC32 [(SA602A)]	24LC32@SOIC8
24LC64 [(SA602A)]	24LC64@SOIC8

Fremont Micro Devices

E (E) PROM/FRAM/NVRAM

FT24C02 [(SA602A)]	FT24C02@SOP8
FT24C02@TSSOP8 [(SA026)]	
FT24C02A FT24C02A@SOP8 [(SA602A)]	FT24C02A@TSSOP8
[(SA026)]	
FT24C04 [(SA602A)]	FT24C04@SOP8
FT24C04@TSSOP8 [(SA026)]	
FT24C04A FT24C04A@SOP8 [(SA602A)]	FT24C04A@TSSOP8
[(SA026)]	
FT24C08 [(SA602A)]	FT24C08@SOP8
FT24C08@TSSOP8 [(SA026)]	
FT24C08A FT24C08A@SOP8 [(SA602A)]	FT24C08A@TSSOP8
[(SA026)]	
FT24C1024 [(SA023A)]	FT24C1024@SOP8
FT24C1024@TSSOP8 [(SA026)]	
FT24C1024A FT24C1024A@SOP8 [(SA023A)]	FT24C1024A@TSSOP8
[(SA026)]	
FT24C128	FT24C128@SOP8

[(SA602A)]	
FT24C128@TSSOP8 [(SA026)]	
FT24C128A	
FT24C128A@SOP8 [(SA602A)]	FT24C128A@TSSOP8
[(SA026)]	
FT24C16	
[(SA602A)]	
FT24C16@TSSOP8 [(SA026)]	FT24C16@SOP8
FT24C16A	
FT24C16A@SOP8 [(SA602A)]	FT24C16A@TSSOP8
[(SA026)]	
FT24C256	
[(SA602A)]	
FT24C256@TSSOP8 [(SA026)]	FT24C256@SOP8
FT24C256A	
FT24C256A@SOP8 [(SA602A)]	FT24C256A@TSSOP8
[(SA026)]	
FT24C32	
[(SA602A)]	
FT24C32@TSSOP8 [(SA026)]	FT24C32@SOP8
FT24C32A	
FT24C32A@SOP8 [(SA602A)]	FT24C32A@TSSOP8
[(SA026)]	
FT24C512	
[(SA602A)]	
FT24C512@TSSOP8 [(SA026)]	FT24C512@SOP8
FT24C512A	
FT24C512A@SOP8 [(SA602A)]	FT24C512A@TSSOP8
[(SA026)]	
FT24C64	
[(SA602A)]	
FT24C64@TSSOP8 [(SA026)]	FT24C64@SOP8
FT24C64A	
FT24C64A@SOP8 [(SA602A)]	FT24C64A@TSSOP8
[(SA026)]	
FT34C02	
[(SA602A)]	
FT34C02@TSSOP8 [(SA026)]	FT34C02@SOP8
FT34C02A	
FT34C02A@SOP8 [(SA602A)]	FT34C02A@TSSOP8
[(SA026)]	
FT93C46(08bit)	
[(SA602A)]	FT93C46(08bit)@SOP8

FT93C46(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C46
FT93C46(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C46(16bit)@TSSOP8
FT93C46A(08bit) [(SA602A)]	FT93C46A(08bit)@SOP8
FT93C46A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C46A
FT93C46A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C46A(16bit)@TSSOP8
FT93C56(08bit) [(SA602A)]	FT93C56(08bit)@SOP8
FT93C56(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C56
FT93C56(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C56(16bit)@TSSOP8
FT93C56A(08bit) [(SA602A)]	FT93C56A(08bit)@SOP8
FT93C56A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C56A
FT93C56A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C56A(16bit)@TSSOP8
FT93C66(08bit) [(SA602A)]	FT93C66(08bit)@SOP8
FT93C66(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66
FT93C66(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66(16bit)@TSSOP8
FT93C66A(08bit) [(SA602A)]	FT93C66A(08bit)@SOP8
FT93C66A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66A
FT93C66A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66A(16bit)@TSSOP8
FT93C86(08bit) [(SA602A)]	FT93C86(08bit)@SOP8
FT93C86(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C86
FT93C86(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C86(16bit)@TSSOP8
FT93C86A(08bit) [(SA602A)]	FT93C86A(08bit)@SOP8
FT93C86A(08bit)@TSSOP8 [(SA026)]	FT93C86A

(16bit)

FT93C86A(16bit)@SOP8 [(SA602A)]
[(SA026)]

FT93C86A(16bit)@TSSOP8

FUJITSU

E (E) PROM / FRAM / NVRAM

MB85R256@SOP28 [(SA630)]
[(SA430T)]

MB85R256@TSOP28

MB85R256A@SOP28 [(SA630)]
[(SA430T)]

MB85R256A@TSOP28

MBM271001
[(SA015A1T)]

MBM271001@PLCC32

MBM271001@TSOP32 [(SA410T)]

MBM27128

MBM27128@PLCC32 [(SA015A1T)]

MBM2716

MBM2716H

MBM27256

MBM27256@PLCC32 [(SA015A1T)]

MBM2732

MBM2732A

MBM2764

MBM2764@PLCC32 [(SA015A1T)]

MBM27C1000

MBM27C1000@TSOP32

[(SA410T)]

MBM27C1001

MBM27C1001@PLCC32

[(SA015A1T)]

MBM27C1001@TSOP32 [(SA410T)]

MBM27C1024

MBM27C1024@PLCC44 [(SA244)]

MBM27C1028

MBM27C1028@PLCC32 [(SA015A1T)]

MBM27C128

MBM27C128@PLCC32 [(SA015A1T)]

MBM27C128P

MBM27C128P@PLCC32 [(SA015A1T)]

MBM27C2000

MBM27C2000@TSOP32

MBM27C2000@PLCC32 [(SA015A1T)]
[(SA410T)]

MBM27C2001 [(SA015A1T)]	MBM27C2001@PLCC32
MBM27C2001@TSOP32 [(SA410T)]	
MBM27C2048	
MBM27C256 [(SA015A1T)]	MBM27C256@PLCC32
MBM27C256A [(SA015A1T)]	MBM27C256A@PLCC32
MBM27C256AP [(SA015A1T)]	MBM27C256AP@PLCC32
MBM27C256H [(SA015A1T)]	MBM27C256H@PLCC32
MBM27C32A	
MBM27C4001	
MBM27C4001@PLCC32 [(SA015A1T)] [(SA410T)]	MBM27C4001@TSOP32
MBM27C4096	
MBM27C512	
MBM27C512@PLCC32 [(SA015A1T)]	
MBM27C512P	
MBM27C512P@PLCC32 [(SA015A1T)]	
MBM27C64	
MBM27C64@PLCC32 [(SA015A1T)]	
MBM28C64	
MBM28C65	
MBM28F010	
MBM28F010@PLCC32 [(SA015A1T)] [(SA410T)]	MBM28F010@TSOP32
MBM29F001B [(SA015A1T)]	MBM29F001B@PLCC32
MBM29F001B@TSOP32 [(SA410T)]	
MBM29F001T	
MBM29F001T@PLCC32 [(SA015A1T)] [(SA410T)]	MBM29F001T@TSOP32
MBM29F002B [(SA015A1T)]	MBM29F002B@PLCC32
MBM29F002B@TSOP32 [(SA410T)]	
MBM29F002NB	
MBM29F002NB@PLCC32 [(SA015A1T)] [(SA410T)]	MBM29F002NB@TSOP32
MBM29F002NT [(SA015A1T)]	MBM29F002NT@PLCC32
MBM29F002NT@TSOP32 [(SA410T)]	

MBM29F002T	
MBM29F002T@PLCC32 [(SA015A1T)]	MBM29F002T@TSOP32
[(SA410T)]	
MBM29F010	MBM29F010@PLCC32
[(SA015A1T)]	
MBM29F010@TSOP32 [(SA410T)]	
MBM29F010A	
MBM29F010A@PLCC32 [(SA015A1T)]	MBM29F010A@TSOP32
[(SA410T)]	
MBM29F016@PSOP44 [(SA638)]	MBM29F016@TSOP40
[(SA409T)]	
MBM29F016@TSOP48 [(SA247-B005)]	MBM29F016A@PSOP44
[(SA638)]	
MBM29F016A@TSOP40 [(SA409T)]	MBM29F016A@TSOP48 [(SA247-
B005)]	
MBM29F016B@PSOP44 [(SA638)]	MBM29F016B@TSOP40
[(SA409T)]	
MBM29F016B@TSOP48 [(SA247-B005)]	MBM29F017B@TSOP48 [(SA247-
B005)]	
MBM29F017D@TSOP40 [(SA409T)]	MBM29F017D@TSOP48 [(SA247-
B005)]	
MBM29F032B@PSOP44 [(SA638)]	MBM29F032B@TSOP40
[(SA409T)]	
MBM29F033C@TSOP40 [(SA409T)]	
MBM29F040	
MBM29F040@PLCC32 [(SA015A1T)]	MBM29F040@TSOP32
[(SA410T)]	
MBM29F040B	MBM29F040B@PLCC32
[(SA015A1T)]	
MBM29F040B@TSOP32 [(SA410T)]	MBM29F040C@PLCC32
[(SA015A1T)]	
MBM29F040C@TSOP32 [(SA410T)]	MBM29F080@PSOP44
[(SA638)]	
MBM29F080@TSOP40 [(SA409T)]	MBM29F080A@TSOP48 [(SA247-
B005)]	
MBM29F080B@PSOP44 [(SA638)]	MBM29F080B@TSOP40
[(SA409T)]	
MBM29F100B@PSOP44 [(SA638-B006)]	MBM29F100B@TSOP48 [(SA247-
B005)]	
MBM29F100T@PSOP44 [(SA638-B006)]	MBM29F100T@TSOP48 [(SA247-
B005)]	
MBM29F160BE@TSOP48 [(SA247-B005)]	
MBM29F160TE@TSOP48 [(SA247-B005)]	

MBM29F200AB@PSOP44 [(SA638-B006)]	
MBM29F200AB@TSOP48 [(SA247-B005)]	
MBM29F200AT@PSOP44 [(SA638-B006)]	
MBM29F200AT@TSOP48 [(SA247-B005)]	
MBM29F200B@PSOP44 [(SA638-B006)]	MBM29F200B@TSOP48 [(SA247-B005)]
MBM29F200T@PSOP44 [(SA638-B006)]	MBM29F200T@TSOP48 [(SA247-B005)]
MBM29F400AB@PSOP44 [(SA638-B006)]	
MBM29F400AB@TSOP48 [(SA247-B005)]	
MBM29F400AT@PSOP44 [(SA638-B006)]	
MBM29F400AT@TSOP48 [(SA247-B005)]	
MBM29F400B@PSOP44 [(SA638-B006)]	MBM29F400B@TSOP48 [(SA247-B005)]
MBM29F400BB@PSOP44 [(SA638-B006)]	
MBM29F400BB@TSOP48 [(SA247-B005)]	
MBM29F400BT@PSOP44 [(SA638-B006)]	
MBM29F400BT@TSOP48 [(SA247-B005)]	
MBM29F400T@PSOP44 [(SA638-B006)]	MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)]	MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BA@PSOP44 [(SA638-B006)]	
MBM29F800BA@TSOP48 [(SA247-B005)]	
MBM29F800BB@PSOP44 [(SA638-B006)]	
MBM29F800BB@TSOP48 [(SA247-B005)]	
MBM29F800BT@PSOP44 [(SA638-B006)]	
MBM29F800BT@TSOP48 [(SA247-B005)]	
MBM29F800T@PSOP44 [(SA638-B006)]	MBM29F800T@TSOP48 [(SA247-B005)]
MBM29F800TA@PSOP44 [(SA638-B006)]	
MBM29F800TA@TSOP48 [(SA247-B005)]	
MBM29LL800B@TSOP48 [(SA247-B005)]	
MBM29LL800BB@TSOP48 [(SA247-B005)]	
MBM29LL800BT@TSOP48 [(SA247-B005)]	
MBM29LL800T@TSOP48 [(SA247-B005)]	
MBM29LV001B@PLCC32 [(SA015A1T)]	MBM29LV001BB@PLCC32 [(SA015A1T)]
MBM29LV001BB@TSOP32 [(SA410T)]	MBM29LV001BC@PLCC32 [(SA015A1T)]
MBM29LV001BC@TSOP32 [(SA410T)]	MBM29LV001BT@PLCC32 [(SA015A1T)]
MBM29LV001BT@TSOP32 [(SA410T)]	MBM29LV001T@TSOP32 [(SA015A1T)]

[(SA410T)]	
MBM29LV001TC@PLCC32 [(SA015A1T)]	MBM29LV001TC@TSOP32
[(SA410T)]	
MBM29LV002B@TSOP40 [(SA409T)]	MBM29LV002T@TSOP40
[(SA409T)]	
MBM29LV004B@PSOP44 [(SA638)]	MBM29LV004B@TSOP40
[(SA409T)]	
MBM29LV004BB@TSOP40 [(SA409T)]	MBM29LV004BT@TSOP40
[(SA409T)]	
MBM29LV004T@PSOP44 [(SA638)]	MBM29LV004T@TSOP40
[(SA409T)]	
MBM29LV008B@PSOP44 [(SA638)]	MBM29LV008B@TSOP40
[(SA409T)]	
MBM29LV008BB@TSOP40 [(SA409T)]	MBM29LV008BT@TSOP40
[(SA409T)]	
MBM29LV008T@PSOP44 [(SA638)]	MBM29LV008T@TSOP40
[(SA409T)]	
MBM29LV016/B@TSOP40 [(SA409T)]	MBM29LV016/T@TSOP40
[(SA409T)]	
MBM29LV016B@TSOP40 [(SA409T)]	MBM29LV017B@TSOP40
[(SA409T)]	
MBM29LV017E@TSOP40 [(SA409T)]	MBM29LV033C@TSOP40
[(SA409T)]	
MBM29LV080@TSOP40 [(SA409T)]	MBM29LV081@TSOP40
[(SA409T)]	
MBM29LV081B@TSOP40 [(SA409T)]	MBM29LV116B@TSOP40
[(SA409T)]	
MBM29LV200B@PSOP44 [(SA638-B006)]	
MBM29LV200B@TSOP48 [(SA247-B005)]	
MBM29LV200BB@PSOP44 [(SA638-B006)]	
MBM29LV200BB@TSOP48 [(SA247-B005)]	
MBM29LV200BC@PSOP44 [(SA638)]	
MBM29LV200BC@TSOP48 [(SA247-B005)]	
MBM29LV200BT@PSOP44 [(SA638-B006)]	
MBM29LV200BT@TSOP48 [(SA247-B005)]	
MBM29LV200T@PSOP44 [(SA638-B006)]	
MBM29LV200T@TSOP48 [(SA247-B005)]	
MBM29LV200TC@PSOP44 [(SA638)]	
MBM29LV200TC@TSOP48 [(SA247-B005)]	
MBM29LV400B@PSOP44 [(SA638-B006)]	
MBM29LV400B@TSOP48 [(SA247-B005)]	
MBM29LV400BB@PSOP44 [(SA638-B006)]	
MBM29LV400BB@TSOP48 [(SA247-B005)]	

MBM29LV400BT@PSOP44 [(SA638-B006)]
MBM29LV400BT@TSOP48 [(SA247-B005)]
MBM29LV400T@PSOP44 [(SA638-B006)]
MBM29LV400T@TSOP48 [(SA247-B005)]
MBM29LV800B@PSOP44 [(SA638-B006)]
MBM29LV800B@SON46 [(SA631)]
MBM29LV800B@TSOP48 [(SA247-B005)]
MBM29LV800BB@PSOP44 [(SA638-B006)]
MBM29LV800BB@TSOP48 [(SA247-B005)]
MBM29LV800BT@PSOP44 [(SA638-B006)]
MBM29LV800BT@TSOP48 [(SA247-B005)]
MBM29LV800T@PSOP44 [(SA638-B006)]
MBM29LV800T@SON46 [(SA631)]
MBM29LV800T@TSOP48 [(SA247-B005)]

DRAM & SRAM

MB81C78A
[(SA630)]

MB81C78A@SOIC28

GENCORE

MICROCONTROLLER

GC87C520A0
[(SA244)]
GC87C520A0@TQFP44 [(SA245A)]
GC87C520G0
GC87C520G0@PLCC44 [(SA244)]
[(SA245A)]

GC87C520A0@PLCC44

GC87C520G0@TQFP44

GENERAL(GI)

E (E) PROM / FRAM / NVRAM

27256
27C128
27C128@PLCC32 [(SA015A1T)]
27C256

27C256@PLCC32 [(SA015A1T)]
27C512
27C513
27C64
27C64@PLCC32 [(SA015A1T)]
27HC191
27HC291
27HC64
27HC641
27HC641L
27HC64L
28C04
28C04A
28C04F
28C16
28C16A
28C16F
28C17
28C17F
ER5911
ER5911@SOIC8 [(SA602A)]
GI5911
GI5911@SOIC8 [(SA602A)]
GI59C11
GI59C11@SOIC8 [(SA602A)]
GI59C12
GI59C12@SOIC8 [(SA602A)]
GR27C513

GENERIC

E (E) PROM / FRAM / NVRAM

27128 (21V) (12.5V)	27128A
2716 (25V) (12.5V)	27256
2732 (25V) (21V)	2732A
2732B (12.5V) (12.5V)	27512
27512 (21V)	2764

(21V)	
27C4A(12.5V)	27C128
(12.5V)	
27C128(21V)	27C16
(25V)	
27C256(12.5V)	27C32
(25V)	
27C512(12.5V)	27C64
(12.5V)	
27C64(21V)	

GIGADEVICE

E (E) PROM / FRAM / NVRAM

GD25D40 HEADER01]	GD25D40(ISP) [ISP-
GD25D40@SOP8 [(SA605A)] HEADER01]	GD25D40@SOP8(ISP) [ISP-
GD25D80 HEADER01]	GD25D80(ISP) [ISP-
GD25D80@SOP8 [(SA605A)] HEADER01]	GD25D80@SOP8(ISP) [ISP-
GD25F40 HEADER01]	GD25F40(ISP) [ISP-
GD25F40@SOP8 [(SA605A)] HEADER01]	GD25F40@SOP8(ISP) [ISP-
GD25F80 HEADER01]	GD25F80(ISP) [ISP-
GD25F80@SOP8 [(SA605A)] HEADER01]	GD25F80@SOP8(ISP) [ISP-
GD25T80 HEADER01]	GD25T80(ISP) [ISP-
GD25T80@SOP8 [(SA605A)] HEADER01]	GD25T80@SOP8(ISP) [ISP-

GOAL

MICROCONTROLLER

VRS1000 [(SA244)]	VRS1000@PLCC44
VRS1000@TQFP44 [(SA245A)]	
VRS1050 VRS1050@PLCC44 [(SA244)] [(SA675)]	VRS1050@TQFP44
VRS1100 [(SA244)]	VRS1100@PLCC44
VRS1100@TQFP44 [(SA245A)]	
VRS540 VRS540@PLCC44 [(SA244)] [(SA245A)]	VRS540@TQFP44
VRS550 [(SA244)]	VRS550@PLCC44
VRS550@TQFP44 [(SA245A)]	
VRS560 VRS560@PLCC44 [(SA244)] [(SA245A)]	VRS560@TQFP44
VRS570 [(SA244)]	VRS570@PLCC44
VRS570@TQFP44 [(SA245A)]	
VRS580 VRS580@PLCC44 [(SA244)] [(SA245A)]	VRS580@TQFP44
VRS700 [(SA244)]	VRS700@PLCC44
VRS700@TQFP44 [(SA245A)]	
VRS900 VRS900@PLCC44 [(SA244)] [(SA245A)]	VRS900@TQFP44

GREENWICH

E (E) PROM / FRAM / NVRAM

GR27128
GR27256
GR27512
GR2764

HAIER

MICROCONTROLLER

HCM87CP311SP@SDIP42 [(SA028)]
 HR6P59P2DL
 HR6P59P2SL@SOP14 [(SA602)]
 HR6P60P2DL
 HR6P60P2DL-A
 HR6P60P2EL
 HR6P60P2EL-A HR6P60P2SL@SOP20
 [(SA404)]
 HR6P60P2SL@SSOP20 [(SA626A)] HR6P60P2SL-A@SOP20
 [(SA404)]
 HR6P60P2SL-A@SSOP20 [(SA626A)] HR6P60P2XL@SOP18
 [(SA404)]
 HR6P60P2XL-A@SOP18 [(SA404)] HR6P60P2YL@SOP14
 [(SA404)]
 HR6P60P2YL-A@SOP14 [(SA404)]
 HR6P62P4D
 HR6P62P4DH
 HR6P62P4DHL
 HR6P62P4DHL(INTOSC) HR6P62P4DHL-
 D
 HR6P62P4DHL-D(INTOSC)
 HR6P62P4NHL(INTOSC)@SSOP20 [(SA626A)]
 HR6P62P4NHL@SSOP20 [(SA626A)]
 HR6P62P4NHL-D(INTOSC)@SSOP20 [(SA626A)]
 HR6P62P4NHL-D@SSOP20 [(SA626A)]
 HR6P62P4RHL(INTOSC)@SSOP20 [(SA626A)]
 HR6P62P4RHL@SSOP20 [(SA626A)]
 HR6P62P4RHL-D(INTOSC)@SSOP20 [(SA626A)]
 HR6P62P4RHL-D@SSOP20 [(SA626A)] HR6P62P4SH@SOP20 [(SA404
 +B003)]
 HR6P62P4SHL(INTOSC)@SOP20 [(SA404)]
 HR6P62P4SHL@SOP20 [(SA404)]
 HR6P62P4SHL-D(INTOSC)@SOP20 [(SA404)]
 HR6P62P4SHL-D@SOP20 [(SA404)]
 HR6P62P4XHL(INTOSC)@SOP18 [(SA404)]
 HR6P62P4XHL@SOP18 [(SA404)]
 HR6P62P4XHL-D(INTOSC)@SOP18 [(SA404)]
 HR6P62P4XHL-D@SOP18 [(SA404)] HR6P62P4YHL@SOIC14
 [(SA602)]
 HR6P62P4YHL-D@SOP14 [(SA602)]

HR6P67P4D	
HR6P67P4DL	HR6P67P4DL-
B	
HR6P67P4SL@SOP14 [(SA404+B003)]	
HR6P67P4SL-B@SOP14 [(SA404+B003)]	
HR6P71F8D	HR6P71F8D
(REVERSE)	
HR6P71F8S(REVERSE)@SOP20 [(SA404)]	
HR6P71F8S@SOP20 [(SA404)]	
HR6P72P4D	
HR6P72P4DL	HR6P72P4S@SOP28
[(SA404)]	
HR6P72P4SL@SOP28 [(SA404+B003)]	
HR6P73P8DB	
HR6P73P8DBL	HR6P73P8SB@SOP28
[(SA404)]	
HR6P73P8SBL@SOP28 [(SA404-B003)]	
HR6P73PGD	
HR6P73PGDH	
HR6P73PGDHL	
HR6P73PGS@SOP28 [(SA404+B003)]	HR6P73PGSH@SOP28
[(SA404)]	
HR6P73PGSHL@SOP28 [(SA404-B003)]	
HR6P76PGD	
HR6P76PGDL	HR6P76PGS@SOP28
[(SA404)]	
HR6P76PGSL@SOP28 [(SA404-B003)]	
HR6P77PGD	
HR6P77PGDL	HR6P77PGL@LQFP44 [(SA245-
B005)]	
HR6P77PGLL@LQFP44 [(SA245-B005)]	HR6P78P4SL@SOP32 [(SA715
+B006)]	
HR6P90FGD	HR6P90FGS@SOP28
[(SA404)]	
HR6P90FHD	HR6P90FHS@SOP28
[(SA404)]	
HR6P91FGS@SOP32 [(SA715)]	HR6P91FHS@SOP32
[(SA715)]	
HR6P92FGD	HR6P92FGL@LQFP44
[(SA245A)]	
HR6P92FHD	HR6P92FHL@LQFP44
[(SA245A)]	
HR6P95F8D	HR6P95F8S@SOP28

[(SA404)]
HR6P97FGD HR6P97FGD
(EEPROM)
HR6P97FGD(EEPROM)(ISP) [ISP-HEADER01]
HR6P97FGD(ISP) [ISP-HEADER01]
HR6P97FGS(EEPROM)@SOP28 [(SA404)]
HR6P97FGS(EEPROM)@SOP28(ISP) [ISP-HEADER01]
HR6P97FGS@SOP28 [(SA404)]
HR6P97FGS@SOP28(ISP) [ISP-HEADER01]
HR6P98FGD HR6P98FGD
(EEPROM)
HR6P98FGD(EEPROM)(ISP) [ISP-HEADER01]
HR6P98FGD(ISP) [ISP-HEADER01]
HR6P98FGL(EEPROM)@LQFP44 [(SA245A)]
HR6P98FGL(EEPROM)@LQFP44(ISP) [ISP-HEADER01]
HR6P98FGL@LQFP44 [(SA245A)]
HR6P98FGL@LQFP44(ISP) [ISP-HEADER01]
HR7T46P8V@SDIP42 [(SA028)] HR7T46PGV@SDIP42 [(SA028
+B005)]
HR7T47P8L@LQFP44 [(SA245A)] HR7T47PGL@LQFP44 [(SA245A
+B005)]

HARRIS

DRAM & SRAM

HM6516 HM6516@PLCC32
[(SA015A1T)]
HM65162 HM65162@PLCC32
[(SA015A1T)]
HM65642 HM65642@TSOP28
[(SA643)]

HITACHI

E (E) PROM / FRAM / NVRAM

HN27128AG
HN27128AP
HN27256G

HN27256P
HN27512G
HN27512P
HN27C101AG
HN27C101AP
HN27C101G
HN27C101P
HN27C1024HG
HN27C1024HG@PLCC44
[(SA244)]
HN27C256AG
HN27C256FP
HN27C256G
HN27C256HG
HN27C301AG
HN27C301AP
HN27C301G
HN27C301P
HN27C4000FP
HN27C4000G
HN27C4001
HN27C4001@TSOP32
[(SA410T)]
HN27C4001G
HN27C4096A
HN27C4096A@PLCC44 [(SA244)]
HN27C4096FP
HN27C4096FP@PLCC44 [(SA244)]
HN27C4096G
HN27C4096G@PLCC44 [(SA244)]
HN27C512G
HN27C512G@PLCC32 [(SA015A1T)]
HN27C64G
HN28F101
HN28F101@PLCC32
[(SA015A1T)]
HN28F101@SOP32 [(SA438T)]
HN28F101@TSOP32
[(SA410T)]
HN462716G
HN462732G
HN48016(P)
HN4827128G
HN4827128P
HN482732AG
HN482764G
HN482764P

HN58064(FP)@SOIC28 [(SA404)] (P)	HN58064
HN58C1001(FP)@SSOP32 [(SA438T)] (P)	HN58C1001
HN58C1001(T)@VSOP32 [(SA620)] [(SA630)]	HN58C256A(FP)@SOP28
HN58C256A(P) [(SA643)]	HN58C256A(T)@TSOP28
HN58C257A(T)@TSOP32 [(SA620)] [(SA404)]	HN58C65(FP)@SOIC28
HN58C65(P) HN58C66	
HN58C66@SOP28 [(SA630)] [(SA430T)]	HN58C66@TSOP28
HN58V24256 [(SA602A)]	HN58V24256@SOIC8
HN58V24256@TSSOP14 [(SA026)] HN58V24512	
HN58V24512@SOIC8 [(SA602A)] HN58V256A	
HN58V256A@TSOP28 [(SA430T)] HN58V65A	
HN58V65A@SOIC28 [(SA630)] [(SA430T)]	HN58V65A@TSOP28
HN58V66A [(SA630)]	HN58V66A@SOIC28
HN58V66A@TSOP28 [(SA430T)] HN58W241000	
HN58W241000@SOIC8 [(SA602A)] HN58X2402	
HN58X2402@SOIC8 [(SA602A)] [(SA026)]	HN58X2402@TSSOP8
HN58X2404 [(SA602A)]	HN58X2404@SOIC8
HN58X2404@TSSOP8 [(SA026)] HN58X2408	
HN58X2408@SOIC8 [(SA602A)] [(SA026)]	HN58X2408@TSSOP8
HN58X24128 [(SA602A)]	HN58X24128@SOIC8
HN58X2416 [(SA602A)]	HN58X2416@SOIC8
HN58X2416@TSSOP8 [(SA026)]	

HN58X24256	
HN58X24256@SOIC8 [(SA602A)]	
HN58X2432	
HN58X2432@SOIC8 [(SA602A)]	HN58X2432@TSSOP8
[(SA026)]	
HN58X24512	HN58X24512@SOIC8
[(SA602A)]	
HN58X2464	HN58X2464@SOIC8
[(SA602A)]	
HN58X2464@TSSOP8 [(SA026)]	HN58X2502@SOIC8
[(SA602A)]	
HN58X2502@TSSOP8 [(SA026)]	HN58X2504@SOIC8
[(SA602A)]	
HN58X2504@TSSOP8 [(SA026)]	HN58X25128@SOIC8
[(SA602A)]	
HN58X25128@TSSOP14 [(SA026)]	HN58X25256@SOIC8
[(SA602A)]	
HN58X25256@TSSOP14 [(SA026)]	HN58X2532@SOIC8
[(SA602A)]	
HN58X2532@TSSOP8 [(SA026)]	HN58X2564@SOIC8
[(SA602A)]	
HN58X2564@TSSOP8 [(SA026)]	HT29VB800@TSOP48 [(SA247-
B005)]	
HT29VT800@TSOP48 [(SA247-B005)]	HT29WB800@TSOP48 [(SA247-
B005)]	
HT29WT800@TSOP48 [(SA247-B005)]	

DRAM & SRAM

HM6116	HM6116@PLCC32
[(SA015A1T)]	
HM6116A	HM6116A@PLCC32
[(SA015A1T)]	
HM6208	HM6208@SOJ24
[(SA646)]	
HM6208H	HM6208H@SOJ24
[(SA646)]	
HM62256	HM62256@TSOP28
[(SA643)]	
HM62256B	HM62256B@TSOP28
[(SA643)]	
HM624256	HM624256@SOJ28

[(SA646)]	
HM6264A	HM6264A@TSOP28
[(SA643)]	
HM6267	
HM6268	
HM628128	HM628128@TSOP32
[(SA410T)]	
HM628128A	HM628128A@TSOP32
[(SA410T)]	
HM62832	HM62832@TSOP28
[(SA643)]	
HM62832H	HM62832H@TSOP28
[(SA643)]	
HM628512	HM628512@TSOP32
[(SA729)]	
HM6287	
HM6287HP	
HM6288	HM6288@SOJ22
[(SA646)]	
HM65256B	HM65256B@TSOP28
[(SA643)]	
HM658128	HM658128@TSOP32
[(SA410T)]	
HM66204	HM66204@TSOP32
[(SA410T)]	
HM6707	HM6707@SOJ24
[(SA646)]	
HM6707A	HM6707A@SOJ24
[(SA646)]	
HM6708	HM6708@SOJ24
[(SA646)]	
HM6708A	HM6708A@SOJ24
[(SA646)]	
HM6716	HM6716@PLCC32
[(SA015A1T)]	
HM6787	
HM6787HP	
HM6788	HM6788@SOJ22
[(SA646)]	
HM6788H	HM6788H@SOJ22
[(SA646)]	
HM6788HA	HM6788HA@SOJ22
[(SA646)]	

MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)]
[(SA404)]
HD4074394@SDIP28 [(SA022A)]
[(SA404)]

HD4074344@SOIC28
HD4074394@SOIC28

HOLTEK

E (E) PROM / FRAM / NVRAM

HT24C01
[(SA602A)]
HT24C02
[(SA602A)]
HT24C04
[(SA602A)]
HT24C08
HT24C16
HT24LC01
[(SA602A)]
HT24LC01@TSSOP8 [(SA026)]
HT24LC02
HT24LC02@SOIC8 [(SA602A)]
[(SA026)]
HT24LC04
[(SA602A)]
HT24LC08
[(SA602A)]
HT24LC16
[(SA602A)]
HT24LC32
[(SA602A)]
HT24LC64
[(SA602A)]
HT25LC512@SOIC8 [(SA602A)]
HT27C010
HT27C010@PLCC32 [(SA015A1T)]
[(SA410T)]
HT27C020

HT24C01@SOIC8
HT24C02@SOIC8
HT24C04@SOIC8
HT24LC01@SOIC8
HT24LC02@TSSOP8
HT24LC04@SOIC8
HT24LC08@SOIC8
HT24LC16@SOIC8
HT24LC32@SOIC8
HT24LC64@SOIC8
HT27C010@TSOP32
HT27C020@PLCC32

[(SA015A1T)]	
HT27C020@TSOP32 [(SA410T)]	
HT27C040	
HT27C040@PLCC32 [(SA015A1T)]	HT27C040@TSOP32
[(SA410T)]	
HT27C4096	HT27C4096@PLCC44
[(SA244)]	
HT27C512	HT27C512@PLCC32
[(SA015A1T)]	
HT27C512@TSOP28 [(SA430T)]	
HT27LC010	
HT27LC010@PLCC32 [(SA015A1T)]	HT27LC010@TSOP32
[(SA410T)]	
HT27LC020	HT27LC020@PLCC32
[(SA015A1T)]	
HT27LC020@TSOP32 [(SA410T)]	
HT27LC040	
HT27LC040@PLCC32 [(SA015A1T)]	HT27LC040@TSOP32
[(SA410T)]	
HT27LC4096	HT27LC4096@PLCC44
[(SA244)]	
HT27LC512	HT27LC512@PLCC32
[(SA015A1T)]	
HT27LC512@TSOP28 [(SA430T)]	HT93C46
(16bit)	
HT93C46(16bit)@SOP8-A [(SA602A)]	HT93C46(16bit)@SOP8-B
[(SA602A)]	
HT93C46(16bit)@TSSOP8 [(SA026)]	HT93C56
(16bit)	
HT93C56(16bit)@SOP8-A [(SA602A)]	HT93C56(16bit)@SOP8-B
[(SA602A)]	
HT93C56(16bit)@TSSOP8 [(SA026)]	HT93C66
(16bit)	
HT93C66(16bit)@SOP8-A [(SA602A)]	HT93C66(16bit)@SOP8-B
[(SA602A)]	
HT93C66(16bit)@TSSOP8 [(SA026)]	HT93LC46A
(08bit)	
HT93LC46A(08bit)@SOP8-A [(SA602A)]	
HT93LC46A(08bit)@SOP8-B [(SA602A)]	
HT93LC46A(08bit)@TSSOP8 [(SA026)]	
HT93LC46A(16bit)	
HT93LC46A(16bit)@SOP8-A [(SA602A)]	
HT93LC46A(16bit)@SOP8-B [(SA602A)]	

HT93LC46A(16bit)@TSSOP8 [(SA026)]
HT93LC46B(08bit)
HT93LC46B(08bit)@SOP8-A [(SA602A)]
HT93LC46B(08bit)@SOP8-B [(SA602A)]
HT93LC46B(08bit)@TSSOP8 [(SA026)]
HT93LC46B(16bit)
HT93LC46B(16bit)@SOP8-A [(SA602A)]
HT93LC46B(16bit)@SOP8-B [(SA602A)]
HT93LC46B(16bit)@TSSOP8 [(SA026)]
HT93LC56A(08bit)
HT93LC56A(08bit)@SOP8-A [(SA602A)]
HT93LC56A(08bit)@SOP8-B [(SA602A)]
HT93LC56A(08bit)@TSSOP8 [(SA026)]
HT93LC56A(16bit)
HT93LC56A(16bit)@SOP8-A [(SA602A)]
HT93LC56A(16bit)@SOP8-B [(SA602A)]
HT93LC56A(16bit)@TSSOP8 [(SA026)]
HT93LC56B(08bit)
HT93LC56B(08bit)@SOP8-A [(SA602A)]
HT93LC56B(08bit)@SOP8-B [(SA026)]
HT93LC56B(08bit)@TSSOP8 [(SA026)]
HT93LC56B(16bit)
HT93LC56B(16bit)@SOP8-A [(SA602A)]
HT93LC56B(16bit)@SOP8-B [(SA602A)]
HT93LC56B(16bit)@TSSOP8 [(SA026)]
HT93LC66A(08bit)
HT93LC66A(08bit)@SOP8-A [(SA602A)]
HT93LC66A(08bit)@SOP8-B [(SA602A)]
HT93LC66A(08bit)@TSSOP8 [(SA026)]
HT93LC66A(16bit)
HT93LC66A(16bit)@SOP8-A [(SA602A)]
HT93LC66A(16bit)@SOP8-B [(SA602A)]
HT93LC66A(16bit)@TSSOP8 [(SA026)]
HT93LC66B(08bit)
HT93LC66B(08bit)@SOP8-A [(SA602A)]
HT93LC66B(08bit)@SOP8-B [(SA026)]
HT93LC66B(08bit)@TSSOP8 [(SA026)]
HT93LC66B(16bit)
HT93LC66B(16bit)@SOP8-A [(SA602A)]
HT93LC66B(16bit)@SOP8-B [(SA602A)]
HT93LC66B(16bit)@TSSOP8 [(SA026)]
HT93LC76(08bit)
HT93LC76(08bit)@SOP8-A [(SA602A)]

HT93LC76(08bit)@SOP8-B [(SA602A)]	
HT93LC76(08bit)@TSSOP8 [(SA026)]	HT93LC76
(16bit)	
HT93LC76(16bit)@SOP8-A [(SA602A)]	
HT93LC76(16bit)@SOP8-B [(SA602A)]	
HT93LC76(16bit)@TSSOP8 [(SA026)]	HT93LC86
(08bit)	
HT93LC86(08bit)@SOP8-A [(SA602A)]	
HT93LC86(08bit)@SOP8-B [(SA602A)]	
HT93LC86(08bit)@TSSOP8 [(SA026)]	HT93LC86
(16bit)	
HT93LC86(16bit)@SOP8-A [(SA602A)]	
HT93LC86(16bit)@SOP8-B [(SA602A)]	
HT93LC86(16bit)@TSSOP8 [(SA026)]	

MICROCONTROLLER

HT46R22	HT46R22@SOP24
[(SA404)]	
HT46R23(dip24)	HT46R23
(dip28)	
HT46R23@SOP24 [(SA404)]	HT46R23@SOP28
[(SA404)]	
HT46R24	HT46R24@SOP28
[(SA404)]	
HT46R24@SSOP48 [(SA669)]	HT46R46
(dip18)	
HT46R46(dip20)	HT46R46@SOP18
[(SA404)]	
HT46R46@SOP20 [(SA404)]	HT46R46E
(dip18)	
HT46R46E@SOP18 [(SA404)]	HT46R46-
H	
HT46R46-H@SOP18 [(SA404)]	HT46R47
(dip18)	
HT46R47(dip20)	HT46R47@SOP18
[(SA404)]	
HT46R47@SOP20 [(SA404)]	HT46R47@SSOP20
[(SA674)]	
HT46R47E(dip18)	HT46R47E@SOP18
[(SA404)]	
HT46R47-H	HT46R47-H@SOP18

[(SA404)]	
HT46R48(dip20)	HT46R48
(dip24)	
HT46R48@SOP20 [(SA404)]	HT46R48@SOP24
[(SA404)]	
HT46R48@SSOP24 [(SA674)]	HT46R48E
(dip24)	
HT46R48E@SOP24 [(SA404)]	HT46R48E@SSOP24
[(SA674)]	
HT46R51A(dip18)	HT46R51A@SOP20
[(SA404)]	
HT46R51A@SSOP20 [(SA674)]	HT46R52A
(dip18)	
HT46R52A@SOP20 [(SA404)]	HT46R52A@SSOP20
[(SA674)]	
HT46R53A(dip28)	HT46R53A@SOP28
[(SA404)]	
HT46R54A(dip28)	HT46R54A@SOP28
[(SA404)]	
HT46R65@PQFP100 [(PEP+S427)]	HT46R65@SSOP56
[(SA669)]	
HT46R71D@SSOP48 [(SA669)]	
HT46RB70	
HT46RB70@SOP28 [(SA404)]	HT46RB70@SSOP48
[(SA669)]	
HT46RU22(dip24)	HT46RU22@SOP24
[(SA404)]	
HT46RU22@SSOP24 [(SA674)]	HT47R10A@QFP44
[(SA245)]	
HT48R05A	HT48R05A@SOP16
[(SA026)]	
HT48R05A@SOP18 [(SA404)]	
HT48R06A	
HT48R06A@SOP16 [(SA026)]	HT48R06A@SOP18
[(SA404)]	
HT48R07A	HT48R07A@SOP24
[(SA404)]	
HT48R07A@SSOP24 [(SA674)]	
HT48R08A	
HT48R08A@SOP16 [(SA026)]	HT48R08A@SOP18
[(SA404)]	
HT48R09A	HT48R09A@SOP24
[(SA404)]	

HT48R09A@SSOP24 [(SA674)]	
HT48R10A	
HT48R10A@SOP24 [(SA404)]	HT48R30A
(dip24)	
HT48R30A(dip28)	HT48R30A@SOP24
[(SA404)]	
HT48R30A@SOP28 [(SA404)]	
HT48R50A	
HT48R50A@SOP28 [(SA404)]	HT48R52A@QFP44
[(SA245A)]	
HT48RA0-1	HT48RA0-1@SOP24
[(SA404)]	
HT48RA0-2	HT48RA0-2@SOP20
[(SA404)]	
HT48RA0-2@SSOP20 [(SA674)]	HT48RA0-
3	
HT48RA0-3@SOP20 [(SA404)]	HT48RA1@SOP28
[(SA404)]	
HT48RA1@SSOP28 [(SA626A)]	HT48RA3
(dip28)	
HT48RA3@SOP28 [(SA404)]	HT48RA3@SSOP28
[(SA626A)]	
HT48RA5(dip28)	HT48RA5@SOP28
[(SA404)]	
HT48RA5@SSOP28 [(SA626A)]	
HT48RB50	
HT48RB50@SOP28 [(SA404)]	HT48RB8@SOP28
[(SA404)]	
HT49R30A@SSOP48 [(SA669)]	HT82A821R@SOP24
[(SA404)]	
HT82A821R@SSOP24 [(SA674)]	HT82A822R@SSOP48
[(SA669)]	
HT82A832R@QFP48 [(SA248)]	HT82A832R@SSOP48
[(SA669)]	
HT82K68E	HT82K68E@SOP20
[(SA404)]	
HT82K68E@SOP28 [(SA404)]	HT82K95E@SOP20
[(SA404)]	
HT82K95E@SOP28 [(SA404)]	HT82K96E
(dip20)	
HT82K96E(dip40)	HT82K96E@SOP20
[(SA404)]	
HT82K96E@SOP28 [(SA404)]	HT82M99E

(dip18)	
HT82M99E(dip20)	HT82M99E@SOP18
[(SA404)]	
HT82M99E@SOP20 [(SA404)]	HT82M9AE@SOP20
[(SA404)]	
HT82M9AE@SOP24 [(SA404)]	HT82M9AE@SSOP20
[(SA674)]	
HT82M9AE@SSOP24 [(SA674)]	HT82M9BE@SOP24
[(SA404)]	
HT82M9BE@SOP28 [(SA404)]	HT82M9BE@SSOP24
[(SA674)]	
HT82M9BE@SSOP28 [(SA626A)]	

HONGKONG

[E \(E\) PROM/FRAM/NVRAM](#)

HK1215
HK1225
HK1235
HK1245
HK1255
HK1265
HK1275
HK1285
HK1295
HK12A5
HK12B5
OKS1225
OKS1235
OKS1245
OKS1255
OKS1265
OKS1275
OKS1285
OKS1295
OKS12A5
OKS12B5

HYNIX

E (E) PROM / FRAM / NVRAM

HY2764	
HY27C64A	
HY29F002T	HY29F002T@PLCC32
[(SA015A1T)]	
HY29F002T@TSOP32 [(SA410T)]	
HY29F040	
HY29F040@PLCC32 [(SA015A1T)]	HY29F040@TSOP32
[(SA410T)]	
HY29F040A	
[(SA015A1T)]	
HY29F040A@TSOP32 [(SA410T)]	HY29F040A@PLCC32
[(SA409T)]	
HY29F200B@PSOP44 [(SA638-B006)]	HY29F080@TSOP40
B005)]	
HY29F200T@PSOP44 [(SA638-B006)]	HY29F200B@TSOP48 [(SA247-
B005)]	HY29F200T@TSOP48 [(SA247-
HY29F400ABG@PSOP44 [(SA638)]	
HY29F400ABT@TSOP48 [(SA247-B005)]	
HY29F400ATG@PSOP44 [(SA638)]	
HY29F400ATT@TSOP48 [(SA247-B005)]	
HY29F400BG@PSOP44 [(SA638)]	HY29F400BT@TSOP48 [(SA247-
B005)]	
HY29F400TG@PSOP44 [(SA638)]	HY29F400TT@TSOP48 [(SA247-
B005)]	
HY29F800ABG@PSOP44 [(SA638)]	
HY29F800ABT@TSOP48 [(SA247-B005)]	
HY29F800ATG@PSOP44 [(SA638)]	
HY29F800ATT@TSOP48 [(SA247-B005)]	
HY29F800BG@PSOP44 [(SA638)]	HY29F800BT@TSOP48 [(SA247-
B005)]	
HY29F800TG@PSOP44 [(SA638)]	HY29F800TT@TSOP48 [(SA247-
B005)]	
HY93C46	HY93C46@SOIC8
[(SA602A)]	
HY93C56	HY93C56@SOIC8
[(SA602A)]	
HY93C66	HY93C66@SOIC8
[(SA602A)]	
HY93C76	HY93C76@SOIC8
[(SA602A)]	
HY93C86	HY93C86@SOIC8

[(SA602A)]

DRAM & SRAM

HY62256A [(SA643)]	HY62256A@TSOP28
HY6264A [(SA643)]	HY6264A@TSOP28
HY628100A [(SA438T)]	HY628100A@SOP32
HY628100A@TSOP32 [(SA410T)]	
HY628100B HY628100B@SOP32 [(SA438T)]	HY628100B@TSOP32
[(SA410T)]	
HY628400 [(SA438T)]	HY628400@SOP32
HY628400@TSOP32 [(SA410T)]	
HY628400A HY628400A@SOP32 [(SA438T)]	HY628400A@TSOP32
[(SA410T)]	
HY62CT08081E [(SA438T)]	HY62CT08081E@SOP28
HY62CT08081E@TSOP28 [(SA643)]	
HY62KT08081E HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28
[(SA643)]	
HY62U8100B [(SA438T)]	HY62U8100B@SOP32
HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32
[(SA410T)]	
HY62U8400A [(SA438T)]	HY62U8400A@SOP32
HY62U8400A@TSOP32 [(SA410T)]	
HY62UT08081E HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28
[(SA643)]	
HY62V8100B [(SA438T)]	HY62V8100B@SOP32
HY62V8100B@TSOP32 [(SA410T)]	
HY62V8200B	

HY62V8200B@SOP32 [(SA438T)]
 [(SA410T)]
 HY62V8400A
 [(SA438T)]
 HY62V8400A@TSOP32 [(SA410T)]
 HY62VT08081E
 HY62VT08081E@SOP28 [(SA438T)]
 [(SA643)]
 HY62WT08081E
 [(SA438T)]
 HY62WT08081E@TSOP28 [(SA643)]

HY62V8200B@TSOP32
 HY62V8400A@SOP32
 HY62VT08081E@TSOP28
 HY62WT08081E@SOP28

MICROCONTROLLER

GMS97C1051
 [(SA404)]
 GMS97C2051
 [(SA404)]
 GMS97C51
 [(SA244)]
 GMS97C51@TQFP44 [(SA245A)]
 GMS97C52
 GMS97C52@PLCC44 [(SA244)]
 [(SA245A)]
 GMS97C54
 [(SA244)]
 GMS97C54@TQFP44 [(SA245A)]
 GMS97C56
 GMS97C56@PLCC44 [(SA244)]
 [(SA245A)]
 GMS97C58
 [(SA244)]
 GMS97C58@TQFP44 [(SA245A)]
 GMS97L1051
 GMS97L1051@SOIC20 [(SA404)]
 GMS97L2051
 GMS97L2051@SOIC20 [(SA404)]
 GMS97L51
 GMS97L51@PLCC44 [(SA244)]
 [(SA245A)]
 GMS97L52
 [(SA244)]

GMS97C1051@SOIC20
 GMS97C2051@SOIC20
 GMS97C51@PLCC44
 GMS97C52@TQFP44
 GMS97C54@PLCC44
 GMS97C56@TQFP44
 GMS97C58@PLCC44
 GMS97L51@TQFP44
 GMS97L52@PLCC44

GMS97L52@TQFP44 [(SA245A)]	
GMS97L54	
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44
[(SA245A)]	
GMS97L56	
[(SA244)]	GMS97L56@PLCC44
GMS97L56@TQFP44 [(SA245A)]	
GMS97L58	
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44
[(SA245A)]	
GMS99C52	
[(SA244)]	GMS99C52@PLCC44
GMS99C52@TQFP44 [(SA245A)]	
GMS99C58	
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44
[(SA245A)]	
HMS99C52	
[(SA244)]	HMS99C52@PLCC44
HMS99C52@TQFP44 [(SA245A)]	
HMS99C58	
HMS99C58@PLCC44 [(SA244)]	HMS99C58@TQFP44
[(SA245A)]	

HYUNDAI

E (E) PROM / FRAM / NVRAM

HY2764	
HY27C64A	
HY29F002T	HY29F002T@PLCC32
[(SA015A1T)]	
HY29F002T@TSOP32 [(SA410T)]	
HY29F040	
HY29F040@PLCC32 [(SA015A1T)]	HY29F040@TSOP32
[(SA410T)]	
HY29F040A	
[(SA015A1T)]	HY29F040A@PLCC32
HY29F040A@TSOP32 [(SA410T)]	
[(SA409T)]	HY29F080@TSOP40
HY29F200B@PSOP44 [(SA638-B006)]	HY29F200B@TSOP48 [(SA247-
B005)]	
HY29F200T@PSOP44 [(SA638-B006)]	HY29F200T@TSOP48 [(SA247-

B005)]	
HY29F400ABG@PSOP44 [(SA638)]	
HY29F400ABT@TSOP48 [(SA247-B005)]	
HY29F400ATG@PSOP44 [(SA638)]	
HY29F400ATT@TSOP48 [(SA247-B005)]	
HY29F400BG@PSOP44 [(SA638)]	HY29F400BT@TSOP48 [(SA247-B005)]
HY29F400TG@PSOP44 [(SA638)]	HY29F400TT@TSOP48 [(SA247-B005)]
HY29F800ABG@PSOP44 [(SA638)]	
HY29F800ABT@TSOP48 [(SA247-B005)]	
HY29F800ATG@PSOP44 [(SA638)]	
HY29F800ATT@TSOP48 [(SA247-B005)]	
HY29F800BG@PSOP44 [(SA638)]	HY29F800BT@TSOP48 [(SA247-B005)]
HY29F800TG@PSOP44 [(SA638)]	HY29F800TT@TSOP48 [(SA247-B005)]
HY93C46 [(SA602A)]	HY93C46@SOIC8
HY93C56 [(SA602A)]	HY93C56@SOIC8
HY93C66 [(SA602A)]	HY93C66@SOIC8
HY93C76 [(SA602A)]	HY93C76@SOIC8
HY93C86 [(SA602A)]	HY93C86@SOIC8

DRAM & SRAM

HY62256A [(SA643)]	HY62256A@TSOP28
HY6264A [(SA643)]	HY6264A@TSOP28
HY628100A [(SA438T)]	HY628100A@SOP32
HY628100A@TSOP32 [(SA410T)]	
HY628100B [(SA438T)]	HY628100B@TSOP32
HY628400 [(SA438T)]	HY628400@SOP32

HY628400@TSOP32 [(SA410T)]	
HY628400A	
HY628400A@SOP32 [(SA438T)]	HY628400A@TSOP32
[(SA410T)]	
HY62CT08081E	HY62CT08081E@SOP28
[(SA438T)]	
HY62CT08081E@TSOP28 [(SA643)]	
HY62KT08081E	
HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28
[(SA643)]	
HY62U8100B	HY62U8100B@SOP32
[(SA438T)]	
HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B	
HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32
[(SA410T)]	
HY62U8400A	HY62U8400A@SOP32
[(SA438T)]	
HY62U8400A@TSOP32 [(SA410T)]	
HY62UT08081E	
HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28
[(SA643)]	
HY62V8100B	HY62V8100B@SOP32
[(SA438T)]	
HY62V8100B@TSOP32 [(SA410T)]	
HY62V8200B	
HY62V8200B@SOP32 [(SA438T)]	HY62V8200B@TSOP32
[(SA410T)]	
HY62V8400A	HY62V8400A@SOP32
[(SA438T)]	
HY62V8400A@TSOP32 [(SA410T)]	
HY62VT08081E	
HY62VT08081E@SOP28 [(SA438T)]	HY62VT08081E@TSOP28
[(SA643)]	
HY62WT08081E	HY62WT08081E@SOP28
[(SA438T)]	
HY62WT08081E@TSOP28 [(SA643)]	

MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20
[(SA404)]	

GMS97C2051 [(SA404)]	GMS97C2051@SOIC20
GMS97C51 [(SA244)]	GMS97C51@PLCC44
GMS97C51@TQFP44 [(SA245A)]	
GMS97C52 GMS97C52@PLCC44 [(SA244)] [(SA245A)]	GMS97C52@TQFP44
GMS97C54 [(SA244)]	GMS97C54@PLCC44
GMS97C54@TQFP44 [(SA245A)]	
GMS97C56 GMS97C56@PLCC44 [(SA244)] [(SA245A)]	GMS97C56@TQFP44
GMS97C58 [(SA244)]	GMS97C58@PLCC44
GMS97C58@TQFP44 [(SA245A)]	
GMS97L1051 GMS97L1051@SOIC20 [(SA404)]	
GMS97L2051 GMS97L2051@SOIC20 [(SA404)]	
GMS97L51 GMS97L51@PLCC44 [(SA244)] [(SA245A)]	GMS97L51@TQFP44
GMS97L52 [(SA244)]	GMS97L52@PLCC44
GMS97L52@TQFP44 [(SA245A)]	
GMS97L54 GMS97L54@PLCC44 [(SA244)] [(SA245A)]	GMS97L54@TQFP44
GMS97L56 [(SA244)]	GMS97L56@PLCC44
GMS97L56@TQFP44 [(SA245A)]	
GMS97L58 GMS97L58@PLCC44 [(SA244)] [(SA245A)]	GMS97L58@TQFP44
GMS99C52 [(SA244)]	GMS99C52@PLCC44
GMS99C52@TQFP44 [(SA245A)]	
GMS99C58 GMS99C58@PLCC44 [(SA244)] [(SA245A)]	GMS99C58@TQFP44
HMS99C52	HMS99C52@PLCC44

[(SA244)]
HMS99C52@TQFP44 [(SA245A)]
HMS99C58
HMS99C58@PLCC44 [(SA244)] HMS99C58@TQFP44
[(SA245A)]

ICE

E (E) PROM / FRAM / NVRAM

ICE25P05 [(SA602A)]	ICE25P05@SOIC8
ICE27C010 [(SA015A1T)]	ICE27C010@PLCC32
ICE27C010@TSOP32 [(SA410T)]	
ICE27C020 ICE27C020@PLCC32 [(SA015A1T)]	ICE27C020@TSOP32
[(SA410T)]	
ICE27C512 [(SA015A1T)]	ICE27C512@PLCC32
ICE27C512@TSOP28 [(SA430T)]	
ICE27LC010 ICE27LC010@PLCC32 [(SA015A1T)]	ICE27LC010@TSOP32
[(SA410T)]	
ICE27LC020 [(SA015A1T)]	ICE27LC020@PLCC32
ICE27LC020@TSOP32 [(SA410T)]	
ICE27LC512 ICE27LC512@PLCC32 [(SA015A1T)]	ICE27LC512@TSOP28
[(SA430T)]	
ICE28LF010 [(SA015A1T)]	ICE28LF010@PLCC32
ICE37C512 [(SA015A1T)]	ICE37C512@PLCC32
ICE37C512@TSOP32 [(SA410T)]	
ICE37LC512 ICE37LC512@PLCC32 [(SA015A1T)]	ICE37LC512@TSOP32
[(SA410T)]	

ICMIC

E (E) PROM / FRAM / NVRAM

X76F101 [(SA602A)]	X76F101@SOIC8
X76F400@SOIC8 [(SA602A)] [(SA026)]	X76F400@TSSOP8

ICSI**MICROCONTROLLER**

IC89LV51A [(SA244)]	IC89LV51A@PLCC44
IC89LV51A@TQFP44 [(SA245A)]	
IC89LV52A IC89LV52A@PLCC44 [(SA244)] [(SA245A)]	IC89LV52A@TQFP44
IS89C51A [(SA244)]	IS89C51A@PLCC44
IS89C51A@TQFP44 [(SA245A)]	
IS89C52A IS89C52A@PLCC44 [(SA244)] [(SA245A)]	IS89C52A@TQFP44
IS89C54 [(SA244)]	IS89C54@PLCC44
IS89C54@TQFP44 [(SA245A)]	
IS89C58 IS89C58@PLCC44 [(SA244)] [(SA245A)]	IS89C58@TQFP44
IS89C64 [(SA244)]	IS89C64@PLCC44
IS89C64@TQFP44 [(SA245A)]	
IS89E54 IS89E54@PLCC44 [(SA244)] [(SA245A)]	IS89E54@TQFP44
IS89E58 [(SA244)]	IS89E58@PLCC44
IS89E58@TQFP44 [(SA245A)]	
IS89E64 IS89E64@PLCC44 [(SA244)] [(SA245A)]	IS89E64@TQFP44

ICT**E (E) PROM/FRAM/NVRAM**

27CX010	27CX010@PLCC32
[(SA015A1T)]	
27CX010@TSOP32 [(SA410T)]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[(SA602A)]	
93C46A	93C46A@SOIC8
[(SA602A)]	
93C56A	93C56A@SOIC8
[(SA602A)]	
93C66A	93C66A@SOIC8
[(SA602A)]	
93CX46	93CX46@SOIC8
[(SA602A)]	
93CX56	93CX56@SOIC8
[(SA602A)]	
93CX66	93CX66@SOIC8
[(SA602A)]	

PLD

PEEL18CV8Z	PEEL18CV8Z@PLCC20
[(SA001A)]	
PEEL18CV8Z@SOIC20 [(SA404)]	PEEL18CV8Z@TSOP20
[(SA026)]	
PEEL18LV8Z	PEEL18LV8Z@PLCC20
[(SA001A)]	
PEEL18LV8Z@SOIC20 [(SA404)]	PEEL18LV8Z@TSOP20
[(SA026)]	
PEEL22CV10	PEEL22CV10@PLCC28

[(SA008A)]	PEEL22CV10A@PLCC28
PEEL22CV10A	
[(SA008A)]	PEEL22CV10A@TSOP24
PEEL22CV10A@SOIC24 [(SA404)]	
[(SA026)]	PEEL22CV10A+@PLCC28
PEEL22CV10A+	
[(SA008A)]	PEEL22CV10A+@TSOP24
PEEL22CV10A+@SOIC24 [(SA404)]	
[(SA026)]	PEEL22CV10A++@PLCC28
PEEL22CV10A++	
[(SA008A)]	PEEL22CV10A++@TSOP24
PEEL22CV10A++@SOIC24 [(SA404)]	
[(SA026)]	PEEL22CV10AZ@PLCC28
PEEL22CV10AZ	
[(SA008A)]	PEEL22CV10AZ@TSOP24
PEEL22CV10AZ@SOIC24 [(SA404)]	
[(SA026)]	PEEL22CV10AZ+@PLCC28
PEEL22CV10AZ+	
[(SA008A)]	PEEL22CV10AZ+@TSOP24
PEEL22CV10AZ+@SOIC24 [(SA404)]	
[(SA026)]	PEEL22CV10AZ++@PLCC28
PEEL22CV10AZ++	
[(SA008A)]	PEEL22CV10AZ++@TSOP24
PEEL22CV10AZ++@SOIC24 [(SA404)]	
[(SA026)]	PEEL22LV10AZ@PLCC28
PEEL22LV10AZ	
[(SA008A)]	PEEL22LV10AZ@TSOP24
PEEL22LV10AZ@SOIC24 [(SA404)]	
[(SA026)]	PEEL22LV10AZ+@PLCC28
PEEL22LV10AZ+	
[(SA008A)]	PEEL22LV10AZ+@TSOP24
PEEL22LV10AZ+@SOIC24 [(SA404)]	
[(SA026)]	PEEL22LV10AZ++@PLCC28
PEEL22LV10AZ++	
[(SA008A)]	PEEL22LV10AZ++@TSOP24
PEEL22LV10AZ++@SOIC24 [(SA404)]	
[(SA026)]	

IDT

[E \(E\) PROM/FRAM/NVRAM](#)

ICS280@TSSOP16 [(SA026)]
[(SA026)]

ICS281@TSSOP16

IMT

E (E) PROM / FRAM / NVRAM

IM29F001B [(SA015A1T)]	IM29F001B@PLCC32
IM29F001B@TSOP32 [(SA410T)] [(SA620)]	IM29F001B@VSOP32
IM29F001T [(SA015A1T)]	IM29F001T@PLCC32
IM29F001T@TSOP32 [(SA410T)] [(SA620)]	IM29F001T@VSOP32
IM29F002B [(SA015A1T)]	IM29F002B@PLCC32
IM29F002B@TSOP32 [(SA410T)] [(SA620)]	IM29F002B@VSOP32
IM29F002T [(SA015A1T)]	IM29F002T@PLCC32
IM29F002T@TSOP32 [(SA410T)] [(SA620)]	IM29F002T@VSOP32
IM29F004B [(SA015A1T)]	IM29F004B@PLCC32
IM29F004B@TSOP32 [(SA410T)] [(SA620)]	IM29F004B@VSOP32
IM29F004T [(SA015A1T)]	IM29F004T@PLCC32
IM29F004T@TSOP32 [(SA410T)] [(SA620)]	IM29F004T@VSOP32
IM29LV004B [(SA015A1T)]	IM29LV004B@PLCC32
IM29LV004B@TSOP32 [(SA410T)] [(SA620)]	IM29LV004B@VSOP32
IM29LV004T [(SA015A1T)]	IM29LV004T@PLCC32
IM29LV004T@TSOP32 [(SA410T)] [(SA620)]	IM29LV004T@VSOP32
IM29LV400B@PSOP44 [(SA638)] B005)]	IM29LV400B@TSOP48 [(SA247-
IM29LV400T@PSOP44 [(SA638)]	IM29LV400T@TSOP48 [(SA247-

B005)]

INTEL**E(E) PROM/FRAM/NVRAM**

27010	27010@PLCC32
[(SA015A1T)]	
27010@TSOP32 [(SA410T)]	
27128	
27128A	
27128B	
2716	
27210	
27256	
2732	
2732A	
27512	
2764	
2764A	
27C010	27C010@PLCC32
[(SA015A1T)]	
27C010@TSOP32 [(SA410T)]	
27C010A	
27C010A@PLCC32 [(SA015A1T)]	27C010A@TSOP32
[(SA410T)]	
27C020	27C020@PLCC32
[(SA015A1T)]	
27C020@TSOP32 [(SA410T)]	
27C040	
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32
[(SA410T)]	
27C100	27C100@PLCC32
[(SA015A1T)]	
27C100@TSOP32 [(SA410T)]	
27C128	
27C128@PLCC32 [(SA015A1T)]	
27C210	
27C210@PLCC44 [(SA244)]	
27C220	
27C220@PLCC44 [(SA244)]	
27C240	

27C240@PLCC44 [(SA244)]	
27C256	
27C256@PLCC32 [(SA015A1T)]	
27C400	
27C400@PLCC44 [(SA244)]	
27C512	
27C512@PLCC32 [(SA015A1T)]	
27C64	
27C64@PLCC32 [(SA015A1T)]	
27C800	
27S512	
2816A	
2817A	
2864A	
68C257	68C257@PLCC32
[(SA015A1T)]	
87C256	
87C257	
87C257@PLCC32 [(SA015A1T)]	
87C64	
D27011	
D27513	
D27C011	
D27C513	
D28F256	
D28F256A	
D28F512	E28F001BX-B@TSOP32
[(SA410T)]	
E28F001BX-T@TSOP32 [(SA410T)]	E28F002BCT@TSOP40
[(SA409T)]	
E28F002BEB@TSOP40 [(SA409T)]	E28F002BET@TSOP40
[(SA409T)]	
E28F002BLB@TSOP40 [(SA409T)]	E28F002BLT@TSOP40
[(SA409T)]	
E28F002BVB@TSOP40 [(SA409T)]	E28F002BVT@TSOP40
[(SA409T)]	
E28F002BXB@TSOP40 [(SA409T)]	E28F002BXT@TSOP40
[(SA409T)]	
E28F004B5B@TSOP40 [(SA409T)]	E28F004B5T@TSOP40
[(SA409T)]	
E28F004BEB@TSOP40 [(SA409T)]	E28F004BET@TSOP40
[(SA409T)]	
E28F004BLB@TSOP40 [(SA409T)]	E28F004BLT@TSOP40

[(SA409T)]	
E28F004BVB@TSOP40 [(SA409T)]	E28F004BVT@TSOP40
[(SA409T)]	
E28F004BXB@TSOP40 [(SA409T)]	E28F004BXT@TSOP40
[(SA409T)]	
E28F004S3@TSOP40 [(SA409T)]	E28F004S5@TSOP40
[(SA409T)]	
E28F004SC@TSOP40 [(SA409T)]	E28F008BEB@TSOP40
[(SA409T)]	
E28F008BET@TSOP40 [(SA409T)]	E28F008BLB@TSOP40
[(SA409T)]	
E28F008BLT@TSOP40 [(SA409T)]	E28F008BVB@TSOP40
[(SA409T)]	
E28F008BVT@TSOP40 [(SA409T)]	E28F008BXB@TSOP40
[(SA409T)]	
E28F008BXT@TSOP40 [(SA409T)]	E28F008S3@TSOP40
[(SA409T)]	
E28F008S5@TSOP40 [(SA409T)]	E28F008SA@TSOP40
[(SA409T)]	
E28F008SA-L@TSOP40 [(SA409T)]	E28F008SC@TSOP40
[(SA409T)]	
E28F010@TSOP32 [(SA410T)]	E28F016S3@TSOP40
[(SA409T)]	
E28F016S5@TSOP40 [(SA409T)]	E28F016SC@TSOP40
[(SA409T)]	
E28F020@TSOP32 [(SA410T)]	E28F256@TSOP32
[(SA410T)]	
E28F256A@TSOP32 [(SA410T)]	E28F512@TSOP32
[(SA410T)]	
E82802AA@TSOP40 [(SA409T)]	E82802AB@TSOP40
[(SA409T)]	
E82802AC@TSOP40 [(SA409T)]	F28F010@TSOP32
[(SA410T)]	
F28F020(REVERSE)@TSOP32 [(SA410T)]	
F28F020@TSOP32 [(SA410T)]	F28F256@TSOP32
[(SA410T)]	
F28F256A@TSOP32 [(SA410T)]	F28F512@TSOP32
[(SA410T)]	
M28F010	M28F010@PLCC32
[(SA015A1T)]	
M28F010@TSOP32 [(SA410T)]	N28F001BN-B@PLCC32
[(SA015A1T)]	
N28F001BN-T@PLCC32 [(SA015A1T)]	N28F001BX-B@PLCC32

[(SA015A1T)]	
N28F001BX-T@PLCC32 [(SA015A1T)]	N28F010@PLCC32
[(SA015A1T)]	
N28F020@PLCC32 [(SA015A1T)]	N28F256@PLCC32
[(SA015A1T)]	
N28F256A@PLCC32 [(SA015A1T)]	N28F512@PLCC32
[(SA015A1T)]	
N82802AA@PLCC32 [(SA015A1T)]	N82802AB@PLCC32
[(SA015A1T)]	
N82802AC@PLCC32 [(SA015A1T)]	
P27011	
P27128A	P27128A@PLCC32
[(SA015A1T)]	
P27128B	P27128B@PLCC32
[(SA015A1T)]	
P27256	P27256@PLCC32
[(SA015A1T)]	
P27512	
P27513	
P2764A	P2764A@PLCC32
[(SA015A1T)]	
P27C011	
P27C128	
P27C128@PLCC32 [(SA015A1T)]	
P27C256	
P27C256@PLCC32 [(SA015A1T)]	
P27C513	
P27C64	P27C64@PLCC32
[(SA015A1T)]	
P28F001BX-B	P28F001BX-
T	
P28F002BCT@TSOP40 [(SA409T)]	
P28F010	
P28F020	
P28F256	
P28F256A	
P28F512	
P87C64	P87C64@PLCC32
[(SA015A1T)]	
PA28F004S3@PSOP44 [(SA638)]	PA28F004S5@PSOP44
[(SA638)]	
PA28F004SC@PSOP44 [(SA638)]	PA28F008S3@PSOP44
[(SA638)]	

PA28F008S5@PSOP44 [(SA638)]	PA28F008SA@PSOP44
[(SA638)]	
PA28F008SA-L@PSOP44 [(SA638)]	PA28F008SC@PSOP44
[(SA638)]	
PA28F016S3@PSOP44 [(SA638)]	PA28F016S5@PSOP44
[(SA638)]	
PA28F016SC@PSOP44 [(SA638)]	PA28F200B5B@PSOP44
[(SA638)]	
PA28F200B5T@PSOP44 [(SA638)]	PA28F200BVB@PSOP44
[(SA638)]	
PA28F200BVT@PSOP44 [(SA638)]	PA28F200BXB@PSOP44
[(SA638)]	
PA28F200BXT@PSOP44 [(SA638)]	PA28F400B5B@PSOP44
[(SA638)]	
PA28F400B5T@PSOP44 [(SA638)]	PA28F400BVB@PSOP44
[(SA638)]	
PA28F400BVT@PSOP44 [(SA638)]	PA28F400BXB@PSOP44
[(SA638)]	
PA28F400BXT@PSOP44 [(SA638)]	PA28F800B5B@PSOP44
[(SA638)]	
PA28F800B5T@PSOP44 [(SA638)]	PA28F800BVB@PSOP44
[(SA638)]	
PA28F800BVT@PSOP44 [(SA638)]	QB25F016S33B60@SOIC8
[(SA605A)]	
QB25F016S33T60@SOIC8 [(SA605A)]	QB25F160S33B60@SOIC16
[(SA404)]	
QB25F160S33T60@SOIC16 [(SA404)]	QB25F320S33B60@SOIC16
[(SA404)]	
QB25F320S33T60@SOIC16 [(SA404)]	QB25F640S33B60@SOIC16
[(SA404)]	
QB25F640S33T60@SOIC16 [(SA404)]	QH25F016S33B60@SOIC8
[(SA605A)]	
QH25F016S33T60@SOIC8 [(SA605A)]	QH25F160S33B60@SOIC16
[(SA404)]	
QH25F160S33T60@SOIC16 [(SA404)]	QH25F320S33B60@SOIC16
[(SA404)]	
QH25F320S33T60@SOIC16 [(SA404)]	QH25F640S33B60@SOIC16
[(SA404)]	
QH25F640S33T60@SOIC16 [(SA404)]	TB28F004S3@PSOP44
[(SA638)]	
TB28F004S5@PSOP44 [(SA638)]	TB28F004SC@PSOP44
[(SA638)]	
TB28F008S3@PSOP44 [(SA638)]	TB28F008S5@PSOP44

[(SA638)]	
TB28F008SA@PSOP44 [(SA638)]	TB28F008SA-L@PSOP44
[(SA638)]	
TB28F008SC@PSOP44 [(SA638)]	TB28F016S3@PSOP44
[(SA638)]	
TB28F016S5@PSOP44 [(SA638)]	TB28F016SC@PSOP44
[(SA638)]	
TB28F200B5B@PSOP44 [(SA638)]	TB28F200B5T@PSOP44
[(SA638)]	
TB28F200BVB@PSOP44 [(SA638)]	TB28F200BVT@PSOP44
[(SA638)]	
TB28F200BXB@PSOP44 [(SA638)]	TB28F200BXT@PSOP44
[(SA638)]	
TB28F400B5B@PSOP44 [(SA638)]	TB28F400B5T@PSOP44
[(SA638)]	
TB28F400BVB@PSOP44 [(SA638)]	TB28F400BVT@PSOP44
[(SA638)]	
TB28F400BXB@PSOP44 [(SA638)]	TB28F400BXT@PSOP44
[(SA638)]	
TB28F800B5B@PSOP44 [(SA638)]	TB28F800B5T@PSOP44
[(SA638)]	
TB28F800BVB@PSOP44 [(SA638)]	TB28F800BVT@PSOP44
[(SA638)]	
TE28F002BEB@TSOP40 [(SA409T)]	TE28F002BET@TSOP40
[(SA409T)]	
TE28F002BVB@TSOP40 [(SA409T)]	TE28F002BVT@TSOP40
[(SA409T)]	
TE28F002BXB@TSOP40 [(SA409T)]	TE28F002BXT@TSOP40
[(SA409T)]	
TE28F004BEB@TSOP40 [(SA409T)]	TE28F004BET@TSOP40
[(SA409T)]	
TE28F004BVB@TSOP40 [(SA409T)]	TE28F004BVT@TSOP40
[(SA409T)]	
TE28F004BXB@TSOP40 [(SA409T)]	TE28F004BXT@TSOP40
[(SA409T)]	
TE28F004S3@TSOP40 [(SA409T)]	TE28F004S5@TSOP40
[(SA409T)]	
TE28F004SC@TSOP40 [(SA409T)]	TE28F008B3B@TSOP40
[(SA409T)]	
TE28F008B3BA@TSOP40 [(SA409T)]	TE28F008B3T@TSOP40
[(SA409T)]	
TE28F008B3TA@TSOP40 [(SA409T)]	TE28F008BEB@TSOP40
[(SA409T)]	

TE28F008BET@TSOP40 [(SA409T)]	TE28F008BVB@TSOP40
[(SA409T)]	
TE28F008BVT@TSOP40 [(SA409T)]	TE28F008S3@TSOP40
[(SA409T)]	
TE28F008S5@TSOP40 [(SA409T)]	TE28F008SA@TSOP40
[(SA409T)]	
TE28F008SA-L@TSOP40 [(SA409T)]	TE28F008SC@TSOP40
[(SA409T)]	
TE28F016B3B@TSOP40 [(SA409T)]	TE28F016B3T@TSOP40
[(SA409T)]	
TE28F016S3@TSOP40 [(SA409T)]	TE28F016S5@TSOP40
[(SA409T)]	
TE28F016SC@TSOP40 [(SA409T)]	

PLD

5C031	5C031@PLCC20
[(SA001A)]	
5C032	5C032@PLCC20
[(SA001A)]	
5C090	5C090@PLCC44
[(SA244)]	
85C090	85C090-P44
[(SA244)]	
85C220	85C220@PLCC20
[(SA001A)]	
IPLD910	IPLD910-P44
[(SA244)]	

MICROCONTROLLER

8751BH	8751BH@PLCC44
[(SA244)]	
8752BH	8752BH@PLCC44
[(SA244)]	
8796BH@PLCC68(*) [(SA648-B6803)]	8796JF@PLCC68(*) [(SA648-B6803)]
8797BH@PGA68(*) [(SA650-B6804)]	8797BH@PLCC68(*) [(SA648-B6803)]
8797JF@PGA68(*) [(SA650-B6804)]	8797JF@PLCC68(*) [(SA648-B6803)]

87C151SA	87C151SA@PLCC44
[(SA244)]	
87C151SB	87C151SB@PLCC44
[(SA244)]	
87C196CA@PLCC68(*) [(SA648-B6805)]	
87C196JQ@PLCC52(*) [(SA647-B5201)]	
87C196JR@PLCC52(*) [(SA647-B5201)]	
87C196JT@PLCC52(*) [(SA647-B5201)]	
87C196JV@PLCC52(*) [(SA647-B5201)]	
87C196KB@PLCC68(*) [(SA648-B6801)]	
87C196KC@PLCC68(*) [(SA648-B6801)]	
87C196KD@PLCC68(*) [(SA648-B6801)]	
87C196KQ@PLCC68(*) [(SA648-B6802)]	
87C196KR@PLCC68(*) [(SA648-B6802)]	
87C196KS@PLCC68(*) [(SA648-B6802)]	
87C196KT@PLCC68(*) [(SA648-B6802)]	
87C196LA@PLCC52(*) [(SA647-B5201)]	
87C196MC@PLCC84(*) [(SA649-B8401)]	
87C196MC@PQFP80(*) [(TA026-B006)]	
87C196MC@SDIP64(*) [(SA651)]	
87C196MH@PLCC84(*) [(SA649-B8401)]	
87C196MH@PQFP80(*) [(TA026-B006)]	
87C196MH@SDIP64(*) [(SA651)]	
87C251SA	
87C251SA@PLCC44 [(SA244)]	
87C251SB	
87C251SB@PLCC44 [(SA244)]	
87C251SP	
87C251SP@PLCC44 [(SA244)]	
87C251SQ	
87C251SQ@PLCC44 [(SA244)]	
87C51	
87C51@PLCC44 [(SA244)]	87C51@TQFP44
[(SA245A)]	
87C51FA	87C51FA@PLCC44
[(SA244)]	
87C51FA@TQFP44 [(SA245A)]	
87C51FB	
87C51FB@PLCC44 [(SA244)]	87C51FB@TQFP44
[(SA245A)]	
87C51FC	87C51FC@PLCC44
[(SA244)]	
87C51FC@TQFP44 [(SA245A)]	

87C51RA	
87C51RA@PLCC44 [(SA244)]	87C51RA@TQFP44
[(SA245A)]	
87C51RB	87C51RB@PLCC44
[(SA244)]	
87C51RB@TQFP44 [(SA245A)]	
87C51RC	
87C51RC@PLCC44 [(SA244)]	87C51RC@TQFP44
[(SA245A)]	
87C52	87C52@PLCC44
[(SA244)]	
87C52@TQFP44 [(SA245A)]	
87C54	
87C54@PLCC44 [(SA244)]	87C54@TQFP44
[(SA245A)]	
87C58	87C58@PLCC44
[(SA244)]	
87C58@TQFP44 [(SA245A)]	87L51FA@PLCC44
[(SA244)]	
87L51FA@TQFP44 [(SA245A)]	87L51FB@PLCC44
[(SA244)]	
87L51FB@TQFP44 [(SA245A)]	87L51FC@PLCC44
[(SA244)]	
87L51FC@TQFP44 [(SA245A)]	87L52@PLCC44
[(SA244)]	
87L52@TQFP44 [(SA245A)]	87L54@PLCC44
[(SA244)]	
87L54@TQFP44 [(SA245A)]	87L58@PLCC44
[(SA244)]	
87L58@TQFP44 [(SA245A)]	

INTELSIL

E(E) PROM/FRAM/NVRAM

HS-6617RH	HS-6617RH@SOIC24
[(SA404)]	
HS-6617RH-T	HS-6617RH-T@SOIC24
[(SA404)]	
HS-6883RH	HS-6883RH@SOIC24
[(SA404)]	
HS-6883RH-T	HS-6883RH-T@SOIC24

[(SA404)]

ISSI**E (E) PROM / FRAM / NVRAM**

IS24C01 [(SA666)]	IS24C01@MSOP8
IS24C01@SOIC8 [(SA602A)] [(SA026)]	IS24C01@TSSOP8
IS24C01B [(SA666)]	IS24C01B@MSOP8
IS24C01B@SOIC8 [(SA602A)] [(SA026)]	IS24C01B@TSSOP8
IS24C02 [(SA666)]	IS24C02@MSOP8
IS24C02@SOIC8 [(SA602A)] [(SA026)]	IS24C02@TSSOP8
IS24C02A IS24C02A@DFN8	
IS24C02A@MSOP8 [(SA666)] [(SA602A)]	IS24C02A@SOIC8
IS24C02A@TSSOP8 [(SA026)]	
IS24C02B IS24C02B@DFN8	
[(SA666)]	IS24C02B@MSOP8
IS24C02B@SOIC8 [(SA602A)] [(SA026)]	IS24C02B@TSSOP8
IS24C02C IS24C02C@DFN8	
IS24C02C@MSOP8 [(SA666)] [(SA602A)]	IS24C02C@SOIC8
IS24C02C@TSSOP8 [(SA026)]	
IS24C04 IS24C04@MSOP8 [(SA666)] [(SA602A)]	IS24C04@SOIC8
IS24C04@TSSOP8 [(SA026)]	
IS24C04A IS24C04A@DFN8	
[(SA666)]	IS24C04A@MSOP8
IS24C04A@SOIC8 [(SA602A)] [(SA026)]	IS24C04A@TSSOP8

IS24C08 [(SA666)]	IS24C08@MSOP8
IS24C08@SOIC8 [(SA602A)] [(SA026)]	IS24C08@TSSOP8
IS24C08A IS24C08A@DFN8	
IS24C08A@MSOP8 [(SA666)] [(SA602A)]	IS24C08A@SOIC8
IS24C08A@TSSOP8 [(SA026)]	
IS24C128 IS24C128@SOIC8 [(SA602A)] [(SA026)]	IS24C128@TSSOP14
IS24C16 [(SA666)]	IS24C16@MSOP8
IS24C16@SOIC8 [(SA602A)] [(SA026)]	IS24C16@TSSOP8
IS24C16A [(SA666)]	IS24C16A@MSOP8
IS24C16A@SOIC8 [(SA602A)] [(SA026)]	IS24C16A@TSSOP8
IS24C256 [(SA602A)]	IS24C256@SOIC8
IS24C256@TSSOP14 [(SA026)]	
IS24C256A IS24C256A@SOIC8 [(SA602A)] [(SA026)]	IS24C256A@TSSOP14
IS24C32 [(SA602A)]	IS24C32@SOIC8
IS24C32@TSSOP8 [(SA026)]	
IS24C32A IS24C32A@MSOP8 [(SA666)] [(SA602A)]	IS24C32A@SOIC8
IS24C32A@TSSOP8 [(SA026)]	
IS24C32B IS24C32B@SOIC8 [(SA602A)] [(SA026)]	IS24C32B@TSSOP8
IS24C64 [(SA602A)]	IS24C64@SOIC8
IS24C64@TSSOP8 [(SA026)]	
IS24C64A IS24C64A@MSOP8 [(SA666)] [(SA602A)]	IS24C64A@SOIC8
IS24C64A@TSSOP8 [(SA026)]	

IS24C64B	
IS24C64B@SOIC8 [(SA602A)]	IS24C64B@TSSOP8
[(SA026)]	
IS24L128	
IS24L128@SOIC8(150mil) [(SA602A)]	
IS24L128@SOIC8(200mil) [(SA605A)]	
IS24L256	
IS24L256@SOIC8(150mil) [(SA602A)]	
IS24L256@SOIC8(200mil) [(SA605A)]	
IS25C01	IS25C01@SOIC8
[(SA602A)]	
IS25C01@TSSOP8 [(SA026)]	
IS25C02	
IS25C02@SOIC8 [(SA602A)]	IS25C02@TSSOP8
[(SA026)]	
IS25C04	IS25C04@SOIC8
[(SA602A)]	
IS25C04@TSSOP8 [(SA026)]	
IS25C08	
IS25C08@SOIC8 [(SA602A)]	IS25C08@TSSOP8
[(SA026)]	
IS25C128@SOIC8 [(SA602A)]	IS25C128@TSSOP8
[(SA026)]	
IS25C16	IS25C16@SOIC8
[(SA602A)]	
IS25C16@TSSOP8 [(SA026)]	IS25C256@SOIC8
[(SA602A)]	
IS25C256@TSSOP8 [(SA026)]	
IS25C32A	
IS25C32A@SOIC8 [(SA602A)]	IS25C32A@TSSOP8
[(SA026)]	
IS25C64A	IS25C64A@SOIC8
[(SA602A)]	
IS25C64A@TSSOP8 [(SA026)]	
IS27C010	
IS27C010@PLCC32 [(SA015A1T)]	IS27C010@TSOP32
[(SA410T)]	
IS27C020	IS27C020@PLCC32
[(SA015A1T)]	
IS27C020@TSOP32 [(SA410T)]	
IS27C256	
IS27C256@PLCC32 [(SA015A1T)]	
IS27C512	

IS27C512@PLCC32 [(SA015A1T)]	IS27C512@TSOP28
[(SA430T)]	
IS27HC010	IS27HC010@PLCC32
[(SA015A1T)]	
IS27HC010@TSOP32 [(SA410T)]	
IS27HC020	IS27HC020@TSOP32
IS27HC020@PLCC32 [(SA015A1T)]	
[(SA410T)]	
IS27HC256	IS27HC256@PLCC32
[(SA015A1T)]	
IS27HC512	IS27HC512@PLCC32
[(SA015A1T)]	
IS27HC512@TSOP28 [(SA430T)]	
IS27LV010	IS27LV010@TSOP32
IS27LV010@PLCC32 [(SA015A1T)]	
[(SA410T)]	
IS27LV512	IS27LV512@PLCC32
[(SA015A1T)]	
IS27LV512@TSOP28 [(SA430T)]	
IS28F010	IS28F010@TSOP32
IS28F010@PLCC32 [(SA015A1T)]	
[(SA410T)]	
IS28F010A	IS28F010A@PLCC32
[(SA015A1T)]	
IS28F010A@TSOP32 [(SA410T)]	
IS28F020	IS28F020@TSOP32
IS28F020@PLCC32 [(SA015A1T)]	
[(SA410T)]	
IS29F010	IS29F010@PLCC32
[(SA015A1T)]	
IS29F010@TSOP32 [(SA410T)]	
IS34C02	IS34C02@SOIC8
IS34C02@MSOP8 [(SA666)]	
[(SA602A)]	
IS34C02@TSSOP8 [(SA026)]	
IS34C02B@DFN8	
IS34C02B@TSSOP8 [(SA026)]	
IS93C46	IS93C46A
IS93C46@SOIC8 [(SA602A)]	
(08bit)	
IS93C46A(08bit)@SOIC8 [(SA602A)]	IS93C46A(08bit)@TSSOP8
[(SA026)]	
IS93C46A(16bit)	IS93C46A(16bit)@SOIC8

[(SA602A)]	
IS93C46A(16bit)@TSSOP8 [(SA026)]	
IS93C46B	
IS93C46B@SOIC8 [(SA602A)]	IS93C46B@TSSOP8
[(SA026)]	
IS93C46D(08bit)	IS93C46D(08bit)@SOIC8
[(SA602A)]	
IS93C46D(08bit)@TSSOP8 [(SA026)]	IS93C46D
(16bit)	
IS93C46D(16bit)@SOIC8 [(SA602A)]	IS93C46D(16bit)@TSSOP8
[(SA026)]	
IS93C56	IS93C56@SOIC8
[(SA602A)]	
IS93C56A(08bit)	IS93C56A(08bit)@SOIC8
[(SA602A)]	
IS93C56A(08bit)@TSSOP8 [(SA026)]	IS93C56A
(16bit)	
IS93C56A(16bit)@SOIC8 [(SA602A)]	IS93C56A(16bit)@TSSOP8
[(SA026)]	
IS93C66	IS93C66@SOIC8
[(SA602A)]	
IS93C66A(08bit)	IS93C66A(08bit)@SOIC8
[(SA602A)]	
IS93C66A(08bit)@TSSOP8 [(SA026)]	IS93C66A
(16bit)	
IS93C66A(16bit)@SOIC8 [(SA602A)]	IS93C66A(16bit)@TSSOP8
[(SA026)]	
IS93C76A(08bit)	IS93C76A(08bit)@SOIC8
[(SA602A)]	
IS93C76A(08bit)@TSSOP8 [(SA026)]	IS93C76A
(16bit)	
IS93C76A(16bit)@SOIC8 [(SA602A)]	IS93C76A(16bit)@TSSOP8
[(SA026)]	
IS93C86A(08bit)	IS93C86A(08bit)@SOIC8
[(SA602A)]	
IS93C86A(08bit)@TSSOP8 [(SA026)]	IS93C86A
(16bit)	
IS93C86A(16bit)@SOIC8 [(SA602A)]	IS93C86A(16bit)@TSSOP8
[(SA026)]	

DRAM & SRAM

IS61C1024 [(SA646)]	IS61C1024(300m)@SOJ32
IS61C1024(400m)@SOJ32 [(SA661)] [(SA410T)]	IS61C1024@TSOP32
IS61C1024L [(SA646)]	IS61C1024L(300m)@SOJ32
IS61C1024L(400m)@SOJ32 [(SA661)] [(SA410T)]	IS61C1024L@TSOP32
IS61C256AH [(SA646)]	IS61C256AH@SOJ28
IS61C256AH@TSOP28 [(SA430T)]	
IS61C512 IS61C512(300m)@SOJ32 [(SA646)] [(SA661)]	IS61C512(400m)@SOJ32
IS61C512@TSOP32 [(SA410T)]	
IS61C64AH IS61C64AH@SOJ28 [(SA646)] [(SA430T)]	IS61C64AH@TSOP28
IS61LV256 [(SA646)]	IS61LV256@SOJ28
IS61LV256@TSOP28 [(SA430T)]	
IS61M256 IS61M256@SOJ28 [(SA646)] [(SA430T)]	IS61M256@TSOP28
IS62C1024 [(SA646)]	IS62C1024(300m)@SOJ32
IS62C1024(400m)@SOJ32 [(SA661)] [(SA410T)]	IS62C1024@TSOP32
IS62C256 [(SA646)]	IS62C256@SOJ28
IS62C256@TSOP28 [(SA430T)]	
IS62C512 IS62C512(300m)@SOJ32 [(SA646)] [(SA661)]	IS62C512(400m)@SOJ32
IS62C512@TSOP32 [(SA410T)]	
IS62C64 IS62C64@SOJ28 [(SA646)] [(SA430T)]	IS62C64@TSOP28
IS62LV256 [(SA646)]	IS62LV256@SOJ28
IS62LV256@TSOP28 [(SA430T)]	

MICROCONTROLLER

IS89C51A [(SA244)]	IS89C51A@PLCC44
IS89C51A@TQFP44 [(SA245A)]	
IS89C52A IS89C52A@PLCC44 [(SA244)] [(SA245A)]	IS89C52A@TQFP44

LATTICE**PLD**

GAL16LV8 [(SA001A)]	GAL16LV8@PLCC20
GAL16LV8C [(SA001A)]	GAL16LV8C@PLCC20
GAL16LV8D [(SA001A)]	GAL16LV8D@PLCC20
GAL16LV8Z [(SA001A)]	GAL16LV8Z@PLCC20
GAL16LV8ZD [(SA001A)]	GAL16LV8ZD@PLCC20
GAL16V8 [(SA001A)]	GAL16V8@PLCC20
GAL16V8@SOIC20 [(SA404)]	
GAL16V8A GAL16V8A@PLCC20 [(SA001A)] [(SA404)]	GAL16V8A@SOIC20
GAL16V8B [(SA001A)]	GAL16V8B@PLCC20
GAL16V8B@SOIC20 [(SA404)]	
GAL16V8C GAL16V8C@PLCC20 [(SA001A)] [(SA404)]	GAL16V8C@SOIC20
GAL16V8D [(SA001A)]	GAL16V8D@PLCC20
GAL16V8D@SOIC20 [(SA404)]	
GAL16V8Z GAL16V8Z@PLCC20 [(SA001A)] [(SA404)]	GAL16V8Z@SOIC20
GAL18V10	GAL18V10@PLCC20

[(SA001A)] GAL18V10B	GAL18V10B@PLCC20
[(SA001A)] GAL20LV8	GAL20LV8@PLCC28
[(SA008A)] GAL20LV8Z	GAL20LV8Z@PLCC28
[(SA008A)] GAL20LV8ZD	GAL20LV8ZD@PLCC28
[(SA008A)] GAL20RA10	GAL20RA10@PLCC28
[(SA008A)] GAL20RA10B	GAL20RA10B@PLCC28
[(SA008A)] GAL20V8	GAL20V8@PLCC28
[(SA008A)] GAL20V8A	GAL20V8A@PLCC28
[(SA008A)] GAL20V8B	GAL20V8B@PLCC28
[(SA008A)] GAL20V8C	GAL20V8C@PLCC28
[(SA008A)] GAL20V8Z	GAL20V8Z@PLCC28
[(SA008A)] GAL20XV10	GAL20XV10@PLCC28
[(SA008A)] GAL20XV10B	GAL20XV10B@PLCC28
[(SA008A)] GAL22LV10C	GAL22LV10C@PLCC28
[(SA008A)] GAL22LV10C@SOIC24 [(SA404)]	GAL22LV10C@TSOP24
[(SA643)] GAL22LV10D	GAL22LV10D@PLCC28
[(SA008A)] GAL22LV10D@SOIC24 [(SA404)]	GAL22LV10D@TSOP24
[(SA643)] GAL22LV10Z	GAL22LV10Z@PLCC28
[(SA008A)] GAL22LV10Z@SOIC24 [(SA404)]	GAL22LV10Z@TSOP24
[(SA643)] GAL22LV10ZD	GAL22LV10ZD@PLCC28
[(SA008A)] GAL22LV10ZD@SOIC24 [(SA404)]	GAL22LV10ZD@TSOP24
[(SA643)]	

GAL22V10	GAL22V10@PLCC28
[(SA008A)]	
GAL22V10@SOIC24 [(SA404)]	
GAL22V10A	
GAL22V10A@PLCC28 [(SA008A)]	GAL22V10A@SOIC24
[(SA404)]	
GAL22V10B	GAL22V10B@PLCC28
[(SA008A)]	
GAL22V10B@SOIC24 [(SA404)]	
GAL22V10BQ	
GAL22V10BQ@PLCC28 [(SA008A)]	GAL22V10BQ@SOIC24
[(SA404)]	
GAL22V10C	GAL22V10C@PLCC28
[(SA008A)]	
GAL22V10C@SOIC24 [(SA404)]	
GAL22V10D	
GAL22V10D@PLCC28 [(SA008A)]	GAL22V10D@SOIC24
[(SA404)]	
ispGAL22LV10	ispGAL22LV10(ISP) [ISP-
HEADER01]	
ispGAL22LV10@PLCC28 [(SA008A)]	
ispGAL22LV10@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10@SSOP28 [(SA626A)]	
ispGAL22LV10@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10A	
ispGAL22LV10A(ISP) [ISP-HEADER01]	
ispGAL22LV10A@PLCC28 [(SA008A)]	
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10A@SSOP28 [(SA626A)]	
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10B	
ispGAL22LV10B(ISP) [ISP-HEADER01]	
ispGAL22LV10B@PLCC28 [(SA008A)]	
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10B@SSOP28 [(SA626A)]	
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10C	
ispGAL22LV10C(ISP) [ISP-HEADER01]	
ispGAL22LV10C@PLCC28 [(SA008A)]	
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10C@SSOP28 [(SA626A)]	
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10D	

ispGAL22LV10D(ISP) [ISP-HEADER01]
ispGAL22LV10D@PLCC28 [(SA008A)]
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10D@SSOP28 [(SA626A)]
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]
ispGAL22V10AB@PLCC28 [(SA008A)] ispGAL22V10AB@QFN32
[(SA686)]
ispGAL22V10AC@PLCC28 [(SA008A)] ispGAL22V10AC@QFN32
[(SA686)]
ispGAL22V10AV@PLCC28 [(SA008A)] ispGAL22V10AV@QFN32
[(SA686)]
ispGAL22V10C(UES)@PLCC28 [(SA008A)]
ispGAL22V10C@PLCC28 [(SA008A)]
LCMXO1200C-FT256(ISP) [ISP-HEADER01]
LCMXO1200C-FT324(ISP) [ISP-HEADER01]
LCMXO1200C-FTN256(ISP) [ISP-HEADER01]
LCMXO1200C-FTN324(ISP) [ISP-HEADER01]
LCMXO1200C-M100(ISP) [ISP-HEADER01]
LCMXO1200C-M132(ISP) [ISP-HEADER01]
LCMXO1200C-MN100(ISP) [ISP-HEADER01]
LCMXO1200C-MN132(ISP) [ISP-HEADER01]
LCMXO1200C-T100(ISP) [ISP-HEADER01]
LCMXO1200C-T144(ISP) [ISP-HEADER01]
LCMXO1200C-TN100(ISP) [ISP-HEADER01]
LCMXO1200C-TN144(ISP) [ISP-HEADER01]
LCMXO1200E-FT256(ISP) [ISP-HEADER01]
LCMXO1200E-FT324(ISP) [ISP-HEADER01]
LCMXO1200E-FTN256(ISP) [ISP-HEADER01]
LCMXO1200E-FTN324(ISP) [ISP-HEADER01]
LCMXO1200E-M100(ISP) [ISP-HEADER01]
LCMXO1200E-M132(ISP) [ISP-HEADER01]
LCMXO1200E-MN100(ISP) [ISP-HEADER01]
LCMXO1200E-MN132(ISP) [ISP-HEADER01]
LCMXO1200E-T100(ISP) [ISP-HEADER01]
LCMXO1200E-T144(ISP) [ISP-HEADER01]
LCMXO1200E-TN100(ISP) [ISP-HEADER01]
LCMXO1200E-TN144(ISP) [ISP-HEADER01]
LCMXO2280C-FT256(ISP) [ISP-HEADER01]
LCMXO2280C-FT324(ISP) [ISP-HEADER01]
LCMXO2280C-FTN256(ISP) [ISP-HEADER01]
LCMXO2280C-FTN324(ISP) [ISP-HEADER01]
LCMXO2280C-M100(ISP) [ISP-HEADER01]
LCMXO2280C-M132(ISP) [ISP-HEADER01]

LCMXO2280C-MN100 (ISP) [ISP-HEADER01]
LCMXO2280C-MN132 (ISP) [ISP-HEADER01]
LCMXO2280C-T100 (ISP) [ISP-HEADER01]
LCMXO2280C-T144 (ISP) [ISP-HEADER01]
LCMXO2280C-TN100 (ISP) [ISP-HEADER01]
LCMXO2280C-TN144 (ISP) [ISP-HEADER01]
LCMXO2280E-FT256 (ISP) [ISP-HEADER01]
LCMXO2280E-FT324 (ISP) [ISP-HEADER01]
LCMXO2280E-FTN256 (ISP) [ISP-HEADER01]
LCMXO2280E-FTN324 (ISP) [ISP-HEADER01]
LCMXO2280E-M100 (ISP) [ISP-HEADER01]
LCMXO2280E-M132 (ISP) [ISP-HEADER01]
LCMXO2280E-MN100 (ISP) [ISP-HEADER01]
LCMXO2280E-MN132 (ISP) [ISP-HEADER01]
LCMXO2280E-T100 (ISP) [ISP-HEADER01]
LCMXO2280E-T144 (ISP) [ISP-HEADER01]
LCMXO2280E-TN100 (ISP) [ISP-HEADER01]
LCMXO2280E-TN144 (ISP) [ISP-HEADER01]
LCMXO256C-FT256 (ISP) [ISP-HEADER01]
LCMXO256C-FT324 (ISP) [ISP-HEADER01]
LCMXO256C-FTN256 (ISP) [ISP-HEADER01]
LCMXO256C-FTN324 (ISP) [ISP-HEADER01]
LCMXO256C-M100 (ISP) [ISP-HEADER01]
LCMXO256C-M132 (ISP) [ISP-HEADER01]
LCMXO256C-MN100 (ISP) [ISP-HEADER01]
LCMXO256C-MN132 (ISP) [ISP-HEADER01]
LCMXO256C-T100 (ISP) [ISP-HEADER01]
LCMXO256C-T144 (ISP) [ISP-HEADER01]
LCMXO256C-TN100 (ISP) [ISP-HEADER01]
LCMXO256C-TN144 (ISP) [ISP-HEADER01]
LCMXO256E-FT256 (ISP) [ISP-HEADER01]
LCMXO256E-FT324 (ISP) [ISP-HEADER01]
LCMXO256E-FTN256 (ISP) [ISP-HEADER01]
LCMXO256E-FTN324 (ISP) [ISP-HEADER01]
LCMXO256E-M100 (ISP) [ISP-HEADER01]
LCMXO256E-M132 (ISP) [ISP-HEADER01]
LCMXO256E-MN100 (ISP) [ISP-HEADER01]
LCMXO256E-MN132 (ISP) [ISP-HEADER01]
LCMXO256E-T100 (ISP) [ISP-HEADER01]
LCMXO256E-T144 (ISP) [ISP-HEADER01]
LCMXO256E-TN100 (ISP) [ISP-HEADER01]
LCMXO256E-TN144 (ISP) [ISP-HEADER01]
LCMXO640C-FT256 (ISP) [ISP-HEADER01]

LCMXO640C-FT324 (ISP) [ISP-HEADER01]
LCMXO640C-FTN256 (ISP) [ISP-HEADER01]
LCMXO640C-FTN324 (ISP) [ISP-HEADER01]
LCMXO640C-M100 (ISP) [ISP-HEADER01]
LCMXO640C-M132 (ISP) [ISP-HEADER01]
LCMXO640C-MN100 (ISP) [ISP-HEADER01]
LCMXO640C-MN132 (ISP) [ISP-HEADER01]
LCMXO640C-T100 (ISP) [ISP-HEADER01]
LCMXO640C-T144 (ISP) [ISP-HEADER01]
LCMXO640C-TN100 (ISP) [ISP-HEADER01]
LCMXO640C-TN144 (ISP) [ISP-HEADER01]
LCMXO640E-FT256 (ISP) [ISP-HEADER01]
LCMXO640E-FT324 (ISP) [ISP-HEADER01]
LCMXO640E-FTN256 (ISP) [ISP-HEADER01]
LCMXO640E-FTN324 (ISP) [ISP-HEADER01]
LCMXO640E-M100 (ISP) [ISP-HEADER01]
LCMXO640E-M132 (ISP) [ISP-HEADER01]
LCMXO640E-MN100 (ISP) [ISP-HEADER01]
LCMXO640E-MN132 (ISP) [ISP-HEADER01]
LCMXO640E-T100 (ISP) [ISP-HEADER01]
LCMXO640E-T144 (ISP) [ISP-HEADER01]
LCMXO640E-TN100 (ISP) [ISP-HEADER01]
LCMXO640E-TN144 (ISP) [ISP-HEADER01]
LFXP10C-3F256C (ISP) [ISP-HEADER01]
LFXP10C-3F256I (ISP) [ISP-HEADER01]
LFXP10C-3F388C (ISP) [ISP-HEADER01]
LFXP10C-3F388I (ISP) [ISP-HEADER01]
LFXP10C-3FN256C (ISP) [ISP-HEADER01]
LFXP10C-3FN256I (ISP) [ISP-HEADER01]
LFXP10C-3FN388C (ISP) [ISP-HEADER01]
LFXP10C-3FN388I (ISP) [ISP-HEADER01]
LFXP10C-4F256C (ISP) [ISP-HEADER01]
LFXP10C-4F256I (ISP) [ISP-HEADER01]
LFXP10C-4F388C (ISP) [ISP-HEADER01]
LFXP10C-4F388I (ISP) [ISP-HEADER01]
LFXP10C-4FN256C (ISP) [ISP-HEADER01]
LFXP10C-4FN256I (ISP) [ISP-HEADER01]
LFXP10C-4FN388C (ISP) [ISP-HEADER01]
LFXP10C-4FN388I (ISP) [ISP-HEADER01]
LFXP10C-5F256C (ISP) [ISP-HEADER01]
LFXP10C-5F256I (ISP) [ISP-HEADER01]
LFXP10C-5F388C (ISP) [ISP-HEADER01]
LFXP10C-5F388I (ISP) [ISP-HEADER01]

LFXP10C-5FN256C (ISP) [ISP-HEADER01]
LFXP10C-5FN256I (ISP) [ISP-HEADER01]
LFXP10C-5FN388C (ISP) [ISP-HEADER01]
LFXP10C-5FN388I (ISP) [ISP-HEADER01]
LFXP10E-3F256C (ISP) [ISP-HEADER01]
LFXP10E-3F256I (ISP) [ISP-HEADER01]
LFXP10E-3F388C (ISP) [ISP-HEADER01]
LFXP10E-3F388I (ISP) [ISP-HEADER01]
LFXP10E-3FN256C (ISP) [ISP-HEADER01]
LFXP10E-3FN256I (ISP) [ISP-HEADER01]
LFXP10E-3FN388C (ISP) [ISP-HEADER01]
LFXP10E-3FN388I (ISP) [ISP-HEADER01]
LFXP10E-4F256C (ISP) [ISP-HEADER01]
LFXP10E-4F256I (ISP) [ISP-HEADER01]
LFXP10E-4F388C (ISP) [ISP-HEADER01]
LFXP10E-4F388I (ISP) [ISP-HEADER01]
LFXP10E-4FN256C (ISP) [ISP-HEADER01]
LFXP10E-4FN256I (ISP) [ISP-HEADER01]
LFXP10E-4FN388C (ISP) [ISP-HEADER01]
LFXP10E-4FN388I (ISP) [ISP-HEADER01]
LFXP10E-5F256C (ISP) [ISP-HEADER01]
LFXP10E-5F256I (ISP) [ISP-HEADER01]
LFXP10E-5F388C (ISP) [ISP-HEADER01]
LFXP10E-5F388I (ISP) [ISP-HEADER01]
LFXP10E-5FN256C (ISP) [ISP-HEADER01]
LFXP10E-5FN256I (ISP) [ISP-HEADER01]
LFXP10E-5FN388C (ISP) [ISP-HEADER01]
LFXP10E-5FN388I (ISP) [ISP-HEADER01]
LFXP15C-3F256C (ISP) [ISP-HEADER01]
LFXP15C-3F256I (ISP) [ISP-HEADER01]
LFXP15C-3F388C (ISP) [ISP-HEADER01]
LFXP15C-3F388I (ISP) [ISP-HEADER01]
LFXP15C-3F484C (ISP) [ISP-HEADER01]
LFXP15C-3F484I (ISP) [ISP-HEADER01]
LFXP15C-3FN256C (ISP) [ISP-HEADER01]
LFXP15C-3FN256I (ISP) [ISP-HEADER01]
LFXP15C-3FN388C (ISP) [ISP-HEADER01]
LFXP15C-3FN388I (ISP) [ISP-HEADER01]
LFXP15C-3FN484C (ISP) [ISP-HEADER01]
LFXP15C-3FN484I (ISP) [ISP-HEADER01]
LFXP15C-4F256C (ISP) [ISP-HEADER01]
LFXP15C-4F256I (ISP) [ISP-HEADER01]
LFXP15C-4F388C (ISP) [ISP-HEADER01]

LFXP15C-4F388I (ISP) [ISP-HEADER01]
LFXP15C-4F484C (ISP) [ISP-HEADER01]
LFXP15C-4F484I (ISP) [ISP-HEADER01]
LFXP15C-4FN256C (ISP) [ISP-HEADER01]
LFXP15C-4FN256I (ISP) [ISP-HEADER01]
LFXP15C-4FN388C (ISP) [ISP-HEADER01]
LFXP15C-4FN388I (ISP) [ISP-HEADER01]
LFXP15C-4FN484C (ISP) [ISP-HEADER01]
LFXP15C-4FN484I (ISP) [ISP-HEADER01]
LFXP15C-5F256C (ISP) [ISP-HEADER01]
LFXP15C-5F256I (ISP) [ISP-HEADER01]
LFXP15C-5F388C (ISP) [ISP-HEADER01]
LFXP15C-5F388I (ISP) [ISP-HEADER01]
LFXP15C-5F484C (ISP) [ISP-HEADER01]
LFXP15C-5F484I (ISP) [ISP-HEADER01]
LFXP15C-5FN256C (ISP) [ISP-HEADER01]
LFXP15C-5FN256I (ISP) [ISP-HEADER01]
LFXP15C-5FN388C (ISP) [ISP-HEADER01]
LFXP15C-5FN388I (ISP) [ISP-HEADER01]
LFXP15C-5FN484C (ISP) [ISP-HEADER01]
LFXP15C-5FN484I (ISP) [ISP-HEADER01]
LFXP15E-3F256C (ISP) [ISP-HEADER01]
LFXP15E-3F256I (ISP) [ISP-HEADER01]
LFXP15E-3F388C (ISP) [ISP-HEADER01]
LFXP15E-3F388I (ISP) [ISP-HEADER01]
LFXP15E-3F484C (ISP) [ISP-HEADER01]
LFXP15E-3F484I (ISP) [ISP-HEADER01]
LFXP15E-3FN256C (ISP) [ISP-HEADER01]
LFXP15E-3FN256I (ISP) [ISP-HEADER01]
LFXP15E-3FN388C (ISP) [ISP-HEADER01]
LFXP15E-3FN388I (ISP) [ISP-HEADER01]
LFXP15E-3FN484C (ISP) [ISP-HEADER01]
LFXP15E-3FN484I (ISP) [ISP-HEADER01]
LFXP15E-4F256C (ISP) [ISP-HEADER01]
LFXP15E-4F256I (ISP) [ISP-HEADER01]
LFXP15E-4F388C (ISP) [ISP-HEADER01]
LFXP15E-4F388I (ISP) [ISP-HEADER01]
LFXP15E-4F484C (ISP) [ISP-HEADER01]
LFXP15E-4F484I (ISP) [ISP-HEADER01]
LFXP15E-4FN256C (ISP) [ISP-HEADER01]
LFXP15E-4FN256I (ISP) [ISP-HEADER01]
LFXP15E-4FN388C (ISP) [ISP-HEADER01]
LFXP15E-4FN388I (ISP) [ISP-HEADER01]

LFXP15E-4FN484C (ISP) [ISP-HEADER01]
LFXP15E-4FN484I (ISP) [ISP-HEADER01]
LFXP15E-5F256C (ISP) [ISP-HEADER01]
LFXP15E-5F256I (ISP) [ISP-HEADER01]
LFXP15E-5F388C (ISP) [ISP-HEADER01]
LFXP15E-5F388I (ISP) [ISP-HEADER01]
LFXP15E-5F484C (ISP) [ISP-HEADER01]
LFXP15E-5F484I (ISP) [ISP-HEADER01]
LFXP15E-5FN256C (ISP) [ISP-HEADER01]
LFXP15E-5FN256I (ISP) [ISP-HEADER01]
LFXP15E-5FN388C (ISP) [ISP-HEADER01]
LFXP15E-5FN388I (ISP) [ISP-HEADER01]
LFXP15E-5FN484C (ISP) [ISP-HEADER01]
LFXP15E-5FN484I (ISP) [ISP-HEADER01]
LFXP20C-3F256C (ISP) [ISP-HEADER01]
LFXP20C-3F256I (ISP) [ISP-HEADER01]
LFXP20C-3F388C (ISP) [ISP-HEADER01]
LFXP20C-3F388I (ISP) [ISP-HEADER01]
LFXP20C-3F484C (ISP) [ISP-HEADER01]
LFXP20C-3F484I (ISP) [ISP-HEADER01]
LFXP20C-3FN256C (ISP) [ISP-HEADER01]
LFXP20C-3FN256I (ISP) [ISP-HEADER01]
LFXP20C-3FN388C (ISP) [ISP-HEADER01]
LFXP20C-3FN388I (ISP) [ISP-HEADER01]
LFXP20C-3FN484C (ISP) [ISP-HEADER01]
LFXP20C-3FN484I (ISP) [ISP-HEADER01]
LFXP20C-4F256C (ISP) [ISP-HEADER01]
LFXP20C-4F256I (ISP) [ISP-HEADER01]
LFXP20C-4F388C (ISP) [ISP-HEADER01]
LFXP20C-4F388I (ISP) [ISP-HEADER01]
LFXP20C-4F484C (ISP) [ISP-HEADER01]
LFXP20C-4F484I (ISP) [ISP-HEADER01]
LFXP20C-4FN256C (ISP) [ISP-HEADER01]
LFXP20C-4FN256I (ISP) [ISP-HEADER01]
LFXP20C-4FN388C (ISP) [ISP-HEADER01]
LFXP20C-4FN388I (ISP) [ISP-HEADER01]
LFXP20C-4FN484C (ISP) [ISP-HEADER01]
LFXP20C-4FN484I (ISP) [ISP-HEADER01]
LFXP20C-5F256C (ISP) [ISP-HEADER01]
LFXP20C-5F256I (ISP) [ISP-HEADER01]
LFXP20C-5F388C (ISP) [ISP-HEADER01]
LFXP20C-5F388I (ISP) [ISP-HEADER01]
LFXP20C-5F484C (ISP) [ISP-HEADER01]

LFXP20C-5F484I (ISP) [ISP-HEADER01]
LFXP20C-5FN256C (ISP) [ISP-HEADER01]
LFXP20C-5FN256I (ISP) [ISP-HEADER01]
LFXP20C-5FN388C (ISP) [ISP-HEADER01]
LFXP20C-5FN388I (ISP) [ISP-HEADER01]
LFXP20C-5FN484C (ISP) [ISP-HEADER01]
LFXP20C-5FN484I (ISP) [ISP-HEADER01]
LFXP20E-3F256C (ISP) [ISP-HEADER01]
LFXP20E-3F256I (ISP) [ISP-HEADER01]
LFXP20E-3F388C (ISP) [ISP-HEADER01]
LFXP20E-3F388I (ISP) [ISP-HEADER01]
LFXP20E-3F484C (ISP) [ISP-HEADER01]
LFXP20E-3F484I (ISP) [ISP-HEADER01]
LFXP20E-3FN256C (ISP) [ISP-HEADER01]
LFXP20E-3FN256I (ISP) [ISP-HEADER01]
LFXP20E-3FN388C (ISP) [ISP-HEADER01]
LFXP20E-3FN388I (ISP) [ISP-HEADER01]
LFXP20E-3FN484C (ISP) [ISP-HEADER01]
LFXP20E-3FN484I (ISP) [ISP-HEADER01]
LFXP20E-4F256C (ISP) [ISP-HEADER01]
LFXP20E-4F256I (ISP) [ISP-HEADER01]
LFXP20E-4F388C (ISP) [ISP-HEADER01]
LFXP20E-4F388I (ISP) [ISP-HEADER01]
LFXP20E-4F484C (ISP) [ISP-HEADER01]
LFXP20E-4F484I (ISP) [ISP-HEADER01]
LFXP20E-4FN256C (ISP) [ISP-HEADER01]
LFXP20E-4FN256I (ISP) [ISP-HEADER01]
LFXP20E-4FN388C (ISP) [ISP-HEADER01]
LFXP20E-4FN388I (ISP) [ISP-HEADER01]
LFXP20E-4FN484C (ISP) [ISP-HEADER01]
LFXP20E-4FN484I (ISP) [ISP-HEADER01]
LFXP20E-5F256C (ISP) [ISP-HEADER01]
LFXP20E-5F256I (ISP) [ISP-HEADER01]
LFXP20E-5F388C (ISP) [ISP-HEADER01]
LFXP20E-5F388I (ISP) [ISP-HEADER01]
LFXP20E-5F484C (ISP) [ISP-HEADER01]
LFXP20E-5F484I (ISP) [ISP-HEADER01]
LFXP20E-5FN256C (ISP) [ISP-HEADER01]
LFXP20E-5FN256I (ISP) [ISP-HEADER01]
LFXP20E-5FN388C (ISP) [ISP-HEADER01]
LFXP20E-5FN388I (ISP) [ISP-HEADER01]
LFXP20E-5FN484C (ISP) [ISP-HEADER01]
LFXP20E-5FN484I (ISP) [ISP-HEADER01]

LFXP3C-3Q208C(ISP) [ISP-HEADER01]
LFXP3C-3Q208I(ISP) [ISP-HEADER01]
LFXP3C-3QN208C(ISP) [ISP-HEADER01]
LFXP3C-3QN208I(ISP) [ISP-HEADER01]
LFXP3C-3T100C(ISP) [ISP-HEADER01]
LFXP3C-3T100I(ISP) [ISP-HEADER01]
LFXP3C-3T144C(ISP) [ISP-HEADER01]
LFXP3C-3T144I(ISP) [ISP-HEADER01]
LFXP3C-3TN100C(ISP) [ISP-HEADER01]
LFXP3C-3TN100I(ISP) [ISP-HEADER01]
LFXP3C-3TN144C(ISP) [ISP-HEADER01]
LFXP3C-3TN144I(ISP) [ISP-HEADER01]
LFXP3C-4Q208C(ISP) [ISP-HEADER01]
LFXP3C-4Q208I(ISP) [ISP-HEADER01]
LFXP3C-4QN208C(ISP) [ISP-HEADER01]
LFXP3C-4QN208I(ISP) [ISP-HEADER01]
LFXP3C-4T100C(ISP) [ISP-HEADER01]
LFXP3C-4T100I(ISP) [ISP-HEADER01]
LFXP3C-4T144C(ISP) [ISP-HEADER01]
LFXP3C-4T144I(ISP) [ISP-HEADER01]
LFXP3C-4TN100C(ISP) [ISP-HEADER01]
LFXP3C-4TN100I(ISP) [ISP-HEADER01]
LFXP3C-4TN144C(ISP) [ISP-HEADER01]
LFXP3C-4TN144I(ISP) [ISP-HEADER01]
LFXP3C-5Q208C(ISP) [ISP-HEADER01]
LFXP3C-5Q208I(ISP) [ISP-HEADER01]
LFXP3C-5QN208C(ISP) [ISP-HEADER01]
LFXP3C-5QN208I(ISP) [ISP-HEADER01]
LFXP3C-5T100C(ISP) [ISP-HEADER01]
LFXP3C-5T100I(ISP) [ISP-HEADER01]
LFXP3C-5T144C(ISP) [ISP-HEADER01]
LFXP3C-5T144I(ISP) [ISP-HEADER01]
LFXP3C-5TN100C(ISP) [ISP-HEADER01]
LFXP3C-5TN100I(ISP) [ISP-HEADER01]
LFXP3C-5TN144C(ISP) [ISP-HEADER01]
LFXP3C-5TN144I(ISP) [ISP-HEADER01]
LFXP3E-3Q208C(ISP) [ISP-HEADER01]
LFXP3E-3Q208I(ISP) [ISP-HEADER01]
LFXP3E-3QN208C(ISP) [ISP-HEADER01]
LFXP3E-3QN208I(ISP) [ISP-HEADER01]
LFXP3E-3T100C(ISP) [ISP-HEADER01]
LFXP3E-3T100I(ISP) [ISP-HEADER01]
LFXP3E-3T144C(ISP) [ISP-HEADER01]

LFXP3E-3T144I (ISP) [ISP-HEADER01]
LFXP3E-3TN100C (ISP) [ISP-HEADER01]
LFXP3E-3TN100I (ISP) [ISP-HEADER01]
LFXP3E-3TN144C (ISP) [ISP-HEADER01]
LFXP3E-3TN144I (ISP) [ISP-HEADER01]
LFXP3E-4Q208C (ISP) [ISP-HEADER01]
LFXP3E-4Q208I (ISP) [ISP-HEADER01]
LFXP3E-4QN208C (ISP) [ISP-HEADER01]
LFXP3E-4QN208I (ISP) [ISP-HEADER01]
LFXP3E-4T100C (ISP) [ISP-HEADER01]
LFXP3E-4T100I (ISP) [ISP-HEADER01]
LFXP3E-4T144C (ISP) [ISP-HEADER01]
LFXP3E-4T144I (ISP) [ISP-HEADER01]
LFXP3E-4TN100C (ISP) [ISP-HEADER01]
LFXP3E-4TN100I (ISP) [ISP-HEADER01]
LFXP3E-4TN144C (ISP) [ISP-HEADER01]
LFXP3E-4TN144I (ISP) [ISP-HEADER01]
LFXP3E-5Q208C (ISP) [ISP-HEADER01]
LFXP3E-5Q208I (ISP) [ISP-HEADER01]
LFXP3E-5QN208C (ISP) [ISP-HEADER01]
LFXP3E-5QN208I (ISP) [ISP-HEADER01]
LFXP3E-5T100C (ISP) [ISP-HEADER01]
LFXP3E-5T100I (ISP) [ISP-HEADER01]
LFXP3E-5T144C (ISP) [ISP-HEADER01]
LFXP3E-5T144I (ISP) [ISP-HEADER01]
LFXP3E-5TN100C (ISP) [ISP-HEADER01]
LFXP3E-5TN100I (ISP) [ISP-HEADER01]
LFXP3E-5TN144C (ISP) [ISP-HEADER01]
LFXP3E-5TN144I (ISP) [ISP-HEADER01]
LFXP6C-3F256C (ISP) [ISP-HEADER01]
LFXP6C-3F256I (ISP) [ISP-HEADER01]
LFXP6C-3FN256C (ISP) [ISP-HEADER01]
LFXP6C-3FN256I (ISP) [ISP-HEADER01]
LFXP6C-3Q208C (ISP) [ISP-HEADER01]
LFXP6C-3Q208I (ISP) [ISP-HEADER01]
LFXP6C-3QN208C (ISP) [ISP-HEADER01]
LFXP6C-3QN208I (ISP) [ISP-HEADER01]
LFXP6C-3T144C (ISP) [ISP-HEADER01]
LFXP6C-3T144I (ISP) [ISP-HEADER01]
LFXP6C-3TN144C (ISP) [ISP-HEADER01]
LFXP6C-3TN144I (ISP) [ISP-HEADER01]
LFXP6C-4F256C (ISP) [ISP-HEADER01]
LFXP6C-4F256I (ISP) [ISP-HEADER01]

LFXP6C-4FN256C(ISP) [ISP-HEADER01]
LFXP6C-4FN256I(ISP) [ISP-HEADER01]
LFXP6C-4Q208C(ISP) [ISP-HEADER01]
LFXP6C-4Q208I(ISP) [ISP-HEADER01]
LFXP6C-4QN208C(ISP) [ISP-HEADER01]
LFXP6C-4QN208I(ISP) [ISP-HEADER01]
LFXP6C-4T144C(ISP) [ISP-HEADER01]
LFXP6C-4T144I(ISP) [ISP-HEADER01]
LFXP6C-4TN144C(ISP) [ISP-HEADER01]
LFXP6C-4TN144I(ISP) [ISP-HEADER01]
LFXP6C-5F256C(ISP) [ISP-HEADER01]
LFXP6C-5F256I(ISP) [ISP-HEADER01]
LFXP6C-5FN256C(ISP) [ISP-HEADER01]
LFXP6C-5FN256I(ISP) [ISP-HEADER01]
LFXP6C-5Q208C(ISP) [ISP-HEADER01]
LFXP6C-5Q208I(ISP) [ISP-HEADER01]
LFXP6C-5QN208C(ISP) [ISP-HEADER01]
LFXP6C-5QN208I(ISP) [ISP-HEADER01]
LFXP6C-5T144C(ISP) [ISP-HEADER01]
LFXP6C-5T144I(ISP) [ISP-HEADER01]
LFXP6C-5TN144C(ISP) [ISP-HEADER01]
LFXP6C-5TN144I(ISP) [ISP-HEADER01]
LFXP6E-3F256C(ISP) [ISP-HEADER01]
LFXP6E-3F256I(ISP) [ISP-HEADER01]
LFXP6E-3FN256C(ISP) [ISP-HEADER01]
LFXP6E-3FN256I(ISP) [ISP-HEADER01]
LFXP6E-3Q208C(ISP) [ISP-HEADER01]
LFXP6E-3Q208I(ISP) [ISP-HEADER01]
LFXP6E-3QN208C(ISP) [ISP-HEADER01]
LFXP6E-3QN208I(ISP) [ISP-HEADER01]
LFXP6E-3T144C(ISP) [ISP-HEADER01]
LFXP6E-3T144I(ISP) [ISP-HEADER01]
LFXP6E-3TN144C(ISP) [ISP-HEADER01]
LFXP6E-3TN144I(ISP) [ISP-HEADER01]
LFXP6E-4F256C(ISP) [ISP-HEADER01]
LFXP6E-4F256I(ISP) [ISP-HEADER01]
LFXP6E-4FN256C(ISP) [ISP-HEADER01]
LFXP6E-4FN256I(ISP) [ISP-HEADER01]
LFXP6E-4Q208C(ISP) [ISP-HEADER01]
LFXP6E-4Q208I(ISP) [ISP-HEADER01]
LFXP6E-4QN208C(ISP) [ISP-HEADER01]
LFXP6E-4QN208I(ISP) [ISP-HEADER01]
LFXP6E-4T144C(ISP) [ISP-HEADER01]

LFXP6E-4T144I (ISP) [ISP-HEADER01]
 LFXP6E-4TN144C (ISP) [ISP-HEADER01]
 LFXP6E-4TN144I (ISP) [ISP-HEADER01]
 LFXP6E-5F256C (ISP) [ISP-HEADER01]
 LFXP6E-5F256I (ISP) [ISP-HEADER01]
 LFXP6E-5FN256C (ISP) [ISP-HEADER01]
 LFXP6E-5FN256I (ISP) [ISP-HEADER01]
 LFXP6E-5Q208C (ISP) [ISP-HEADER01]
 LFXP6E-5Q208I (ISP) [ISP-HEADER01]
 LFXP6E-5QN208C (ISP) [ISP-HEADER01]
 LFXP6E-5QN208I (ISP) [ISP-HEADER01]
 LFXP6E-5T144C (ISP) [ISP-HEADER01]
 LFXP6E-5T144I (ISP) [ISP-HEADER01]
 LFXP6E-5TN144C (ISP) [ISP-HEADER01]
 LFXP6E-5TN144I (ISP) [ISP-HEADER01]

LG Semicon

DRAM & SRAM

GM76C256CL [(SA430T)]	GM76C256CL@SSOP28
GM76C256CL@TSOP28 [(SA630)]	
GM76C256CLL GM76C256CLL@SSOP28 [(SA430T)] [(SA630)]	GM76C256CLL@TSOP28
GM76C8128CL [(SA438T)]	GM76C8128CL@SSOP32
GM76C8128CL@TSOP32 [(SA410T)] [(SA620)]	GM76C8128CL@VSOP32
GM76C8128CLL [(SA438T)]	GM76C8128CLL@SSOP32
GM76C8128CLL@TSOP32 [(SA410T)] [(SA620)]	GM76C8128CLL@VSOP32
GM76C88AL [(SA430T)]	GM76C88AL@SSOP28
GM76C88AL@TSOP28 [(SA643)]	
GM76U256CL GM76U256CL@SSOP28 [(SA430T)] [(SA643)]	GM76U256CL@TSOP28
GM76U256CLL [(SA430T)]	GM76U256CLL@SSOP28

GM76U256CLL@TSOP28 [(SA643)]	
GM76U8128CL	
GM76U8128CL@SSOP32 [(SA438T)]	GM76U8128CL@TSOP32
[(SA410T)]	
GM76U8128CL@VSOP32 [(SA620)]	
GM76U8128CLL	
GM76U8128CLL@SSOP32 [(SA438T)]	GM76U8128CLL@TSOP32
[(SA410T)]	
GM76U8128CLL@VSOP32 [(SA620)]	
GM76U8128DL	
GM76U8128DL@SSOP32 [(SA438T)]	GM76U8128DL@TSOP32
[(SA410T)]	
GM76U8128DL@VSOP32 [(SA620)]	
GM76U8128DLL	
GM76U8128DLL@SSOP32 [(SA438T)]	GM76U8128DLL@TSOP32
[(SA410T)]	
GM76U8128DLL@VSOP32 [(SA620)]	
GM76U8512L	
GM76U8512L@SSOP32 [(SA438T)]	GM76U8512L@TSOP32
[(SA410T)]	
GM76U8512L@VSOP32 [(SA620)]	
GM76U8512LL	
GM76U8512LL@SSOP32 [(SA438T)]	GM76U8512LL@TSOP32
[(SA410T)]	
GM76U8512LL@VSOP32 [(SA620)]	
GM76V256CL	
GM76V256CL@SSOP28 [(SA430T)]	GM76V256CL@TSOP28
[(SA630)]	
GM76V256CLL	GM76V256CLL@SSOP28
[(SA430T)]	
GM76V256CLL@TSOP28 [(SA630)]	
GM76V8128CL	
GM76V8128CL@SSOP32 [(SA438T)]	GM76V8128CL@TSOP32
[(SA410T)]	
GM76V8128CL@VSOP32 [(SA620)]	
GM76V8128CLL	
GM76V8128CLL@SSOP32 [(SA438T)]	GM76V8128CLL@TSOP32
[(SA410T)]	
GM76V8128CLL@VSOP32 [(SA620)]	
GM76V8128DL	
GM76V8128DL@SSOP32 [(SA438T)]	GM76V8128DL@TSOP32
[(SA410T)]	
GM76V8128DL@VSOP32 [(SA620)]	

GM76V8128DLL	
GM76V8128DLL@SSOP32 [(SA438T)]	GM76V8128DLL@TSOP32
[(SA410T)]	
GM76V8128DLL@VSOP32 [(SA620)]	
GM76V8512L	
GM76V8512L@SSOP32 [(SA438T)]	GM76V8512L@TSOP32
[(SA410T)]	
GM76V8512L@VSOP32 [(SA620)]	
GM76V8512LL	
GM76V8512LL@SSOP32 [(SA438T)]	GM76V8512LL@TSOP32
[(SA410T)]	
GM76V8512LL@VSOP32 [(SA620)]	
GM77C8128A	
GM77C8128A@SSOP32 [(SA438T)]	GM77C8128A@TSOP32
[(SA410T)]	
GM77C8128A@VSOP32 [(SA620)]	

MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20
[(SA404)]	
GMS97C2051	GMS97C2051@SOIC20
[(SA404)]	
GMS97C51	GMS97C51@PLCC44
[(SA244)]	
GMS97C51@TQFP44 [(SA245A)]	
GMS97C52	
GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44
[(SA245A)]	
GMS97C54	GMS97C54@PLCC44
[(SA244)]	
GMS97C54@TQFP44 [(SA245A)]	
GMS97C56	
GMS97C56@PLCC44 [(SA244)]	GMS97C56@TQFP44
[(SA245A)]	
GMS97C58	GMS97C58@PLCC44
[(SA244)]	
GMS97C58@TQFP44 [(SA245A)]	
GMS97L1051	
GMS97L1051@SOIC20 [(SA404)]	
GMS97L2051	
GMS97L2051@SOIC20 [(SA404)]	

GMS97L51	
GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44
[(SA245A)]	
GMS97L52	GMS97L52@PLCC44
[(SA244)]	
GMS97L52@TQFP44 [(SA245A)]	
GMS97L54	
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44
[(SA245A)]	
GMS97L56	GMS97L56@PLCC44
[(SA244)]	
GMS97L56@TQFP44 [(SA245A)]	
GMS97L58	
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44
[(SA245A)]	
GMS99C52	GMS99C52@PLCC44
[(SA244)]	
GMS99C52@TQFP44 [(SA245A)]	
GMS99C58	
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44
[(SA245A)]	

LINKSMART

E (E) PROM/FRAM/NVRAM

L24C02	L24C02@SSOP8
[(SA602A)]	
L24C02@TSOP8 [(SA026)]	
L24C04	
L24C04@SSOP8 [(SA602A)]	L24C04@TSOP8
[(SA026)]	
L29004C	L29004C@PLCC32
[(SA015A1T)]	
L29004C@TSOP32 [(SA620)]	L29S160F@TSOP48 [(SA247-
B005)]	
L29S160F-B@TSOP48 [(SA247-B005)]	L29S400F@PSOP44
[(SA638)]	
L29S400F@TSOP48 [(SA247-B005)]	L29S400F-B@PSOP44
[(SA638)]	
L29S400F-B@TSOP48 [(SA247-B005)]	L29S800F@TSOP48 [(SA247-
B005)]	

L29S800F-B@TSOP48 [(SA247-B005)]	L29W800E@TSOP48 [(SA247-B005)]
L29W800E-B@TSOP48 [(SA247-B005)]	
LST28001	
LST28001@PLCC32 [(SA015A1T)]	LST28001@TSOP32
[(SA620)]	
LST28002	LST28002@PLCC32
[(SA015A1T)]	
LST28002@TSOP32 [(SA620)]	
LST28004	
LST28004@PLCC32 [(SA015A1T)]	LST28004@TSOP32
[(SA620)]	

MACRONIX

E (E) PROM/FRAM/NVRAM

KH25L1005	KH25L1005 (ISP) [ISP-
HEADER01]	
KH25L1005@SON8 [(SA683)]	
KH25L1005@SON8 (ISP) [ISP-HEADER01]	
KH25L1005@SOP8 [(SA602A)]	
KH25L1005@SOP8 (ISP) [ISP-HEADER01]	
KH25L1005A	KH25L1005A@SON8
[(SA683)]	
KH25L1005A@SOP8 [(SA602A)]	
KH25L12805D@SON8 (Fast Mode) [(SA684)]	
KH25L12805D@SOP16 (Fast Mode) [(SA404)]	
KH25L12805N@SOP16 [(SA404)]	
KH25L12805N@SOP16 (Fast Mode) [(SA404)]	
KH25L1602@SOP28 [(SA630)]	KH25L1605@SON8
[(SA684)]	
KH25L1605@SON8 (Fast Mode) [(SA684)]	
KH25L1605@SOP16 [(SA404)]	
KH25L1605@SOP16 (Fast Mode) [(SA404)]	
KH25L1605A@SON8 [(SA684)]	
KH25L1605A@SON8 (Fast Mode) [(SA684)]	
KH25L1605A@SOP16 [(SA404)]	
KH25L1605A@SOP16 (Fast Mode) [(SA404)]	
KH25L1605A@SOP8 [(SA023A)]	
KH25L1605A@SOP8 (Fast Mode) [(SA023A)]	
KH25L1605D@SON8 [(SA684)]	

KH25L1605D@SON8(Fast Mode) [(SA683)]
 KH25L1605D@SOP16 [(SA404)]
 KH25L1605D@SOP16(Fast Mode) [(SA404)]
 KH25L1605D@SOP8(150)(Fast Mode) [(SA602A)]
 KH25L1605D@SOP8(200)(Fast Mode) [(SA605B)]
 KH25L1636DM1I@SOP8 [(SA602A)] KH25L1636DM2I@SOP8
 [(SA605B)]
 KH25L1636DMI@SOP16 [(SA404)] KH25L1636DZNI@WSON8
 [(SA683)]
 KH25L2005 KH25L2005(ISP) [ISP-
 HEADER01]
 KH25L2005@SON8 [(SA683)]
 KH25L2005@SON8(ISP) [ISP-HEADER01]
 KH25L2005@SOP8 [(SA602A)]
 KH25L2005@SOP8(ISP) [ISP-HEADER01]
 KH25L2025 KH25L2025@SON8
 [(SA683)]
 KH25L2025@SOP8 [(SA602A)] KH25L3202@SOP32
 [(SA438T)]
 KH25L3205@SOP16 [(SA404)]
 KH25L3205@SOP16(Fast Mode) [(SA404)]
 KH25L3205@SOP8 [(SA023A)]
 KH25L3205@SOP8(Fast Mode) [(SA023A)]
 KH25L3205A@SON8 [(SA684)]
 KH25L3205A@SON8(Fast Mode) [(SA684)]
 KH25L3205A@SOP16 [(SA404)]
 KH25L3205A@SOP16(Fast Mode) [(SA404)]
 KH25L3205A@SOP8 [(SA023A)]
 KH25L3205A@SOP8(Fast Mode) [(SA023A)]
 KH25L3205D@SON8(Fast Mode) [(SA683)]
 KH25L3205D@SOP16 [(SA404)]
 KH25L3205D@SOP16(Fast Mode) [(SA404)]
 KH25L3205D@SOP8 [(SA023A)]
 KH25L3205D@SOP8(Fast Mode) [(SA605B)]
 KH25L3236DM2I@SOP8 [(SA605B)] KH25L3236DMI@SOP16
 [(SA404)]
 KH25L3236DZNI@WSON8 [(SA683)]
 KH25L4005
 KH25L4005(150mil)@SOP8 [(SA602A)]
 KH25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]
 KH25L4005(209mil)@SOP8 [(SA023A)]
 KH25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]
 KH25L4005(ISP) [ISP-HEADER01] KH25L4005@SON8

[(SA683)]
KH25L4005@SON8 (ISP) [ISP-HEADER01]
KH25L4005A
KH25L4005A(150mil)@SOP8 [(SA602A)]
KH25L4005A(150mil)@SOP8 (ISP) [ISP-HEADER01]
KH25L4005A(209mil)@SOP8 [(SA023A)]
KH25L4005A(209mil)@SOP8 (ISP) [ISP-HEADER01]
KH25L4005A (ISP) [ISP-HEADER01] KH25L4005A@SON8
[(SA683)]
KH25L4005A@SON8 (ISP) [ISP-HEADER01]
KH25L4025A
KH25L4025A(150mil)@SOP8 [(SA602A)]
KH25L4025A(209mil)@SOP8 [(SA023A)]
KH25L4025A@SON8 [(SA683)] KH25L512@SON8
[(SA683)]
KH25L512@SOP8 [(SA602A)]
KH25L512A
KH25L512A@SON8 [(SA683)] KH25L512A@SOP8
[(SA602A)]
KH25L6402@SOP32 [(SA438T)] KH25L6402A@SOP28
[(SA630)]
KH25L6405@SOP16 [(SA404)]
KH25L6405@SOP16 (Fast Mode) [(SA404)]
KH25L6405@SOP8 [(SA023A)]
KH25L6405@SOP8 (Fast Mode) [(SA023A)]
KH25L6405D@SON8 (Fast Mode) [(SA684)]
KH25L6405D@SOP16 [(SA404)]
KH25L6405D@SOP16 (Fast Mode) [(SA404)]
KH25L6405D@SOP8 [(SA023A)]
KH25L8005
KH25L8005(150mil)@SOP8 [(SA602A)]
KH25L8005(150mil)@SOP8 (ISP) [ISP-HEADER01]
KH25L8005(209mil)@SOP8 [(SA023A)]
KH25L8005(209mil)@SOP8 (ISP) [ISP-HEADER01]
KH25L8005 (ISP) [ISP-HEADER01] KH25L8005@SON8
[(SA683)]
KH25L8005@SON8 (ISP) [ISP-HEADER01]
KH25L802@SOP28 [(SA630)]
KH25L8025
KH25L8025(150mil)@SOP8 [(SA602A)]
KH25L8025(209mil)@SOP8 [(SA023A)]
KH25L8025@SON8 [(SA683)]
KH25L8036D

KH25L8036D@SOP16 [(SA404)]
 KH25L8036D@SOP8[150 mil] [(SA602A)]
 KH25L8036D@SOP8[200 mil] [(SA023A)]
 KH25L8036D@WSON8 [(SA683)] KH29LV004CB@PLCC32
 [(SA015A1T)]
 KH29LV004CB@TSOP40 [(SA409T)] KH29LV004CT@PLCC32
 [(SA015A1T)]
 KH29LV004CT@TSOP40 [(SA409T)] KH29LV008CB@TSOP40
 [(SA409T)]
 KH29LV008CT@TSOP40 [(SA409T)]
 KH29LV040C
 KH29LV040C@PLCC32 [(SA015A1T)]
 MX25L1005
 MX25L1005(ISP) [ISP-HEADER01] MX25L1005@SON8
 [(SA683)]
 MX25L1005@SON8(ISP) [ISP-HEADER01]
 MX25L1005@SOP8 [(SA602A)]
 MX25L1005@SOP8(ISP) [ISP-HEADER01]
 MX25L1005A MX25L1005A@SON8
 [(SA683)]
 MX25L1005A@SOP8 [(SA602A)]
 MX25L12805D@SON8(Fast Mode) [(SA684)]
 MX25L12805D@SOP16(Fast Mode) [(SA404)]
 MX25L12805N@SOP16 [(SA404)]
 MX25L12805N@SOP16(Fast Mode) [(SA404)]
 MX25L1602@SOP28 [(SA630)] MX25L1605@SON8
 [(SA684)]
 MX25L1605@SON8(Fast Mode) [(SA684)]
 MX25L1605@SOP16 [(SA404)]
 MX25L1605@SOP16(Fast Mode) [(SA404)]
 MX25L1605A@SON8 [(SA684)]
 MX25L1605A@SON8(Fast Mode) [(SA684)]
 MX25L1605A@SOP16 [(SA404)]
 MX25L1605A@SOP16(Fast Mode) [(SA404)]
 MX25L1605A@SOP8 [(SA023A)]
 MX25L1605A@SOP8(Fast Mode) [(SA023A)]
 MX25L1605D@SON8 [(SA684)]
 MX25L1605D@SON8(Fast Mode) [(SA683)]
 MX25L1605D@SOP16 [(SA404)]
 MX25L1605D@SOP16(Fast Mode) [(SA404)]
 MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]
 MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]
 MX25L1615D@SOP16 [(SA404)] MX25L1615D@SOP8

[(SA023A)]	
MX25L1635DM1I@SOP8 [(SA602A)]	MX25L1635DM2I@SOP8
[(SA605B)]	
MX25L1635DMI@SOP16 [(SA404)]	MX25L1635DZNI@WSON8
[(SA683)]	
MX25L1636DM1I@SOP8 [(SA602A)]	MX25L1636DM2I@SOP8
[(SA605B)]	
MX25L1636DMI@SOP16 [(SA404)]	MX25L1636DZNI@WSON8
[(SA683)]	
MX25L2005	MX25L2005 (ISP) [ISP-
HEADER01]	
MX25L2005@SON8 [(SA683)]	
MX25L2005@SON8 (ISP) [ISP-HEADER01]	
MX25L2005@SOP8 [(SA602A)]	
MX25L2005@SOP8 (ISP) [ISP-HEADER01]	
MX25L2025	MX25L2025@SON8
[(SA683)]	
MX25L2025@SOP8 [(SA602A)]	MX25L3202@SOP32
[(SA438T)]	
MX25L3205@SOP16 [(SA404)]	
MX25L3205@SOP16 (Fast Mode) [(SA404)]	
MX25L3205@SOP8 [(SA023A)]	
MX25L3205@SOP8 (Fast Mode) [(SA023A)]	
MX25L3205A@SON8 [(SA684)]	
MX25L3205A@SON8 (Fast Mode) [(SA684)]	
MX25L3205A@SOP16 [(SA404)]	
MX25L3205A@SOP16 (Fast Mode) [(SA404)]	
MX25L3205A@SOP16 (Parallel Mode) [(SA404)]	
MX25L3205A@SOP8 [(SA023A)]	
MX25L3205A@SOP8 (Fast Mode) [(SA023A)]	
MX25L3205D@SON8 (Fast Mode) [(SA683)]	
MX25L3205D@SOP16 [(SA404)]	
MX25L3205D@SOP16 (Fast Mode) [(SA404)]	
MX25L3205D@SOP8 [(SA023A)]	
MX25L3205D@SOP8 (Fast Mode) [(SA605B)]	
MX25L3215D@SOP16 [(SA404)]	MX25L3215D@SOP8
[(SA023A)]	
MX25L3235DM2I@SOP8 [(SA605B)]	MX25L3235DMI@SOP16
[(SA404)]	
MX25L3235DZNI@WSON8 [(SA683)]	MX25L3236DM2I@SOP8
[(SA605B)]	
MX25L3236DMI@SOP16 [(SA404)]	MX25L3236DZNI@WSON8
[(SA683)]	

MX25L3237D@SOP16 [(SA404)] MX25L3237D@WSON8
 [(SA683)]
 MX25L4005
 MX25L4005(150mil)@SOP8 [(SA602A)]
 MX25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L4005(209mil)@SOP8 [(SA023A)]
 MX25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L4005(ISP) [ISP-HEADER01] MX25L4005@SON8
 [(SA683)]
 MX25L4005@SON8(ISP) [ISP-HEADER01]
 MX25L4005A
 MX25L4005A(150mil)@SOP8 [(SA602A)]
 MX25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L4005A(209mil)@SOP8 [(SA023A)]
 MX25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L4005A(ISP) [ISP-HEADER01] MX25L4005A@SON8
 [(SA683)]
 MX25L4005A@SON8(ISP) [ISP-HEADER01]
 MX25L4025A
 MX25L4025A(150mil)@SOP8 [(SA602A)]
 MX25L4025A(209mil)@SOP8 [(SA023A)]
 MX25L4025A@SON8 [(SA683)] MX25L512@SON8
 [(SA683)]
 MX25L512@SOP8 [(SA602A)]
 MX25L512A
 MX25L512A@SON8 [(SA683)] MX25L512A@SOP8
 [(SA602A)]
 MX25L6402@SOP32 [(SA438T)] MX25L6402A@SOP28
 [(SA630)]
 MX25L6405@SOP16 [(SA404)]
 MX25L6405@SOP16(Fast Mode) [(SA404)]
 MX25L6405@SOP8 [(SA023A)]
 MX25L6405@SOP8(Fast Mode) [(SA023A)]
 MX25L6405D@SON8(Fast Mode) [(SA684)]
 MX25L6405D@SOP16 [(SA404)]
 MX25L6405D@SOP16(Fast Mode) [(SA404)]
 MX25L6405D@SOP8 [(SA023A)] MX25L6415D@SOP16
 [(SA404)]
 MX25L6415D@SOP8 [(SA023A)] MX25L6445E@SOP16
 [(SA404)]
 MX25L6445E@SOP8 [(SA023A)] MX25L6445E@WSON8
 [(SA684)]
 MX25L6455E@SOP16 [(SA404)]

MX25L8005
 MX25L8005(150mil)@SOP8 [(SA602A)]
 MX25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L8005(209mil)@SOP8 [(SA023A)]
 MX25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L8005(ISP) [ISP-HEADER01] MX25L8005@SON8
 [(SA683)]
 MX25L8005@SON8(ISP) [ISP-HEADER01]
 MX25L802@SOP28 [(SA630)]
 MX25L8025
 MX25L8025(150mil)@SOP8 [(SA602A)]
 MX25L8025(209mil)@SOP8 [(SA023A)]
 MX25L8025@SON8 [(SA683)]
 MX25L8036D
 MX25L8036D@SOP16 [(SA602A)]
 MX25L8036D@SOP8[150 mil] [(SA602A)]
 MX25L8036D@SOP8[200 mil] [(SA023A)]
 MX25L8036D@WSON8 [(SA683)] MX25U1635@SOIC8
 [(SA602A)]
 MX25U1635@USON8(4*4mm) [(SA744)] MX25U1635@USON8(6*5mm)
 [(SA683)]
 MX25U4035@SOIC8 [(SA602A)] MX25U4035@USON8(4*4mm)
 [(SA744)]
 MX25U4035@USON8(6*5mm) [(SA683)] MX25U8035@SOIC8
 [(SA602A)]
 MX25U8035@USON8(4*4mm) [(SA744)] MX25U8035@USON8(6*5mm)
 [(SA683)]
 MX25V512@USON8 [(SA724)]
 MX26C1000B
 MX26C1000B@PLCC32 [(SA015A1T)] MX26C1000B@SOIC32
 [(SA603)]
 MX26C1000B@TSOP32 [(SA410T)]
 MX26C2000B
 MX26C2000B@PLCC32 [(SA015A1T)] MX26C2000B@SOIC32
 [(SA603)]
 MX26C2000B@TSOP32 [(SA410T)]
 MX26C512A
 MX26C512A@PLCC32 [(SA015A1T)] MX26C512A@SOIC28
 [(SA630)]
 MX26C512A@TSOP28 [(SA430T)] MX26LV004B@PLCC32
 [(SA015A1T)]
 MX26LV004B@TSOP40 [(SA409T)] MX26LV004T@PLCC32
 [(SA015A1T)]

MX26LV004T@TSOP40 [(SA409T)]	MX26LV008B@TSOP40
[(SA409T)]	
MX26LV008T@TSOP40 [(SA409T)]	
MX26LV040(QC)@PLCC32 [(SA015A1T)]	
MX26LV040(TC)@TSOP32 [(SA410T)]	
MX27C1000	
MX27C1000@PLCC32 [(SA015A1T)]	MX27C1000@SOIC32
[(SA603)]	
MX27C1000@TSOP32 [(SA410T)]	
MX27C1000A	
MX27C1000A@PLCC32 [(SA015A1T)]	MX27C1000A@SOIC32
[(SA603)]	
MX27C1000A@TSOP32 [(SA410T)]	
MX27C1001	
MX27C1001@PLCC32 [(SA015A1T)]	MX27C1001@SOIC32
[(SA603)]	
MX27C1001@TSOP32 [(SA410T)]	
MX27C1024	
MX27C1024@PLCC44 [(SA244)]	MX27C1024@TSOP40
[(SA409T)]	
MX27C1024A	MX27C1024A@PLCC44
[(SA244)]	
MX27C1024A@TSOP40 [(SA409T)]	
MX27C1024B	
MX27C1024B@PLCC44 [(SA244)]	MX27C1024B@TSOP40
[(SA409T)]	
MX27C1100	
MX27C2000	
MX27C2000@PLCC32 [(SA015A1T)]	MX27C2000@SOIC32
[(SA603)]	
MX27C2000@TSOP32 [(SA410T)]	
MX27C2000A	
MX27C2000A@PLCC32 [(SA015A1T)]	MX27C2000A@SOIC32
[(SA603)]	
MX27C2000A@TSOP32 [(SA410T)]	
MX27C2048	
MX27C2048@PLCC44 [(SA244)]	MX27C2048@TSOP40
[(SA409T)]	
MX27C2100	
MX27C256	
MX27C256@PLCC32 [(SA015A1T)]	
MX27C4000	
MX27C4000@PLCC32 [(SA015A1T)]	MX27C4000@SOIC32

[(SA603)]	
MX27C4000@TSOP32 [(SA410T)]	
MX27C4000A	
MX27C4000A@PLCC32 [(SA015A1T)]	MX27C4000A@SOIC32
[(SA603)]	
MX27C4000A@TSOP32 [(SA410T)]	
MX27C4096	
MX27C4096@PLCC44 [(SA244)]	
MX27C4100	
MX27C4111	
MX27C512	
MX27C512@PLCC32 [(SA015A1T)]	
MX27C516	
MX27C516@PLCC44 [(SA244)]	MX27C516@TSOP40
[(SA409T)]	
MX27C8000	MX27C8000@PLCC32
[(SA015A1T)]	
MX27C8000@SOIC32 [(SA603)]	MX27C8000@TSOP32
[(SA410T)]	
MX27C8000A	MX27C8000A@PLCC32
[(SA015A1T)]	
MX27C8000A@SOIC32 [(SA603)]	MX27C8000A@TSOP32
[(SA410T)]	
MX27C8100	MX27C8100@PSOP44
[(SA638)]	
MX27C8111	MX27C8111@PSOP44
[(SA638)]	
MX27L1000	MX27L1000@PLCC32
[(SA015A1T)]	
MX27L1000@TSOP32 [(SA410T)]	
MX27L2000	
MX27L2000@PLCC32 [(SA015A1T)]	MX27L2000@TSOP32
[(SA410T)]	
MX27L256	MX27L256@PLCC32
[(SA015A1T)]	
MX27L256@TSOP32 [(SA430T)]	
MX27L4000	
MX27L4000@PLCC32 [(SA015A1T)]	MX27L4000@TSOP32
[(SA410T)]	
MX27L4096	MX27L4096@PLCC44
[(SA244)]	
MX27L512	MX27L512@PLCC32
[(SA015A1T)]	

MX27L512@TSOP28 [(SA430T)]	MX28F002B@TSOP40
[(SA409T)]	
MX28F002T@TSOP40 [(SA409T)]	
MX28F1000	
MX28F1000@PLCC32 [(SA015A1T)]	MX28F1000@SOP32
[(SA603)]	
MX28F1000@TSOP32 [(SA410T)]	
MX28F1000P	
MX28F1000P@PLCC32 [(SA015A1T)]	MX28F1000P@TSOP32
[(SA410T)]	
MX28F2000	
[(SA015A1T)]	MX28F2000@PLCC32
MX28F2000@TSOP32 [(SA410T)]	
MX28F2000P	
MX28F2000P@PLCC32 [(SA015A1T)]	MX28F2000P@TSOP32
[(SA410T)]	
MX28F2100B@PSOP44 [(SA638)]	MX28F2100B@TSOP48 [(SA247-
B005)]	
MX28F2100T@PSOP44 [(SA638)]	MX28F2100T@TSOP48 [(SA247-
B005)]	
MX28F4000	
[(SA015A1T)]	MX28F4000@PLCC32
MX28F4000@TSOP32 [(SA410T)]	
MX29F001B	
MX29F001B@PLCC32 [(SA015A1T)]	MX29F001B@TSOP32
[(SA410T)]	
MX29F001T	MX29F001T@PLCC32
[(SA015A1T)]	
MX29F001T@TSOP32 [(SA410T)]	
MX29F002B	
MX29F002B@PLCC32 [(SA015A1T)]	MX29F002B@TSOP32
[(SA410T)]	
MX29F002NB	MX29F002NB@PLCC32
[(SA015A1T)]	
MX29F002NB@TSOP32 [(SA410T)]	
MX29F002NT	
MX29F002NT@PLCC32 [(SA015A1T)]	MX29F002NT@TSOP32
[(SA410T)]	
MX29F002T	MX29F002T@PLCC32
[(SA015A1T)]	
MX29F002T@TSOP32 [(SA410T)]	
MX29F004B	
MX29F004B@PLCC32 [(SA015A1T)]	MX29F004B@TSOP32

[(SA410T)]	
MX29F004T	MX29F004T@PLCC32
[(SA015A1T)]	
MX29F004T@TSOP32 [(SA410T)]	MX29F016@PSOP44
[(SA638)]	
MX29F016@TSOP40 [(SA409T)]	MX29F016@TSOP48 [(SA247-
B005)]	
MX29F022B	MX29F022B@PLCC32
[(SA015A1T)]	
MX29F022B@TSOP32 [(SA410T)]	
MX29F022NB	
MX29F022NB@PLCC32 [(SA015A1T)]	MX29F022NB@TSOP32
[(SA410T)]	
MX29F022NT	MX29F022NT@PLCC32
[(SA015A1T)]	
MX29F022NT@TSOP32 [(SA410T)]	
MX29F022T	
MX29F022T@PLCC32 [(SA015A1T)]	MX29F022T@TSOP32
[(SA410T)]	
MX29F040	MX29F040@PLCC32
[(SA015A1T)]	
MX29F040@TSOP32 [(SA410T)]	
MX29F040C	
MX29F040C@PLCC32 [(SA015A1T)]	MX29F040C@TSOP32
[(SA410T)]	
MX29F080@PSOP44 [(SA638)]	MX29F080@TSOP40
[(SA409T)]	
MX29F100B@PSOP44 [(SA638-B006)]	MX29F100B@TSOP48 [(SA247-
B005)]	
MX29F100T@PSOP44 [(SA638-B006)]	MX29F100T@TSOP48 [(SA247-
B005)]	
MX29F1610@PSOP44 [(SA638)]	MX29F1610@TSOP48 [(SA247-
B005)]	
MX29F1610A@PSOP44 [(SA638)]	MX29F1610A@TSOP48 [(SA247-
B005)]	
MX29F1610B@TSOP48 [(SA247-B005)]	MX29F1611@PSOP44
[(SA638)]	
MX29F1615	MX29F200B@PSOP44 [(SA638-
B006)]	
MX29F200B@TSOP48 [(SA247-B005)]	MX29F200CB@PSOP44
[(SA638)]	
MX29F200CB@TSOP48 [(SA247-B005)]	MX29F200CT@PSOP44
[(SA638)]	

MX29F200CT@TSOP48 [(SA247-B005)] B006]	MX29F200T@PSOP44 [(SA638-
MX29F200T@TSOP48 [(SA247-B005)]	
MX29F4000	
MX29F400B@PSOP44 [(SA638-B006)] B005]	MX29F400B@TSOP48 [(SA247-
MX29F400CB@PSOP44 [(SA638)] B005]	MX29F400CB@TSOP48 [(SA247-
MX29F400CT@PSOP44 [(SA638)] B005]	MX29F400CT@TSOP48 [(SA247-
MX29F400T@PSOP44 [(SA638-B006)] B005]	MX29F400T@TSOP48 [(SA247-
MX29F800B@PSOP44 [(SA638-B006)] B005]	MX29F800B@TSOP48 [(SA247-
MX29F800T@PSOP44 [(SA638-B006)] B005]	MX29F800T@TSOP48 [(SA247-
MX29L1611@PSOP44 [(SA638)] B005]	MX29L1611@TSOP48 [(SA247-
MX29L1611G [(SA638)]	MX29L3211@PSOP44
MX29L3211@TSOP48 [(SA247-B005)] [(SA015A1T)]	MX29LV004B@PLCC32
MX29LV004B@TSOP40 [(SA409T)] [(SA015A1T)]	MX29LV004CB@PLCC32
MX29LV004CB@TSOP40 [(SA409T)] [(SA015A1T)]	MX29LV004CT@PLCC32
MX29LV004CT@TSOP40 [(SA409T)] [(SA015A1T)]	MX29LV004T@PLCC32
MX29LV004T@TSOP40 [(SA409T)] [(SA409T)]	MX29LV008B@TSOP40
MX29LV008BB@TSOP40 [(SA409T)] [(SA409T)]	MX29LV008BT@TSOP40
MX29LV008CB@TSOP40 [(SA409T)] [(SA409T)]	MX29LV008CT@TSOP40
MX29LV008T@TSOP40 [(SA409T)] [(SA409T)]	MX29LV033T@TSOP40
MX29LV040@PLCC32 [(SA015A1T)] [(SA410T)]	MX29LV040@TSOP32
MX29LV040C@PLCC32 [(SA015A1T)] [(SA410T)]	MX29LV040C@TSOP32
MX29LV081@TSOP40 [(SA409T)]	

MICROCONTROLLER

MX10E8050I [(SA244)]	MX10E8050I@PLCC44
MX10E8050I@TQFP44 [(SA245A)] [(SA244)]	MX10EXA@PLCC44
MX10EXA@TQFP44 [(SA245A)]	
MX10FLCD	
MX10FMAXD [(SA244)]	MX10FMAXD@PLCC44
MX10FMAXD@TQFP44 [(SA245A)]	

MAXIM

E (E) PROM / FRAM / NVRAM

DS1220AB
DS1220AD
DS1220Y
DS1225AB
DS1225AD
DS1225D
DS1225E
DS1225Y
DS1230AB
DS1230W
DS1230Y
DS1235AB
DS1235Y
DS1243Y
DS1244
DS1244Y
DS1245AB
DS1245EE
DS1245P
DS1245W
DS1245Y
DS1248P
DS1248W
DS1248Y
DS1249AB
DS1249W

DS1249Y
DS1250AB
DS1250W
DS1250Y
DS1251AB
DS1251W
DS1251Y
DS1256P
DS1256W
DS1256Y
DS1258AB
DS1258W
DS1258Y
DS1265AB
DS1265W
DS1265Y
DS1270AB
DS1270W
DS1270Y
DS1284
DS1284N
DS1284Q@PLCC28
[(SA008A)]
DS1284QN@PLCC28 [(SA008A)]
DS1286
DS1286I
DS1287
DS1287A
DS12887
DS12887A
DS12C887
DS12C887A
DS1386
(32K)
DS1386 (8K)
DS1485
DS1485@SOIC28 [(SA630)]
DS1488
DS1553
DS1553W
DS1554
DS1554W
DS1556
DS1642
DS1643

DS1644	
DS1644P	
DS1645AB	
DS1645EE	
DS1645Y	
DS1646	
DS1647	
DS1647LPM	
DS1650AB	
DS1650Y	DS1687-
3	
DS1687-5	DS17287-
3	
DS17287-5	
DS1742	
DS1742W	
DS1743	
DS1743P	
DS1743W	
DS1743WP	
DS1744	
DS1744P	
DS1744W	
DS1744WP	
DS1746	
DS1747	
DS1747P	
DS1747W	
DS1747WP	
DS17487-3	DS17487-
5	
DS17887-3	DS17887-
5	
DS2430A@TO-92	DS2430AP@TSOC6
[(SA602A)]	
DS2431@TO-92	DS2431P@TSOC6
[(SA602A)]	
DS2432P@TSOC6 [(SA602A)]	DS2433@PR-
35	
DS2433S(3.9)@SOIC8 [(SA602A)]	DS2433S(5.5)@SOIC8
[(SA605A)]	
DS2502	DS2502P@TSOC6
[(SA602A)]	

DS2502S@SOIC8 [(SA602A)]	
DS2502UNW	
DS2502UNW@SOIC8 [(SA602A)]	DS2502UNW@TSOC6
[(SA602A)]	
DS2506	DS2506S@SOIC8
[(SA023A)]	
DS4510@uSOP10	DS4520@TSSOP16
[(SA026)]	
DS4550@TSSOP20 [(SA026)]	

MICROCONTROLLER

DS87C520	DS87C520@PLCC44
[(SA244)]	
DS87C520@TQFP44 [(SA245A)]	DS89C420 (rev.
A)	
DS89C420 (rev.A)@PLCC44 [(SA244)]	
DS89C420 (rev.A)@TQFP44 [(SA245A)]	

MAXWELL

E (E) PROM/FRAM/NVRAM

27C010T@LDFP32 [(SA438T)]	
28C010	
28C010@PLCC32 [(SA015A1T)]	28C010@TSOP32
[(SA438T)]	
28C010T	28C010T@PLCC32
[(SA015A1T)]	
28C010T@TSOP32 [(SA438T)]	
28C011	
28C011@PLCC32 [(SA015A1T)]	28C011@TSOP32
[(SA438T)]	
28C011T	28C011T@PLCC32
[(SA015A1T)]	
28C011T@TSOP32 [(SA438T)]	

MEGAWIN

E (E) PROM / FRAM / NVRAM

MM25SB512@SOIC8 [(SA602A)]	
MM29F040	
MM29F040@PLCC32 [(SA015A1T)]	MM29F040@TSOP32
[(SA410T)]	
MM29LF040	MM29LF040@PLCC32
[(SA015A1T)]	
MM29LF040@TSOP32 [(SA410T)]	

MICROCONTROLLER

MPC89L516X2	MPC89L516X2@PLCC44
[(SA244)]	
MPC89L516X2@TQFP44 [(SA245A)]	
MPC89L556X2	
MPC89L556X2@PLCC44 [(SA244)]	MPC89L556X2@TQFP44
[(SA245A)]	

MICON**MICROCONTROLLER**

MDT10P21(dip18)	MDT10P21
(dip20)	
MDT10P21(dip22)	MDT10P21@SOP18
[(SA404A)]	
MDT10P21@SOP20 [(SA404A)]	MDT10P21@SOP24
[(SA404A)]	
MDT10P22(dip18)	MDT10P22
(dip20)	
MDT10P22(dip22)	MDT10P22@SOP18
[(SA404A)]	
MDT10P22@SOP20 [(SA404A)]	MDT10P22@SOP24
[(SA404A)]	
MDT10P23(dip18)	MDT10P23
(dip20)	
MDT10P23(dip22)	MDT10P23@SOP18
[(SA404A)]	
MDT10P23@SOP20 [(SA404A)]	MDT10P23@SOP24
[(SA404A)]	

MDT10P61 [(SA404A)]	MDT10P61@SOP18
MDT10P61@SSOP20 [(SA626A)]	
MDT2005 MDT2005@SOP18 [(SA404A)] [(SA626A)]	MDT2005@SSOP20
MDT2010 [(SA404A)]	MDT2010@SOP18
MDT2010@SSOP20 [(SA626A)]	
MDT2020 MDT2020@SOP28 [(SA404A)] [(SA626A)]	MDT2020@SSOP28
MDT2030 [(SA404A)]	MDT2030@SOP18
MDT2030@SSOP20 [(SA626A)]	
MDT2050 MDT2050@SOP18 [(SA404A)] [(SA626A)]	MDT2050@SSOP20
MDT2051 [(SA404A)]	MDT2051@SOP18
MDT2051@SSOP20 [(SA626A)]	
MDT2060 MDT2060@SOP18 [(SA404A)] [(SA626A)]	MDT2060@SSOP20

MICROCHIP

E (E) PROM/FRAM/NVRAM

24AA00 [(SA602A)]	24AA00@SOIC8
24AA00@SOT-23 [(SA717)] [(SA026)]	24AA00@TSSOP8
24AA01 [(SA602A)]	24AA01@SOIC8
24AA01@TSSOP8 [(SA026)]	
24AA014 24AA014@SOIC8 [(SA602A)] [(SA026)]	24AA014@TSSOP8
24AA02 [(SA694)]	24AA02@DFN8
24AA02@MSOP8 [(SA666)]	24AA02@SOIC8

[(SA602A)]	
24AA02@SOT-23-5 [(SA717)]	24AA02@TSSOP8
[(SA026)]	
24AA024	24AA024@DFN8
[(SA694)]	
24AA024@MSOP8 [(SA666)]	24AA024@SOIC8
[(SA602A)]	
24AA024@TSSOP8 [(SA026)]	
24AA025	
24AA025@DFN8 [(SA694)]	24AA025@MSOP8
[(SA666)]	
24AA025@SOIC8 [(SA602A)]	24AA025@TSSOP8
[(SA026)]	
24AA04	24AA04@SOIC8
[(SA602A)]	
24AA04@TSSOP8 [(SA026)]	
24AA08	
24AA08@SOIC8 [(SA602A)]	24AA08@TSSOP8
[(SA026)]	
24AA1025	24AA1025@SOIC8
[(SA602A)]	
24AA1025@TSSOP8 [(SA026)]	
24AA128	
24AA128@MSOP8 [(SA666)]	24AA128@SOIC8
[(SA602A)]	
24AA128@TSSOP14 [(SA026)]	24AA128@TSSOP8
[(SA026)]	
24AA16	24AA16@SOIC8
[(SA602A)]	
24AA16@TSSOP8 [(SA026)]	
24AA164	
24AA164@SOIC8 [(SA602A)]	24AA164@TSSOP8
[(SA026)]	
24AA174	24AA174@SOIC8
[(SA602A)]	
24AA174@TSSOP8 [(SA026)]	
24AA256	
24AA256@MSOP8 [(SA666)]	24AA256@SOIC8
[(SA605A)]	
24AA256@TSSOP14 [(SA026)]	24AA256@TSSOP8
[(SA026)]	
24AA32	24AA32 (Rotated)@TSSOP8
[(SA026)]	

24AA32@MSOP8 [(SA666)]	24AA32@SOIC8
[(SA602A)]	
24AA32@TSSOP8 [(SA026)]	
24AA32A	
24AA32A(Rotated)@TSSOP8 [(SA026)]	
24AA32A@MSOP8 [(SA666)]	24AA32A@SOIC8
[(SA602A)]	
24AA32A@TSSOP8 [(SA026)]	
24AA512	
24AA512@DFN8 [(SA683)]	24AA512@SOIC8
[(SA605A)]	
24AA512@TSSOP14 [(SA602)]	
24AA515	
24AA515@SOIC8 [(SA605A)]	
24AA52	
24AA52@DFN8 [(SA694)]	24AA52@MSOP8
[(SA666)]	
24AA52@SOIC8 [(SA602A)]	24AA52@TSSOP8
[(SA026)]	
24AA64	24AA64(Rotated)@TSSOP8
[(SA026)]	
24AA64@MSOP8 [(SA666)]	24AA64@SOIC8
[(SA602A)]	
24AA64@TSSOP8 [(SA026)]	
24AA65	
24AA65@SOIC8 [(SA602A)]	24AA65@TSSOP8
[(SA026)]	
24C00	24C00@SOIC8
[(SA602A)]	
24C00@SOT-23 [(SA717)]	24C00@TSSOP8
[(SA026)]	
24C01	
24C01A	
24C01A@SOIC8 [(SA602A)]	
24C01C	
24C01C@SOIC8 [(SA602A)]	24C01C@TSSOP8
[(SA026)]	
24C02	
24C02A	
24C02A@SOIC8 [(SA602A)]	
24C02C	
24C02C@SOIC8 [(SA602A)]	24C02C@TSSOP8
[(SA026)]	

24C04	
24C04A	
24C04A@SOIC8 [(SA602A)]	24C04A@TSSOP8
[(SA026)]	
24C08	24C08@SOIC8
[(SA602A)]	
24C08B	24C08B@SOIC8
[(SA602A)]	
24C16	24C16@SOIC8
[(SA602A)]	
24C16B	24C16B@SOIC8
[(SA602A)]	
24C32	24C32@SOIC8
[(SA602A)]	
24C64	24C64@SOIC8
[(SA602A)]	
24C64@TSSOP8 [(SA026)]	
24C65	
24C65@SOIC8 [(SA602A)]	
24FC1025	
24FC1025@SOIC8 [(SA602A)]	24FC1025@TSSOP8
[(SA026)]	
24FC128	24FC128@MSOP8
[(SA666)]	
24FC128@SOIC8 [(SA602A)]	24FC128@TSSOP14
[(SA026)]	
24FC128@TSSOP8 [(SA026)]	
24FC256	
24FC256@MSOP8 [(SA666)]	24FC256@SOIC8
[(SA605A)]	
24FC256@TSSOP14 [(SA026)]	24FC256@TSSOP8
[(SA026)]	
24FC32	24FC32@SOIC8
[(SA602A)]	
24FC512	24FC512@DFN8
[(SA683)]	
24FC512@SOIC8 [(SA605A)]	24FC512@TSSOP14
[(SA602)]	
24FC515	24FC515@SOIC8
[(SA605A)]	
24FC65	24FC65@SOIC8
[(SA605A)]	
24LC00	24LC00@SOIC8

[(SA602A)]	
24LC00@SOT-23 [(SA717)]	24LC00@TSSOP8
[(SA026)]	
24LC01	
24LC014	
24LC014@SOIC8 [(SA602A)]	24LC014@TSSOP8
[(SA026)]	
24LC01B	24LC01B@SOIC8
[(SA602A)]	
24LC01B@TSSOP8 [(SA026)]	
24LC02	
24LC024	24LC024@SOIC8
[(SA602A)]	
24LC024@TSSOP8 [(SA026)]	
24LC025	
24LC025@SOIC8 [(SA602A)]	24LC025@TSSOP8
[(SA026)]	
24LC02B	24LC02B@DFN8
[(SA694)]	
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8
[(SA602A)]	
24LC02B@SOT-23-5 [(SA717)]	24LC02B@TSSOP8
[(SA026)]	
24LC04	
24LC04B	
24LC04B@SOIC8 [(SA602A)]	24LC04B@TSSOP8
[(SA026)]	
24LC08	
24LC08B	
24LC08B@SOIC8 [(SA602A)]	24LC08B@TSSOP8
[(SA026)]	
24LC1025	24LC1025@SOIC8
[(SA602A)]	
24LC1025@TSSOP8 [(SA026)]	
24LC128	
24LC128@MSOP8 [(SA666)]	24LC128@SOIC8
[(SA605A)]	
24LC128@TSSOP14 [(SA026)]	24LC128@TSSOP8
[(SA026)]	
24LC16	24LC16@MSOP8
[(SA605A)]	
24LC16@SOIC8 [(SA602A)]	
24LC164	

24LC164@SOIC8 [(SA602A)]	
24LC16B	
24LC16B@SOIC8 [(SA602A)]	24LC16B@TSSOP8
[(SA026)]	
24LC174	
[(SA602A)]	24LC174@SOIC8
24LC21	
[(SA602A)]	24LC21@SOIC8
24LC21A	
[(SA602A)]	24LC21A@SOIC8
24LC22A	
[(SA602A)]	24LC22A@SOIC8
24LC256	
[(SA666)]	24LC256@MSOP8
24LC256@SOIC8 [(SA605A)]	
[(SA026)]	24LC256@TSSOP14
24LC256@TSSOP8 [(SA026)]	
24LC32	
24LC32@SOIC8 [(SA602A)]	
24LC32A	
24LC32A@SOIC8 [(SA602A)]	24LC32A@TSSOP8
[(SA026)]	
24LC512	
[(SA683)]	24LC512@DFN8
24LC512@SOIC8 [(SA605A)]	
[(SA602)]	24LC512@TSSOP14
24LC515	
[(SA605A)]	24LC515@SOIC8
24LC64	
[(SA026)]	24LC64 (Rotated)@TSSOP8
24LC64@MSOP8 [(SA605A)]	
[(SA602A)]	24LC64@SOIC8
24LC64@TSSOP8 [(SA026)]	
24LC65	
24LC65@SOIC8 [(SA602A)]	
24LCS21	
24LCS21@SOIC8 [(SA602A)]	
24LCS21A	
24LCS21A@SOIC8 [(SA602A)]	
24LCS22	
24LCS22@SOIC8 [(SA602A)]	
24LCS22A	
24LCS22A@SOIC8 [(SA602A)]	

24LCS52	
24LCS52@DFN8 [(SA694)]	24LCS52@MSOP8
[(SA666)]	
24LCS52@SOIC8 [(SA602A)]	24LCS52@TSSOP8
[(SA026)]	
25AA010A	25AA010A@DFN8
[(SA683)]	
25AA010A@MSOP8 [(SA605A)]	25AA010A@SOIC8
[(SA602A)]	
25AA010A@SOT-23 [(SA698)]	25AA010A@TSSOP8
[(SA026)]	
25AA010A[X-Rotated]@TSSOP8 [(SA026)]	
25AA020A	25AA020A@DFN8
[(SA683)]	
25AA020A@MSOP8 [(SA605A)]	25AA020A@SOIC8
[(SA602A)]	
25AA020A@SOT-23 [(SA698)]	25AA020A@TSSOP8
[(SA026)]	
25AA020A[X-Rotated]@TSSOP8 [(SA026)]	
25AA040	25AA040@SOIC8
[(SA602A)]	
25AA040@TSSOP8 [(SA026)]	
25AA040A	
25AA040A@DFN8 [(SA683)]	25AA040A@MSOP8
[(SA605A)]	
25AA040A@SOIC8 [(SA602A)]	25AA040A@SOT-23
[(SA698)]	
25AA040A@TSSOP8 [(SA026)]	
25AA040A[X-Rotated]@TSSOP8 [(SA026)]	
25AA080	25AA080@SOIC8
[(SA602A)]	
25AA080A	25AA080A@MSOP8
[(SA605A)]	
25AA080A@SOIC8 [(SA602A)]	25AA080A@TSSOP8
[(SA026)]	
25AA080B	25AA080B@MSOP8
[(SA605A)]	
25AA080B@SOIC8 [(SA602A)]	25AA080B@TSSOP8
[(SA026)]	
25AA1024	25AA1024@DFN8
[(SA683)]	
25AA1024@SOIC8 [(SA602A)]	25AA1024@SOIJ8
[(SA605)]	

25AA160 [(SA602A)]	25AA160@SOIC8
25AA160A [(SA605A)]	25AA160A@MSOP8
25AA160A@SOIC8 [(SA602A)] [(SA026)]	25AA160A@TSSOP8
25AA160B [(SA605A)]	25AA160B@MSOP8
25AA160B@SOIC8 [(SA602A)] [(SA026)]	25AA160B@TSSOP8
25AA256 [(SA683)]	25AA256@DFN8
25AA256@SOIC8(4.0) [(SA602A)] [(SA605A)]	25AA256@SOIC8(5.4)
25AA256@TSSOP8 [(SA026)]	
25AA256[X-Rotated]@TSSOP8 [(SA026)]	
25AA320 [(SA602A)]	25AA320@SOIC8
25AA320@TSSOP14 [(SA026)] [(SA026)]	25AA320@TSSOP8
25AA512 [(SA683)]	25AA512@DFN8
25AA512@SOIC8 [(SA602A)] [(SA605)]	25AA512@SOIJ8
25AA640 [(SA602A)]	25AA640@SOIC8
25AA640@TSSOP8 [(SA026)]	
25C040 25C040@SOIC8 [(SA602A)] [(SA026)]	25C040@TSSOP8
25C080 [(SA602A)]	25C080@SOIC8
25C160 [(SA602A)]	25C160@SOIC8
25C320 [(SA602A)]	25C320@SOIC8
25C320@TSSOP14 [(SA026)] [(SA026)]	25C320@TSSOP8
25C640 [(SA602A)]	25C640@SOIC8
25C640@TSSOP8 [(SA026)]	
25LC010A 25LC010A@DFN8 [(SA683)]	25LC010A@MSOP8

[(SA605A)]	
25LC010A@SOIC8 [(SA602A)]	25LC010A@SOT-23
[(SA698)]	
25LC010A@TSSOP8 [(SA026)]	
25LC010A[X-Rotated]@TSSOP8 [(SA026)]	
25LC020A	25LC020A@DFN8
[(SA683)]	
25LC020A@MSOP8 [(SA605A)]	25LC020A@SOIC8
[(SA602A)]	
25LC020A@SOT-23 [(SA698)]	25LC020A@TSSOP8
[(SA026)]	
25LC020A[X-Rotated]@TSSOP8 [(SA026)]	
25LC040	25LC040@SOIC8
[(SA602A)]	
25LC040@TSSOP8 [(SA026)]	
25LC040A	
25LC040A@DFN8 [(SA683)]	25LC040A@MSOP8
[(SA605A)]	
25LC040A@SOIC8 [(SA602A)]	25LC040A@SOT-23
[(SA698)]	
25LC040A@TSSOP8 [(SA026)]	
25LC040A[X-Rotated]@TSSOP8 [(SA026)]	
25LC080	25LC080@SOIC8
[(SA602A)]	
25LC080A	25LC080A@MSOP8
[(SA605A)]	
25LC080A@SOIC8 [(SA602A)]	25LC080A@TSSOP8
[(SA026)]	
25LC080B	25LC080B@MSOP8
[(SA605A)]	
25LC080B@SOIC8 [(SA602A)]	25LC080B@TSSOP8
[(SA026)]	
25LC1024	25LC1024@DFN8
[(SA683)]	
25LC1024@SOIC8 [(SA602A)]	25LC1024@SOIJ8
[(SA605)]	
25LC160	25LC160@SOIC8
[(SA602A)]	
25LC160A	25LC160A@MSOP8
[(SA605A)]	
25LC160A@SOIC8 [(SA602A)]	25LC160A@TSSOP8
[(SA026)]	
25LC160B	25LC160B@MSOP8

[(SA605A)]	
25LC160B@SOIC8 [(SA602A)]	25LC160B@TSSOP8
[(SA026)]	
25LC256	25LC256@DFN8
[(SA683)]	
25LC256@SOIC8(4.0) [(SA602A)]	25LC256@SOIC8(5.4)
[(SA605A)]	
25LC256@TSSOP8 [(SA026)]	
25LC256[X-Rotated]@TSSOP8 [(SA026)]	
25LC320	25LC320(SN)@SOIC8
[(SA602A)]	
25LC320@TSSOP14 [(SA026)]	25LC320@TSSOP8
[(SA026)]	
25LC512	25LC512@DFN8
[(SA683)]	
25LC512@SOIC8 [(SA602A)]	25LC512@SOIJ8
[(SA605)]	
25LC640	25LC640@SOIC8
[(SA602A)]	
25LC640@TSSOP8 [(SA026)]	
27256	
27256@PLCC32 [(SA015A1T)]	
27C128	
27C128@PLCC32 [(SA015A1T)]	
27C128A	
27C128A@PLCC32 [(SA015A1T)]	
27C256	
27C256@PLCC32 [(SA015A1T)]	
27C32A	
27C512	27C512@PLCC32
[(SA015A1T)]	
27C512A	27C512A@PLCC32
[(SA015A1T)]	
27C513	
27C64	
27C64@PLCC32 [(SA015A1T)]	27C64@SOIC28
[(SA404)]	
27HC1616	27HC1616@PLCC44
[(SA244)]	
27HC1616L	27HC1616L@PLCC44
[(SA244)]	
27HC191	27HC191@PLCC28
[(SA008A)]	

27HC191@SOIC24 [(SA404)]	
27HC256	
27HC256@PLCC32 [(SA015A1T)]	
27HC256L	
27HC256L@PLCC32 [(SA015A1T)]	
27HC291	
27HC291@PLCC28 [(SA008A)]	27HC291@SOIC24
[(SA404)]	
27HC416	
27HC64	
27HC64@PLCC32 [(SA015A1T)]	27HC64@SOIC28
[(SA404)]	
27HC641	27HC641@PLCC28
[(SA008A)]	
27HC641@SOIC24 [(SA404)]	
27HC641L	
27HC641L@PLCC28 [(SA008A)]	27HC641L@SOIC24
[(SA404)]	
27HC64L	27HC64L@PLCC32
[(SA015A1T)]	
27HC64L@SOIC28 [(SA404)]	
27LV256	
27LV256@PLCC32 [(SA015A1T)]	
27LV64	
2817	
2864	
2864@PLCC32 [(SA015A1T)]	
28C04	
28C04@PLCC32 [(SA015A1T)]	28C04@SOIC24
[(SA404)]	
28C04A	28C04A@PLCC32
[(SA015A1T)]	
28C04A@SOIC24 [(SA404)]	
28C04AF	
28C04AF@PLCC32 [(SA015A1T)]	28C04AF@SOIC24
[(SA404)]	
28C04F	28C04F@PLCC32
[(SA015A1T)]	
28C04F@SOIC24 [(SA404)]	
28C16	
28C16@PLCC32 [(SA015A1T)]	28C16@SOIC24
[(SA404)]	
28C16A	28C16A@PLCC32

[(SA015A1T)]	
28C16A@SOIC24 [(SA404)]	
28C16AF	
28C16AF@PLCC32 [(SA015A1T)]	28C16AF@SOIC24
[(SA404)]	
28C16F	28C16F@PLCC32
[(SA015A1T)]	
28C16F@SOIC24 [(SA404)]	
28C17	
28C17@PLCC32 [(SA015A1T)]	28C17@SOIC28
[(SA404)]	
28C17A	28C17A@PLCC32
[(SA015A1T)]	
28C17A@SOIC28 [(SA404)]	
28C17AF	
28C17AF@PLCC32 [(SA015A1T)]	28C17AF@SOIC28
[(SA404)]	
28C17F	28C17F@PLCC32
[(SA015A1T)]	
28C17F@SOIC28 [(SA404)]	
28C256	
28C256@PLCC32 [(SA015A1T)]	
28C256F	
28C256F@PLCC32 [(SA015A1T)]	
28C64A	
28C64A@PLCC32 [(SA015A1T)]	28C64A@SOIC28
[(SA404)]	
28C64A@TSOP32 [(SA410T)]	
28C64AF	
28C64AF@PLCC32 [(SA015A1T)]	28C64AF@SOIC28
[(SA404)]	
28LV64A	28LV64A@PLCC32
[(SA015A1T)]	
28LV64A@SOIC28 [(SA404)]	
28PC64	
28PC64@PLCC32 [(SA015A1T)]	
59C11	
59C11@SOIC8 [(SA602A)]	
85C72	
85C72@SOIC8 [(SA602A)]	
85C82	
85C82@SOIC8 [(SA602A)]	
85C92	

85C92@SOIC8 [(SA602A)] (08bit)	93AA46
93AA46(08bit)@SOIC8 [(SA602A)] (16bit)	93AA46
93AA46(16bit)@SOIC8 [(SA602A)] (08bit)	93AA46A
93AA46A(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA46A(08bit)@MSOP8
93AA46A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA46A(08bit)@SOT-23
93AA46A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA46B
93AA46B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA46B(16bit)@MSOP8
93AA46B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA46B(16bit)@SOT-23
93AA46B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA46C
93AA46C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA46C(08bit)@MSOP8
93AA46C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA46C(08bit)@TSSOP8
93AA46C(16bit) [(BBBB)]	93AA46C(16bit)@DFN8
93AA46C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA46C(16bit)@SOIC8
93AA46C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA56
93AA56(08bit)@SOIC8 [(SA602A)] (16bit)	93AA56
93AA56(16bit)@SOIC8 [(SA602A)] (08bit)	93AA56A
93AA56A(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA56A(08bit)@MSOP8
93AA56A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA56A(08bit)@SOT-23
93AA56A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA56B
93AA56B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA56B(16bit)@MSOP8
93AA56B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA56B(16bit)@SOT-23
93AA56B(16bit)@TSSOP8 [(SA026)]	93AA56C

(08bit)	
93AA56C(08bit)@DFN8 [(BBBB)]	93AA56C(08bit)@MSOP8
[(SA666)]	
93AA56C(08bit)@SOIC8 [(SA602A)]	93AA56C(08bit)@TSSOP8
[(SA026)]	
93AA56C(16bit)	93AA56C(16bit)@DFN8
[(BBBB)]	
93AA56C(16bit)@MSOP8 [(SA666)]	93AA56C(16bit)@SOIC8
[(SA602A)]	
93AA56C(16bit)@TSSOP8 [(SA026)]	93AA66
(08bit)	
93AA66(08bit)@SOIC8 [(SA602A)]	93AA66
(16bit)	
93AA66(16bit)@SOIC8 [(SA602A)]	93AA66A
(08bit)	
93AA66A(08bit)@DFN8 [(BBBB)]	93AA66A(08bit)@MSOP8
[(SA666)]	
93AA66A(08bit)@SOIC8 [(SA602A)]	93AA66A(08bit)@SOT-23
[(SA717)]	
93AA66A(08bit)@TSSOP8 [(SA026)]	93AA66B
(16bit)	
93AA66B(16bit)@DFN8 [(BBBB)]	93AA66B(16bit)@MSOP8
[(SA666)]	
93AA66B(16bit)@SOIC8 [(SA602A)]	93AA66B(16bit)@SOT-23
[(SA717)]	
93AA66B(16bit)@TSSOP8 [(SA026)]	93AA66C
(08bit)	
93AA66C(08bit)@DFN8 [(BBBB)]	93AA66C(08bit)@MSOP8
[(SA666)]	
93AA66C(08bit)@SOIC8 [(SA602A)]	93AA66C(08bit)@TSSOP8
[(SA026)]	
93AA66C(16bit)	93AA66C(16bit)@DFN8
[(BBBB)]	
93AA66C(16bit)@MSOP8 [(SA666)]	93AA66C(16bit)@SOIC8
[(SA602A)]	
93AA66C(16bit)@TSSOP8 [(SA026)]	93AA76
(08bit)	
93AA76(08bit)@SOIC8 [(SA602A)]	93AA76
(16bit)	
93AA76(16bit)@SOIC8 [(SA602A)]	93AA76A
(08bit)	
93AA76A(08bit)@DFN8 [(BBBB)]	93AA76A(08bit)@MSOP8
[(SA666)]	

93AA76A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA76A(08bit)@SOT-23
93AA76A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA76B
93AA76B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA76B(16bit)@MSOP8
93AA76B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA76B(16bit)@SOT-23
93AA76B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA76C
93AA76C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA76C(08bit)@MSOP8
93AA76C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA76C(08bit)@TSSOP8
93AA76C(16bit) [(BBBB)]	93AA76C(16bit)@DFN8
93AA76C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA76C(16bit)@SOIC8
93AA76C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA86
93AA86(08bit)@SOIC8 [(SA602A)] (16bit)	93AA86
93AA86(16bit)@SOIC8 [(SA602A)] (08bit)	93AA86A
93AA86A(08bit)@DFN8 [(BBBB)] [(SSA666)]	93AA86A(08bit)@MSOP8
93AA86A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA86A(08bit)@SOT-23
93AA86A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA86B
93AA86B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA86B(16bit)@MSOP8
93AA86B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA86B(16bit)@SOT-23
93AA86B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA86C
93AA86C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA86C(08bit)@MSOP8
93AA86C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA86C(08bit)@TSSOP8
93AA86C(16bit) [(BBBB)]	93AA86C(16bit)@DFN8
93AA86C(16bit)@MSOP8 [(SA666)]	93AA86C(16bit)@SOIC8

[(SA602A)]	
93AA86C(16bit)@TSSOP8 [(SA026)]	93C06
(08bit)	
93C06(08bit)@SOIC8 [(SA602A)]	93C06
(16bit)	
93C06(16bit)@SOIC8 [(SA602A)]	93C46
(08bit)	
93C46(08bit)@SOIC8 [(SA602A)]	93C46
(16bit)	
93C46(16bit)@SOIC8 [(SA602A)]	93C46A
(08bit)	
93C46A(08bit)@DFN8 [(BBBB)]	93C46A(08bit)@MSOP8
[(SA666)]	
93C46A(08bit)@SOIC8 [(SA602A)]	93C46A(08bit)@SOT-23
[(SA717)]	
93C46A(08bit)@TSSOP8 [(SA026)]	93C46B
(16bit)	
93C46B(16bit)@DFN8 [(BBBB)]	93C46B(16bit)@MSOP8
[(SA666)]	
93C46B(16bit)@SOIC8 [(SA602A)]	93C46B(16bit)@SOT-23
[(SA717)]	
93C46B(16bit)@TSSOP8 [(SA026)]	93C46C
(08bit)	
93C46C(08bit)@DFN8 [(BBBB)]	93C46C(08bit)@MSOP8
[(SA666)]	
93C46C(08bit)@SOIC8 [(SA602A)]	93C46C(08bit)@TSSOP8
[(SA026)]	
93C46C(16bit)	93C46C(16bit)@DFN8
[(BBBB)]	
93C46C(16bit)@MSOP8 [(SA666)]	93C46C(16bit)@SOIC8
[(SA602A)]	
93C46C(16bit)@TSSOP8 [(SA026)]	93C56
(08bit)	
93C56(08bit)@SOIC8 [(SA602A)]	93C56
(16bit)	
93C56(16bit)@SOIC8 [(SA602A)]	93C56A
(08bit)	
93C56A(08bit)@DFN8 [(BBBB)]	93C56A(08bit)@MSOP8
[(SA666)]	
93C56A(08bit)@SOIC8 [(SA602A)]	93C56A(08bit)@SOT-23
[(SA717)]	
93C56A(08bit)@TSSOP8 [(SA026)]	93C56B
(16bit)	

93C56B(16bit)@DFN8 [(BBBB)]	93C56B(16bit)@MSOP8
[(SA666)]	
93C56B(16bit)@SOIC8 [(SA602A)]	93C56B(16bit)@SOT-23
[(SA717)]	
93C56B(16bit)@TSSOP8 [(SA026)]	93C56C
(08bit)	
93C56C(08bit)@DFN8 [(BBBB)]	93C56C(08bit)@MSOP8
[(SA666)]	
93C56C(08bit)@SOIC8 [(SA602A)]	93C56C(08bit)@TSSOP8
[(SA026)]	
93C56C(16bit)	93C56C(16bit)@DFN8
[(BBBB)]	
93C56C(16bit)@MSOP8 [(SA666)]	93C56C(16bit)@SOIC8
[(SA602A)]	
93C56C(16bit)@TSSOP8 [(SA026)]	93C66
(08bit)	
93C66(08bit)@SOIC8 [(SA602A)]	93C66
(16bit)	
93C66(16bit)@SOIC8 [(SA602A)]	93C66A
(08bit)	
93C66A(08bit)@DFN8 [(BBBB)]	93C66A(08bit)@MSOP8
[(SA666)]	
93C66A(08bit)@SOIC8 [(SA602A)]	93C66A(08bit)@SOT-23
[(SA717)]	
93C66A(08bit)@TSSOP8 [(SA026)]	93C66B
(16bit)	
93C66B(16bit)@DFN8 [(BBBB)]	93C66B(16bit)@MSOP8
[(SA666)]	
93C66B(16bit)@SOIC8 [(SA602A)]	93C66B(16bit)@SOT-23
[(SA717)]	
93C66B(16bit)@TSSOP8 [(SA026)]	93C66C
(08bit)	
93C66C(08bit)@DFN8 [(BBBB)]	93C66C(08bit)@MSOP8
[(SA666)]	
93C66C(08bit)@SOIC8 [(SA602A)]	93C66C(08bit)@TSSOP8
[(SA026)]	
93C66C(16bit)	93C66C(16bit)@DFN8
[(BBBB)]	
93C66C(16bit)@MSOP8 [(SA666)]	93C66C(16bit)@SOIC8
[(SA602A)]	
93C66C(16bit)@TSSOP8 [(SA026)]	93C76
(08bit)	
93C76(08bit)@SOIC8 [(SA602A)]	93C76

(16bit)	
93C76(16bit)@SOIC8 [(SA602A)]	93C76A
(08bit)	
93C76A(08bit)@DFN8 [(BBBB)]	93C76A(08bit)@MSOP8
[(SA666)]	
93C76A(08bit)@SOIC8 [(SA602A)]	93C76A(08bit)@SOT-23
[(SA717)]	
93C76A(08bit)@TSSOP8 [(SA026)]	93C76B
(16bit)	
93C76B(16bit)@DFN8 [(BBBB)]	93C76B(16bit)@MSOP8
[(SA666)]	
93C76B(16bit)@SOIC8 [(SA602A)]	93C76B(16bit)@SOT-23
[(SA717)]	
93C76B(16bit)@TSSOP8 [(SA026)]	93C76C
(08bit)	
93C76C(08bit)@DFN8 [(BBBB)]	93C76C(08bit)@MSOP8
[(SA666)]	
93C76C(08bit)@SOIC8 [(SA602A)]	93C76C(08bit)@TSSOP8
[(SA026)]	
93C76C(16bit)	93C76C(16bit)@DFN8
[(BBBB)]	
93C76C(16bit)@MSOP8 [(SA666)]	93C76C(16bit)@SOIC8
[(SA602A)]	
93C76C(16bit)@TSSOP8 [(SA026)]	93C86
(08bit)	
93C86(08bit)@SOIC8 [(SA602A)]	93C86
(16bit)	
93C86(16bit)@SOIC8 [(SA602A)]	93C86A
(08bit)	
93C86A(08bit)@DFN8 [(BBBB)]	93C86A(08bit)@MSOP8
[(SSA666)]	
93C86A(08bit)@SOIC8 [(SA602A)]	93C86A(08bit)@SOT-23
[(SA717)]	
93C86A(08bit)@TSSOP8 [(SA026)]	93C86B
(16bit)	
93C86B(16bit)@DFN8 [(BBBB)]	93C86B(16bit)@MSOP8
[(SA666)]	
93C86B(16bit)@SOIC8 [(SA602A)]	93C86B(16bit)@SOT-23
[(SA717)]	
93C86B(16bit)@TSSOP8 [(SA026)]	93C86C
(08bit)	
93C86C(08bit)@DFN8 [(BBBB)]	93C86C(08bit)@MSOP8
[(SA666)]	

93C86C(08bit)@SOIC8 [(SA602A)]	93C86C(08bit)@TSSOP8
[(SA026)]	
93C86C(16bit)	93C86C(16bit)@DFN8
[(BBBB)]	
93C86C(16bit)@MSOP8 [(SA666)]	93C86C(16bit)@SOIC8
[(SA602A)]	
93C86C(16bit)@TSSOP8 [(SA026)]	93LC46
(08bit)	
93LC46(08bit)@SOIC8 [(SA602A)]	93LC46
(16bit)	
93LC46(16bit)@SOIC8 [(SA602A)]	93LC46A
(08bit)	
93LC46A(08bit)@DFN8 [(BBBB)]	93LC46A(08bit)@MSOP8
[(SA666)]	
93LC46A(08bit)@SOIC8 [(SA602A)]	93LC46A(08bit)@SOT-23
[(SA717)]	
93LC46A(08bit)@TSSOP8 [(SA026)]	93LC46B
(16bit)	
93LC46B(16bit)@DFN8 [(BBBB)]	93LC46B(16bit)@MSOP8
[(SA666)]	
93LC46B(16bit)@SOIC8 [(SA602A)]	93LC46B(16bit)@SOT-23
[(SA717)]	
93LC46B(16bit)@TSSOP8 [(SA026)]	
93LC46BX	
93LC46BX@SOIC8 [(SA602A)]	93LC46C
(08bit)	
93LC46C(08bit)@DFN8 [(BBBB)]	93LC46C(08bit)@MSOP8
[(SA666)]	
93LC46C(08bit)@SOIC8 [(SA602A)]	93LC46C(08bit)@TSSOP8
[(SA026)]	
93LC46C(16bit)	93LC46C(16bit)@DFN8
[(BBBB)]	
93LC46C(16bit)@MSOP8 [(SA666)]	93LC46C(16bit)@SOIC8
[(SA602A)]	
93LC46C(16bit)@TSSOP8 [(SA026)]	93LC56
(08bit)	
93LC56(08bit)@SOIC8 [(SA602A)]	93LC56
(16bit)	
93LC56(16bit)@SOIC8 [(SA602A)]	93LC56A
(08bit)	
93LC56A(08bit)@DFN8 [(BBBB)]	93LC56A(08bit)@MSOP8
[(SA666)]	
93LC56A(08bit)@SOIC8 [(SA602A)]	93LC56A(08bit)@SOT-23

[(SA717)]	
93LC56A(08bit)@TSSOP8 [(SA026)]	93LC56B
(16bit)	
93LC56B(16bit)@DFN8 [(BBBB)]	93LC56B(16bit)@MSOP8
[(SA666)]	
93LC56B(16bit)@SOIC8 [(SA602A)]	93LC56B(16bit)@SOT-23
[(SA717)]	
93LC56B(16bit)@TSSOP8 [(SA026)]	
93LC56BX	
93LC56BX@SOIC8 [(SA602A)]	93LC56C
(08bit)	
93LC56C(08bit)@DFN8 [(BBBB)]	93LC56C(08bit)@MSOP8
[(SA666)]	
93LC56C(08bit)@SOIC8 [(SA602A)]	93LC56C(08bit)@TSSOP8
[(SA026)]	
93LC56C(16bit)	93LC56C(16bit)@DFN8
[(BBBB)]	
93LC56C(16bit)@MSOP8 [(SA666)]	93LC56C(16bit)@SOIC8
[(SA602A)]	
93LC56C(16bit)@TSSOP8 [(SA026)]	93LC66
(08bit)	
93LC66(08bit)@SOIC8 [(SA602A)]	93LC66
(16bit)	
93LC66(16bit)@SOIC8 [(SA602A)]	93LC66A
(08bit)	
93LC66A(08bit)@DFN8 [(BBBB)]	93LC66A(08bit)@MSOP8
[(SA666)]	
93LC66A(08bit)@SOIC8 [(SA602A)]	93LC66A(08bit)@SOT-23
[(SA717)]	
93LC66A(08bit)@TSSOP8 [(SA026)]	93LC66B
(16bit)	
93LC66B(16bit)@DFN8 [(BBBB)]	93LC66B(16bit)@MSOP8
[(SA666)]	
93LC66B(16bit)@SOIC8 [(SA602A)]	93LC66B(16bit)@SOT-23
[(SA717)]	
93LC66B(16bit)@TSSOP8 [(SA026)]	
93LC66BX	
93LC66BX@SOIC8 [(SA602A)]	93LC66C
(08bit)	
93LC66C(08bit)@DFN8 [(BBBB)]	93LC66C(08bit)@MSOP8
[(SA666)]	
93LC66C(08bit)@SOIC8 [(SA602A)]	93LC66C(08bit)@TSSOP8
[(SA026)]	

93LC66C(16bit) [(BBBB)]	93LC66C(16bit)@DFN8
93LC66C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC66C(16bit)@SOIC8
93LC66C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC76
93LC76(08bit)@SOIC8 [(SA602A)] (16bit)	93LC76
93LC76(16bit)@SOIC8 [(SA602A)] (08bit)	93LC76A
93LC76A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC76A(08bit)@MSOP8
93LC76A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC76A(08bit)@SOT-23
93LC76A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC76B
93LC76B(16bit)@DFN8 [(BBBB)] [(SA666)]	93LC76B(16bit)@MSOP8
93LC76B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93LC76B(16bit)@SOT-23
93LC76B(16bit)@TSSOP8 [(SA026)] (08bit)	93LC76C
93LC76C(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC76C(08bit)@MSOP8
93LC76C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93LC76C(08bit)@TSSOP8
93LC76C(16bit) [(BBBB)]	93LC76C(16bit)@DFN8
93LC76C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC76C(16bit)@SOIC8
93LC76C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC86
93LC86(08bit)@SOIC8 [(SA602A)] (16bit)	93LC86
93LC86(16bit)@SOIC8 [(SA602A)] (08bit)	93LC86A
93LC86A(08bit)@DFN8 [(BBBB)] [(SSA666)]	93LC86A(08bit)@MSOP8
93LC86A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC86A(08bit)@SOT-23
93LC86A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC86B
93LC86B(16bit)@DFN8 [(BBBB)]	93LC86B(16bit)@MSOP8

[(SA666)]	
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23
[(SA717)]	
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C
(08bit)	
93LC86C(08bit)@DFN8 [(BBBB)]	93LC86C(08bit)@MSOP8
[(SA666)]	
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8
[(SA026)]	
93LC86C(16bit)	93LC86C(16bit)@DFN8
[(BBBB)]	
93LC86C(16bit)@MSOP8 [(SA666)]	93LC86C(16bit)@SOIC8
[(SA602A)]	
93LC86C(16bit)@TSSOP8 [(SA026)]	
93LCS46	
93LCS46@SOIC14 [(SA026)]	93LCS46@SOIC8
[(SA602A)]	
93LCS56	93LCS56@SOIC14
[(SA026)]	
93LCS56@SOIC8 [(SA602A)]	
93LCS66	
93LCS66@SOIC14 [(SA026)]	93LCS66@SOIC8
[(SA602A)]	
ER5911	ER5911@SOIC8
[(SA602A)]	
HCS101	HCS101SN@SOIC8
[(SA602A)]	
HCS200	HCS200SN@SOIC8
[(SA602A)]	
HCS300	HCS300SN@SOIC8
[(SA602A)]	
HCS301	HCS301SN@SOIC8
[(SA602A)]	
HCS320	HCS320SN@SOIC8
[(SA602A)]	
HCS360	HCS360SN@SOIC8
[(SA602A)]	
HCS361	HCS361SN@SOIC8
[(SA602A)]	

MICROCONTROLLER

```

MCP25020(150mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25020(208mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25020(ISP) [ISP-HEADER01]
MCP25025(150mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25025(208mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25025(ISP) [ISP-HEADER01]
MCP25050(150mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25050(208mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25050(ISP) [ISP-HEADER01]
MCP25055(150mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25055(208mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25055(ISP) [ISP-HEADER01]
PIC10F200
PIC10F200(ISP) [ISP-HEADER01]          PIC10F200@SOT6
[(SA717)]
PIC10F200@SOT6(ISP) [ISP-HEADER01]
PIC10F202          PIC10F202(ISP) [ISP-
HEADER01]
PIC10F202@SOT6 [(SA717)]
PIC10F202@SOT6(ISP) [ISP-HEADER01]
PIC10F204          PIC10F204(ISP) [ISP-
HEADER01]
PIC10F204@SOT6 [(SA717)]
PIC10F204@SOT6(ISP) [ISP-HEADER01]
PIC10F206          PIC10F206(ISP) [ISP-
HEADER01]
PIC10F206@SOT6 [(SA717)]
PIC10F206@SOT6(ISP) [ISP-HEADER01]
PIC10F220          PIC10F220(ISP) [ISP-
HEADER01]
PIC10F220@SOT6 [(SA717)]
PIC10F220@SOT6(ISP) [ISP-HEADER01]
PIC10F222          PIC10F222(ISP) [ISP-
HEADER01]
PIC10F222@SOT6 [(SA717)]
PIC10F222@SOT6(ISP) [ISP-HEADER01]
PIC12C508          PIC12C508(ISP) [ISP-
HEADER01]
PIC12C508@SOIC8 [(SA605A)]
PIC12C508@SOIC8(ISP) [ISP-HEADER01]
PIC12C508A          PIC12C508A(ISP) [ISP-
HEADER01]
PIC12C508A(SM)@SOIC8 [(SA605A)]

```

PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C508A(SN)@SOIC8 [(SA602A)]
PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509 PIC12C509(ISP) [ISP-
HEADER01]
PIC12C509(SM)@SOIC8 [(SA605A)]
PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509(SN)@SOIC8 [(SA602A)]
PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A PIC12C509A(ISP) [ISP-
HEADER01]
PIC12C509A(SM)@SOIC8 [(SA605A)]
PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A(SN)@SOIC8 [(SA602A)]
PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A@DFN8 [(SA683)]
PIC12C509A@DFN8(ISP) [ISP-HEADER01]
PIC12C671 PIC12C671(ISP) [ISP-
HEADER01]
PIC12C671@DFN8 [(SA683)]
PIC12C671@DFN8(ISP) [ISP-HEADER01]
PIC12C671@SOIC8 [(SA605A)]
PIC12C671@SOIC8(ISP) [ISP-HEADER01]
PIC12C672 PIC12C672(ISP) [ISP-
HEADER01]
PIC12C672@DFN8 [(SA683)]
PIC12C672@DFN8(ISP) [ISP-HEADER01]
PIC12C672@SOIC8 [(SA605A)]
PIC12C672@SOIC8(ISP) [ISP-HEADER01]
PIC12CE518 PIC12CE518(ISP) [ISP-
HEADER01]
PIC12CE518@SOIC8 [(SA605A)]
PIC12CE518@SOIC8(ISP) [ISP-HEADER01]
PIC12CE519 PIC12CE519(ISP) [ISP-
HEADER01]
PIC12CE519(SM)@SOIC8 [(SA605A)]
PIC12CE519(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12CE519(SN)@SOIC8 [(SA602A)]
PIC12CE519(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12CE673 PIC12CE673(ISP) [ISP-
HEADER01]
PIC12CE673@SOIC8 [(SA605A)]
PIC12CE673@SOIC8(ISP) [ISP-HEADER01]

```

PIC12CE674                                PIC12CE674(ISP) [ISP-
HEADER01]
PIC12CE674@SOIC8 [(SA605A)]
PIC12CE674@SOIC8(ISP) [ISP-HEADER01]
PIC12F508                                PIC12F508(ISP) [ISP-
HEADER01]
PIC12F508@MSOP8 [(SA666)]
PIC12F508@MSOP8(ISP) [ISP-HEADER01]
PIC12F508@SOIC8 [(SA602)]
PIC12F508@SOIC8(ISP) [ISP-HEADER01]
PIC12F509                                PIC12F509(ISP) [ISP-
HEADER01]
PIC12F509@MSOP8 [(SA666)]
PIC12F509@MSOP8(ISP) [ISP-HEADER01]
PIC12F509@SOIC8 [(SA602)]
PIC12F509@SOIC8(ISP) [ISP-HEADER01]
PIC12F510                                PIC12F510(ISP) [ISP-
HEADER01]
PIC12F510@MSOP8 [(SA666)]
PIC12F510@MSOP8(ISP) [ISP-HEADER01]
PIC12F510@SOIC8 [(SA605A)]
PIC12F510@SOIC8(ISP) [ISP-HEADER01]
PIC12F609                                PIC12F609(ISP) [ISP-
HEADER01]
PIC12F609@DFN8 [(BBBB)]
PIC12F609@DFN8(ISP) [ISP-HEADER01]
PIC12F609@SOIC8 [(SA602A)]
PIC12F609@SOIC8(ISP) [ISP-HEADER01]
PIC12F615                                PIC12F615(ISP) [ISP-
HEADER01]
PIC12F615@DFN8 [(BBBB)]
PIC12F615@DFN8(ISP) [ISP-HEADER01]
PIC12F615@SOIC8 [(SA602A)]
PIC12F615@SOIC8(ISP) [ISP-HEADER01]
PIC12F629                                PIC12F629(ISP) [ISP-
HEADER01]
PIC12F629(SM)@SOIC8 [(SA605A)]
PIC12F629(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F629(SN)@SOIC8 [(SA602A)]
PIC12F629(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12F629@DFN8 [(SA683)]
PIC12F629@DFN8(ISP) [ISP-HEADER01]
PIC12F635                                PIC12F635(ISP) [ISP-

```

```
HEADER01 ]
PIC12F635(MD)@DFN8 [(SA744)]
PIC12F635(MD)@DFN8(ISP) [ISP-HEADER01]
PIC12F635(MF)@DFN8 [(SA683)]
PIC12F635(MF)@DFN8(ISP) [ISP-HEADER01]
PIC12F635(SM)@SOIC8 [(SA605A)]
PIC12F635(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F635(SN)@SOIC8 [(SA602A)]
PIC12F635(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12F675 PIC12F675(ISP) [ISP-
HEADER01]
PIC12F675(SM)@SOIC8 [(SA605A)]
PIC12F675(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F675(SN)@SOIC8 [(SA602A)]
PIC12F675(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12F675@DFN8 [(SA683)]
PIC12F675@DFN8(ISP) [ISP-HEADER01]
PIC12F675@SSOP20 [(SA626A)]
PIC12F675@SSOP20(ISP) [ISP-HEADER01]
PIC12F683 PIC12F683(ISP) [ISP-
HEADER01]
PIC12F683(MD)@DFN8 [(SA744)]
PIC12F683(MD)@DFN8(ISP) [ISP-HEADER01]
PIC12F683(MF)@DFN8 [(SA683)]
PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]
PIC12F683(SM)@SOIC8 [(SA605A)]
PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F683(SN)@SOIC8 [(SA602A)]
PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12HV609 PIC12HV609(ISP) [ISP-
HEADER01]
PIC12HV609@DFN8 [(BBBB)]
PIC12HV609@DFN8(ISP) [ISP-HEADER01]
PIC12HV609@SOIC8 [(SA602A)]
PIC12HV609@SOIC8(ISP) [ISP-HEADER01]
PIC12HV615 PIC12HV615(ISP) [ISP-
HEADER01]
PIC12HV615@DFN8 [(BBBB)]
PIC12HV615@DFN8(ISP) [ISP-HEADER01]
PIC12HV615@SOIC8 [(SA602A)]
PIC12HV615@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508 PIC12LC508(ISP) [ISP-
HEADER01]
```

```
PIC12LC508@SOIC8 [(SA605A)]
PIC12LC508@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508A PIC12LC508A(ISP) [ISP-
HEADER01]
PIC12LC508A(SM)@SOIC8 [(SA605A)]
PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508A(SN)@SOIC8 [(SA602A)]
PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509 PIC12LC509(ISP) [ISP-
HEADER01]
PIC12LC509(SM)@SOIC8 [(SA605A)]
PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509(SN)@SOIC8 [(SA602A)]
PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509A PIC12LC509A(ISP) [ISP-
HEADER01]
PIC12LC509A(SM)@SOIC8 [(SA605A)]
PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509A(SN)@SOIC8 [(SA602A)]
PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC671 PIC12LC671(ISP) [ISP-
HEADER01]
PIC12LC671@DFN8 [(SA683)]
PIC12LC671@DFN8(ISP) [ISP-HEADER01]
PIC12LC671@SOIC8 [(SA605A)]
PIC12LC671@SOIC8(ISP) [ISP-HEADER01]
PIC12LC672 PIC12LC672(ISP) [ISP-
HEADER01]
PIC12LC672@DFN8 [(SA683)]
PIC12LC672@DFN8(ISP) [ISP-HEADER01]
PIC12LC672@SOIC8 [(SA605A)]
PIC12LC672@SOIC8(ISP) [ISP-HEADER01]
PIC12LF508 PIC12LF508(ISP) [ISP-
HEADER01]
PIC12LF508@MSOP8 [(SA666)]
PIC12LF508@MSOP8(ISP) [ISP-HEADER01]
PIC12LF508@SOIC8 [(SA602)]
PIC12LF508@SOIC8(ISP) [ISP-HEADER01]
PIC12LF509 PIC12LF509(ISP) [ISP-
HEADER01]
PIC12LF509@MSOP8 [(SA666)]
PIC12LF509@MSOP8(ISP) [ISP-HEADER01]
PIC12LF509@SOIC8 [(SA602)]
```

PIC12LF509@SOIC8(ISP) [ISP-HEADER01]	
PIC14000 HEADER01]	PIC14000(ISP) [ISP-
PIC14000@SOIC28 [(SA404)]	
PIC14000@SOIC28(ISP) [ISP-HEADER01]	
PIC14000@SSOP28 [(SA626A)]	
PIC14000@SSOP28(ISP) [ISP-HEADER01]	
PIC16C432 HEADER01]	PIC16C432(ISP) [ISP-
PIC16C432@SSOP20 [(SA626A)]	
PIC16C432@SSOP20(ISP) [ISP-HEADER01]	
PIC16C433 HEADER01]	PIC16C433(ISP) [ISP-
PIC16C433@SOIC18 [(SA404)]	
PIC16C433@SOIC18(ISP) [ISP-HEADER01]	
PIC16C505 [(SA602)]	PIC16C505@SOIC14
PIC16C52 [(SA404)]	PIC16C52@SOIC18
PIC16C54 [(SA404)]	PIC16C54@SOIC18
PIC16C54A [(SA404)]	PIC16C54A@SOIC18
PIC16C54A@SSOP20 [(SA626A)]	
PIC16C54B	
PIC16C54B@SOIC18 [(SA404)]	PIC16C54B@SSOP20
[(SA626A)]	
PIC16C54C	PIC16C54C@SOIC18
[(SA404)]	
PIC16C54C@SSOP20 [(SA626A)]	
PIC16C55	
PIC16C55@SOIC28 [(SA404)]	
PIC16C554	
PIC16C554(ISP) [ISP-HEADER01]	PIC16C554@SOIC18
[(SA404)]	
PIC16C554@SOIC18(ISP) [ISP-HEADER01]	
PIC16C554@SSOP20 [(SA626A)]	
PIC16C554@SSOP20(ISP) [ISP-HEADER01]	
PIC16C556 HEADER01]	PIC16C556(ISP) [ISP-
PIC16C556@SOIC18 [(SA404)]	
PIC16C556@SOIC18(ISP) [ISP-HEADER01]	
PIC16C558	PIC16C558(ISP) [ISP-


```

HEADER01 ]
PIC16C558@SOIC18 [ (SA404) ]
PIC16C558@SOIC18(ISP) [ ISP-HEADER01 ]
PIC16C558@SSOP20 [ (SA626A) ]
PIC16C558@SSOP20(ISP) [ ISP-HEADER01 ]
PIC16C55A PIC16C55A@SOIC28
[ (SA404) ]
PIC16C55A@SSOP28 [ (SA626A) ]
PIC16C56
PIC16C56@SOIC18 [ (SA404) ]
PIC16C56A
PIC16C56A@SOIC18 [ (SA404) ] PIC16C56A@SSOP20
[ (SA626A) ]
PIC16C57 PIC16C57@SOIC28
[ (SA404) ]
PIC16C57@SSOP28 [ (SA626A) ]
PIC16C57C
PIC16C57C@SOIC28 [ (SA404) ] PIC16C57C@SSOP28
[ (SA626A) ]
PIC16C58 PIC16C58@SOIC18
[ (SA404) ]
PIC16C58A PIC16C58A@SOIC18
[ (SA404) ]
PIC16C58A@SSOP20 [ (SA626A) ]
PIC16C58B
PIC16C58B@SOIC18 [ (SA404) ] PIC16C58B@SSOP20
[ (SA626A) ]
PIC16C61 PIC16C61(ISP) [ ISP-
HEADER01 ]
PIC16C61@SOIC18 [ (SA404) ]
PIC16C61@SOIC18(ISP) [ ISP-HEADER01 ]
PIC16C62 PIC16C62(ISP) [ ISP-
HEADER01 ]
PIC16C62@SOIC28 [ (SA404) ]
PIC16C62@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16C62@SSOP28 [ (SA626A) ]
PIC16C62@SSOP28(ISP) [ ISP-HEADER01 ]
PIC16C620 PIC16C620(ISP) [ ISP-
HEADER01 ]
PIC16C620@SOIC18 [ (SA404) ]
PIC16C620@SOIC18(ISP) [ ISP-HEADER01 ]
PIC16C620A PIC16C620A(ISP) [ ISP-
HEADER01 ]

```

PIC16C620A@SOIC18 [(SA404)]
PIC16C620A@SOIC18(ISP) [ISP-HEADER01]
PIC16C620A@SSOP20 [(SA626A)]
PIC16C620A@SSOP20(ISP) [ISP-HEADER01]
PIC16C621 PIC16C621(ISP) [ISP-
HEADER01]
PIC16C621@SOIC18 [(SA404)]
PIC16C621@SOIC18(ISP) [ISP-HEADER01]
PIC16C621A PIC16C621A(ISP) [ISP-
HEADER01]
PIC16C621A@SOIC18 [(SA404)]
PIC16C621A@SOIC18(ISP) [ISP-HEADER01]
PIC16C621A@SSOP20 [(SA626A)]
PIC16C621A@SSOP20(ISP) [ISP-HEADER01]
PIC16C622 PIC16C622(ISP) [ISP-
HEADER01]
PIC16C622@SOIC18 [(SA404)]
PIC16C622@SOIC18(ISP) [ISP-HEADER01]
PIC16C622A PIC16C622A(ISP) [ISP-
HEADER01]
PIC16C622A@SOIC18 [(SA404)]
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]
PIC16C622A@SSOP20 [(SA626A)]
PIC16C622A@SSOP20(ISP) [ISP-HEADER01]
PIC16C625 PIC16C625(ISP) [ISP-
HEADER01]
PIC16C625@SOIC18 [(SA404)]
PIC16C625@SOIC18(ISP) [ISP-HEADER01]
PIC16C62A PIC16C62A(ISP) [ISP-
HEADER01]
PIC16C62A@SOIC28 [(SA404)]
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]
PIC16C62A@SSOP28 [(SA626A)]
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]
PIC16C62B PIC16C62B(ISP) [ISP-
HEADER01]
PIC16C62B@SOIC28 [(SA404)]
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]
PIC16C62B@SSOP28 [(SA626A)]
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]
PIC16C63 PIC16C63(ISP) [ISP-
HEADER01]
PIC16C63@SOIC28 [(SA404)]

```

PIC16C63@SOIC28(ISP) [ISP-HEADER01]
PIC16C63A PIC16C63A(ISP) [ISP-
HEADER01]
PIC16C63A@SOIC28 [(SA404)]
PIC16C63A@SOIC28(ISP) [ISP-HEADER01]
PIC16C63A@SSOP28 [(SA626A)]
PIC16C63A@SSOP28(ISP) [ISP-HEADER01]
PIC16C64 PIC16C64(ISP) [ISP-
HEADER01]
PIC16C64@PLCC44 [(SA244)]
PIC16C64@PLCC44(ISP) [ISP-HEADER01]
PIC16C64@TQFP44 [(SA245A)]
PIC16C64@TQFP44(ISP) [ISP-HEADER01]
PIC16C641 PIC16C641@SOIC28
[(SA404)]
PIC16C641@SSOP28 [(SA626A)]
PIC16C642 PIC16C642@SSOP28
[(SA626A)]
PIC16C64A PIC16C64A(ISP) [ISP-
HEADER01]
PIC16C64A@PLCC44 [(SA244)]
PIC16C64A@PLCC44(ISP) [ISP-HEADER01]
PIC16C64A@TQFP44 [(SA245A)]
PIC16C64A@TQFP44(ISP) [ISP-HEADER01]
PIC16C65 PIC16C65(ISP) [ISP-
HEADER01]
PIC16C65@PLCC44 [(SA244)]
PIC16C65@PLCC44(ISP) [ISP-HEADER01]
PIC16C65@TQFP44 [(SA245A)]
PIC16C65@TQFP44(ISP) [ISP-HEADER01]
PIC16C65A PIC16C65A(ISP) [ISP-
HEADER01]
PIC16C65A@PLCC44 [(SA244)]
PIC16C65A@PLCC44(ISP) [ISP-HEADER01]
PIC16C65A@TQFP44 [(SA245A)]
PIC16C65A@TQFP44(ISP) [ISP-HEADER01]
PIC16C65B PIC16C65B(ISP) [ISP-
HEADER01]
PIC16C65B@PLCC44 [(SA244)]
PIC16C65B@PLCC44(ISP) [ISP-HEADER01]
PIC16C65B@TQFP44 [(SA245A)]
PIC16C65B@TQFP44(ISP) [ISP-HEADER01]

```

```
PIC16C66 PIC16C66(ISP) [ISP-
HEADER01]
PIC16C66@SOIC28 [(SA404)]
PIC16C66@SOIC28(ISP) [ISP-HEADER01]
PIC16C661 PIC16C661@PLCC44
[(SA244)]
PIC16C661@TQFP44 [(SA245A)]
PIC16C662 PIC16C662@TQFP44
PIC16C662@PLCC44 [(SA244)]
[(SA245A)]
PIC16C67 PIC16C67(ISP) [ISP-
HEADER01]
PIC16C67@PLCC44 [(SA244)]
PIC16C67@PLCC44(ISP) [ISP-HEADER01]
PIC16C67@TQFP44 [(SA245A)]
PIC16C67@TQFP44(ISP) [ISP-HEADER01]
PIC16C70 PIC16C70(ISP) [ISP-
HEADER01]
PIC16C70@SOIC18 [(SA404)]
PIC16C70@SOIC18(ISP) [ISP-HEADER01]
PIC16C71 PIC16C71(ISP) [ISP-
HEADER01]
PIC16C71@SOIC18 [(SA404)]
PIC16C71@SOIC18(ISP) [ISP-HEADER01]
PIC16C710 PIC16C710(ISP) [ISP-
HEADER01]
PIC16C710@SOIC18 [(SA404)]
PIC16C710@SOIC18(ISP) [ISP-HEADER01]
PIC16C710@SSOP20 [(SA626A)]
PIC16C710@SSOP20(ISP) [ISP-HEADER01]
PIC16C711 PIC16C711(ISP) [ISP-
HEADER01]
PIC16C711@SOIC18 [(SA404)]
PIC16C711@SOIC18(ISP) [ISP-HEADER01]
PIC16C711@SSOP20 [(SA626A)]
PIC16C711@SSOP20(ISP) [ISP-HEADER01]
PIC16C712 PIC16C712(ISP) [ISP-
HEADER01]
PIC16C712@SOIC18 [(SA404)]
PIC16C712@SOIC18(ISP) [ISP-HEADER01]
PIC16C712@SSOP20 [(SA626A)]
PIC16C712@SSOP20(ISP) [ISP-HEADER01]
PIC16C715 PIC16C715@SOIC18
```

```

[ (SA404) ]
PIC16C715@SSOP20 [ (SA626A) ]
PIC16C716
PIC16C716(ISP) [ ISP-HEADER01 ]          PIC16C716@SOIC18
[ (SA404) ]
PIC16C716@SOIC18(ISP) [ ISP-HEADER01 ]
PIC16C716@SSOP20 [ (SA626A) ]
PIC16C716@SSOP20(ISP) [ ISP-HEADER01 ]
PIC16C717          PIC16C717(ISP) [ ISP-
HEADER01 ]
PIC16C717@SOIC18 [ (SA404) ]
PIC16C717@SOIC18(ISP) [ ISP-HEADER01 ]
PIC16C717@SSOP20 [ (SA626A) ]
PIC16C717@SSOP20(ISP) [ ISP-HEADER01 ]
PIC16C71A          PIC16C71A(ISP) [ ISP-
HEADER01 ]
PIC16C71A@SOIC18 [ (SA404) ]
PIC16C71A@SOIC18(ISP) [ ISP-HEADER01 ]
PIC16C72          PIC16C72(ISP) [ ISP-
HEADER01 ]
PIC16C72@SOIC28 [ (SA404) ]
PIC16C72@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16C72@SSOP28 [ (SA626A) ]
PIC16C72@SSOP28(ISP) [ ISP-HEADER01 ]
PIC16C72A          PIC16C72A(ISP) [ ISP-
HEADER01 ]
PIC16C72A@SOIC28 [ (SA404) ]
PIC16C72A@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16C72A@SSOP28 [ (SA626A) ]
PIC16C72A@SSOP28(ISP) [ ISP-HEADER01 ]
PIC16C73          PIC16C73(ISP) [ ISP-
HEADER01 ]
PIC16C73@SOIC28 [ (SA404) ]
PIC16C73@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16C73A          PIC16C73A(ISP) [ ISP-
HEADER01 ]
PIC16C73A@SOIC28 [ (SA404) ]
PIC16C73A@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16C73B          PIC16C73B(ISP) [ ISP-
HEADER01 ]
PIC16C73B@SOIC28 [ (SA404) ]
PIC16C73B@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16C73B@SSOP28 [ (SA626A) ]

```

PIC16C73B@SSOP28(ISP) [ISP-HEADER01]
PIC16C74 PIC16C74(ISP) [ISP-
HEADER01]
PIC16C74@PLCC44 [(SA244)]
PIC16C74@PLCC44(ISP) [ISP-HEADER01]
PIC16C74@TQFP44 [(SA245A)]
PIC16C74@TQFP44(ISP) [ISP-HEADER01]
PIC16C745 PIC16C745(ISP) [ISP-
HEADER01]
PIC16C745@SOIC28 [(SA404)]
PIC16C745@SOIC28(ISP) [ISP-HEADER01]
PIC16C74A PIC16C74A(ISP) [ISP-
HEADER01]
PIC16C74A@PLCC44 [(SA244)]
PIC16C74A@PLCC44(ISP) [ISP-HEADER01]
PIC16C74A@TQFP44 [(SA245A)]
PIC16C74A@TQFP44(ISP) [ISP-HEADER01]
PIC16C74B PIC16C74B(ISP) [ISP-
HEADER01]
PIC16C74B@MQFP44 [(SA675)]
PIC16C74B@MQFP44(ISP) [ISP-HEADER01]
PIC16C74B@PLCC44 [(SA244)]
PIC16C74B@PLCC44(ISP) [ISP-HEADER01]
PIC16C74B@TQFP44 [(SA245A)]
PIC16C74B@TQFP44(ISP) [ISP-HEADER01]
PIC16C76 PIC16C76(ISP) [ISP-
HEADER01]
PIC16C76@SOIC28 [(SA404)]
PIC16C76@SOIC28(ISP) [ISP-HEADER01]
PIC16C765 PIC16C765(ISP) [ISP-
HEADER01]
PIC16C765@PLCC44 [(SA244)]
PIC16C765@PLCC44(ISP) [ISP-HEADER01]
PIC16C765@TQFP44 [(SA245A)]
PIC16C765@TQFP44(ISP) [ISP-HEADER01]
PIC16C77 PIC16C77(ISP) [ISP-
HEADER01]
PIC16C77@PLCC44 [(SA244)]
PIC16C77@PLCC44(ISP) [ISP-HEADER01]
PIC16C77@TQFP44 [(SA245A)]
PIC16C77@TQFP44(ISP) [ISP-HEADER01]
PIC16C770 PIC16C770(ISP) [ISP-
HEADER01]

```
PIC16C770@SOIC20 [(SA404)]
PIC16C770@SOIC20(ISP) [ISP-HEADER01]
PIC16C770@SSOP20 [(SA626A)]
PIC16C770@SSOP20(ISP) [ISP-HEADER01]
PIC16C771 PIC16C771(ISP) [ISP-
HEADER01]
PIC16C771@SOIC20 [(SA404)]
PIC16C771@SOIC20(ISP) [ISP-HEADER01]
PIC16C771@SSOP20 [(SA626A)]
PIC16C771@SSOP20(ISP) [ISP-HEADER01]
PIC16C773 PIC16C773(ISP) [ISP-
HEADER01]
PIC16C773@SOIC28 [(SA404)]
PIC16C773@SOIC28(ISP) [ISP-HEADER01]
PIC16C773@SSOP28 [(SA626A)]
PIC16C773@SSOP28(ISP) [ISP-HEADER01]
PIC16C774 PIC16C774(ISP) [ISP-
HEADER01]
PIC16C774@PLCC44 [(SA244)]
PIC16C774@PLCC44(ISP) [ISP-HEADER01]
PIC16C774@TQFP44 [(SA675)]
PIC16C774@TQFP44(ISP) [ISP-HEADER01]
PIC16C781 PIC16C781(ISP) [ISP-
HEADER01]
PIC16C781@SOIC20 [(SA404)]
PIC16C781@SOIC20(ISP) [ISP-HEADER01]
PIC16C781@SSOP20 [(SA626A)]
PIC16C781@SSOP20(ISP) [ISP-HEADER01]
PIC16C782 PIC16C782(ISP) [ISP-
HEADER01]
PIC16C782@SOIC20 [(SA404)]
PIC16C782@SOIC20(ISP) [ISP-HEADER01]
PIC16C782@SSOP20 [(SA626A)]
PIC16C782@SSOP20(ISP) [ISP-HEADER01]
PIC16C84 PIC16C84(ISP) [ISP-
HEADER01]
PIC16C84@SOIC18 [(SA404)]
PIC16C84@SOIC18(ISP) [ISP-HEADER01]
PIC16C923@PLCC68(*) [(SA648-B6807)]
PIC16C923@PLCC68(ISP) [ISP-HEADER01]
PIC16C923@SDIP64(ISP) [ISP-HEADER01]
PIC16C923@TQFP64(ISP) [ISP-HEADER01]
PIC16C924@PLCC68(*) [(SA648-B6807)]
```

PIC16C924@PLCC68(ISP) [ISP-HEADER01]
PIC16C924@SDIP64(ISP) [ISP-HEADER01]
PIC16C924@TQFP64(ISP) [ISP-HEADER01]
PIC16C925@PLCC68(*) [(SA648-B6807)]
PIC16C925@PLCC68(ISP) [ISP-HEADER01]
PIC16C925@TQFP64(ISP) [ISP-HEADER01]
PIC16C926@PLCC68(*) [(SA648-B6807)]
PIC16C926@PLCC68(ISP) [ISP-HEADER01]
PIC16C926@TQFP64(ISP) [ISP-HEADER01]
PIC16CE623 PIC16CE623(ISP) [ISP-
HEADER01]
PIC16CE623@SOIC18 [(SA404)]
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]
PIC16CE624 PIC16CE624(ISP) [ISP-
HEADER01]
PIC16CE624@SOIC18 [(SA404)]
PIC16CE624@SOIC18(ISP) [ISP-HEADER01]
PIC16CE625 PIC16CE625(ISP) [ISP-
HEADER01]
PIC16CE625@SOIC18 [(SA404)]
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]
PIC16CE625@SSOP20 [(SA626A)]
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]
PIC16CR83 PIC16CR83(ISP) [ISP-
HEADER01]
PIC16CR83@SOIC18 [(SA404)]
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]
PIC16CR84 PIC16CR84(ISP) [ISP-
HEADER01]
PIC16CR84@SOIC18 [(SA404)]
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]
PIC16F505 PIC16F505(ISP) [ISP-
HEADER01]
PIC16F505@SOIC14 [(SA602)]
PIC16F505@SOIC14(ISP) [ISP-HEADER01]
PIC16F505@TSSOP14 [(SA026)]
PIC16F505@TSSOP14(ISP) [ISP-HEADER01]
PIC16F506 PIC16F506(ISP) [ISP-
HEADER01]
PIC16F506@SOIC14 [(SA602)]
PIC16F506@SOIC14(ISP) [ISP-HEADER01]
PIC16F506@TSSOP14 [(SA026)]
PIC16F506@TSSOP14(ISP) [ISP-HEADER01]

PIC16F526 [(SA602)]	PIC16F526@SOIC14
PIC16F526@TSSOP14 [(SA026)]	
PIC16F54	
PIC16F54(ISP) [ISP-HEADER01] [(SA404)]	PIC16F54@SOIC18
PIC16F54@SOIC18(ISP) [ISP-HEADER01]	
PIC16F54@SSOP20 [(SA626A)]	
PIC16F54@SSOP20(ISP) [ISP-HEADER01]	
PIC16F57 HEADER01]	PIC16F57(ISP) [ISP-
PIC16F57@SOIC28 [(SA404)]	
PIC16F57@SOIC28(ISP) [ISP-HEADER01]	
PIC16F57@SSOP28 [(SA626A)]	
PIC16F57@SSOP28(ISP) [ISP-HEADER01]	
PIC16F59 HEADER01]	PIC16F59(ISP) [ISP-
PIC16F59@PLCC44 [(SA244)]	
PIC16F59@PLCC44(ISP) [ISP-HEADER01]	
PIC16F59@TQFP44 [(SA245A)]	
PIC16F59@TQFP44(ISP) [ISP-HEADER01]	
PIC16F610 HEADER01]	PIC16F610(ISP) [ISP-
PIC16F610@QFN16 [(SA727)]	
PIC16F610@QFN16(ISP) [ISP-HEADER01]	
PIC16F610@SOIC14 [(SA602)]	
PIC16F610@SOIC14(ISP) [ISP-HEADER01]	
PIC16F610@TSSOP14 [(SA026)]	
PIC16F610@TSSOP14(ISP) [ISP-HEADER01]	
PIC16F616 HEADER01]	PIC16F616(ISP) [ISP-
PIC16F616@QFN16 [(SA727)]	
PIC16F616@QFN16(ISP) [ISP-HEADER01]	
PIC16F616@SOIC14 [(SA602)]	
PIC16F616@SOIC14(ISP) [ISP-HEADER01]	
PIC16F616@TSSOP14 [(SA026)]	
PIC16F616@TSSOP14(ISP) [ISP-HEADER01]	
PIC16F627 HEADER01]	PIC16F627(ISP) [ISP-
PIC16F627@SOIC18 [(SA404)]	
PIC16F627@SOIC18(ISP) [ISP-HEADER01]	
PIC16F627@SSOP20 [(SA626A)]	
PIC16F627@SSOP20(ISP) [ISP-HEADER01]	

PIC16F627A PIC16F627A(ISP) [ISP-
HEADER01]
PIC16F627A@SOIC18 [(SA404)]
PIC16F627A@SOIC18(ISP) [ISP-HEADER01]
PIC16F627A@SSOP20 [(SA626A)]
PIC16F627A@SSOP20(ISP) [ISP-HEADER01]
PIC16F628 PIC16F628(ISP) [ISP-
HEADER01]
PIC16F628@SOIC18 [(SA404)]
PIC16F628@SOIC18(ISP) [ISP-HEADER01]
PIC16F628@SSOP20 [(SA626A)]
PIC16F628@SSOP20(ISP) [ISP-HEADER01]
PIC16F628A PIC16F628A(ISP) [ISP-
HEADER01]
PIC16F628A@SOIC18 [(SA404)]
PIC16F628A@SOIC18(ISP) [ISP-HEADER01]
PIC16F628A@SSOP20 [(SA626A)]
PIC16F628A@SSOP20(ISP) [ISP-HEADER01]
PIC16F630 PIC16F630(ISP) [ISP-
HEADER01]
PIC16F630@SOIC14 [(SA602)]
PIC16F630@SOIC14(ISP) [ISP-HEADER01]
PIC16F630@TSSOP14 [(SA026)]
PIC16F630@TSSOP14(ISP) [ISP-HEADER01]
PIC16F631 PIC16F631(ISP) [ISP-
HEADER01]
PIC16F631@QFN20 [(SA692)]
PIC16F631@QFN20(ISP) [ISP-HEADER01]
PIC16F631@SOIC20 [(SA404)]
PIC16F631@SOIC20(ISP) [ISP-HEADER01]
PIC16F631@SSOP20 [(SA626A)]
PIC16F631@SSOP20(ISP) [ISP-HEADER01]
PIC16F636 PIC16F636(ISP) [ISP-
HEADER01]
PIC16F636@QFN16 [(SA727)]
PIC16F636@QFN16(ISP) [ISP-HEADER01]
PIC16F636@SOIC14 [(SA602)]
PIC16F636@SOIC14(ISP) [ISP-HEADER01]
PIC16F636@TSSOP14 [(SA026)]
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]
PIC16F639 PIC16F639(ISP) [ISP-
HEADER01]
PIC16F639@QFN20 [(SA692)]

PIC16F639@QFN20(ISP) [ISP-HEADER01]
PIC16F639@SOIC20 [(SA404)]
PIC16F639@SOIC20(ISP) [ISP-HEADER01]
PIC16F639@SSOP20 [(SA626A)]
PIC16F639@SSOP20(ISP) [ISP-HEADER01]
PIC16F648A PIC16F648A(ISP) [ISP-
HEADER01]
PIC16F648A@SOIC18 [(SA404)]
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]
PIC16F648A@SSOP20 [(SA626A)]
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]
PIC16F676 PIC16F676(ISP) [ISP-
HEADER01]
PIC16F676@SOIC14 [(SA602)]
PIC16F676@SOIC14(ISP) [ISP-HEADER01]
PIC16F676@TSSOP14 [(SA026)]
PIC16F676@TSSOP14(ISP) [ISP-HEADER01]
PIC16F677 PIC16F677(ISP) [ISP-
HEADER01]
PIC16F677@QFN20 [(SA692)]
PIC16F677@QFN20(ISP) [ISP-HEADER01]
PIC16F677@SOIC20 [(SA404)]
PIC16F677@SOIC20(ISP) [ISP-HEADER01]
PIC16F677@SSOP20 [(SA626A)]
PIC16F677@SSOP20(ISP) [ISP-HEADER01]
PIC16F684 PIC16F684(ISP) [ISP-
HEADER01]
PIC16F684@QFN16 [(SA727)]
PIC16F684@QFN16(ISP) [ISP-HEADER01]
PIC16F684@SOIC14 [(SA602)]
PIC16F684@SOIC14(ISP) [ISP-HEADER01]
PIC16F684@TSSOP14 [(SA026)]
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]
PIC16F685 PIC16F685(ISP) [ISP-
HEADER01]
PIC16F685@QFN20 [(SA692)]
PIC16F685@QFN20(ISP) [ISP-HEADER01]
PIC16F685@SOIC20 [(SA404)]
PIC16F685@SOIC20(ISP) [ISP-HEADER01]
PIC16F685@SSOP20 [(SA626A)]
PIC16F685@SSOP20(ISP) [ISP-HEADER01]
PIC16F687 PIC16F687(ISP) [ISP-
HEADER01]

```
PIC16F687@QFN20 [(SA692)]
PIC16F687@QFN20(ISP) [ISP-HEADER01]
PIC16F687@SOIC20 [(SA404)]
PIC16F687@SOIC20(ISP) [ISP-HEADER01]
PIC16F687@SSOP20 [(SA626A)]
PIC16F687@SSOP20(ISP) [ISP-HEADER01]
PIC16F688 PIC16F688(ISP) [ISP-
HEADER01]
PIC16F688@QFN16 [(SA727)]
PIC16F688@QFN16(ISP) [ISP-HEADER01]
PIC16F688@SOIC14 [(SA602)]
PIC16F688@SOIC14(ISP) [ISP-HEADER01]
PIC16F688@TSSOP14 [(SA026)]
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]
PIC16F689 PIC16F689(ISP) [ISP-
HEADER01]
PIC16F689@QFN20 [(SA692)]
PIC16F689@QFN20(ISP) [ISP-HEADER01]
PIC16F689@SOIC20 [(SA404)]
PIC16F689@SOIC20(ISP) [ISP-HEADER01]
PIC16F689@SSOP20 [(SA626A)]
PIC16F689@SSOP20(ISP) [ISP-HEADER01]
PIC16F690 PIC16F690(ISP) [ISP-
HEADER01]
PIC16F690@QFN20 [(SA692)]
PIC16F690@QFN20(ISP) [ISP-HEADER01]
PIC16F690@SOIC20 [(SA404)]
PIC16F690@SOIC20(ISP) [ISP-HEADER01]
PIC16F690@SSOP20 [(SA626A)]
PIC16F690@SSOP20(ISP) [ISP-HEADER01]
PIC16F716 PIC16F716(ISP) [ISP-
HEADER01]
PIC16F716@SOIC18 [(SA404)]
PIC16F716@SOIC18(ISP) [ISP-HEADER01]
PIC16F716@SSOP20 [(SA626A)]
PIC16F716@SSOP20(ISP) [ISP-HEADER01]
PIC16F72 PIC16F72(ISP) [ISP-
HEADER01]
PIC16F72@QFN28 [(SA685-B006)]
PIC16F72@QFN28(ISP) [ISP-HEADER01]
PIC16F72@SOIC28 [(SA404)]
PIC16F72@SOIC28(ISP) [ISP-HEADER01]
PIC16F72@SSOP28 [(SA626A)]
```

PIC16F72@SSOP28 (ISP) [ISP-HEADER01]	
PIC16F722	PIC16F722@QFN28 [(SA685-
B006)]	
PIC16F722@SOIC28 [(SA404)]	PIC16F722@SSOP28
[(SA626A)]	
PIC16F723	PIC16F723@QFN28 [(SA685-
B006)]	
PIC16F723@SOIC28 [(SA404)]	PIC16F723@SSOP28
[(SA626A)]	
PIC16F724	PIC16F724@QFN44
[(SA737)]	
PIC16F724@TQFP44 [(SA245A)]	
PIC16F726	
PIC16F726@QFN28 [(SA685-B006)]	PIC16F726@SOIC28
[(SA404)]	
PIC16F726@SSOP28 [(SA626A)]	
PIC16F727	
PIC16F727@QFN44 [(SA737)]	PIC16F727@TQFP44
[(SA245A)]	
PIC16F73	PIC16F73 (ISP) [ISP-
HEADER01]	
PIC16F73@SOIC28 [(SA404)]	
PIC16F73@SOIC28 (ISP) [ISP-HEADER01]	
PIC16F73@SSOP28 [(SA626A)]	
PIC16F73@SSOP28 (ISP) [ISP-HEADER01]	
PIC16F737	PIC16F737 (ISP) [ISP-
HEADER01]	
PIC16F737@SOIC28 [(SA404)]	
PIC16F737@SOIC28 (ISP) [ISP-HEADER01]	
PIC16F737@SSOP28 [(SA626A)]	
PIC16F737@SSOP28 (ISP) [ISP-HEADER01]	
PIC16F74	PIC16F74 (ISP) [ISP-
HEADER01]	
PIC16F74@PLCC44 [(SA244)]	
PIC16F74@PLCC44 (ISP) [ISP-HEADER01]	
PIC16F74@TQFP44 [(SA245A)]	
PIC16F74@TQFP44 (ISP) [ISP-HEADER01]	
PIC16F747	PIC16F747 (ISP) [ISP-
HEADER01]	
PIC16F747@TQFP44 [(SA245A)]	
PIC16F747@TQFP44 (ISP) [ISP-HEADER01]	
PIC16F76	PIC16F76 (ISP) [ISP-
HEADER01]	

PIC16F76@SOIC28 [(SA404)]
PIC16F76@SOIC28(ISP) [ISP-HEADER01]
PIC16F76@SSOP28 [(SA626A)]
PIC16F76@SSOP28(ISP) [ISP-HEADER01]
PIC16F767 PIC16F767(ISP) [ISP-
HEADER01]
PIC16F767@SOIC28 [(SA404)]
PIC16F767@SOIC28(ISP) [ISP-HEADER01]
PIC16F767@SSOP28 [(SA626A)]
PIC16F767@SSOP28(ISP) [ISP-HEADER01]
PIC16F77 PIC16F77(ISP) [ISP-
HEADER01]
PIC16F77@PLCC44 [(SA244)]
PIC16F77@PLCC44(ISP) [ISP-HEADER01]
PIC16F77@TQFP44 [(SA245A)]
PIC16F77@TQFP44(ISP) [ISP-HEADER01]
PIC16F777 PIC16F777(ISP) [ISP-
HEADER01]
PIC16F777@TQFP44 [(SA245A)]
PIC16F777@TQFP44(ISP) [ISP-HEADER01]
PIC16F785 PIC16F785(ISP) [ISP-
HEADER01]
PIC16F785@QFN20 [(SA692)]
PIC16F785@QFN20(ISP) [ISP-HEADER01]
PIC16F785@SOIC20 [(SA404)]
PIC16F785@SOIC20(ISP) [ISP-HEADER01]
PIC16F785@SSOP20 [(SA626A)]
PIC16F785@SSOP20(ISP) [ISP-HEADER01]
PIC16F818 PIC16F818(ISP) [ISP-
HEADER01]
PIC16F818@QFN28 [(SA685-B006)]
PIC16F818@QFN28(ISP) [ISP-HEADER01]
PIC16F818@SOIC18 [(SA404)]
PIC16F818@SOIC18(ISP) [ISP-HEADER01]
PIC16F818@SSOP20 [(SA626A)]
PIC16F818@SSOP20(ISP) [ISP-HEADER01]
PIC16F819 PIC16F819(ISP) [ISP-
HEADER01]
PIC16F819@QFN28 [(SA685-B006)]
PIC16F819@QFN28(ISP) [ISP-HEADER01]
PIC16F819@SOIC18 [(SA404)]
PIC16F819@SOIC18(ISP) [ISP-HEADER01]
PIC16F819@SSOP20 [(SA626A)]

PIC16F819@SSOP20(ISP) [ISP-HEADER01]
PIC16F83 PIC16F83(ISP) [ISP-
HEADER01]
PIC16F83@SOIC18 [(SA404)]
PIC16F83@SOIC18(ISP) [ISP-HEADER01]
PIC16F84 PIC16F84(ISP) [ISP-
HEADER01]
PIC16F84@SOIC18 [(SA404)]
PIC16F84@SOIC18(ISP) [ISP-HEADER01]
PIC16F84A PIC16F84A(ISP) [ISP-
HEADER01]
PIC16F84A@SOIC18 [(SA404)]
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]
PIC16F84A@SSOP20 [(SA626A)]
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]
PIC16F87 PIC16F87(ISP) [ISP-
HEADER01]
PIC16F87@QFN28 [(SA685-B006)]
PIC16F87@QFN28(ISP) [ISP-HEADER01]
PIC16F87@SOIC18 [(SA404)]
PIC16F87@SOIC18(ISP) [ISP-HEADER01]
PIC16F87@SSOP20 [(SA626A)]
PIC16F87@SSOP20(ISP) [ISP-HEADER01]
PIC16F870 PIC16F870(ISP) [ISP-
HEADER01]
PIC16F870@SOIC28 [(SA404)]
PIC16F870@SOIC28(ISP) [ISP-HEADER01]
PIC16F870@SSOP28 [(SA626A)]
PIC16F870@SSOP28(ISP) [ISP-HEADER01]
PIC16F871 PIC16F871(ISP) [ISP-
HEADER01]
PIC16F871@PLCC44 [(SA244)]
PIC16F871@PLCC44(ISP) [ISP-HEADER01]
PIC16F871@TQFP44 [(SA245A)]
PIC16F871@TQFP44(ISP) [ISP-HEADER01]
PIC16F872 PIC16F872(ISP) [ISP-
HEADER01]
PIC16F872@SOIC28 [(SA404)]
PIC16F872@SOIC28(ISP) [ISP-HEADER01]
PIC16F872@SSOP28 [(SA626A)]
PIC16F872@SSOP28(ISP) [ISP-HEADER01]
PIC16F873 PIC16F873(ISP) [ISP-
HEADER01]

PIC16F873@SOIC28 [(SA404)]
PIC16F873@SOIC28(ISP) [ISP-HEADER01]
PIC16F873A
PIC16F873A(ISP)(High-V) [ISP-HEADER01]
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@QFN28 [(SA697-B006)]
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@SOIC28 [(SA404)]
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@SSOP28 [(SA626A)]
PIC16F873A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874 PIC16F874(ISP) [ISP-
HEADER01]
PIC16F874@PLCC44 [(SA244)]
PIC16F874@PLCC44(ISP) [ISP-HEADER01]
PIC16F874@TQFP44 [(SA245A)]
PIC16F874@TQFP44(ISP) [ISP-HEADER01]
PIC16F874A
PIC16F874A(ISP)(High-V) [ISP-HEADER01]
PIC16F874A(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874A@PLCC44 [(SA244)]
PIC16F874A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874A@TQFP44 [(SA245A)]
PIC16F874A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]


```
PIC16F876 PIC16F876(ISP) [ISP-  
HEADER01]  
PIC16F876@SOIC28 [(SA404)]  
PIC16F876@SOIC28(ISP) [ISP-HEADER01]  
PIC16F876A  
PIC16F876A(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@QFN28 [(SA697-B006)]  
PIC16F876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SOIC28 [(SA404)]  
PIC16F876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SSOP28 [(SA626A)]  
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877 PIC16F877(ISP) [ISP-  
HEADER01]  
PIC16F877@PLCC44 [(SA244)]  
PIC16F877@PLCC44(ISP) [ISP-HEADER01]  
PIC16F877@TQFP44 [(SA245A)]  
PIC16F877@TQFP44(ISP) [ISP-HEADER01]  
PIC16F877A  
PIC16F877A(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@PLCC44 [(SA244)]  
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@TQFP44 [(SA245A)]  
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
```

PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F88 PIC16F88(ISP) [ISP-
HEADER01]
PIC16F88@QFN28 [(SA685-B006)]
PIC16F88@QFN28(ISP) [ISP-HEADER01]
PIC16F88@SOIC18 [(SA404)]
PIC16F88@SOIC18(ISP) [ISP-HEADER01]
PIC16F88@SSOP20 [(SA626A)]
PIC16F88@SSOP20(ISP) [ISP-HEADER01]
PIC16F882
PIC16F882(ISP)(High-V) [ISP-HEADER01]
PIC16F882(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@QFN28 [(SA697-B005)]
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@SOIC28 [(SA404)]
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@SSOP28 [(SA626A)]
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883
PIC16F883(ISP)(High-V) [ISP-HEADER01]
PIC16F883(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@QFN28 [(SA697-B005)]
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@SOIC28 [(SA404)]
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@SSOP28 [(SA626A)]
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F884
PIC16F884(ISP)(High-V) [ISP-HEADER01]
PIC16F884(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@QFN44 [(SA712)]
PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@QFN44(ML) [(SA737)]
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]

```
PIC16F884@TQFP44 [(SA245A)]
PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F886
PIC16F886(ISP)(High-V) [ISP-HEADER01]
PIC16F886(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@QFN28 [(SA697-B005)]
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@SOIC28 [(SA404)]
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@SSOP28 [(SA626A)]
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F887
PIC16F887(ISP)(High-V) [ISP-HEADER01]
PIC16F887(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@QFN44 [(SA712)]
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@QFN44(ML) [(SA737)]
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]
PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@TQFP44 [(SA245A)]
PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F913 PIC16F913(ISP) [ISP-
HEADER01]
PIC16F913@QFN28 [(SA697-B006)]
PIC16F913@QFN28(ISP) [ISP-HEADER01]
PIC16F913@SOIC28 [(SA404)]
PIC16F913@SOIC28(ISP) [ISP-HEADER01]
PIC16F913@SSOP28 [(SA626A)]
PIC16F913@SSOP28(ISP) [ISP-HEADER01]
PIC16F914 PIC16F914(ISP) [ISP-
HEADER01]
PIC16F914@QFN44 [(SA712)]
PIC16F914@QFN44(ISP) [ISP-HEADER01]
PIC16F914@QFN44(ML) [(SA737)]
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16F914@TQFP44 [(SA245A)]
PIC16F914@TQFP44(ISP) [ISP-HEADER01]
```

```

PIC16F916                                PIC16F916(ISP) [ISP-
HEADER01]
PIC16F916@QFN28 [(SA697-B006)]
PIC16F916@QFN28(ISP) [ISP-HEADER01]
PIC16F916@SOIC28 [(SA404)]
PIC16F916@SOIC28(ISP) [ISP-HEADER01]
PIC16F916@SSOP28 [(SA626A)]
PIC16F916@SSOP28(ISP) [ISP-HEADER01]
PIC16F917                                PIC16F917(ISP) [ISP-
HEADER01]
PIC16F917@QFN44 [(SA712)]
PIC16F917@QFN44(ISP) [ISP-HEADER01]
PIC16F917@QFN44(ML) [(SA737)]
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16F917@TQFP44 [(SA245A)]
PIC16F917@TQFP44(ISP) [ISP-HEADER01]
PIC16F946@TQFP64(ISP) [ISP-HEADER01]
PIC16HV540                                PIC16HV540@SOIC18
[(SA404)]
PIC16HV540@SSOP20 [(SA626A)]
PIC16HV610
PIC16HV610(ISP) [ISP-HEADER01]          PIC16HV610@QFN16
[(SA727)]
PIC16HV610@QFN16(ISP) [ISP-HEADER01]
PIC16HV610@SOIC14 [(SA602)]
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]
PIC16HV610@TSSOP14 [(SA026)]
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]
PIC16HV616                                PIC16HV616(ISP) [ISP-
HEADER01]
PIC16HV616@QFN16 [(SA727)]
PIC16HV616@QFN16(ISP) [ISP-HEADER01]
PIC16HV616@SOIC14 [(SA602)]
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]
PIC16HV616@TSSOP14 [(SA026)]
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]
PIC16HV785                                PIC16HV785(ISP) [ISP-
HEADER01]
PIC16HV785@QFN20 [(SA692)]
PIC16HV785@QFN20(ISP) [ISP-HEADER01]
PIC16HV785@SOIC20 [(SA404)]
PIC16HV785@SOIC20(ISP) [ISP-HEADER01]
PIC16HV785@SSOP20 [(SA626A)]

```

PIC16HV785@SSOP20 (ISP) [ISP-HEADER01]
 PIC16LC505 PIC16LC505@SOIC14
 [(SA602)]
 PIC16LC54A PIC16LC54A@SOIC18
 [(SA404)]
 PIC16LC54A@SSOP20 [(SA626A)]
 PIC16LC54C
 PIC16LC54C@SOIC18 [(SA404)] PIC16LC54C@SSOP20
 [(SA626A)]
 PIC16LC554 PIC16LC554 (ISP) [ISP-
 HEADER01]
 PIC16LC554@SOIC18 [(SA404)]
 PIC16LC554@SOIC18 (ISP) [ISP-HEADER01]
 PIC16LC558 PIC16LC558 (ISP) [ISP-
 HEADER01]
 PIC16LC558@SOIC18 [(SA404)]
 PIC16LC558@SOIC18 (ISP) [ISP-HEADER01]
 PIC16LC56A PIC16LC56A@SOIC18
 [(SA404)]
 PIC16LC56A@SSOP20 [(SA626A)]
 PIC16LC58A
 PIC16LC58A@SOIC18 [(SA404)] PIC16LC58A@SSOP20
 [(SA626A)]
 PIC16LC58B PIC16LC58B@SOIC18
 [(SA404)]
 PIC16LC58B@SSOP20 [(SA626A)]
 PIC16LC620
 PIC16LC620 (ISP) [ISP-HEADER01] PIC16LC620@SOIC18
 [(SA404)]
 PIC16LC620@SOIC18 (ISP) [ISP-HEADER01]
 PIC16LC620A PIC16LC620A (ISP) [ISP-
 HEADER01]
 PIC16LC620A@SOIC18 [(SA404)]
 PIC16LC620A@SOIC18 (ISP) [ISP-HEADER01]
 PIC16LC620A@SSOP20 [(SA626A)]
 PIC16LC620A@SSOP20 (ISP) [ISP-HEADER01]
 PIC16LC621A PIC16LC621A (ISP) [ISP-
 HEADER01]
 PIC16LC621A@SOIC18 [(SA404)]
 PIC16LC621A@SOIC18 (ISP) [ISP-HEADER01]
 PIC16LC621A@SSOP20 [(SA626A)]
 PIC16LC621A@SSOP20 (ISP) [ISP-HEADER01]
 PIC16LC622 PIC16LC622 (ISP) [ISP-

```
HEADER01 ]
PIC16LC622@SOIC18 [ (SA404) ]
PIC16LC622@SOIC18(ISP) [ ISP-HEADER01 ]
PIC16LC62A PIC16LC62A(ISP) [ ISP-
HEADER01 ]
PIC16LC62A@SOIC28 [ (SA404) ]
PIC16LC62A@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16LC62A@SSOP28 [ (SA626A) ]
PIC16LC62A@SSOP28(ISP) [ ISP-HEADER01 ]
PIC16LC62B PIC16LC62B(ISP) [ ISP-
HEADER01 ]
PIC16LC62B@SOIC28 [ (SA404) ]
PIC16LC62B@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16LC62B@SSOP28 [ (SA626A) ]
PIC16LC62B@SSOP28(ISP) [ ISP-HEADER01 ]
PIC16LC63 PIC16LC63(ISP) [ ISP-
HEADER01 ]
PIC16LC63@SOIC28 [ (SA404) ]
PIC16LC63@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16LC63A PIC16LC63A(ISP) [ ISP-
HEADER01 ]
PIC16LC63A@SOIC28 [ (SA404) ]
PIC16LC63A@SOIC28(ISP) [ ISP-HEADER01 ]
PIC16LC63A@SSOP28 [ (SA626A) ]
PIC16LC63A@SSOP28(ISP) [ ISP-HEADER01 ]
PIC16LC64A PIC16LC64A(ISP) [ ISP-
HEADER01 ]
PIC16LC64A@PLCC44 [ (SA244) ]
PIC16LC64A@PLCC44(ISP) [ ISP-HEADER01 ]
PIC16LC64A@TQFP44 [ (SA245A) ]
PIC16LC64A@TQFP44(ISP) [ ISP-HEADER01 ]
PIC16LC65A PIC16LC65A(ISP) [ ISP-
HEADER01 ]
PIC16LC65A@PLCC44 [ (SA244) ]
PIC16LC65A@PLCC44(ISP) [ ISP-HEADER01 ]
PIC16LC65A@TQFP44 [ (SA245A) ]
PIC16LC65A@TQFP44(ISP) [ ISP-HEADER01 ]
PIC16LC65B PIC16LC65B(ISP) [ ISP-
HEADER01 ]
PIC16LC65B@PLCC44 [ (SA244) ]
PIC16LC65B@PLCC44(ISP) [ ISP-HEADER01 ]
PIC16LC65B@TQFP44 [ (SA245A) ]
PIC16LC65B@TQFP44(ISP) [ ISP-HEADER01 ]
```

```
PIC16LC66 PIC16LC66(ISP) [ISP-  
HEADER01]  
PIC16LC66@SOIC28 [(SA404)]  
PIC16LC66@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC67 PIC16LC67(ISP) [ISP-  
HEADER01]  
PIC16LC67@PLCC44 [(SA244)]  
PIC16LC67@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC67@TQFP44 [(SA245A)]  
PIC16LC67@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC71 PIC16LC71(ISP) [ISP-  
HEADER01]  
PIC16LC71@SOIC18 [(SA404)]  
PIC16LC71@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC710 PIC16LC710(ISP) [ISP-  
HEADER01]  
PIC16LC710@SOIC18 [(SA404)]  
PIC16LC710@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC710@SSOP20 [(SA626A)]  
PIC16LC710@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC711 PIC16LC711(ISP) [ISP-  
HEADER01]  
PIC16LC711@SOIC18 [(SA404)]  
PIC16LC711@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC711@SSOP20 [(SA626A)]  
PIC16LC711@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC712 PIC16LC712(ISP) [ISP-  
HEADER01]  
PIC16LC712@SOIC18 [(SA404)]  
PIC16LC712@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC712@SSOP20 [(SA626A)]  
PIC16LC712@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC715 PIC16LC715@SOIC18  
[(SA404)]  
PIC16LC716 PIC16LC716(ISP) [ISP-  
HEADER01]  
PIC16LC716@SOIC18 [(SA404)]  
PIC16LC716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC716@SSOP20 [(SA626A)]  
PIC16LC716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC717 PIC16LC717(ISP) [ISP-  
HEADER01]  
PIC16LC717@SOIC18 [(SA404)]
```

PIC16LC717@SOIC18(ISP) [ISP-HEADER01]
PIC16LC717@SSOP20 [(SA626A)]
PIC16LC717@SSOP20(ISP) [ISP-HEADER01]
PIC16LC72 PIC16LC72(ISP) [ISP-
HEADER01]
PIC16LC72@SOIC28 [(SA404)]
PIC16LC72@SOIC28(ISP) [ISP-HEADER01]
PIC16LC72@SSOP28 [(SA626A)]
PIC16LC72@SSOP28(ISP) [ISP-HEADER01]
PIC16LC72A PIC16LC72A(ISP) [ISP-
HEADER01]
PIC16LC72A@SOIC28 [(SA404)]
PIC16LC72A@SOIC28(ISP) [ISP-HEADER01]
PIC16LC72A@SSOP28 [(SA626A)]
PIC16LC72A@SSOP28(ISP) [ISP-HEADER01]
PIC16LC73A PIC16LC73A(ISP) [ISP-
HEADER01]
PIC16LC73A@SOIC28 [(SA404)]
PIC16LC73A@SOIC28(ISP) [ISP-HEADER01]
PIC16LC73B PIC16LC73B(ISP) [ISP-
HEADER01]
PIC16LC73B@SOIC28 [(SA404)]
PIC16LC73B@SOIC28(ISP) [ISP-HEADER01]
PIC16LC73B@SSOP28 [(SA626A)]
PIC16LC73B@SSOP28(ISP) [ISP-HEADER01]
PIC16LC74 PIC16LC74(ISP) [ISP-
HEADER01]
PIC16LC74@PLCC44 [(SA244)]
PIC16LC74@PLCC44(ISP) [ISP-HEADER01]
PIC16LC74@TQFP44 [(SA245A)]
PIC16LC74@TQFP44(ISP) [ISP-HEADER01]
PIC16LC74A PIC16LC74A(ISP) [ISP-
HEADER01]
PIC16LC74A@PLCC44 [(SA244)]
PIC16LC74A@PLCC44(ISP) [ISP-HEADER01]
PIC16LC74A@TQFP44 [(SA245A)]
PIC16LC74A@TQFP44(ISP) [ISP-HEADER01]
PIC16LC74B PIC16LC74B(ISP) [ISP-
HEADER01]
PIC16LC74B@MQFP44 [(SA675)]
PIC16LC74B@MQFP44(ISP) [ISP-HEADER01]
PIC16LC74B@PLCC44 [(SA244)]
PIC16LC74B@PLCC44(ISP) [ISP-HEADER01]

PIC16LC74B@TQFP44 [(SA245A)]
PIC16LC74B@TQFP44(ISP) [ISP-HEADER01]
PIC16LC76 PIC16LC76(ISP) [ISP-
HEADER01]
PIC16LC76@SOIC28 [(SA404)]
PIC16LC76@SOIC28(ISP) [ISP-HEADER01]
PIC16LC77 PIC16LC77(ISP) [ISP-
HEADER01]
PIC16LC77@PLCC44 [(SA244)]
PIC16LC77@PLCC44(ISP) [ISP-HEADER01]
PIC16LC773 PIC16LC773(ISP) [ISP-
HEADER01]
PIC16LC773@SOIC28 [(SA404)]
PIC16LC773@SOIC28(ISP) [ISP-HEADER01]
PIC16LC773@SSOP28 [(SA626A)]
PIC16LC773@SSOP28(ISP) [ISP-HEADER01]
PIC16LC774 PIC16LC774(ISP) [ISP-
HEADER01]
PIC16LC774@PLCC44 [(SA244)]
PIC16LC774@PLCC44(ISP) [ISP-HEADER01]
PIC16LC774@TQFP44 [(SA675)]
PIC16LC774@TQFP44(ISP) [ISP-HEADER01]
PIC16LC84 PIC16LC84(ISP) [ISP-
HEADER01]
PIC16LC84@SOIC18 [(SA404)]
PIC16LC84@SOIC18(ISP) [ISP-HEADER01]
PIC16LC923@PLCC68(*) [(SA648-B6807)]
PIC16LC923@PLCC68(ISP) [ISP-HEADER01]
PIC16LC923@SDIP64(ISP) [ISP-HEADER01]
PIC16LC923@TQFP64(ISP) [ISP-HEADER01]
PIC16LC924@PLCC68(*) [(SA648-B6807)]
PIC16LC924@PLCC68(ISP) [ISP-HEADER01]
PIC16LC924@SDIP64(ISP) [ISP-HEADER01]
PIC16LC924@TQFP64(ISP) [ISP-HEADER01]
PIC16LC925@PLCC68(*) [(SA648-B6807)]
PIC16LC925@PLCC68(ISP) [ISP-HEADER01]
PIC16LC925@TQFP64(ISP) [ISP-HEADER01]
PIC16LC926@PLCC68(*) [(SA648-B6807)]
PIC16LC926@PLCC68(ISP) [ISP-HEADER01]
PIC16LC926@TQFP64(ISP) [ISP-HEADER01]
PIC16LCE623@SOIC18 [(SA404)]
PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]
PIC16LCE623@SSOP20 [(SA626A)]

```
PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]
PIC16LF505 PIC16LF505(ISP) [ISP-
HEADER01]
PIC16LF505@SOIC14 [(SA602)]
PIC16LF505@SOIC14(ISP) [ISP-HEADER01]
PIC16LF505@TSSOP14 [(SA026)]
PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]
PIC16LF506 PIC16LF506(ISP) [ISP-
HEADER01]
PIC16LF506@SOIC14 [(SA602)]
PIC16LF506@SOIC14(ISP) [ISP-HEADER01]
PIC16LF506@TSSOP14 [(SA026)]
PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]
PIC16LF526 PIC16LF526@SOIC14
[(SA602)]
PIC16LF526@TSSOP14 [(SA026)]
PIC16LF54 PIC16LF54@SOIC18
PIC16LF54(ISP) [ISP-HEADER01] [(SA404)]
PIC16LF54@SOIC18(ISP) [ISP-HEADER01]
PIC16LF54@SSOP20 [(SA626A)]
PIC16LF54@SSOP20(ISP) [ISP-HEADER01]
PIC16LF57 PIC16LF57(ISP) [ISP-
HEADER01]
PIC16LF57@SOIC28 [(SA404)]
PIC16LF57@SOIC28(ISP) [ISP-HEADER01]
PIC16LF57@SSOP28 [(SA626A)]
PIC16LF57@SSOP28(ISP) [ISP-HEADER01]
PIC16LF59 PIC16LF59(ISP) [ISP-
HEADER01]
PIC16LF59@PLCC44 [(SA244)]
PIC16LF59@PLCC44(ISP) [ISP-HEADER01]
PIC16LF59@TQFP44 [(SA245A)]
PIC16LF59@TQFP44(ISP) [ISP-HEADER01]
PIC16LF627 PIC16LF627(ISP) [ISP-
HEADER01]
PIC16LF627@SOIC18 [(SA404)]
PIC16LF627@SOIC18(ISP) [ISP-HEADER01]
PIC16LF627@SSOP20 [(SA626A)]
PIC16LF627@SSOP20(ISP) [ISP-HEADER01]
PIC16LF627A PIC16LF627A(ISP) [ISP-
HEADER01]
PIC16LF627A@SOIC18 [(SA404)]
```

PIC16LF627A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF627A@SSOP20 [(SA626A)]
PIC16LF627A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF628 PIC16LF628(ISP) [ISP-
HEADER01]
PIC16LF628@SOIC18 [(SA404)]
PIC16LF628@SOIC18(ISP) [ISP-HEADER01]
PIC16LF628@SSOP20 [(SA626A)]
PIC16LF628@SSOP20(ISP) [ISP-HEADER01]
PIC16LF628A PIC16LF628A(ISP) [ISP-
HEADER01]
PIC16LF628A@SOIC18 [(SA404)]
PIC16LF628A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF628A@SSOP20 [(SA626A)]
PIC16LF628A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF631 PIC16LF631(ISP) [ISP-
HEADER01]
PIC16LF631@QFN20 [(SA692)]
PIC16LF631@QFN20(ISP) [ISP-HEADER01]
PIC16LF631@SOIC20 [(SA404)]
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]
PIC16LF631@SSOP20 [(SA626A)]
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]
PIC16LF639 PIC16LF639(ISP) [ISP-
HEADER01]
PIC16LF639@QFN20 [(SA692)]
PIC16LF639@QFN20(ISP) [ISP-HEADER01]
PIC16LF639@SOIC20 [(SA404)]
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]
PIC16LF639@SSOP20 [(SA626A)]
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]
PIC16LF648A PIC16LF648A(ISP) [ISP-
HEADER01]
PIC16LF648A@SOIC18 [(SA404)]
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF648A@SSOP20 [(SA626A)]
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF677 PIC16LF677(ISP) [ISP-
HEADER01]
PIC16LF677@QFN20 [(SA692)]
PIC16LF677@QFN20(ISP) [ISP-HEADER01]
PIC16LF677@SOIC20 [(SA404)]
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]

PIC16LF677@SSOP20 [(SA626A)]
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]
PIC16LF685 PIC16LF685(ISP) [ISP-
HEADER01]
PIC16LF685@QFN20 [(SA692)]
PIC16LF685@QFN20(ISP) [ISP-HEADER01]
PIC16LF685@SOIC20 [(SA404)]
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]
PIC16LF685@SSOP20 [(SA626A)]
PIC16LF685@SSOP20(ISP) [ISP-HEADER01]
PIC16LF687 PIC16LF687(ISP) [ISP-
HEADER01]
PIC16LF687@QFN20 [(SA692)]
PIC16LF687@QFN20(ISP) [ISP-HEADER01]
PIC16LF687@SOIC20 [(SA404)]
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]
PIC16LF687@SSOP20 [(SA626A)]
PIC16LF687@SSOP20(ISP) [ISP-HEADER01]
PIC16LF689 PIC16LF689(ISP) [ISP-
HEADER01]
PIC16LF689@QFN20 [(SA692)]
PIC16LF689@QFN20(ISP) [ISP-HEADER01]
PIC16LF689@SOIC20 [(SA404)]
PIC16LF689@SOIC20(ISP) [ISP-HEADER01]
PIC16LF689@SSOP20 [(SA626A)]
PIC16LF689@SSOP20(ISP) [ISP-HEADER01]
PIC16LF690 PIC16LF690(ISP) [ISP-
HEADER01]
PIC16LF690@QFN20 [(SA692)]
PIC16LF690@QFN20(ISP) [ISP-HEADER01]
PIC16LF690@SOIC20 [(SA404)]
PIC16LF690@SOIC20(ISP) [ISP-HEADER01]
PIC16LF690@SSOP20 [(SA626A)]
PIC16LF690@SSOP20(ISP) [ISP-HEADER01]
PIC16LF716 PIC16LF716(ISP) [ISP-
HEADER01]
PIC16LF716@SOIC18 [(SA404)]
PIC16LF716@SOIC18(ISP) [ISP-HEADER01]
PIC16LF716@SSOP20 [(SA626A)]
PIC16LF716@SSOP20(ISP) [ISP-HEADER01]
PIC16LF72 PIC16LF72(ISP) [ISP-
HEADER01]
PIC16LF72@QFN28 [(SA685-B006)]

```

PIC16LF72@QFN28 (ISP) [ISP-HEADER01]
PIC16LF72@SOIC28 [(SA404)]
PIC16LF72@SOIC28 (ISP) [ISP-HEADER01]
PIC16LF72@SSOP28 [(SA626A)]
PIC16LF72@SSOP28 (ISP) [ISP-HEADER01]
PIC16LF722 PIC16LF722@QFN28 [(SA685-
B006)]
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28
[(SA626A)]
PIC16LF723 PIC16LF723@QFN28 [(SA685-
B006)]
PIC16LF723@SOIC28 [(SA404)] PIC16LF723@SSOP28
[(SA626A)]
PIC16LF724 PIC16LF724@QFN44
[(SA737)]
PIC16LF724@TQFP44 [(SA245A)]
PIC16LF726 PIC16LF726@SOIC28
PIC16LF726@QFN28 [(SA685-B006)] [(SA404)]
PIC16LF726@SSOP28 [(SA626A)]
PIC16LF727 PIC16LF727@TQFP44
PIC16LF727@QFN44 [(SA737)] [(SA245A)]
PIC16LF73 PIC16LF73 (ISP) [ISP-
HEADER01]
PIC16LF73@SOIC28 [(SA404)]
PIC16LF73@SOIC28 (ISP) [ISP-HEADER01]
PIC16LF73@SSOP28 [(SA626A)]
PIC16LF73@SSOP28 (ISP) [ISP-HEADER01]
PIC16LF737 PIC16LF737 (ISP) [ISP-
HEADER01]
PIC16LF737@SOIC28 [(SA404)]
PIC16LF737@SOIC28 (ISP) [ISP-HEADER01]
PIC16LF737@SSOP28 [(SA626A)]
PIC16LF737@SSOP28 (ISP) [ISP-HEADER01]
PIC16LF74 PIC16LF74 (ISP) [ISP-
HEADER01]
PIC16LF74@PLCC44 [(SA244)]
PIC16LF74@PLCC44 (ISP) [ISP-HEADER01]
PIC16LF74@TQFP44 [(SA245A)]
PIC16LF74@TQFP44 (ISP) [ISP-HEADER01]
PIC16LF747 PIC16LF747 (ISP) [ISP-
HEADER01]

```

PIC16LF747@TQFP44 [(SA245A)]
PIC16LF747@TQFP44(ISP) [ISP-HEADER01]
PIC16LF76 PIC16LF76(ISP) [ISP-
HEADER01]
PIC16LF76@SOIC28 [(SA404)]
PIC16LF76@SOIC28(ISP) [ISP-HEADER01]
PIC16LF76@SSOP28 [(SA626A)]
PIC16LF76@SSOP28(ISP) [ISP-HEADER01]
PIC16LF767 PIC16LF767(ISP) [ISP-
HEADER01]
PIC16LF767@SOIC28 [(SA404)]
PIC16LF767@SOIC28(ISP) [ISP-HEADER01]
PIC16LF767@SSOP28 [(SA626A)]
PIC16LF767@SSOP28(ISP) [ISP-HEADER01]
PIC16LF77 PIC16LF77(ISP) [ISP-
HEADER01]
PIC16LF77@PLCC44 [(SA244)]
PIC16LF77@PLCC44(ISP) [ISP-HEADER01]
PIC16LF77@TQFP44 [(SA245A)]
PIC16LF77@TQFP44(ISP) [ISP-HEADER01]
PIC16LF777 PIC16LF777(ISP) [ISP-
HEADER01]
PIC16LF777@TQFP44 [(SA245A)]
PIC16LF777@TQFP44(ISP) [ISP-HEADER01]
PIC16LF818 PIC16LF818(ISP) [ISP-
HEADER01]
PIC16LF818@QFN28 [(SA685-B006)]
PIC16LF818@QFN28(ISP) [ISP-HEADER01]
PIC16LF818@SOIC18 [(SA404)]
PIC16LF818@SOIC18(ISP) [ISP-HEADER01]
PIC16LF818@SSOP20 [(SA626A)]
PIC16LF818@SSOP20(ISP) [ISP-HEADER01]
PIC16LF819 PIC16LF819(ISP) [ISP-
HEADER01]
PIC16LF819@QFN28 [(SA685-B006)]
PIC16LF819@QFN28(ISP) [ISP-HEADER01]
PIC16LF819@SOIC18 [(SA404)]
PIC16LF819@SOIC18(ISP) [ISP-HEADER01]
PIC16LF819@SSOP20 [(SA626A)]
PIC16LF819@SSOP20(ISP) [ISP-HEADER01]
PIC16LF83 PIC16LF83(ISP) [ISP-
HEADER01]
PIC16LF83@SOIC18 [(SA404)]

PIC16LF83@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84 PIC16LF84(ISP) [ISP-
HEADER01]
PIC16LF84@SOIC18 [(SA404)]
PIC16LF84@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84A PIC16LF84A(ISP) [ISP-
HEADER01]
PIC16LF84A@SOIC18 [(SA404)]
PIC16LF84A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84A@SSOP20 [(SA626A)]
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF87 PIC16LF87(ISP) [ISP-
HEADER01]
PIC16LF87@QFN28 [(SA685-B006)]
PIC16LF87@QFN28(ISP) [ISP-HEADER01]
PIC16LF87@SOIC18 [(SA404)]
PIC16LF87@SOIC18(ISP) [ISP-HEADER01]
PIC16LF87@SSOP20 [(SA626A)]
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]
PIC16LF870 PIC16LF870(ISP) [ISP-
HEADER01]
PIC16LF870@SOIC28 [(SA404)]
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]
PIC16LF870@SSOP28 [(SA626A)]
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]
PIC16LF871 PIC16LF871(ISP) [ISP-
HEADER01]
PIC16LF871@PLCC44 [(SA244)]
PIC16LF871@PLCC44(ISP) [ISP-HEADER01]
PIC16LF871@TQFP44 [(SA245A)]
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]
PIC16LF872 PIC16LF872(ISP) [ISP-
HEADER01]
PIC16LF872@SOIC28 [(SA404)]
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]
PIC16LF872@SSOP28 [(SA626A)]
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]
PIC16LF873 PIC16LF873(ISP) [ISP-
HEADER01]
PIC16LF873@SOIC28 [(SA404)]
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]
PIC16LF873A
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]

PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@QFN28 [(SA697-B006)]
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@SOIC28 [(SA404)]
PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@SSOP28 [(SA626A)]
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874 PIC16LF874(ISP) [ISP-
HEADER01]
PIC16LF874@PLCC44 [(SA244)]
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]
PIC16LF874@TQFP44 [(SA245A)]
PIC16LF874@TQFP44(ISP) [ISP-HEADER01]
PIC16LF874A
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874A@PLCC44 [(SA244)]
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874A@TQFP44 [(SA245A)]
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876 PIC16LF876(ISP) [ISP-
HEADER01]
PIC16LF876@SOIC28 [(SA404)]
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]

PIC16LF876A

PIC16LF876A(ISP)(High-V) [ISP-HEADER01]

PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]

PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]

PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]

PIC16LF876A@QFN28 [(SA697-B006)]

PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]

PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]

PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]

PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]

PIC16LF876A@SOIC28 [(SA404)]

PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]

PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]

PIC16LF876A@SSOP28 [(SA626A)]

PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]

PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]

PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]

PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]

PIC16LF877 PIC16LF877(ISP) [ISP-HEADER01]

PIC16LF877@PLCC44 [(SA244)]

PIC16LF877@PLCC44(ISP) [ISP-HEADER01]

PIC16LF877@TQFP44 [(SA245A)]

PIC16LF877@TQFP44(ISP) [ISP-HEADER01]

PIC16LF877A

PIC16LF877A(ISP)(High-V) [ISP-HEADER01]

PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]

PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]

PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]

PIC16LF877A@PLCC44 [(SA244)]

PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]

PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]

PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]

PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]

PIC16LF877A@TQFP44 [(SA245A)]

PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]

PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]

PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]

PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]

PIC16LF88 PIC16LF88(ISP) [ISP-HEADER01]

PIC16LF88@QFN28 [(SA685-B006)]
PIC16LF88@QFN28(ISP) [ISP-HEADER01]
PIC16LF88@SOIC18 [(SA404)]
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]
PIC16LF88@SSOP20 [(SA626A)]
PIC16LF88@SSOP20(ISP) [ISP-HEADER01]
PIC16LF913 PIC16LF913(ISP) [ISP-
HEADER01]
PIC16LF913@QFN28 [(SA697-B006)]
PIC16LF913@QFN28(ISP) [ISP-HEADER01]
PIC16LF913@SOIC28 [(SA404)]
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]
PIC16LF913@SSOP28 [(SA626A)]
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]
PIC16LF914 PIC16LF914(ISP) [ISP-
HEADER01]
PIC16LF914@QFN44 [(SA712)]
PIC16LF914@QFN44(ISP) [ISP-HEADER01]
PIC16LF914@QFN44(ML) [(SA737)]
PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16LF914@TQFP44 [(SA245A)]
PIC16LF914@TQFP44(ISP) [ISP-HEADER01]
PIC16LF916 PIC16LF916(ISP) [ISP-
HEADER01]
PIC16LF916@QFN28 [(SA697-B006)]
PIC16LF916@QFN28(ISP) [ISP-HEADER01]
PIC16LF916@SOIC28 [(SA404)]
PIC16LF916@SOIC28(ISP) [ISP-HEADER01]
PIC16LF916@SSOP28 [(SA626A)]
PIC16LF916@SSOP28(ISP) [ISP-HEADER01]
PIC16LF917 PIC16LF917(ISP) [ISP-
HEADER01]
PIC16LF917@QFN44 [(SA712)]
PIC16LF917@QFN44(ISP) [ISP-HEADER01]
PIC16LF917@QFN44(ML) [(SA737)]
PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16LF917@TQFP44 [(SA245A)]
PIC16LF917@TQFP44(ISP) [ISP-HEADER01]
PIC16LF946@TQFP64(ISP) [ISP-HEADER01]
PIC16LV54A PIC16LV54A@SOIC18
[(SA404)]
PIC16LV54A@SSOP20 [(SA626A)]
PIC16LV58A

PIC16LV58A@SOIC18 [(SA404)]	PIC16LV58A@SSOP20
[(SA626A)]	
PIC18C242	PIC18C242@SOIC28
[(SA404)]	
PIC18C252	PIC18C252@SOIC28
[(SA404)]	
PIC18C442	PIC18C442@PLCC44
[(SA244)]	
PIC18C442@TQFP44 [(SA245A)]	
PIC18C452	
PIC18C452@PLCC44 [(SA244)]	PIC18C452@TQFP44
[(SA245A)]	
PIC18F1220	PIC18F1220(ISP) [ISP-
HEADER01]	
PIC18F1220@SOIC18 [(SA404)]	
PIC18F1220@SOIC18(ISP) [ISP-HEADER01]	
PIC18F1220@SSOP20 [(SA626A)]	
PIC18F1220@SSOP20(ISP) [ISP-HEADER01]	
PIC18F1230	PIC18F1230(ISP) [ISP-
HEADER01]	
PIC18F1230@QFN28 [(SA685-B006)]	
PIC18F1230@QFN28(ISP) [ISP-HEADER01]	
PIC18F1230@SOIC18 [(SA404)]	
PIC18F1230@SOIC18(ISP) [ISP-HEADER01]	
PIC18F1230@SSOP20 [(SA626A)]	
PIC18F1230@SSOP20(ISP) [ISP-HEADER01]	
PIC18F1320	PIC18F1320(ISP) [ISP-
HEADER01]	
PIC18F1320@SOIC18 [(SA404)]	
PIC18F1320@SOIC18(ISP) [ISP-HEADER01]	
PIC18F1320@SSOP20 [(SA626A)]	
PIC18F1320@SSOP20(ISP) [ISP-HEADER01]	
PIC18F1330	PIC18F1330(ISP) [ISP-
HEADER01]	
PIC18F1330@QFN28 [(SA685-B006)]	
PIC18F1330@QFN28(ISP) [ISP-HEADER01]	
PIC18F1330@SOIC18 [(SA404)]	
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]	
PIC18F1330@SSOP20 [(SA626A)]	
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]	
PIC18F1330-ICD@QFN28 [(SA685-B006)]	
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]	
PIC18F2220	PIC18F2220(ISP) [ISP-

```
HEADER01 ]
PIC18F2220@SOIC28 [(SA404)]
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]
PIC18F2221
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]
PIC18F2221@QFN28 [(SA685-B006)]
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2221@SOIC28 [(SA404)]
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2320 PIC18F2320(ISP) [ISP-
HEADER01]
PIC18F2320@SOIC28 [(SA404)]
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]
PIC18F2321
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]
PIC18F2321@QFN28 [(SA685-B006)]
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2321@SOIC28 [(SA404)]
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2331 PIC18F2331(ISP) [ISP-
HEADER01]
PIC18F2331@SOIC28 [(SA404)]
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]
PIC18F23K20
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@QFN28 [(SA685-B006)]
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@SOIC28 [(SA404)]
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@SSOP28 [(SA626A)]
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410@QFN28 [(SA685-B006)]
PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410@SOIC28 [(SA404)]
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F242 PIC18F242(ISP) [ISP-
HEADER01]
```

PIC18F242@SOIC28 [(SA404)]
PIC18F242@SOIC28(ISP) [ISP-HEADER01]
PIC18F2420
PIC18F2420(ISP)(High-V) [ISP-HEADER01]
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]
PIC18F2420@SOIC28 [(SA404)]
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423
PIC18F2423(ISP)(High-V) [ISP-HEADER01]
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423@QFN28 [(SA685-B006)]
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423@SOIC28 [(SA404)]
PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2431 PIC18F2431(ISP) [ISP-
HEADER01]
PIC18F2431@SOIC28 [(SA404)]
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]
PIC18F2439 PIC18F2439(ISP) [ISP-
HEADER01]
PIC18F2439@SOIC28 [(SA404)]
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]
PIC18F2450
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]
PIC18F2450@QFN28 [(SA685-B006)]
PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2450@SOIC28 [(SA404)]
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2455
PIC18F2455(ISP)(High-V) [ISP-HEADER01]
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]
PIC18F2455@SOIC28 [(SA404)]
PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458
PIC18F2458(ISP)(High-V) [ISP-HEADER01]
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458@SOIC28 [(SA404)]
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2458@SOIC28(ISP)(Low-V) [ISP-HEADER01]

```
PIC18F2458@SSOP28 [(SA626A)]
PIC18F2458@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2458@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F248                                PIC18F248(ISP) [ISP-
HEADER01]
PIC18F248@SOIC28 [(SA404)]
PIC18F248@SOIC28(ISP) [ISP-HEADER01]
PIC18F2480
PIC18F2480(ISP)(High-V) [ISP-HEADER01]
PIC18F2480(ISP)(Low-V) [ISP-HEADER01]
PIC18F2480@QFN28 [(SA685-B006)]
PIC18F2480@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2480@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2480@SOIC28 [(SA404)]
PIC18F2480@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24J10                               PIC18F24J10(ISP) [ISP-
HEADER01]
PIC18F24J10@QFN28 [(SA685-B006)]
PIC18F24J10@QFN28(ISP) [ISP-HEADER01]
PIC18F24J10@SOIC28 [(SA404)]
PIC18F24J10@SOIC28(ISP) [ISP-HEADER01]
PIC18F24J10@SSOP28 [(SA626A)]
PIC18F24J10@SSOP28(ISP) [ISP-HEADER01]
PIC18F24K20
PIC18F24K20(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@QFN28 [(SA685-B006)]
PIC18F24K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@SOIC28 [(SA404)]
PIC18F24K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@SSOP28 [(SA626A)]
PIC18F24K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2510                               PIC18F2510(ISP) [ISP-
HEADER01]
PIC18F2510@QFN28 [(SA685-B006)]
PIC18F2510@QFN28(ISP) [ISP-HEADER01]
PIC18F2510@SOIC28 [(SA404)]
PIC18F2510@SOIC28(ISP) [ISP-HEADER01]
PIC18F2515
```

```
PIC18F2515(ISP)(Low-V) [ISP-HEADER01]
PIC18F2515@SOIC28 [(SA404)]
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F252 PIC18F252(ISP) [ISP-
HEADER01]
PIC18F252@SOIC28 [(SA404)]
PIC18F252@SOIC28(ISP) [ISP-HEADER01]
PIC18F2520
PIC18F2520(ISP)(High-V) [ISP-HEADER01]
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]
PIC18F2520@SOIC28 [(SA404)]
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523
PIC18F2523(ISP)(High-V) [ISP-HEADER01]
PIC18F2523(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523@QFN28 [(SA685-B006)]
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523@SOIC28 [(SA404)]
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2525
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]
PIC18F2525@SOIC28 [(SA404)]
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2539 PIC18F2539(ISP) [ISP-
HEADER01]
PIC18F2539@SOIC28 [(SA404)]
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]
PIC18F2550
PIC18F2550(ISP)(High-V) [ISP-HEADER01]
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]
PIC18F2550@SOIC28 [(SA404)]
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553
PIC18F2553(ISP)(High-V) [ISP-HEADER01]
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553@SOIC28 [(SA404)]
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553@SSOP28 [(SA626A)]
```

PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F258 PIC18F258(ISP) [ISP-
HEADER01]
PIC18F258@SOIC28 [(SA404)]
PIC18F258@SOIC28(ISP) [ISP-HEADER01]
PIC18F2580
PIC18F2580(ISP)(High-V) [ISP-HEADER01]
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]
PIC18F2580@QFN28 [(SA685-B006)]
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2580@SOIC28 [(SA404)]
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585
PIC18F2585(ISP)(High-V) [ISP-HEADER01]
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585@SDIP28 [(SA022A)]
PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585@SOIC28 [(SA404)]
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25J10 PIC18F25J10(ISP) [ISP-
HEADER01]
PIC18F25J10@QFN28 [(SA685-B006)]
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]
PIC18F25J10@SOIC28 [(SA404)]
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]
PIC18F25J10@SSOP28 [(SA626A)]
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]
PIC18F25K20
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@QFN28 [(SA685-B006)]
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@SOIC28 [(SA404)]
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@SSOP28 [(SA626A)]
PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]

PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2610
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]
PIC18F2610@SOIC28 [(SA404)]
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2620
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]
PIC18F2620@SOIC28 [(SA404)]
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680
PIC18F2680(ISP)(High-V) [ISP-HEADER01]
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680@SDIP28 [(SA022A)]
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680@SOIC28 [(SA404)]
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682
PIC18F2682(ISP)(High-V) [ISP-HEADER01]
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682@QFN28 [(SA685)]
PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682@SOIC28 [(SA404)]
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685
PIC18F2685(ISP)(High-V) [ISP-HEADER01]
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685@QFN28 [(SA685)]
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685@SOIC28 [(SA404)]
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20
PIC18F26K20(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@QFN28 [(SA685-B006)]
PIC18F26K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@SOIC28 [(SA404)]

```
PIC18F26K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@SSOP28 [(SA626A)]
PIC18F26K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F4220 PIC18F4220(ISP) [ISP-
HEADER01]
PIC18F4220@QFN44 [(SA712)]
PIC18F4220@QFN44(ISP) [ISP-HEADER01]
PIC18F4220@QFN44(ML) [(SA737)]
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4220@TQFP44 [(SA245A)]
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]
PIC18F4221
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@QFN44 [(SA712)]
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@QFN44(ML) [(SA737)]
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@TQFP44 [(SA245A)]
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4320 PIC18F4320(ISP) [ISP-
HEADER01]
PIC18F4320@QFN44 [(SA712)]
PIC18F4320@QFN44(ISP) [ISP-HEADER01]
PIC18F4320@QFN44(ML) [(SA737)]
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4320@TQFP44 [(SA245A)]
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]
PIC18F4321
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@QFN44 [(SA712)]
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@QFN44(ML) [(SA737)]
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@TQFP44 [(SA245A)]
PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4331(ISP) [ISP-HEADER01]
PIC18F4331@TQFP44(ISP) [ISP-HEADER01]
PIC18F43K20
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F43K20@QFN44 [(SA712)]
```

PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ML) [(SA737)]
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F43K20@TQFP44 [(SA245A)]
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410
PIC18F4410(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@QFN44 [(SA712)]
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@QFN44(ML) [(SA737)]
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@TQFP44 [(SA245A)]
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F442 PIC18F442(ISP) [ISP-
HEADER01]
PIC18F442@PLCC44 [(SA244)]
PIC18F442@PLCC44(ISP) [ISP-HEADER01]
PIC18F442@TQFP44 [(SA245A)]
PIC18F442@TQFP44(ISP) [ISP-HEADER01]
PIC18F4420
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@QFN44 [(SA712)]
PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@QFN44(ML) [(SA737)]
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@TQFP44 [(SA245A)]
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423
PIC18F4423(ISP)(High-V) [ISP-HEADER01]
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@QFN44 [(SA712)]
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@QFN44(ML) [(SA737)]
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@TQFP44 [(SA245A)]
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4431(ISP) [ISP-HEADER01]

PIC18F4431@TQFP44(ISP) [ISP-HEADER01]
PIC18F4439(ISP) [ISP-HEADER01]
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]
PIC18F4450
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@QFN44 [(SA712)]
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@QFN44(ML) [(SA737)]
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@TQFP44 [(SA245A)]
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455
PIC18F4455(ISP)(High-V) [ISP-HEADER01]
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@QFN44 [(SA712)]
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@QFN44(ML) [(SA737)]
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@TQFP44 [(SA245A)]
PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458
PIC18F4458(ISP)(High-V) [ISP-HEADER01]
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458@QFN44 [(SA737)]
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458@TQFP44 [(SA245A)]
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F448 PIC18F448(ISP) [ISP-
HEADER01]
PIC18F448@PLCC44 [(SA244)]
PIC18F448@PLCC44(ISP) [ISP-HEADER01]
PIC18F448@TQFP44 [(SA245A)]
PIC18F448@TQFP44(ISP) [ISP-HEADER01]
PIC18F4480
PIC18F4480(ISP)(High-V) [ISP-HEADER01]
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@QFN44 [(SA712)]
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]

PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@QFN44(ML) [(SA737)]
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@TQFP44 [(SA245A)]
PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F44J10(ISP) [ISP-HEADER01]
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]
PIC18F44K20
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F44K20@QFN44 [(SA712)]
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ML) [(SA737)]
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F44K20@TQFP44 [(SA245A)]
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4510 PIC18F4510(ISP) [ISP-
HEADER01]
PIC18F4510@QFN44 [(SA712)]
PIC18F4510@QFN44(ISP) [ISP-HEADER01]
PIC18F4510@QFN44(ML) [(SA737)]
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4510@TQFP44 [(SA245A)]
PIC18F4510@TQFP44(ISP) [ISP-HEADER01]
PIC18F4515
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@QFN44 [(SA712)]
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@QFN44(ML) [(SA737)]
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@TQFP44 [(SA245A)]
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F452 PIC18F452(ISP) [ISP-
HEADER01]
PIC18F452@PLCC44 [(SA244)]
PIC18F452@PLCC44(ISP) [ISP-HEADER01]

PIC18F452@TQFP44 [(SA245A)]
PIC18F452@TQFP44(ISP) [ISP-HEADER01]
PIC18F4520 PIC18F4520(ISP) [ISP-
HEADER01]
PIC18F4520@QFN44 [(SA712)]
PIC18F4520@QFN44(ISP) [ISP-HEADER01]
PIC18F4520@QFN44(ML) [(SA737)]
PIC18F4520@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4520@TQFP44 [(SA245A)]
PIC18F4520@TQFP44(ISP) [ISP-HEADER01]
PIC18F4523
PIC18F4523(ISP)(High-V) [ISP-HEADER01]
PIC18F4523(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@QFN44 [(SA712)]
PIC18F4523@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4523@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@QFN44(ML) [(SA737)]
PIC18F4523@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4523@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@TQFP44 [(SA245A)]
PIC18F4523@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4523@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525
PIC18F4525(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525@QFN44 [(SA712)]
PIC18F4525@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525@QFN44(ML) [(SA737)]
PIC18F4525@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525@TQFP44 [(SA245A)]
PIC18F4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4539(ISP) [ISP-HEADER01]
PIC18F4539@TQFP44(ISP) [ISP-HEADER01]
PIC18F4550
PIC18F4550(ISP)(High-V) [ISP-HEADER01]
PIC18F4550(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@QFN44 [(SA712)]
PIC18F4550@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4550@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@QFN44(ML) [(SA737)]
PIC18F4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4550@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@TQFP44 [(SA245A)]
PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]

PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553
PIC18F4553(ISP)(High-V) [ISP-HEADER01]
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553@QFN44 [(SA737)]
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553@TQFP44 [(SA245A)]
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F458 PIC18F458(ISP) [ISP-
HEADER01]
PIC18F458@PLCC44 [(SA244)]
PIC18F458@PLCC44(ISP) [ISP-HEADER01]
PIC18F458@TQFP44 [(SA245A)]
PIC18F458@TQFP44(ISP) [ISP-HEADER01]
PIC18F4580
PIC18F4580(ISP)(High-V) [ISP-HEADER01]
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@QFN44 [(SA712)]
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@QFN44(ML) [(SA737)]
PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@TQFP44 [(SA245A)]
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585
PIC18F4585(ISP)(High-V) [ISP-HEADER01]
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@QFN44 [(SA712)]
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@QFN44(ML) [(SA737)]
PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@TQFP44 [(SA245A)]
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F45J10(ISP) [ISP-HEADER01]
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]

PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]
PIC18F45K20
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F45K20@QFN44 [(SA712)]
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ML) [(SA737)]
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F45K20@TQFP44 [(SA245A)]
PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@QFN44 [(SA712)]
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@QFN44(ML) [(SA737)]
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@TQFP44 [(SA245A)]
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@QFN44 [(SA712)]
PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@QFN44(ML) [(SA737)]
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@TQFP44 [(SA245A)]
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680
PIC18F4680(ISP)(High-V) [ISP-HEADER01]
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@QFN44 [(SA712)]
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@QFN44(ML) [(SA737)]
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@TQFP44 [(SA245A)]
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682
PIC18F4682(ISP)(High-V) [ISP-HEADER01]

PIC18F4682(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@QFN44 [(SA712)]
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@QFN44(ML) [(SA737)]
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@TQFP44 [(SA245A)]
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685
PIC18F4685(ISP)(High-V) [ISP-HEADER01]
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@QFN44 [(SA712)]
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@QFN44(ML) [(SA737)]
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@TQFP44 [(SA245A)]
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20
PIC18F46K20(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20@QFN44 [(SA712)]
PIC18F46K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ML) [(SA737)]
PIC18F46K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F46K20@TQFP44 [(SA245A)]
PIC18F46K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]
PIC18F6393@TQFP64(ISP) [ISP-HEADER01]
PIC18F63J11@TQFP64(*) [(SA732+B340)]
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F63J90@TQFP64(*) [(SA732+B340)]
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]

PIC18F6493@TQFP64(ISP) [ISP-HEADER01]
PIC18F64J11@TQFP64(*) [(SA732+B340)]
PIC18F64J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F64J90@TQFP64(*) [(SA732+B340)]
PIC18F64J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6520@TQFP64(ISP) [ISP-HEADER01]
PIC18F6525@TQFP64(ISP) [ISP-HEADER01]
PIC18F6527@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6585@PLCC68(ISP) [ISP-HEADER01]
PIC18F6585@TQFP64(ISP) [ISP-HEADER01]
PIC18F65J10@TQFP64(*) [(SA732+B340)]
PIC18F65J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F65J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F65J11@TQFP64(*) [(SA732+B340)]
PIC18F65J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F65J15@TQFP64(*) [(SA732+B340)]
PIC18F65J15@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F65J15@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F65J50@TQFP64(*) [(SA732+B340)]
PIC18F65J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F65J90@TQFP64(*) [(SA732+B340)]
PIC18F65J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6620@TQFP64(ISP) [ISP-HEADER01]
PIC18F6621@TQFP64(ISP) [ISP-HEADER01]
PIC18F6622@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6627@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6680@PLCC68(ISP) [ISP-HEADER01]
PIC18F6680@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J10@TQFP64(*) [(SA732+B340)]
PIC18F66J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F66J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F66J11@TQFP64(*) [(SA732+B340)]
PIC18F66J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J15@TQFP64(*) [(SA732+B340)]
PIC18F66J15@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F66J15@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F66J16@TQFP64(*) [(SA732+B340)]
PIC18F66J16@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J50@TQFP64(*) [(SA732+B340)]
PIC18F66J50@TQFP64(ISP) [ISP-HEADER01]

PIC18F66J55@TQFP64(*) [(SA732+B340)]
PIC18F66J55@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J60@TQFP64(*) [(SA732+B340)]
PIC18F66J60@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J65@TQFP64(*) [(SA732+B340)]
PIC18F66J65@TQFP64(ISP) [ISP-HEADER01]
PIC18F6720@TQFP64(ISP) [ISP-HEADER01]
PIC18F6722@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F67J10@TQFP64(*) [(SA732+B340)]
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F67J11@TQFP64(*) [(SA732+B340)]
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J50@TQFP64(*) [(SA732+B340)]
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J60@TQFP64(*) [(SA732+B340)]
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]
PIC18F8390@TQFP80(ISP) [ISP-HEADER01]
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8520@TQFP80(ISP) [ISP-HEADER01]
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]

```

PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J55@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J60@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J65@TQFP80(ISP) [ISP-HEADER01]
PIC18F8720@TQFP80(ISP) [ISP-HEADER01]
PIC18F8722@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F87J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F87J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F87J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F87J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F87J60@TQFP80(ISP) [ISP-HEADER01]
PIC18F96J60@TQFP100(ISP) [ISP-HEADER01]
PIC18F96J65@TQFP100(ISP) [ISP-HEADER01]
PIC18F97J60@TQFP100(ISP) [ISP-HEADER01]
PIC18LC452 PIC18LC452@PLCC44
[(SA244)]
PIC18LC452@TQFP44 [(SA245A)]
PIC18LF1220
PIC18LF1220(ISP) [ISP-HEADER01] PIC18LF1220@SOIC18
[(SA404)]
PIC18LF1220@SOIC18(ISP) [ISP-HEADER01]
PIC18LF1220@SSOP20 [(SA626A)]
PIC18LF1220@SSOP20(ISP) [ISP-HEADER01]
PIC18LF1320 PIC18LF1320(ISP) [ISP-
HEADER01]
PIC18LF1320@SOIC18 [(SA404)]
PIC18LF1320@SOIC18(ISP) [ISP-HEADER01]
PIC18LF1320@SSOP20 [(SA626A)]
PIC18LF1320@SSOP20(ISP) [ISP-HEADER01]
PIC18LF2220 PIC18LF2220(ISP) [ISP-
HEADER01]
PIC18LF2220@SOIC28 [(SA404)]

```

PIC18LF2220@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2221
PIC18LF2221(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2221@QFN28 [(SA685-B006)]
PIC18LF2221@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2221@SOIC28 [(SA404)]
PIC18LF2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2320 PIC18LF2320(ISP) [ISP-
HEADER01]
PIC18LF2320@SOIC28 [(SA404)]
PIC18LF2320@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2321
PIC18LF2321(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2321@QFN28 [(SA685-B006)]
PIC18LF2321@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2321@SOIC28 [(SA404)]
PIC18LF2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2331 PIC18LF2331(ISP) [ISP-
HEADER01]
PIC18LF2331@SOIC28 [(SA404)]
PIC18LF2331@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2410
PIC18LF2410(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2410@QFN28 [(SA685-B006)]
PIC18LF2410@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2410@SOIC28 [(SA404)]
PIC18LF2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF242 PIC18LF242(ISP) [ISP-
HEADER01]
PIC18LF242@SOIC28 [(SA404)]
PIC18LF242@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2420
PIC18LF2420(ISP)(High-V) [ISP-HEADER01]
PIC18LF2420(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2420@SOIC28 [(SA404)]
PIC18LF2420@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2431 PIC18LF2431(ISP) [ISP-
HEADER01]
PIC18LF2431@SOIC28 [(SA404)]
PIC18LF2431@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2439 PIC18LF2439(ISP) [ISP-
HEADER01]

```
PIC18LF2439@SOIC28 [(SA404)]
PIC18LF2439@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2450
PIC18LF2450(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2450@QFN28 [(SA685-B006)]
PIC18LF2450@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2450@SOIC28 [(SA404)]
PIC18LF2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2455
PIC18LF2455(ISP)(High-V) [ISP-HEADER01]
PIC18LF2455(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2455@SOIC28 [(SA404)]
PIC18LF2455@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF248 PIC18LF248(ISP) [ISP-
HEADER01]
PIC18LF248@SOIC28 [(SA404)]
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2480
PIC18LF2480(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2480@QFN28 [(SA685-B006)]
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2480@SOIC28 [(SA404)]
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF24J10 PIC18LF24J10(ISP) [ISP-
HEADER01]
PIC18LF24J10@QFN28 [(SA685-B006)]
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]
PIC18LF24J10@SOIC28 [(SA404)]
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]
PIC18LF24J10@SSOP28 [(SA626A)]
PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]
PIC18LF2510 PIC18LF2510(ISP) [ISP-
HEADER01]
PIC18LF2510@QFN28 [(SA685-B006)]
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]
PIC18LF2510@SOIC28 [(SA404)]
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2515
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]
```

PIC18LF2515@SOIC28 [(SA404)]
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF252 PIC18LF252(ISP) [ISP-
HEADER01]
PIC18LF252@SOIC28 [(SA404)]
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2520
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2520@SOIC28 [(SA404)]
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2525
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2525@SOIC28 [(SA404)]
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2539 PIC18LF2539(ISP) [ISP-
HEADER01]
PIC18LF2539@SOIC28 [(SA404)]
PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2550
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2550@SOIC28 [(SA404)]
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF258 PIC18LF258(ISP) [ISP-
HEADER01]
PIC18LF258@SOIC28 [(SA404)]
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2580
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2580@QFN28 [(SA685-B006)]
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2580@SOIC28 [(SA404)]
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585@SDIP28 [(SA022A)]

PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585@SOIC28 [(SA404)]
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF25J10 PIC18LF25J10(ISP) [ISP-
HEADER01]
PIC18LF25J10@QFN28 [(SA685-B006)]
PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]
PIC18LF25J10@SOIC28 [(SA404)]
PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]
PIC18LF25J10@SSOP28 [(SA626A)]
PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]
PIC18LF2610
PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2610@SOIC28 [(SA404)]
PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2620
PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2620@SOIC28 [(SA404)]
PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680
PIC18LF2680(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680@SDIP28 [(SA022A)]
PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680@SOIC28 [(SA404)]
PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682
PIC18LF2682(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682@QFN28 [(SA685)]
PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682@SOIC28 [(SA404)]
PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685
PIC18LF2685(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685@QFN28 [(SA685)]

PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685@SOIC28 [(SA404)]
PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4220 PIC18LF4220(ISP) [ISP-
HEADER01]
PIC18LF4220@QFN44 [(SA712)]
PIC18LF4220@QFN44(ISP) [ISP-HEADER01]
PIC18LF4220@QFN44(ML) [(SA737)]
PIC18LF4220@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4220@TQFP44 [(SA245A)]
PIC18LF4220@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4221
PIC18LF4221(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4221@QFN44 [(SA712)]
PIC18LF4221@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4221@QFN44(ML) [(SA737)]
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4221@TQFP44 [(SA245A)]
PIC18LF4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4320 PIC18LF4320(ISP) [ISP-
HEADER01]
PIC18LF4320@QFN44 [(SA712)]
PIC18LF4320@QFN44(ISP) [ISP-HEADER01]
PIC18LF4320@QFN44(ML) [(SA737)]
PIC18LF4320@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4320@TQFP44 [(SA245A)]
PIC18LF4320@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4321
PIC18LF4321(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4321@QFN44 [(SA712)]
PIC18LF4321@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4321@QFN44(ML) [(SA737)]
PIC18LF4321@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4321@TQFP44 [(SA245A)]
PIC18LF4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4331(ISP) [ISP-HEADER01]
PIC18LF4331@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4410
PIC18LF4410(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4410@QFN44 [(SA712)]
PIC18LF4410@QFN44(ISP)(Low-V) [ISP-HEADER01]

PIC18LF4410@QFN44(ML) [(SA737)]
PIC18LF4410@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4410@TQFP44 [(SA245A)]
PIC18LF4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF442 PIC18LF442(ISP) [ISP-
HEADER01]
PIC18LF442@PLCC44 [(SA244)]
PIC18LF442@PLCC44(ISP) [ISP-HEADER01]
PIC18LF442@TQFP44 [(SA245A)]
PIC18LF442@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4420
PIC18LF4420(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4420@QFN44 [(SA712)]
PIC18LF4420@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4420@QFN44(ML) [(SA737)]
PIC18LF4420@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4420@TQFP44 [(SA245A)]
PIC18LF4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4431(ISP) [ISP-HEADER01]
PIC18LF4431@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4439(ISP) [ISP-HEADER01]
PIC18LF4439@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4450
PIC18LF4450(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4450@QFN44 [(SA712)]
PIC18LF4450@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4450@QFN44(ML) [(SA737)]
PIC18LF4450@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4450@TQFP44 [(SA245A)]
PIC18LF4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455
PIC18LF4455(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455@QFN44 [(SA712)]
PIC18LF4455@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ML) [(SA737)]
PIC18LF4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4455@TQFP44 [(SA245A)]
PIC18LF4455@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF448 PIC18LF448(ISP) [ISP-

```

HEADER01 ]
PIC18LF448@PLCC44 [ (SA244) ]
PIC18LF448@PLCC44(ISP) [ ISP-HEADER01 ]
PIC18LF448@TQFP44 [ (SA245A) ]
PIC18LF448@TQFP44(ISP) [ ISP-HEADER01 ]
PIC18LF4480
PIC18LF4480(ISP)(High-V) [ ISP-HEADER01 ]
PIC18LF4480(ISP)(Low-V) [ ISP-HEADER01 ]
PIC18LF4480@QFN44 [ (SA712) ]
PIC18LF4480@QFN44(ISP)(High-V) [ ISP-HEADER01 ]
PIC18LF4480@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]
PIC18LF4480@QFN44(ML) [ (SA737) ]
PIC18LF4480@QFN44(ML)(ISP)(H-V) [ ISP-HEADER01 ]
PIC18LF4480@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]
PIC18LF4480@TQFP44 [ (SA245A) ]
PIC18LF4480@TQFP44(ISP)(High-V) [ ISP-HEADER01 ]
PIC18LF4480@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]
PIC18LF44J10(ISP) [ ISP-HEADER01 ]
PIC18LF44J10@QFN44(ISP) [ ISP-HEADER01 ]
PIC18LF44J10@QFN44(ML)(ISP) [ ISP-HEADER01 ]
PIC18LF44J10@TQFP44(ISP) [ ISP-HEADER01 ]
PIC18LF4510 PIC18LF4510(ISP) [ ISP-
HEADER01 ]
PIC18LF4510@QFN44 [ (SA712) ]
PIC18LF4510@QFN44(ISP) [ ISP-HEADER01 ]
PIC18LF4510@QFN44(ML) [ (SA737) ]
PIC18LF4510@QFN44(ML)(ISP) [ ISP-HEADER01 ]
PIC18LF4510@TQFP44 [ (SA245A) ]
PIC18LF4510@TQFP44(ISP) [ ISP-HEADER01 ]
PIC18LF4515
PIC18LF4515(ISP)(Low-V) [ ISP-HEADER01 ]
PIC18LF4515@QFN44 [ (SA712) ]
PIC18LF4515@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]
PIC18LF4515@QFN44(ML) [ (SA737) ]
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]
PIC18LF4515@TQFP44 [ (SA245A) ]
PIC18LF4515@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]
PIC18LF452 PIC18LF452(ISP) [ ISP-
HEADER01 ]
PIC18LF452@PLCC44 [ (SA244) ]
PIC18LF452@PLCC44(ISP) [ ISP-HEADER01 ]
PIC18LF452@TQFP44 [ (SA245A) ]
PIC18LF452@TQFP44(ISP) [ ISP-HEADER01 ]

```

PIC18LF4520 PIC18LF4520 (ISP) [ISP-
HEADER01]
PIC18LF4520@QFN44 [(SA712)]
PIC18LF4520@QFN44 (ISP) [ISP-HEADER01]
PIC18LF4520@QFN44 (ML) [(SA737)]
PIC18LF4520@QFN44 (ML) (ISP) [ISP-HEADER01]
PIC18LF4520@TQFP44 [(SA245A)]
PIC18LF4520@TQFP44 (ISP) [ISP-HEADER01]
PIC18LF4525
PIC18LF4525 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4525@QFN44 [(SA712)]
PIC18LF4525@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4525@QFN44 (ML) [(SA737)]
PIC18LF4525@QFN44 (ML) (ISP) (L-V) [ISP-HEADER01]
PIC18LF4525@TQFP44 [(SA245A)]
PIC18LF4525@TQFP44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4539 (ISP) [ISP-HEADER01]
PIC18LF4539@TQFP44 (ISP) [ISP-HEADER01]
PIC18LF4550
PIC18LF4550 (ISP) (High-V) [ISP-HEADER01]
PIC18LF4550 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4550@QFN44 [(SA712)]
PIC18LF4550@QFN44 (ISP) (High-V) [ISP-HEADER01]
PIC18LF4550@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4550@QFN44 (ML) [(SA737)]
PIC18LF4550@QFN44 (ML) (ISP) (H-V) [ISP-HEADER01]
PIC18LF4550@QFN44 (ML) (ISP) (L-V) [ISP-HEADER01]
PIC18LF4550@TQFP44 [(SA245A)]
PIC18LF4550@TQFP44 (ISP) (High-V) [ISP-HEADER01]
PIC18LF4550@TQFP44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF458 PIC18LF458 (ISP) [ISP-
HEADER01]
PIC18LF458@PLCC44 [(SA244)]
PIC18LF458@PLCC44 (ISP) [ISP-HEADER01]
PIC18LF458@TQFP44 [(SA245A)]
PIC18LF458@TQFP44 (ISP) [ISP-HEADER01]
PIC18LF4580
PIC18LF4580 (ISP) (High-V) [ISP-HEADER01]
PIC18LF4580 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4580@QFN44 [(SA712)]
PIC18LF4580@QFN44 (ISP) (High-V) [ISP-HEADER01]
PIC18LF4580@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4580@QFN44 (ML) [(SA737)]

PIC18LF4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4580@TQFP44 [(SA245A)]
PIC18LF4580@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585
PIC18LF4585(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585@QFN44 [(SA712)]
PIC18LF4585@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ML) [(SA737)]
PIC18LF4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4585@TQFP44 [(SA245A)]
PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF45J10(ISP) [ISP-HEADER01]
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4610
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4610@QFN44 [(SA712)]
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4610@QFN44(ML) [(SA737)]
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4610@TQFP44 [(SA245A)]
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620@QFN44 [(SA712)]
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620@QFN44(ML) [(SA737)]
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4620@TQFP44 [(SA245A)]
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680@QFN44 [(SA712)]
PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]

PIC18LF4680@QFN44(ML) [(SA737)]
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4680@TQFP44 [(SA245A)]
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682@QFN44 [(SA712)]
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ML) [(SA737)]
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4682@TQFP44 [(SA245A)]
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685@QFN44 [(SA712)]
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ML) [(SA737)]
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4685@TQFP44 [(SA245A)]
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6390@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6393@TQFP64(ISP) [ISP-HEADER01]
PIC18LF63J11@TQFP64(*) [(SA732+B340)]
PIC18LF63J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF63J90@TQFP64(*) [(SA732+B340)]
PIC18LF63J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6410@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6490@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6493@TQFP64(ISP) [ISP-HEADER01]
PIC18LF64J11@TQFP64(*) [(SA732+B340)]
PIC18LF64J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF64J90@TQFP64(*) [(SA732+B340)]

PIC18LF64J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6520@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6525@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6527@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6585@PLCC68(ISP) [ISP-HEADER01]
PIC18LF6585@TQFP64(ISP) [ISP-HEADER01]
PIC18LF65J11@TQFP64(*) [(SA732+B340)]
PIC18LF65J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF65J90@TQFP64(*) [(SA732+B340)]
PIC18LF65J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6620@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6621@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6622@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6627@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6680@PLCC68(ISP) [ISP-HEADER01]
PIC18LF6680@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6720@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6722@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8310@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8390@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8393@TQFP80(ISP) [ISP-HEADER01]
PIC18LF83J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF83J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8410@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8490@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8493@TQFP80(ISP) [ISP-HEADER01]
PIC18LF84J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF84J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8520@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8525@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8527@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8585@TQFP80(ISP) [ISP-HEADER01]
PIC18LF85J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF85J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8620@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]

PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC30F2010 PIC30F2010(ISP) [ISP-
HEADER01]
PIC30F2010@SDIP28 [(SA022A)]
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]
PIC30F2010@SOIC28 [(SA404)]
PIC30F2010@SOIC28(ISP) [ISP-HEADER01]
PIC30F2011(ISP) [ISP-HEADER01]
PIC30F2011@QFN28(ISP) [ISP-HEADER01]
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]
PIC30F2012(ISP) [ISP-HEADER01]
PIC30F2012@QFN28(ISP) [ISP-HEADER01]
PIC30F2012@SDIP28(ISP) [ISP-HEADER01]
PIC30F2012@SOIC28(ISP) [ISP-HEADER01]
PIC30F3010(ISP) [ISP-HEADER01]
PIC30F3010@QFN44(ISP) [ISP-HEADER01]
PIC30F3010@SDIP28(ISP) [ISP-HEADER01]
PIC30F3010@SOIC28(ISP) [ISP-HEADER01]
PIC30F3011(ISP) [ISP-HEADER01]
PIC30F3011@QFN44(ISP) [ISP-HEADER01]
PIC30F3011@QFP44(ISP) [ISP-HEADER01]
PIC30F3012(ISP) [ISP-HEADER01]
PIC30F3012@QFN44(ISP) [ISP-HEADER01]
PIC30F3012@QFP44(ISP) [ISP-HEADER01]
PIC30F3012@SDIP18(ISP) [ISP-HEADER01]
PIC30F3012@SOIC18(ISP) [ISP-HEADER01]
PIC30F3013(ISP) [ISP-HEADER01]
PIC30F3013@QFN44(ISP) [ISP-HEADER01]
PIC30F3013@QFP44(ISP) [ISP-HEADER01]
PIC30F3013@SDIP28(ISP) [ISP-HEADER01]
PIC30F3013@SOIC28(ISP) [ISP-HEADER01]
PIC30F3014(ISP) [ISP-HEADER01]
PIC30F3014@QFN44(ISP) [ISP-HEADER01]
PIC30F3014@QFP44(ISP) [ISP-HEADER01]
PIC30F4011(ISP) [ISP-HEADER01]
PIC30F4011@QFN44(ISP) [ISP-HEADER01]
PIC30F4011@QFP44(ISP) [ISP-HEADER01]

PIC30F4012(ISP) [ISP-HEADER01]
 PIC30F4012@QFN44(ISP) [ISP-HEADER01]
 PIC30F4012@SDIP28(ISP) [ISP-HEADER01]
 PIC30F4012@SOIC28(ISP) [ISP-HEADER01]
 PIC30F4013(ISP) [ISP-HEADER01]
 PIC30F4013@QFN44(ISP) [ISP-HEADER01]
 PIC30F4013@QFP44(ISP) [ISP-HEADER01]
 PIC30F5011@QFP64(ISP) [ISP-HEADER01]
 PIC30F5013@QFP80(ISP) [ISP-HEADER01]
 PIC30F5015@QFP64(ISP) [ISP-HEADER01]
 PIC30F5016@QFP80(ISP) [ISP-HEADER01]
 PIC30F6010@QFP80(ISP) [ISP-HEADER01]
 PIC30F6010@TQFP80(ISP) [ISP-HEADER01]
 PIC30F6010A@QFP80(ISP) [ISP-HEADER01]
 PIC30F6010A@TQFP80(ISP) [ISP-HEADER01]
 PIC30F6011@QFP64(ISP) [ISP-HEADER01]
 PIC30F6011A@QFP64(ISP) [ISP-HEADER01]
 PIC30F6012@QFP64(ISP) [ISP-HEADER01]
 PIC30F6012A@QFP64(ISP) [ISP-HEADER01]
 PIC30F6013@QFP80(ISP) [ISP-HEADER01]
 PIC30F6013A@QFP80(ISP) [ISP-HEADER01]
 PIC30F6014@QFP80(ISP) [ISP-HEADER01]
 PIC30F6014@TQFP80(ISP) [ISP-HEADER01]
 PIC30F6014A@QFP80(ISP) [ISP-HEADER01]
 PIC30F6014A@TQFP80(ISP) [ISP-HEADER01]
 PIC30F6015@QFP64(ISP) [ISP-HEADER01]
 PS200 PS200(ISP) [ISP-
 HEADER01]
 PS200@SOIC20 [(SA404)] PS200@SOIC20(ISP) [ISP-
 HEADER01]
 PS200@SSOP20 [(SA626A)] PS200@SSOP20(ISP) [ISP-
 HEADER01]
 rfPIC12C509AF@SSOP20 [(SA626A)]
 rfPIC12C509AF@SSOP20(ISP) [ISP-HEADER01]
 rfPIC12C509AG@SOIC18 [(SA404)]
 rfPIC12C509AG@SOIC18(ISP) [ISP-HEADER01]
 rfPIC12LC509AF@SSOP20 [(SA626A)]
 rfPIC12LC509AF@SSOP20(ISP) [ISP-HEADER01]
 rfPIC12LC509AG@SOIC18 [(SA404)]
 rfPIC12LC509AG@SOIC18(ISP) [ISP-HEADER01]

MICRON

E (E) PROM / FRAM / NVRAM

MT28F002B1VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F002B1VG-T@TSOP40
MT28F002B3VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F002B3VG-T@TSOP40
MT28F002B5VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F002B5VG-T@TSOP40
MT28F002C1VG-T@TSOP40 [(SA409T)] [(SA409T)]	MT28F002C5VG-T@TSOP40
MT28F002VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F002VG-T@TSOP40
MT28F004B1VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F004B1VG-T@TSOP40
MT28F004B3VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F004B3VG-T@TSOP40
MT28F004B5VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F004B5VG-T@TSOP40
MT28F004VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F004VG-T@TSOP40
MT28F008B1VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F008B1VG-T@TSOP40
MT28F008B3VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F008B3VG-T@TSOP40
MT28F008B5VG-B@TSOP40 [(SA409T)] [(SA409T)]	MT28F008B5VG-T@TSOP40
MT28F016S3VG@TSOP40 [(SA409T)] [(SA409T)]	MT28F016S5VG@TSOP40
MT28F200B1SGB@PSOP44 [(SA638)] [(SA638)]	MT28F200B1SGT@PSOP44
MT28F200B1WGB@TSOP48 [(SA247-B005)]	
MT28F200B1WGT@TSOP48 [(SA247-B005)]	
MT28F200B3SGB@PSOP44 [(SA638)] [(SA638)]	MT28F200B3SGT@PSOP44
MT28F200B3WGB@TSOP48 [(SA247-B005)]	
MT28F200B3WGT@TSOP48 [(SA247-B005)]	
MT28F200B5SGB@PSOP44 [(SA638)] [(SA638)]	MT28F200B5SGT@PSOP44
MT28F200B5WGB@TSOP48 [(SA247-B005)]	
MT28F200B5WGT@TSOP48 [(SA247-B005)]	
MT28F400B1SGB@PSOP44 [(SA638)] [(SA638)]	MT28F400B1SGT@PSOP44

MT28F400B1WGB@TSOP48 [(SA247-B005)]
MT28F400B1WGT@TSOP48 [(SA247-B005)]
MT28F400B3SGB@PSOP44 [(SA638)] MT28F400B3SGT@PSOP44
[(SA638)]
MT28F400B3WGB@TSOP48 [(SA247-B005)]
MT28F400B3WGT@TSOP48 [(SA247-B005)]
MT28F400B5SGB@PSOP44 [(SA638)] MT28F400B5SGT@PSOP44
[(SA638)]
MT28F400B5WGB@TSOP48 [(SA247-B005)]
MT28F400B5WGT@TSOP48 [(SA247-B005)]
MT28F800B1SGB@PSOP44 [(SA638)] MT28F800B1SGT@PSOP44
[(SA638)]
MT28F800B1WGB@TSOP48 [(SA247-B005)]
MT28F800B1WGT@TSOP48 [(SA247-B005)]
MT28F800B3SGB@PSOP44 [(SA638)] MT28F800B3SGT@PSOP44
[(SA638)]
MT28F800B3WGB@TSOP48 [(SA247-B005)]
MT28F800B3WGT@TSOP48 [(SA247-B005)]
MT28F800B5SGB@PSOP44 [(SA638)] MT28F800B5SGT@PSOP44
[(SA638)]
MT28F800B5WGB@TSOP48 [(SA247-B005)]
MT28F800B5WGT@TSOP48 [(SA247-B005)]

MICRONAS

MICROCONTROLLER

SDA555XFL@SDIP52(*) [(SA627-B5603)]

MITSUBISHI

E (E) PROM / FRAM / NVRAM

M5L27128K
M5L2716
M5L27256K
M5L2732
M5L2732A
M5L27512
M5L27512K

M5L2764K	
M5L27C512A	
M5M27128P	
M5M27256P	
M5M27512P	
M5M2764P	
M5M27C100K	
M5M27C100K@PLCC32 [(SA015A1T)]	M5M27C100K@TSOP32
[(SA410T)]	
M5M27C100P	M5M27C100P@PLCC32
[(SA015A1T)]	
M5M27C100P@TSOP32 [(SA410T)]	
M5M27C101JK	
M5M27C101JK@PLCC32 [(SA015A1T)]	M5M27C101JK@TSOP32
[(SA410T)]	
M5M27C101K	M5M27C101K@PLCC32
[(SA015A1T)]	
M5M27C101K@TSOP32 [(SA410T)]	
M5M27C101P	
M5M27C101P@PLCC32 [(SA015A1T)]	M5M27C101P@TSOP32
[(SA410T)]	
M5M27C102K	M5M27C102K@PLCC44
[(SA244)]	
M5M27C102P	M5M27C102P@PLCC44
[(SA244)]	
M5M27C128K	
M5M27C201K	
M5M27C201K@PLCC32 [(SA015A1T)]	M5M27C201K@TSOP32
[(SA410T)]	
M5M27C202K	M5M27C202K@PLCC44
[(SA244)]	
M5M27C256 (K)	M5M27C256
(P)	
M5M27C256A (FP)	M5M27C256A
(K)	
M5M27C256A (P)	
M5M27C401K	
M5M27C401K@PLCC32 [(SA015A1T)]	M5M27C401K@TSOP32
[(SA410T)]	
M5M27C402K	M5M27C512
(FP)	
M5M27C512A (FP)	M5M27C512A
(K)	

M5M27C512A(P)
 M5M28F101
 M5M28F101@PLCC32 [(SA015A1T)] M5M28F101@SOP32
 [(SA438T)]
 M5M28F101@TSOP32 [(SA410T)]
 M5M28F101A
 M5M28F101A@PLCC32 [(SA015A1T)] M5M28F101A@SOIC32
 [(SA438T)]
 M5M28F101A@TSOP32 [(SA410T)]
 M5M29FB160A@TSOP48 [(SA247-B005)]
 M5M29FB800(FP)@PSOP44 [(SA638)]
 M5M29FB800(VP)@TSOP48 [(SA247-B005)]
 M5M29FT160A@TSOP48 [(SA247-B005)]
 M5M29FT800(FP)@PSOP44 [(SA638)]
 M5M29FT800(VP)@TSOP48 [(SA247-B005)]
 M6M80011A M6M80011A@SOIC10
 [(SA023A)]
 M6M80011A@SOIC16 [(SA023A)]
 M6M80021
 M6M80021@SOIC10 [(SA023A)] M6M80021@SOIC16
 [(SA023A)]
 M6M80041 M6M80041@SOIC10
 [(SA023A)]

MICROCONTROLLER

M30240EFCFP@QFP80(Renesas) [(PCA7302E1F-80)]
 M30620EFCFP@QFP100(Renesas) [(PCA7412F-100)]
 M30620ECFS@QFN100(Renesas) [(PCA7412L-100)]
 M30620ECGP@LQFP100(Renesas) [(PCA7412G-100)]
 M30621ECGP@QFP80(Renesas) [(PCA7413F-80)]
 M30622ECTFP@QFP100(Renesas) [(PCA7412F-100)]
 M30623ECTGP@QFP80(Renesas) [(PCA7413F-80)]
 M306V0EEFP@QFP100(Renesas) [(PCA7412F-100)]
 M306V0EEFS@QFN100(Renesas) [(PCA7412L-100)]
 M306V2EEFP@QFP100(Renesas) [(PCA7412F-100)]
 M306V2EEFS@QFN100(Renesas) [(PCA7412L-100)]
 M34513E4FP@LQFP32(Renesas) [(PCA7442FPG02)]
 M34513E4SP@SDIP32(Renesas) [(PCA7442SP)]
 M34513E8FP@LQFP32(Renesas) [(PCA7442FPG02)]
 M34514E8FP@SSOP42(Renesas) [(PCA7441)]
 M34518E8FP@LQFP32(Renesas) [(PCA7442FPG02)]

M34518E8SP@SDIP32 (Renesas) [(PCA7442SP)]
M34519E8FP@SSOP42 (Renesas) [(PCA7441)]
M34524EDFP@QFP64 (Renesas) [(PCA7448)]
M34551E8FP@QFP48 (Renesas) [(PCA7414)]
M34554EDFP@QFP64 (Renesas) [(PCA7448)]
M34570E8FP@SSOP36 (Renesas) [(PCA7425)]
M34570EDFP@SSOP36 (Renesas) [(PCA7425)]
M34583EDFP@LQFP32 (Renesas) [(PCA7442FPG02)]
M34584EDFP@SSOP42 (Renesas) [(PCA7441)]
M37150EFFP@SSOP42 (Renesas) [(PCA7450FP)]
M37151EFFP@SSOP42 (Renesas) [(PCA7450FP)]
M37160EFFP@SSOP42 (Renesas) [(PCA7450FP)]
M37161EFFP@SSOP42 (Renesas) [(PCA7450FP)]
M37516E6HKP@QFN44 (Renesas) [(PCA7446)]
M37516E6HP@LQFP48 (Renesas) [(PCA7419)]
M37540E2FP@SSOP36 (Renesas) [(PCA7435FPG02)]
M37540E2GP@LQFP32 (Renesas) [(PCA7435GPG03)]
M37540E2SP@SDIP32 (Renesas) [(PCA7435SPG02)]
M37540E8FP@SSOP36 (Renesas) [(PCA7435FPG02)]
M37540E8GP@LQFP32 (Renesas) [(PCA7435GPG03)]
M37540E8SP@SDIP32 (Renesas) [(PCA7435SPG02)]
M37560EFDFP@QFP100 (Renesas) [(PCA4738F-100A)]
M37560EFFP@QFN100 (Renesas) [(PCA4738L-100A)]
M37560EFFP@QFP100 (Renesas) [(PCA4738F-100A)]
M37560EFGP@LQFP100 (Renesas) [(PCA4738G-100A)]
M37630E4FP@QFP44 (Renesas) [(PCA7430)]
M37630E4FS@QFN80 (Renesas) [(PCA7431)]
M37640E8FP@QFP80 (Renesas) [(PCA7440FP)]
M37640E8FS@QFN80 (Renesas) [(PCA7440FS)]
M37733EHBFP@QFP80 (Renesas) [(PCA4774G05)]
M37733EHBFS@QFN80 (Renesas) [(PCA4708G05)]
M37735EHBFP@QFP80 (Renesas) [(PCA4774G05)]
M37735EHBFS@QFN80 (Renesas) [(PCA4708G05)]
M37736EHBGP@QFP100 (Renesas) [(PCA7422GPG02)]
M37736EHBGS@QFN100 (Renesas) [(PCA7422GSG02)]
M37751E6CFP@QFP80 (Renesas) [(PCA4774G05)]
M37751E6CFS@QFN80 (Renesas) [(PCA4708G05)]
M37751F6CFP@QFP80 (Renesas) [(PCA4774G05)]
M38027E8DFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]
M38027E8DSP@DIP64 (Mitsubishi) [(BBBB)]
M38027E8DXXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]
M38027E8DXXXSP@DIP64 (Mitsubishi) [(BBBB)]
M38027E8FS@LCC64 (Mitsubishi) [(BBBB)]

M38027E8SP@DIP64(Mitsubishi) [(BBBB)]
M38027E8SS@DIP64(Mitsubishi) [(BBBB)]
M38027E8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]
M38027E8-XXXSP@DIP64(Mitsubishi) [(BBBB)]
M38027M8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]
M38039FFFP@QFP64(Renesas) [(PCA4738FF-64)]
M38039FFHP@LQFP64(Renesas) [(PCA4738HF-64)]
M38039FFSP@SDIP64(Renesas) [(PCA4738SF-64)]
M38049FFFP@QFP64(Renesas) [(PCA4738FF-64)]
M38049FFHP@LQFP64(Renesas) [(PCA4738HF-64)]
M38049FFSP@SDIP64(Renesas) [(PCA4738SF-64)]
M38223E4FP@QFP80(Renesas) [(PCA4738F-80A)]
M38223E4FS@QFN80(Renesas) [(PCA4738L-80A)]
M38223E4GP@QFP80(Renesas) [(PCA4738G-80A)]
M38223E4HP@LQFP80(Renesas) [(PCA4738H-80A)]
M38227ECFP@QFP80(Renesas) [(PCA4738F-80A)]
M38227ECFS@QFN80(Renesas) [(PCA4738L-80A)]
M38227ECHP@LQFP80(Renesas) [(PCA4738H-80A)]
M38267E8FP@QFP100(Renesas) [(PCA4738F-100A)]
M38267E8GP@LQFP100(Renesas) [(PCA4738G-100A)]
M3826AEFFP@QFP100(Renesas) [(PCA4738F-100A)]
M3826AEFFS@QFN100(Renesas) [(PCA4738L-100A)]
M3826AEFGP@LQFP100(Renesas) [(PCA4738G-100A)]
M38504E6FP@SSOP42(Renesas) [(PCA4738F-42A)]
M38504E6SP@SDIP42(Renesas) [(PCA4738S-42A)]
M38504E6SS@SDIP42(Renesas) [(PCA4738S-42A)]
M38514E6FP@SSOP42(Renesas) [(PCA4738F-42A)]
M38514E6SP@SDIP42(Renesas) [(PCA4738S-42A)]
M38514E6SS@SDIP42(Renesas) [(PCA4738S-42A)]
M38867E8AFS@QFN80(Renesas) [(PCA4738L-80A)]
M38867E8AHP@LQFP80(Renesas) [(PCA4738H-80A)]
M38869FFAGP@QFP80(Renesas) [(PCA4738GF-80)]
M38869FFAHP@LQFP80(Renesas) [(PCA4738HF-80)]
M38B79FFFP@QFP100(Renesas) [(PCA7438FF-100)]
M38C13E6FP@LQFP64(Renesas) [(PCA7438F-64A)]
M38C13E6HP@QFP64(Renesas) [(PCA7438H-64A)]
M38C89EFFP@LQFP144(Renesas) [(PCA7447FP)]
R5F21102DFP@TQFP32 [(SA663+B005)]
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21102FP@TQFP32 [(SA663+B005)]
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]
R5F21103DFP@TQFP32 [(SA663+B005)]
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]

R5F21103FFP@TQFP32 [(SA663+B005)]
R5F21103FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21104DFP@TQFP32 [(SA663+B005)]
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21104FFP@TQFP32 [(SA663+B005)]
R5F21104FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21112DFP@TQFP32 [(SA663+B005)]
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21112FFP@TQFP32 [(SA663+B005)]
R5F21112FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21113DFP@TQFP32 [(SA663+B005)]
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21113FFP@TQFP32 [(SA663+B005)]
R5F21113FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21114DFP@TQFP32 [(SA663+B005)]
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21114FFP@TQFP32 [(SA663+B005)]
R5F21114FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21122DFP@TQFP32 [(SA663+B005)]
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21122FFP@TQFP32 [(SA663+B005)]
R5F21122FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21123DFP@TQFP32 [(SA663+B005)]
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21123FFP@TQFP32 [(SA663+B005)]
R5F21123FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21124DFP@TQFP32 [(SA663+B005)]
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21124FFP@TQFP32 [(SA663+B005)]
R5F21124FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21132DFP@TQFP32 [(SA663+B005)]
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21132FFP@TQFP32 [(SA663+B005)]
R5F21132FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21133DFP@TQFP32 [(SA663+B005)]
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21133FFP@TQFP32 [(SA663+B005)]
R5F21133FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21134DFP@TQFP32 [(SA663+B005)]
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21134FFP@TQFP32 [(SA663+B005)]
R5F21134FFP@TQFP32(ISP) [ISP-HEADER01]
R5F21181DD@SDIP20 [(SA725-B005)]


```
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(single wire) [(SA725-B005)]
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]
R5F21181DSP@TSSOP20 [(SA026-B001)]
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21181SP@TSSOP20 [(SA026-B001)]
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182DD@SDIP20 [(SA725-B005)]
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(single wire) [(SA725-B005)]
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]
R5F21182DSP@TSSOP20 [(SA026-B001)]
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182NP@QFN28 [(SA697-B006)]
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]
R5F21182NP@QFN28(single wire) [(SA697-B006)]
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21182NP@QFN28(UART mode) [(SA697+B006)]
R5F21182SP@TSSOP20 [(SA026-B001)]
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183DD@SDIP20 [(SA725-B005)]
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(single wire) [(SA725-B005)]
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]
R5F21183DSP@TSSOP20 [(SA026-B001)]
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]
```

R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183NP@QFN28 [(SA697-B006)]
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]
R5F21183NP@QFN28(single wire) [(SA697-B006)]
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21183NP@QFN28(UART mode) [(SA697+B006)]
R5F21183SP@TSSOP20 [(SA026-B001)]
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184DD@SDIP20 [(SA725-B005)]
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(single wire) [(SA725-B005)]
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]
R5F21184DSP@TSSOP20 [(SA026-B001)]
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184NP@QFN28 [(SA697-B006)]
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]
R5F21184NP@QFN28(single wire) [(SA697-B006)]
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21184NP@QFN28(UART mode) [(SA697+B006)]
R5F21184SP@TSSOP20 [(SA026-B001)]
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191DD@SDIP20 [(SA725-B005)]
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(single wire) [(SA725+B005)]
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]
R5F21191DSP@TSSOP20 [(SA026-B001)]
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191SP@TSSOP20 [(SA026-B001)]
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]

R5F21191SP@TSSOP20(single wire) [(SA026+B001)]
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192DD@SDIP20 [(SA725-B005)]
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(single wire) [(SA725+B005)]
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]
R5F21192DSP@TSSOP20 [(SA026-B001)]
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192NP@QFN28 [(SA697-B006)]
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]
R5F21192NP@QFN28(single wire) [(SA697+B006)]
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21192NP@QFN28(UART mode) [(SA697+B006)]
R5F21192SP@TSSOP20 [(SA026-B001)]
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193DD@SDIP20 [(SA725-B005)]
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(single wire) [(SA725+B005)]
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]
R5F21193DSP@TSSOP20 [(SA026-B001)]
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193NP@QFN28 [(SA697-B006)]
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]
R5F21193NP@QFN28(single wire) [(SA697+B006)]
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21193NP@QFN28(UART mode) [(SA697+B006)]
R5F21193SP@TSSOP20 [(SA026-B001)]
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]

```
R5F21194DD@SDIP20 [(SA725-B005)]
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(single wire) [(SA725+B005)]
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]
R5F21194DSP@TSSOP20 [(SA026-B001)]
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194NP@QFN28 [(SA697-B006)]
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]
R5F21194NP@QFN28(single wire) [(SA697+B006)]
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21194NP@QFN28(UART mode) [(SA697+B006)]
R5F21194SP@TSSOP20 [(SA026-B001)]
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1DD@SDIP20 [(SA725-B005)]
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A1DSP@TSSOP20 [(SA026-B001)]
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1SP@TSSOP20 [(SA026-B001)]
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2DD@SDIP20 [(SA725-B005)]
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A2DSP@TSSOP20 [(SA026-B001)]
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]
```

R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2NP@QFN28 [(SA697-B006)]
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(single wire) [(SA697-B006)]
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]
R5F211A2SP@TSSOP20 [(SA026-B001)]
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3DD@SDIP20 [(SA725-B005)]
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A3DSP@TSSOP20 [(SA026-B001)]
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3NP@QFN28 [(SA697-B006)]
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(single wire) [(SA697-B006)]
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]
R5F211A3SP@TSSOP20 [(SA026-B001)]
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4DD@SDIP20 [(SA725-B005)]
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A4DSP@TSSOP20 [(SA026-B001)]
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4NP@QFN28 [(SA697-B006)]

R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(single wire) [(SA697-B006)]
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]
R5F211A4SP@TSSOP20 [(SA026-B001)]
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1DD@SDIP20 [(SA725-B005)]
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B1DSP@TSSOP20 [(SA026-B001)]
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1SP@TSSOP20 [(SA026-B001)]
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2DD@SDIP20 [(SA725-B005)]
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B2DSP@TSSOP20 [(SA026-B001)]
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2NP@QFN28 [(SA697-B006)]
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(single wire) [(SA697+B006)]
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]
R5F211B2SP@TSSOP20 [(SA026-B001)]
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3DD@SDIP20 [(SA725-B005)]
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B3DSP@TSSOP20 [(SA026-B001)]
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3NP@QFN28 [(SA697-B006)]
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(single wire) [(SA697+B006)]
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]
R5F211B3SP@TSSOP20 [(SA026-B001)]
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4DD@SDIP20 [(SA725-B005)]
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B4DSP@TSSOP20 [(SA026-B001)]
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4NP@QFN28 [(SA697-B006)]
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(single wire) [(SA697+B006)]
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]
R5F211B4SP@TSSOP20 [(SA026-B001)]
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21206JFP@TQFP48 [(SA248-B005)]
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]

R5F21206JFP@TQFP48(single wire) [(SA248-B005)]
R5F21206KFP@TQFP48 [(SA248-B005)]
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]
R5F21207JFP@TQFP48 [(SA248-B005)]
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]
R5F21207KFP@TQFP48 [(SA248-B005)]
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]
R5F21208JFP@TQFP48 [(SA248-B005)]
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]
R5F21208KFP@TQFP48 [(SA248-B005)]
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AJFP@TQFP48 [(SA248-B005)]
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AKFP@TQFP48 [(SA248-B005)]
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CJFP@TQFP48 [(SA248-B005)]
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CKFP@TQFP48 [(SA248-B005)]
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21216JFP@TQFP48 [(SA248-B005)]
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]
R5F21216KFP@TQFP48 [(SA248-B005)]
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]
R5F21217JFP@TQFP48 [(SA248-B005)]
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]
R5F21217KFP@TQFP48 [(SA248-B005)]
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]
R5F21218JFP@TQFP48 [(SA248-B005)]
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]

R5F21218KFP@TQFP48 [(SA248-B005)]
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AJFP@TQFP48 [(SA248-B005)]
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AKFP@TQFP48 [(SA248-B005)]
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CJFP@TQFP48 [(SA248-B005)]
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CKFP@TQFP48 [(SA248-B005)]
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21226JFP@TQFP48 [(SA248-B005)]
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]
R5F21226KFP@TQFP48 [(SA248-B005)]
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]
R5F21227JFP@TQFP48 [(SA248-B005)]
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]
R5F21227KFP@TQFP48 [(SA248-B005)]
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]
R5F21228JFP@TQFP48 [(SA248-B005)]
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]
R5F21228KFP@TQFP48 [(SA248-B005)]
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AJFP@TQFP48 [(SA248-B005)]
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AKFP@TQFP48 [(SA248-B005)]
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CJFP@TQFP48 [(SA248-B005)]
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CKFP@TQFP48 [(SA248-B005)]

R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21236JFP@TQFP48 [(SA248-B005)]
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]
R5F21236KFP@TQFP48 [(SA248-B005)]
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]
R5F21237JFP@TQFP48 [(SA248-B005)]
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]
R5F21237KFP@TQFP48 [(SA248-B005)]
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]
R5F21238JFP@TQFP48 [(SA248-B005)]
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]
R5F21238KFP@TQFP48 [(SA248-B005)]
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AJFP@TQFP48 [(SA248-B005)]
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AKFP@TQFP48 [(SA248-B005)]
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CJFP@TQFP48 [(SA248-B005)]
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CKFP@TQFP48 [(SA248-B005)]
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]

R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]

R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]

R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]

R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20 [(SA026-B001)]
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H1SNSP@TSSOP20 [(SA026-B001)]
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SDSP@TSSOP20 [(SA725-B005)]
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SNSP@TSSOP20 [(SA725-B005)]
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SDSP@TSSOP20 [(SA026-B001)]
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SNSP@TSSOP20 [(SA026-B001)]
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SDSP@TSSOP20 [(SA026-B001)]
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SNSP@TSSOP20 [(SA026-B001)]
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212K2SDFP@QFP32 [(SA663-B005)]

```

R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SDFP@QFP32(single wire) [(SA663-B005)]
R5F212K2SNFP@QFP32 [(SA663-B005)]
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SNFP@QFP32(single wire) [(SA663-B005)]
R5F212K4SDFP@QFP32 [(SA663-B005)]
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SDFP@QFP32(single wire) [(SA663-B005)]
R5F212K4SNFP@QFP32 [(SA663-B005)]
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SNFP@QFP32(single wire) [(SA663-B005)]
R5F212L2SDFP@QFP32 [(SA663-B005)]
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]
R5F212L2SNFP@QFP32 [(SA663-B005)]
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]
R5F212L4SDFP@QFP32 [(SA663-B005)]
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]
R5F212L4SNFP@QFP32 [(SA663-B005)]
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]

```

MOSEL-VITELIC

E (E) PROM/FRAM/NVRAM

```

V29C31004B                                V29C31004B@PLCC32
[(SA015A1T)]
V29C31004B@TSOP32 [(SA410T)]
V29C31004T                                V29C31004T@TSOP32
V29C31004T@PLCC32 [(SA015A1T)]
[(SA410T)]
V29C51000B                                V29C51000B@PLCC32
[(SA015A1T)]
V29C51000T                                V29C51000T@PLCC32
[(SA015A1T)]
V29C51001B                                V29C51001B@PLCC32
[(SA015A1T)]
V29C51001B@TSOP32 [(SA410T)]
V29C51001T

```

V29C51001T@PLCC32 [(SA015A1T)] [(SA410T)]	V29C51001T@TSOP32
V29C51002B [(SA015A1T)]	V29C51002B@PLCC32
V29C51002B@TSOP32 [(SA410T)]	
V29C51002T	
V29C51002T@PLCC32 [(SA015A1T)] [(SA410T)]	V29C51002T@TSOP32
V29C51004B [(SA015A1T)]	V29C51004B@PLCC32
V29C51004B@TSOP32 [(SA410T)]	
V29C51004T	
V29C51004T@PLCC32 [(SA015A1T)] [(SA410T)]	V29C51004T@TSOP32
V29LC51000 [(SA015A1T)]	V29LC51000@PLCC32
V29LC51001 [(SA015A1T)]	V29LC51001@PLCC32
V29LC51002 [(SA015A1T)]	V29LC51002@PLCC32

MICROCONTROLLER

MSU1958 [(SA244)]	MSU1958@PLCC44
MSU1958@TQFP44 [(SA245A)]	
MSU2952	
MSU2952@PLCC44 [(SA244)] [(SA245A)]	MSU2952@TQFP44
MSU2958 [(SA244)]	MSU2958@PLCC44
MSU2958@TQFP44 [(SA245A)]	
MSU2964	
MSU2964@PLCC44 [(SA244)] [(SA245A)]	MSU2964@TQFP44

MOSTEK

E (E) PROM / FRAM / NVRAM

ET2716

ETC2716
ETC2732
MK2716
MK2764
MK48C02
MK48C12
MK48T02
MK48T08
MK48T12
MK48T12B
MK48T18
MK48Z02
MK48Z08
MK48Z12
MK48Z12B
MK48Z18

MOTOROLA

E (E) PROM / FRAM / NVRAM

MC68764
MC68766
MCM2716

DRAM & SRAM

MCM2018A [(SA015A1T)]	MCM2018A@PLCC32
MCM60256A [(SA630)]	MCM60256A@SOIC28
MCM60256AC [(SA630)]	MCM60256AC@SOIC28
MCM60256AV [(SA630)]	MCM60256AV@SOIC28
MCM60L256A [(SA630)]	MCM60L256A@SOIC28
MCM60L256AC [(SA630)]	MCM60L256AC@SOIC28
MCM60L256AV [(SA630)]	MCM60L256AV@SOIC28

MCM6206	MCM6206@SOIC28
[(SA630)]	
MCM6206C	MCM6206C@SOIC28
[(SA630)]	
MCM6207	MCM6207@SOJ24
[(SA646)]	
MCM6207C	MCM6207C@SOJ24
[(SA646)]	
MCM6208	MCM6208@SOJ24
[(SA646)]	
MCM6208C	MCM6208C@SOJ24
[(SA646)]	
MCM6209	MCM6209@SOJ28
[(SA646)]	
MCM6209C	MCM6209C@SOJ28
[(SA646)]	
MCM6229	MCM6229 (300m) @SOJ28
[(SA646)]	
MCM6229 (400m) @SOJ28 [(SA661)]	
MCM6229A	
MCM6229A (300m) @SOJ28 [(SA646)]	MCM6229A (400m) @SOJ28
[(SA661)]	
MCM6264	MCM6264@SOIC28
[(SA630)]	
MCM6264C	MCM6264C@SOIC28
[(SA630)]	
MCM6268	
MCM6269	
MCM6287	MCM6287@SOJ24
[(SA646)]	
MCM6288	MCM6288@SOJ22
[(SA646)]	
MCM6288B	MCM6288B@SOJ22
[(SA646)]	
MCM6288C	MCM6288C@SOJ22
[(SA646)]	
MCM6290	MCM6290@SOJ24
[(SA646)]	
MCM6290B	MCM6290B@SOJ24
[(SA646)]	
MCM6290C	MCM6290C@SOJ24
[(SA646)]	
MCM62L07	MCM62L07@SOJ24

[(SA646)]	
MCM62L08	MCM62L08@SOJ24
[(SA646)]	
MCM62L09	MCM62L09@SOJ28
[(SA646)]	
MCM6706	MCM6706@SOIC28
[(SA630)]	
MCM6706A	MCM6706A@SOJ28
[(SA646)]	
MCM6708A	MCM6708A@SOJ24
[(SA646)]	
MCM6709A	MCM6709A@SOJ28
[(SA646)]	

NEC

E (E) PROM / FRAM / NVRAM

D2716D	
uPD271000	
uPD271000@PLCC32 [(SA015A1T)]	uPD271000@TSOP32
[(SA410T)]	
uPD27128	uPD27128
(C)	
uPD27128 (D)	
uPD2716	
uPD27256	uPD27256
(C)	
uPD27256 (D)	
uPD27256A	
uPD27256A (C)	uPD27256A
(D)	
uPD2732	
uPD2732A	
uPD27512	
uPD27512ACT	
uPD27512AD	
uPD2764	
uPD2764C	
uPD2764D	
uPD27C1000	uPD27C1000@PLCC32
[(SA015A1T)]	

uPD27C1000@TSOP32 [(SA410T)]	
uPD27C1000A	
uPD27C1000A@PLCC32 [(SA015A1T)]	uPD27C1000A@TSOP32
[(SA410T)]	
uPD27C1000AD	uPD27C1000AD@PLCC32
[(SA015A1T)]	
uPD27C1000AD@TSOP32 [(SA410T)]	
uPD27C1001	
uPD27C1001@PLCC32 [(SA015A1T)]	uPD27C1001@TSOP32
[(SA410T)]	
uPD27C1001A	uPD27C1001A@PLCC32
[(SA015A1T)]	
uPD27C1001A@TSOP32 [(SA410T)]	
uPD27C1001D	
uPD27C1001D@PLCC32 [(SA015A1T)]	uPD27C1001D@TSOP32
[(SA410T)]	
uPD27C1024	
uPD27C1024A	
uPD27C2001	uPD27C2001@PLCC32
[(SA015A1T)]	
uPD27C2001@TSOP32 [(SA410T)]	
uPD27C2001D	
uPD27C2001D@PLCC32 [(SA015A1T)]	uPD27C2001D@TSOP32
[(SA410T)]	
uPD27C210	
uPD27C256	
uPD27C256A	
uPD27C400	
uPD27C4001	uPD27C4001@PLCC32
[(SA015A1T)]	
uPD27C4001@TSOP32 [(SA410T)]	
uPD27C4096	
uPD27C512	uPD27C64
(C)	
uPD27C64(D)	
uPD27C8000	
uPD27C8001	uPD27C8001@PLCC32
[(SA015A1T)]	
uPD27C8001@TSOP32 [(SA410T)]	
uPD28C04	
uPD28C04@SOIC24 [(SA404)]	
uPD28C05	
uPD28C05@SOIC24 [(SA404)]	

uPD28C256	
uPD28C64	uPD28C64@SOIC28
[(SA404)]	
uPD29F008CB@TSOP40 [(SA409T)]	uPD29F008CT@TSOP40
[(SA409T)]	

DRAM & SRAM

PD4361B	PD4361B@SOJ24
[(SA646)]	

NEXFLASH

E (E) PROM / FRAM / NVRAM

NX25B40 (Bottom Boot)@MLP8 [(SA683)]	
NX25B40 (Bottom Boot)@SOIC8 [(SA602A)]	
NX25B40 (Top Boot)@MLP8 [(SA683)]	
NX25B40 (Top Boot)@SOIC8 [(SA602A)]	
NX25P10@MLP8 [(SA683)]	NX25P10@SOIC8
[(SA602A)]	
NX25P16@MLP8 [(SA683)]	NX25P16@MLP8 (ISP) [ISP-
HEADER01]	
NX25P16@SOIC16 [(SA404)]	
NX25P16@SOIC16 (ISP) [ISP-HEADER01]	
NX25P16@SOIC8 [(SA023A)]	
NX25P16@SOIC8 (ISP) [ISP-HEADER01]	
NX25P20@MLP8 [(SA683)]	NX25P20@SOIC8
[(SA602A)]	
NX25P32@MLP8 [(SA683)]	NX25P32@MLP8 (ISP) [ISP-
HEADER01]	
NX25P32@SOIC16 [(SA404)]	
NX25P32@SOIC16 (ISP) [ISP-HEADER01]	
NX25P40@MLP8 [(SA683)]	NX25P40@SOIC8
[(SA602A)]	
NX25P64@MLP8 [(SA683)]	NX25P64@MLP8 (ISP) [ISP-
HEADER01]	
NX25P64@SOIC16 [(SA404)]	
NX25P64@SOIC16 (ISP) [ISP-HEADER01]	
NX25P80@MLP8 [(SA683)]	NX25P80@SOIC8
[(SA602A)]	

NX29F010
[(SA015A1T)]
NX29F010@TSOP32 [(SA410T)]

NX29F010@PLCC32

NJRC

E (E) PROM / FRAM / NVRAM

NJU26040V
[(SA626A)]

NJU26040V@SSOP32

NSC

E (E) PROM / FRAM / NVRAM

2864
MM2716
MM2716E
NM24C02
NM24C02@SOIC8 [(SA602A)]
[(SA026)]
NM24C02L
[(SA602A)]
NM24C02L@TSOP8 [(SA026)]
NM24C03
NM24C03@SOIC8 [(SA602A)]
[(SA026)]
NM24C04
[(SA602A)]
NM24C04@TSOP8 [(SA026)]
NM24C05
NM24C05@SOIC8 [(SA602A)]
[(SA026)]
NM24C08
[(SA602A)]
NM24C09
[(SA602A)]
NM24C16
[(SA602A)]
NM24C17

NM24C02@TSOP8

NM24C02L@SOIC8

NM24C03@TSOP8

NM24C04@SOIC8

NM24C05@TSOP8

NM24C08@SOIC8

NM24C09@SOIC8

NM24C16@SOIC8

NM24C17@SOIC8

[(SA602A)]	
NM25C04	NM25C04@SOIC16
[(SA602)]	
NM25C04@SOIC8 [(SA602A)]	NM25C04@TSSOP14
[(SA026)]	
NM25C04@TSSOP8 [(SA026)]	
NM27C010	
NM27C010@PLCC32 [(SA015A1T)]	NM27C010@TSOP32
[(SA410T)]	
NM27C010Q	NM27C010Q@PLCC32
[(SA015A1T)]	
NM27C010Q@TSOP32 [(SA410T)]	
NM27C020	
NM27C020@PLCC32 [(SA015A1T)]	NM27C020@TSOP32
[(SA410T)]	
NM27C020Q	NM27C020Q@PLCC32
[(SA015A1T)]	
NM27C020Q@TSOP32 [(SA410T)]	
NM27C040	
NM27C040@PLCC32 [(SA015A1T)]	NM27C040@TSOP32
[(SA410T)]	
NM27C1023	
NM27C128	
NM27C128@PLCC32 [(SA015A1T)]	
NM27C210	
NM27C210@PLCC44 [(SA244)]	
NM27C210Q	
NM27C210Q@PLCC44 [(SA244)]	
NM27C240	
NM27C240@PLCC44 [(SA244)]	
NM27C256	
NM27C256@PLCC32 [(SA015A1T)]	
NM27C400	
NM27C512	NM27C512@PLCC32
[(SA015A1T)]	
NM27C512Q	NM27C512Q@PLCC32
[(SA015A1T)]	
NM27C64Q	NM27C64Q@PLCC32
[(SA015A1T)]	
NM27CP256	NM27CP256@PLCC32
[(SA015A1T)]	
NM27LC010	NM27LC010@PLCC32
[(SA015A1T)]	

NM27LC010@TSOP32 [(SA410T)]	
NM27LC256	
NM27LC256@PLCC32 [(SA015A1T)]	
NM27LC512	
NM27LC512@PLCC32 [(SA015A1T)]	
NM27LC64	
NM27LC64@PLCC32 [(SA015A1T)]	
NM27LV010	
NM27LV010@PLCC32 [(SA015A1T)]	NM27LV010@TSOP32
[(SA410T)]	
NM27LV210	NM27LV210@PLCC44
[(SA244)]	
NM27LV512	NM27LV512@PLCC32
[(SA015A1T)]	
NM27LV512@TSOP32 [(SA410T)]	
NM27P040	
NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32
[(SA410T)]	
NM27P210	NM27P210@PLCC44
[(SA244)]	
NM27P512	NM27P512@PLCC32
[(SA015A1T)]	
NM59C11	NM59C11@SOIC8
[(SA602A)]	
NM93C06(08bit)	NM93C06(08bit)@SOIC8
[(SA602A)]	
NM93C06(16bit)	NM93C06(16bit)@SOIC8
[(SA602A)]	
NM93C46	NM93C46@SOIC8
[(SA602A)]	
NM93C46A(08bit)	NM93C46A(08bit)@SOIC8
[(SA602A)]	
NM93C46A(16bit)	NM93C46A(16bit)@SOIC8
[(SA602A)]	
NM93C46AL(08bit)	
NM93C46AL(08bit)@SOIC8 [(SA602A)]	
NM93C46AL(16bit)	
NM93C46AL(16bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(08bit)	
NM93C46ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(16bit)	
NM93C46ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C46L	NM93C46L@SOIC8

[(SA602A)]	
NM93C46LZ	NM93C46LZ@SOIC8
[(SA602A)]	
NM93C56	NM93C56@SOIC8
[(SA602A)]	
NM93C56A(08bit)	NM93C56A(08bit)@SOIC8
[(SA602A)]	
NM93C56A(16bit)	NM93C56A(16bit)@SOIC8
[(SA602A)]	
NM93C56AL(08bit)	
NM93C56AL(08bit)@SOIC8 [(SA602A)]	
NM93C56AL(16bit)	
NM93C56AL(16bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(08bit)	
NM93C56ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(16bit)	
NM93C56ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C56L	NM93C56L@SOIC8
[(SA602A)]	
NM93C56LZ	NM93C56LZ@SOIC8
[(SA602A)]	
NM93C66	NM93C66@SOIC8
[(SA602A)]	
NM93C66A	NM93C66A
(08bit)	
NM93C66A(08bit)@SOIC8 [(SA602A)]	NM93C66A@SOIC8
[(SA602A)]	
NM93C66AL(08bit)	
NM93C66AL(08bit)@SOIC8 [(SA602A)]	
NM93C66AL(16bit)	
NM93C66AL(16bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(08bit)	
NM93C66ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(16bit)	
NM93C66ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C66L	NM93C66L@SOIC8
[(SA602A)]	
NM93C66LZ	NM93C66LZ@SOIC8
[(SA602A)]	
NM93C86(16bit)	NM93C86(16bit)@SOIC8
[(SA602A)]	
NM93C86A	NM93C86A
(08bit)	

NM93C86A(08bit)@SOIC8 [(SA602A)]	NM93C86A@SOIC8
[(SA602A)]	
NM93C86AL(08bit)	
NM93C86AL(08bit)@SOIC8 [(SA602A)]	
NM93C86AL(16bit)	
NM93C86AL(16bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(08bit)	
NM93C86ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(16bit)	
NM93C86ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C86L	NM93C86L@SOIC8
[(SA602A)]	
NM93C86LZ	NM93C86LZ@SOIC8
[(SA602A)]	
NM93CS06(M8)@SOIC8 [(SA602A)]	NM93CS06(MT8)@TSSOP8
[(SA026)]	
NM93CS06(N)	NM93CS46(M8)@SOIC8
[(SA602A)]	
NM93CS46(MT8)@TSSOP8 [(SA026)]	NM93CS46
(N)	
NM93CS56(M8)@SOIC8 [(SA602A)]	NM93CS56(MT8)@TSSOP8
[(SA026)]	
NM93CS56(N)	NM93CS66(M8)@SOIC8
[(SA602A)]	
NM93CS66(MT8)@TSSOP8 [(SA026)]	NM93CS66
(N)	
NMC2732	
NMC2732B	
NMC2732H	
NMC27C010	
NMC27C010@PLCC32 [(SA015A1T)]	NMC27C010@TSOP32
[(SA410T)]	
NMC27C1024	NMC27C1024@PLCC44
[(SA244)]	
NMC27C128B	NMC27C128B@PLCC32
[(SA015A1T)]	
NMC27C128BN	NMC27C128BN@PLCC32
[(SA015A1T)]	
NMC27C128BQ	NMC27C128BQ@PLCC32
[(SA015A1T)]	
NMC27C128CQ	
NMC27C128Q	
NMC27C16	

NMC27C16BQ
NMC27C16BQE
NMC27C16H
NMC27C16HQ
NMC27C16Q
NMC27C210 NMC27C210@PLCC44
[(SA244)]
NMC27C210Q NMC27C210Q@PLCC44
[(SA244)]
NMC27C256B NMC27C256B@PLCC32
[(SA015A1T)]
NMC27C256BN
NMC27C256BQE
NMC27C256BQM
NMC27C256Q
NMC27C256Q@PLCC32 [(SA015A1T)]
NMC27C32
NMC27C32B
NMC27C32BQ
NMC27C32E
NMC27C32EH
NMC27C32H
NMC27C512
NMC27C512@PLCC32 [(SA015A1T)]
NMC27C512A
NMC27C512A@PLCC32 [(SA015A1T)]
NMC27C512AN
NMC27C512AN@PLCC32 [(SA015A1T)]
NMC27C64
NMC27C64@PLCC32 [(SA015A1T)]
NMC27C64BN
NMC27C64N
NMC27CP128
NMC27CP256
NMC27CP64
NMC59C11 NMC59C11@SOIC8
[(SA602A)]
NMC87C257Q
NMC87C257Q@PLCC32
NMC87C257V
NMC87C257V@PLCC32
NMC9306 NMC9306@SOIC8
[(SA602A)]

NMC9307	NMC9307@SOIC8
[(SA602A)]	
NMC9346	NMC9346@SOIC8
[(SA602A)]	
NMC93C56	NMC93C56@SOIC14
[(SA602)]	
NMC93C56@SOIC8 [(SA602A)]	
NMC93C66	
NMC93C66@SOIC14 [(SA602)]	
NMC93C86A	
NMC93C86A@SOIC14 [(SA602)]	NMC93C86A@SOIC8
[(SA602A)]	
NMC93CS06 (M14)@SOIC14 [(SA602)]	NMC93CS06
(N)	
NMC93CS46 (M14)@SOIC14 [(SA602)]	NMC93CS46
(N)	
NMC93CS56 (M14)@SOIC14 [(SA602)]	NMC93CS56
(N)	
NMC93CS66 (M14)@SOIC14 [(SA602)]	NMC93CS66
(N)	
NMC93S06 (M14)@SOIC14 [(SA602)]	NMC93S06
(N)	
NMC9817	
NMC9817A	
NS2816A	
NS9816A	

PLD

GAL16V8	GAL16V8@PLCC20
[(SA001A)]	
GAL16V8A	GAL16V8A@PLCC20
[(SA001A)]	
GAL20V8	GAL20V8@PLCC28
[(SA008A)]	
GAL20V8A	GAL20V8A@PLCC28
[(SA008A)]	
GAL20V8QS	GAL20V8QS@PLCC28
[(SA008A)]	

NTE

E (E) PROM / FRAM / NVRAM

NTE2532
NTE2532A
NTE25L32

NUMONYX

E (E) PROM / FRAM / NVRAM

M25PX32@SOIC16 [(SA404)] [(SA023A)]	M25PX32@SOIC8
M25PX32@VFQFPN8 [(SA683)] [(SA404)]	M25PX64@SOIC16
M25PX64@VDFPN8 [(SA684)]	

NUVOTON

MICROCONTROLLER

N79E342AKG [(SA404)]	N79E342ASG@SOP16
N79E342RAKG [(SA404)]	N79E342RASG@SOP16
N79E352AEG [(SA245)]	N79E352AFG@TQFP44
N79E352ALG@TQFP48 [(SA248)] [(SA244)]	N79E352APG@PLCC44
N79E8213AKG [(SA404)]	N79E8213ASG@SOP20
N79E8213RAKG [(SA404)]	N79E8213RASG@SOP20
W78E051DDG [(SA245A)]	W78E051DFG@TQFP44
W78E051DLG@TQFP48 [(SA248A-B005)]	
W78E051DPG@PLCC44 [(SA244)]	
W78E052DDG	
W78E052DFG@TQFP44 [(SA245A)]	
W78E052DLG@TQFP48 [(SA248A-B005)]	

W78E052DPG@PLCC44 [(SA244)]
 W78E054DDG
 W78E054DFG@TQFP44 [(SA245A)]
 W78E054DLG@TQFP48 [(SA248A-B005)]
 W78E054DPG@PLCC44 [(SA244)]
 W78E058DDG
 W78E058DFG@TQFP44 [(SA245A)]
 W78E058DLG@TQFP48 [(SA248A-B005)]
 W78E058DPG@PLCC44 [(SA244)]
 W78E516DDG
 W78E516DFG@TQFP44 [(SA245A)]
 W78E516DLG@TQFP48 [(SA248A-B005)]
 W78E516DPG@PLCC44 [(SA244)]
 W78I051DDG
 W78I051DFG@TQFP44 [(SA245A)]
 W78I051DLG@TQFP48 [(SA248A-B005)]
 W78I051DPG@PLCC44 [(SA244)]
 W78I052DDG
 W78I052DFG@TQFP44 [(SA245A)]
 W78I052DLG@TQFP48 [(SA248A-B005)]
 W78I052DPG@PLCC44 [(SA244)]
 W78I054DDG
 W78I054DFG@TQFP44 [(SA245A)]
 W78I054DLG@TQFP48 [(SA248A-B005)]
 W78I054DPG@PLCC44 [(SA244)]

NXP

MICROCONTROLLER

P83C660X2@PLCC44 [(SA244)]	P83C660X2@TQFP44
[(SA245A)]	
P83C661X2@PLCC44 [(SA244)]	P83C661X2@TQFP44
[(SA245A)]	
P87C51	P87C51@PLCC44
[(SA244)]	
P87C51@TQFP44 [(SA245A)]	
P87C51FA	
P87C51FA@PLCC44 [(SA244)]	P87C51FA@TQFP44
[(SA245A)]	
P87C51FB	P87C51FB@PLCC44
[(SA244)]	

P87C51FB@TQFP44 [(SA245A)]	
P87C51FC	
P87C51FC@PLCC44 [(SA244)]	P87C51FC@TQFP44
[(SA245A)]	
P87C51MA2@PLCC44 [(SA244)]	P87C51MB2@PLCC44
[(SA244)]	
P87C51MC2@PLCC44 [(SA244)]	P87C51RA
+	
P87C51RA+@PLCC44 [(SA244)]	P87C51RA+@TQFP44
[(SA245A)]	
P87C51RA2	P87C51RA2@PLCC44
[(SA244)]	
P87C51RA2@TQFP44 [(SA245A)]	P87C51RB
+	
P87C51RB+@PLCC44 [(SA244)]	P87C51RB+@TQFP44
[(SA245A)]	
P87C51RB2	P87C51RB2@PLCC44
[(SA244)]	
P87C51RB2@TQFP44 [(SA245A)]	P87C51RC
+	
P87C51RC+@PLCC44 [(SA244)]	P87C51RC+@TQFP44
[(SA245A)]	
P87C51RC2	P87C51RC2@PLCC44
[(SA244)]	
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD
+	
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44
[(SA245A)]	
P87C51RD2	P87C51RD2@PLCC44
[(SA244)]	
P87C51RD2@TQFP44 [(SA245A)]	
P87C51SB	
P87C51SB@PLCC44 [(SA244)]	P87C51SB@TQFP44
[(SA245A)]	
P87C51SF	P87C51SF@PLCC44
[(SA244)]	
P87C51SF@TQFP44 [(SA245A)]	
P87C51UB	
P87C51UB@PLCC44 [(SA244)]	P87C51UB@TQFP44
[(SA245A)]	
P87C51UF	P87C51UF@PLCC44
[(SA244)]	
P87C51UF@TQFP44 [(SA245A)]	

P87C51X2	
P87C51X2@PLCC44 [(SA244)]	P87C51X2@TQFP44
[(SA245A)]	
P87C52	P87C52@PLCC44
[(SA244)]	
P87C52@TQFP44 [(SA245A)]	
P87C524	
P87C524@PLCC44 [(SA244)]	P87C524@TQFP44
[(SA245A)]	
P87C528	P87C528@PLCC44
[(SA244)]	
P87C528@TQFP44 [(SA245A)]	
P87C52SB	
P87C52SB@PLCC44 [(SA244)]	P87C52SB@TQFP44
[(SA245A)]	
P87C52SF	P87C52SF@PLCC44
[(SA244)]	
P87C52SF@TQFP44 [(SA675)]	
P87C52UB	
P87C52UB@PLCC44 [(SA244)]	P87C52UB@TQFP44
[(SA245A)]	
P87C52UF	P87C52UF@PLCC44
[(SA244)]	
P87C52UF@TQFP44 [(SA245A)]	
P87C52X2	
P87C52X2@PLCC44 [(SA244)]	P87C52X2@TQFP44
[(SA245A)]	
P87C54	P87C54@PLCC44
[(SA244)]	
P87C54@TQFP44 [(SA245A)]	
P87C54SB	
P87C54SB@PLCC44 [(SA244)]	P87C54SB@TQFP44
[(SA245A)]	
P87C54SF	P87C54SF@PLCC44
[(SA244)]	
P87C54SF@TQFP44 [(SA245A)]	
P87C54UB	
P87C54UB@PLCC44 [(SA244)]	P87C54UB@TQFP44
[(SA245A)]	
P87C54UF	P87C54UF@PLCC44
[(SA244)]	
P87C54UF@TQFP44 [(SA245A)]	
P87C54X2	

P87C54X2@PLCC44 [(SA244)]	P87C54X2@TQFP44
[(SA245A)]	
P87C550	P87C550@PLCC44
[(SA244)]	
P87C552@PLCC68(*) [(SA648-B6806)]	
P87C554@PLCC68(*) [(SA648-B6806)]	
P87C575	P87C575@PLCC44
[(SA244)]	
P87C575@TQFP44 [(SA245A)]	
P87C576	
P87C576@PLCC44 [(SA244)]	P87C576@TQFP44
[(SA245A)]	
P87C58	P87C58@PLCC44
[(SA244)]	
P87C58@TQFP44 [(SA245A)]	
P87C58SB	
P87C58SB@PLCC44 [(SA244)]	P87C58SB@TQFP44
[(SA245A)]	
P87C58UB	P87C58UB@PLCC44
[(SA244)]	
P87C58UB@TQFP44 [(SA245A)]	
P87C58X2	
P87C58X2@PLCC44 [(SA244)]	P87C58X2@TQFP44
[(SA245A)]	
P87C591@PLCC44 [(SA244)]	P87C591@TQFP44
[(SA245A)]	
P87C652	P87C652@PLCC44
[(SA244)]	
P87C652@TQFP44 [(SA245A)]	
P87C654	
P87C654@PLCC44 [(SA244)]	P87C654@TQFP44
[(SA245A)]	
P87C660X2@PLCC44 [(SA244)]	P87C660X2@TQFP44
[(SA245A)]	
P87C661X2@PLCC44 [(SA244)]	P87C661X2@TQFP44
[(SA245A)]	
P87C748	P87C748@PLCC28
[(SA008A)]	
P87C749	P87C749@PLCC28
[(SA008A)]	
P87C750	P87C750@PLCC28
[(SA008A)]	
P87C750@SSOP24 [(SA626A)]	

P87C751	
P87C751@PLCC28 [(SA008A)]	P87C751@SSOP24
[(SA626A)]	
P87C752	P87C752@PLCC28
[(SA008A)]	
P87C752@SSOP28 [(SA626A)]	
P87C754	
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28
[(SA626A)]	
P87CL52X2	P87CL52X2@PLCC44
[(SA244)]	
P87CL52X2@TQFP44 [(SA245A)]	
P87CL54X2	
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44
[(SA245A)]	
P87L51FA	P87L51FA@PLCC44
[(SA244)]	
P87L51FA@TQFP44 [(SA245A)]	
P87L51FB	
P87L51FB@PLCC44 [(SA244)]	P87L51FB@TQFP44
[(SA245A)]	
P87LPC759	P87LPC759(ISP) [ISP-
HEADER01]	
P87LPC760	P87LPC760(ISP) [ISP-
HEADER01]	
P87LPC760@TSSOP14 [(SA026)]	
P87LPC760@TSSOP14(ISP) [ISP-HEADER01]	
P87LPC761	P87LPC761(ISP) [ISP-
HEADER01]	
P87LPC762	P87LPC762(ISP) [ISP-
HEADER01]	
P87LPC762@PLCC44 [(SA244)]	
P87LPC762@PLCC44(ISP) [ISP-HEADER01]	
P87LPC762@SOIC20 [(SA404)]	
P87LPC762@SOIC20(ISP) [ISP-HEADER01]	
P87LPC764	P87LPC764(ISP) [ISP-
HEADER01]	
P87LPC764@PLCC44 [(SA244)]	
P87LPC764@PLCC44(ISP) [ISP-HEADER01]	
P87LPC764@SOIC20 [(SA404)]	
P87LPC764@SOIC20(ISP) [ISP-HEADER01]	
P87LPC764@TSSOP20 [(SA643)]	
P87LPC764@TSSOP20(ISP) [ISP-HEADER01]	

P87LPC767 HEADER01]	P87LPC767(ISP) [ISP-
P87LPC767@PLCC44 [(SA244)]	
P87LPC767@PLCC44(ISP) [ISP-HEADER01]	
P87LPC767@SOIC20 [(SA404)]	
P87LPC767@SOIC20(ISP) [ISP-HEADER01]	
P87LPC768 HEADER01]	P87LPC768(ISP) [ISP-
P87LPC768@SOIC20 [(SA404)]	
P87LPC768@SOIC20(ISP) [ISP-HEADER01]	
P87LPC769 HEADER01]	P87LPC769(ISP) [ISP-
P87LPC769@PLCC44 [(SA244)]	
P87LPC769@PLCC44(ISP) [ISP-HEADER01]	
P87LPC769@SOIC20 [(SA404)]	
P87LPC769@SOIC20(ISP) [ISP-HEADER01]	
P87LPC778 HEADER01]	P87LPC778(ISP) [ISP-
P87LPC778@TSSOP20 [(SA026)]	
P87LPC778@TSSOP20(ISP) [ISP-HEADER01]	
P87LPC779 HEADER01]	P87LPC779(ISP) [ISP-
P87LPC779@TSSOP20 [(SA643)]	
P87LPC779@TSSOP20(ISP) [ISP-HEADER01]	
P89C138 [(SA244)]	P89C138@PLCC44
P89C138@TQFP44 [(SA245A)]	
P89C238 [(SA244)]	P89C238@TQFP44
P89C238@PLCC44 [(SA244)]	
P89C238@PLCC44 [(SA245A)]	
P89C51B [(SA244)]	P89C51B@PLCC44
P89C51B@TQFP44 [(SA245A)]	P89C51RA
+	
P89C51RA+@PLCC44 [(SA244)]	P89C51RA+@TQFP44
[(SA245A)]	
P89C51RA2B [(SA244)]	P89C51RA2B@PLCC44
P89C51RA2B@TQFP44 [(SA245A)]	P89C51RB
+	
P89C51RB+@PLCC44 [(SA244)]	P89C51RB+@TQFP44
[(SA245A)]	
P89C51RB2B	P89C51RB2B@PLCC44

[(SA244)]	
P89C51RB2B@TQFP44 [(SA245A)]	
P89C51RB2H	
P89C51RB2H@PLCC44 [(SA244)]	P89C51RB2H@TQFP44
[(SA245A)]	
P89C51RC+	
[(SA244)]	
P89C51RC+@TQFP44 [(SA245A)]	P89C51RC+@PLCC44
P89C51RC2B	
P89C51RC2B@PLCC44 [(SA244)]	P89C51RC2B@TQFP44
[(SA245A)]	
P89C51RC2H	
[(SA244)]	
P89C51RC2H@TQFP44 [(SA245A)]	P89C51RC2H@PLCC44
+	
P89C51RD+@PLCC44 [(SA244)]	P89C51RD
[(SA245A)]	
P89C51RD2B	
[(SA244)]	
P89C51RD2B@TQFP44 [(SA245A)]	P89C51RD2B@PLCC44
P89C51RD2H	
P89C51RD2H@PLCC44 [(SA244)]	
[(SA245A)]	
P89C51RD2H@TQFP44 [(SA245A)]	P89C51RD2H@TQFP44
P89C51UB	
[(SA244)]	
P89C51UB@TQFP44 [(SA245A)]	P89C51UB@PLCC44
P89C51UF	
P89C51UF@PLCC44 [(SA244)]	
[(SA245A)]	
P89C51X2	
[(SA244)]	
P89C51X2@TQFP44 [(SA245A)]	P89C51X2@PLCC44
P89C51X2B	
P89C51X2B@PLCC44 [(SA244)]	
[(SA245A)]	
P89C51X2B@TQFP44 [(SA245A)]	P89C51X2B@TQFP44
P89C51X2F	
[(SA244)]	
P89C51X2F@PLCC44 [(SA244)]	P89C51X2F@PLCC44
P89C52	
P89C52@PLCC44 [(SA244)]	
[(SA245A)]	
P89C52@TQFP44 [(SA245A)]	P89C52@TQFP44
P89C52B	
[(SA244)]	
P89C52B@PLCC44 [(SA244)]	P89C52B@PLCC44

P89C52B@TQFP44 [(SA245A)]	
P89C52UB	
P89C52UB@PLCC44 [(SA244)]	P89C52UB@TQFP44
[(SA245A)]	
P89C52UF	
[(SA244)]	P89C52UF@PLCC44
P89C52UF@TQFP44 [(SA245A)]	
P89C52X2	
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44
[(SA245A)]	
P89C52X2B	
[(SA244)]	P89C52X2B@PLCC44
P89C52X2B@TQFP44 [(SA245A)]	
P89C52X2F	
P89C52X2F@PLCC44 [(SA244)]	P89C52X2F@TQFP44
[(SA245A)]	
P89C536@PLCC44 [(SA244)]	P89C538@PLCC44
[(SA244)]	
P89C54	
[(SA244)]	P89C54@PLCC44
P89C54@TQFP44 [(SA245A)]	
P89C54B	
P89C54B@PLCC44 [(SA244)]	P89C54B@TQFP44
[(SA245A)]	
P89C54UB	
[(SA244)]	P89C54UB@PLCC44
P89C54UB@TQFP44 [(SA245A)]	
P89C54UF	
P89C54UF@PLCC44 [(SA244)]	P89C54UF@TQFP44
[(SA245A)]	
P89C54X2	
[(SA244)]	P89C54X2@PLCC44
P89C54X2@TQFP44 [(SA245A)]	
P89C54X2B	
P89C54X2B@PLCC44 [(SA244)]	P89C54X2B@TQFP44
[(SA245A)]	
P89C54X2F	
[(SA244)]	P89C54X2F@PLCC44
P89C54X2F@TQFP44 [(SA245A)]	
P89C58	
P89C58@PLCC44 [(SA244)]	P89C58@TQFP44
[(SA245A)]	
P89C58B	
	P89C58B@PLCC44

[(SA244)]	
P89C58B@TQFP44 [(SA245A)]	
P89C58UB	
P89C58UB@PLCC44 [(SA244)]	P89C58UB@TQFP44
[(SA245A)]	
P89C58UF	
[(SA244)]	
P89C58UF@TQFP44 [(SA245A)]	P89C58UF@PLCC44
P89C58X2	
P89C58X2@PLCC44 [(SA244)]	P89C58X2@TQFP44
[(SA245A)]	
P89C58X2B	
[(SA244)]	
P89C58X2B@TQFP44 [(SA245A)]	P89C58X2B@PLCC44
P89C58X2F	
P89C58X2F@PLCC44 [(SA244)]	P89C58X2F@TQFP44
[(SA245A)]	
P89C60X2	
[(SA244)]	
P89C60X2@TQFP44 [(SA245A)]	P89C60X2@PLCC44
P89C61X2	
P89C61X2@PLCC44 [(SA244)]	P89C61X2@TQFP44
[(SA245A)]	
P89C660	
[(SA244)]	
P89C660@TQFP44 [(SA245A)]	P89C660@PLCC44
P89C662	
P89C662@PLCC44 [(SA244)]	P89C662@TQFP44
[(SA245A)]	
P89C664	
[(SA244)]	
P89C664@TQFP44 [(SA245A)]	P89C664@PLCC44
P89C668	
P89C668@PLCC44 [(SA244)]	P89C668@TQFP44
[(SA245A)]	
P89C669	
[(SA245A)]	
P89C669@PLCC44 [(SA244)]	P89C669@LQFP44
P89C738	
P89C738@PLCC44 [(SA244)]	P89C738@TQFP44
[(SA245A)]	
P89C838	
[(SA244)]	
	P89C838@PLCC44

P89C838@TQFP44 [(SA245A)] P89CV51RB2@PLCC44
[(SA244)]
P89CV51RB2@TQFP44 [(SA245A)] P89CV51RC2@PLCC44
[(SA244)]
P89CV51RC2@TQFP44 [(SA245A)] P89CV51RD2@PLCC44
[(SA244)]
P89CV51RD2@TQFP44 [(SA245A)] P89LPC901(FD)
[(SA602A)]
P89LPC901(FD)(ISP) [ISP-HEADER01]
P89LPC901(FN)
P89LPC901(FN)(ISP) [ISP-HEADER01]
P89LPC902(FD) [(SA602A)]
P89LPC902(FD)(ISP) [ISP-HEADER01]
P89LPC902(FN)
P89LPC902(FN)(ISP) [ISP-HEADER01]
P89LPC903(FD) [(SA602A)]
P89LPC903(FD)(ISP) [ISP-HEADER01]
P89LPC904(FD) [(SA605A)]
P89LPC904(FD)(ISP) [ISP-HEADER01]
P89LPC904(FN)
P89LPC904(FN)(ISP) [ISP-HEADER01]
P89LPC906(FD) [(SA605A)]
P89LPC906(FD)(ISP) [ISP-HEADER01]
P89LPC907(FD) [(SA605A)]
P89LPC907(FD)(ISP) [ISP-HEADER01]
P89LPC908(FD) [(SA605A)]
P89LPC908(FD)(ISP) [ISP-HEADER01]
P89LPC9102(FTK)@HVSON10 [(SA695A)]
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9103(FTK)@HVSON10 [(SA695A)]
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9107(FDH)@TSSOP14 [(SA643)]
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9107(FN)
P89LPC9107(FN)(ISP) [ISP-HEADER01]
P89LPC912(FDH)@TSSOP14 [(SA643)]
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC913(FDH)@TSSOP14 [(SA643)]
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC914(FDH)@TSSOP14 [(SA643)]
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC915(FDH)@TSSOP14 [(SA643)]
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]

P89LPC916(FDH)@TSSOP16 [(SA643)]
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC917(FDH)@TSSOP16 [(SA643)]
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC920(FDH)@TSSOP20 [(SA643)]
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920(FN)
P89LPC920(FN)(ISP) [ISP-HEADER01]
P89LPC9201(FDH)@TSSOP20 [(SA643)]
P89LPC9201(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9201(FN)
P89LPC9201(FN)(ISP) [ISP-HEADER01]
P89LPC920A1(FDH)@TSSOP20 [(SA643)]
P89LPC920A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920A1(FN)
P89LPC920A1(FN)(ISP) [ISP-HEADER01]
P89LPC921(FDH)@TSSOP20 [(SA643)]
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921(FN)
P89LPC921(FN)(ISP) [ISP-HEADER01]
P89LPC9211(FDH)@TSSOP20 [(SA643)]
P89LPC9211(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9211(FN)
P89LPC9211(FN)(ISP) [ISP-HEADER01]
P89LPC921A1(FDH)@TSSOP20 [(SA643)]
P89LPC921A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921A1(FN)
P89LPC921A1(FN)(ISP) [ISP-HEADER01]
P89LPC922(FDH)@TSSOP20 [(SA643)]
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922(FN)
P89LPC922(FN)(ISP) [ISP-HEADER01]
P89LPC9221(FDH)@TSSOP20 [(SA643)]
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221(FN)
P89LPC9221(FN)(ISP) [ISP-HEADER01]
P89LPC9221A1(FDH)@TSSOP20 [(SA643)]
P89LPC9221A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221A1(FN)
P89LPC9221A1(FN)(ISP) [ISP-HEADER01]
P89LPC922A1(FDH)@TSSOP20 [(SA643)]
P89LPC922A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922A1(FN)

P89LPC922A1(FN)(ISP) [ISP-HEADER01]
P89LPC924(FDH)@TSSOP20 [(SA643)]
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924(FN)
P89LPC924(FN)(ISP) [ISP-HEADER01]
P89LPC9241(FDH)@TSSOP20 [(SA643)]
P89LPC9241(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9241(FN)
P89LPC9241(FN)(ISP) [ISP-HEADER01]
P89LPC924A1(FDH)@TSSOP20 [(SA643)]
P89LPC924A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924A1(FN)
P89LPC924A1(FN)(ISP) [ISP-HEADER01]
P89LPC925(FDH)@TSSOP20 [(SA643)]
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925(FN)
P89LPC925(FN)(ISP) [ISP-HEADER01]
P89LPC9251(FDH)@TSSOP20 [(SA643)]
P89LPC9251(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9251(FN)
P89LPC9251(FN)(ISP) [ISP-HEADER01]
P89LPC925A1(FDH)@TSSOP20 [(SA643)]
P89LPC925A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925A1(FN)
P89LPC925A1(FN)(ISP) [ISP-HEADER01]
P89LPC930(BA)@PLCC28 [(SA008A)]
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC930(BDH)@TSSOP28 [(SA643)]
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9301(BA)@PLCC28 [(SA008A)]
P89LPC9301(BDH)@TSSOP28 [(SA643)]
P89LPC931(BA)@PLCC28 [(SA008A)]
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC931(BDH)@TSSOP28 [(SA643)]
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9311(BA)@PLCC28 [(SA008A)]
P89LPC9311(BDH)@TSSOP28 [(SA643)]
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28
[(SA643)]
P89LPC93201(BA)@PLCC28 [(SA008A)]
P89LPC93201(BDH)@TSSOP28 [(SA643)]
P89LPC93201(FA)@PLCC28 [(SA008A)]
P89LPC93201(FDH)@TSSOP28 [(SA643)]

P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9321(BA)@PLCC28 [(SA008A)]
P89LPC9321(BDH)@TSSOP28 [(SA643)]
P89LPC9321(FA)@PLCC28 [(SA008A)]
P89LPC9321(FDH)@TSSOP28 [(SA643)]
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(BA)@PLCC28 [(SA008A)]
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC932A1(BDH)@TSSOP28 [(SA643)]
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FDH)@TSSOP28 [(SA643)]
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC933(BDH)@TSSOP28 [(SA643)]
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(FDH)@TSSOP28 [(SA643)]
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(HDH)@TSSOP28 [(SA643)]
P89LPC9331(BDH)@TSSOP28 [(SA643)]
P89LPC9331(FDH)@TSSOP28 [(SA643)]
P89LPC9331(HDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC934(FDH)@TSSOP28 [(SA643)]
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC93401(FDH)@TSSOP28 [(SA643)]
P89LPC93401V
P89LPC9341(BDH)@TSSOP28 [(SA643)]
P89LPC9341(FDH)@TSSOP28 [(SA643)]
P89LPC9341V
P89LPC935(BA)@PLCC28
[(SA008A)]
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(BDH)@TSSOP28 [(SA643)]
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FA)@PLCC28 [(SA008A)]
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(FDH)@TSSOP28 [(SA643)]
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93501(BA)@PLCC28 [(SA008A)]
P89LPC93501(BDH)@TSSOP28 [(SA643)]

P89LPC93501(FA)@PLCC28 [(SA008A)]
P89LPC93501(FDH)@TSSOP28 [(SA643)]
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9351(BA)@PLCC28 [(SA008A)]
P89LPC9351(BDH)@TSSOP28 [(SA643)]
P89LPC9351(FA)@PLCC28 [(SA008A)]
P89LPC9351(FDH)@TSSOP28 [(SA643)]
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]
P89LPC936(FA)@PLCC28 [(SA008A)]
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC936(FDH)@TSSOP28 [(SA643)]
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9361(FA)@PLCC28 [(SA008A)]
P89LPC9361(FDH)@TSSOP28 [(SA643)]
P89LPC938(FA)@PLCC28 [(SA008A)]
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC938(FDH)@TSSOP28 [(SA643)]
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93801(BA)@PLCC28 [(SA008A)]
P89LPC93801(BDH)@TSSOP28 [(SA643)]
P89LPC93801(FA)@PLCC28 [(SA008A)]
P89LPC93801(FDH)@TSSOP28 [(SA643)]
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9381(BA)@PLCC28 [(SA008A)]
P89LPC9381(BDH)@TSSOP28 [(SA643)]
P89LPC9381(FA)@PLCC28 [(SA008A)]
P89LPC9381(FDH)@TSSOP28 [(SA643)]
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC952@LQFP44 [(SA245A)]
P89LPC952@LQFP44(ISP) [ISP-HEADER01]
P89LPC952@LQFP48 [(SA248)]
P89LPC952@LQFP48(ISP) [ISP-HEADER01]
P89LPC952@PLCC44 [(SA244)]
P89LPC952@PLCC44(ISP) [ISP-HEADER01]
P89LPC954@LQFP44 [(SA245A)]
P89LPC954@LQFP44(ISP) [ISP-HEADER01]
P89LPC954@LQFP48 [(SA248)]
P89LPC954@LQFP48(ISP) [ISP-HEADER01]
P89LPC954@PLCC44 [(SA244)]

P89LPC954@PLCC44 (ISP) [ISP-HEADER01]
 P89LV51RB2 P89LV51RB2@PLCC44
 [(SA244)]
 P89LV51RB2@TQFP44 [(SA245A)]
 P89LV51RC2
 P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44
 [(SA245A)]
 P89LV51RD2 P89LV51RD2
 (new)
 P89LV51RD2(new)@PLCC44 [(SA244)]
 P89LV51RD2(new)@TQFP44 [(SA245A)]
 P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44
 [(SA245A)]
 P89LV51RD2BA(new)@PLCC44 [(SA244)]
 P89LV51RD2BA@PLCC44 [(SA244)]
 P89LV51RD2BBC(new)@TQFP44 [(SA245A)]
 P89LV51RD2BBC@TQFP44 [(SA245A)]
 P89LV51RD2BN
 P89LV51RD2BN(new)
 P89LV51RD2FA(new)@PLCC44 [(SA244)]
 P89LV51RD2FA@PLCC44 [(SA244)]
 P89LV51RD2FBC(new)@TQFP44 [(SA245A)]
 P89LV51RD2FBC@TQFP44 [(SA245A)]
 P89LV51RD2FN
 P89LV51RD2FN(new)
 P89V51RB2
 P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44
 [(SA245A)]
 P89V51RC2 P89V51RC2@PLCC44
 [(SA244)]
 P89V51RC2@TQFP44 [(SA245A)]
 P89V51RD2
 P89V51RD2(new) P89V51RD2(new)@PLCC44
 [(SA244)]
 P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44
 [(SA244)]
 P89V51RD2@TQFP44 [(SA245A)]
 P89V51RD2BA(new)@PLCC44 [(SA244)]
 P89V51RD2BA@PLCC44 [(SA244)]
 P89V51RD2BBC(new)@TQFP44 [(SA245A)]
 P89V51RD2BBC@TQFP44 [(SA245A)]
 P89V51RD2BN
 P89V51RD2BN(new)

P89V51RD2FA(new)@PLCC44 [(SA244)]	
P89V51RD2FA@PLCC44 [(SA244)]	
P89V51RD2FBC(new)@TQFP44 [(SA245A)]	
P89V51RD2FBC@TQFP44 [(SA245A)]	
P89V51RD2FN	
P89V51RD2FN(new)	
P89V52X2	
P89V52X2(ISP) [ISP-HEADER01]	P89V52X2@PLCC44
[(SA244)]	
P89V52X2@PLCC44(ISP) [ISP-HEADER01]	
P89V52X2@TQFP44 [(SA245A)]	
P89V52X2@TQFP44(ISP) [ISP-HEADER01]	
P89V660@PLCC44 [(SA244)]	P89V660@TQFP44
[(SA245A)]	
P89V662@PLCC44 [(SA244)]	P89V662@TQFP44
[(SA245A)]	
P89V664@PLCC44 [(SA244)]	P89V664@TQFP44
[(SA245A)]	
PXAC37@PLCC44 [(SA244)]	PXAC37@TQFP44
[(SA245A)]	
PXAG17@PLCC44 [(SA244)]	PXAG17@TQFP44
[(SA245A)]	
PXAG27@PLCC44 [(SA244)]	PXAG27@TQFP44
[(SA245A)]	
PXAG37@PLCC44 [(SA244)]	PXAG37@TQFP44
[(SA245A)]	
PXAG39@PLCC44 [(SA244)]	PXAG39@TQFP44
[(SA245A)]	
PXAG49@PLCC44 [(SA244)]	PXAG49@TQFP44
[(SA245A)]	

OKI

E(E) PROM/FRAM/NVRAM

MSM16812(08bit)	MSM16812(08bit)@SOIC8
[(SA602A)]	
MSM271000	MSM271000@PLCC32
[(SA015A1T)]	
MSM271000@TSOP32 [(SA410T)]	
MSM27128	
MSM27128A	

MSM27128AS	
MSM27128AZB-RS	
MSM2716	
MSM27256	
MSM27256AS	
MSM27256ZB-RS	
MSM2732	
MSM2732A	
MSM27512	
MSM27512AS	MSM27512ZB-
RS	
MSM2764	
MSM2764A	
MSM2764AS	MSM2764AZB-
RS	
MSM2764RS	
MSM27C1024	
MSM27C1024AS	
MSM27C128	
MSM27C128AZB-RS	
MSM27C256	
MSM27C256A	
MSM27C256H	
MSM27C256HZB	
MSM27C256ZB	
MSM27C64AS	
MSM27C802CZ	
MSM27C802CZ@PSOP44 [(SA638)]	MSM27C802CZ@TSOP44
[(SA645)]	
MSM2816A(RS)	
MSM28C16A	

DRAM & SRAM

MSM51256	MSM51256@SOIC28
[(SA630)]	
MSM51257AL	MSM51257AL@SOIC28
[(SA630)]	
MSM51257ALL	MSM51257ALL@SOIC28
[(SA630)]	
MSM5165AL	MSM5165AL@SOIC28
[(SA630)]	

MSM5188
[(SA646)]

MSM5188@SOJ22

ON Semiconductor

E (E) PROM / FRAM / NVRAM

CAT1320
[(SA602A)]

CAT1320@SOIC8

CAT1320@TDFN8
[(SA026)]

CAT1320@TSSOP8

CAT1321
[(SA602A)]

CAT1321@SOIC8

CAT1321@TDFN8
[(SA026)]

CAT1321@TSSOP8

CAT14002@SOIC8 [(SA602A)]
[(SA602A)]

CAT14004@SOIC8

CAT14008@SOIC8 [(SA602A)]
[(SA602A)]

CAT14016@SOIC8

CAT15002@SOIC8 [(SA602A)]
[(SA602A)]

CAT15004@SOIC8

CAT15008@SOIC8 [(SA602A)]
[(SA602A)]

CAT15016@SOIC8

CAT1640
[(SA602A)]

CAT1640@SOIC8

CAT1640@TDFN8
[(SA026)]

CAT1640@TSSOP8

CAT1641
[(SA602A)]

CAT1641@SOIC8

CAT1641@TDFN8
[(SA026)]

CAT1641@TSSOP8

PFLASH(MSTAR)

E (E) PROM / FRAM / NVRAM

PS25LV010A@SOIC8 [(SA602A)]
[(SA683)]

PS25LV010A@WSON8

PS25LV020@SOIC8 [(SA602A)]
[(SA683)]

PS25LV020@WSON8

PS25LV040@SOIC8 [(SA605A)]
 [(SA683)]
 PS25LV080@SOIC8 [(SA605A)]
 [(SA683)]

PS25LV040@WSON8
 PS25LV080@WSON8

PHILIPS

E (E) PROM / FRAM / NVRAM

27C010
 [(SA015A1T)]
 27C010@TSOP32 [(SA410T)]
 27C040
 27C040@PLCC32 [(SA015A1T)]
 [(SA410T)]
 27C210
 [(SA244)]
 27C240
 [(SA244)]
 27C256
 [(SA015A1T)]
 27C32
 27C512
 27C512@PLCC32 [(SA015A1T)]
 27C64
 27C64@PLCC32 [(SA015A1T)]
 27C64A
 27C64A@PLCC32 [(SA015A1T)]
 27C64AF
 27C64AF@PLCC32 [(SA015A1T)]
 27HC641
 27HC641@PLCC28 [(SA008A)]
 27PC32
 PCA24S08@SOIC8 [(SA602A)]
 [(SA026)]
 PCA8574 (P)
 [(SA404)]
 PCA8574 (TS)@SSOP20 [(SA026)]
 (P)
 PCA8574A (T)@SOIC16 [(SA404)]
 [(SA026)]
 PCA8581

27C010@PLCC32
 27C040@TSOP32
 27C210@PLCC44
 27C240@PLCC44
 27C256@PLCC32
 PCA24S08@TSSOP8
 PCA8574 (T)@SOIC16
 PCA8574A
 PCA8574A (TS)@SSOP20
 PCA8581@SOIC8

[(SA602A)]	
PCA8581C	PCA8581C@SOIC8
[(SA602A)]	
PCA8582A	PCA8582A@SOIC8
[(SA602A)]	
PCA8582B	PCA8582B@SOIC8
[(SA602A)]	
PCA8582C	PCA8582C@SOIC8
[(SA602A)]	
PCA8582D	PCA8582D@SOIC8
[(SA602A)]	
PCA8582E	PCA8582E@SOIC8
[(SA602A)]	
PCA9500@HQVFN16	PCA9500@SOIC16
[(SA404)]	
PCA9500@TSSOP16 [(SA026)]	
PCA9501@HQVFN20	
PCA9501@SOIC20 [(SA404)]	PCA9501@TSSOP20
[(SA026)]	
PCA9561D@SOP20 [(SA404)]	PCA9561W@TSSOP20
[(SA026)]	
PCD8581	PCD8581@SOIC8
[(SA602A)]	
PCD8581C	PCD8581C@SOIC8
[(SA602A)]	
PCD8582A	PCD8582A@SOIC8
[(SA602A)]	
PCD8582B	PCD8582B@SOIC8
[(SA602A)]	
PCD8582C	PCD8582C@SOIC8
[(SA602A)]	
PCD8582D	PCD8582D@SOIC8
[(SA602A)]	
PCD8582E	PCD8582E@SOIC8
[(SA602A)]	
PCF85102C	PCF85102C@SOIC8
[(SA602A)]	
PCF85103C	PCF85103C@SOIC8
[(SA602A)]	
PCF85116	PCF85116@SOIC8
[(SA602A)]	
PCF8581	PCF8581@SOIC8
[(SA602A)]	

PCF8581C [(SA602A)]	PCF8581C@SOIC8
PCF8582A [(SA602A)]	PCF8582A@SOIC8
PCF8582B [(SA602A)]	PCF8582B@SOIC8
PCF8582C [(SA602A)]	PCF8582C@SOIC8
PCF8582D [(SA602A)]	PCF8582D@SOIC8
PCF8582E [(SA602A)]	PCF8582E@SOIC8
PCF8594 [(SA602A)]	PCF8594@SOIC8
PCF8594C [(SA602A)]	PCF8594C@SOIC8
PCF8594D [(SA602A)]	PCF8594D@SOIC8
PCF8594E [(SA602A)]	PCF8594E@SOIC8
PCF8598 [(SA605A)]	PCF8598@SOIC8
PCF8598C [(SA605A)]	PCF8598C@SOIC8
PCF8598D [(SA605A)]	PCF8598D@SOIC8
PCF8598E [(SA605A)]	PCF8598E@SOIC8

MICROCONTROLLER

P83C660X2@PLCC44 [(SA244)] [(SA245A)]	P83C660X2@TQFP44
P83C661X2@PLCC44 [(SA244)] [(SA245A)]	P83C661X2@TQFP44
P87C51 [(SA244)]	P87C51@PLCC44
P87C51@TQFP44 [(SA245A)]	
P87C51FA P87C51FA@PLCC44 [(SA244)] [(SA245A)]	P87C51FA@TQFP44
P87C51FB	P87C51FB@PLCC44

[(SA244)]	
P87C51FB@TQFP44 [(SA245A)]	
P87C51FC	
P87C51FC@PLCC44 [(SA244)]	P87C51FC@TQFP44
[(SA245A)]	
P87C51MA2@PLCC44 [(SA244)]	P87C51MB2@PLCC44
[(SA244)]	
P87C51MC2@PLCC44 [(SA244)]	P87C51RA
+	
P87C51RA+@PLCC44 [(SA244)]	P87C51RA+@TQFP44
[(SA245A)]	
P87C51RA2	P87C51RA2@PLCC44
[(SA244)]	
P87C51RA2@TQFP44 [(SA245A)]	P87C51RB
+	
P87C51RB+@PLCC44 [(SA244)]	P87C51RB+@TQFP44
[(SA245A)]	
P87C51RB2	P87C51RB2@PLCC44
[(SA244)]	
P87C51RB2@TQFP44 [(SA245A)]	P87C51RC
+	
P87C51RC+@PLCC44 [(SA244)]	P87C51RC+@TQFP44
[(SA245A)]	
P87C51RC2	P87C51RC2@PLCC44
[(SA244)]	
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD
+	
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44
[(SA245A)]	
P87C51RD2	P87C51RD2@PLCC44
[(SA244)]	
P87C51RD2@TQFP44 [(SA245A)]	
P87C51SB	
P87C51SB@PLCC44 [(SA244)]	P87C51SB@TQFP44
[(SA245A)]	
P87C51SF	P87C51SF@PLCC44
[(SA244)]	
P87C51SF@TQFP44 [(SA245A)]	
P87C51UB	
P87C51UB@PLCC44 [(SA244)]	P87C51UB@TQFP44
[(SA245A)]	
P87C51UF	P87C51UF@PLCC44
[(SA244)]	

P87C51UF@TQFP44 [(SA245A)]	
P87C51X2	
P87C51X2@PLCC44 [(SA244)]	P87C51X2@TQFP44
[(SA245A)]	
P87C52	P87C52@PLCC44
[(SA244)]	
P87C52@TQFP44 [(SA245A)]	
P87C524	
P87C524@PLCC44 [(SA244)]	P87C524@TQFP44
[(SA245A)]	
P87C528	P87C528@PLCC44
[(SA244)]	
P87C528@TQFP44 [(SA245A)]	
P87C52SB	
P87C52SB@PLCC44 [(SA244)]	P87C52SB@TQFP44
[(SA245A)]	
P87C52SF	P87C52SF@PLCC44
[(SA244)]	
P87C52SF@TQFP44 [(SA675)]	
P87C52UB	
P87C52UB@PLCC44 [(SA244)]	P87C52UB@TQFP44
[(SA245A)]	
P87C52UF	P87C52UF@PLCC44
[(SA244)]	
P87C52UF@TQFP44 [(SA245A)]	
P87C52X2	
P87C52X2@PLCC44 [(SA244)]	P87C52X2@TQFP44
[(SA245A)]	
P87C54	P87C54@PLCC44
[(SA244)]	
P87C54@TQFP44 [(SA245A)]	
P87C54SB	
P87C54SB@PLCC44 [(SA244)]	P87C54SB@TQFP44
[(SA245A)]	
P87C54SF	P87C54SF@PLCC44
[(SA244)]	
P87C54SF@TQFP44 [(SA245A)]	
P87C54UB	
P87C54UB@PLCC44 [(SA244)]	P87C54UB@TQFP44
[(SA245A)]	
P87C54UF	P87C54UF@PLCC44
[(SA244)]	
P87C54UF@TQFP44 [(SA245A)]	

P87C54X2	
P87C54X2@PLCC44 [(SA244)]	P87C54X2@TQFP44
[(SA245A)]	
P87C550	P87C550@PLCC44
[(SA244)]	
P87C552@PLCC68(*) [(SA648-B6806)]	
P87C554@PLCC68(*) [(SA648-B6806)]	
P87C575	P87C575@PLCC44
[(SA244)]	
P87C575@TQFP44 [(SA245A)]	
P87C576	
P87C576@PLCC44 [(SA244)]	P87C576@TQFP44
[(SA245A)]	
P87C58	P87C58@PLCC44
[(SA244)]	
P87C58@TQFP44 [(SA245A)]	
P87C58SB	
P87C58SB@PLCC44 [(SA244)]	P87C58SB@TQFP44
[(SA245A)]	
P87C58UB	P87C58UB@PLCC44
[(SA244)]	
P87C58UB@TQFP44 [(SA245A)]	
P87C58X2	
P87C58X2@PLCC44 [(SA244)]	P87C58X2@TQFP44
[(SA245A)]	
P87C591@PLCC44 [(SA244)]	P87C591@TQFP44
[(SA245A)]	
P87C652	P87C652@PLCC44
[(SA244)]	
P87C652@TQFP44 [(SA245A)]	
P87C654	
P87C654@PLCC44 [(SA244)]	P87C654@TQFP44
[(SA245A)]	
P87C660X2@PLCC44 [(SA244)]	P87C660X2@TQFP44
[(SA245A)]	
P87C661X2@PLCC44 [(SA244)]	P87C661X2@TQFP44
[(SA245A)]	
P87C748	P87C748@PLCC28
[(SA008A)]	
P87C749	P87C749@PLCC28
[(SA008A)]	
P87C750	P87C750@PLCC28
[(SA008A)]	

P87C750@SSOP24 [(SA626A)]	
P87C751	
P87C751@PLCC28 [(SA008A)]	P87C751@SSOP24
[(SA626A)]	
P87C752	P87C752@PLCC28
[(SA008A)]	
P87C752@SSOP28 [(SA626A)]	
P87C754	
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28
[(SA626A)]	
P87CL52X2	P87CL52X2@PLCC44
[(SA244)]	
P87CL52X2@TQFP44 [(SA245A)]	
P87CL54X2	
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44
[(SA245A)]	
P87L51FA	P87L51FA@PLCC44
[(SA244)]	
P87L51FA@TQFP44 [(SA245A)]	
P87L51FB	
P87L51FB@PLCC44 [(SA244)]	P87L51FB@TQFP44
[(SA245A)]	
P87LPC759	P87LPC759(ISP) [ISP-
HEADER01]	
P87LPC760	P87LPC760(ISP) [ISP-
HEADER01]	
P87LPC760@TSSOP14 [(SA026)]	
P87LPC760@TSSOP14(ISP) [ISP-HEADER01]	
P87LPC761	P87LPC761(ISP) [ISP-
HEADER01]	
P87LPC762	P87LPC762(ISP) [ISP-
HEADER01]	
P87LPC762@PLCC44 [(SA244)]	
P87LPC762@PLCC44(ISP) [ISP-HEADER01]	
P87LPC762@SOIC20 [(SA404)]	
P87LPC762@SOIC20(ISP) [ISP-HEADER01]	
P87LPC764	P87LPC764(ISP) [ISP-
HEADER01]	
P87LPC764@PLCC44 [(SA244)]	
P87LPC764@PLCC44(ISP) [ISP-HEADER01]	
P87LPC764@SOIC20 [(SA404)]	
P87LPC764@SOIC20(ISP) [ISP-HEADER01]	
P87LPC764@TSSOP20 [(SA643)]	

```

P87LPC764@TSSOP20 (ISP) [ ISP-HEADER01 ]
P87LPC767                                P87LPC767 (ISP) [ ISP-
HEADER01 ]
P87LPC767@PLCC44 [ (SA244) ]
P87LPC767@PLCC44 (ISP) [ ISP-HEADER01 ]
P87LPC767@SOIC20 [ (SA404) ]
P87LPC767@SOIC20 (ISP) [ ISP-HEADER01 ]
P87LPC768                                P87LPC768 (ISP) [ ISP-
HEADER01 ]
P87LPC768@SOIC20 [ (SA404) ]
P87LPC768@SOIC20 (ISP) [ ISP-HEADER01 ]
P87LPC769                                P87LPC769 (ISP) [ ISP-
HEADER01 ]
P87LPC769@PLCC44 [ (SA244) ]
P87LPC769@PLCC44 (ISP) [ ISP-HEADER01 ]
P87LPC769@SOIC20 [ (SA404) ]
P87LPC769@SOIC20 (ISP) [ ISP-HEADER01 ]
P87LPC778                                P87LPC778 (ISP) [ ISP-
HEADER01 ]
P87LPC778@TSSOP20 [ (SA026) ]
P87LPC778@TSSOP20 (ISP) [ ISP-HEADER01 ]
P87LPC779                                P87LPC779 (ISP) [ ISP-
HEADER01 ]
P87LPC779@TSSOP20 [ (SA643) ]
P87LPC779@TSSOP20 (ISP) [ ISP-HEADER01 ]
P89C138                                P89C138@PLCC44
[ (SA244) ]
P89C138@TQFP44 [ (SA245A) ]
P89C238                                P89C238@TQFP44
P89C238@PLCC44 [ (SA244) ]
[ (SA245A) ]
P89C51B                                P89C51B@PLCC44
[ (SA244) ]
P89C51B@TQFP44 [ (SA245A) ]
P89C51RA                                P89C51RA
+
P89C51RA+@PLCC44 [ (SA244) ]
[ (SA245A) ]
P89C51RA2B                                P89C51RA2B@PLCC44
[ (SA244) ]
P89C51RA2B@TQFP44 [ (SA245A) ]
+
P89C51RB                                P89C51RB
+
P89C51RB+@PLCC44 [ (SA244) ]
[ (SA245A) ]

```

P89C51RB2B [(SA244)]	P89C51RB2B@PLCC44
P89C51RB2B@TQFP44 [(SA245A)]	
P89C51RB2H P89C51RB2H@PLCC44 [(SA244)] [(SA245A)]	P89C51RB2H@TQFP44
P89C51RC+ [(SA244)]	P89C51RC+@PLCC44
P89C51RC+@TQFP44 [(SA245A)]	
P89C51RC2B P89C51RC2B@PLCC44 [(SA244)] [(SA245A)]	P89C51RC2B@TQFP44
P89C51RC2H [(SA244)]	P89C51RC2H@PLCC44
P89C51RC2H@TQFP44 [(SA245A)]	P89C51RD
+ P89C51RD+@PLCC44 [(SA244)] [(SA245A)]	P89C51RD+@TQFP44
P89C51RD2B [(SA244)]	P89C51RD2B@PLCC44
P89C51RD2B@TQFP44 [(SA245A)]	
P89C51RD2H P89C51RD2H@PLCC44 [(SA244)] [(SA245A)]	P89C51RD2H@TQFP44
P89C51UB [(SA244)]	P89C51UB@PLCC44
P89C51UB@TQFP44 [(SA245A)]	
P89C51UF P89C51UF@PLCC44 [(SA244)] [(SA245A)]	P89C51UF@TQFP44
P89C51X2 [(SA244)]	P89C51X2@PLCC44
P89C51X2@TQFP44 [(SA245A)]	
P89C51X2B P89C51X2B@PLCC44 [(SA244)] [(SA245A)]	P89C51X2B@TQFP44
P89C51X2F [(SA244)]	P89C51X2F@PLCC44
P89C51X2F@TQFP44 [(SA245A)]	
P89C52 P89C52@PLCC44 [(SA244)] [(SA245A)]	P89C52@TQFP44
P89C52B	P89C52B@PLCC44

[(SA244)]	
P89C52B@TQFP44 [(SA245A)]	
P89C52UB	
P89C52UB@PLCC44 [(SA244)]	P89C52UB@TQFP44
[(SA245A)]	
P89C52UF	
[(SA244)]	
P89C52UF@TQFP44 [(SA245A)]	P89C52UF@PLCC44
P89C52X2	
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44
[(SA245A)]	
P89C52X2B	
[(SA244)]	
P89C52X2B@TQFP44 [(SA245A)]	P89C52X2B@PLCC44
P89C52X2F	
P89C52X2F@PLCC44 [(SA244)]	P89C52X2F@TQFP44
[(SA245A)]	
P89C536@PLCC44 [(SA244)]	P89C538@PLCC44
[(SA244)]	
P89C54	
[(SA244)]	
P89C54@TQFP44 [(SA245A)]	P89C54@PLCC44
P89C54B	
P89C54B@PLCC44 [(SA244)]	P89C54B@TQFP44
[(SA245A)]	
P89C54UB	
[(SA244)]	
P89C54UB@TQFP44 [(SA245A)]	P89C54UB@PLCC44
P89C54UF	
P89C54UF@PLCC44 [(SA244)]	P89C54UF@TQFP44
[(SA245A)]	
P89C54X2	
[(SA244)]	
P89C54X2@TQFP44 [(SA245A)]	P89C54X2@PLCC44
P89C54X2B	
P89C54X2B@PLCC44 [(SA244)]	P89C54X2B@TQFP44
[(SA245A)]	
P89C54X2F	
[(SA244)]	
P89C54X2F@TQFP44 [(SA245A)]	P89C54X2F@PLCC44
P89C58	
P89C58@PLCC44 [(SA244)]	P89C58@TQFP44
[(SA245A)]	

P89C58B [(SA244)]	P89C58B@PLCC44
P89C58B@TQFP44 [(SA245A)]	
P89C58UB P89C58UB@PLCC44 [(SA244)] [(SA245A)]	P89C58UB@TQFP44
P89C58UF [(SA244)]	P89C58UF@PLCC44
P89C58UF@TQFP44 [(SA245A)]	
P89C58X2 P89C58X2@PLCC44 [(SA244)] [(SA245A)]	P89C58X2@TQFP44
P89C58X2B [(SA244)]	P89C58X2B@PLCC44
P89C58X2B@TQFP44 [(SA245A)]	
P89C58X2F P89C58X2F@PLCC44 [(SA244)] [(SA245A)]	P89C58X2F@TQFP44
P89C60X2 [(SA244)]	P89C60X2@PLCC44
P89C60X2@TQFP44 [(SA245A)]	
P89C61X2 P89C61X2@PLCC44 [(SA244)] [(SA245A)]	P89C61X2@TQFP44
P89C660 [(SA244)]	P89C660@PLCC44
P89C660@TQFP44 [(SA245A)]	
P89C662 P89C662@PLCC44 [(SA244)] [(SA245A)]	P89C662@TQFP44
P89C664 [(SA244)]	P89C664@PLCC44
P89C664@TQFP44 [(SA245A)]	
P89C668 P89C668@PLCC44 [(SA244)] [(SA245A)]	P89C668@TQFP44
P89C669 [(SA245A)]	P89C669@LQFP44
P89C669@PLCC44 [(SA244)]	
P89C738 P89C738@PLCC44 [(SA244)] [(SA245A)]	P89C738@TQFP44
P89C838	P89C838@PLCC44

```

[ (SA244) ]
P89C838@TQFP44 [ (SA245A) ]           P89CV51RB2@PLCC44
[ (SA244) ]
P89CV51RB2@TQFP44 [ (SA245A) ]       P89CV51RC2@PLCC44
[ (SA244) ]
P89CV51RC2@TQFP44 [ (SA245A) ]       P89CV51RD2@PLCC44
[ (SA244) ]
P89CV51RD2@TQFP44 [ (SA245A) ]       P89LPC901 (FD)
[ (SA602A) ]
P89LPC901 (FD) (ISP) [ ISP-HEADER01 ]
P89LPC901 (FN)
P89LPC901 (FN) (ISP) [ ISP-HEADER01 ]
P89LPC902 (FD) [ (SA602A) ]
P89LPC902 (FD) (ISP) [ ISP-HEADER01 ]
P89LPC902 (FN)
P89LPC902 (FN) (ISP) [ ISP-HEADER01 ]
P89LPC903 (FD) [ (SA602A) ]
P89LPC903 (FD) (ISP) [ ISP-HEADER01 ]
P89LPC904 (FD) [ (SA605A) ]
P89LPC904 (FD) (ISP) [ ISP-HEADER01 ]
P89LPC904 (FN)
P89LPC904 (FN) (ISP) [ ISP-HEADER01 ]
P89LPC906 (FD) [ (SA605A) ]
P89LPC906 (FD) (ISP) [ ISP-HEADER01 ]
P89LPC907 (FD) [ (SA605A) ]
P89LPC907 (FD) (ISP) [ ISP-HEADER01 ]
P89LPC908 (FD) [ (SA605A) ]
P89LPC908 (FD) (ISP) [ ISP-HEADER01 ]
P89LPC9102 (FTK)@HVSON10 [ (SA695A) ]
P89LPC9102 (FTK)@HVSON10 (ISP) [ ISP-HEADER01 ]
P89LPC9103 (FTK)@HVSON10 [ (SA695A) ]
P89LPC9103 (FTK)@HVSON10 (ISP) [ ISP-HEADER01 ]
P89LPC9107 (FDH)@TSSOP14 [ (SA643) ]
P89LPC9107 (FDH)@TSSOP14 (ISP) [ ISP-HEADER01 ]
P89LPC9107 (FN)
P89LPC9107 (FN) (ISP) [ ISP-HEADER01 ]
P89LPC912 (FDH)@TSSOP14 [ (SA643) ]
P89LPC912 (FDH)@TSSOP14 (ISP) [ ISP-HEADER01 ]
P89LPC913 (FDH)@TSSOP14 [ (SA643) ]
P89LPC913 (FDH)@TSSOP14 (ISP) [ ISP-HEADER01 ]
P89LPC914 (FDH)@TSSOP14 [ (SA643) ]
P89LPC914 (FDH)@TSSOP14 (ISP) [ ISP-HEADER01 ]
P89LPC915 (FDH)@TSSOP14 [ (SA643) ]

```

P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC916(FDH)@TSSOP16 [(SA643)]
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC917(FDH)@TSSOP16 [(SA643)]
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC920(FDH)@TSSOP20 [(SA643)]
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920(FN)
P89LPC920(FN)(ISP) [ISP-HEADER01]
P89LPC9201(FDH)@TSSOP20 [(SA643)]
P89LPC9201(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9201(FN)
P89LPC9201(FN)(ISP) [ISP-HEADER01]
P89LPC920A1(FDH)@TSSOP20 [(SA643)]
P89LPC920A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920A1(FN)
P89LPC920A1(FN)(ISP) [ISP-HEADER01]
P89LPC921(FDH)@TSSOP20 [(SA643)]
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921(FN)
P89LPC921(FN)(ISP) [ISP-HEADER01]
P89LPC9211(FDH)@TSSOP20 [(SA643)]
P89LPC9211(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9211(FN)
P89LPC9211(FN)(ISP) [ISP-HEADER01]
P89LPC921A1(FDH)@TSSOP20 [(SA643)]
P89LPC921A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921A1(FN)
P89LPC921A1(FN)(ISP) [ISP-HEADER01]
P89LPC922(FDH)@TSSOP20 [(SA643)]
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922(FN)
P89LPC922(FN)(ISP) [ISP-HEADER01]
P89LPC9221(FDH)@TSSOP20 [(SA643)]
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221(FN)
P89LPC9221(FN)(ISP) [ISP-HEADER01]
P89LPC9221A1(FDH)@TSSOP20 [(SA643)]
P89LPC9221A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221A1(FN)
P89LPC9221A1(FN)(ISP) [ISP-HEADER01]
P89LPC922A1(FDH)@TSSOP20 [(SA643)]
P89LPC922A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]

P89LPC922A1 (FN)
P89LPC922A1 (FN) (ISP) [ISP-HEADER01]
P89LPC924 (FDH)@TSSOP20 [(SA643)]
P89LPC924 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]
P89LPC924 (FN)
P89LPC924 (FN) (ISP) [ISP-HEADER01]
P89LPC9241 (FDH)@TSSOP20 [(SA643)]
P89LPC9241 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]
P89LPC9241 (FN)
P89LPC9241 (FN) (ISP) [ISP-HEADER01]
P89LPC924A1 (FDH)@TSSOP20 [(SA643)]
P89LPC924A1 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]
P89LPC924A1 (FN)
P89LPC924A1 (FN) (ISP) [ISP-HEADER01]
P89LPC925 (FDH)@TSSOP20 [(SA643)]
P89LPC925 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]
P89LPC925 (FN)
P89LPC925 (FN) (ISP) [ISP-HEADER01]
P89LPC9251 (FDH)@TSSOP20 [(SA643)]
P89LPC9251 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]
P89LPC9251 (FN)
P89LPC9251 (FN) (ISP) [ISP-HEADER01]
P89LPC925A1 (FDH)@TSSOP20 [(SA643)]
P89LPC925A1 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]
P89LPC925A1 (FN)
P89LPC925A1 (FN) (ISP) [ISP-HEADER01]
P89LPC930 (BA)@PLCC28 [(SA008A)]
P89LPC930 (BA)@PLCC28 (ISP) [ISP-HEADER01]
P89LPC930 (BDH)@TSSOP28 [(SA643)]
P89LPC930 (BDH)@TSSOP28 (ISP) [ISP-HEADER01]
P89LPC9301 (BA)@PLCC28 [(SA008A)]
P89LPC9301 (BDH)@TSSOP28 [(SA643)]
P89LPC931 (BA)@PLCC28 [(SA008A)]
P89LPC931 (BA)@PLCC28 (ISP) [ISP-HEADER01]
P89LPC931 (BDH)@TSSOP28 [(SA643)]
P89LPC931 (BDH)@TSSOP28 (ISP) [ISP-HEADER01]
P89LPC9311 (BA)@PLCC28 [(SA008A)]
P89LPC9311 (BDH)@TSSOP28 [(SA643)]
P89LPC932 (BA)@PLCC28 [(SA008A)] P89LPC932 (BDH)@TSSOP28
[(SA643)]
P89LPC93201 (BA)@PLCC28 [(SA008A)]
P89LPC93201 (BDH)@TSSOP28 [(SA643)]
P89LPC93201 (FA)@PLCC28 [(SA008A)]

P89LPC93201(FDH)@TSSOP28 [(SA643)]
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9321(BA)@PLCC28 [(SA008A)]
P89LPC9321(BDH)@TSSOP28 [(SA643)]
P89LPC9321(FA)@PLCC28 [(SA008A)]
P89LPC9321(FDH)@TSSOP28 [(SA643)]
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(BA)@PLCC28 [(SA008A)]
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC932A1(BDH)@TSSOP28 [(SA643)]
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FDH)@TSSOP28 [(SA643)]
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC933(BDH)@TSSOP28 [(SA643)]
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(FDH)@TSSOP28 [(SA643)]
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(HDH)@TSSOP28 [(SA643)]
P89LPC9331(BDH)@TSSOP28 [(SA643)]
P89LPC9331(FDH)@TSSOP28 [(SA643)]
P89LPC9331(HDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC934(FDH)@TSSOP28 [(SA643)]
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC93401(FDH)@TSSOP28 [(SA643)]
P89LPC93401V
P89LPC9341(BDH)@TSSOP28 [(SA643)]
P89LPC9341(FDH)@TSSOP28 [(SA643)]
P89LPC9341V
P89LPC935(BA)@PLCC28
[(SA008A)]
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(BDH)@TSSOP28 [(SA643)]
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FA)@PLCC28 [(SA008A)]
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(FDH)@TSSOP28 [(SA643)]
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93501(BA)@PLCC28 [(SA008A)]

P89LPC93501(BDH)@TSSOP28 [(SA643)]
P89LPC93501(FA)@PLCC28 [(SA008A)]
P89LPC93501(FDH)@TSSOP28 [(SA643)]
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9351(BA)@PLCC28 [(SA008A)]
P89LPC9351(BDH)@TSSOP28 [(SA643)]
P89LPC9351(FA)@PLCC28 [(SA008A)]
P89LPC9351(FDH)@TSSOP28 [(SA643)]
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]
P89LPC936(FA)@PLCC28 [(SA008A)]
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC936(FDH)@TSSOP28 [(SA643)]
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9361(FA)@PLCC28 [(SA008A)]
P89LPC9361(FDH)@TSSOP28 [(SA643)]
P89LPC938(FA)@PLCC28 [(SA008A)]
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC938(FDH)@TSSOP28 [(SA643)]
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93801(BA)@PLCC28 [(SA008A)]
P89LPC93801(BDH)@TSSOP28 [(SA643)]
P89LPC93801(FA)@PLCC28 [(SA008A)]
P89LPC93801(FDH)@TSSOP28 [(SA643)]
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9381(BA)@PLCC28 [(SA008A)]
P89LPC9381(BDH)@TSSOP28 [(SA643)]
P89LPC9381(FA)@PLCC28 [(SA008A)]
P89LPC9381(FDH)@TSSOP28 [(SA643)]
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC952@LQFP44 [(SA245A)]
P89LPC952@LQFP44(ISP) [ISP-HEADER01]
P89LPC952@LQFP48 [(SA248)]
P89LPC952@LQFP48(ISP) [ISP-HEADER01]
P89LPC952@PLCC44 [(SA244)]
P89LPC952@PLCC44(ISP) [ISP-HEADER01]
P89LPC954@LQFP44 [(SA245A)]
P89LPC954@LQFP44(ISP) [ISP-HEADER01]
P89LPC954@LQFP48 [(SA248)]
P89LPC954@LQFP48(ISP) [ISP-HEADER01]

P89LPC954@PLCC44 [(SA244)]
 P89LPC954@PLCC44(ISP) [ISP-HEADER01]
 P89LV51RB2 P89LV51RB2@PLCC44
 [(SA244)]
 P89LV51RB2@TQFP44 [(SA245A)]
 P89LV51RC2
 P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44
 [(SA245A)]
 P89LV51RD2 P89LV51RD2
 (new)
 P89LV51RD2(new)@PLCC44 [(SA244)]
 P89LV51RD2(new)@TQFP44 [(SA245A)]
 P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44
 [(SA245A)]
 P89LV51RD2BA(new)@PLCC44 [(SA244)]
 P89LV51RD2BA@PLCC44 [(SA244)]
 P89LV51RD2BBC(new)@TQFP44 [(SA245A)]
 P89LV51RD2BBC@TQFP44 [(SA245A)]
 P89LV51RD2BN
 P89LV51RD2BN(new)
 P89LV51RD2FA(new)@PLCC44 [(SA244)]
 P89LV51RD2FA@PLCC44 [(SA244)]
 P89LV51RD2FBC(new)@TQFP44 [(SA245A)]
 P89LV51RD2FBC@TQFP44 [(SA245A)]
 P89LV51RD2FN
 P89LV51RD2FN(new)
 P89V51RB2
 P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44
 [(SA245A)]
 P89V51RC2 P89V51RC2@PLCC44
 [(SA244)]
 P89V51RC2@TQFP44 [(SA245A)]
 P89V51RD2
 P89V51RD2(new) P89V51RD2(new)@PLCC44
 [(SA244)]
 P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44
 [(SA244)]
 P89V51RD2@TQFP44 [(SA245A)]
 P89V51RD2BA(new)@PLCC44 [(SA244)]
 P89V51RD2BA@PLCC44 [(SA244)]
 P89V51RD2BBC(new)@TQFP44 [(SA245A)]
 P89V51RD2BBC@TQFP44 [(SA245A)]
 P89V51RD2BN

P89V51RD2BN(new)	
P89V51RD2FA(new)@PLCC44 [(SA244)]	
P89V51RD2FA@PLCC44 [(SA244)]	
P89V51RD2FBC(new)@TQFP44 [(SA245A)]	
P89V51RD2FBC@TQFP44 [(SA245A)]	
P89V51RD2FN	
P89V51RD2FN(new)	
P89V52X2	
P89V52X2(ISP) [ISP-HEADER01]	P89V52X2@PLCC44
[(SA244)]	
P89V52X2@PLCC44(ISP) [ISP-HEADER01]	
P89V52X2@TQFP44 [(SA245A)]	
P89V52X2@TQFP44(ISP) [ISP-HEADER01]	
P89V660@PLCC44 [(SA244)]	P89V660@TQFP44
[(SA245A)]	
P89V662@PLCC44 [(SA244)]	P89V662@TQFP44
[(SA245A)]	
P89V664@PLCC44 [(SA244)]	P89V664@TQFP44
[(SA245A)]	
PXAC37@PLCC44 [(SA244)]	PXAC37@TQFP44
[(SA245A)]	
PXAG17@PLCC44 [(SA244)]	PXAG17@TQFP44
[(SA245A)]	
PXAG27@PLCC44 [(SA244)]	PXAG27@TQFP44
[(SA245A)]	
PXAG37@PLCC44 [(SA244)]	PXAG37@TQFP44
[(SA245A)]	
PXAG39@PLCC44 [(SA244)]	PXAG39@TQFP44
[(SA245A)]	
PXAG49@PLCC44 [(SA244)]	PXAG49@TQFP44
[(SA245A)]	

PJ

E(E) PROM/FRAM/NVRAM

PJ24C02	PJ24C02@SOIC8
[(SA602A)]	
PJ24C02@TSSOP8 [(SA026)]	

PMC

E (E) PROM / FRAM / NVRAM

PM24C64	PM24C64@SOIC8
[(SA602A)]	
PM24C64@TSOP8 [(SA026)]	PM25LV010 (B) @SOIC8
[(SA023A)]	
PM25LV010 (Q) @WSON8 [(SA683)]	PM25LV010 (S) @SOIC8
[(SA602A)]	
PM25LV010A@SOIC8 [(SA602A)]	PM25LV010A@WSON8
[(SA683)]	
PM25LV016@SOIC8 [(SA605A)]	PM25LV016@WSON8
[(SA683)]	
PM25LV016A@SOIC8 [(SA605A)]	PM25LV016A@WSON8
[(SA683)]	
PM25LV020 (B) @SOIC8 [(SA023A)]	PM25LV020 (Q) @WSON8
[(SA683)]	
PM25LV020 (S) @SOIC8 [(SA602A)]	PM25LV040 (B) @SOIC8
[(SA023A)]	
PM25LV040 (Q) @WSON8 [(SA683)]	PM25LV040 (S) @SOIC8
[(SA602A)]	
PM25LV080@SOIC8 [(SA605A)]	PM25LV080@WSON8
[(SA683)]	
PM25LV080A@SOIC8 [(SA605A)]	PM25LV080A@WSON8
[(SA683)]	
PM25LV512 (B) @SOIC8 [(SA023A)]	PM25LV512 (Q) @WSON8
[(SA683)]	
PM25LV512 (S) @SOIC8 [(SA602A)]	PM25LV512A (B) @SOIC8
[(SA023A)]	
PM25LV512A (Q) @WSON8 [(SA683)]	PM25LV512A (S) @SOIC8
[(SA602A)]	
PM29F002B	PM29F002B@PLCC32
[(SA015A1T)]	
PM29F002T	PM29F002T@PLCC32
[(SA015A1T)]	
PM29F004B	PM29F004B@PLCC32
[(SA015A1T)]	
PM29F004T	PM29F004T@PLCC32
[(SA015A1T)]	
PM29LV002B	PM29LV002B@PLCC32
[(SA015A1T)]	
PM29LV002B@VSOP32 [(SA620)]	
PM29LV002T	

PM29LV002T@PLCC32 [(SA015A1T)] [(SA620)]	PM29LV002T@VSOP32
PM29LV004B@PLCC32 [(SA015A1T)] [(SA620)]	PM29LV004B@VSOP32
PM29LV004T@PLCC32 [(SA015A1T)] [(SA620)]	PM29LV004T@VSOP32
PM29LV104RB@PLCC32 [(SA015A1T)] [(SA620)]	PM29LV104RB@VSOP32
PM29LV104RT@PLCC32 [(SA015A1T)] [(SA620)]	PM29LV104RT@VSOP32
PM37LV512 [(SA015A1T)]	PM37LV512@PLCC32
PM37LV512@VSOP32 [(SA620)]	
PM39F010 PM39F010@PLCC32 [(SA015A1T)] [(SA620)]	PM39F010@VSOP32
PM39F020 [(SA015A1T)]	PM39F020@PLCC32
PM39F020@VSOP32 [(SA620)]	
PM39F040 PM39F040@PLCC32 [(SA015A1T)] [(SA620)]	PM39F040@VSOP32
PM39LV010@PLCC32 [(SA015A1T)] [(SA620)]	PM39LV010@VSOP32
PM39LV010R@PLCC32 [(SA015A1T)] [(SA620)]	PM39LV010R@VSOP32
PM39LV020@PLCC32 [(SA015A1T)] [(SA620)]	PM39LV020@VSOP32
PM39LV040@PLCC32 [(SA015A1T)] [(SA620)]	PM39LV040@VSOP32
PM39LV512@PLCC32 [(SA015A1T)] [(SA620)]	PM39LV512@VSOP32
PM39LV512R@PLCC32 [(SA015A1T)] [(SA620)]	PM39LV512R@VSOP32
PM49FL002T@PLCC32 [(SA015A1T)] [(SA620)]	PM49FL002T@VSOP32
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)] [(SA620)]	PM49FL004T@VSOP32
PM49FL008T@PLCC32 [(SA015A1T)] [(SA620)]	PM49FL008T@VSOP32
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32

[(SA620)]

PSS

E (E) PROM / FRAM / NVRAM

PS24C256
[(SA602A)]

PS24C256@SOIC8

PTC

E (E) PROM / FRAM / NVRAM

PT28C020
[(SA015A1T)]
PT28C040
[(SA015A1T)]
PT29C020
[(SA015A1T)]
PT29C040
[(SA015A1T)]

PT28C020@PLCC32

PT28C040@PLCC32

PT29C020@PLCC32

PT29C040@PLCC32

MICROCONTROLLER

PT89316
[(SA244)]
PT89316@TQFP44 [(SA245A)]
PT8932
PT8932@PLCC44 [(SA244)]
[(SA245)]
PT8936
[(SA244)]
PT8936@TQFP44 [(SA245A)]
PT8956
PT8956@PLCC44 [(SA244)]
[(SA245A)]

PT89316@PLCC44

PT8932@TQFP44

PT8936@PLCC44

PT8956@TQFP44

QIXIN

MICROCONTROLLER

LS2051
[(SA404)]

LS2051@SOIC20

Quick Pulse

E (E) PROM / FRAM / NVRAM

27010
27011
27040
27128A
27210
27256
27512
2764A

RAMTRON

E (E) PROM / FRAM / NVRAM

FM1208
[(SA404)]
FM1608
[(SA404)]
FM1808
[(SA404)]
FM18L08
[(SA404)]
FM24164
[(SA602A)]
FM24C04 (P)
[(SA602A)]
FM24C04A (P)
[(SA602A)]
FM24C16 (P)
[(SA602A)]
FM24C16A (P)
[(SA602A)]

FM1208@SOIC24

FM1608@SOIC28

FM1808@SOIC28

FM18L08@SOIC28

FM24164@SOIC8

FM24C04 (S) @SOP8

FM24C04A (S) @SOP8

FM24C16 (S) @SOP8

FM24C16A (S) @SOP8

FM24C256@SOIC8 [(SA605A)]	FM24C512@SOIC8
[(SA602A)]	
FM24C64	FM24C64@SOIC8
[(SA602A)]	
FM24CL04	FM24CL04@SOIC8
[(SA602A)]	
FM24CL16	FM24CL16@SOIC8
[(SA602A)]	
FM24CL64@SOIC8 [(SA602A)]	
FM25040	
FM25040@SOIC8 [(SA602A)]	
FM25160	
FM25160@SOIC8 [(SA602A)]	
FM25640	
FM25640@SOIC8 [(SA602A)]	
FM25C160	
FM25C160@SOIC8 [(SA602A)]	FM25CL04@SOIC8
[(SA602A)]	
FM25CL64	FM25CL64@SOIC8
[(SA602A)]	
FM25L16	FM25L16@SOIC8
[(SA602A)]	
FM25L256	FM25L256@SOIC8
[(SA602A)]	
FM25L256@TDFN8 [(BBBB)]	
FM25L512	
FM25L512@SOIC8 [(SA602A)]	FM25W256@SOIC8
[(SA602A)]	
FM30C256@SOIC20 [(SA404)]	FM3104@SOIC14
[(SA602)]	
FM3116@SOIC14 [(SA602)]	FM31256@SOIC14
[(SA602)]	
FM3164@SOIC14 [(SA602)]	FM32256G@SOIC14
[(SA602)]	
FM32256S@SOIC14 [(SA602)]	FM3264G@SOIC14
[(SA602)]	
FM3264S@SOIC14 [(SA602)]	
FM3808	
FM3808@TSOP32 [(SA620)]	

MICROCONTROLLER

VMX51C900 [(SA244)]	VMX51C900@PLCC44
VMX51C900@TQFP44 [(SA245A)]	
VRS1000 VRS1000@PLCC44 [(SA244)] [(SA245A)]	VRS1000@TQFP44
VRS1100 [(SA244)]	VRS1100@PLCC44
VRS1100@TQFP44 [(SA245A)]	
VRS51C1000 VRS51C1000@PLCC44 [(SA244)] [(SA245A)]	VRS51C1000@TQFP44
VRS51C1100 [(SA244)]	VRS51C1100@PLCC44
VRS51C1100@TQFP44 [(SA245A)]	
VRS51C540 VRS51C540@PLCC44 [(SA244)] [(SA245A)]	VRS51C540@TQFP44
VRS51C550 [(SA244)]	VRS51C550@PLCC44
VRS51C550@TQFP44 [(SA245A)]	
VRS51C560 VRS51C560@PLCC44 [(SA244)] [(SA245A)]	VRS51C560@TQFP44
VRS51C570 [(SA244)]	VRS51C570@PLCC44
VRS51C570@TQFP44 [(SA245A)]	
VRS51C580 VRS51C580@PLCC44 [(SA244)] [(SA245A)]	VRS51C580@TQFP44
VRS51C700 [(SA244)]	VRS51C700@PLCC44
VRS51C700@TQFP44 [(SA245A)]	
VRS51L1050 VRS51L1050@PLCC44 [(SA244)] [(SA245A)]	VRS51L1050@TQFP44
VRS51L540 [(SA244)]	VRS51L540@PLCC44
VRS51L540@TQFP44 [(SA245A)]	
VRS51L550 VRS51L550@PLCC44 [(SA244)] [(SA245A)]	VRS51L550@TQFP44
VRS51L560	VRS51L560@PLCC44

[(SA244)]	
VRS51L560@TQFP44 [(SA245A)]	
VRS51L570	
VRS51L570@PLCC44 [(SA244)]	VRS51L570@TQFP44
[(SA245A)]	
VRS51L580	
[(SA244)]	VRS51L580@PLCC44
VRS51L580@TQFP44 [(SA245A)]	
VRS51X540	
VRS51X540@PLCC44 [(SA244)]	VRS51X540@TQFP44
[(SA245A)]	
VRS51X550	
[(SA244)]	VRS51X550@PLCC44
VRS51X550@TQFP44 [(SA245A)]	
VRS51X560	
VRS51X560@PLCC44 [(SA244)]	VRS51X560@TQFP44
[(SA245A)]	
VRS51X570	
[(SA244)]	VRS51X570@PLCC44
VRS51X570@TQFP44 [(SA245A)]	
VRS51X580	
VRS51X580@PLCC44 [(SA244)]	VRS51X580@TQFP44
[(SA245A)]	
VRS540	
[(SA244)]	VRS540@PLCC44
VRS540@TQFP44 [(SA245A)]	
VRS550	
VRS550@PLCC44 [(SA244)]	VRS550@TQFP44
[(SA245A)]	
VRS560	
[(SA244)]	VRS560@PLCC44
VRS560@TQFP44 [(SA245A)]	
VRS570	
VRS570@PLCC44 [(SA244)]	VRS570@TQFP44
[(SA245A)]	
VRS580	
[(SA244)]	VRS580@PLCC44
VRS580@TQFP44 [(SA245A)]	
VRS700	
VRS700@PLCC44 [(SA244)]	VRS700@TQFP44
[(SA245A)]	
VRS900	
[(SA244)]	VRS900@PLCC44

VRS900@TQFP44 [(SA245A)]

RATO

E (E) PROM/FRAM/NVRAM

RT24A02 [(SA602A)]	RT24A02@SOIC8
RT24A02@TSSOP8 [(SA026)]	
RT24A04 RT24A04@SOIC8 [(SA602A)] [(SA026)]	RT24A04@TSSOP8
RT24A08 [(SA602A)]	RT24A08@SOIC8
RT24A08@TSSOP8 [(SA026)]	
RT24A16 RT24A16@SOIC8 [(SA602A)] [(SA026)]	RT24A16@TSSOP8
RT93C46B(16bit) [(SA602A)]	RT93C46B(16bit)@SOIC8
RT93C46B(16bit)@TSSOP8 [(SA026)] (08bit)	RT93LC46
RT93LC46(08bit)@SOIC8 [(SA602A)] [(SA026)]	RT93LC46(08bit)@TSSOP8
RT93LC46(16bit) [(SA602A)]	RT93LC46(16bit)@SOIC8
RT93LC46(16bit)@TSSOP8 [(SA026)]	

RAYDIUM

E (E) PROM/FRAM/NVRAM

RM24C02@SOP8 [(SA602A)] [(SA602A)]	RM24C04@SOP8
RM24C08@SOP8 [(SA602A)] [(SA602A)]	RM24C128@SOP8
RM24C16@SOP8 [(SA602A)] [(SA602A)]	RM24C32@SOP8
RM24C64@SOP8 [(SA602A)]	

RENESAS**E (E) PROM / FRAM / NVRAM**

HN58C256A (FP)@SOP28 [(SA630)] (P)	HN58C256A
HN58C256A (T)@TSOP28 [(SA643)] [(SA620)]	HN58C257A (T)@TSOP32
HN58V24256 [(SA602A)]	HN58V24256@SOIC8
HN58V24256@TSSOP14 [(SA026)]	
HN58V24512	
HN58V24512@SOIC8 [(SA602A)]	
HN58W241000	
HN58W241000@SOIC8 [(SA602A)]	
HN58X2402	
HN58X2402@SOIC8 [(SA602A)] [(SA026)]	HN58X2402@TSSOP8
HN58X2404 [(SA602A)]	HN58X2404@SOIC8
HN58X2404@TSSOP8 [(SA026)]	
HN58X2408	
HN58X2408@SOIC8 [(SA602A)] [(SA026)]	HN58X2408@TSSOP8
HN58X24128 [(SA602A)]	HN58X24128@SOIC8
HN58X2416 [(SA602A)]	HN58X2416@SOIC8
HN58X2416@TSSOP8 [(SA026)]	
HN58X24256	
HN58X24256@SOIC8 [(SA602A)]	
HN58X2432	
HN58X2432@SOIC8 [(SA602A)] [(SA026)]	HN58X2432@TSSOP8
HN58X24512 [(SA602A)]	HN58X24512@SOIC8
HN58X2464 [(SA602A)]	HN58X2464@SOIC8
HN58X2464@TSSOP8 [(SA026)] [(SA602A)]	HN58X2502@SOIC8
HN58X2502@TSSOP8 [(SA026)] [(SA602A)]	HN58X2504@SOIC8

HN58X2504@TSSOP8 [(SA026)] [(SA602A)]	HN58X25128@SOIC8
HN58X25128@TSSOP14 [(SA026)] [(SA602A)]	HN58X25256@SOIC8
HN58X25256@TSSOP14 [(SA026)] [(SA602A)]	HN58X2532@SOIC8
HN58X2532@TSSOP8 [(SA026)] [(SA602A)]	HN58X2564@SOIC8
HN58X2564@TSSOP8 [(SA026)]	
M5L2732	
M5L2732A	

DRAM & SRAM

R1LV0408C@SOP32 [(SA438T)] [(SA620)]	R1LV0408C@STSOP32
R1LV0408C@TSOP32 [(SA410T)]	

MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)] [(SA404)]	HD4074344@SOIC28
HD4074394@SDIP28 [(SA022A)] [(SA404)]	HD4074394@SOIC28
R5F21102DFP@TQFP32 [(SA663+B005)]	
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21102FP@TQFP32 [(SA663+B005)]	
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21103DFP@TQFP32 [(SA663+B005)]	
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21103FP@TQFP32 [(SA663+B005)]	
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21104DFP@TQFP32 [(SA663+B005)]	
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21104FP@TQFP32 [(SA663+B005)]	
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21112DFP@TQFP32 [(SA663+B005)]	
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21112FP@TQFP32 [(SA663+B005)]	
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21113DFP@TQFP32 [(SA663+B005)]	

R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21113FP@TQFP32 [(SA663+B005)]
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]
R5F21114DFP@TQFP32 [(SA663+B005)]
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21114FP@TQFP32 [(SA663+B005)]
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]
R5F21122DFP@TQFP32 [(SA663+B005)]
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21122FP@TQFP32 [(SA663+B005)]
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]
R5F21123DFP@TQFP32 [(SA663+B005)]
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21123FP@TQFP32 [(SA663+B005)]
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]
R5F21124DFP@TQFP32 [(SA663+B005)]
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21124FP@TQFP32 [(SA663+B005)]
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]
R5F21132DFP@TQFP32 [(SA663+B005)]
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21132FP@TQFP32 [(SA663+B005)]
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]
R5F21133DFP@TQFP32 [(SA663+B005)]
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21133FP@TQFP32 [(SA663+B005)]
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]
R5F21134DFP@TQFP32 [(SA663+B005)]
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21134FP@TQFP32 [(SA663+B005)]
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]
R5F21181DD@SDIP20 [(SA725-B005)]
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(single wire) [(SA725-B005)]
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]
R5F21181DSP@TSSOP20 [(SA026-B001)]
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21181SP@TSSOP20 [(SA026-B001)]
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]

R5F21181SP@TSSOP20(single wire) [(SA026-B001)]
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182DD@SDIP20 [(SA725-B005)]
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(single wire) [(SA725-B005)]
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]
R5F21182DSP@TSSOP20 [(SA026-B001)]
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182NP@QFN28 [(SA697-B006)]
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]
R5F21182NP@QFN28(single wire) [(SA697-B006)]
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21182NP@QFN28(UART mode) [(SA697+B006)]
R5F21182SP@TSSOP20 [(SA026-B001)]
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183DD@SDIP20 [(SA725-B005)]
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(single wire) [(SA725-B005)]
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]
R5F21183DSP@TSSOP20 [(SA026-B001)]
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183NP@QFN28 [(SA697-B006)]
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]
R5F21183NP@QFN28(single wire) [(SA697-B006)]
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21183NP@QFN28(UART mode) [(SA697+B006)]
R5F21183SP@TSSOP20 [(SA026-B001)]
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]

```
R5F21184DD@SDIP20 [(SA725-B005)]
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(single wire) [(SA725-B005)]
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]
R5F21184DSP@TSSOP20 [(SA026-B001)]
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184NP@QFN28 [(SA697-B006)]
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]
R5F21184NP@QFN28(single wire) [(SA697-B006)]
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21184NP@QFN28(UART mode) [(SA697+B006)]
R5F21184SP@TSSOP20 [(SA026-B001)]
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191DD@SDIP20 [(SA725-B005)]
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(single wire) [(SA725+B005)]
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]
R5F21191DSP@TSSOP20 [(SA026-B001)]
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191SP@TSSOP20 [(SA026-B001)]
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192DD@SDIP20 [(SA725-B005)]
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(single wire) [(SA725+B005)]
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]
R5F21192DSP@TSSOP20 [(SA026-B001)]
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]
```

```
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192NP@QFN28 [(SA697-B006)]
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]
R5F21192NP@QFN28(single wire) [(SA697+B006)]
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21192NP@QFN28(UART mode) [(SA697+B006)]
R5F21192SP@TSSOP20 [(SA026-B001)]
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193DD@SDIP20 [(SA725-B005)]
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(single wire) [(SA725+B005)]
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]
R5F21193DSP@TSSOP20 [(SA026-B001)]
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193NP@QFN28 [(SA697-B006)]
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]
R5F21193NP@QFN28(single wire) [(SA697+B006)]
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21193NP@QFN28(UART mode) [(SA697+B006)]
R5F21193SP@TSSOP20 [(SA026-B001)]
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194DD@SDIP20 [(SA725-B005)]
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(single wire) [(SA725+B005)]
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]
R5F21194DSP@TSSOP20 [(SA026-B001)]
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194NP@QFN28 [(SA697-B006)]
```

R5F21194NP@QFN28(single ISP) [ISP-HEADER01]
R5F21194NP@QFN28(single wire) [(SA697+B006)]
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21194NP@QFN28(UART mode) [(SA697+B006)]
R5F21194SP@TSSOP20 [(SA026-B001)]
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1DD@SDIP20 [(SA725-B005)]
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A1DSP@TSSOP20 [(SA026-B001)]
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1SP@TSSOP20 [(SA026-B001)]
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2DD@SDIP20 [(SA725-B005)]
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A2DSP@TSSOP20 [(SA026-B001)]
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2NP@QFN28 [(SA697-B006)]
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(single wire) [(SA697-B006)]
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]
R5F211A2SP@TSSOP20 [(SA026-B001)]
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3DD@SDIP20 [(SA725-B005)]
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A3DSP@TSSOP20 [(SA026-B001)]
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3NP@QFN28 [(SA697-B006)]
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(single wire) [(SA697-B006)]
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]
R5F211A3SP@TSSOP20 [(SA026-B001)]
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4DD@SDIP20 [(SA725-B005)]
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A4DSP@TSSOP20 [(SA026-B001)]
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4NP@QFN28 [(SA697-B006)]
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(single wire) [(SA697-B006)]
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]
R5F211A4SP@TSSOP20 [(SA026-B001)]
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1DD@SDIP20 [(SA725-B005)]
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]

R5F211B1DD@SDIP20(single wire) [(SA725+B005)]
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B1DSP@TSSOP20 [(SA026-B001)]
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1SP@TSSOP20 [(SA026-B001)]
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2DD@SDIP20 [(SA725-B005)]
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B2DSP@TSSOP20 [(SA026-B001)]
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2NP@QFN28 [(SA697-B006)]
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(single wire) [(SA697+B006)]
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]
R5F211B2SP@TSSOP20 [(SA026-B001)]
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3DD@SDIP20 [(SA725-B005)]
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B3DSP@TSSOP20 [(SA026-B001)]
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]

R5F211B3NP@QFN28 [(SA697-B006)]
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(single wire) [(SA697+B006)]
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]
R5F211B3SP@TSSOP20 [(SA026-B001)]
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4DD@SDIP20 [(SA725-B005)]
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B4DSP@TSSOP20 [(SA026-B001)]
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4NP@QFN28 [(SA697-B006)]
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(single wire) [(SA697+B006)]
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]
R5F211B4SP@TSSOP20 [(SA026-B001)]
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21206JFP@TQFP48 [(SA248-B005)]
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]
R5F21206KFP@TQFP48 [(SA248-B005)]
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]
R5F21207JFP@TQFP48 [(SA248-B005)]
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]
R5F21207KFP@TQFP48 [(SA248-B005)]
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]
R5F21208JFP@TQFP48 [(SA248-B005)]

R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]
R5F21208KFP@TQFP48 [(SA248-B005)]
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AJFP@TQFP48 [(SA248-B005)]
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AKFP@TQFP48 [(SA248-B005)]
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CJFP@TQFP48 [(SA248-B005)]
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CKFP@TQFP48 [(SA248-B005)]
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21216JFP@TQFP48 [(SA248-B005)]
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]
R5F21216KFP@TQFP48 [(SA248-B005)]
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]
R5F21217JFP@TQFP48 [(SA248-B005)]
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]
R5F21217KFP@TQFP48 [(SA248-B005)]
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]
R5F21218JFP@TQFP48 [(SA248-B005)]
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]
R5F21218KFP@TQFP48 [(SA248-B005)]
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AJFP@TQFP48 [(SA248-B005)]
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AKFP@TQFP48 [(SA248-B005)]
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CJFP@TQFP48 [(SA248-B005)]
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]

R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CKFP@TQFP48 [(SA248-B005)]
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21226JFP@TQFP48 [(SA248-B005)]
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]
R5F21226KFP@TQFP48 [(SA248-B005)]
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]
R5F21227JFP@TQFP48 [(SA248-B005)]
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]
R5F21227KFP@TQFP48 [(SA248-B005)]
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]
R5F21228JFP@TQFP48 [(SA248-B005)]
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]
R5F21228KFP@TQFP48 [(SA248-B005)]
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AJFP@TQFP48 [(SA248-B005)]
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AKFP@TQFP48 [(SA248-B005)]
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CJFP@TQFP48 [(SA248-B005)]
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CKFP@TQFP48 [(SA248-B005)]
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21236JFP@TQFP48 [(SA248-B005)]
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]
R5F21236KFP@TQFP48 [(SA248-B005)]
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]
R5F21237JFP@TQFP48 [(SA248-B005)]
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]

```
R5F21237KFP@TQFP48 [(SA248-B005)]
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]
R5F21238JFP@TQFP48 [(SA248-B005)]
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]
R5F21238KFP@TQFP48 [(SA248-B005)]
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AJFP@TQFP48 [(SA248-B005)]
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AKFP@TQFP48 [(SA248-B005)]
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CJFP@TQFP48 [(SA248-B005)]
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CKFP@TQFP48 [(SA248-B005)]
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]
```

R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]

R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]

R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]

R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]

R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]

```
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20 [(SA026-B001)]
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H1SNSP@TSSOP20 [(SA026-B001)]
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SDSP@TSSOP20 [(SA725-B005)]
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SNSP@TSSOP20 [(SA725-B005)]
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SDSP@TSSOP20 [(SA026-B001)]
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SNSP@TSSOP20 [(SA026-B001)]
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SDSP@TSSOP20 [(SA026-B001)]
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SNSP@TSSOP20 [(SA026-B001)]
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212K2SDFP@QFP32 [(SA663-B005)]
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SDFP@QFP32(single wire [(SA663-B005)])
R5F212K2SNFP@QFP32 [(SA663-B005)]
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SNFP@QFP32(single wire [(SA663-B005)])
R5F212K4SDFP@QFP32 [(SA663-B005)]
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SDFP@QFP32(single wire [(SA663-B005)])
R5F212K4SNFP@QFP32 [(SA663-B005)]
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SNFP@QFP32(single wire [(SA663-B005)])
```

R5F212L2SDFP@QFP32 [(SA663-B005)]
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]
R5F212L2SNFP@QFP32 [(SA663-B005)]
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]
R5F212L4SDFP@QFP32 [(SA663-B005)]
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]
R5F212L4SNFP@QFP32 [(SA663-B005)]
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]

RICOH

E (E) PROM/FRAM/NVRAM

RD27C256
RD27C32
RD27C64

ROCKWELL

E (E) PROM/FRAM/NVRAM

R2764
R2764C
R2764P
R27C64
R2816
R5213
R52B13
R52B33

ROHM

E (E) PROM/FRAM/NVRAM

BR24A01A(F) [(SA602A)]

BR24A01A(FJ)

[(SA602A)]	
BR24A02 (F) [(SA602A)]	BR24A02 (FJ)
[(SA602A)]	
BR24A04 (F) [(SA602A)]	BR24A04 (FJ)
[(SA602A)]	
BR24A08 (F) [(SA602A)]	BR24A08 (FJ)
[(SA602A)]	
BR24A16 (F) [(SA602A)]	BR24A16 (FJ)
[(SA602A)]	
BR24A32 (F) [(SA602A)]	BR24A32 (FJ)
[(SA602A)]	
BR24A64 (F) [(SA602A)]	BR24A64 (FJ)
[(SA602A)]	
BR24C01@SOP8 [(SA602A)]	BR24C01@TSSOP8
[(SA026)]	
BR24C01@TSSOP8 (3*3mm) [(SA666)]	
BR24C01A	
BR24C01A (F) [(SA602A)]	BR24C01A (FJ)
[(SA602A)]	
BR24C01A (FV) [(SA026)]	
BR24C02	
BR24C02 (F) [(SA602A)]	BR24C02 (FJ)
[(SA602A)]	
BR24C02 (FV) [(SA026)]	BR24C02@SOP8
[(SA602A)]	
BR24C02@TSSOP8 [(SA026)]	BR24C02@TSSOP8 (3*3mm)
[(SA666)]	
BR24C04	BR24C04 (F)
[(SA602A)]	
BR24C04 (FJ) [(SA602A)]	BR24C04 (FV)
[(SA026)]	
BR24C04@SOP8 [(SA602A)]	BR24C04@TSSOP8
[(SA026)]	
BR24C04@TSSOP8 (3*3mm) [(SA666)]	
BR24C08	
BR24C08 (F) [(SA602A)]	BR24C08 (FJ)
[(SA602A)]	
BR24C08 (FV) [(SA026)]	BR24C08@SOP8
[(SA602A)]	
BR24C08@TSSOP8 [(SA026)]	BR24C08@TSSOP8 (3*3mm)
[(SA666)]	
BR24C16	BR24C16 (F)
[(SA602A)]	

BR24C16(FJ) [(SA602A)]	BR24C16(FV)
[(SA026)]	
BR24C21	BR24C21(F)
[(SA602A)]	
BR24C21(FJ) [(SA602A)]	BR24C21(FV)
[(SA026)]	
BR24C32	BR24C32(F)
[(SA602A)]	
BR24C64	BR24C64(F)
[(SA602A)]	
BR24E16	BR24E16(F)
[(SA602A)]	
BR24E16(FJ) [(SA602A)]	BR24E16(FV)
[(SA026)]	
BR24G32	BR24G32(F)
[(SA602A)]	
BR24G32(FJ) [(SA602A)]	BR24G32(FV)
[(SA026)]	
BR24G32(FVT) [(SA026)]	
BR24L01A	
BR24L01A(F) [(SA602A)]	BR24L01A(FJ)
[(SA602A)]	
BR24L01A(FV) [(SA026)]	BR24L01A(FVM)
[(SA666)]	
BR24L02	BR24L02(F)
[(SA602A)]	
BR24L02(FJ) [(SA602A)]	BR24L02(FV)
[(SA026)]	
BR24L02(FVM) [(SA666)]	
BR24L04	
BR24L04(F) [(SA602A)]	BR24L04(FJ)
[(SA602A)]	
BR24L04(FV) [(SA026)]	BR24L04(FVM)
[(SA666)]	
BR24L08	BR24L08(F)
[(SA602A)]	
BR24L08(FJ) [(SA602A)]	BR24L08(FV)
[(SA026)]	
BR24L08(FVM) [(SA666)]	
BR24L16	
BR24L16(F) [(SA602A)]	BR24L16(FJ)
[(SA602A)]	
BR24L16(FV) [(SA026)]	BR24L16(FVM)

[(SA666)]	
BR24L32	BR24L32(F)
[(SA602A)]	
BR24L32(FJ) [(SA602A)]	BR24L32(FV)
[(SA026)]	
BR24L64	BR24L64(F)
[(SA602A)]	
BR24L64(FJ) [(SA602A)]	BR24L64(FV)
[(SA026)]	
BR24S08(F) [(SA602A)]	BR24S08(FJ)
[(SA602A)]	
BR24S08(FV) [(SA026)]	BR24S08(FVJ)
[(SA026)]	
BR24S08(FVM) [(SA666)]	BR24S08(FVT)
[(SA026)]	
BR24S128	BR24S128(F)
[(SA602A)]	
BR24S128(FJ) [(SA602A)]	BR24S128(FV)
[(SA026)]	
BR24S16	BR24S16(F)
[(SA602A)]	
BR24S16(FJ) [(SA602A)]	BR24S16(FV)
[(SA026)]	
BR24S16(FVM) [(SA666)]	
BR24S256	
BR24S256(F) [(SA602A)]	BR24S256(FJ)
[(SA602A)]	
BR24S256(FV) [(SA026)]	
BR24S32	
BR24S32(F) [(SA602A)]	BR24S32(FJ)
[(SA602A)]	
BR24S32(FV) [(SA026)]	
BR24S64	
BR24S64(F) [(SA602A)]	BR24S64(FJ)
[(SA602A)]	
BR24S64(FV) [(SA026)]	BR25010@SOIC8
[(SA602A)]	
BR25010@TSSOP8 [(SA026)]	BR25020@SOIC8
[(SA602A)]	
BR25020@TSSOP8 [(SA026)]	BR25040@SOIC8
[(SA602A)]	
BR25040@TSSOP8 [(SA026)]	BR25080@SOIC8
[(SA602A)]	

BR25080@TSSOP8 [(SA026)]	BR25160@SOIC8
[(SA602A)]	
BR25160@TSSOP8 [(SA026)]	BR25320@SOIC8
[(SA602A)]	
BR25H010(F) [(SA602A)]	BR25H010(FJ)
[(SA602A)]	
BR25H020(F) [(SA602A)]	BR25H020(FJ)
[(SA602A)]	
BR25H040(F) [(SA602A)]	BR25H040(FJ)
[(SA602A)]	
BR25H080(F) [(SA602A)]	BR25H080(FJ)
[(SA602A)]	
BR25H080(FVT) [(SA026)]	BR25H160(F)
[(SA602A)]	
BR25H160(FJ) [(SA602A)]	BR25H160(FVT)
[(SA026)]	
BR25H320(F) [(SA602A)]	BR25H320(FJ)
[(SA602A)]	
BR25H320(FVT) [(SA026)]	
BR25L010	
BR25L010(F) [(SA602A)]	BR25L010(FJ)
[(SA602A)]	
BR25L010(FV) [(SA026)]	BR25L010(FVM)
[(SA666)]	
BR25L020	BR25L020(F)
[(SA602A)]	
BR25L020(FJ) [(SA602A)]	BR25L020(FV)
[(SA026)]	
BR25L020(FVM) [(SA666)]	
BR25L040	
BR25L040(F) [(SA602A)]	BR25L040(FJ)
[(SA602A)]	
BR25L040(FV) [(SA026)]	BR25L040(FVM)
[(SA666)]	
BR25L080	BR25L080(F)
[(SA602A)]	
BR25L080(FJ) [(SA602A)]	BR25L080(FV)
[(SA026)]	
BR25L160	BR25L160(F)
[(SA602A)]	
BR25L160(FJ) [(SA602A)]	BR25L160(FV)
[(SA026)]	
BR25L320	BR25L320(F)

[(SA602A)]	
BR25L320 (FJ) [(SA602A)]	BR25L320 (FV)
[(SA026)]	
BR25L640	BR25L640 (F)
[(SA602A)]	
BR25L640 (FJ) [(SA602A)]	BR25L640 (FV)
[(SA026)]	
BR34C02A [(SA026)]	
BR34L02	
BR34L02 (F) [(SA602A)]	BR34L02 (FJ)
[(SA602A)]	
BR34L02 (FV) [(SA026)]	BR34L02 (FVM)
[(SA666)]	
BR9010	BR9010 (F)
[(SA602A)]	
BR9010 (FV) [(SA026)]	BR9010 (RFV)
[(SA026)]	
BR9010 (RFVM) [(SA666)]	
BR9016	
BR9016 (F) [(SA602A)]	BR9016 (RFV)
[(SA026)]	
BR9016A (F) [(SA602A)]	BR9016A (RFV)
[(SA026)]	
BR9016A (RFVM) [(SA666)]	
BR9020	
BR9020 (F) [(SA602A)]	BR9020 (FV)
[(SA026)]	
BR9020 (RFV) [(SA026)]	BR9020 (RFVM)
[(SA666)]	
BR9040	BR9040 (F)
[(SA602A)]	
BR9040 (FV) [(SA026)]	BR9040 (RFV)
[(SA026)]	
BR9040 (RFVM) [(SA666)]	
BR9080	
BR9080 (F) [(SA602A)]	BR9080 (RFV)
[(SA026)]	
BR9080A	BR9080A (F)
[(SA602A)]	
BR9080A (FV) [(SA026)]	BR9080A (RFV)
[(SA026)]	
BR9080A (RFVM) [(SA666)]	BR93A46 (F)
[(SA602A)]	

BR93A46 (FJ) [(SA602A)]	BR93A46 (RF)
[(SA602A)]	
BR93A46 (RFJ) [(SA602A)]	BR93A56 (F)
[(SA602A)]	
BR93A56 (FJ) [(SA602A)]	BR93A56 (RF)
[(SA602A)]	
BR93A56 (RFJ) [(SA602A)]	BR93A66 (F)
[(SA602A)]	
BR93A66 (FJ) [(SA602A)]	BR93A66 (RF)
[(SA602A)]	
BR93A66 (RFJ) [(SA602A)]	BR93A76 (F)
[(SA602A)]	
BR93A76 (FJ) [(SA602A)]	BR93A76 (RF)
[(SA602A)]	
BR93A76 (RFJ) [(SA602A)]	BR93A86 (F)
[(SA602A)]	
BR93A86 (FJ) [(SA602A)]	BR93A86 (RF)
[(SA602A)]	
BR93A86 (RFJ) [(SA602A)]	
BR93C46	
BR93C46 (F) [(SA602A)]	BR93C46 (FJ)
[(SA602A)]	
BR93C46 (FV) [(SA026)]	BR93C46 (RF)
[(SA602A)]	
BR93C46 (RFJ) [(SA602A)]	
BR93C56	
BR93C56 (F) [(SA602A)]	BR93C56 (FJ)
[(SA602A)]	
BR93C56 (FV) [(SA026)]	BR93C56 (RF)
[(SA602A)]	
BR93C56 (RFJ) [(SA602A)]	
BR93C66	
BR93C66 (F) [(SA602A)]	BR93C66 (FJ)
[(SA602A)]	
BR93C66 (FV) [(SA026)]	BR93C66 (RF)
[(SA602A)]	
BR93C66 (RFJ) [(SA602A)]	BR93H46 (RF)
[(SA602A)]	
BR93H46 (RFJ) [(SA602A)]	BR93H56 (RF)
[(SA602A)]	
BR93H56 (RFJ) [(SA602A)]	BR93H66 (RF)
[(SA602A)]	
BR93H66 (RFJ) [(SA602A)]	BR93H76 (RF)

[(SA602A)]	
BR93H76 (RFJ) [(SA602A)]	BR93H86 (RF)
[(SA602A)]	
BR93H86 (RFJ) [(SA602A)]	
BR93L46	
BR93L46 (F) [(SA602A)]	BR93L46 (FJ)
[(SA602A)]	
BR93L46 (FV) [(SA026)]	BR93L46 (RF)
[(SA602A)]	
BR93L46 (RFJ) [(SA602A)]	
BR93L56	
BR93L56 (F) [(SA602A)]	BR93L56 (FJ)
[(SA602A)]	
BR93L56 (FV) [(SA026)]	BR93L56 (RF)
[(SA602A)]	
BR93L56 (RFJ) [(SA602A)]	
BR93L66	
BR93L66 (F) [(SA602A)]	BR93L66 (FJ)
[(SA602A)]	
BR93L66 (FV) [(SA026)]	BR93L66 (RF)
[(SA602A)]	
BR93L66 (RFJ) [(SA602A)]	BR93L76 (F)
[(SA602A)]	
BR93L76 (FJ) [(SA602A)]	BR93L76 (RF)
[(SA602A)]	
BR93L76 (RFJ) [(SA602A)]	BR93L76 (RFV)
[(SA026A)]	
BR93L76 (RFVJ) [(SA666A)]	BR93L76 (RFVM)
[(SA666A)]	
BR93L76 (RFVT) [(SA026A)]	BR93L86 (F)
[(SA602A)]	
BR93L86 (FJ) [(SA602A)]	BR93L86 (RF)
[(SA602A)]	
BR93L86 (RFJ) [(SA602A)]	BR93L86 (RFV)
[(SA026A)]	
BR93L86 (RFVJ) [(SA666A)]	BR93L86 (RFVM)
[(SA666A)]	
BR93L86 (RFVT) [(SA026A)]	
BR93LC46	
BR93LC46 (F) [(SA602A)]	BR93LC46 (FJ)
[(SA602A)]	
BR93LC46 (FV) [(SA026)]	BR93LC46 (RF)
[(SA602A)]	

BR93LC46(RFJ) [(SA602A)]	
BR93LC56	
BR93LC56(F) [(SA602A)]	BR93LC56(FJ)
[(SA602A)]	
BR93LC56(FV) [(SA026)]	BR93LC56(RF)
[(SA602A)]	
BR93LC56(RFJ) [(SA602A)]	
BR93LC66	
BR93LC66(F) [(SA602A)]	BR93LC66(FJ)
[(SA602A)]	
BR93LC66(FV) [(SA026)]	BR93LC66(RF)
[(SA602A)]	
BR93LC66(RFJ) [(SA602A)]	BR93LL46(F)
[(SA602A)]	
BR93LL46(FV) [(SA026)]	BR95010(3*3)@TSSOP8
[(SA666)]	
BR95010@SO8 [(SA602A)]	BR95010@TSSOP8
[(SA026)]	
BR95020(3*3)@TSSOP8 [(SA666)]	BR95020@SO8
[(SA602A)]	
BR95020@TSSOP8 [(SA026)]	BR95040(3*3)@TSSOP8
[(SA666)]	
BR95040@SO8 [(SA602A)]	BR95040@TSSOP8
[(SA026)]	
BR95080@SO8 [(SA602A)]	BR95080@TSSOP8
[(SA026)]	
BR95160@SO8 [(SA602A)]	BR95160@TSSOP8
[(SA026)]	

SAIFUN

E(E) PROM/FRAM/NVRAM

SA24C1024	SA24C1024@SOIC8
[(SA602A)]	
SA24C512	SA24C512@SOIC8
[(SA602A)]	
SA24C512@TSSOP8 [(SA026)]	
SA25C020	
SA25C020@MLF8 [(SA683)]	SA25C020@SOIC8
[(SA602A)]	
SA25C040	SA25C040@MLF8

[(SA683)]	
SA25C040@SOIC8 [(SA602A)]	
SA25C080	
SA25C080@MLF8 [(SA683)]	SA25C080@SOIC8
[(SA602A)]	
SA25C1024(H)	SA25C1024(H)@CSP8
[(SA683)]	
SA25C1024(H)@SOIC8 [(SA602A)]	SA25C1024
(L)	
SA25C1024(L)@CSP8 [(SA683)]	SA25C1024(L)@SOIC8
[(SA602A)]	
SA25C512(H)	SA25C512(H)@CSP8
[(SA683)]	
SA25C512(H)@SOIC8 [(SA602A)]	SA25C512
(L)	
SA25C512(L)@CSP8 [(SA683)]	SA25C512(L)@SOIC8
[(SA602A)]	
SA25F005	SA25F005@MLF8
[(SA683)]	
SA25F005@SOIC8 [(SA602A)]	
SA25F010	
SA25F010@MLF8 [(SA683)]	SA25F010@SOIC8
[(SA602A)]	
SA25F020	SA25F020@MLF8
[(SA683)]	
SA25F020@SOIC8 [(SA602A)]	
SA25F040	
SA25F040@MLF8 [(SA683)]	SA25F040@SOIC8
[(SA602A)]	
SA25F080	SA25F080@MLF8
[(SA683)]	
SA25F080@SOIC8 [(SA602A)]	
SA25F160	
SA25F160(ISP) [ISP-HEADER01]	SA25F160@MLF8
[(SA683)]	
SA25F160@MLF8(ISP) [ISP-HEADER01]	
SA25F160@SOIC16 [(SA602)]	
SA25F160@SOIC16(ISP) [ISP-HEADER01]	

SAMSUNG

E (E) PROM / FRAM / NVRAM

KM2816A	
KM2816AI	
KM2817A	
KM2817AI	
KM2864A	
KM2864AH	
KM2865A	
KM2865AH	
KM28C16	KM28C16@PLCC32
[(SA015A1T)]	
KM28C16I	KM28C16I@PLCC32
[(SA015A1T)]	
KM28C17	KM28C17@PLCC32
[(SA015A1T)]	
KM28C17I	KM28C17I@PLCC32
[(SA015A1T)]	
KM28C256	KM28C256@PLCC32
[(SA015A1T)]	
KM28C256I	KM28C256I@PLCC32
[(SA015A1T)]	
KM28C64	KM28C64@PLCC32
[(SA015A1T)]	
KM28C64A	KM28C64A@PLCC32
[(SA015A1T)]	
KM28C64B	KM28C64B@PLCC32
[(SA015A1T)]	
KM28C64I	KM28C64I@PLCC32
[(SA015A1T)]	
KM28C65	KM28C65@PLCC32
[(SA015A1T)]	
KM28C65A	KM28C65A@PLCC32
[(SA015A1T)]	
KM28C65I	KM28C65I@PLCC32
[(SA015A1T)]	
KM93C06(08bit)	KM93C06
(16bit)	
KM93C06(G)(08bit)@SOIC8	[(SA602A)]
KM93C06(G)(16bit)@SOIC8	[(SA602A)]
KM93C06(GD)(08bit)@SOIC8	[(SA602A)]
KM93C06(GD)(16bit)@SOIC8	[(SA602A)]
KM93C07(08bit)	KM93C07
(16bit)	

KM93C07(G)(08bit)@SOIC8 [(SA602A)]	
KM93C07(G)(16bit)@SOIC8 [(SA602A)]	
KM93C07(GD)(08bit)@SOIC8 [(SA602A)]	
KM93C07(GD)(16bit)@SOIC8 [(SA602A)]	
KM93C46V	KM93C46V(G)@SOIC8
[(SA602A)]	
KM93C46V(GD)@SOIC8 [(SA602A)]	
KM93C47V	
KM93C47V(G)@SOIC8 [(SA602A)]	KM93C47V(GD)@SOIC8
[(SA602A)]	
KM93C56V	KM93C56V(G)@SOIC8
[(SA602A)]	
KM93C56V(GD)@SOIC8 [(SA602A)]	
KM93C57V	
KM93C57V(G)@SOIC8 [(SA602A)]	KM93C57V(GD)@SOIC8
[(SA602A)]	
KM93C66V	KM93C66V(G)@SOIC8
[(SA602A)]	
KM93C66V(GD)@SOIC8 [(SA602A)]	
KM93C67V	
KM93C67V(G)@SOIC8 [(SA602A)]	KM93C67V(GD)@SOIC8
[(SA602A)]	
KS24C010	KS24C010@SOIC8
[(SA602A)]	
KS24C010@TSSOP8 [(SA026)]	
KS24C011	
KS24C011@SOIC8 [(SA602A)]	KS24C011@TSSOP8
[(SA026)]	
KS24C020	KS24C020@SOIC8
[(SA602A)]	
KS24C020@TSSOP8 [(SA026)]	
KS24C021	
KS24C021@SOIC8 [(SA602A)]	KS24C021@TSSOP8
[(SA026)]	
KS24C040	KS24C040@SOIC8
[(SA602A)]	
KS24C040@TSSOP8 [(SA026)]	
KS24C041	
KS24C041@SOIC8 [(SA602A)]	KS24C041@TSSOP8
[(SA026)]	
KS24C080	KS24C080@SOIC8
[(SA602A)]	
KS24C080@TSSOP8 [(SA026)]	

KS24C081	
KS24C081@SOIC8 [(SA602A)]	KS24C081@TSSOP8
[(SA026)]	
S524A40X10	S524A40X10@SOP8
[(SA602A)]	
S524A40X10@TSSOP8 [(SA026)]	
S524A40X11	
S524A40X11@SOP8 [(SA602A)]	S524A40X11@TSSOP8
[(SA026)]	
S524A40X20	S524A40X20@SOP8
[(SA602A)]	
S524A40X20@TSSOP8 [(SA026)]	
S524A40X21	
S524A40X21@SOP8 [(SA602A)]	S524A40X21@TSSOP8
[(SA026)]	
S524A40X40	S524A40X40@SOP8
[(SA602A)]	
S524A40X40@TSSOP8 [(SA026)]	
S524A40X41	
S524A40X41@SOP8 [(SA602A)]	S524A40X41@TSSOP8
[(SA026)]	
S524A60X51	S524A60X51@SOP8
[(SA602A)]	
S524A60X51@TSSOP8 [(SA026)]	
S524A60X81	
S524A60X81@SOP8 [(SA602A)]	S524A60X81@TSSOP8
[(SA026)]	
S524AB0X91	S524AB0X91@SOP8
[(SA602A)]	
S524AB0X91@TSSOP8 [(SA026)]	
S524AB0XB1	
S524AB0XB1@SOP8 [(SA602A)]	S524AB0XB1@TSSOP8
[(SA026)]	
S524AD0XD1	S524AD0XD1@SOP8
[(SA602A)]	
S524AD0XD1@TSSOP8 [(SA026)]	
S524AD0XF1	
S524AD0XF1@SOP8 [(SA602A)]	S524AD0XF1@TSSOP8
[(SA026)]	
S524C20D11	S524C20D11@SOP8
[(SA602A)]	
S524C20D11@TSSOP8 [(SA026)]	
S524C20D21	

S524C20D21@SOP8 [(SA602A)]	S524C20D21@TSSOP8
[(SA026)]	
S524C80D41	S524C80D41@SOP8
[(SA602A)]	
S524C80D41@TSSOP8 [(SA026)]	
S524C80D81	
S524C80D81@SOP8 [(SA602A)]	S524C80D81@TSSOP8
[(SA026)]	
S524L50X51	S524L50X51@SOP8
[(SA602A)]	
S524L50X51@TSSOP8 [(SA026)]	
S524LB0X91	
S524LB0X91@SOP8 [(SA602A)]	S524LB0X91@TSSOP8
[(SA026)]	
S524LB0XB1	S524LB0XB1@SOP8
[(SA602A)]	
S524LB0XB1@TSSOP8 [(SA026)]	

DRAM & SRAM

KM61257	KM61257@SOJ24
[(SA646)]	
KM61257L	KM61257L@SOJ24
[(SA646)]	
KM6165	KM6165@SOJ24
[(SA646)]	
KM6165L	KM6165L@SOJ24
[(SA646)]	
KM62256A	KM62256A@SOIC28
[(SA630)]	
KM62256AL	KM62256AL@SOIC28
[(SA630)]	
KM6264A	KM6264A@SOIC28
[(SA630)]	
KM6264AL	KM6264AL@SOIC28
[(SA630)]	
KM64257	KM64257@SOJ24
[(SA646)]	
KM64257L	KM64257L@SOJ24
[(SA646)]	
KM6465LP	KM6465LP@SOJ22
[(SA646)]	

KM6465P
KM68257LP
KM68257LP@SOIC28 [(SA630)]
KM68257P
KM68257P@SOIC28 [(SA630)]
KM6865LP
KM6865LP@SOIC28 [(SA630)]
KM6865P
KM6865P@SOIC28 [(SA630)]

PLD

CPL16L8 [(SA001A)]	CPL16L8@PLCC20
CPL16L8L [(SA001A)]	CPL16L8L@PLCC20
CPL16R4 [(SA001A)]	CPL16R4@PLCC20
CPL16R4L [(SA001A)]	CPL16R4L@PLCC20
CPL16R6 [(SA001A)]	CPL16R6@PLCC20
CPL16R6L [(SA001A)]	CPL16R6L@PLCC20
CPL16R8 [(SA001A)]	CPL16R8@PLCC20
CPL16R8L [(SA001A)]	CPL16R8L@PLCC20

SANYO

E (E) PROM/FRAM/NVRAM

LE24C041 [(SA654)]	LE24C041@MFP8
LE24C042 [(SA654)]	LE24C042@MFP8
LE24C081 [(SA654)]	LE24C081@MFP8
LE24C082 [(SA654)]	LE24C082@MFP8

LE24C161 [(SA654)]	LE24C161@MFP8
LE24C162 [(SA654)]	LE24C162@MFP8
LE24C322@MFP8 [(SA654)] [(SA698)]	LE24C322@WLP6
LE24L322@MFP8 [(SA654)] [(SA654)]	LE25FU106BMA@MFP8
LE25FU106BTT@MSOP8 [(SA654)] [(SA602A)]	LE25FU406BMA@MFP8
LE25FU406BTT@MSOP8 [(SA654)] [(SA654)]	LE25FV055T@MSOP8
LE25FV101T@MSOP8 [(SA654)] [(SA654)]	LE25FV105T@MSOP8
LE25FV201T@MSOP8 [(SA654)] [(SA654)]	LE25FV401T@MSOP8
LE25FV411T@MSOP8 [(SA654)] [(SA620)]	LE25FV451T@VSOP32
LE25FW056FN@VSON8 [(SA683)] [(SA602A)]	LE25FW056MA@MFP8
LE25FW106M@SOP8 [(SA602A)] [(SA654)]	LE25FW106T@MSOP8
LE25FW1606FN@VSON8 [(SA683)] [(SA654)]	LE25FW203ATT@MSOP8
LE25FW206M@SOP8 [(SA602A)] [(SA654)]	LE25FW206T@MSOP8
LE25FW406BMA@MFP8 [(SA602A)] [(SA654)]	LE25FW406BTT@MSOP8
LE25FW406M@SOP8 [(SA602A)] [(SA654)]	LE25FW406T@MSOP8
LE25FW806M@SOP8 [(SA602A)] [(SA654)]	LE25FW806T@MSOP8
LE26CW006@WLP6 [(SA698)] [(SA687)]	LE28C1001AM@SOP32
LE28C1001AT@TSOP32 [(SA410T)] [(SA620)]	LE28C1001ATS@VSOP32
LE28C1001DT@TSOP32 [(SA410T)] [(SA620)]	LE28C1001DTS@VSOP32
LE28CV1001AT@TSOP32 [(SA410T)] [(SA620)]	LE28CV1001ATS@VSOP32
LE28CV1001DT@TSOP32 [(SA410T)] [(SA620)]	LE28CV1001DTS@VSOP32
LE28CW1001DT@TSOP32 [(SA410T)]	LE28CW1001DTS@VSOP32

[(SA620)]	
LE28F1101T@TSOP40 [(SA623)]	LE28F1601T@TSOP40
[(SA409T)]	
LE28F2001ATS@TSOP32 [(SA410T)]	LE28F4001ATS@TSOP32
[(SA410T)]	
LE28F4001M@SSOP32 [(SA438T)]	LE28F8001T@TSOP40
[(SA409T)]	
LE28FV1101T@TSOP40 [(SA623)]	LE28FV1601T@TSOP40
[(SA409T)]	
LE28FV2001ATS@TSOP32 [(SA410T)]	LE28FV4001ATS@TSOP32
[(SA410T)]	
LE28FV4001CTS@TSOP32 [(SA410T)]	LE28FV4001M@SSOP32
[(SA438T)]	
LE28FV4001T@TSOP40 [(SA409T)]	LE28FV8001T@TSOP40
[(SA409T)]	

SEEQ

E (E) PROM/FRAM/NVRAM

27128
27256
2764
27C256
2804
2804A
2816A
2816AH
5213
52B13
52B13H
52B23
52B23H
52B33
52B33H
5516A
5516AH
5517A
5517AH
DE2817A
DE2817A@PLCC32 [(SA015A1T)]
DE2817AH

DE2817AH@PLCC32 [(SA015A1T)]
DQ2817A
DQ2817A@PLCC32 [(SA015A1T)]
DQ2817AH
DQ2817AH@PLCC32 [(SA015A1T)]
DQ2864
DQ2864@PLCC32 [(SA015A1T)]
DQ2864H
DQ2864H@PLCC32 [(SA015A1T)]
DQ28C256
DQ28C256@PLCC32 [(SA015A1T)]
DQ28C64
DQ28C64@PLCC32 [(SA015A1T)]
DQ28C64A
DQ28C64A@PLCC32 [(SA015A1T)]
DQ28C65
DQ28C65@PLCC32 [(SA015A1T)]
DQ52B13
DQ52B13H
E28C64
E28C64@PLCC32 [(SA015A1T)]
E52B13
E52B13H
E52B23
E52B23H
E52B33
E52B33H
M28C64
M28C64@PLCC32 [(SA015A1T)]
M52B13
M52B13H
M52B23
M52B23H
M52B33
M52B33H
PQ2864
PQ2864@PLCC32 [(SA015A1T)]
PQ2864H
PQ2864H@PLCC32 [(SA015A1T)]
PQ28C64
PQ28C64@PLCC32 [(SA015A1T)]
PQ28C65
PQ28C65@PLCC32 [(SA015A1T)]

SEIKO**E (E) PROM / FRAM / NVRAM**

S-22H10 [(SA404)]	S-22H10@SOP18
S-22H12 [(SA404)]	S-22H12@SOP18
S-22S10 [(SA404)]	S-22S10@SOP18
S-22S12 [(SA404)]	S-22S12@SOP18
S-24C01A(DP) (DPA)	S-24C01A
S-24C01A(FJA)@SOIC8 [(SA602A)] (DP)	S-24C01B
S-24C01B(FJ)@SOIC8 [(SA602A)] (DP)	S-24C02A
S-24C02A(DPA) [(SA602A)]	S-24C02A(FJA)@SOIC8
S-24C02B(DP) [(SA602A)]	S-24C02B(FJ)@SOIC8
S-24C04A(DP) (DPA)	S-24C04A
S-24C04A(FJA)@SOIC8 [(SA602A)] (DP)	S-24C04B
S-24C04B(FJ)@SOIC8 [(SA602A)] (DPA)	S-24C08A
S-24C08A(FJA)@SOIC8 [(SA602A)] (DPA)	S-24C16A
S-24C16A(FJA)@SOIC8 [(SA602A)] (DP)	S-24CS01A
S-24CS01A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-24CS01A(FT)@TSSOP8
S-24CS02A(DP) [(SA602A)]	S-24CS02A(FJ)@SOIC8
S-24CS02A(FT)@TSSOP8 [(SA026)] (DP)	S-24CS04A
S-24CS04A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-24CS04A(FT)@TSSOP8
S-24CS08A(DP)	S-24CS08A(FJ)@SOIC8

[(SA602A)]	
S-24CS08A(FT)@TSSOP8 [(SA026)]	S-24CS16A
(DP)	
S-24CS16A(FJ)@SOIC8 [(SA602A)]	S-24CS16A(FT)@TSSOP8
[(SA026)]	
S-24CS64A(FJ)@SOIC8 [(SA602A)]	S-24CS64A(FT)@TSSOP8
[(SA026)]	
S-24H45	S-24H45@SOP8
[(SA605A)]	
S-24S45	S-24S45@SOP8
[(SA605A)]	
S-25A010A@SOP8 [(SA602A)]	S-25A020A@SOP8
[(SA602A)]	
S-25A040A@SOP8 [(SA602A)]	S-25A080A@SOP8
[(SA602A)]	
S-25A160A@SOP8 [(SA602A)]	S-25A320A@SOP8
[(SA602A)]	
S-25A640A@SOP8 [(SA602A)]	S-25C010A@SOP8
[(SA602A)]	
S-25C010A@TSSOP8 [(SA026)]	S-25C020A@SOP8
[(SA602A)]	
S-25C020A@TSSOP8 [(SA026)]	S-25C040A@SOP8
[(SA602A)]	
S-25C040A@TSSOP8 [(SA026)]	S-25C080A@SOP8
[(SA602A)]	
S-25C080A@TSSOP8 [(SA026)]	S-25C160A@SOP8
[(SA602A)]	
S-25C160A@TSSOP8 [(SA026)]	S-25C320A@SOP8
[(SA602A)]	
S-25C320A@TSSOP8 [(SA026)]	S-25C640A@SOP8
[(SA602A)]	
S-25C640A@TSSOP8 [(SA026)]	S-2817A@SOP28
[(SA630)]	
S-29130A(DFJA)@SOIC8 [(SA602A)]	S-29130A
(DPA)	
S-29130A(FJA)@SOIC8 [(SA602A)]	S-29131A
(DPA)	
S-29131A(FJA)@SOIC8 [(SA602A)]	S-29190A
(DPA)	
S-29190A(FJA)@SOIC8 [(SA602A)]	S-29191A
(DPA)	
S-29191A(FJA)@SOIC8 [(SA602A)]	S-29194A
(DPA)	

S-29194A(FJA)@SOIC8 [(SA602A)]	S-29220A(DFJA)@SOIC8
[(SA602A)]	
S-29220A(DPA)	S-29220A(FJA)@SOIC8
[(SA602A)]	
S-29221A(DPA)	S-29221A(FJA)@SOIC8
[(SA602A)]	
S-29230A(DFJA)@SOIC8 [(SA602A)]	S-29230A
(DPA)	
S-29230A(FJA)@SOIC8 [(SA602A)]	S-29231A
(DPA)	
S-29231A(FJA)@SOIC8 [(SA602A)]	S-29290A
(DPA)	
S-29290A(FJA)@SOIC8 [(SA602A)]	S-29291A
(DPA)	
S-29291A(FJA)@SOIC8 [(SA602A)]	S-29294A
(DPA)	
S-29294A(FJA)@SOIC8 [(SA602A)]	S-29330A(DFJA)@SOIC8
[(SA602A)]	
S-29330A(DPA)	S-29330A(FJA)@SOIC8
[(SA602A)]	
S-29331A(DPA)	S-29331A(FJA)@SOIC8
[(SA602A)]	
S-29390A(DPA)	S-29390A(FJA)@SOIC8
[(SA602A)]	
S-29391A(DPA)	S-29391A(FJA)@SOIC8
[(SA602A)]	
S-29394A(DPA)	S-29394A(FJA)@SOIC8
[(SA602A)]	
S-29430A	S-29430A@SOIC8
[(SA602A)]	
S-29530A	S-29530A@SOIC8
[(SA602A)]	
S-29630A	S-29630A@SOIC8
[(SA602A)]	
S-29L130A(DFE)@SOIC8 [(SA602A)]	S-29L130A(FE)@SOIC8
[(SA602A)]	
S-29L130A(FS)@SSOP8 [(SA026)]	S-29L131A(DFE)@SOIC8
[(SA602A)]	
S-29L131A(FS)@SSOP8 [(SA026)]	S-29L194A(DFE)@SOIC8
[(SA602A)]	
S-29L194A(FS)@TSSOP8 [(SA026)]	S-29L220A(DFE)@SOIC8
[(SA602A)]	
S-29L220A(FE)@SOIC8 [(SA602A)]	S-29L220A(FS)@SSOP8

[(SA026)]	
S-29L221A(DFE)@SOIC8 [(SA602A)]	S-29L221A(FS)@SSOP8
[(SA026)]	
S-29L294A(DFE)@SOIC8 [(SA602A)]	S-29L294A(FS)@TSSOP8
[(SA026)]	
S-29L330A(DFE)@SOIC8 [(SA602A)]	S-29L330A(FE)@SOIC8
[(SA602A)]	
S-29L330A(FS)@SSOP8 [(SA026)]	S-29L331A(DFE)@SOIC8
[(SA602A)]	
S-29L331A(FS)@SSOP8 [(SA026)]	S-29L394A(DFE)@SOIC8
[(SA602A)]	
S-29L394A(FS)@TSSOP8 [(SA026)]	S-29U130A(DFE)@SOIC8
[(SA602A)]	
S-29U130A(FS)@SSOP8 [(SA026)]	S-29U131A(DFE)@SOIC8
[(SA602A)]	
S-29U131A(FS)@SSOP8 [(SA026)]	S-29U194A(DFE)@SOIC8
[(SA602A)]	
S-29U194A(FS)@TSSOP8 [(SA026)]	S-29U220A(DFE)@SOIC8
[(SA602A)]	
S-29U220A(FS)@SSOP8 [(SA026)]	S-29U221A(DFE)@SOIC8
[(SA602A)]	
S-29U221A(FS)@SSOP8 [(SA026)]	S-29U294A(DFE)@SOIC8
[(SA602A)]	
S-29U294A(FS)@TSSOP8 [(SA026)]	S-29U330A(DFE)@SOIC8
[(SA602A)]	
S-29U330A(FS)@SSOP8 [(SA026)]	S-29U331A(DFE)@SOIC8
[(SA602A)]	
S-29U331A(FS)@SSOP8 [(SA026)]	S-29U394A(DFE)@SOIC8
[(SA602A)]	
S-29U394A(FS)@TSSOP8 [(SA026)]	S-29Z330A(DFJA)@SOIC8
[(SA602A)]	
S-29Z330A(FS)@SSOP8 [(SA026)]	S-29Z430A(DFJA)@SOIC8
[(SA602A)]	
S-29Z430A(FS)@SSOP8 [(SA026)]	S-93A46A(D0A)@SOIC8
[(SA602A)]	
S-93A56A(D0A)@SOIC8 [(SA602A)]	S-93A66A(D0A)@SOIC8
[(SA602A)]	
S-93A66A(FJ)@SOIC8 [(SA602A)]	S-93A86A@SOIC8
[(SA602A)]	
S-93C46A(DFJ)@SOIC8 [(SA602A)]	S-93C46A
(DP)	
S-93C46A(FJ)@SOIC8 [(SA602A)]	S-93C46A(FT)@TSSOP8
[(SA026)]	

S-93C46B(DP) [(SA602A)]	S-93C46B(FJ)@SOIC8
S-93C46B(FT)@TSSOP8 [(SA026)] [(SA602A)]	S-93C56A(DFJ)@SOIC8
S-93C56A(DP) [(SA602A)]	S-93C56A(FJ)@SOIC8
S-93C56A(FT)@TSSOP8 [(SA026)] (DP)	S-93C56B
S-93C56B(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C56B(FT)@TSSOP8
S-93C66A(DFJ)@SOIC8 [(SA602A)] (DP)	S-93C66A
S-93C66A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C66A(FT)@TSSOP8
S-93C66B(DP) [(SA602A)]	S-93C66B(FJ)@SOIC8
S-93C66B(FT)@TSSOP8 [(SA026)] (DP)	S-93C76A
S-93C76A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C76A(FT)@TSSOP8
S-93C86A(DP) [(SA602A)]	S-93C86A(FJ)@SOIC8
S-93C86A(FT)@TSSOP8 [(SA026)] [(SA602A)]	S-93C86B@SOIC8
S-93C86B@TSSOP8 [(SA026)] [(SA602A)]	S-93L46A(D0I)@SOIC8
S-93L56A(D0I)@SOIC8 [(SA602A)] [(SA602A)]	S-93L66A(D0I)@SOIC8
S-93L76A(D0I)@SOIC8 [(SA602A)]	

SGS-THOMSON

E (E) PROM / FRAM / NVRAM

ET2716
 ETC2716
 ETC2732
 M24128
 M24128@SOIC8 [(SA602A)]
 M24164
 M24164@SOIC8 [(SA602A)]
 M24256

M24256[3.9]@SOIC8 [(SA602A)]	M24256[5.5]@SOIC8
[(SA605A)]	
M24512	M24512@SOIC8
[(SA605A)]	
M24512@TSOP8 [(SA026)]	
M24C04	
M24C04@SOIC8 [(SA602A)]	
M24C08	
M24C08@SOIC8 [(SA602A)]	
M24C08W	
M24C08W@SOIC8 [(SA602A)]	M24C08W@TSOP8
[(SA026)]	
M24C64(BN)	M24C64(DL)@TSSOP14
[(SA026)]	
M24C64(DW)@TSSOP8 [(SA602A)]	M24C64(MN)@SOIC8
[(SA605A)]	
M24C64(MW)@SOIC8 [(SA602A)]	
M27128A	
M2716	
M27256	
M27256A	
M2732A	
M27512	
M2764	
M2764A	
M27C1000	
M27C1000@PLCC32 [(SA015A1T)]	M27C1000@TSOP32
[(SA410T)]	
M27C1001	M27C1001@PLCC32
[(SA015A1T)]	
M27C1001@TSOP32 [(SA410T)]	
M27C1024	
M27C1024@PLCC44 [(SA244)]	
M27C160	
M27C160@PLCC44 [(SA244)]	M27C160@PSOP44
[(SA638)]	
M27C2001	M27C2001@PLCC32
[(SA015A1T)]	
M27C2001@TSOP32 [(SA410T)]	
M27C202	
M27C202@PLCC44 [(SA244)]	M27C202@TSOP40
[(SA409T)]	
M27C256B	M27C256B@PLCC32

[(SA015A1T)]	
M27C400	
M27C4001	
M27C4001@PLCC32 [(SA015A1T)]	M27C4001@TSOP32
[(SA410T)]	
M27C4002	M27C4002@PLCC44
[(SA244)]	
M27C405	M27C405@PLCC32
[(SA015A1T)]	
M27C405@TSOP32 [(SA410T)]	
M27C512	
M27C512@PLCC32 [(SA015A1T)]	
M27C516	
M27C516@PLCC44 [(SA244)]	
M27C64A	
M27C64A@PLCC32 [(SA015A1T)]	
M27C800	
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44
[(SA638)]	
M27C801	M27C801@PLCC32
[(SA015A1T)]	
M27C801@TSOP32 [(SA410T)]	
M27HC641	
M27HC641@PLCC28 [(SA008A)]	
M27HC642	
M27HC642@PLCC28 [(SA008A)]	
M27V101	
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32
[(SA410T)]	
M27V201	M27V201@PLCC32
[(SA015A1T)]	
M27V201@TSOP32 [(SA410T)]	
M27V401	
M27V401@PLCC32 [(SA015A1T)]	M27V401@TSOP32
[(SA410T)]	
M27V402	M27V402@PLCC44
[(SA244)]	
M27V402@TSOP40 [(SA409T)]	
M27V512	
M27V512@PLCC32 [(SA015A1T)]	M27V512@TSOP28
[(SA430T)]	
M27V800	M27V800@PLCC44
[(SA244)]	

M27V801 [(SA015A1T)]	M27V801@PLCC32
M27V801@TSOP32 [(SA410T)]	
M27W201 M27W201@PLCC32 [(SA015A1T)] [(SA410T)]	M27W201@TSOP32
M28010 [(SA015A1T)]	M28010@PLCC32
M28010@TSOP32 [(SA410T)] [(SA015A1T)]	M28C16@PLCC32
M28C64C [(SA015A1T)]	M28C64C@PLCC32
M28C64C@SOIC28 [(SA404)] [(SA430T)]	M28C64C@TSOP28
M28F101 [(SA015A1T)]	M28F101@PLCC32
M28F101@TSOP32 [(SA410T)]	
M28F102 M28F102@PLCC44 [(SA244)] [(SA409T)]	M28F102@TSOP40
M28F201 [(SA015A1T)]	M28F201@PLCC32
M28F201@TSOP32 [(SA410T)] [(SA409T)]	M28F211@TSOP40
M28F256 [(SA015A1T)]	M28F256@PLCC32
M28F256@TSOP32 [(SA410T)] [(SA409T)]	M28F411@TSOP40
M28F512 [(SA015A1T)]	M28F512@PLCC32
M28F512@TSOP32 [(SA410T)]	
M29F002B M29F002B@PLCC32 [(SA015A1T)] [(SA410T)]	M29F002B@TSOP32
M29F002T [(SA015A1T)]	M29F002T@PLCC32
M29F002T@TSOP32 [(SA410T)]	
M29F040 M29F040@PLCC32 [(SA015A1T)] [(SA410T)]	M29F040@TSOP32
M29F040B [(SA015A1T)]	M29F040B@PLCC32
M29F040B@TSOP32 [(SA410T)]	M29F100B@PSOP44 [(SA638-

B006)]	
M29F100B@TSOP48 [(SA247-B005)]	M29F100T@PSOP44 [(SA638-
B006)]	
M29F100T@TSOP48 [(SA247-B005)]	M29F102B@PLCC44
[(SA244)]	
M29F102B@TSOP40 [(SA623)]	M29F102BB@PLCC44
[(SA244)]	
M29F102BB@TSOP40 [(SA623)]	M29F200B@PSOP44 [(SA638-
B006)]	
M29F200B@TSOP48 [(SA247-B005)]	M29F200T@PSOP44 [(SA638-
B006)]	
M29F200T@TSOP48 [(SA247-B005)]	M29F400B@PSOP44 [(SA638-
B006)]	
M29F400B@TSOP48 [(SA247-B005)]	M29F400T@PSOP44 [(SA638-
B006)]	
M29F400T@TSOP48 [(SA247-B005)]	M29V040@PLCC32
[(SA015A1T)]	
M29V040@TSOP32 [(SA410T)]	M29W008B@TSOP40
[(SA409T)]	
M29W008T@TSOP40 [(SA409T)]	M29W040@PLCC32
[(SA015A1T)]	
M29W040@TSOP32 [(SA410T)]	M29W512B@PLCC32
[(SA015A1T)]	
M29W512B@TSOP32 [(SA620)]	
M48T35	
M48T35@SOIC28 [(SA404)]	
M48T35Y	
M48T35Y@SOIC28 [(SA404)]	
M48T59	
M48T59@SOIC28 [(SA404)]	
M48T59Y	
M48T59Y@SOIC28 [(SA404)]	
M48Z128	
M48Z128Y	
M48Z30	
M48Z30Y	
M48Z32	
M48Z32Y	M50FW080@PLCC32
[(SA015A1T)]	
M50FW080@TSOP40 [(SA409T)]	M50FW080@VSOP32
[(SA620)]	
M87C257	
[(SA015A1T)]	M87C257@PLCC32

M93C06(08bit) [(SA602A)]	M93C06(08bit)@SOIC8
M93C06(16bit) [(SA602A)]	M93C06(16bit)@SOIC8
M93S46 [(SA602A)]	M93S46@SOIC8
M93S46@TSSOP8 [(SA026)]	
M95P02	
M95P02@SOIC8 [(SA602A)]	
M95P04	
M95P04@SOIC8 [(SA602A)]	
M95P08	
M95P08@SOIC8 [(SA602A)]	
MK48C02	
MK48C02B	
MK48C12	
MK48C12B	
MK48T02	
MK48T02B	
MK48T08	
MK48T12	
MK48T12B	
MK48T18	
MK48Z02	
MK48Z02B	
MK48Z08	
MK48Z12	
MK48Z12B	
MK48Z18	
MKI48Z02	
MKI48Z02B	
MKI48Z12	
MKI48Z12B	
MKI48Z18	
ST24C01 [(SA602A)]	ST24C01@SOIC8
ST24C02A [(SA602A)]	ST24C02A@SOIC8
ST24C16 [(SA602A)]	ST24C16@SOIC8
ST24W01 [(SA602A)]	ST24W01@SOIC8
ST24W02	ST24W02@SOIC8

[(SA602A)]	
ST24W04C	ST24W04C@SOIC8
[(SA602A)]	
ST27128A	
ST27256	
ST2764A	
ST27C256	
ST93C06(08bit)	ST93C06(08bit)@SOIC8
[(SA602A)]	
ST93C06(16bit)	ST93C06(16bit)@SOIC8
[(SA602A)]	
ST93CS46	ST93CS46@SOIC8
[(SA602A)]	
TS27C256	
TS27C64	
TS27C64@PLCC32 [(SA015A1T)]	
TS27C64A	
TS27C64A@PLCC32 [(SA015A1T)]	
TS28C16A	
TS28C17A	

PLD

GAL16V8
GAL16V8A
GAL20V8
GAL20V8A

SHARP

E (E) PROM / FRAM / NVRAM

LH28F002SCHN@PSOP44 [(SA638)]	LH28F002SCHT@TSOP40
[(SA409T)]	
LH28F002SCN@PSOP44 [(SA638)]	LH28F002SCT@TSOP40
[(SA409T)]	
LH28F004BVE(BT)@TSOP40 [(SA409T)]	
LH28F004BVE(TT)@TSOP40 [(SA409T)]	
LH28F004BVHS(BT)@VSOP40 [(SA623)]	
LH28F004BVHS(TT)@VSOP40 [(SA623)]	
LH28F004BVT(BT)@TSOP40 [(SA409T)]	

LH28F004BVT(TT)@TSOP40 [(SA409T)]	
LH28F004SCHN@PSOP44 [(SA638)]	LH28F004SCHS@VSOP40
[(SA623)]	
LH28F004SCHT@TSOP40 [(SA409T)]	LH28F004SCN@PSOP44
[(SA638)]	
LH28F004SCS@VSOP40 [(SA623)]	LH28F004SCT@TSOP40
[(SA409T)]	
LH28F008BJT(BTLZ1)@TSOP40 [(SA409T)]	
LH28F008BJT(TB)@TSOP40 [(SA409T)]	
LH28F008BJT(TT)@TSOP40 [(SA409T)]	
LH28F008BJT(TTLZ2)@TSOP40 [(SA409T)]	
LH28F008BVT(BT)@TSOP40 [(SA409T)]	
LH28F008BVT(TT)@TSOP40 [(SA409T)]	
LH28F008SAN@PSOP44 [(SA638)]	LH28F008SAR@RTSOP40
[(SA409T)]	
LH28F008SAT@TSOP40 [(SA409T)]	
LH28F008SCH(L85)@RTSOP40 [(SA409T)]	
LH28F008SCH-L@TSOP40 [(SA409T)]	LH28F008SCHN@PSOP44
[(SA638)]	
LH28F008SCH-V@TSOP40 [(SA409T)]	
LH28F008SCH-ZU-120@TSOP40 [(SA409T)]	
LH28F008SCN@PSOP44 [(SA638)]	LH28F008SCN-L@PSOP44
[(SA638)]	
LH28F008SCT@TSOP40 [(SA409T)]	LH28F008SCT-L@TSOP40
[(SA409T)]	
LH28F008SCT-V@TSOP40 [(SA409T)]	LH28F008SCV@TSOP40
[(SA409T)]	
LH28F016SC@PSOP44 [(SA638)]	
LH28F016SCR(L95)@RTSOP40 [(SA409T)]	
LH28F016SCT-L95@TSOP40 [(SA409T)]	
LHF00L03@PLCC32 [(SA015A1T)]	LHF00L04@TSOP40
[(SA409T)]	
LHF00L06@TSOP40 [(SA409T)]	LHF00L07@PLCC32
[(SA015A1T)]	

SIEMENS

E (E) PROM / FRAM / NVRAM

SDA2526	SDA2526@SOIC8
[(SA602A)]	
SDA2546	SDA2546@SOIC8

[(SA602A)]	
SDA25X26	SDA25X26@SOIC8
[(SA602A)]	
SDA25X46	SDA25X46@SOIC8
[(SA602A)]	
SDE2526	SDE2526@SOIC8
[(SA602A)]	
SDE2546	SDE2546@SOIC8
[(SA602A)]	
SDE25X26	SDE25X26@SOIC8
[(SA602A)]	
SDE25X46	SDE25X46@SOIC8
[(SA602A)]	
SLA24C01	SLA24C01@SOIC8
[(SA602A)]	
SLA24C02	SLA24C02@SOIC8
[(SA602A)]	
SLA24C04	SLA24C04@SOIC8
[(SA602A)]	
SLA24C08	SLA24C08@SOIC8
[(SA602A)]	
SLA24C16	SLA24C16@SOIC8
[(SA602A)]	
SLA24C164	SLA24C164@SOIC8
[(SA602A)]	
SLA24C32	SLA24C32@SOIC8
[(SA602A)]	
SLA24C64	SLA24C64@SOIC8
[(SA602A)]	
SLA25010	SLA25010@SOIC8
[(SA602A)]	
SLA25020	SLA25020@SOIC8
[(SA602A)]	
SLA25040	SLA25040@SOIC8
[(SA602A)]	
SLA25080	SLA25080@SOIC8
[(SA602A)]	
SLA25160	SLA25160@SOIC8
[(SA602A)]	
SLE24C01	SLE24C01@SOIC8
[(SA602A)]	
SLE24C02	SLE24C02@SOIC8
[(SA602A)]	

SLE24C04 [(SA602A)]	SLE24C04@SOIC8
SLE24C08 [(SA602A)]	SLE24C08@SOIC8
SLE24C16 [(SA602A)]	SLE24C16@SOIC8
SLE24C164 [(SA602A)]	SLE24C164@SOIC8
SLE24C32 [(SA602A)]	SLE24C32@SOIC8
SLE24C64 [(SA602A)]	SLE24C64@SOIC8
SLE25010 [(SA602A)]	SLE25010@SOIC8
SLE25020 [(SA602A)]	SLE25020@SOIC8
SLE25040 [(SA602A)]	SLE25040@SOIC8
SLE25080 [(SA602A)]	SLE25080@SOIC8
SLE25160 [(SA602A)]	SLE25160@SOIC8

SIGNETICS

E (E) PROM/FRAM/NVRAM

27C010 [(SA015A1T)]	27C010@PLCC32
27C010@TSOP32 [(SA410T)]	
27C040 27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32
[(SA410T)]	
27C210 [(SA244)]	27C210@PLCC44
27C240 [(SA244)]	27C240@PLCC44
27C256 [(SA015A1T)]	27C256@PLCC32
27C512 [(SA015A1T)]	27C512@PLCC32
27C64A	27C64A@PLCC32

[(SA015A1T)]	
27HC641	27HC641@PLCC28
[(SA008A)]	
27HC642	27HC642@PLCC28
[(SA008A)]	
PCA8582A	PCA8582A@SOIC8
[(SA602A)]	
PCA8582B	PCA8582B@SOIC8
[(SA602A)]	
PCA8582C	PCA8582C@SOIC8
[(SA602A)]	
PCA8582D	PCA8582D@SOIC8
[(SA602A)]	
PCA8582E	PCA8582E@SOIC8
[(SA602A)]	
PCD8582A	PCD8582A@SOIC8
[(SA602A)]	
PCD8582B	PCD8582B@SOIC8
[(SA602A)]	
PCD8582C	PCD8582C@SOIC8
[(SA602A)]	
PCD8582D	PCD8582D@SOIC8
[(SA602A)]	
PCD8582E	PCD8582E@SOIC8
[(SA602A)]	
PCF8582A	PCF8582A@SOIC8
[(SA602A)]	
PCF8582B	PCF8582B@SOIC8
[(SA602A)]	
PCF8582C	PCF8582C@SOIC8
[(SA602A)]	
PCF8582D	PCF8582D@SOIC8
[(SA602A)]	
PCF8582E	PCF8582E@SOIC8
[(SA602A)]	
PCF8594	PCF8594@SOIC8
[(SA602A)]	
PCF8594C	PCF8594C@SOIC8
[(SA602A)]	
PCF8594D	PCF8594D@SOIC8
[(SA602A)]	
PCF8594E	PCF8594E@SOIC8
[(SA602A)]	

PCF8598 [(SA605A)]	PCF8598@SOIC8
PCF8598C [(SA605A)]	PCF8598C@SOIC8
PCF8598D [(SA605A)]	PCF8598D@SOIC8
PCF8598E [(SA605A)]	PCF8598E@SOIC8

MICROCONTROLLER

S87C51 [(SA244)]	S87C51@PLCC44
S87C51@TQFP44 [(SA245A)]	
S87C51FA S87C51FA@PLCC44 [(SA244)]	S87C51FA@TQFP44
[(SA245A)]	
S87C51FB [(SA244)]	S87C51FB@PLCC44
S87C51FB@TQFP44 [(SA245A)]	
S87C51FC S87C51FC@PLCC44 [(SA244)]	S87C51FC@TQFP44
[(SA245A)]	
S87C52 [(SA244)]	S87C52@PLCC44
S87C52@TQFP44 [(SA245A)]	
S87C524 S87C524@PLCC44 [(SA244)]	S87C524@TQFP44
[(SA245A)]	
S87C528 [(SA244)]	S87C528@PLCC44
S87C528@TQFP44 [(SA245A)]	
S87C54 S87C54@PLCC44 [(SA244)]	S87C54@TQFP44
[(SA245A)]	
S87C550 [(SA244)]	S87C550@PLCC44
S87C552@PLCC68 (*) [(SA648-B6806)]	
S87C554@PLCC68 (*) [(SA648-B6806)]	
S87C575 [(SA244)]	S87C575@PLCC44
S87C575@TQFP44 [(SA245A)]	

S87C576	
S87C576@PLCC44 [(SA244)]	S87C576@TQFP44
[(SA245A)]	
S87C58	S87C58@PLCC44
[(SA244)]	
S87C58@TQFP44 [(SA245A)]	S87C591@PLCC44
[(SA244)]	
S87C591@TQFP44 [(SA245A)]	
S87C652	
S87C652@PLCC44 [(SA244)]	S87C652@TQFP44
[(SA245A)]	
S87C654	S87C654@PLCC44
[(SA244)]	
S87C654@TQFP44 [(SA245A)]	
S87C748	
S87C748@PLCC28 [(SA008A)]	
S87C749	
S87C749@PLCC28 [(SA008A)]	
S87C750	
S87C750@PLCC28 [(SA008A)]	S87C750@SSOP24
[(SA626A)]	
S87C751	S87C751@PLCC28
[(SA008A)]	
S87C751@SSOP24 [(SA626A)]	
S87C752	
S87C752@PLCC28 [(SA008A)]	S87C752@SSOP28
[(SA626A)]	
S87C754	S87C754@PLCC28
[(SA008A)]	
S87C754@SSOP28 [(SA626A)]	
S87L51FA	
S87L51FA@PLCC44 [(SA244)]	S87L51FA@TQFP44
[(SA245A)]	
S87L51FB	S87L51FB@PLCC44
[(SA244)]	
S87L51FB@TQFP44 [(SA245A)]	

Silicon Laboratories

MICROCONTROLLER

C8051F000@TQFP64 (ISP) [(PEP+S616)]

C8051F001@TQFP48 [(SA248)] [(SA248)]	C8051F001@TQFP48 (ISP)
C8051F002@TQFP32 [(SA663)] [(SA663)]	C8051F002@TQFP32 (ISP)
C8051F005@TQFP64 (ISP) [(PEP+S616)]	
C8051F006@TQFP48 [(SA248)] [(SA248)]	C8051F006@TQFP48 (ISP)
C8051F007@TQFP32 [(SA663)] [(SA663)]	C8051F007@TQFP32 (ISP)
C8051F010@TQFP64 (ISP) [(PEP+S616)]	
C8051F011@TQFP48 [(SA248)] [(SA248)]	C8051F011@TQFP48 (ISP)
C8051F012@TQFP32 [(SA663)] [(SA663)]	C8051F012@TQFP32 (ISP)
C8051F015@TQFP64 (ISP) [(PEP+S616)]	
C8051F016@TQFP48 [(SA248)] [(SA248)]	C8051F016@TQFP48 (ISP)
C8051F017@TQFP32 [(SA663)] [(SA663)]	C8051F017@TQFP32 (ISP)
C8051F018@TQFP64 (ISP) [(PEP+S616)]	
C8051F019@TQFP48 [(SA248)] [(SA248)]	C8051F019@TQFP48 (ISP)
C8051F020@TQFP100 (ISP) [ISP-HEADER01]	
C8051F021@TQFP64 (ISP) [ISP-HEADER01]	
C8051F022@TQFP100 (ISP) [ISP-HEADER01]	
C8051F023@TQFP64 (ISP) [ISP-HEADER01]	
C8051F040@TQFP100 (ISP) [ISP-HEADER01]	
C8051F041@TQFP64 (ISP) [ISP-HEADER01]	
C8051F042@TQFP100 (ISP) [ISP-HEADER01]	
C8051F043@TQFP64 (ISP) [ISP-HEADER01]	
C8051F044@TQFP100 (ISP) [ISP-HEADER01]	
C8051F045@TQFP64 (ISP) [ISP-HEADER01]	
C8051F046@TQFP100 (ISP) [ISP-HEADER01]	
C8051F047@TQFP64 (ISP) [ISP-HEADER01]	
C8051F206@TQFP48 [(SA248)] [(SA248)]	C8051F220@TQFP48
C8051F221@TQFP32 [(SA663)] [(SA248)]	C8051F226@TQFP48
C8051F230@TQFP48 [(SA248)] [(SA663)]	C8051F231@TQFP32
C8051F236@TQFP48 [(SA248)] [(SA695A)]	C8051F300
C8051F301 [(SA695A)]	C8051F302

[(SA695A)]	
C8051F303 [(SA695A)]	C8051F304
[(SA695A)]	
C8051F305 [(SA695A)]	C8051F310@TQFP32
[(SA663)]	
C8051F310-GQ@TQFP32 [(SA663)]	C8051F311@QFN28 [(SA697-
B006)]	
C8051F311-GM@QFN28 [(SA697-B006)]	
C8051F312@TQFP32 [(SA663)]	C8051F312-GQ@TQFP32
[(SA663)]	
C8051F313@QFN28 [(SA697-B006)]	
C8051F313-GM@QFN28 [(SA697-B006)]	
C8051F314@TQFP32 [(SA663)]	C8051F314-GQ@TQFP32
[(SA663)]	
C8051F315@QFN28 [(SA697-B006)]	
C8051F315-GM@QFN28 [(SA697-B006)]	
C8051F316-GM@QFN24 [(SA710-B006)]	
C8051F317-GM@QFN24 [(SA710-B006)]	
C8051F320@TQFP32 [(SA663)]	C8051F321@QFN28 [(SA697-
B006)]	
C8051F326@QFN28 [(SA697-B006)]	
C8051F326-GQ@QFN28 [(SA697-B006)]	
C8051F327@QFN28 [(SA697-B006)]	
C8051F327-GQ@QFN28 [(SA697-B006)]	
C8051F330@MLP20 [(SA692)]	
C8051F330D	
C8051F331@MLP20 [(SA692)]	C8051F332-GM@MLP20
[(SA692)]	
C8051F333-GM@MLP20 [(SA692)]	C8051F334-GM@MLP20
[(SA692)]	
C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20
[(SA692)]	
C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24
[(SA710)]	
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48
[(SA248)]	
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32
[(SA663)]	
C8051F343-GQ@LQFP32 [(SA663)]	C8051F344-GQ@TQFP48
[(SA248)]	
C8051F345-GQ@TQFP48 [(SA248)]	C8051F346-GQ@LQFP32
[(SA663)]	
C8051F347-GQ@LQFP32 [(SA663)]	C8051F350-GQ@LQFP32

[(SA663)]	
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F410-GQ@LQFP32 [(SA663)]	C8051F411-GM@QFN28
[(SA697)]	
C8051F412-GQ@LQFP32 [(SA663)]	C8051F413-GM@QFN28
[(SA697)]	
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10
[(SA695A)]	
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10
[(SA695A)]	
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10
[(SA695A)]	
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20
[(SA026)]	
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20
[(SA026)]	
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20
[(SA026)]	
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20
[(SA026)]	
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20
[(SA026)]	
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20
[(SA026)]	
C8051F610-GQ@QFP32 [(SA663)]	
C8051F611-GM@QFN28 [(SA697-B006)]	
C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	
C8051T600@QFN11 [(SA695A)]	C8051T600@SOIC14
[(SA602)]	
C8051T601@QFN11 [(SA695A)]	C8051T601@SOIC14
[(SA602)]	
C8051T602@SOIC14 [(SA602)]	C8051T603@SOIC14
[(SA602)]	
C8051T604@QFN11 [(SA695A)]	C8051T604@SOIC14
[(SA602)]	
C8051T605@QFN11 [(SA695A)]	C8051T605@SOIC14

[(SA602)]	
SI8250@LQFP32 [(SA663)]	SI8250@QFN28
[(SA697)]	
SI8251@LQFP32 [(SA663)]	SI8251@QFN28
[(SA697)]	
SI8252@LQFP32 [(SA663)]	SI8252@QFN28
[(SA697)]	

SIMTEK

E (E) PROM / FRAM / NVRAM

STK10C48	
STK10C48@SOIC28(300 mil) [(SA404)]	
STK10C48@SOIC28(350 mil) [(SA630)]	
STK10C68	STK10C68@PLCC28
[(SA008A)]	
STK10C68@SOIC28(350 mil) [(SA630)]	
STK11C48	
STK11C48@SOIC28(300 mil) [(SA404)]	
STK11C48@SOIC28(350 mil) [(SA630)]	
STK11C68	STK11C68@PLCC28
[(SA008A)]	
STK11C68@SOIC28(350 mil) [(SA630)]	
STK11C88	STK11C88
(3V)	
STK11C88(3V)@SOIC28(300 mil) [(SA404)]	
STK11C88(3V)@SOIC28(350 mil) [(SA630)]	
STK11C88@SOIC28(300 mil) [(SA404)]	
STK11C88@SOIC28(350 mil) [(SA630)]	
STK12C68	STK12C68@PLCC28
[(SA008A)]	
STK12C68@SOIC28(350 mil) [(SA630)]	
STK14C88	STK14C88
(3V)	
STK14C88(3V)@PLCC32 [(SA015A1T)]	
STK14C88(3V)@SOIC32(300 mil) [(SA715)]	
STK14C88(3V)@SOIC32(350 mil) [(SA630)]	
STK14C88@PLCC32 [(SA015A1T)]	
STK14C88@SOIC32(300 mil) [(SA715)]	
STK14C88@SOIC32(350 mil) [(SA630)]	
STK14CA8	STK14CA8@SOIC32

[(SA715)]
STK14CA8@SSOP48 [(SA669)] STK14D88@SOIC32
[(SA715)]
STK14D88@SSOP48 [(SA669)]
STK15C68
STK15C68@SOIC28(350 mil) [(SA630)]
STK15C88
STK15C88@SOIC28(300 mil) [(SA404)]
STK15C88@SOIC28(350 mil) [(SA630)]
STK16C68
STK16C88
STK16C88(3V)
STK16CA8
STK20C04
STK22C48
STK22C48@SOIC28(300 mil) [(SA404)]
STK22C48@SOIC28(350 mil) [(SA630)]
STK25C48

SMOS

E (E) PROM / FRAM / NVRAM

SPM27128
SPM27128C
SPM27C256
SPM27C64
SPM27C64H

SONY

E (E) PROM / FRAM / NVRAM

CXK1011M@SOIC8 [(SA602A)]
CXK1011P
CXK1012P
CXK1013P
CXK1023P
CXK27C4001

DRAM & SRAM

CXK581000
[(SA630)]

CXK581000@SOIC32

SPACE ELECTRONICS[SEI]

E (E) PROM / FRAM / NVRAM

28C010
[(SA015A1T)]

28C010@PLCC32

28C010@TSOP32 [(SA410T)]

28C010T

28C010T@PLCC32 [(SA015A1T)]
[(SA410T)]

28C010T@TSOP32

28C011
[(SA015A1T)]

28C011@PLCC32

28C011@TSOP32 [(SA410T)]

28C011T

28C011T@PLCC32 [(SA015A1T)]
[(SA410T)]

28C011T@TSOP32

SPANSION

E (E) PROM / FRAM / NVRAM

AM29DL400BB@PSOP44 [(SA638-B006)]

AM29DL400BB@TSOP48 [(SA247-B005)]

AM29DL400BT@PLCC44 [(SA638-B006)]

AM29DL400BT@TSOP48 [(SA247-B005)]

AM29DL800B@PSOP44 [(SA638-B006)] AM29DL800B@TSOP48 [(SA247-B005)]

AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]

AM29DL800BB@PSOP44 [(SA638)]

AM29DL800BB@TSOP48 [(SA247-B005)]

AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]

AM29DL800BT@PSOP44 [(SA638)]

AM29DL800BT@TSOP48 [(SA247-B005)]

AM29DL800T@PSOP44 [(SA638-B006)] AM29DL800T@TSOP48 [(SA247-B005)]

AM29F002B [(SA015A1T)]	AM29F002B@PLCC32
AM29F002B@TSOP32 [(SA410T)]	
AM29F002BB AM29F002BB@PLCC32 [(SA015A1T)]	AM29F002BB@TSOP32
[(SA410T)]	
AM29F002BT [(SA015A1T)]	AM29F002BT@PLCC32
AM29F002BT@TSOP32 [(SA410T)]	
AM29F002NB AM29F002NB@PLCC32 [(SA015A1T)]	AM29F002NB@TSOP32
[(SA410T)]	
AM29F002NBB [(SA015A1T)]	AM29F002NBB@PLCC32
AM29F002NBB@TSOP32 [(SA410T)]	
AM29F002NBT AM29F002NBT@PLCC32 [(SA015A1T)]	AM29F002NBT@TSOP32
[(SA410T)]	
AM29F002NT [(SA015A1T)]	AM29F002NT@PLCC32
AM29F002NT@TSOP32 [(SA410T)]	
AM29F002T AM29F002T@PLCC32 [(SA015A1T)]	AM29F002T@TSOP32
[(SA410T)]	
AM29F004BB@PLCC32 [(SA015A1T)]	AM29F004BB@TSOP32
[(SA410T)]	
AM29F004BT@PLCC32 [(SA015A1T)]	AM29F004BT@TSOP32
[(SA410T)]	
AM29F010 [(SA015A1T)]	AM29F010@PLCC32
AM29F010@TSOP32 [(SA410T)]	
AM29F010A AM29F010A@PLCC32 [(SA015A1T)]	AM29F010A@TSOP32
[(SA410T)]	
AM29F010B [(SA015A1T)]	AM29F010B@PLCC32
AM29F010B@TSOP32 [(SA410T)]	AM29F016@PSOP44
[(SA638)]	
AM29F016@TSOP40 [(SA409T)]	AM29F016@TSOP48 [(SA247-
B005)]	
AM29F016B@PSOP44 [(SA638)]	AM29F016B@TSOP40
[(SA409T)]	
AM29F016B@TSOP48 [(SA247-B005)]	

AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016D@PSOP44 [(SA638)]	AM29F016D@TSOP40
[(SA409T)]	
AM29F016D@TSOP48 [(SA247-B005)]	AM29F017B@TSOP48 [(SA247-B005)]
AM29F017D@TSOP40 [(SA409T)]	AM29F017D@TSOP48 [(SA247-B005)]
AM29F032B@PSOP44 [(SA638)]	AM29F032B@TSOP40
[(SA409T)]	
AM29F040	AM29F040@PLCC32
[(SA015A1T)]	
AM29F040@TSOP32 [(SA410T)]	
AM29F040A	
AM29F040A@PLCC32 [(SA015A1T)]	AM29F040A@TSOP32
[(SA410T)]	
AM29F040B	
AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)]	AM29F040B@TSOP32
[(SA410T)]	
AM29F080@PSOP44 [(SA638)]	AM29F080@TSOP40
[(SA409T)]	
AM29F080B@PSOP44 [(SA638)]	AM29F080B@TSOP40
[(SA409T)]	
AM29F100BE@PSOP44 [(SA638-B006)]	AM29F100BE@TSOP48 [(SA247-B005)]
AM29F100BS@PSOP44 [(SA638-B006)]	AM29F100BS@TSOP48 [(SA247-B005)]
AM29F100TE@PSOP44 [(SA638-B006)]	AM29F100TE@TSOP48 [(SA247-B005)]
AM29F100TS@PSOP44 [(SA638-B006)]	AM29F100TS@TSOP48 [(SA247-B005)]
AM29F160DB@TSOP48 [(SA247-B005)]	AM29F160DT@TSOP48 [(SA247-B005)]
AM29F200AB@PSOP44 [(SA638-B006)]	AM29F200AB@TSOP48 [(SA247-B005)]
AM29F200AT@PSOP44 [(SA638-B006)]	AM29F200AT@TSOP48 [(SA247-B005)]
AM29F200BB@PSOP44 [(SA638-B006)]	AM29F200BB@TSOP48 [(SA247-B005)]
AM29F200BE@PSOP44 [(SA638-B006)]	AM29F200BE@TSOP48 [(SA247-B005)]
AM29F200BS@PSOP44 [(SA638-B006)]	AM29F200BS@TSOP48 [(SA247-B005)]

AM29F200BT@PSOP44 [(SA638-B006)]	AM29F200BT@TSOP48 [(SA247-
B005)]	
AM29F200TE@PSOP44 [(SA638-B006)]	AM29F200TE@TSOP48 [(SA247-
B005)]	
AM29F200TS@PSOP44 [(SA638-B006)]	AM29F200TS@TSOP48 [(SA247-
B005)]	
AM29F400AB@PSOP44 [(SA638-B006)]	AM29F400AB@TSOP48 [(SA247-
B005)]	
AM29F400AT@PSOP44 [(SA638-B006)]	AM29F400AT@TSOP48 [(SA247-
B005)]	
AM29F400BB@PSOP44 [(SA638-B006)]	AM29F400BB@TSOP48 [(SA247-
B005)]	
AM29F400BBE@PSOP44 [(SA638-B006)]	
AM29F400BBE@TSOP48 [(SA247-B005)]	
AM29F400BBF@PSOP44 [(SA638-B006)]	
AM29F400BBF@TSOP48 [(SA247-B005)]	
AM29F400BBS@PSOP44 [(SA638-B006)]	
AM29F400BBS@TSOP48 [(SA247-B005)]	
AM29F400BE@PSOP44 [(SA638-B006)]	AM29F400BE@TSOP48 [(SA247-
B005)]	
AM29F400BF@PSOP44 [(SA638-B006)]	AM29F400BF@TSOP48 [(SA247-
B005)]	
AM29F400BS@PSOP44 [(SA638-B006)]	AM29F400BS@TSOP48 [(SA247-
B005)]	
AM29F400BT@PSOP44 [(SA638-B006)]	AM29F400BT@TSOP48 [(SA247-
B005)]	
AM29F400BTE@PSOP44 [(SA638-B006)]	
AM29F400BTE@TSOP48 [(SA247-B005)]	
AM29F400BTF@PSOP44 [(SA638-B006)]	
AM29F400BTF@TSOP48 [(SA247-B005)]	
AM29F400BTS@PSOP44 [(SA638-B006)]	
AM29F400BTS@TSOP48 [(SA247-B005)]	
AM29F800B@PSOP44 [(SA638-B006)]	AM29F800B@TSOP48 [(SA247-
B005)]	
AM29F800BB@PSOP44 [(SA638-B006)]	AM29F800BB@TSOP48 [(SA247-
B005)]	
AM29F800BBF@PSOP44 [(SA638-B006)]	
AM29F800BBF@TSOP48 [(SA247-B005)]	
AM29F800BF@PSOP44 [(SA638-B006)]	AM29F800BF@TSOP48 [(SA247-
B005)]	
AM29F800BT@PSOP44 [(SA638-B006)]	AM29F800BT@TSOP48 [(SA247-
B005)]	
AM29F800BTF@PSOP44 [(SA638-B006)]	

AM29F800BTF@TSOP48 [(SA247-B005)]	
AM29F800T@PSOP44 [(SA638-B006)]	AM29F800T@TSOP48 [(SA247-B005)]
AM29F800TB@PSOP44 [(SA638-B006)]	AM29F800TB@TSOP48 [(SA247-B005)]
AM29F800TF@PSOP44 [(SA638-B006)]	AM29F800TF@TSOP48 [(SA247-B005)]
AM29LL800B@TSOP48 [(SA247-B005)]	
AM29LL800BB@TSOP48 [(SA247-B005)]	
AM29LL800BT@TSOP48 [(SA247-B005)]	
AM29LL800T@TSOP48 [(SA247-B005)]	AM29LV001BB@PLCC32
[(SA015A1T)]	
AM29LV001BB@TSOP32 [(SA410T)]	AM29LV001BT@PLCC32
[(SA015A1T)]	
AM29LV001BT@TSOP32 [(SA410T)]	AM29LV002@TSOP40
[(SA409T)]	
AM29LV002B@TSOP40 [(SA409T)]	AM29LV002BB@TSOP40
[(SA409T)]	
AM29LV002BT@TSOP40 [(SA409T)]	AM29LV004B@PSOP44
[(SA638)]	
AM29LV004B@TSOP40 [(SA409T)]	AM29LV004BB@TSOP40
[(SA409T)]	
AM29LV004BT@TSOP40 [(SA409T)]	AM29LV004T@PSOP44
[(SA638)]	
AM29LV004T@TSOP40 [(SA409T)]	AM29LV008B@PSOP44
[(SA638)]	
AM29LV008B@TSOP40 [(SA409T)]	AM29LV008BB@TSOP40
[(SA409T)]	
AM29LV008BT@TSOP40 [(SA409T)]	AM29LV008T@PSOP44
[(SA638)]	
AM29LV008T@TSOP40 [(SA409T)]	AM29LV010B@PLCC32
[(SA015A1T)]	
AM29LV010B@TSOP32 [(SA410T)]	AM29LV017B@TSOP40
[(SA409T)]	
AM29LV020B@PLCC32 [(SA015A1T)]	AM29LV020B@TSOP32
[(SA410T)]	
AM29LV033C@TSOP40 [(SA409T)]	AM29LV033MU@TSOP40
[(SA409T)]	
AM29LV040B@PLCC32 [(SA015A1T)]	AM29LV040B@TSOP32
[(SA410T)]	
AM29LV040E@PLCC32 [(SA015A1T)]	AM29LV040E@TSOP32
[(SA410T)]	
AM29LV040J@PLCC32 [(SA015A1T)]	AM29LV040J@TSOP32

[(SA410T)]
AM29LV081@TSOP40 [(SA409T)] AM29LV081B@TSOP40
[(SA409T)]
AM29LV116BB@TSOP40 [(SA409T)] AM29LV116BT@TSOP40
[(SA409T)]
AM29LV116DB@TSOP40 [(SA409T)] AM29LV116DT@TSOP40
[(SA409T)]
AM29LV200B@PSOP44 [(SA638-B006)] AM29LV200B@TSOP48 [(SA247-B005)]
AM29LV200BB@PSOP44 [(SA638-B006)]
AM29LV200BB@TSOP48 [(SA247-B005)]
AM29LV200BE@PSOP44 [(SA638-B006)]
AM29LV200BE@TSOP48 [(SA247-B005)]
AM29LV200BF@PSOP44 [(SA638-B006)]
AM29LV200BF@TSOP48 [(SA247-B005)]
AM29LV200BS@PSOP44 [(SA638-B006)]
AM29LV200BS@TSOP48 [(SA247-B005)]
AM29LV200BT@PSOP44 [(SA638-B006)]
AM29LV200BT@TSOP48 [(SA247-B005)]
AM29LV200T@PSOP44 [(SA638-B006)] AM29LV200T@TSOP48 [(SA247-B005)]
AM29LV200TE@PSOP44 [(SA638-B006)]
AM29LV200TE@TSOP48 [(SA247-B005)]
AM29LV200TF@PSOP44 [(SA638-B006)]
AM29LV200TF@TSOP48 [(SA247-B005)]
AM29LV200TS@PSOP44 [(SA638-B006)]
AM29LV200TS@TSOP48 [(SA247-B005)]
AM29LV400B@PSOP44 [(SA638-B006)] AM29LV400B@TSOP48 [(SA247-B005)]
AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BB@PSOP44 [(SA638-B006)]
AM29LV400BB@TSOP48 [(SA247-B005)]
AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BT@PSOP44 [(SA638-B006)]
AM29LV400BT@TSOP48 [(SA247-B005)]
AM29LV400T@PSOP44 [(SA638-B006)] AM29LV400T@TSOP48 [(SA247-B005)]
AM29LV800B@PSOP44 [(SA638-B006)] AM29LV800B@TSOP48 [(SA247-B005)]
AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BB@PSOP44 [(SA638-B006)]
AM29LV800BB@TSOP48 [(SA247-B005)]
AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]

AM29LV800BT@PSOP44 [(SA638-B006)]	
AM29LV800BT@TSOP48 [(SA247-B005)]	
AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]	
AM29LV800DB@PSOP44 [(SA638)]	
AM29LV800DB@TSOP48 [(SA247-B005)]	
AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]	
AM29LV800DT@PSOP44 [(SA638)]	
AM29LV800DT@TSOP48 [(SA247-B005)]	
AM29LV800T@PSOP44 [(SA638-B006)]	AM29LV800T@TSOP48 [(SA247-B005)]
MBM29F001B [(SA015A1T)]	MBM29F001B@PLCC32
MBM29F001B@TSOP32 [(SA410T)]	
MBM29F001T	
MBM29F001T@PLCC32 [(SA015A1T)]	MBM29F001T@TSOP32
[(SA410T)]	
MBM29F002B [(SA015A1T)]	MBM29F002B@PLCC32
MBM29F002B@TSOP32 [(SA410T)]	
MBM29F002NB	
MBM29F002NB@PLCC32 [(SA015A1T)]	MBM29F002NB@TSOP32
[(SA410T)]	
MBM29F002NT	
[(SA015A1T)]	MBM29F002NT@PLCC32
MBM29F002NT@TSOP32 [(SA410T)]	
MBM29F002T	
MBM29F002T@PLCC32 [(SA015A1T)]	MBM29F002T@TSOP32
[(SA410T)]	
MBM29F010 [(SA015A1T)]	MBM29F010@PLCC32
MBM29F010@TSOP32 [(SA410T)]	
MBM29F010A	
MBM29F010A@PLCC32 [(SA015A1T)]	MBM29F010A@TSOP32
[(SA410T)]	
MBM29F016@PSOP44 [(SA638)]	MBM29F016@TSOP40
[(SA409T)]	
MBM29F016@TSOP48 [(SA247-B005)]	MBM29F016A@PSOP44
[(SA638)]	
MBM29F016A@TSOP40 [(SA409T)]	MBM29F016A@TSOP48 [(SA247-B005)]
MBM29F016B@PSOP44 [(SA638)]	MBM29F016B@TSOP40

[(SA409T)]	
MBM29F016B@TSOP48 [(SA247-B005)]	MBM29F017B@TSOP48 [(SA247-B005)]
MBM29F017D@TSOP40 [(SA409T)]	MBM29F017D@TSOP48 [(SA247-B005)]
MBM29F032B@PSOP44 [(SA638)]	MBM29F032B@TSOP40 [(SA409T)]
MBM29F033C@TSOP40 [(SA409T)]	
MBM29F040@PLCC32 [(SA015A1T)]	MBM29F040@TSOP32 [(SA410T)]
MBM29F040B@PLCC32 [(SA015A1T)]	MBM29F040B@PLCC32 [(SA410T)]
MBM29F040B@TSOP32 [(SA410T)]	MBM29F040C@PLCC32 [(SA015A1T)]
MBM29F040C@TSOP32 [(SA410T)]	MBM29F080@PSOP44 [(SA638)]
MBM29F080@TSOP40 [(SA409T)]	MBM29F080A@TSOP48 [(SA247-B005)]
MBM29F080B@PSOP44 [(SA638)]	MBM29F080B@TSOP40 [(SA409T)]
MBM29F100B@PSOP44 [(SA638-B006)]	MBM29F100B@TSOP48 [(SA247-B005)]
MBM29F100T@PSOP44 [(SA638-B006)]	MBM29F100T@TSOP48 [(SA247-B005)]
MBM29F160BE@TSOP48 [(SA247-B005)]	
MBM29F160TE@TSOP48 [(SA247-B005)]	
MBM29F200AB@PSOP44 [(SA638-B006)]	
MBM29F200AB@TSOP48 [(SA247-B005)]	
MBM29F200AT@PSOP44 [(SA638-B006)]	
MBM29F200AT@TSOP48 [(SA247-B005)]	
MBM29F200B@PSOP44 [(SA638-B006)]	MBM29F200B@TSOP48 [(SA247-B005)]
MBM29F200T@PSOP44 [(SA638-B006)]	MBM29F200T@TSOP48 [(SA247-B005)]
MBM29F400AB@PSOP44 [(SA638-B006)]	
MBM29F400AB@TSOP48 [(SA247-B005)]	
MBM29F400AT@PSOP44 [(SA638-B006)]	
MBM29F400AT@TSOP48 [(SA247-B005)]	
MBM29F400B@PSOP44 [(SA638-B006)]	MBM29F400B@TSOP48 [(SA247-B005)]
MBM29F400BB@PSOP44 [(SA638-B006)]	
MBM29F400BB@TSOP48 [(SA247-B005)]	

MBM29F400BT@PSOP44 [(SA638-B006)]	
MBM29F400BT@TSOP48 [(SA247-B005)]	
MBM29F400T@PSOP44 [(SA638-B006)]	MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)]	MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BB@PSOP44 [(SA638-B006)]	
MBM29F800BB@TSOP48 [(SA247-B005)]	
MBM29F800BT@PSOP44 [(SA638-B006)]	
MBM29F800BT@TSOP48 [(SA247-B005)]	
MBM29F800T@PSOP44 [(SA638-B006)]	MBM29F800T@TSOP48 [(SA247-B005)]
MBM29LL800B@TSOP48 [(SA247-B005)]	
MBM29LL800BB@TSOP48 [(SA247-B005)]	
MBM29LL800BT@TSOP48 [(SA247-B005)]	
MBM29LL800T@TSOP48 [(SA247-B005)]	
MBM29LV001B@PLCC32 [(SA015A1T)]	MBM29LV001BB@PLCC32 [(SA015A1T)]
MBM29LV001BB@TSOP32 [(SA410T)]	MBM29LV001BC@PLCC32 [(SA015A1T)]
MBM29LV001BC@TSOP32 [(SA410T)]	MBM29LV001BT@PLCC32 [(SA015A1T)]
MBM29LV001BT@TSOP32 [(SA410T)]	MBM29LV001T@TSOP32 [(SA410T)]
MBM29LV001TC@PLCC32 [(SA015A1T)]	MBM29LV001TC@TSOP32 [(SA410T)]
MBM29LV002B@TSOP40 [(SA409T)]	MBM29LV002T@TSOP40 [(SA409T)]
MBM29LV004B@PSOP44 [(SA638)]	MBM29LV004B@TSOP40 [(SA409T)]
MBM29LV004BB@TSOP40 [(SA409T)]	MBM29LV004BT@TSOP40 [(SA409T)]
MBM29LV004T@PSOP44 [(SA638)]	MBM29LV004T@TSOP40 [(SA409T)]
MBM29LV008B@PSOP44 [(SA638)]	MBM29LV008B@TSOP40 [(SA409T)]
MBM29LV008BB@TSOP40 [(SA409T)]	MBM29LV008BT@TSOP40 [(SA409T)]
MBM29LV008T@PSOP44 [(SA638)]	MBM29LV008T@TSOP40 [(SA409T)]
MBM29LV016/B@TSOP40 [(SA409T)]	MBM29LV016/T@TSOP40 [(SA409T)]
MBM29LV016B@TSOP40 [(SA409T)]	MBM29LV017B@TSOP40 [(SA409T)]

[(SA409T)]	
MBM29LV017E@TSOP40 [(SA409T)]	MBM29LV033C@TSOP40
[(SA409T)]	
MBM29LV080@TSOP40 [(SA409T)]	MBM29LV081@TSOP40
[(SA409T)]	
MBM29LV081B@TSOP40 [(SA409T)]	MBM29LV116B@TSOP40
[(SA409T)]	
MBM29LV200B@PSOP44 [(SA638-B006)]	
MBM29LV200B@TSOP48 [(SA247-B005)]	
MBM29LV200BB@PSOP44 [(SA638-B006)]	
MBM29LV200BB@TSOP48 [(SA247-B005)]	
MBM29LV200BC@PSOP44 [(SA638)]	
MBM29LV200BC@TSOP48 [(SA247-B005)]	
MBM29LV200BT@PSOP44 [(SA638-B006)]	
MBM29LV200BT@TSOP48 [(SA247-B005)]	
MBM29LV200T@PSOP44 [(SA638-B006)]	
MBM29LV200T@TSOP48 [(SA247-B005)]	
MBM29LV200TC@PSOP44 [(SA638)]	
MBM29LV200TC@TSOP48 [(SA247-B005)]	
MBM29LV400B@PSOP44 [(SA638-B006)]	
MBM29LV400B@TSOP48 [(SA247-B005)]	
MBM29LV400BB@PSOP44 [(SA638-B006)]	
MBM29LV400BB@TSOP48 [(SA247-B005)]	
MBM29LV400BT@PSOP44 [(SA638-B006)]	
MBM29LV400BT@TSOP48 [(SA247-B005)]	
MBM29LV400T@PSOP44 [(SA638-B006)]	
MBM29LV400T@TSOP48 [(SA247-B005)]	
MBM29LV800B@PSOP44 [(SA638-B006)]	
MBM29LV800B@SON46 [(SA631)]	
MBM29LV800B@TSOP48 [(SA247-B005)]	
MBM29LV800BB@PSOP44 [(SA638-B006)]	
MBM29LV800BB@TSOP48 [(SA247-B005)]	
MBM29LV800BT@PSOP44 [(SA638-B006)]	
MBM29LV800BT@TSOP48 [(SA247-B005)]	
MBM29LV800T@PSOP44 [(SA638-B006)]	
MBM29LV800T@SON46 [(SA631)]	
MBM29LV800T@TSOP48 [(SA247-B005)]	
S25FL001D@SOIC8 [(SA602A)]	S25FL001D@USON8
[(SA683)]	
S25FL002A@SOIC8 [(SA605A)]	S25FL002A@USON8
[(SA683)]	
S25FL002D@SOIC8 [(SA602A)]	S25FL002D@USON8
[(SA683)]	

S25FL004A@SOIC8 [(SA605A)] [(SA683)]	S25FL004A@USON8
S25FL004D@SOIC8 [(SA602A)] [(SA683)]	S25FL004D@USON8
S25FL008A@SOIC8 [(SA605A)] [(SA683)]	S25FL008A@USON8
S25FL008D@SOIC8 [(SA602A)] [(SA683)]	S25FL008D@USON8
S25FL016A@SOIC16 [(SA404)]	
S25FL016A@SOIC16(ISP) [ISP-HEADER01]	
S25FL016A@SOIC8 [(SA605A)]	
S25FL016A@SOIC8(ISP) [ISP-HEADER01]	
S25FL016A@WSON8 [(SA684)]	
S25FL016A@WSON8(ISP) [ISP-HEADER01]	
S25FL020A@SOIC8(4.0) [(SA602A)] [(SA605A)]	S25FL020A@SOIC8(5.4)
S25FL020A@USON8 [(SA683)] [(SA404)]	S25FL032A@SOIC16
S25FL032A@SOIC16(ISP) [ISP-HEADER01]	
S25FL032A@WSON8 [(SA684)]	
S25FL032A@WSON8(ISP) [ISP-HEADER01]	
S25FL040A(Bottom Boot)@SOP8(4.0) [(SA602A)]	
S25FL040A(Bottom Boot)@SOP8(5.4) [(SA605A)]	
S25FL040A(Bottom Boot)@USON8 [(SA683)]	
S25FL040A(Top Boot)@SOP8(4.0) [(SA602A)]	
S25FL040A(Top Boot)@SOP8(5.4) [(SA605A)]	
S25FL040A(Top Boot)@USON8 [(SA683)]	
S25FL040A@SOP8(4.0) [(SA602A)] [(SA605A)]	S25FL040A@SOP8(5.4)
S25FL040A@USON8 [(SA683)] [(SA404)]	S25FL064A@SOIC16
S25FL064A@SOIC16(ISP) [ISP-HEADER01]	
S25FL064A@WSON8 [(SA684)]	
S25FL064A@WSON8(ISP) [ISP-HEADER01]	
S25FL080A@SOIC8(4.0) [(SA602A)] [(SA605A)]	S25FL080A@SOIC8(5.4)
S25FL080A@USON8 [(SA683)]	
S25FL128P(256 KB)@SOIC16 [(SA404)]	
S25FL128P(256 KB)@SOIC16(ISP) [ISP-HEADER01]	
S25FL128P(256 KB)@WSON8 [(SA684)]	
S25FL128P(256 KB)@WSON8(ISP) [ISP-HEADER01]	
S25FL128P(64 KB)@SOIC16 [(SA404)]	
S25FL128P(64 KB)@SOIC16(ISP) [ISP-HEADER01]	

S25FL128P(64 KB)@WSON8 [(SA684)]
S25FL128P(64 KB)@WSON8(ISP) [ISP-HEADER01]
S25FLK05D@SOIC8 [(SA602A)] S25FLK05D@USON8
[(SA683)]

SSSC

MICROCONTROLLER

SSU7301 SSU7301@PLCC44
[(SA244)]
SSU7301@TQFP44 [(SA245A)]

SST

E(E) PROM/FRAM/NVRAM

SST25LF010@SOIC8(4.0) [(SA602A)] SST25LF010@SOIC8(5.4)
[(SA605B)]
SST25LF010@WSON8 [(SA683)]
SST25LF010A@SOIC8(4.0) [(SA602A)]
SST25LF010A@SOIC8(5.4) [(SA605B)]
SST25LF010A@WSON8 [(SA683)]
SST25LF016A@SOIC8(4.0) [(SA602A)]
SST25LF016A@SOIC8(5.4) [(SA605A)]
SST25LF016A@WSON8 [(SA683)]
SST25LF016B@SOIC8(4.0) [(SA602A)]
SST25LF016B@SOIC8(5.4) [(SA605A)]
SST25LF016B@WSON8 [(SA683)] SST25LF020@SOIC8(4.0)
[(SA602A)]
SST25LF020@SOIC8(5.4) [(SA605B)] SST25LF020@WSON8
[(SA683)]
SST25LF020A@SOIC8(4.0) [(SA602A)]
SST25LF020A@SOIC8(5.4) [(SA605B)]
SST25LF020A@WSON8 [(SA683)] SST25LF040@SOIC8(4.0)
[(SA602A)]
SST25LF040@SOIC8(5.4) [(SA605B)] SST25LF040@WSON8
[(SA683)]
SST25LF040A@SOIC8(4.0) [(SA602A)]
SST25LF040A@SOIC8(5.4) [(SA605B)]

SST25LF040A@WSON8 [(SA683)]	SST25LF080@SOIC8(4.0)
[(SA602A)]	
SST25LF080@SOIC8(5.4) [(SA605B)]	SST25LF080@WSON8
[(SA683)]	
SST25LF080A@SOIC8(4.0) [(SA602A)]	
SST25LF080A@SOIC8(5.4) [(SA605B)]	
SST25LF080A@WSON8 [(SA683)]	SST25VF010@SOIC8(4.0)
[(SA602A)]	
SST25VF010@SOIC8(5.4) [(SA605B)]	SST25VF010@WSON8
[(SA683)]	
SST25VF010A@SOIC8(4.0) [(SA602A)]	
SST25VF010A@SOIC8(5.4) [(SA605B)]	
SST25VF010A@WSON8 [(SA683)]	
SST25VF016B@SOIC8(4.0) [(SA602A)]	
SST25VF016B@SOIC8(5.4) [(SA605A)]	
SST25VF016B@WSON8 [(SA683)]	SST25VF020@SOIC8(4.0)
[(SA602A)]	
SST25VF020@SOIC8(5.4) [(SA605B)]	SST25VF020@WSON8
[(SA683)]	
SST25VF032B@SOIC8(4.0) [(SA602A)]	
SST25VF032B@SOIC8(5.4) [(SA605A)]	
SST25VF032B@WSON8 [(SA683)]	SST25VF040@SOIC8(4.0)
[(SA602A)]	
SST25VF040@SOIC8(5.4) [(SA605B)]	SST25VF040@WSON8
[(SA683)]	
SST25VF040B@SOIC8(4.0) [(SA602A)]	
SST25VF040B@SOIC8(5.4) [(SA605A)]	
SST25VF040B@WSON8 [(SA683)]	SST25VF080@SOIC8(4.0)
[(SA602A)]	
SST25VF080@SOIC8(5.4) [(SA605B)]	SST25VF080@WSON8
[(SA683)]	
SST25VF080B@SOIC8(4.0) [(SA602A)]	
SST25VF080B@SOIC8(5.4) [(SA605A)]	
SST25VF080B@WSON8 [(SA683)]	SST25VF512@SOIC8(4.0)
[(SA602A)]	
SST25VF512@SOIC8(5.4) [(SA605B)]	SST25VF512@WSON8
[(SA683)]	
SST25VF512A@SOIC8(4.0) [(SA602A)]	
SST25VF512A@SOIC8(5.4) [(SA605B)]	
SST25VF512A@WSON8 [(SA683)]	SST25WF010@SOIC8
[(SA602A)]	
SST25WF020@SOIC8 [(SA602A)]	SST25WF040@SOIC8
[(SA602A)]	

SST25WF080@SOIC8 [(SA602A)]	SST25WF512@SOIC8
[(SA602A)]	
SST27SF010	SST27SF010@PLCC32
[(SA015A1T)]	
SST27SF010@TSOP32 [(SA410T)]	
SST27SF020	
SST27SF020@PLCC32 [(SA015A1T)]	SST27SF020@TSOP32
[(SA410T)]	
SST27SF256	SST27SF256@PLCC32
[(SA015A1T)]	
SST27SF256@VSOP32 [(SA620)]	
SST27SF512	
SST27SF512@PLCC32 [(SA015A1T)]	SST27SF512@VSOP32
[(SA620)]	
SST27VF010	SST27VF010@PLCC32
[(SA015A1T)]	
SST27VF010@TSOP32 [(SA410T)]	
SST27VF020	
SST27VF020@PLCC32 [(SA015A1T)]	SST27VF020@TSOP32
[(SA410T)]	
SST27VF040	SST27VF040@PLCC32
[(SA015A1T)]	
SST27VF040@TSOP32 [(SA410T)]	
SST27VF256	
SST27VF256@PLCC32 [(SA015A1T)]	SST27VF256@VSOP32
[(SA620)]	
SST27VF512	SST27VF512@PLCC32
[(SA015A1T)]	
SST27VF512@VSOP32 [(SA620)]	
SST28EE011	
SST28EE011@PLCC32 [(SA015A1T)]	SST28EE011@TSOP32
[(SA410T)]	
SST28LE011	SST28LE011@PLCC32
[(SA015A1T)]	
SST28LE011@TSOP32 [(SA410T)]	
SST28LF040	
SST28LF040@PLCC32 [(SA015A1T)]	SST28LF040@TSOP32
[(SA410T)]	
SST28SF040	SST28SF040@PLCC32
[(SA015A1T)]	
SST28SF040@TSOP32 [(SA410T)]	
SST28SF040A	
SST28SF040A@PLCC32 [(SA015A1T)]	SST28SF040A@TSOP32

[(SA410T)]	
SST28VE011	SST28VE011@PLCC32
[(SA015A1T)]	
SST28VE011@TSOP32 [(SA410T)]	
SST28VF040	
SST28VF040@PLCC32 [(SA015A1T)]	SST28VF040@TSOP32
[(SA410T)]	
SST28VF040A	SST28VF040A@PLCC32
[(SA015A1T)]	
SST28VF040A@TSOP32 [(SA410T)]	
SST29EE010	
SST29EE010@PLCC32 [(SA015A1T)]	SST29EE010@TSOP32
[(SA410T)]	
SST29EE020	SST29EE020@PLCC32
[(SA015A1T)]	
SST29EE020@TSOP32 [(SA410T)]	
SST29EE512	
SST29EE512@PLCC32 [(SA015A1T)]	SST29EE512@TSOP32
[(SA410T)]	
SST29LE010	SST29LE010@PLCC32
[(SA015A1T)]	
SST29LE010@TSOP32 [(SA410T)]	
SST29LE020	
SST29LE020@PLCC32 [(SA015A1T)]	SST29LE020@TSOP32
[(SA410T)]	
SST29LE512	SST29LE512@PLCC32
[(SA015A1T)]	
SST29LE512@TSOP32 [(SA410T)]	
SST29SF010	
SST29SF010@PLCC32 [(SA015A1T)]	SST29SF010@VSOP32
[(SA620)]	
SST29SF020	SST29SF020@PLCC32
[(SA015A1T)]	
SST29SF020@VSOP32 [(SA620)]	
SST29SF040	
SST29SF040@PLCC32 [(SA015A1T)]	SST29SF040@VSOP32
[(SA620)]	
SST29SF512	SST29SF512@PLCC32
[(SA015A1T)]	
SST29SF512@VSOP32 [(SA620)]	
SST29VE010	
SST29VE010@PLCC32 [(SA015A1T)]	SST29VE010@TSOP32
[(SA410T)]	

SST29VE020 [(SA015A1T)]	SST29VE020@PLCC32
SST29VE020@TSOP32 [(SA410T)]	
SST29VE512 SST29VE512@PLCC32 [(SA015A1T)]	SST29VE512@TSOP32
[(SA410T)]	
SST29VF010 [(SA015A1T)]	SST29VF010@PLCC32
SST29VF010@VSOP32 [(SA620)]	
SST29VF020 SST29VF020@PLCC32 [(SA015A1T)]	SST29VF020@VSOP32
[(SA620)]	
SST29VF040 [(SA015A1T)]	SST29VF040@PLCC32
SST29VF040@VSOP32 [(SA620)]	
SST29VF512 SST29VF512@PLCC32 [(SA015A1T)]	SST29VF512@VSOP32
[(SA620)]	
SST31LF021@VSOP32 [(SA620)]	SST31LF041@VSOP40
[(SA623)]	
SST31LF041A@VSOP32 [(SA620)]	SST31LF043@VSOP40
[(SA623)]	
SST31LF043A@VSOP32 [(SA620)]	
SST37VF010 SST37VF010@PLCC32 [(SA015A1T)]	SST37VF010@VSOP32
[(SA620)]	
SST37VF020 [(SA015A1T)]	SST37VF020@PLCC32
SST37VF020@VSOP32 [(SA620)]	
SST37VF040 SST37VF040@PLCC32 [(SA015A1T)]	SST37VF040@VSOP32
[(SA620)]	
SST37VF512 [(SA015A1T)]	SST37VF512@PLCC32
SST37VF512@VSOP32 [(SA620)]	SST39LF010@PLCC32
[(SA015A1T)]	
SST39LF010@VSOP32 [(SA620)]	SST39LF016@TSOP40
[(SA409T)]	
SST39LF020@PLCC32 [(SA015A1T)]	SST39LF020@VSOP32
[(SA620)]	
SST39LF040@PLCC32 [(SA015A1T)]	SST39LF040@VSOP32
[(SA620)]	
SST39LF080@TSOP40 [(SA409T)]	SST39LF080Q@TSOP40

[(SA409T)]	
SST39LF512@PLCC32 [(SA015A1T)]	SST39LF512@VSOP32
[(SA620)]	
SST39LH010	SST39LH010@PLCC32
[(SA015A1T)]	
SST39LH010@TSOP32 [(SA410T)]	
SST39LH040	
SST39LH040@PLCC32 [(SA015A1T)]	SST39LH040@TSOP32
[(SA410T)]	
SST39LH512	SST39LH512@PLCC32
[(SA015A1T)]	
SST39LH512@TSOP32 [(SA410T)]	
SST39SF010	
SST39SF010@PLCC32 [(SA015A1T)]	SST39SF010@VSOP32
[(SA620)]	
SST39SF010A	SST39SF010A@PLCC32
[(SA015A1T)]	
SST39SF010A@VSOP32 [(SA620)]	
SST39SF020	
SST39SF020@PLCC32 [(SA015A1T)]	SST39SF020@VSOP32
[(SA620)]	
SST39SF020A	SST39SF020A@PLCC32
[(SA015A1T)]	
SST39SF020A@VSOP32 [(SA620)]	
SST39SF020P	
SST39SF020P@PLCC32 [(SA015A1T)]	SST39SF020P@VSOP32
[(SA620)]	
SST39SF040	SST39SF040@PLCC32
[(SA015A1T)]	
SST39SF040@VSOP32 [(SA620)]	
SST39SF040P	
SST39SF040P@PLCC32 [(SA015A1T)]	SST39SF040P@VSOP32
[(SA620)]	
SST39SF512	SST39SF512@PLCC32
[(SA015A1T)]	
SST39SF512@VSOP32 [(SA620)]	
SST39SF512A	
SST39SF512A@PLCC32 [(SA015A1T)]	SST39SF512A@VSOP32
[(SA620)]	
SST39VF010	SST39VF010@PLCC32
[(SA015A1T)]	
SST39VF010@VSOP32 [(SA620)]	SST39VF016@TSOP40
[(SA409T)]	

SST39VF016Q@TSOP40 [(SA409T)]	
SST39VF020	
SST39VF020@PLCC32 [(SA015A1T)]	SST39VF020@VSOP32
[(SA620)]	
SST39VF020P	
[(SA015A1T)]	SST39VF020P@PLCC32
SST39VF020P@VSOP32 [(SA620)]	
SST39VF040	
SST39VF040@PLCC32 [(SA015A1T)]	SST39VF040@VSOP32
[(SA620)]	
SST39VF040P	
[(SA015A1T)]	SST39VF040P@PLCC32
SST39VF040P@VSOP32 [(SA620)]	
[(SA409T)]	SST39VF080@TSOP40
SST39VF080Q@TSOP40 [(SA409T)]	
SST39VF512	
SST39VF512@PLCC32 [(SA015A1T)]	SST39VF512@VSOP32
[(SA620)]	
SST45LF010@SOIC8 [(SA602A)]	SST45LF010@WSON8
[(SA683)]	
SST45VF010@SOIC8 [(SA602A)]	SST45VF020@SOIC8
[(SA602A)]	
SST45VF512@SOIC8 [(SA602A)]	SST49LF002@PLCC32
[(SA015A1T)]	
SST49LF002@VSOP32 [(SA620)]	SST49LF002A@PLCC32
[(SA015A1T)]	
SST49LF002A@VSOP32 [(SA620)]	SST49LF002B@PLCC32
[(SA015A1T)]	
SST49LF003A@PLCC32 [(SA015A1T)]	SST49LF003A@VSOP32
[(SA620)]	
SST49LF003B@PLCC32 [(SA015A1T)]	SST49LF004@PLCC32
[(SA015A1T)]	
SST49LF004@VSOP32 [(SA620)]	SST49LF004A@PLCC32
[(SA015A1T)]	
SST49LF004A@VSOP32 [(SA620)]	SST49LF004B@PLCC32
[(SA015A1T)]	
SST49LF004B@VSOP32 [(SA620)]	SST49LF004B@VSOP40
[(SA409T)]	
SST49LF004C@PLCC32 [(SA015A1T)]	SST49LF004C@VSOP32
[(SA620)]	
SST49LF008@PLCC32 [(SA015A1T)]	SST49LF008@VSOP32
[(SA620)]	
SST49LF008A@PLCC32 [(SA015A1T)]	SST49LF008A@TSOP40

[(SA409T)]	
SST49LF008A@VSOP32 [(SA620)]	SST49LF008C@PLCC32
[(SA015A1T)]	
SST49LF008C@VSOP32 [(SA620)]	SST49LF016C@PLCC32
[(SA015A1T)]	
SST49LF016C@TSOP40 [(SA409T)]	SST49LF016C@VSOP32
[(SA620)]	
SST49LF020@PLCC32 [(SA015A1T)]	SST49LF020@VSOP32
[(SA620)]	
SST49LF020A@PLCC32 [(SA015A1T)]	SST49LF020A@VSOP32
[(SA620)]	
SST49LF030A@PLCC32 [(SA015A1T)]	SST49LF030A@VSOP32
[(SA620)]	
SST49LF040@PLCC32 [(SA015A1T)]	SST49LF040@VSOP32
[(SA620)]	
SST49LF040A@PLCC32 [(SA015A1T)]	SST49LF040A@VSOP32
[(SA620)]	
SST49LF040B@PLCC32 [(SA015A1T)]	SST49LF040B@TSOP40
[(SA409T)]	
SST49LF040B@VSOP32 [(SA620)]	SST49LF080A@PLCC32
[(SA015A1T)]	
SST49LF080A@VSOP32 [(SA620)]	SST49LF160C@PLCC32
[(SA015A1T)]	
SST49LF160C@TSOP32 [(SA620)]	

MICROCONTROLLER

SST65P542R@SOIC28 [(SA404)]	
SST89C54	
SST89C54@PLCC44 [(SA244)]	SST89C54@TQFP44
[(SA245A)]	
SST89C58	SST89C58@PLCC44
[(SA244)]	
SST89C58@TQFP44 [(SA245A)]	SST89C58RC@PLCC44
[(SA244)]	
SST89C58RC@TQFP44 [(SA245A)]	SST89C58RC@WQFN40
[(SA245A)]	
SST89E516RD	SST89E516RD@PLCC44
[(SA244)]	
SST89E516RD@TQFP44 [(SA245A)]	
SST89E516RD2	
SST89E516RD2@PLCC44 [(SA244)]	SST89E516RD2@TQFP44

[(SA245A)]	
SST89E52RC	SST89E52RC@PLCC44
[(SA244)]	
SST89E52RC@TQFP44 [(SA245A)]	
SST89E52RD	
SST89E52RD@PLCC44 [(SA244)]	SST89E52RD@TQFP44
[(SA245A)]	
SST89E52RD2	SST89E52RD2@PLCC44
[(SA244)]	
SST89E52RD2@TQFP44 [(SA245A)]	
SST89E54RC	
SST89E54RC@PLCC44 [(SA244)]	SST89E54RC@TQFP44
[(SA245A)]	
SST89E54RD	SST89E54RD@PLCC44
[(SA244)]	
SST89E54RD@TQFP44 [(SA245A)]	
SST89E54RD2	
SST89E54RD2@PLCC44 [(SA244)]	SST89E54RD2@TQFP44
[(SA245A)]	
SST89E554RC	SST89E554RC@PLCC44
[(SA244)]	
SST89E554RC@TQFP44 [(SA245A)]	
SST89E564RD	
SST89E564RD@PLCC44 [(SA244)]	SST89E564RD@TQFP44
[(SA245A)]	
SST89E58RD	SST89E58RD@PLCC44
[(SA244)]	
SST89E58RD@TQFP44 [(SA245A)]	
SST89E58RD2	
SST89E58RD2@PLCC44 [(SA244)]	SST89E58RD2@TQFP44
[(SA245A)]	
SST89V516RD	SST89V516RD@PLCC44
[(SA244)]	
SST89V516RD@TQFP44 [(SA245A)]	
SST89V516RD2	
SST89V516RD2@PLCC44 [(SA244)]	SST89V516RD2@TQFP44
[(SA245A)]	
SST89V52RD	SST89V52RD@PLCC44
[(SA244)]	
SST89V52RD@TQFP44 [(SA245A)]	
SST89V52RD2	
SST89V52RD2@PLCC44 [(SA244)]	SST89V52RD2@TQFP44
[(SA245A)]	

SST89V54RD2 [(SA244)]	SST89V54RD2@PLCC44
SST89V54RD2@TQFP44 [(SA245A)]	
SST89V554RC SST89V554RC@PLCC44 [(SA244)] [(SA245A)]	SST89V554RC@TQFP44
SST89V564RD [(SA244)]	SST89V564RD@PLCC44
SST89V564RD@TQFP44 [(SA245A)]	
SST89V58RD2 SST89V58RD2@PLCC44 [(SA244)] [(SA245A)]	SST89V58RD2@TQFP44

ST

E (E) PROM/FRAM/NVRAM

ET2716	
ETC2716	
ETC2732	
M24128 M24128@MLP8 [(SA724)] [(SA602A)]	M24128@SOIC8
M24128@TSOP8 [(SA026)]	
M24164 M24164@SOIC8 [(SA602A)]	
M24256 M24256@MLP8 [(SA724)] [(SA026)]	M24256@TSOP8
M24256[3.9]@SOIC8 [(SA602A)] [(SA605A)]	M24256[5.5]@SOIC8
M24512 [(SA605A)]	M24512@SOIC8
M24512@TSOP8 [(SA026)]	
M24C01 M24C01@MLP8 [(SA724)] [(SA602A)]	M24C01@SOIC8
M24C01R [(SA724)]	M24C01R@MLP8
M24C01R@SOIC8 [(SA602A)] [(SA026)]	M24C01R@TSOP8
M24C01W	M24C01W@MLP8

[(SA724)]	
M24C01W@SOIC8 [(SA602A)]	M24C01W@TSOP8
[(SA026)]	
M24C02	M24C02@MLP8
[(SA724)]	
M24C02@SOIC8 [(SA602A)]	
M24C02R	
M24C02R@MLP8 [(SA724)]	M24C02R@SOIC8
[(SA602A)]	
M24C02R@TSOP8 [(SA026)]	
M24C02W	
M24C02W@MLP8 [(SA724)]	M24C02W@SOIC8
[(SA602A)]	
M24C02W@TSOP8 [(SA026)]	
M24C04	
M24C04@MLP8 [(SA724)]	M24C04@SOIC8
[(SA602A)]	
M24C04R	M24C04R@MLP8
[(SA724)]	
M24C04R@SOIC8 [(SA602A)]	M24C04R@TSOP8
[(SA026)]	
M24C04W	M24C04W@MLP8
[(SA724)]	
M24C04W@SOIC8 [(SA602A)]	M24C04W@TSOP8
[(SA026)]	
M24C08	M24C08@MLP8
[(SA724)]	
M24C08@MSOP8 [(SA695A)]	M24C08@SOIC8
[(SA602A)]	
M24C08@TSOP8 [(SA026)]	
M24C08R	
M24C08R@MLP8 [(SA724)]	M24C08R@MSOP8
[(SA695A)]	
M24C08R@SOIC8 [(SA602A)]	M24C08R@TSOP8
[(SA026)]	
M24C08W	M24C08W@MLP8
[(SA724)]	
M24C08W@MSOP8 [(SA695A)]	M24C08W@SOIC8
[(SA602A)]	
M24C08W@TSOP8 [(SA026)]	M24C128
(BN)	
M24C128(MN)@SOIC8 [(SA605A)]	M24C128(MW)@SOIC8
[(SA602A)]	

M24C128@MLP8 [(SA724)] (BN)	M24C128B
M24C128B(MN)@SOIC8 [(SA605A)] [(SA602A)]	M24C128B(MW)@SOIC8
M24C128B@MLP8 [(SA724)] M24C16	
M24C16@MLP8 [(SA724)] [(SA602A)]	M24C16@SOIC8
M24C16R [(SA724)]	M24C16R@MLP8
M24C16R@SOIC8 [(SA602A)] [(SA026)]	M24C16R@TSOP8
M24C16W [(SA724)]	M24C16W@MLP8
M24C16W@SOIC8 [(SA602A)] [(SA026)]	M24C16W@TSOP8
M24C256(BN) [(SA605A)]	M24C256(MN)@SOIC8
M24C256(MW)@SOIC8 [(SA602A)] [(SA724)]	M24C256@MLP8
M24C256A(BN) [(SA605A)]	M24C256A(MN)@SOIC8
M24C256A(MW)@SOIC8 [(SA602A)] [(SA724)]	M24C256A@MLP8
M24C256B(BN) [(SA605A)]	M24C256B(MN)@SOIC8
M24C256B(MW)@SOIC8 [(SA602A)] [(SA724)]	M24C256B@MLP8
M24C256W(BN) [(SA605A)]	M24C256W(MN)@SOIC8
M24C256W(MW)@SOIC8 [(SA602A)] [(SA724)]	M24C256W@MLP8
M24C32(BN) [(SA026)]	M24C32(DL)@TSSOP14
M24C32(DW)@TSSOP8 [(SA602A)] [(SA605A)]	M24C32(MN)@SOIC8
M24C32(MW)@SOIC8 [(SA602A)] [(SA724)]	M24C32@MLP8
M24C32W(BN) [(SA026)]	M24C32W(DL)@TSSOP14
M24C32W(DW)@TSSOP8 [(SA602A)] [(SA605A)]	M24C32W(MN)@SOIC8
M24C32W(MW)@SOIC8 [(SA602A)]	M24C32W@MLP8

[(SA724)]	
M24C64 (BN)	M24C64 (DL)@TSSOP14
[(SA026)]	
M24C64 (DW)@TSSOP8 [(SA602A)]	M24C64 (MN)@SOIC8
[(SA605A)]	
M24C64 (MW)@SOIC8 [(SA602A)]	M24C64@MLP8
[(SA724)]	
M24C64W (BN)	M24C64W (DL)@TSSOP14
[(SA026)]	
M24C64W (DW)@TSSOP8 [(SA602A)]	M24C64W (MN)@SOIC8
[(SA605A)]	
M24C64W (MW)@SOIC8 [(SA602A)]	M24C64W@MLP8
[(SA724)]	
M24CL04B	M24CL04B@MLP8
[(SA724)]	
M24CL04B@SOIC8 [(SA602A)]	M24CL04B@TSOP8
[(SA026)]	
M24E16	M24E32
(BN)	
M24E32 (DW)@TSSOP8 [(SA602A)]	M24E32 (MN)@SOIC8
[(SA605A)]	
M24E32 (MW)@SOIC8 [(SA602A)]	
M24W01	
M24W01@SOIC8 [(SA602A)]	
M24W02	
M24W02@SOIC8 [(SA602A)]	
M24W04	
M24W04@SOIC8 [(SA602A)]	
M24W08	
M24W08@SOIC8 [(SA602A)]	
M24W16	
M24W16@SOIC8 [(SA602A)]	
M25C01	
M25C02	
M25C04	
M25C08	
M25C16	
M25E16	M25P05@SOIC8
[(SA602A)]	
M25P05@VQFPN8 [(SA683)]	M25P05-A@SOIC8
[(SA602A)]	
M25P05-A@TSSOP8 [(SA605A)]	M25P05-A@VDFPN8
[(SA684)]	

M25P10@SOIC8 [(SA602A)]	M25P10@VQFPN8
[(SA683)]	
M25P10-A@SOIC8 [(SA602A)]	M25P10-A@VFQFPN8
[(SA684)]	
M25P128@SOIC16 [(SA404)]	
M25P128@SOIC16(ISP) [ISP-HEADER01]	
M25P128@VDFPN8 [(SA684)]	
M25P128@VDFPN8(ISP) [ISP-HEADER01]	
M25P16@SOIC16 [(SA404)]	
M25P16@SOIC16(ISP) [ISP-HEADER01]	
M25P16@SOIC8(150mil) [(SA602A)]	
M25P16@SOIC8(150mil)(ISP) [ISP-HEADER01]	
M25P16@SOIC8(200mil) [(SA605A)]	
M25P16@SOIC8(200mil)(ISP) [ISP-HEADER01]	
M25P16@VDFPN8 [(SA684)]	
M25P16@VDFPN8(ISP) [ISP-HEADER01]	
M25P16@VFQFPN8 [(SA683)]	
M25P16@VFQFPN8(ISP) [ISP-HEADER01]	
M25P20@SOIC8 [(SA602A)]	M25P20@SOIC8(ISP) [ISP-
HEADER01]	
M25P20@VFQFPN8 [(SA683)]	
M25P20@VFQFPN8(ISP) [ISP-HEADER01]	
M25P32(Fast Mode)@SOIC16 [(SA404)]	
M25P32(Fast Mode)@VQFPN8 [(SA684)]	
M25P32@SOIC16 [(SA404)]	
M25P32@SOIC16(ISP) [ISP-HEADER01]	
M25P32@SOIC8 [(SA605A)]	M25P32@SOIC8(ISP) [ISP-
HEADER01]	
M25P32@VDFPN8 [(SA684)]	
M25P32@VDFPN8(ISP) [ISP-HEADER01]	
M25P32@VFQFPN8 [(SA683)]	
M25P32@VFQFPN8(ISP) [ISP-HEADER01]	
M25P40@SOIC8 [(SA602A)]	M25P40@SOIC8(ISP) [ISP-
HEADER01]	
M25P40@VFQFPN8 [(SA683)]	
M25P40@VFQFPN8(ISP) [ISP-HEADER01]	
M25P64(Fast Mode)@SOIC16 [(SA404)]	
M25P64(Fast Mode)@VDFPN8 [(SA684)]	
M25P64@SOIC16 [(SA404)]	
M25P64@SOIC16(ISP) [ISP-HEADER01]	
M25P64@VDFPN8 [(SA684)]	
M25P64@VDFPN8(ISP) [ISP-HEADER01]	
M25P80@SOIC16 [(SA404)]	

M25P80@SOIC16(ISP) [ISP-HEADER01]
M25P80@SOIC8 [(SA605A)] M25P80@SOIC8(ISP) [ISP-
HEADER01]
M25P80@VFQFPN8 [(SA683)]
M25P80@VFQFPN8(ISP) [ISP-HEADER01]
M25PE10@SOIC8 [(SA602A)]
M25PE10@SOIC8(ISP) [ISP-HEADER01]
M25PE10@VQFPN8 [(SA683)]
M25PE10@VQFPN8(ISP) [ISP-HEADER01]
M25PE16@SOIC8 [(SA023A)] M25PE16@VQFPN8
[(SA683)]
M25PE20@SOIC8 [(SA602A)]
M25PE20@SOIC8(ISP) [ISP-HEADER01]
M25PE20@VQFPN8 [(SA683)]
M25PE20@VQFPN8(ISP) [ISP-HEADER01]
M25PE40@SOIC8 [(SA023A)]
M25PE40@SOIC8(ISP) [ISP-HEADER01]
M25PE40@VQFPN8 [(SA683)]
M25PE40@VQFPN8(ISP) [ISP-HEADER01]
M25PE80@SOIC8 [(SA023A)]
M25PE80@SOIC8(ISP) [ISP-HEADER01]
M25PE80@VQFPN8 [(SA683)]
M25PE80@VQFPN8(ISP) [ISP-HEADER01]
M25PX32@SOIC16 [(SA404)] M25PX32@SOIC8
[(SA023A)]
M25PX32@VFQFPN8 [(SA683)] M25PX64@SOIC16
[(SA404)]
M25PX64@VDFPN8 [(SA684)]
M25W01
M25W02
M25W04
M25W08
M25W16
M25W166
M27128A
M2716
M2716F1
M27256
M27256A
M2732A
M27512
M2764
M2764A

M27C1000 [(SA015A1T)]	M27C1000@PLCC32
M27C1000@TSOP32 [(SA410T)]	
M27C1001	
M27C1001@PLCC32 [(SA015A1T)] [(SA410T)]	M27C1001@TSOP32
M27C1024 [(SA244)]	M27C1024@PLCC44
M27C128B	
M27C16	
M27C160 [(SA244)]	M27C160@PLCC44
M27C160@PSOP44 [(SA638)]	
M27C160K	
M27C160K@PLCC44 [(SA244)] [(SA638)]	M27C160K@PSOP44
M27C2001 [(SA015A1T)]	M27C2001@PLCC32
M27C2001@TSOP32 [(SA410T)]	
M27C202	
M27C202@PLCC44 [(SA244)] [(SA409T)]	M27C202@TSOP40
M27C256B [(SA015A1T)]	M27C256B@PLCC32
M27C32	
M27C322	
M27C322@SDIP42 [(SA028)]	
M27C400	
M27C4001 [(SA015A1T)]	M27C4001@PLCC32
M27C4001@TSOP32 [(SA410T)]	
M27C4002	
M27C4002@PLCC44 [(SA244)]	
M27C405	
M27C405@PLCC32 [(SA015A1T)] [(SA410T)]	M27C405@TSOP32
M27C512 [(SA015A1T)]	M27C512@PLCC32
M27C513	
M27C516	
M27C516@PLCC44 [(SA244)]	
M27C64A	
M27C64A@PLCC32 [(SA015A1T)]	

M27C800	
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44
[(SA638)]	
M27C801	M27C801@PLCC32
[(SA015A1T)]	
M27C801@TSOP32 [(SA410T)]	
M27HC641	
M27HC641@PLCC28 [(SA008A)]	
M27HC642	
M27HC642@PLCC28 [(SA008A)]	
M27V101	
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32
[(SA410T)]	
M27V102	M27V102@PLCC44
[(SA244)]	
M27V160	M27V160@PLCC44
[(SA244)]	
M27V160@PSOP44 [(SA638)]	
M27V160K	
M27V160K@PLCC44 [(SA244)]	M27V160K@PSOP44
[(SA638)]	
M27V201	M27V201@PLCC32
[(SA015A1T)]	
M27V201@TSOP32 [(SA410T)]	
M27V256	
M27V322	M27V322@SDIP42
[(SA028)]	
M27V401	M27V401@PLCC32
[(SA015A1T)]	
M27V401@TSOP32 [(SA410T)]	
M27V402	
M27V402@PLCC44 [(SA244)]	M27V402@TSOP40
[(SA409T)]	
M27V405	M27V405@PLCC32
[(SA015A1T)]	
M27V405@TSOP32 [(SA410T)]	
M27V512	
M27V512@PLCC32 [(SA015A1T)]	M27V512@TSOP28
[(SA430T)]	
M27V800	M27V800@PLCC44
[(SA244)]	
M27V801	M27V801@PLCC32
[(SA015A1T)]	

M27V801@TSOP32 [(SA410T)]	
M27W101	
M27W101@PLCC32 [(SA015A1T)]	M27W101@TSOP32
[(SA410T)]	
M27W102	
[(SA244)]	M27W102@PLCC44
M27W160	
[(SA244)]	M27W160@PLCC44
M27W160@PSOP44 [(SA638)]	
M27W201	
M27W201@PLCC32 [(SA015A1T)]	M27W201@TSOP32
[(SA410T)]	
M27W202	
[(SA244)]	M27W202@PLCC44
M27W202@TSOP40 [(SA409T)]	
M27W400	
M27W400@PLCC44 [(SA244)]	
M27W401	
M27W401@PLCC32 [(SA015A1T)]	M27W401@TSOP32
[(SA410T)]	
M27W402	
[(SA244)]	M27W402@PLCC44
M27W402@TSOP40 [(SA409T)]	
M27W512	
M27W512@PLCC32 [(SA015A1T)]	M27W512@TSOP28
[(SA430T)]	
M27W800	
[(SA244)]	M27W800@PLCC44
M27W801	
[(SA015A1T)]	M27W801@PLCC32
M27W801@TSOP32 [(SA410T)]	
M28010	
M28010@PLCC32 [(SA015A1T)]	M28010@TSOP32
[(SA410T)]	
M28010R	
[(SA015A1T)]	M28010R@PLCC32
M28010R@TSOP32 [(SA410T)]	
M28010W	
M28010W@PLCC32 [(SA015A1T)]	M28010W@TSOP32
[(SA410T)]	
M28256	
[(SA015A1T)]	M28256@PLCC32
M28256@TSOP28 [(SA430T)]	

M28C010	
M28C010@PLCC32 [(SA015A1T)]	M28C010@TSOP32
[(SA410T)]	
M28C010R	M28C010R@PLCC32
[(SA015A1T)]	
M28C010R@TSOP32 [(SA410T)]	
M28C010W	
M28C010W@PLCC32 [(SA015A1T)]	M28C010W@TSOP32
[(SA410T)]	
M28C16@PLCC32 [(SA015A1T)]	M28C17@SOIC28
[(SA404)]	
M28C64	M28C64@PLCC32
[(SA015A1T)]	
M28C64@TSOP28 [(SA430T)]	
M28C64C	
M28C64C@PLCC32 [(SA015A1T)]	M28C64C@SOIC28
[(SA404)]	
M28C64C@TSOP28 [(SA430T)]	
M28C64X	
M28C64X@PLCC32 [(SA015A1T)]	M28C64X@TSOP28
[(SA430T)]	
M28F101	M28F101@PLCC32
[(SA015A1T)]	
M28F101@TSOP32 [(SA410T)]	
M28F102	
M28F102@PLCC44 [(SA244)]	M28F102@TSOP40
[(SA409T)]	
M28F151	M28F151@PLCC32
[(SA015A1T)]	
M28F151@TSOP32 [(SA410T)]	
M28F201	
M28F201@PLCC32 [(SA015A1T)]	M28F201@TSOP32
[(SA410T)]	
M28F211@TSOP40 [(SA409T)]	M28F221@TSOP40
[(SA409T)]	
M28F256	M28F256@PLCC32
[(SA015A1T)]	
M28F256@TSOP32 [(SA410T)]	M28F411@TSOP40
[(SA409T)]	
M28F421@TSOP40 [(SA409T)]	
M28F512	
M28F512@PLCC32 [(SA015A1T)]	M28F512@TSOP32
[(SA410T)]	

M28LV64 [(SA015A1T)]	M28LV64@PLCC32
M28LV64@TSOP28 [(SA430T)] [(SA409T)]	M28V411@TSOP40
M28V421@TSOP40 [(SA409T)]	
M29F002B M29F002B@PLCC32 [(SA015A1T)] [(SA410T)]	M29F002B@TSOP32
M29F002BB [(SA015A1T)]	M29F002BB@PLCC32
M29F002BB@TSOP32 [(SA410T)]	
M29F002BNT M29F002BNT@PLCC32 [(SA015A1T)] [(SA410T)]	M29F002BNT@TSOP32
M29F002BT [(SA015A1T)]	M29F002BT@PLCC32
M29F002BT@TSOP32 [(SA410T)]	
M29F002T M29F002T@PLCC32 [(SA015A1T)] [(SA410T)]	M29F002T@TSOP32
M29F010B [(SA015A1T)]	M29F010B@PLCC32
M29F010B@TSOP32 [(SA410T)] [(SA638)]	M29F016B@PSOP44
M29F016B@TSOP40 [(SA409T)] [(SA638)]	M29F016D@PSOP44
M29F016D@TSOP40 [(SA409T)] [(SA409T)]	M29F032D@TSOP40
M29F040 [(SA015A1T)]	M29F040@PLCC32
M29F040@TSOP32 [(SA410T)]	
M29F040B M29F040B@PLCC32 [(SA015A1T)] [(SA410T)]	M29F040B@TSOP32
M29F080A@PSOP44 [(SA638)] [(SA409T)]	M29F080A@TSOP40
M29F080D@PSOP44 [(SA638)] [(SA409T)]	M29F080D@TSOP40
M29F100B@PSOP44 [(SA638-B006)] B005)]	M29F100B@TSOP48 [(SA247-
M29F100T@PSOP44 [(SA638-B006)] B005)]	M29F100T@TSOP48 [(SA247-
M29F102B@PLCC44 [(SA244)]	M29F102B@TSOP40

[(SA623)]	
M29F102BB@PLCC44 [(SA244)]	M29F102BB@TSOP40
[(SA623)]	
M29F160BB@TSOP48 [(SA247-B005)]	M29F160BT@TSOP48 [(SA247-B005)]
M29F200B@PSOP44 [(SA638-B006)]	M29F200B@TSOP48 [(SA247-B005)]
M29F200BB@PSOP44 [(SA638-B006)]	M29F200BB@TSOP48 [(SA247-B005)]
M29F200BT@PSOP44 [(SA638-B006)]	M29F200BT@TSOP48 [(SA247-B005)]
M29F200T@PSOP44 [(SA638-B006)]	M29F200T@TSOP48 [(SA247-B005)]
M29F400B@PSOP44 [(SA638-B006)]	M29F400B@TSOP48 [(SA247-B005)]
M29F400BB@PSOP44 [(SA638-B006)]	M29F400BB@TSOP48 [(SA247-B005)]
M29F400BT@PSOP44 [(SA638-B006)]	M29F400BT@TSOP48 [(SA247-B005)]
M29F400T@PSOP44 [(SA638-B006)]	M29F400T@TSOP48 [(SA247-B005)]
M29F512B@PLCC32 [(SA015A1T)]	M29F512B@TSOP32
[(SA620)]	
M29F800AB@PSOP44 [(SA638-B006)]	M29F800AB@TSOP48 [(SA247-B005)]
M29F800AT@PSOP44 [(SA638-B006)]	M29F800AT@TSOP48 [(SA247-B005)]
M29F800DB@PSOP44 [(SA638)]	M29F800DB@TSOP48 [(SA247-B005)]
M29F800DT@PSOP44 [(SA638)]	M29F800DT@TSOP48 [(SA247-B005)]
M29V040@PLCC32 [(SA015A1T)]	M29V040@TSOP32
[(SA410T)]	
M29W004B@TSOP40 [(SA409T)]	M29W004BB@TSOP40
[(SA409T)]	
M29W004BT@TSOP40 [(SA409T)]	M29W004T@TSOP40
[(SA409T)]	
M29W008AB@TSOP40 [(SA409T)]	M29W008AT@TSOP40
[(SA409T)]	
M29W008B@TSOP40 [(SA409T)]	M29W008T@TSOP40
[(SA409T)]	
M29W010B@PLCC32 [(SA015A1T)]	M29W010B@TSOP32
[(SA410T)]	

M29W022BB [(SA015A1T)]	M29W022BB@PLCC32
M29W022BB@TSOP32 [(SA410T)]	
M29W022BT	
M29W022BT@PLCC32 [(SA015A1T)]	M29W022BT@TSOP32
[(SA410T)]	
M29W040@PLCC32 [(SA015A1T)]	M29W040@TSOP32
[(SA410T)]	
M29W040B@PLCC32 [(SA015A1T)]	M29W040B@TSOP32
[(SA410T)]	
M29W102BB@TSOP40 [(SA623)]	M29W102BT@TSOP40
[(SA623)]	
M29W116BB@TSOP40 [(SA409T)]	M29W116BT@TSOP40
[(SA409T)]	
M29W200BB@PSOP44 [(SA638)]	M29W200BB@TSOP48 [(SA247-
B005)]	
M29W200BT@PSOP44 [(SA638)]	M29W200BT@TSOP48 [(SA247-
B005)]	
M29W512B@PLCC32 [(SA015A1T)]	M29W512B@TSOP32
[(SA620)]	
M34C02	M34C02@MSOP8
[(SA666)]	
M34C02@SOIC8 [(SA602A)]	M34C02@TSOP8
[(SA026)]	
M34D32	M34D32@SOIC8
[(SA602A)]	
M34D32@TSSOP8 [(SA026)]	
M34D64	
M34D64@SOIC8 [(SA602A)]	M34D64@TSSOP8
[(SA026)]	
M34E02	M34E02@MSOP8
[(SA666)]	
M34E02@SOIC8 [(SA602A)]	M34E02@TSOP8
[(SA026)]	
M35080	M35080@SOIC8
[(SA602A)]	
M45PE10@SOIC8 [(SA602A)]	M45PE10@VQFPN8
[(SA683)]	
M45PE16@SOIC8 [(SA023A)]	M45PE16@VQFPN8
[(SA683)]	
M45PE20@SOIC8 [(SA602A)]	
M45PE20@SOIC8(ISP) [ISP-HEADER01]	
M45PE20@VQFPN8 [(SA683)]	

M45PE20@VQFPN8 (ISP) [ISP-HEADER01]
M45PE40@SOIC8 [(SA023A)]
M45PE40@SOIC8 (ISP) [ISP-HEADER01]
M45PE40@VQFPN8 [(SA683)]
M45PE40@VQFPN8 (ISP) [ISP-HEADER01]
M45PE80@SOIC16 [(SA023A)]
M45PE80@SOIC16 (ISP) [ISP-HEADER01]
M45PE80@SOIC8 [(SA023A)]
M45PE80@SOIC8 (ISP) [ISP-HEADER01]
M45PE80@VQFPN8 [(SA683)]
M45PE80@VQFPN8 (ISP) [ISP-HEADER01]
M48C02
M48C02B
M48C12
M48C12B
M48T02
M48T02B
M48T08
M48T12
M48T128V
M48T128Y
M48T129V
M48T129Y
M48T12B
M48T18
M48T30
M48T30Y
M48T32
M48T32Y
M48T35 M48T35@SOIC28
[(SA404)]
M48T35AV M48T35AV@SOIC28
[(SA630)]
M48T35AY M48T35AY@SOIC28
[(SA630)]
M48T35Y M48T35Y@SOIC28
[(SA404)]
M48T512AV
M48T512AY
M48T512V
M48T512Y
M48T513V
M48T513Y

M48T559 [(SA630)]	M48T559@SOIC28
M48T559Y [(SA630)]	M48T559Y@SOIC28
M48T58 [(SA404)]	M48T58@SOIC28
M48T58Y [(SA404)]	M48T58Y@SOIC28
M48T59 [(SA404)]	M48T59@SOIC28
M48T59V [(SA404)]	M48T59V@SOIC28
M48T59Y [(SA404)]	M48T59Y@SOIC28
M48Z02	
M48Z02B	
M48Z08	
M48Z09	
M48Z12	
M48Z128	
M48Z128V	
M48Z128Y	
M48Z129V	
M48Z129Y	
M48Z12B	
M48Z18	
M48Z19	
M48Z30	
M48Z30Y	
M48Z32	
M48Z32Y	
M48Z35	
M48Z35@SOIC28 [(SA630)]	
M48Z35Y	
M48Z35Y@SOIC28 [(SA630)]	
M48Z512AV	
M48Z512AY	
M48Z512V	
M48Z512Y	
M48Z513V	
M48Z513Y	
M48Z58	
M48Z58@SOIC28 [(SA404)]	

M48Z58Y	
M48Z58Y@SOIC28 [(SA404)]	
M48Z59	
M48Z59@SOIC28 [(SA404)]	
M48Z59W	
M48Z59W@SOIC28 [(SA404)]	
M48Z59Y	
M48Z59Y@SOIC28 [(SA404)]	M50FLW040A@PLCC32
[(SA015A1T)]	
M50FLW040A@TSOP40 [(SA409T)]	M50FLW040A@VSOP32
[(SA620)]	
M50FLW040B@PLCC32 [(SA015A1T)]	M50FLW040B@TSOP40
[(SA409T)]	
M50FLW040B@VSOP32 [(SA620)]	M50FLW080A@PLCC32
[(SA015A1T)]	
M50FLW080A@TSOP40 [(SA409T)]	M50FLW080A@VSOP32
[(SA620)]	
M50FLW080B@PLCC32 [(SA015A1T)]	M50FLW080B@TSOP40
[(SA409T)]	
M50FLW080B@VSOP32 [(SA620)]	M50FW002@PLCC32
[(SA015A1T)]	
M50FW016@TSOP40 [(SA409T)]	M50FW020@PLCC32
[(SA015A1T)]	
M50FW040@PLCC32 [(SA015A1T)]	M50FW040@TSOP40
[(SA409T)]	
M50FW080@PLCC32 [(SA015A1T)]	M50FW080@TSOP40
[(SA409T)]	
M50FW080@VSOP32 [(SA620)]	M50LPW002@PLCC32
[(SA015A1T)]	
M50LPW012@PLCC32 [(SA015A1T)]	M50LPW020@PLCC32
[(SA015A1T)]	
M50LPW040@PLCC32 [(SA015A1T)]	M50LPW040@TSOP40
[(SA409T)]	
M50LPW041@PLCC32 [(SA015A1T)]	M50LPW041@TSOP40
[(SA409T)]	
M50LPW080@PLCC32 [(SA015A1T)]	M50LPW080@TSOP40
[(SA409T)]	
M50LPW116@TSOP40 [(SA409T)]	
M87C257	
M87C257@PLCC32 [(SA015A1T)]	M93C06
(08bit)	
M93C06(08bit)@SOIC8 [(SA602A)]	M93C06
(16bit)	

M93C06(16bit)@SOIC8 [(SA602A)] (08bit)	M93C46
M93C46(08bit)@MLP8 [(SA694)] [(SA666)]	M93C46(08bit)@MSOP8
M93C46(08bit)@SOIC8 [(SA602A)] [(SA026)]	M93C46(08bit)@TSSOP8
M93C46(16bit) [(SA694)]	M93C46(16bit)@MLP8
M93C46(16bit)@MSOP8 [(SA666)] [(SA602A)]	M93C46(16bit)@SOIC8
M93C46(16bit)@TSSOP8 [(SA026)] (08bit)	M93C46R
M93C46R(08bit)@MLP8 [(SA694)] [(SA666)]	M93C46R(08bit)@MSOP8
M93C46R(08bit)@SOIC8 [(SA602A)] [(SA026)]	M93C46R(08bit)@TSSOP8
M93C46R(16bit) [(SA694)]	M93C46R(16bit)@MLP8
M93C46R(16bit)@MSOP8 [(SA666)] [(SA602A)]	M93C46R(16bit)@SOIC8
M93C46R(16bit)@TSSOP8 [(SA026)] (08bit)	M93C46W
M93C46W(08bit)@MLP8 [(SA694)] [(SA666)]	M93C46W(08bit)@MSOP8
M93C46W(08bit)@SOIC8 [(SA602A)] [(SA026)]	M93C46W(08bit)@TSSOP8
M93C46W(16bit) [(SA694)]	M93C46W(16bit)@MLP8
M93C46W(16bit)@MSOP8 [(SA666)] [(SA602A)]	M93C46W(16bit)@SOIC8
M93C46W(16bit)@TSSOP8 [(SA026)] (08bit)	M93C56
M93C56(08bit)@MLP8 [(SA694)] [(SA666)]	M93C56(08bit)@MSOP8
M93C56(08bit)@SOIC8 [(SA602A)] [(SA026)]	M93C56(08bit)@TSSOP8
M93C56(16bit) [(SA694)]	M93C56(16bit)@MLP8
M93C56(16bit)@MSOP8 [(SA666)] [(SA602A)]	M93C56(16bit)@SOIC8
M93C56(16bit)@TSSOP8 [(SA026)] (08bit)	M93C56R
M93C56R(08bit)@MLP8 [(SA694)]	M93C56R(08bit)@MSOP8

[(SA666)]	
M93C56R(08bit)@SOIC8 [(SA602A)]	M93C56R(08bit)@TSSOP8
[(SA026)]	
M93C56R(16bit)	M93C56R(16bit)@MLP8
[(SA694)]	
M93C56R(16bit)@MSOP8 [(SA666)]	M93C56R(16bit)@SOIC8
[(SA602A)]	
M93C56R(16bit)@TSSOP8 [(SA026)]	M93C56W
(08bit)	
M93C56W(08bit)@MLP8 [(SA694)]	M93C56W(08bit)@MSOP8
[(SA666)]	
M93C56W(08bit)@SOIC8 [(SA602A)]	M93C56W(08bit)@TSSOP8
[(SA026)]	
M93C56W(16bit)	M93C56W(16bit)@MLP8
[(SA694)]	
M93C56W(16bit)@MSOP8 [(SA666)]	M93C56W(16bit)@SOIC8
[(SA602A)]	
M93C56W(16bit)@TSSOP8 [(SA026)]	M93C66
(08bit)	
M93C66(08bit)@MLP8 [(SA694)]	M93C66(08bit)@MSOP8
[(SA666)]	
M93C66(08bit)@SOIC8 [(SA602A)]	M93C66(08bit)@TSSOP8
[(SA026)]	
M93C66(16bit)	M93C66(16bit)@MLP8
[(SA694)]	
M93C66(16bit)@MSOP8 [(SA666)]	M93C66(16bit)@SOIC8
[(SA602A)]	
M93C66(16bit)@TSSOP8 [(SA026)]	M93C66R
(08bit)	
M93C66R(08bit)@MLP8 [(SA694)]	M93C66R(08bit)@MSOP8
[(SA666)]	
M93C66R(08bit)@SOIC8 [(SA602A)]	M93C66R(08bit)@TSSOP8
[(SA026)]	
M93C66R(16bit)	M93C66R(16bit)@MLP8
[(SA694)]	
M93C66R(16bit)@MSOP8 [(SA666)]	M93C66R(16bit)@SOIC8
[(SA602A)]	
M93C66R(16bit)@TSSOP8 [(SA026)]	M93C66W
(08bit)	
M93C66W(08bit)@MLP8 [(SA694)]	M93C66W(08bit)@MSOP8
[(SA666)]	
M93C66W(08bit)@SOIC8 [(SA602A)]	M93C66W(08bit)@TSSOP8
[(SA026)]	

M93C66W(16bit) [(SA694)]	M93C66W(16bit)@MLP8
M93C66W(16bit)@MSOP8 [(SA666)] [(SA602A)]	M93C66W(16bit)@SOIC8
M93C66W(16bit)@TSSOP8 [(SA026)] (08bit)	M93C76
M93C76(08bit)@MLP8 [(SA694)] [(SA666)]	M93C76(08bit)@MSOP8
M93C76(08bit)@SOIC8 [(SA602A)] [(SA026)]	M93C76(08bit)@TSSOP8
M93C76(16bit) [(SA694)]	M93C76(16bit)@MLP8
M93C76(16bit)@MSOP8 [(SA666)] [(SA602A)]	M93C76(16bit)@SOIC8
M93C76(16bit)@TSSOP8 [(SA026)] (08bit)	M93C76R
M93C76R(08bit)@MLP8 [(SA694)] [(SA666)]	M93C76R(08bit)@MSOP8
M93C76R(08bit)@SOIC8 [(SA602A)] [(SA026)]	M93C76R(08bit)@TSSOP8
M93C76R(16bit) [(SA694)]	M93C76R(16bit)@MLP8
M93C76R(16bit)@MSOP8 [(SA666)] [(SA602A)]	M93C76R(16bit)@SOIC8
M93C76R(16bit)@TSSOP8 [(SA026)] (08bit)	M93C76W
M93C76W(08bit)@MLP8 [(SA694)] [(SA666)]	M93C76W(08bit)@MSOP8
M93C76W(08bit)@SOIC8 [(SA602A)] [(SA026)]	M93C76W(08bit)@TSSOP8
M93C76W(16bit) [(SA694)]	M93C76W(16bit)@MLP8
M93C76W(16bit)@MSOP8 [(SA666)] [(SA602A)]	M93C76W(16bit)@SOIC8
M93C76W(16bit)@TSSOP8 [(SA026)] (08bit)	M93C86
M93C86(08bit)@MLP8 [(SA694)] [(SA666)]	M93C86(08bit)@MSOP8
M93C86(08bit)@SOIC8 [(SA602A)] [(SA026)]	M93C86(08bit)@TSSOP8
M93C86(16bit) [(SA694)]	M93C86(16bit)@MLP8
M93C86(16bit)@MSOP8 [(SA666)]	M93C86(16bit)@SOIC8

[(SA602A)]	
M93C86(16bit)@TSSOP8 [(SA026)]	M93C86R
(08bit)	
M93C86R(08bit)@MLP8 [(SA694)]	M93C86R(08bit)@MSOP8
[(SA666)]	
M93C86R(08bit)@SOIC8 [(SA602A)]	M93C86R(08bit)@TSSOP8
[(SA026)]	
M93C86R(16bit)	M93C86R(16bit)@MLP8
[(SA694)]	
M93C86R(16bit)@MSOP8 [(SA666)]	M93C86R(16bit)@SOIC8
[(SA602A)]	
M93C86R(16bit)@TSSOP8 [(SA026)]	M93C86W
(08bit)	
M93C86W(08bit)@MLP8 [(SA694)]	M93C86W(08bit)@MSOP8
[(SA666)]	
M93C86W(08bit)@SOIC8 [(SA602A)]	M93C86W(08bit)@TSSOP8
[(SA026)]	
M93C86W(16bit)	M93C86W(16bit)@MLP8
[(SA694)]	
M93C86W(16bit)@MSOP8 [(SA666)]	M93C86W(16bit)@SOIC8
[(SA602A)]	
M93C86W(16bit)@TSSOP8 [(SA026)]	
M93CS566	
M93CS566@SOIC8 [(SA602A)]	
M93S46	
M93S46@SOIC8 [(SA602A)]	M93S46@TSSOP8
[(SA026)]	
M93S46R	M93S46R@SOIC8
[(SA602A)]	
M93S46R@TSSOP8 [(SA026)]	
M93S46W	
M93S46W@SOIC8 [(SA602A)]	M93S46W@TSSOP8
[(SA026)]	
M93S56	M93S56@SOIC8
[(SA602A)]	
M93S56@TSSOP8 [(SA026)]	
M93S56R	
M93S56R@SOIC8 [(SA602A)]	M93S56R@TSSOP8
[(SA026)]	
M93S56W	M93S56W@SOIC8
[(SA602A)]	
M93S56W@TSSOP8 [(SA026)]	
M93S66	

M93S66@SOIC8 [(SA602A)]	M93S66@TSSOP8
[(SA026)]	
M93S66R	M93S66R@SOIC8
[(SA602A)]	
M93S66R@TSSOP8 [(SA026)]	
M93S66W	
M93S66W@SOIC8 [(SA602A)]	M93S66W@TSSOP8
[(SA026)]	
M95010	M95010(ISP) [ISP-
HEADER01]	
M95010@SOIC8 [(SA602A)]	M95010@SOIC8(ISP) [ISP-
HEADER01]	
M95010@TSSOP8 [(SA026)]	
M95010@TSSOP8(ISP) [ISP-HEADER01]	
M95020	M95020(ISP) [ISP-
HEADER01]	
M95020@SOIC8 [(SA602A)]	M95020@SOIC8(ISP) [ISP-
HEADER01]	
M95020@TSSOP8 [(SA026)]	
M95020@TSSOP8(ISP) [ISP-HEADER01]	
M95040	M95040(ISP) [ISP-
HEADER01]	
M95040@SOIC8 [(SA602A)]	M95040@SOIC8(ISP) [ISP-
HEADER01]	
M95040@TSSOP8 [(SA026)]	
M95040@TSSOP8(ISP) [ISP-HEADER01]	
M95080	M95080(ISP) [ISP-
HEADER01]	
M95080@SOIC8 [(SA602A)]	M95080@SOIC8(ISP) [ISP-
HEADER01]	
M95080@TSSOP14 [(SA026)]	
M95080@TSSOP14(ISP) [ISP-HEADER01]	
M95080@TSSOP8 [(SA026)]	
M95080@TSSOP8(ISP) [ISP-HEADER01]	
M95128	M95128(ISP) [ISP-
HEADER01]	
M95128@TSSOP14 [(SA026)]	
M95128@TSSOP14(ISP) [ISP-HEADER01]	
M95128@TSSOP8 [(SA026)]	
M95128@TSSOP8(ISP) [ISP-HEADER01]	
M95128[150mil]@SOIC8 [(SA602A)]	
M95128[150mil]@SOIC8(ISP) [ISP-HEADER01]	
M95128[200mil]@SOIC8 [(SA023A)]	

M95128[200mil]@SOIC8(ISP) [ISP-HEADER01]
M95160 M95160(ISP) [ISP-
HEADER01]
M95160@SOIC8 [(SA602A)] M95160@SOIC8(ISP) [ISP-
HEADER01]
M95160@TSSOP14 [(SA026)]
M95160@TSSOP14(ISP) [ISP-HEADER01]
M95160@TSSOP8 [(SA026)]
M95160@TSSOP8(ISP) [ISP-HEADER01]
M95256 M95256(ISP) [ISP-
HEADER01]
M95256@TSSOP14 [(SA026)]
M95256@TSSOP14(ISP) [ISP-HEADER01]
M95256@TSSOP8 [(SA026)]
M95256@TSSOP8(ISP) [ISP-HEADER01]
M95256[150mil]@SOIC8 [(SA602A)]
M95256[150mil]@SOIC8(ISP) [ISP-HEADER01]
M95256[200mil]@SOIC8 [(SA023A)]
M95256[200mil]@SOIC8(ISP) [ISP-HEADER01]
M95320 M95320(ISP) [ISP-
HEADER01]
M95320@SOIC8 [(SA602A)] M95320@SOIC8(ISP) [ISP-
HEADER01]
M95320@TSSOP14 [(SA026)]
M95320@TSSOP14(ISP) [ISP-HEADER01]
M95320@TSSOP8 [(SA026)]
M95320@TSSOP8(ISP) [ISP-HEADER01]
M95512@SOIC8 [(SA602A)] M95512@SOIC8(ISP) [ISP-
HEADER01]
M95512@TSSOP8 [(SA026)]
M95512@TSSOP8(ISP) [ISP-HEADER01]
M95640 M95640(ISP) [ISP-
HEADER01]
M95640@SOIC8 [(SA602A)] M95640@SOIC8(ISP) [ISP-
HEADER01]
M95640@TSSOP14 [(SA026)]
M95640@TSSOP14(ISP) [ISP-HEADER01]
M95640@TSSOP8 [(SA026)]
M95640@TSSOP8(ISP) [ISP-HEADER01]
M95M01[150mil]@SOIC8 [(SA602A)]
M95P02
M95P02@SOIC8 [(SA602A)]
M95P04

M95P04@SOIC8 [(SA602A)]
M95P08
M95P08@SOIC8 [(SA602A)]
MK48C02
MK48C02B
MK48C12
MK48C12B
MK48T02
MK48T02B
MK48T08
MK48T12
MK48T12B
MK48T18
MK48T32
MK48T32Y
MK48T35
MK48T35@SOIC28 [(SA630)]
MK48T35Y
MK48T35Y@SOIC28 [(SA630)]
MK48T512V
MK48T512Y
MK48Z02
MK48Z02B
MK48Z08
MK48Z12
MK48Z12B
MK48Z18
MK48Z32
MK48Z32Y
MK48Z35
MK48Z35@SOIC28 [(SA630)]
MK48Z35Y
MK48Z35Y@SOIC28 [(SA630)]
MK48Z512V
MK48Z512Y
MKI48Z02
MKI48Z02B
MKI48Z12
MKI48Z12B
MKI48Z18
ST24C01
[(SA602A)]
ST24C02A

ST24C01@SOIC8

ST24C02A@SOIC8

[(SA602A)] ST24C16	ST24C16@SOIC8
[(SA602A)] ST24FC21	ST24FC21@SOIC8
[(SA602A)] ST24FW21	ST24FW21@SOIC8
[(SA602A)] ST24LC21B	ST24LC21B@SOIC8
[(SA602A)] ST24LW21	ST24LW21@SOIC8
[(SA602A)] ST24W01	ST24W01@SOIC8
[(SA602A)] ST24W02	ST24W02@SOIC8
[(SA602A)] ST24W04C	ST24W04C@SOIC8
[(SA602A)] ST26C201	ST26C201@PLCC32
[(SA015A1T)] ST26C201@TSOP32 [(SA410T)]	
ST27128A	
ST27256	
ST2764A	
ST27C256	ST93C06
(08bit)	
ST93C06(08bit)@SOIC8 [(SA602A)]	ST93C06
(16bit)	
ST93C06(16bit)@SOIC8 [(SA602A)]	ST93C46
(08bit)	
ST93C46(08bit)@SOIC8 [(SA602A)]	ST93C46
(16bit)	
ST93C46(16bit)@SOIC8 [(SA602A)]	ST93C46A
(08bit)	
ST93C46A(08bit)@SOIC8 [(SA602A)]	ST93C46A
(16bit)	
ST93C46A(16bit)@SOIC8 [(SA602A)]	ST93C46C
(08bit)	
ST93C46C(08bit)@SOIC8 [(SA602A)]	ST93C46C
(16bit)	
ST93C46C(16bit)@SOIC8 [(SA602A)]	ST93C46T
(08bit)	
ST93C46T(08bit)@SOIC8 [(SA602A)]	ST93C46T
(16bit)	

ST93C46T(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C47C
ST93C47C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C47C
ST93C47C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C47T
ST93C47T(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C47T
ST93C47T(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56
ST93C56(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56
ST93C56(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56B
ST93C56B(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56B
ST93C56B(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56C
ST93C56C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56C
ST93C56C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C57C
ST93C57C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C57C
ST93C57C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C66
ST93C66(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C66
ST93C66(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C67
ST93C67(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C67
ST93C67(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C76
ST93C76(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C76
ST93C76(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C86
ST93C86(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C86
ST93C86(16bit)@SOIC8 [(SA602A)]	
ST93CS46	
ST93CS46@SOIC8 [(SA602A)]	

ST93CS47
 ST93CS47@SOIC8 [(SA602A)]
 ST93CS56
 ST93CS56@SOIC8 [(SA602A)]
 ST93CS566
 ST93CS566@SOIC8 [(SA602A)]
 ST93CS57
 ST93CS57@SOIC8 [(SA602A)]
 ST93CS66
 ST93CS66@SOIC14 [(SA602)]
 ST93CS67
 ST93CS67@SOIC14 [(SA602)]
 TS27C256
 TS27C64
 [(SA015A1T)]
 TS27C64A
 [(SA015A1T)]
 TS28C16A
 TS28C17A

TS27C64@PLCC32
 TS27C64A@PLCC32

MICROCONTROLLER

ST62T60C6
 ST72F324J2B5@SDIP42 (ISP) [ISP-HEADER01]
 ST72F324J2T6@TQFP44 (ISP) [ISP-HEADER01]
 ST72F324J2TA@TQFP44 (ISP) [ISP-HEADER01]
 ST72F324J4B5@SDIP42 (ISP) [ISP-HEADER01]
 ST72F324J4T6@TQFP44 (ISP) [ISP-HEADER01]
 ST72F324J4TA@TQFP44 (ISP) [ISP-HEADER01]
 ST72F324J6B5@SDIP42 (ISP) [ISP-HEADER01]
 ST72F324J6T5@TQFP44 (ISP) [ISP-HEADER01]
 ST72F324J6T6@TQFP44 (ISP) [ISP-HEADER01]
 ST72F324J6TA@TQFP44 (ISP) [ISP-HEADER01]
 ST72F324J6TC@TQFP44 (ISP) [ISP-HEADER01]
 ST72F324K2B5@SDIP32 (ISP) [ISP-HEADER01]
 ST72F324K2B6@SDIP32 (ISP) [ISP-HEADER01]
 ST72F324K2T6@TQFP32 (ISP) [ISP-HEADER01]
 ST72F324K2TA@TQFP32 (ISP) [ISP-HEADER01]
 ST72F324K4B5@SDIP32 (ISP) [ISP-HEADER01]
 ST72F324K4B6@SDIP32 (ISP) [ISP-HEADER01]
 ST72F324K4T6@TQFP32 (ISP) [ISP-HEADER01]
 ST72F324K4TA@TQFP32 (ISP) [ISP-HEADER01]

ST72F324K6B5@SDIP32 (ISP) [ISP-HEADER01]
 ST72F324K6B6@SDIP32 (ISP) [ISP-HEADER01]
 ST72F324K6T5@TQFP32 (ISP) [ISP-HEADER01]
 ST72F324K6T6@TQFP32 (ISP) [ISP-HEADER01]
 ST72F324K6TA@TQFP32 (ISP) [ISP-HEADER01]
 ST72F324K6TC@TQFP32 (ISP) [ISP-HEADER01]

STC

MICROCONTROLLER

STC89C516RD [(SA244)]	STC89C516RD@PLCC44
STC89C516RD@TQFP44 [(SA245A)]	
STC89C58RD STC89C58RD@PLCC44 [(SA244)] [(SA245A)]	STC89C58RD@TQFP44
STC89LE516AD [(SA244)]	STC89LE516AD@PLCC44
STC89LE516AD@TQFP44 [(SA245A)]	
STC89LE516X2 STC89LE516X2@PLCC44 [(SA244)] [(SA245A)]	STC89LE516X2@TQFP44
STC89LE52AD [(SA244)]	STC89LE52AD@PLCC44
STC89LE52AD@TQFP44 [(SA675)]	
STC89LE54AD STC89LE54AD@PLCC44 [(SA244)] [(SA675)]	STC89LE54AD@TQFP44
STC89LE556AD [(SA244)]	STC89LE556AD@PLCC44
STC89LE556AD@TQFP44 [(SA245A)]	
STC89LE556X2 STC89LE556X2@PLCC44 [(SA244)] [(SA245A)]	STC89LE556X2@TQFP44
STC89LE58AD [(SA244)]	STC89LE58AD@PLCC44
STC89LE58AD@TQFP44 [(SA675)]	
STC89LV516RD STC89LV516RD@PLCC44 [(SA244)] [(SA245A)]	STC89LV516RD@TQFP44
STC89LV58RD	STC89LV58RD@PLCC44

[(SA244)]
 STC89LV58RD@TQFP44 [(SA245A)]

SUMMIT

E (E) PROM / FRAM / NVRAM

S24022	S24022@SOIC8
[(SA602A)]	
S24023	S24023@SOIC8
[(SA602A)]	
S24042	S24042@SOIC8
[(SA602A)]	
S24043	S24043@SOIC8
[(SA602A)]	
S24162	S24162@SOIC8
[(SA602A)]	
S24VP02	S24VP02@SOIC8
[(SA602A)]	
S24VP04	S24VP04@SOIC8
[(SA602A)]	
S24VP08	S24VP08@SOIC8
[(SA602A)]	
S24VP16	S24VP16@SOIC8
[(SA602A)]	
S93462(08bit)	S93462(08bit)@SOIC8
[(SA602A)]	
S93462(16bit)	S93462(16bit)@SOIC8
[(SA602A)]	
S93463(08bit)	S93463(08bit)@SOIC8
[(SA602A)]	
S93463(16bit)	S93463(16bit)@SOIC8
[(SA602A)]	
S93662(08bit)	S93662(08bit)@SOIC8
[(SA602A)]	
S93662(16bit)	S93662(16bit)@SOIC8
[(SA602A)]	
S93663(08bit)	S93663(08bit)@SOIC8
[(SA602A)]	
S93663(16bit)	S93663(16bit)@SOIC8
[(SA602A)]	
S93WD462(08bit)	S93WD462(08bit)@SOIC8

[(SA602A)]	
S93WD462(16bit)	S93WD462(16bit)@SOIC8
[(SA602A)]	
S93WD463(08bit)	S93WD463(08bit)@SOIC8
[(SA602A)]	
S93WD463(16bit)	S93WD463(16bit)@SOIC8
[(SA602A)]	
S93WD662(08bit)	S93WD662(08bit)@SOIC8
[(SA602A)]	
S93WD662(16bit)	S93WD662(16bit)@SOIC8
[(SA602A)]	
S93WD663(08bit)	S93WD663(08bit)@SOIC8
[(SA602A)]	
S93WD663(16bit)	S93WD663(16bit)@SOIC8
[(SA602A)]	

SUNPLUS

E (E) PROM/FRAM/NVRAM

SPHE6400A	SPHE6400A@SOIC8
[(SA602A)]	

MICROCONTROLLER

SPMC65P2102A(dip18)
 SPMC65P2102A(dip18)(ISP) [ISP-HEADER01]
 SPMC65P2102A@SOP18 [(SA404)]
 SPMC65P2102A@SOP18(ISP) [ISP-HEADER01]
 SPMC65P2104A(dip18)
 SPMC65P2104A(dip18)(ISP) [ISP-HEADER01]
 SPMC65P2104A@SOP18 [(SA404)]
 SPMC65P2104A@SOP18(ISP) [ISP-HEADER01]
 SPMC65P2202A(dip16)
 SPMC65P2202A(dip16)(ISP) [ISP-HEADER01]
 SPMC65P2202A(dip20)
 SPMC65P2202A(dip20)(ISP) [ISP-HEADER01]
 SPMC65P2202A@SOP16 [(SA404)]
 SPMC65P2202A@SOP16(ISP) [ISP-HEADER01]
 SPMC65P2202A@SOP20 [(SA404)]
 SPMC65P2202A@SOP20(ISP) [ISP-HEADER01]

SPMC65P2204A(dip16)
 SPMC65P2204A(dip16)(ISP) [ISP-HEADER01]
 SPMC65P2204A(dip20)
 SPMC65P2204A(dip20)(ISP) [ISP-HEADER01]
 SPMC65P2204A@SOP16 [(SA404)]
 SPMC65P2204A@SOP16(ISP) [ISP-HEADER01]
 SPMC65P2204A@SOP20 [(SA404)]
 SPMC65P2204A@SOP20(ISP) [ISP-HEADER01]
 SPMC65P2404A(dip20)
 SPMC65P2404A(dip20)(ISP) [ISP-HEADER01]
 SPMC65P2404A(dip28)
 SPMC65P2404A(dip28)(ISP) [ISP-HEADER01]
 SPMC65P2404A@SOP20 [(SA404)]
 SPMC65P2404A@SOP20(ISP) [ISP-HEADER01]
 SPMC65P2404A@SOP28 [(SA404)]
 SPMC65P2404A@SOP28(ISP) [ISP-HEADER01]
 SPMC65P2408A(dip28)
 SPMC65P2408A(dip28)(ISP) [ISP-HEADER01]
 SPMC65P2408A(dip32)
 SPMC65P2408A(dip32)(ISP) [ISP-HEADER01]
 SPMC65P2408A@SOP28 [(SA404)]
 SPMC65P2408A@SOP28(ISP) [ISP-HEADER01]
 SPMC65P2408A@SOP32 [(SA603)]
 SPMC65P2408A@SOP32(ISP) [ISP-HEADER01]

SYNCMOS

E (E) PROM / FRAM / NVRAM

F29C31004B [(SA015A1T)]	F29C31004B@PLCC32
F29C31004B@TSOP32 [(SA410T)]	
F29C31004T F29C31004T@PLCC32 [(SA015A1T)]	F29C31004T@TSOP32
[(SA410T)]	
F29C51000B [(SA015A1T)]	F29C51000B@PLCC32
F29C51000T [(SA015A1T)]	F29C51000T@PLCC32
F29C51001B [(SA015A1T)]	F29C51001B@PLCC32
F29C51001B@TSOP32 [(SA410T)]	

F29C51001T	
F29C51001T@PLCC32 [(SA015A1T)]	F29C51001T@TSOP32
[(SA410T)]	
F29C51002B	F29C51002B@PLCC32
[(SA015A1T)]	
F29C51002B@TSOP32 [(SA410T)]	
F29C51002T	
F29C51002T@PLCC32 [(SA015A1T)]	F29C51002T@TSOP32
[(SA410T)]	
F29C51004B	F29C51004B@PLCC32
[(SA015A1T)]	
F29C51004B@TSOP32 [(SA410T)]	
F29C51004T	
F29C51004T@PLCC32 [(SA015A1T)]	F29C51004T@TSOP32
[(SA410T)]	
F29LC51000	F29LC51000@PLCC32
[(SA015A1T)]	
F29LC51001	F29LC51001@PLCC32
[(SA015A1T)]	
F29LC51002	F29LC51002@PLCC32
[(SA015A1T)]	
S29C31001B	S29C31001B@PLCC32
[(SA015A1T)]	
S29C31001B@TSOP32 [(SA410T)]	
S29C31001T	
S29C31001T@PLCC32 [(SA015A1T)]	S29C31001T@TSOP32
[(SA410T)]	
S29C31002B	S29C31002B@PLCC32
[(SA015A1T)]	
S29C31002B@TSOP32 [(SA410T)]	
S29C31002T	
S29C31002T@PLCC32 [(SA015A1T)]	S29C31002T@TSOP32
[(SA410T)]	
S29C31004B	S29C31004B@PLCC32
[(SA015A1T)]	
S29C31004B@TSOP32 [(SA410T)]	
S29C31004T	
S29C31004T@PLCC32 [(SA015A1T)]	S29C31004T@TSOP32
[(SA410T)]	
S29C51001B	S29C51001B@PLCC32
[(SA015A1T)]	
S29C51001B@TSOP32 [(SA410T)]	
S29C51001T	

S29C51001T@PLCC32 [(SA015A1T)] [(SA410T)]	S29C51001T@TSOP32
S29C51002B [(SA015A1T)]	S29C51002B@PLCC32
S29C51002B@TSOP32 [(SA410T)] S29C51002T	S29C51002T@TSOP32
S29C51002T@PLCC32 [(SA015A1T)] [(SA410T)]	S29C51004B@PLCC32
S29C51004B [(SA015A1T)]	S29C51004T@TSOP32
S29C51004B@TSOP32 [(SA410T)] S29C51004T	
S29C51004T@PLCC32 [(SA015A1T)] [(SA410T)]	

MICROCONTROLLER

MSU1958 [(SA244)]	MSU1958@PLCC44
MSU1958@TQFP44 [(SA245A)] MSU2952	
MSU2952@PLCC44 [(SA244)] [(SA245A)]	MSU2952@TQFP44
MSU2964 [(SA244)]	MSU2964@PLCC44
MSU2964@TQFP44 [(SA245A)] SM2958	
SM2958@PLCC44 [(SA244)] [(SA245A)]	SM2958@TQFP44
SM2965 [(SA244)]	SM2965@PLCC44
SM2965@TQFP44 [(SA245A)] SM59064	
SM59064@PLCC44 [(SA244)] [(SA245A)]	SM59064@TQFP44
SM59128C [(SA244)]	SM59128C@PLCC44
SM59128C@TQFP44 [(SA245A)] SM59128L	
SM59128L@PLCC44 [(SA244)] [(SA245A)]	SM59128L@TQFP44
SM59164	SM59164@PLCC44

[(SA244)]	
SM59164@TQFP44 [(SA245A)]	
SM59264	
SM59264@PLCC44 [(SA244)]	SM59264@TQFP44
[(SA245A)]	
SM5964	SM5964@PLCC44
[(SA244)]	
SM5964@TQFP44 [(SA245A)]	
SM5964A	
SM5964A@PLCC44 [(SA244)]	SM5964A@TQFP44
[(SA245A)]	
SM5964AC	SM5964AC@PLCC44
[(SA244)]	
SM5964AC@TQFP44 [(SA245A)]	
SM5964AL	
SM5964AL@PLCC44 [(SA244)]	SM5964AL@TQFP44
[(SA245A)]	
SM5964C	SM5964C@PLCC44
[(SA244)]	
SM5964C@TQFP44 [(SA245A)]	
SM5964D0	
SM5964D0@PLCC44 [(SA244)]	SM5964D0@TQFP44
[(SA245A)]	
SM5964D0A	SM5964D0A@PLCC44
[(SA244)]	
SM5964D0A@TQFP44 [(SA245A)]	
SM5964D1A	
SM5964D1A@PLCC44 [(SA244)]	SM5964D1A@TQFP44
[(SA245A)]	
SM59D02G2C	SM59D02G2C (ISP) [ISP-
HEADER01]	
SM59D02G2C@LQFP44 [(SA675-B005)]	
SM59D02G2C@LQFP44 (ISP) [ISP-HEADER01]	
SM59D02G2C@PLCC44 [(SA244-B002)]	
SM59D02G2C@PLCC44 (ISP) [ISP-HEADER01]	
SM59D02G2L	SM59D02G2L (ISP) [ISP-
HEADER01]	
SM59D02G2L@LQFP44 [(SA675-B005)]	
SM59D02G2L@LQFP44 (ISP) [ISP-HEADER01]	
SM59D02G2L@PLCC44 [(SA244-B002)]	
SM59D02G2L@PLCC44 (ISP) [ISP-HEADER01]	
SM59D03G2C	SM59D03G2C (ISP) [ISP-
HEADER01]	

```

SM59D03G2C@LQFP44 [ (SA675-B005) ]
SM59D03G2C@LQFP44( ISP) [ ISP-HEADER01 ]
SM59D03G2C@PLCC44 [ (SA244-B002) ]
SM59D03G2C@PLCC44( ISP) [ ISP-HEADER01 ]
SM59D03G2L                                SM59D03G2L( ISP) [ ISP-
HEADER01 ]
SM59D03G2L@LQFP44 [ (SA675-B005) ]
SM59D03G2L@LQFP44( ISP) [ ISP-HEADER01 ]
SM59D03G2L@PLCC44 [ (SA244-B002) ]
SM59D03G2L@PLCC44( ISP) [ ISP-HEADER01 ]
SM59D04G2C                                SM59D04G2C( ISP) [ ISP-
HEADER01 ]
SM59D04G2C@LQFP44 [ (SA675-B005) ]
SM59D04G2C@LQFP44( ISP) [ ISP-HEADER01 ]
SM59D04G2C@PLCC44 [ (SA244-B002) ]
SM59D04G2C@PLCC44( ISP) [ ISP-HEADER01 ]
SM59D04G2L                                SM59D04G2L( ISP) [ ISP-
HEADER01 ]
SM59D04G2L@LQFP44 [ (SA675-B005) ]
SM59D04G2L@LQFP44( ISP) [ ISP-HEADER01 ]
SM59D04G2L@PLCC44 [ (SA244-B002) ]
SM59D04G2L@PLCC44( ISP) [ ISP-HEADER01 ]
SM59R08A2@TQFP64(*) [ (SA732-B292) ]
SM59R16A2@TQFP64(*) [ (SA732-B292) ]
SM7908                                SM7908@PLCC44
[ (SA244) ]
SM7908@TQFP44 [ (SA245A) ]
SM79108                                SM79108@TQFP44
SM79108@PLCC44 [ (SA244) ]
[ (SA245A) ]
SM79164                                SM79164@PLCC44
[ (SA244) ]
SM79164@TQFP44 [ (SA245A) ]
SM79164L                                SM79164L@TQFP44
SM79164L@PLCC44 [ (SA244) ]
[ (SA245A) ]
SM79164V                                SM79164V@PLCC44
[ (SA244) ]
SM79164V@TQFP44 [ (SA245A) ]
SM7932                                SM7932@TQFP44
SM7932@PLCC44 [ (SA244) ]
[ (SA245A) ]
SM7964                                SM7964@PLCC44

```


[(SA244)]	
SM7964@TQFP44 [(SA245A)]	
SM894051	
SM894051@SOIC20 [(SA023A)]	
SM8951	
SM8951@PLCC44 [(SA244)]	SM8951@TQFP44
[(SA245A)]	
SM89516	SM89516@PLCC44
[(SA244)]	
SM89516@TQFP44 [(SA245A)]	
SM89516A	
SM89516A@PLCC44 [(SA244)]	SM89516A@TQFP44
[(SA245A)]	
SM89516AL	SM89516AL@PLCC44
[(SA244)]	
SM89516AL@TQFP44 [(SA245A)]	
SM89516B	
SM89516B@PLCC44 [(SA244)]	SM89516B@TQFP44
[(SA245A)]	
SM89516BL	SM89516BL@PLCC44
[(SA244)]	
SM89516BL@TQFP44 [(SA245A)]	
SM89516L	
SM89516L@PLCC44 [(SA244)]	SM89516L@TQFP44
[(SA245A)]	
SM8951A	SM8951A@PLCC44
[(SA244)]	
SM8951A@TQFP44 [(SA245A)]	
SM8951AL	
SM8951AL@PLCC44 [(SA244)]	SM8951AL@TQFP44
[(SA245A)]	
SM8951B	SM8951B@PLCC44
[(SA244)]	
SM8951B@TQFP44 [(SA245A)]	
SM8951BL	
SM8951BL@PLCC44 [(SA244)]	SM8951BL@TQFP44
[(SA245A)]	
SM8951L	SM8951L@PLCC44
[(SA244)]	
SM8951L@TQFP44 [(SA245A)]	
SM8952	
SM8952@PLCC44 [(SA244)]	SM8952@TQFP44
[(SA245A)]	

SM8952A	SM8952A@PLCC44
[(SA244)]	
SM8952A@TQFP44 [(SA245A)]	
SM8952AL	
SM8952AL@PLCC44 [(SA244)]	SM8952AL@TQFP44
[(SA245A)]	
SM8952B	SM8952B@PLCC44
[(SA244)]	
SM8952B@TQFP44 [(SA245A)]	
SM8952BL	
SM8952BL@PLCC44 [(SA244)]	SM8952BL@TQFP44
[(SA245A)]	
SM8952L	SM8952L@PLCC44
[(SA244)]	
SM8952L@TQFP44 [(SA245A)]	
SM8954	
SM8954@PLCC44 [(SA244)]	SM8954@TQFP44
[(SA245A)]	
SM8954A	SM8954A@PLCC44
[(SA244)]	
SM8954A@TQFP44 [(SA245A)]	
SM8954AL	
SM8954AL@PLCC44 [(SA244)]	SM8954AL@TQFP44
[(SA245A)]	
SM8954B	SM8954B@PLCC44
[(SA244)]	
SM8954B@TQFP44 [(SA245A)]	
SM8954BL	
SM8954BL@PLCC44 [(SA244)]	SM8954BL@TQFP44
[(SA245A)]	
SM8954L	SM8954L@PLCC44
[(SA244)]	
SM8954L@TQFP44 [(SA245A)]	
SM8958	
SM8958@PLCC44 [(SA244)]	SM8958@TQFP44
[(SA245A)]	
SM8958A	SM8958A@PLCC44
[(SA244)]	
SM8958A@TQFP44 [(SA245A)]	
SM8958AL	
SM8958AL@PLCC44 [(SA244)]	SM8958AL@TQFP44
[(SA245A)]	
SM8958B	SM8958B@PLCC44

[(SA244)]	
SM8958B@TQFP44 [(SA245A)]	
SM8958BL	
SM8958BL@PLCC44 [(SA244)]	SM8958BL@TQFP44
[(SA245A)]	
SM8958L	
[(SA244)]	
SM8958L@TQFP44 [(SA245A)]	SM8958L@PLCC44
SM89S16R1C	
SM89S16R1C@PLCC44 [(SA244)]	SM89S16R1C@TQFP44
[(SA245A)]	
SM89T04R1C	SM89T04R1C@PLCC44
[(SA244)]	
SM89T04R1C@TQFP44 [(SA245A)]	
SM89T04R1L	
SM89T04R1L@PLCC44 [(SA244)]	SM89T04R1L@TQFP44
[(SA245A)]	
SM89T08R1C	SM89T08R1C@PLCC44
[(SA244)]	
SM89T08R1C@TQFP44 [(SA245A)]	
SM89T08R1L	
SM89T08R1L@PLCC44 [(SA244)]	SM89T08R1L@TQFP44
[(SA245A)]	
SM89T16R1C	SM89T16R1C@PLCC44
[(SA244)]	
SM89T16R1C@TQFP44 [(SA245A)]	
SM89T16R1L	
SM89T16R1L@PLCC44 [(SA244)]	SM89T16R1L@TQFP44
[(SA245A)]	

SYNERTEK

[E \(E \) PROM / FRAM / NVRAM](#)

SY2716

SYNTEK

[MICROCONTROLLER](#)

STK6011BP1-3V@PLCC44 [(SA244)] [(SA244)]	STK6011BP21-5V@PLCC44
STK6011BP5-3V@TQFP44 [(SA245A)] [(SA248)]	STK6011P10-5V@LQFP48
STK6011P1-3V@PLCC44 [(SA244)] [(SA244)]	STK6011P2-5V@PLCC44
STK6011P3-3V@SDIP42 [(SA028)] [(SA028)]	STK6011P4-5V@SDIP42
STK6011P5-3V@PQFP44 [(SA245A)] [(SA245A)]	STK6011P6-5V@PQFP44
STK6011P7-3V 5V	STK6011P8-
STK6011P9-3V@LQFP48 [(SA248)] [(SA244)]	STK6012BP1-3V@PLCC44
STK6012BP22-5V@PLCC44 [(SA244)] [(SA245A)]	STK6012BP5-3V@TQFP44
STK6012P10-5V@LQFP48 [(SA248)] [(SA244)]	STK6012P1-3V@PLCC44
STK6012P2-5V@PLCC44 [(SA244)] [(SA028)]	STK6012P3-3V@SDIP42
STK6012P4-5V@SDIP42 [(SA028)] [(SA245A)]	STK6012P5-3V@PQFP44
STK6012P6-5V@PQFP44 [(SA245A)] 3V	STK6012P7-
STK6012P8-5V [(SA248)]	STK6012P9-3V@LQFP48
STK6031@LQFP48 [(SA248)] [(SA244)]	STK6031@PLCC44
STK6031@QFP44 [(SA245A)] STK6032	
STK6032@LQFP48 [(SA248)] [(SA244)]	STK6032@PLCC44
STK6032@QFP44 [(SA245A)] STK6033	
STK6033@LQFP48 [(SA248)] [(SA244)]	STK6033@PLCC44
STK6033@QFP44 [(SA245A)]	

TECHCODE

MICROCONTROLLER

T89C516
[(SA244)]
T89C516@TQFP44 [(SA245A)]
T89C52
T89C52@PLCC44 [(SA244)]
[(SA245A)]
T89C58
[(SA244)]
T89C58@TQFP44 [(SA245A)]

T89C516@PLCC44

T89C52@TQFP44

T89C58@PLCC44

TEKMOS

E (E) PROM / FRAM / NVRAM

TK17LV040@PLCC20 [(SA001A)]

TEMIC

MICROCONTROLLER

T89C51RD2
[(SA244)]
T89C51RD2@TQFP44 [(SA245A)]
T89F64
T89F64@PLCC44 [(SA244)]
[(SA245A)]
TS87C51RB2
[(SA244)]
TS87C51RB2@TQFP44 [(SA245A)]
TS87C51RC2
TS87C51RC2@PLCC44 [(SA244)]
[(SA245A)]
TS87C51RD2
[(SA244)]
TS87C51RD2@TQFP44 [(SA245A)]
TS87C51U2
TS87C51U2@PLCC44 [(SA244)]
[(SA245A)]
TS87C52X2
[(SA244)]

T89C51RD2@PLCC44

T89F64@TQFP44

TS87C51RB2@PLCC44

TS87C51RC2@TQFP44

TS87C51RD2@PLCC44

TS87C51U2@TQFP44

TS87C52X2@PLCC44

TS87C52X2@TQFP44 [(SA245A)]	
TS87C54X2	
TS87C54X2@PLCC44 [(SA244)]	TS87C54X2@TQFP44
[(SA245A)]	
TS87C58X2	
[(SA244)]	TS87C58X2@PLCC44
TS87C58X2@TQFP44 [(SA245A)]	
TSC71RBX2	
TSC71RBX2@PLCC44 [(SA244)]	TSC71RBX2@TQFP44
[(SA245A)]	
TSC71RCX2	
[(SA244)]	TSC71RCX2@PLCC44
TSC71RCX2@TQFP44 [(SA245A)]	
TSC71RDX2	
TSC71RDX2@PLCC44 [(SA244)]	TSC71RDX2@TQFP44
[(SA245A)]	
TSC87251A1@PLCC44 [(SA244)]	
TSC87251G1	
TSC87251G1@PLCC44 [(SA244)]	
TSC87251G1A	
TSC87251G1A@PLCC44 [(SA244)]	
TSC87251G2D	
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44
[(SA245A)]	
TSC87C51	
[(SA244)]	TSC87C51@PLCC44
TSC87C51@TQFP44 [(SA245A)]	
TSC87C52	
TSC87C52@PLCC44 [(SA244)]	TSC87C52@TQFP44
[(SA245A)]	
TSC87C54	
[(SA244)]	TSC87C54@PLCC44
TSC87C54@TQFP44 [(SA245A)]	
TSC87C58	
TSC87C58@PLCC44 [(SA244)]	TSC87C58@TQFP44
[(SA245A)]	

TI

E (E) PROM / FRAM / NVRAM

BQ4010

BQ4010Y	
BQ4011	
BQ4011Y	
BQ4013	
BQ4013Y	
BQ4014	
BQ4014Y	
BQ4015	
BQ4015Y	
SMJ2516	
SMJ2532	
SMJ2532A	
SMJ2564	
SMJ2564@PLCC32 [(SA015A1T)]	
SMJ2716	
SMJ27C256	SMJ27C256@PLCC32
[(SA015A1T)]	
SMJ27C512	SMJ27C512@PLCC32
[(SA015A1T)]	
TMS2516	
TMS2516JLW	
TMS2532	
TMS2532A	
TMS2564	TMS2564@PLCC32
[(SA015A1T)]	
TMS25L32	
TMS27128	
TMS27128A	
TMS2716	
TMS2732	
TMS2732A	
TMS2764	
TMS27C010	
TMS27C010@PLCC32 [(SA015A1T)]	TMS27C010@TSOP32
[(SA410T)]	
TMS27C010A	TMS27C010A@PLCC32
[(SA015A1T)]	
TMS27C010A@TSOP32 [(SA410T)]	
TMS27C020	
TMS27C020@PLCC32 [(SA015A1T)]	TMS27C020@TSOP32
[(SA410T)]	
TMS27C040	TMS27C040@PLCC32
[(SA015A1T)]	

TMS27C040@TSOP32 [(SA410T)]	
TMS27C128	
TMS27C128@PLCC32 [(SA015A1T)]	
TMS27C2001	
TMS27C2001@PLCC32 [(SA015A1T)]	TMS27C2001@TSOP32
[(SA410T)]	
TMS27C210	TMS27C210@PLCC44
[(SA244)]	
TMS27C210A	TMS27C210A@PLCC44
[(SA244)]	
TMS27C240	TMS27C240@PLCC44
[(SA244)]	
TMS27C256	TMS27C256@PLCC32
[(SA015A1T)]	
TMS27C291	TMS27C291@PLCC28
[(SA008A)]	
TMS27C292	TMS27C292@PLCC28
[(SA008A)]	
TMS27C32	
TMS27C512	
TMS27C512@PLCC32 [(SA015A1T)]	
TMS27C64	
TMS27LV010A	TMS27LV010A@PLCC32
[(SA015A1T)]	
TMS27LV010A@TSOP32 [(SA410T)]	
TMS27P32A	
TMS27P64	
TMS27PC010	
TMS27PC010@PLCC32 [(SA015A1T)]	TMS27PC010@TSOP32
[(SA410T)]	
TMS27PC010A	TMS27PC010A@PLCC32
[(SA015A1T)]	
TMS27PC010A@TSOP32 [(SA410T)]	
TMS27PC020	
TMS27PC020@PLCC32 [(SA015A1T)]	TMS27PC020@TSOP32
[(SA410T)]	
TMS27PC040	TMS27PC040@PLCC32
[(SA015A1T)]	
TMS27PC040@TSOP32 [(SA410T)]	
TMS27PC128	
TMS27PC128@PLCC32 [(SA015A1T)]	
TMS27PC210	
TMS27PC210@PLCC44 [(SA244)]	

TMS27PC210A	
TMS27PC210A@PLCC44 [(SA244)]	
TMS27PC240	
TMS27PC240@PLCC44 [(SA244)]	
TMS27PC256	
TMS27PC256@PLCC32 [(SA015A1T)]	
TMS27PC291	
TMS27PC291@PLCC28 [(SA008A)]	
TMS27PC32	
TMS27PC32A	
TMS27PC512	
TMS27PC512@PLCC32 [(SA015A1T)]	
TMS27PC64	
TMS28F010 [(SA015A1T)]	TMS28F010@PLCC32
TMS28F010@TSOP32 [(SA410T)]	
TMS28F020	
TMS28F020@PLCC32 [(SA015A1T)] [(SA410T)]	TMS28F020@TSOP32
TMS28F210 [(SA244)]	TMS28F210@PLCC44
TMS28F210@TSOP40 [(SA409T)]	
TMS28F512	
TMS28F512@PLCC32 [(SA015A1T)] [(SA410T)]	TMS28F512@TSOP32
TMS29F040 [(SA015A1T)]	TMS29F040@PLCC32
TMS29F040@TSOP32 [(SA410T)]	
TMS29F259	
TMS29F259@PLCC32 [(SA015A1T)] [(SA410T)]	TMS29F259@TSOP32
TMS29F512 [(SA015A1T)]	TMS29F512@PLCC32
TMS29F512@TSOP32 [(SA410T)]	
TMS87C257	
TMS87C257@PLCC32 [(SA015A1T)]	

PLD

EP330 [(SA001A)]	EP330@PLCC20
EP910	EP910-P44

[(SA244)]

MICROCONTROLLER

MSP430F1122@SOIC20(ISP) [ISP-HEADER01]
MSP430F1122@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1132@SOIC20(ISP) [ISP-HEADER01]
MSP430F1132@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1222@SOIC28(ISP) [ISP-HEADER01]
MSP430F1222@TSSOP28(ISP) [ISP-HEADER01]
MSP430F1232@SOIC28(ISP) [ISP-HEADER01]
MSP430F1232@TSSOP28(ISP) [ISP-HEADER01]
MSP430F133@QFN64(ISP) [ISP-HEADER01]
MSP430F133@TQFP64(ISP) [ISP-HEADER01]
MSP430F135@QFN64(ISP) [ISP-HEADER01]
MSP430F135@TQFP64(ISP) [ISP-HEADER01]
MSP430F147@QFN64(ISP) [ISP-HEADER01]
MSP430F147@TQFP64(ISP) [ISP-HEADER01]
MSP430F1471@QFN64(ISP) [ISP-HEADER01]
MSP430F1471@TQFP64(ISP) [ISP-HEADER01]
MSP430F148@QFN64(ISP) [ISP-HEADER01]
MSP430F148@TQFP64(ISP) [ISP-HEADER01]
MSP430F1481@QFN64(ISP) [ISP-HEADER01]
MSP430F1481@TQFP64(ISP) [ISP-HEADER01]
MSP430F149@QFN64(ISP) [ISP-HEADER01]
MSP430F149@TQFP64(ISP) [ISP-HEADER01]
MSP430F1491@QFN64(ISP) [ISP-HEADER01]
MSP430F1491@TQFP64(ISP) [ISP-HEADER01]
MSP430F155@QFN64(ISP) [ISP-HEADER01]
MSP430F155@TQFP64(ISP) [ISP-HEADER01]
MSP430F156@QFN64(ISP) [ISP-HEADER01]
MSP430F156@TQFP64(ISP) [ISP-HEADER01]
MSP430F157@QFN64(ISP) [ISP-HEADER01]
MSP430F157@TQFP64(ISP) [ISP-HEADER01]
MSP430F1610@QFN64(ISP) [ISP-HEADER01]
MSP430F1610@TQFP64(ISP) [ISP-HEADER01]
MSP430F1611@QFN64(ISP) [ISP-HEADER01]
MSP430F1611@TQFP64(ISP) [ISP-HEADER01]
MSP430F1612@QFN64(ISP) [ISP-HEADER01]
MSP430F1612@TQFP64(ISP) [ISP-HEADER01]
MSP430F167@QFN64(ISP) [ISP-HEADER01]
MSP430F167@TQFP64(ISP) [ISP-HEADER01]

MSP430F168@QFN64 (ISP) [ISP-HEADER01]
 MSP430F168@TQFP64 (ISP) [ISP-HEADER01]
 MSP430F169@QFN64 (ISP) [ISP-HEADER01]
 MSP430F169@TQFP64 (ISP) [ISP-HEADER01]
 MSP430F412@QFN64 (ISP) [ISP-HEADER01]
 MSP430F412@TQFP64 (ISP) [ISP-HEADER01]
 MSP430F413@QFN64 (ISP) [ISP-HEADER01]
 MSP430F413@TQFP64 (ISP) [ISP-HEADER01]
 MSP430F435@TQFP100 (ISP) [ISP-HEADER01]
 MSP430F435@TQFP80 (ISP) [ISP-HEADER01]
 MSP430F4351@TQFP100 (ISP) [ISP-HEADER01]
 MSP430F4351@TQFP80 (ISP) [ISP-HEADER01]
 MSP430F436@TQFP100 (ISP) [ISP-HEADER01]
 MSP430F436@TQFP80 (ISP) [ISP-HEADER01]
 MSP430F4361@TQFP100 (ISP) [ISP-HEADER01]
 MSP430F4361@TQFP80 (ISP) [ISP-HEADER01]
 MSP430F437@TQFP100 (ISP) [ISP-HEADER01]
 MSP430F437@TQFP80 (ISP) [ISP-HEADER01]
 MSP430F4371@TQFP100 (ISP) [ISP-HEADER01]
 MSP430F4371@TQFP80 (ISP) [ISP-HEADER01]
 MSP430F447@TQFP100 (ISP) [ISP-HEADER01]
 MSP430F448@TQFP100 (ISP) [ISP-HEADER01]
 MSP430F449@TQFP100 (ISP) [ISP-HEADER01]
 MSP430FG4250@QFN48 (ISP) [ISP-HEADER01]
 MSP430FG4260@QFN48 (ISP) [ISP-HEADER01]
 MSP430FG4270@QFN48 (ISP) [ISP-HEADER01]
 MSP430FG437@TQFP100 (ISP) [ISP-HEADER01]
 MSP430FG437@TQFP80 (ISP) [ISP-HEADER01]
 MSP430FG438@TQFP100 (ISP) [ISP-HEADER01]
 MSP430FG438@TQFP80 (ISP) [ISP-HEADER01]
 MSP430FG439@TQFP100 (ISP) [ISP-HEADER01]
 MSP430FG439@TQFP80 (ISP) [ISP-HEADER01]

TMC

E (E) PROM / FRAM / NVRAM

24A01	24A01@SOIC8
[(SA602A)]	
24A01@TSSOP8 [(SA026)]	
24A02	
24A02@SOIC8 [(SA602A)]	24A02@TSSOP8

[(SA026)]	
24A04	24A04@SOIC8
[(SA602A)]	
24A04@TSSOP8 [(SA026)]	
24A08	
24A08@SOIC8 [(SA602A)]	24A08@TSSOP8
[(SA026)]	
24A16	24A16@SOIC8
[(SA602A)]	
24A16@TSSOP8 [(SA026)]	93LC46
(08bit)	
93LC46(08bit)@SOIC8 [(SA602A)]	93LC46(08bit)@TSSOP8
[(SA026)]	
93LC46(16bit)	93LC46(16bit)@SOIC8
[(SA602A)]	
93LC46(16bit)@TSSOP8 [(SA026)]	93LC56
(08bit)	
93LC56(08bit)@SOIC8 [(SA602A)]	93LC56(08bit)@TSSOP8
[(SA026)]	
93LC56(16bit)	93LC56(16bit)@SOIC8
[(SA602A)]	
93LC56(16bit)@TSSOP8 [(SA026)]	
93LC57	
93LC57@SOIC8 [(SA602A)]	93LC57@TSSOP8
[(SA026)]	
93LC66(08bit)	93LC66(08bit)@SOIC8
[(SA602A)]	
93LC66(08bit)@TSSOP8 [(SA026)]	93LC66
(16bit)	
93LC66(16bit)@SOIC8 [(SA602A)]	93LC66(16bit)@TSSOP8
[(SA026)]	
93LC86(08bit)	93LC86(08bit)@SOIC8
[(SA602A)]	
93LC86(08bit)@TSSOP8 [(SA026)]	93LC86
(16bit)	
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86(16bit)@TSSOP8
[(SA026)]	

TOPRO

MICROCONTROLLER

TP2804H [(SA244)]	TP2804H@PLCC44
TP2804H@TQFP44 [(SA245A)]	
TP2804L TP2804L@PLCC44 [(SA244)] [(SA245A)]	TP2804L@TQFP44
TP2808H [(SA244)]	TP2808H@PLCC44
TP2808H@TQFP44 [(SA245A)]	
TP2808L TP2808L@PLCC44 [(SA244)] [(SA245A)]	TP2808L@TQFP44
TP2851 [(SA244)]	TP2851@PLCC44
TP2851@TQFP44 [(SA245A)]	
TP2852 TP2852@PLCC44 [(SA244)] [(SA245A)]	TP2852@TQFP44

TOSHIBA

E (E) PROM / FRAM / NVRAM

TC541000AF@PLCC32 [(SA015A1T)]	
TC541000AP	
TC541001AF@PLCC32 [(SA015A1T)]	
TC541001AP	
TC54256AF [(SA404)]	TC54256AF@SOIC28
TC54256AP [(SA404)]	TC54256AP@SOIC28
TC544000P	
TC54512AF	
TC54512AP	
TC571000	
TC571000AD	
TC571000D	
TC571001AD	
TC571001D	
TC571024D	
TC57256	
TC57256A	

TC57256AD	
TC57256ADI	
TC57256D	
TC574000D	
TC574096D	
TC574200D	
TC57512	
TC57512AD	
TC578200D	
TC57H1000AD	
TC57H1001AD	
TC57H256D	TC89101
(08bit)	
TC89101(16bit)	TC89102
(08bit)	
TC89102(16bit)	
TC89121	
TC89121@SOIC8 [(SA602A)]	
TC89122	
TC89122@SOIC8 [(SA602A)]	
TC97101	
TC9WMA1FK@US8 [(BBBB)]	TC9WMA2FK@US8
[(BBBB)]	
TC9WMB1AFK@US8 [(BBBB)]	TC9WMB1AFU@SM8
[(SA666)]	
TC9WMB1FK@US8 [(BBBB)]	TC9WMB2AFK@US8
[(BBBB)]	
TC9WMB2AFU@SM8 [(SA666)]	TC9WMB2FK@US8
[(BBBB)]	
TC9WMB4FU@SM8 [(SA666)]	TC9WMB8FU@SM8
[(SA666)]	
TC9WMC1FK@US8 [(BBBB)]	TC9WMC1FU@SM8
[(SA666)]	
TC9WMC2FK@US8 [(BBBB)]	TC9WMC2FU@SM8
[(SA666)]	
TC9WMC4FK@US8 [(BBBB)]	TC9WMC4FU@SM8
[(SA602A)]	
TMM24128	
TMM24128A	
TMM24128AP	
TMM24256	
TMM24256A	
TMM24256AP	

TMM24256B
TMM24512
TMM24512A
TMM24512P
TMM2464AP
TMM27128
TMM27128A
TMM27128ADI
TMM27128AP
TMM27256
TMM27256A
TMM27256AD
TMM27256ADI
TMM27256BD
TMM27256BDI
TMM27256D
TMM27256DI
TMM2732
TMM2732A
TMM2732D
TMM27512
TMM27512AD
TMM27512ADI
TMM27512D
TMM27512DI
TMM2764
TMM2764AD
TMM2764ADI
TMM2764AP
TMM2764D
TMM2764DI

DRAM & SRAM

TC518128 [(SA630)]	TC518128@SOIC32
TC518129 [(SA630)]	TC518129@SOIC32
TC51832 [(SA630)]	TC51832@SOIC28
TC518512 [(SA630)]	TC518512@SOIC32

TC551001FL [(SA630)]	TC551001FL@SOIC32
TC551001PL [(SA630)]	TC551001PL@SOIC32
TC55257 [(SA630)]	TC55257@SOIC28
TC55257L [(SA630)]	TC55257L@SOIC28
TC55258 [(SA630)]	TC55258@SOIC28
TC55258L [(SA630)]	TC55258L@SOIC28
TC55328 [(SA630)]	TC55328@SOIC28
TC5561P [(SA646)]	TC5561P@SOJ24
TC5562P [(SA646)]	TC5562P@SOJ24
TC5563APL [(SA630)]	TC5563APL@SOIC28
TC5564APL [(SA630)]	TC5564APL@SOIC28
TC5565AFL [(SA630)]	TC5565AFL@SOIC28
TC5565APL [(SA630)]	TC5565APL@SOIC28
TC5588 [(SA630)]	TC5588@SOIC28
TC55B88 [(SA630)]	TC55B88@SOIC28
TMM2018 [(SA015A1T)]	TMM2018@PLCC32
TMM2063 [(SA630)]	TMM2063@SOIC28

MICROCONTROLLER

TMP87P808LM@SOP28 (Toshiba) [(BM11116)]
TMP87P808LN@SDIP28 (Toshiba) [(BM11122)]
TMP87P808M@SOP28 (Toshiba) [(BM11116)]
TMP87P808N@SDIP28 (Toshiba) [(BM11122)]
TMP87P844N@SDIP42 (Toshiba) [(BM11108)]

TMP87P844NG@SDIP42(Toshiba) [(BM11108)]
TMP87PH00DF@QFP64(Toshiba) [(BM1173)]
TMP87PH00F@QFP64(Toshiba) [(BM1137)]
TMP87PH00LF@QFP64(Toshiba) [(BM1173)]
TMP87PH00N@SDIP64(Toshiba) [(BM1136)]
TMP87PH20F@QFP80(Toshiba) [(BM1138)]
TMP87PH40AF@PQFP64(Toshiba) [(BM1137)]
TMP87PH40AN@SDIP64(Toshiba) [(BM1136)]
TMP87PH46N@SDIP42(Toshiba) [(BM1193)]
TMP87PH47LU@QFP44(Toshiba) [(BM1194C)]
TMP87PH47U@QFP44(Toshiba) [(BM1194C)]
TMP87PM14F@QFP64(Toshiba) [(BM1199)]
TMP87PM14N@SDIP64(Toshiba) [(BM1198)]
TMP87PM20F@QFP80(Toshiba) [(BM1138)]
TMP87PM29U@LQFP64(Toshiba) [(BM11117)]
TMP87PM34AN@SDIP42(Toshiba) [(BM1183A)]
TMP87PM36N@SDIP42(Toshiba) [(BM1183A)]
TMP87PM40AF@PQFP64(Toshiba) [(BM1137)]
TMP87PM40AN@SDIP64(Toshiba) [(BM1136)]
TMP87PM41F@QFP64(Toshiba) [(BM1137)]
TMP87PM41N@SDIP64(Toshiba) [(BM1136)]
TMP87PM41U@LQFP64(Toshiba) [(BM1121)]
TMP87PM43N@SDIP42(Toshiba) [(BM1163)]
TMP87PM70F@QFP80(Toshiba) [(BM1150B)]
TMP87PM74F@QFP80(Toshiba) [(BM11120)]
TMP87PM75F@QFP100(Toshiba) [(BM11124)]
TMP87PM78F@QFP100(Toshiba) [(BM1188)]
TMP87PP21DF@LQFP80(Toshiba) [(BM11105)]
TMP87PP21F@QFP80(Toshiba) [(BM11104)]
TMP87PP23F@QFP100(Toshiba) [(BM1185A)]
TMP87PP24F@LQFP100(Toshiba) [(BM11127)]
TMP87PP71F@QFP80(Toshiba) [(BM11107)]
TMP87PS38F@QFP44(Toshiba) [(BM11136)]
TMP87PS38N@SDIP42(Toshiba) [(BM11112)]
TMP87PS39F@QFP64(Toshiba) [(BM11138)]
TMP87PS39N@SDIP64(Toshiba) [(BM11118)]
TMP87PS64F@QFP100(Toshiba) [(BM1185A)]
TMP87PS71F@QFP80(Toshiba) [(BM11107)]

TURBO IC

E (E) PROM / FRAM / NVRAM

TU24C01 [(SA602A)]	TU24C01@SOIC8
TU24C02 [(SA602A)]	TU24C02@SOIC8
TU24C04 [(SA602A)]	TU24C04@SOIC8
TU24C08 [(SA602A)]	TU24C08@SOIC8
TU24C128 [(SA602A)]	TU24C128@SOIC8
TU24C16 [(SA602A)]	TU24C16@SOIC8
TU24C16@TSSOP8 [(SA026)]	
TU24C256 TU24C256@SOIC8 [(SA602A)]	
TU24C32 TU24C32@SOIC8 [(SA602A)]	
TU24C64 TU24C64@SOIC8 [(SA602A)]	

UMC

E (E) PROM / FRAM / NVRAM

2732
2764

DRAM & SRAM

UM6116 [(SA015A1T)]	UM6116@PLCC32
UM6116A [(SA015A1T)]	UM6116A@PLCC32
UM61256 [(SA630)]	UM61256@SOIC28
UM61257	
UM61512 UM61512@SOIC32 [(SA630)]	
UM6164 UM6164@SOIC28 [(SA630)]	

UM6167	
UM621024	UM621024@SOIC32
[(SA630)]	
UM62256	UM62256@SOIC28
[(SA630)]	
UM62256A	UM62256A@SOIC28
[(SA630)]	
UM6264	UM6264@SOIC28
[(SA630)]	
UM6264A	UM6264A@SOIC28
[(SA630)]	

UTRON

E (E) PROM / FRAM / NVRAM

UT61256C	UT61256C@SOIC28
[(SA630)]	
UT61256C@TSOP28 [(SA430T)]	UT6164C@SOIC28
[(SA630)]	
UT6164C@TSOP28 [(SA430T)]	
UT61L256C	
UT61L256C@SOIC28 [(SA630)]	UT61L256C@TSOP28
[(SA430T)]	
UT62256C	UT62256C@SOIC28
[(SA630)]	
UT62256C@TSOP28 [(SA430T)]	
UT62256CE	
UT62256CE@SOIC28 [(SA630)]	UT62256CE@TSOP28
[(SA430T)]	
UT62257C	UT62257C@SOIC28
[(SA630)]	
UT62257C@TSOP28 [(SA430T)]	
UT6264C	
UT6264C@SOIC28 [(SA630)]	
UT62L256C	
UT62L256C@SOIC28 [(SA630)]	UT62L256C@TSOP28
[(SA430T)]	
UT62L64C	UT62L64C@SOIC28
[(SA630)]	
UT62W256C	UT62W256C@SOIC28
[(SA630)]	

UT62W256C@TSOP28 [(SA430T)]
UT62W64C
UT62W64C@SOIC28 [(SA630)]

VLSI

E (E) PROM / FRAM / NVRAM

VT27C128
VT27C256
VT27C512
VT27C64
VT28H64
VT28HC64

PLD

GAL16V8

WELTRENED

MICROCONTROLLER

WT6703F@SOP20 [(SA404)] [(SA404)]	WT6703F@SOP24
WT6703F@SOP28 [(SA404)] [(SA674)]	WT6703F@SSOP24
WT6703FS161@SSOP16 [(SA602)] [(SA602)]	WT6703FS163@SSOP16

WHITE ELECTRONIC DESIGNS

E (E) PROM / FRAM / NVRAM

WE128K8
WE256K8
WE512K8
WF256K8

WF256K8@CLCC32 [(SA015A1T)]	WF256K8@CSOJ32
[(SA661)]	
WF512K8	WF512K8@CLCC32
[(SA015A1T)]	
WF512K8@CSOJ32 [(SA661)]	
WME128K8	
WME128K8@CLCC32 [(SA015A1T)]	WME128K8@CSOJ32
[(SA661)]	
WMF128K8	WMF128K8@CLCC32
[(SA015A1T)]	
WMF128K8@CSOJ32 [(SA661)]	
WMF256K8	
WMF256K8@CLCC32 [(SA015A1T)]	WMF256K8@CSOJ32
[(SA661)]	
WMF512K8	WMF512K8@CLCC32
[(SA015A1T)]	
WMF512K8@CSOJ32 [(SA661)]	
WMS128K8	
WMS128K8@CLCC32 [(SA015A1T)]	WMS128K8@CSOJ32
[(SA661)]	
WMS256K8	WMS256K8@CLCC32
[(SA015A1T)]	
WMS256K8@CSOJ32 [(SA661)]	
WMS512K8	
WMS512K8@CLCC32 [(SA015A1T)]	WMS512K8@CSOJ32
[(SA661)]	

WINBOND

E(E) PROM/FRAM/NVRAM

W15B020L	W15B020L@SOIC8
[(SA602A)]	
W15B020M	W15B020M@SOIC8
[(SA602A)]	
W15B040L	W15B040L@SOIC8
[(SA602A)]	
W15B040M	W15B040M@SOIC8
[(SA602A)]	
W25B40(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40(Bottom Boot)@WSON8 [(SA683)]	
W25B40(Top Boot)@SOIC8 [(SA602A)]	

W25B40(Top Boot)@WSON8 [(SA683)]	
W25B40A(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40A(Bottom Boot)@WSON8 [(SA683)]	
W25B40A(Top Boot)@SOIC8 [(SA602A)]	
W25B40A(Top Boot)@WSON8 [(SA683)]	
W25D10 [(SA602A)]	W25D10(SN)@SOIC8
W25D10(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D10(ZP)@WSON8
W25D20 [(SA602A)]	W25D20(SN)@SOIC8
W25D20(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D20(ZP)@WSON8
W25D40 [(SA602A)]	W25D40(SN)@SOIC8
W25D40(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D40(ZP)@WSON8
W25D80 [(SA602A)]	W25D80(SN)@SOIC8
W25D80(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D80(ZP)@WSON8
W25P10@SOIC8 [(SA602A)] [(SA683)]	W25P10@WSON8
W25P16@SOIC16 [(SA404)]	
W25P16@SOIC16(ISP) [ISP-HEADER01]	
W25P16@SOIC8 [(SA023A)]	W25P16@SOIC8(ISP) [ISP-HEADER01]
W25P16@WSON8 [(SA683)]	W25P16@WSON8(ISP) [ISP-HEADER01]
W25P20@SOIC8 [(SA602A)] [(SA683)]	W25P20@WSON8
W25P32@SOIC16 [(SA404)]	
W25P32@SOIC16(ISP) [ISP-HEADER01]	
W25P32@WSON8 [(SA683)]	W25P32@WSON8(ISP) [ISP-HEADER01]
W25P40@SOIC8 [(SA602A)] [(SA683)]	W25P40@WSON8
W25P64@SOIC16 [(SA404)]	
W25P64@SOIC16(ISP) [ISP-HEADER01]	
W25P64@WSON8 [(SA683)]	W25P64@WSON8(ISP) [ISP-HEADER01]
W25P80@SOIC8 [(SA602A)] [(SA683)]	W25P80@WSON8

W25Q16@SOIC16 [(SA404)]	
W25Q16@SOIC16(ISP) [ISP-HEADER01]	
W25Q16@SOIC8 [(SA023A)]	W25Q16@SOIC8(ISP) [ISP-HEADER01]
W25Q16@WSON8 [(SA683)]	W25Q16@WSON8(ISP) [ISP-HEADER01]
W25Q16BV@SOIC16 [(SA404)]	W25Q16BV@SOIC8
[(SA023A)]	
W25Q16BV@WSON8 [(SA683)]	W25Q16V@SOIC16
[(SA404)]	
W25Q16V@SOIC8 [(SA023A)]	W25Q16V@WSON8
[(SA683)]	
W25Q32@SOIC16 [(SA404)]	
W25Q32@SOIC16(ISP) [ISP-HEADER01]	
W25Q32@WSON8 [(SA683)]	W25Q32@WSON8(ISP) [ISP-HEADER01]
W25Q32BV@SOIC16 [(SA404)]	W25Q32BV@WSON8
[(SA683)]	
W25Q32V@SOIC16 [(SA404)]	W25Q32V@WSON8
[(SA683)]	
W25Q64BV@SOIC16 [(SA404)]	W25Q64BV@SOIC8
[(SA023A)]	
W25Q80@SOIC8 [(SA602A)]	W25Q80@WSON8
[(SA683)]	
W25X10	W25X10(SN)@SOIC8
[(SA602A)]	
W25X10(SS)@SOIC8 [(SA023A)]	W25X10(ZP)@WSON8
[(SA683)]	
W25X10AV	W25X10AV(SN)@SOIC8
[(SA602A)]	
W25X10AV(SS)@SOIC8 [(SA023A)]	W25X10AV(ZP)@WSON8
[(SA683)]	
W25X10L	W25X10L(SN)@SOIC8
[(SA602A)]	
W25X10L(ZP)@WSON8 [(SA683)]	
W25X10V	W25X10V(SS)@SOIC8
W25X10V(SN)@SOIC8 [(SA602A)]	
[(SA023A)]	
W25X10V(ZP)@WSON8 [(SA683)]	W25X16@SOIC16
[(SA404)]	
W25X16@SOIC16(ISP) [ISP-HEADER01]	
W25X16@SOIC8 [(SA023A)]	W25X16@SOIC8(ISP) [ISP-HEADER01]
HEADER01]	

W25X20 [(SA602A)]	W25X20 (SN)@SOIC8
W25X20(SS)@SOIC8 [(SA023A)] [(SA683)]	W25X20 (ZP)@WSON8
W25X20AV [(SA602A)]	W25X20AV(SN)@SOIC8
W25X20AV(SS)@SOIC8 [(SA023A)] [(SA683)]	W25X20AV(ZP)@WSON8
W25X20L [(SA602A)]	W25X20L(SN)@SOIC8
W25X20L(ZP)@WSON8 [(SA683)]	
W25X20V W25X20V(SN)@SOIC8 [(SA602A)] [(SA023A)]	W25X20V(SS)@SOIC8
W25X20V(ZP)@WSON8 [(SA683)] [(SA404)]	W25X32@SOIC16
W25X32@SOIC16(ISP) [ISP-HEADER01]	
W25X32@SOIC8 [(SA023A)] HEADER01]	W25X32@SOIC8(ISP) [ISP-
W25X40 [(SA602A)]	W25X40(SN)@SOIC8
W25X40(SS)@SOIC8 [(SA023A)] [(SA683)]	W25X40(ZP)@WSON8
W25X40AV [(SA602A)]	W25X40AV(SN)@SOIC8
W25X40AV(SS)@SOIC8 [(SA023A)] [(SA683)]	W25X40AV(ZP)@WSON8
W25X40L [(SA602A)]	W25X40L(SN)@SOIC8
W25X40L(SS)@SOIC8 [(SA023A)] [(SA683)]	W25X40L(ZP)@WSON8
W25X40V [(SA602A)]	W25X40V(SN)@SOIC8
W25X40V(SS)@SOIC8 [(SA023A)] [(SA683)]	W25X40V(ZP)@WSON8
W25X64@SOIC16 [(SA404)]	
W25X64@SOIC16(ISP) [ISP-HEADER01]	
W25X64@SOIC8 [(SA023A)] HEADER01]	W25X64@SOIC8(ISP) [ISP-
W25X80 [(SA602A)]	W25X80(SN)@SOIC8
W25X80(SS)@SOIC8 [(SA023A)] [(SA683)]	W25X80(ZP)@WSON8

W25X80AV [(SA602A)]	W25X80AV(SN)@SOIC8
W25X80AV(SS)@SOIC8 [(SA023A)] [(SA683)]	W25X80AV(ZP)@WSON8
W25X80L [(SA023A)]	W25X80L(SS)@SOIC8
W25X80L(ZP)@WSON8 [(SA683)]	
W25X80V W25X80V(SN)@SOIC8 [(SA602A)] [(SA023A)]	W25X80V(SS)@SOIC8
W25X80V(ZP)@WSON8 [(SA683)]	
W27C01 W27C01@PLCC32 [(SA015A1T)] [(SA620)]	W27C01@VSOP32
W27C010 [(SA015A1T)]	W27C010@PLCC32
W27C010@SOIC32 [(SA438T)]	
W27C02 W27C02@PLCC32 [(SA015A1T)] [(SA620)]	W27C02@VSOP32
W27C020 [(SA015A1T)]	W27C020@PLCC32
W27C020M [(SA015A1T)]	W27C020M@PLCC32
W27C257 [(SA015A1T)]	W27C257@PLCC32
W27C4096 [(SA244)]	W27C4096@PLCC44
W27C4096@TSOP40 [(SA409T)]	
W27C512 W27C512@PLCC32 [(SA015A1T)] [(SA430T)]	W27C512@TSOP28
W27C520@SOIC20 [(SA404)] [(SA026)]	W27C520@TSSOP20
W27E01 [(SA015A1T)]	W27E01@PLCC32
W27E01@VSOP32 [(SA620)]	
W27E010 W27E010@PLCC32 [(SA015A1T)] [(SA438T)]	W27E010@SOIC32
W27E02 [(SA015A1T)]	W27E02@PLCC32
W27E02@VSOP32 [(SA620)]	

W27E020	
W27E020@PLCC32 [(SA015A1T)]	
W27E040	
W27E040@PLCC32 [(SA015A1T)]	W27E040@SOIC32
[(SA438T)]	
W27E257	
[(SA015A1T)]	W27E257@PLCC32
W27E4096	
[(SA244)]	W27E4096@PLCC44
W27E4096@TSOP40 [(SA409T)]	
W27E512	
W27E512@PLCC32 [(SA015A1T)]	W27E512@TSOP28
[(SA430T)]	
W27E520@SOIC20 [(SA404)]	W27E520@TSSOP20
[(SA026)]	
W27L01	
[(SA015A1T)]	W27L01@PLCC32
W27L01@VSOP32 [(SA620)]	
W27L010	
W27L010@PLCC32 [(SA015A1T)]	
W27L02	
W27L02@PLCC32 [(SA015A1T)]	W27L02@VSOP32
[(SA620)]	
W27L520@SOIC20 [(SA404)]	W27L520@TSSOP20
[(SA026)]	
W29C010	W29C010@PLCC32
[(SA015A1T)]	
W29C011A	W29C011A@PLCC32
[(SA015A1T)]	
W29C020	W29C020@PLCC32
[(SA015A1T)]	
W29C020@SOIC32 [(SA438T)]	W29C020@TSOP32
[(SA410T)]	
W29C020C	
W29C020C@PLCC32 [(SA015A1T-B001)]	
W29C020C@TSOP32 [(SA410T-B003)]	W29C020C@VSOP32 [(SA620-
B005)]	
W29C040	W29C040@PLCC32 [(SA015A1T-
B001)]	
W29C040@TSOP32 [(SA410T-B003)]	W29C040@VSOP32 [(SA620-
B005)]	
W29C101	W29C101@PLCC44
[(SA244)]	

W29C101@TSOP40 [(SA409T)]	
W29C102	
W29C102@PLCC44 [(SA244)]	W29C102@TSOP40
[(SA409T)]	
W29EE010	W29EE010@PLCC32
[(SA015A1T)]	
W29EE010@SOIC32 [(SA438T)]	W29EE010@TSOP32
[(SA410T)]	
W29EE011	W29EE011@PLCC32
[(SA015A1T)]	
W29EE011@SOIC32 [(SA438T)]	
W29EE012	
W29EE012@PLCC32 [(SA015A1T)]	W29EE012@SOIC32
[(SA438T)]	
W29EE512	W29EE512@PLCC32
[(SA015A1T)]	
W29EE512@SOIC32 [(SA438T)]	W29EE512@TSOP32
[(SA410T)]	
W29F040	W29F040@PLCC32
[(SA015A1T)]	
W29F040@TSOP32 [(SA410T)]	
W39F010	
W39F010@PLCC32 [(SA015A1T-B001)]	
W39F010@TSOP32[12.4mm] [(SA620-B005)]	
W39F010@TSOP32[18.4mm] [(SA410T-B003)]	
W39L010@PLCC32 [(SA015A1T-B001)]	W39L010@TSOP32 [(SA620-B005)]
W39L020@PLCC32 [(SA015A1T-B001)]	
W39L020@TSOP32[12.4mm] [(SA620-B005)]	
W39L020@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040@PLCC32 [(SA015A1T-B001)]	
W39L040@TSOP32[12.4mm] [(SA620-B005)]	
W39L040@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040A	W39L040A@PLCC32
[(SA015A1T)]	
W39L040A@TSOP32 [(SA410T)]	W39L040A@VSOP32
[(SA620)]	
W39L512@PLCC32 [(SA015A1T-B001)]	W39L512@TSOP32 [(SA620-B005)]
W39V040AP@PLCC32 [(SA015A1T)]	W39V040AQ@VSOP32
[(SA620)]	
W39V040B(P)@PLCC32 [(SA015A1T)]	W39V040B(Q)@VSOP32
[(SA620)]	

W39V040CP@PLCC32 [(SA015A1T)]	W39V040CPZ@PLCC32
[(SA015A1T)]	
W39V040CQ@VSOP32 [(SA620)]	W39V040CQZ@VSOP32
[(SA620)]	
W39V040FAP@PLCC32 [(SA015A1T)]	W39V040FAQ@VSOP32
[(SA620)]	
W39V040FAT@TSOP40 [(SA409T)]	W39V040FB(P)@PLCC32
[(SA015A1T)]	
W39V040FB(Q)@VSOP32 [(SA620)]	W39V040FCP@PLCC32
[(SA015A1T)]	
W39V040FCPZ@PLCC32 [(SA015A1T)]	W39V040FCQ@VSOP32
[(SA620)]	
W39V040FCQZ@VSOP32 [(SA620)]	W39V080A(P)@PLCC32
[(SA015A1T)]	
W39V080A(Q)@VSOP32 [(SA620)]	W39V080A(T)@TSOP40
[(SA409T)]	
W39V080FA(P)@PLCC32 [(SA015A1T)]	W39V080FA(Q)@VSOP32
[(SA620)]	
W39V080FA(T)@TSOP40 [(SA409T)]	W45B012@PLCC32
[(SA015A1T)]	
W45B012@SON8 [(SA683)]	W45B512@PLCC32
[(SA015A1T)]	
W45B512@SON8 [(SA683)]	
W49F002	
W49F002@PLCC32 [(SA015A1T-B001)]	W49F002@TSOP32 [(SA410T-
B003)]	
W49F002B	
W49F002B@PLCC32 [(SA015A1T-B001)]	
W49F002B@TSOP32 [(SA410T-B003)]	
W49F002N	
W49F002N@PLCC32 [(SA015A1T-B001)]	
W49F002N@TSOP32 [(SA410T-B003)]	
W49F002U	
W49F002U@PLCC32 [(SA015A1T-B001)]	
W49F002U@TSOP32 [(SA410T-B003)]	
W49F020	
W49F020@PLCC32 [(SA015A1T)]	W49F020@TSOP32
[(SA410T)]	
W49F102@PLCC44 [(SA244)]	W49F102@TSOP40
[(SA623)]	
W49F201@PSOP44 [(SA638)]	W49F201@TSOP48 [(SA247-
B005)]	
W49L102@PLCC44 [(SA244)]	W49L102@TSOP40

[(SA623)]	
W49L201@PSOP44 [(SA638)]	W49L201@TSOP48 [(SA247-
B005)]	
W49L401@PSOP44 [(SA638)]	W49L401@TSOP48 [(SA247-
B005)]	
W49L401T@PSOP44 [(SA638)]	W49L401T@TSOP48 [(SA247-
B005)]	
W49V002A@PLCC32 [(SA015A1T)]	W49V002A@VSOP32
[(SA620)]	
W49V002FA@PLCC32 [(SA015A1T)]	W49V002FA@VSOP32
[(SA620)]	
W49V002FP@PLCC32 [(SA015A1T)]	W49V002FP@VSOP32
[(SA620)]	
W49V002P@PLCC32 [(SA015A1T)]	W49V002P@VSOP32
[(SA620)]	
W55F05	
W55F10A	
W55F20	

MICROCONTROLLER

N79E342AKG	N79E342ASG@SOP16
[(SA404)]	
N79E342RAKG	N79E342RASG@SOP16
[(SA404)]	
N79E352AEG	N79E352AFG@TQFP44
[(SA245)]	
N79E352ALG@TQFP48 [(SA248)]	N79E352APG@PLCC44
[(SA244)]	
N79E8213AKG	N79E8213ASG@SOP20
[(SA404)]	
N79E8213RAKG	N79E8213RASG@SOP20
[(SA404)]	
W77E058	W77E058@PLCC44
[(SA244)]	
W77E058@TQFP44 [(SA245A)]	
W77E516	
W77E516@PLCC44 [(SA244)]	W77E516@TQFP44
[(SA245A)]	
W77E532	W77E532@PLCC44
[(SA244)]	
W77E532@TQFP44 [(SA245A)]	

W77E532A	
W77E532A@PLCC44 [(SA244)]	W77E532A@TQFP44
[(SA245A)]	
W77E58	W77E58@PLCC44
[(SA244)]	
W77E58@TQFP44 [(SA245A)]	
W77E58A	
W77E58A@PLCC44 [(SA244)]	W77E58A@TQFP44
[(SA245A)]	
W77IE58	W77IE58@PLCC44
[(SA244)]	
W77IE58@TQFP44 [(SA245A)]	
W77L058	
W77L058@PLCC44 [(SA244)]	W77L058@TQFP44
[(SA245A)]	
W77L516A	W77L516A@PLCC44
[(SA244)]	
W77L516A@TQFP44 [(SA245A)]	
W77L532A	
W77L532A@PLCC44 [(SA244)]	W77L532A@TQFP44
[(SA245A)]	
W77LE516	W77LE516@PLCC44
[(SA244)]	
W77LE516@TQFP44 [(SA245A)]	
W77LE532	
W77LE532@PLCC44 [(SA244)]	W77LE532@TQFP44
[(SA245A)]	
W77LE58	W77LE58@PLCC44
[(SA244)]	
W77LE58@TQFP44 [(SA245A)]	
W78E051B	
W78E051B@PLCC44 [(SA244)]	W78E051B@TQFP44
[(SA245A)]	
W78E051C	W78E051C@PLCC44
[(SA244)]	
W78E051C@TQFP44 [(SA245A)]	
W78E051DDG	
W78E051DFG@TQFP44 [(SA245A)]	
W78E051DLG@TQFP48 [(SA248A-B005)]	
W78E051DPG@PLCC44 [(SA244)]	
W78E052B	
W78E052B@PLCC44 [(SA244)]	W78E052B@TQFP44
[(SA245A)]	

W78E052C	W78E052C@PLCC44
[(SA244)]	
W78E052C@TQFP44 [(SA245A)]	
W78E052DDG	
W78E052DFG@TQFP44 [(SA245A)]	
W78E052DLG@TQFP48 [(SA248A-B005)]	
W78E052DPG@PLCC44 [(SA244)]	
W78E054B	
W78E054B@PLCC44 [(SA244)]	W78E054B@TQFP44
[(SA245A)]	
W78E054C	W78E054C@PLCC44
[(SA244)]	
W78E054C@TQFP44 [(SA245A)]	
W78E054DDG	
W78E054DFG@TQFP44 [(SA245A)]	
W78E054DLG@TQFP48 [(SA248A-B005)]	
W78E054DPG@PLCC44 [(SA244)]	
W78E058B	
W78E058B@PLCC44 [(SA244)]	W78E058B@TQFP44
[(SA245A)]	
W78E058DDG	W78E058DFG@TQFP44
[(SA245A)]	
W78E058DLG@TQFP48 [(SA248A-B005)]	
W78E058DPG@PLCC44 [(SA244)]	
W78E065	
W78E065@PLCC44 [(SA244)]	W78E065@TQFP44
[(SA245A)]	
W78E354(dip40)	
W78E365	
W78E365@PLCC44 [(SA244)]	W78E365@TQFP44
[(SA245A)]	
W78E374B	
W78E378	
W78E378E	W78E378P@PLCC44
[(SA244)]	
W78E51	W78E51@PLCC44
[(SA244)]	
W78E51@TQFP44 [(SA245A)]	
W78E516	
W78E516@PLCC44 [(SA244)]	W78E516@TQFP44
[(SA245A)]	
W78E516B	W78E516B@PLCC44
[(SA244)]	

W78E516B@TQFP44 [(SA245A)]	
W78E516DDG	
W78E516DFG@TQFP44 [(SA245A)]	
W78E516DLG@TQFP48 [(SA248A-B005)]	
W78E516DPG@PLCC44 [(SA244)]	
W78E51B	
W78E51B@PLCC44 [(SA244)]	W78E51B@TQFP44
[(SA245A)]	
W78E51C	W78E51C@PLCC44
[(SA244)]	
W78E51C@TQFP44 [(SA245A)]	
W78E52	
W78E52@PLCC44 [(SA244)]	W78E52@TQFP44
[(SA245A)]	
W78E52B	W78E52B@PLCC44
[(SA244)]	
W78E52B@TQFP44 [(SA245A)]	
W78E52C	
W78E52C@PLCC44 [(SA244)]	W78E52C@TQFP44
[(SA245A)]	
W78E54	W78E54@PLCC44
[(SA244)]	
W78E54@TQFP44 [(SA245A)]	
W78E54B	
W78E54B@PLCC44 [(SA244)]	W78E54B@TQFP44
[(SA245A)]	
W78E54C	W78E54C@PLCC44
[(SA244)]	
W78E54C@TQFP44 [(SA245A)]	
W78E58	
W78E58@PLCC44 [(SA244)]	W78E58@TQFP44
[(SA245A)]	
W78E58B	W78E58B@PLCC44
[(SA244)]	
W78E58B@TQFP44 [(SA245A)]	
W78E62B	
W78E62B@PLCC44 [(SA244)]	W78E62B@TQFP44
[(SA245A)]	
W78E65	W78E65@PLCC44
[(SA244)]	
W78E65@TQFP44 [(SA245A)]	
W78E858	
W78E858@PLCC44 [(SA244)]	W78E858@TQFP44

[(SA245A)]
W78ERD2 W78ERD2@PLCC44
[(SA244)]
W78ERD2@TQFP44 [(SA245A)]
W78I051DDG
W78I051DFG@TQFP44 [(SA245A)]
W78I051DLG@TQFP48 [(SA248A-B005)]
W78I051DPG@PLCC44 [(SA244)]
W78I052
W78I052@PLCC44 [(SA244)]
W78I052DDG
W78I052DFG@TQFP44 [(SA245A)]
W78I052DLG@TQFP48 [(SA248A-B005)]
W78I052DPG@PLCC44 [(SA244)]
W78I054
W78I054@PLCC44 [(SA244)]
W78I054DDG
W78I054DFG@TQFP44 [(SA245A)]
W78I054DLG@TQFP48 [(SA248A-B005)]
W78I054DPG@PLCC44 [(SA244)]
W78IE52
W78IE52@PLCC44 [(SA244)]
W78IE54
W78IE54@PLCC44 [(SA244)]
W78IRD2
W78IRD2@PLCC44 [(SA244)] W78IRD2@TQFP44
[(SA245A)]
W78L051 W78L051@PLCC44
[(SA244)]
W78L051@TQFP44 [(SA245A)]
W78L051C
W78L051C@PLCC44 [(SA244)] W78L051C@TQFP44
[(SA245A)]
W78L052 W78L052@PLCC44
[(SA244)]
W78L052@TQFP44 [(SA245A)]
W78L052C
W78L052C@PLCC44 [(SA244)] W78L052C@TQFP44
[(SA245A)]
W78L054 W78L054@PLCC44
[(SA244)]
W78L054@TQFP44 [(SA245A)]
W78L054C

W78L054C@PLCC44 [(SA244)]	W78L054C@TQFP44
[(SA245A)]	
W78L058	W78L058@PLCC44
[(SA244)]	
W78L058@TQFP44 [(SA245A)]	
W78L365	
W78L365@PLCC44 [(SA244)]	W78L365@TQFP44
[(SA245A)]	
W78L365@TQFP48 [(SA248A-B005)]	
W78L516	
W78L516@PLCC44 [(SA244)]	W78L516@TQFP44
[(SA245A)]	
W78L516A	W78L516A@PLCC44
[(SA244)]	
W78L516A@TQFP44 [(SA245A)]	
W78L812	
W78L812@PLCC44 [(SA244)]	W78L812@TQFP44
[(SA245A)]	
W78LE365	W78LE365@PLCC44
[(SA244)]	
W78LE365@TQFP44 [(SA245A)]	W78LE365@TQFP48 [(SA248A-
B005)]	
W78LE51	W78LE51@PLCC44
[(SA244)]	
W78LE51@TQFP44 [(SA245A)]	
W78LE516	
W78LE516@PLCC44 [(SA244)]	W78LE516@TQFP44
[(SA675)]	
W78LE51C	W78LE51C@PLCC44
[(SA244)]	
W78LE51C@TQFP44 [(SA245A)]	
W78LE52	
W78LE52@PLCC44 [(SA244)]	W78LE52@TQFP44
[(SA245A)]	
W78LE52C	W78LE52C@PLCC44
[(SA244)]	
W78LE52C@TQFP44 [(SA245A)]	
W78LE54	
W78LE54@PLCC44 [(SA244)]	W78LE54@TQFP44
[(SA245A)]	
W78LE54C	W78LE54C@PLCC44
[(SA244)]	
W78LE54C@TQFP44 [(SA245A)]	

W78LE58	
W78LE58@PLCC44 [(SA244)]	W78LE58@TQFP44
[(SA245A)]	
W78LE812	W78LE812@PLCC44
[(SA244)]	
W78LE812@TQFP44 [(SA245A)]	
W79E201	
W79E201@PLCC44 [(SA244)]	W79E201@TQFP44
[(SA245A)]	
W79E2051(dip14)	W79E2051
(dip16)	
W79E2051(dip20)	W79E2051@SOP20
[(SA404A)]	
W79E2051@SSOP14 [(SA626A)]	W79E2051@SSOP16
[(SA626A)]	
W79E2051@SSOP20 [(SA626A)]	W79E2051R
(dip20)	
W79E2051R@SOP20 [(SA404A)]	W79E225A@LQFP48
[(SA248)]	
W79E225A@PLCC44 [(SA244)]	W79E226A@LQFP48
[(SA248)]	
W79E226A@PLCC44 [(SA244)]	W79E227A@LQFP48
[(SA248)]	
W79E227A@PLCC44 [(SA244)]	W79E4051
(dip14)	
W79E4051(dip16)	W79E4051
(dip20)	
W79E4051@SOP20 [(SA404A)]	W79E4051@SSOP14
[(SA626A)]	
W79E4051@SSOP16 [(SA626A)]	W79E4051@SSOP20
[(SA626A)]	
W79E4051R(dip20)	W79E4051R@SOP20
[(SA404A)]	
W79E532	W79E532@PLCC44
[(SA244)]	
W79E532@TQFP44 [(SA245A)]	
W79E532A	
W79E532A@PLCC44 [(SA244)]	W79E532A@TQFP44
[(SA245A)]	
W79E632	W79E632@PLCC44
[(SA244)]	
W79E632@TQFP44 [(SA245A)]	W79E633@PLCC44
[(SA244)]	

W79E648A@PLCC68(*) [(SA648-B6809)]	
W79E649A@PLCC68(*) [(SA648-B6809)]	
W79E659A@PQFP100(*) [(SA741-B233)]	
W79E801A	W79E801A@SOIC20
[(SA404)]	
W79E802A	W79E802A@SOIC20
[(SA404)]	
W79E803A	W79E803A@SOIC20
[(SA404)]	
W79E804A	W79E804A@SOIC20
[(SA404)]	
W79E821A	W79E821A@SOIC20
[(SA404)]	
W79E822A	W79E822A@SOIC20
[(SA404)]	
W79E822B	W79E822B@SOIC20
[(SA404)]	
W79E823A	W79E823A@SOIC20
[(SA404)]	
W79E823B	W79E823B@SOIC20
[(SA404)]	
W79E824A	W79E824A@SOIC20
[(SA404)]	
W79E825A	W79E825A@SOIC20
[(SA404)]	
W79E831A	W79E831A@SOIC28
[(SA404)]	
W79E832A	W79E832A@SOIC28
[(SA404)]	
W79E833A	W79E833A@SOIC28
[(SA404)]	
W79E834A	W79E834A@SOIC28
[(SA404)]	
W79L532	W79L532@PLCC44
[(SA244)]	
W79L532@TQFP44 [(SA245A)]	
W79L632	
W79L632@PLCC44 [(SA244)]	W79L632@TQFP44
[(SA245A)]	
W79L633@PLCC44 [(SA244)]	
W79L648A@PLCC68(*) [(SA648-B6809)]	
W79L649A@PLCC68(*) [(SA648-B6809)]	
W79L659A@PQFP100(*) [(SA741-B233)]	

W925EP01@PQFP100(*) [(TA041-B006)]
W99100DG@TQFP48 [(SA248A-B005)]

WSI

E(E) PROM/FRAM/NVRAM

WS27C010L [(SA015A1T)]	WS27C010L@PLCC32
WS27C010L@TSOP32 [(SA410T)]	
WS27C010R WS27C010R@PLCC32 [(SA015A1T)] [(SA410T)]	WS27C010R@TSOP32
WS27C040L [(SA015A1T)]	WS27C040L@PLCC32
WS27C040L@TSOP32 [(SA410T)]	
WS27C128F WS27C128F@PLCC32 [(SA015A1T)]	
WS27C128L WS27C128L@PLCC32 [(SA015A1T)]	
WS27C210L WS27C210L@PLCC44 [(SA244)]	
WS27C256F WS27C256F@PLCC32 [(SA015A1T)]	
WS27C256L WS27C256L@PLCC32 [(SA015A1T)]	
WS27C512F WS27C512F@PLCC32 [(SA015A1T)]	
WS27C512L WS27C512L@PLCC32 [(SA015A1T)]	
WS27C64 WS27C64@PLCC32 [(SA015A1T)]	
WS27C64F WS27C64F@PLCC32 [(SA015A1T)]	
WS27C64L WS27C64L@PLCC32 [(SA015A1T)]	
WS57C128 WS57C128@PLCC32 [(SA015A1T)]	
WS57C128F WS57C128F@PLCC32 [(SA015A1T)]	
WS57C128FB WS57C128FB@PLCC32 [(SA015A1T)]	

WS57C191
WS57C191@PLCC28 [(SA008A)]
WS57C191B
WS57C191B@PLCC28 [(SA008A)]
WS57C191C
WS57C191C@PLCC28 [(SA008A)]
WS57C256F
WS57C256F@PLCC32 [(SA015A1T)]
WS57C256FB
WS57C256FB@PLCC32 [(SA015A1T)]
WS57C257
WS57C257@PLCC44 [(SA244)]
WS57C291
WS57C291@PLCC28 [(SA008A)]
WS57C291B
WS57C291B@PLCC28 [(SA008A)]
WS57C291C
WS57C291C@PLCC28 [(SA008A)]
WS57C43
WS57C43@PLCC28 [(SA008A)]
WS57C43B
WS57C43B@PLCC28 [(SA008A)]
WS57C43C
WS57C43C@PLCC28 [(SA008A)]
WS57C45
WS57C45@PLCC28 [(SA008A)]
WS57C49
WS57C49@PLCC28 [(SA008A)]
WS57C49B
WS57C49B@PLCC28 [(SA008A)]
WS57C49C
WS57C49C@PLCC28 [(SA008A)]
WS57C51
WS57C51@PLCC32 [(SA015A1T)]
WS57C51B
WS57C51B@PLCC32 [(SA015A1T)]
WS57C51C
WS57C51C@PLCC32 [(SA015A1T)]
WS57C64F
WS57C64F@PLCC32 [(SA015A1T)]
WS57C71C
WS57C71C@PLCC32 [(SA015A1T)]
WS57LV191C

WS57LV191C@PLCC28 [(SA008A)]
WS57LV291C
WS57LV291C@PLCC28 [(SA008A)]

XELTEK

MICROCONTROLLER

#####1111111111111111	
#####2222222222222222	
#####3333333333333333	
#####4444444444444444	
#####9999999999999999	ATMEGA168@TQFP32
[(SA636)]	
ATMEGA48@TQFP32 [(SA636)]	ATMEGA88@TQFP32
[(SA636)]	
ATMEGA8L(fast)@TQFP32 [(SA636)]	ATMEGA8L@TQFP32
[(SA636)]	

XICOR

E (E) PROM / FRAM / NVRAM

X2004	X2004@PLCC32
[(SA015A1T)]	
X2004D	X2004D@PLCC32
[(SA015A1T)]	
X2004I	X2004I@PLCC32
[(SA015A1T)]	
X2210	X2210@SOIC16
[(SA404)]	
X2210A	X2210A@SOIC16
[(SA404)]	
X2210I	X2210I@SOIC16
[(SA404)]	
X2212	X2212@SOIC20
[(SA404)]	
X2212A	X2212A@SOIC20
[(SA404)]	
X2212I	X2212I@SOIC20

[(SA404)] X22C10	X22C10@SOIC16
[(SA404)] X22C10I	X22C10I@SOIC16
[(SA404)] X22C12	X22C12@SOIC20
[(SA404)] X22C12I	X22C12I@SOIC20
[(SA404)] X24012	X24012@SOIC8
[(SA602A)] X24022	X24022@SOIC8
[(SA602A)] X24026	X24026@SOIC8
[(SA602A)] X24042	X24042@SOIC8
[(SA602A)] X24164	X24164@SOIC8
[(SA602A)] X24165	X24165@SOIC8
[(SA602A)] X24325	X24325@SOIC8
[(SA602A)] X24645	X24645@SOIC8
[(SA602A)] X24C01	X24C01@MSOP8
[(SA666)] X24C01@SOIC8 [(SA602A)]	
X24C01A	
X24C01A@SOIC8 [(SA602A)]	
X24C01I	
X24C01I@SOIC8 [(SA602A)]	
X24C02	
X24C02@SOIC8 [(SA602A)]	
X24C02I	
X24C02I@SOIC8 [(SA602A)]	
X24C04	
X24C04@SOIC14 [(SA602)]	X24C04@SOIC8
[(SA602A)] X24C04I	X24C04I@SOIC14
[(SA602)] X24C04I@SOIC8 [(SA602A)]	
X24C08	

X24C08@SOIC14 [(SA602)]	X24C08@SOIC8
[(SA602A)]	
X24C08I	X24C08I@SOIC14
[(SA602)]	
X24C08I@SOIC8 [(SA602A)]	
X24C16	X24C16@SOIC8
X24C16@SOIC14 [(SA602)]	
[(SA602A)]	
X24C16I	X24C16I@SOIC14
[(SA602)]	
X24C16I@SOIC8 [(SA602A)]	
X24C44	
X24C44@SOIC8 [(SA602A)]	
X24C44I	
X24C44I@SOIC8 [(SA602A)]	
X24C45	
X24C45@SOIC8 [(SA602A)]	
X24C45I	
X24C45I@SOIC8 [(SA602A)]	X24F008
(3V)	
X24F008(3V)@SOIC8 [(SA602A)]	X24F008(3V)@TSSOP14
[(SA602)]	
X24F008(5V)	X24F008(5V)@SOIC8
[(SA602A)]	
X24F008(5V)@TSSOP14 [(SA602)]	X24F016
(3V)	
X24F016(3V)@SOIC8 [(SA602A)]	X24F016(3V)@TSSOP14
[(SA602)]	
X24F016(5V)	X24F016(5V)@SOIC8
[(SA602A)]	
X24F016(5V)@TSSOP14 [(SA602)]	X24F032
(3V)	
X24F032(3V)@SOIC8 [(SA602A)]	X24F032(3V)@TSSOP14
[(SA602)]	
X24F032(5V)	X24F032(5V)@SOIC8
[(SA602A)]	
X24F032(5V)@TSSOP14 [(SA602)]	X24F064
(3V)	
X24F064(3V)@SOIC8 [(SA602A)]	X24F064(3V)@TSSOP20
[(SA404)]	
X24F064(5V)	X24F064(5V)@SOIC8
[(SA602A)]	
X24F064(5V)@TSSOP20 [(SA404)]	

X25020	
X25020@SOIC8 [(SA602A)]	
X25021	
X25021@SOIC8 [(SA602A)]	
X25040	
X25040@SOIC8 [(SA602A)]	
X25041	
X25041@SOIC8 [(SA602A)]	
X25043	
X25043@MSOP8 [(SA666)]	X25043@SOIC8
[(SA602A)]	
X25043@TSSOP14 [(SA026)]	
X25045	
X25045@MSOP8 [(SA666)]	X25045@SOIC8
[(SA602A)]	
X25045@TSSOP14 [(SA026)]	X25057@MSOP8
[(SA666)]	
X25057@TSSOP8 [(SA026)]	
X25080	
X25080@SOIC8 [(SA602A)]	X25080@TSSOP14
[(SA026)]	
X25097@MSOP8 [(SA666)]	X25097@SOIC8
[(SA602A)]	
X25097@TSSOP8 [(SA026)]	
X25128	
X25128@SOIC16 [(SA602)]	
X25138	
X25138@SOIC14 [(SA602)]	X25138@SOIC16
[(SA602)]	
X25138@SOIC8 [(SA602A)]	X25138@TSSOP8
[(SA026)]	
X25160	X25160@SOIC8
[(SA602A)]	
X25160@TSSOP14 [(SA026)]	
X25163	
X25163@SOIC8 [(SA602A)]	X25163@TSSOP14
[(SA026)]	
X25164	X25164@SOIC8
[(SA602A)]	
X25164@TSSOP14 [(SA026)]	
X25165	
X25165@SOIC8 [(SA602A)]	X25165@TSSOP14
[(SA026)]	

X25166	X25166@SOIC8
[(SA602A)]	
X25166@TSSOP14 [(SA026)]	
X25168	
X25168@SOIC8 [(SA602A)]	X25168@TSSOP14
[(SA026)]	
X25169	X25169@SOIC8
[(SA602A)]	
X25169@TSSOP14 [(SA026)]	
X25256	
X25256@SOIC8 [(SA602A)]	X25256@TSSOP20
[(SA026)]	
X25320	X25320@SOIC8
[(SA602A)]	
X25323@SOIC8 [(SA602A)]	X25323@TSSOP14
[(SA026)]	
X25324@SOIC8 [(SA602A)]	X25324@TSSOP14
[(SA026)]	
X25325@SOIC8 [(SA602A)]	X25325@TSSOP14
[(SA026)]	
X25326@SOIC8 [(SA602A)]	X25328@SOIC8
[(SA602A)]	
X25328@TSSOP14 [(SA026)]	X25329@SOIC8
[(SA602A)]	
X25329@TSSOP14 [(SA026)]	X25330@SOIC8
[(SA602A)]	
X25330@TSSOP14 [(SA026)]	
X25401	
X25401@SOIC8 [(SA602A)]	
X25640	
X25640@SOIC14 [(SA602)]	
X25642	
X25642@SOIC14 [(SA602)]	X25642@SOIC8
[(SA602A)]	
X25642@TSSOP20 [(SA026)]	X25643@SOIC14
[(SA602)]	
X25644@SOIC14 [(SA602)]	
X25645	
X25645@SOIC14 [(SA602)]	X25645@SOIC8
[(SA602A)]	
X25645@TSSOP20 [(SA026)]	X25648@SOIC14
[(SA602)]	
X25649@SOIC14 [(SA602)]	

X25650	X25650@SOIC8
X25650@SOIC14 [(SA602)]	
[(SA602A)]	
X25650@TSSOP20 [(SA026)]	
X25C02	X25C02@TSSOP8
X25C02@SOIC8 [(SA602A)]	
[(SA026)]	
X25F008(3V)	X25F008(3V)@SOIC8
[(SA602A)]	
X25F008(3V)@TSSOP14 [(SA602)]	X25F008(3V)@TSSOP20
[(SA404)]	
X25F008(5V)	X25F008(5V)@SOIC8
[(SA602A)]	
X25F008(5V)@TSSOP14 [(SA602)]	X25F008(5V)@TSSOP20
[(SA404)]	
X25F016(3V)	X25F016(3V)@SOIC8
[(SA602A)]	
X25F016(3V)@TSSOP14 [(SA602)]	X25F016(3V)@TSSOP20
[(SA404)]	
X25F016(5V)	X25F016(5V)@SOIC8
[(SA602A)]	
X25F016(5V)@TSSOP14 [(SA602)]	X25F016(5V)@TSSOP20
[(SA404)]	
X25F032(3V)	X25F032(3V)@SOIC8
[(SA602A)]	
X25F032(3V)@TSSOP14 [(SA602)]	X25F032(3V)@TSSOP20
[(SA404)]	
X25F032(5V)	X25F032(5V)@SOIC8
[(SA602A)]	
X25F032(5V)@TSSOP14 [(SA602)]	X25F032(5V)@TSSOP20
[(SA404)]	
X25F047(3V)	X25F047(3V)@MSOP8
[(SA666)]	
X25F047(3V)@SOIC8 [(SA602A)]	X25F047(3V)@TSSOP8
[(SA026)]	
X25F047(5V)	X25F047(5V)@MSOP8
[(SA666)]	
X25F047(5V)@SOIC8 [(SA602A)]	X25F047(5V)@TSSOP8
[(SA026)]	
X25F064(3V)	X25F064(3V)@SOIC8
[(SA602A)]	
X25F064(3V)@TSSOP14 [(SA602)]	X25F064(3V)@TSSOP20
[(SA404)]	

X25F064(5V) [(SA602A)]	X25F064(5V)@SOIC8
X25F064(5V)@TSSOP14 [(SA602)] [(SA404)]	X25F064(5V)@TSSOP20
X25F087(3V) [(SA666)]	X25F087(3V)@MSOP8
X25F087(3V)@SOIC8 [(SA602A)] [(SA026)]	X25F087(3V)@TSSOP8
X25F087(5V) [(SA666)]	X25F087(5V)@MSOP8
X25F087(5V)@SOIC8 [(SA602A)] [(SA026)]	X25F087(5V)@TSSOP8
X25F128(3V) [(SA602)]	X25F128(3V)@SOIC16
X25F128(5V) [(SA602)]	X25F128(5V)@SOIC16
X28010 [(SA015A1T)]	X28010@PLCC32
X28010@TSOP32 [(SA410T)]	
X2804A X2804A(I) (MB)	X2804A
X2816A [(SA015A1T)]	X2816A@PLCC32
X2816B [(SA015A1T)]	X2816B@PLCC32
X2816BI [(SA015A1T)]	X2816BI@PLCC32
X2816BMB X2816C X2816C@PLCC32 [(SA015A1T)]	
X28256 X28256@PLCC32 [(SA015A1T)]	
X28256I X28256I@PLCC32 [(SA015A1T)]	
X2864A X2864A(I) [(SA015A1T)]	X2864A(I)@PLCC32
X2864A(M) [(SA015A1T)]	X2864A(M)@PLCC32
X2864A(MB) [(SA015A1T)]	X2864A(MB)@PLCC32
X2864A(T)	X2864A(T)@PLCC32

[(SA015A1T)]	
X2864A@PLCC32 [(SA015A1T)]	
X2864B	
X2864B(I)	X2864B(I)@PLCC32
[(SA015A1T)]	
X2864B(M)	X2864B(M)@PLCC32
[(SA015A1T)]	
X2864B@PLCC32 [(SA015A1T)]	
X2864H	
X2864H(I)	X2864H(I)@PLCC32
[(SA015A1T)]	
X2864H@PLCC32 [(SA015A1T)]	
X28C010	
X28C010@PLCC32 [(SA015A1T)]	
X28C16A	
X28C16A@PLCC32 [(SA015A1T)]	
X28C16B	
X28C16B@PLCC32 [(SA015A1T)]	
X28C16C	
X28C16C@PLCC32 [(SA015A1T)]	
X28C256	
X28C256@PLCC32 [(SA015A1T)]	X28C256@TSOP28
[(SA430T)]	
X28C512	X28C512@PLCC32
[(SA015A1T)]	
X28C513	X28C513@PLCC32
[(SA015A1T)]	
X28C64	X28C64@PLCC32
[(SA015A1T)]	
X28C64@SOIC28 [(SA404)]	X28C64@TSOP28
[(SA430T)]	
X28HC16	X28HC16@PLCC32
[(SA015A1T)]	
X28HC16@SOIC24 [(SA404)]	
X28HC256	
X28HC256@PLCC32 [(SA015A1T)]	X28HC256@TSOP28
[(SA430T)]	
X28HC64	X28HC64@PLCC32
[(SA015A1T)]	
X28HC64@SOIC28 [(SA404)]	X28HC64@TSOP28
[(SA430T)]	
X28LC512	X28LC512@PLCC32
[(SA015A1T)]	

X28LC513 [(SA015A1T)]	X28LC513@PLCC32
X28VC256 [(SA015A1T)]	X28VC256@PLCC32
X28VC256@TSOP28 [(SA430T)] [(SA404)]	X40231@SOIC16
X40233@SOIC16 [(SA404)] [(SA404)]	X40235@SOIC16
X40237@SOIC16 [(SA404)] [(SA404)]	X40239@SOIC16
X40430@SOIC14 [(SA404)] [(SA026)]	X40430@TSSOP14
X40431@SOIC14 [(SA404)] [(SA026)]	X40431@TSSOP14
X40434@SOIC14 [(SA404)] [(SA026)]	X40434@TSSOP14
X40435@SOIC14 [(SA404)] [(SA026)]	X40435@TSSOP14
X4C105@TSSOP20 [(SA026)]	
X5043 X5043@MSOP8 [(SA666)] [(SA602A)]	X5043@SOIC8
X5043@TSSOP14 [(SA026)]	
X5045 X5045@MSOP8 [(SA666)] [(SA602A)]	X5045@SOIC8
X5045@TSSOP14 [(SA026)]	
X5083 X5083@SOIC8 [(SA602A)] [(SA026)]	X5083@TSSOP8
X5163 [(SA602A)]	X5163@SOIC8
X5163@TSSOP14 [(SA026)]	
X51638 X51638@SOIC8 [(SA602A)] [(SA026)]	X51638@TSSOP14
X5165 [(SA602A)]	X5165@SOIC8
X5165@TSSOP14 [(SA026)]	
X5168 X5168@SOIC8 [(SA602A)] [(SA026)]	X5168@TSSOP14
X5169	X5169@SOIC8

[(SA602A)]	
X5169@TSSOP14 [(SA026)]	
X5323	
X5323@SOIC8 [(SA602A)]	X5323@TSSOP14
[(SA026)]	
X5325	
X5325@SOIC8	X5325@SOIC8
[(SA602A)]	
X5325@TSSOP14 [(SA026)]	
X5328	
X5328@SOIC8 [(SA602A)]	X5328@TSSOP14
[(SA026)]	
X5329	
X5329@SOIC8	X5329@SOIC8
[(SA602A)]	
X5329@TSSOP14 [(SA026)]	
X5643	
X5643@SOIC14 [(SA602)]	X5643@SOIC8
[(SA602A)]	
X5643@TSSOP20 [(SA026)]	
X5645	
X5645@SOIC14 [(SA602)]	X5645@SOIC8
[(SA602A)]	
X5645@TSSOP20 [(SA026)]	
X5648	
X5648@SOIC14 [(SA602)]	
X5649	
X5649@SOIC14 [(SA602)]	
X76F041	
X76F041(3)	X76F041(3)@SOIC8
[(SA605)]	
X76F041@SOIC8 [(SA605)]	
X76F101	
X76F101@SOIC8 [(SA602A)]	X76F400@SOIC8
[(SA602A)]	
X76F400@TSSOP8 [(SA026)]	
XD2210	
XD2210@SOIC16 [(SA404)]	
XM28C010	
XM28C020	
XM28C040	

XILINX

E (E) PROM / FRAM / NVRAM

XC1701 [(SA001A)]	XC1701@PLCC20
XC1701@SOIC20 [(SA404)]	
XC1701L	
XC1701L@PLCC20 [(SA001A)]	XC1701L@PLCC44
[(SA244)]	
XC1701L@SOIC20 [(SA404)]	XC1702L@PLCC44
[(SA244)]	
XC1702L@TQFP44 [(SA245A)]	XC1704L@PLCC44
[(SA244)]	
XC1704L@TQFP44 [(SA245A)]	
XC17128	
XC17128@SOIC8 [(SA602A)]	
XC17128D	
XC17128D@PLCC20 [(SA001A)]	XC17128D@SOIC8
[(SA602A)]	
XC17128D@VOIC8 [(SA602A)]	
XC17128E	
XC17128E@PLCC20 [(SA001A)]	XC17128E@VOIC8
[(SA602A)]	
XC17128EL	XC17128EL@PLCC20
[(SA001A)]	
XC17128EL@VOIC8 [(SA602A)]	
XC17128L	
XC17128L@PLCC20 [(SA001A)]	XC17128L@SOIC8
[(SA602A)]	
XC17128L@VOIC8 [(SA602A)]	
XC17128X	
XC17128X@PLCC20 [(SA001A)]	XC17128X@SOIC8
[(SA602A)]	
XC17128X@VOIC8 [(SA602A)]	
XC1718D	
XC1718D@PLCC20 [(SA001A)]	XC1718D@SOIC8
[(SA602A)]	
XC1718D@VOIC8 [(SA602A)]	
XC1718L	
XC1718L@PLCC20 [(SA001A)]	XC1718L@SOIC8
[(SA602A)]	
XC1718L@VOIC8 [(SA602A)]	
XC17256D	
XC17256D@PLCC20 [(SA001A)]	XC17256D@SOIC8

[(SA602A)]	
XC17256D@VOIC8 [(SA602A)]	
XC17256E	
XC17256E@PLCC20 [(SA001A)]	XC17256E@VOIC8
[(SA602A)]	
XC17256EL	
[(SA001A)]	
XC17256EL@VOIC8 [(SA602A)]	XC17256EL@PLCC20
XC17256L	
XC17256L@PLCC20 [(SA001A)]	XC17256L@SOIC8
[(SA602A)]	
XC17256L@VOIC8 [(SA602A)]	
XC17256X	
XC17256X@PLCC20 [(SA001A)]	XC17256X@SOIC8
[(SA602A)]	
XC17256X@VOIC8 [(SA602A)]	
XC1736	
XC1736@SOIC8 [(SA602A)]	
XC1736A	
XC1736A@SOIC8 [(SA602A)]	
XC1736D	
XC1736D@PLCC20 [(SA001A)]	XC1736D@SOIC8
[(SA602A)]	
XC1736D@VOIC8 [(SA602A)]	
XC1736E	
XC1736E@PLCC20 [(SA001A)]	XC1736E@SOIC8
[(SA602A)]	
XC1736E@VOIC8 [(SA602A)]	
XC17512L	
XC17512L@PLCC20 [(SA001A)]	XC17512L@PLCC44
[(SA244)]	
XC17512L@SOIC20 [(SA404)]	
XC1765	
XC1765@SOIC8 [(SA602A)]	
XC1765D	
XC1765D@PLCC20 [(SA001A)]	XC1765D@SOIC8
[(SA602A)]	
XC1765D@VOIC8 [(SA602A)]	
XC1765E	
XC1765E@PLCC20 [(SA001A)]	XC1765E@SOIC8
[(SA602A)]	
XC1765E@VOIC8 [(SA602A)]	
XC1765EL	

XC1765EL@PLCC20 [(SA001A)]	XC1765EL@SOIC8
[(SA602A)]	
XC1765EL@VOIC8 [(SA602A)]	
XC1765L	
XC1765L@PLCC20 [(SA001A)]	XC1765L@SOIC8
[(SA602A)]	
XC1765L@VOIC8 [(SA602A)]	
XC1765X	
XC1765X@PLCC20 [(SA001A)]	XC1765X@SOIC8
[(SA602A)]	
XC1765X@VOIC8 [(SA602A)]	
XC17S05	
XC17S05@SOIC8 [(SA602A)]	XC17S05XL
(L)	
XC17S05XL(L)@SOIC8 [(SA602A)]	
XC17S10	
XC17S10@SOIC8 [(SA602A)]	
XC17S100A	
XC17S100A@SOIC20 [(SA404)]	XC17S100A@SOIC8
[(SA602A)]	
XC17S100XL(L)	XC17S100XL(L)@SOIC20
[(SA404)]	
XC17S10XL(L)	XC17S10XL(L)@SOIC8
[(SA602A)]	
XC17S150A	XC17S150A@SOIC20
[(SA404)]	
XC17S150A@SOIC8 [(SA602A)]	XC17S150XL
(L)	
XC17S150XL(L)@SOIC20 [(SA404)]	
XC17S15A	
XC17S15A@SOIC20 [(SA404)]	XC17S15A@SOIC8
[(SA602A)]	
XC17S20	XC17S20@SOIC8
[(SA602A)]	
XC17S200A	XC17S200A@SOIC8
[(SA602A)]	
XC17S200A@TQFP44 [(SA245A)]	XC17S20XL
(L)	
XC17S20XL(L)@SOIC8 [(SA602A)]	
XC17S30	
XC17S30@SOIC8 [(SA602A)]	XC17S300A@TQFP44
[(SA245A)]	
XC17S30A	XC17S30A@SOIC20

[(SA404)]	
XC17S30A@SOIC8 [(SA602A)]	XC17S30XL
(L)	
XC17S30XL(L)@SOIC8 [(SA602A)]	
XC17S40	
XC17S40@SOIC20 [(SA404)]	XC17S40XL
(L)	
XC17S40XL(L)@SOIC20 [(SA404)]	
XC17S50A	
XC17S50A@SOIC20 [(SA404)]	XC17S50A@SOIC8
[(SA602A)]	
XC17S50XL(L)	XC17S50XL(L)@SOIC20
[(SA404)]	
XC17V01@PLCC20 [(SA001A)]	XC17V01@SOIC20
[(SA404)]	
XC17V01@SOIC8 [(SA602A)]	XC17V02@PLCC20
[(SA001A)]	
XC17V02@PLCC44 [(SA244)]	XC17V02@TQFP44
[(SA245A)]	
XC17V04@PLCC20 [(SA001A)]	XC17V04@PLCC44
[(SA244)]	
XC17V04@TQFP44 [(SA245A)]	XC17V08@PLCC44
[(SA244)]	
XC17V08@TQFP44 [(SA245A)]	XC17V16@PLCC44
[(SA244)]	
XC17V16@TQFP44 [(SA245A)]	

XILINX-CUSTOMER

E (E) PROM / FRAM / NVRAM

XC17S100A	XC17S100A@SOIC20
[(SA404)]	
XC17S100A@SOIC8 [(SA602A)]	
XC17S150A	
XC17S150A@SOIC20 [(SA404)]	XC17S150A@SOIC8
[(SA602A)]	
XC17S15A	XC17S15A@SOIC20
[(SA404)]	
XC17S15A@SOIC8 [(SA602A)]	
XC17S200A	
XC17S200A@SOIC8 [(SA602A)]	XC17S200A@TQFP44

[(SA245A)]	
XC17S300A@TQFP44 [(SA245A)]	
XC17S30A	
XC17S30A@SOIC20 [(SA404)]	XC17S30A@SOIC8
[(SA602A)]	
XC17S50A	
[(SA404)]	
XC17S50A@SOIC8 [(SA602A)]	XC17S50A@SOIC20
[(SA001A)]	
XC17V01@SOIC20 [(SA404)]	XC17V01@SOIC8
[(SA602A)]	
XC17V02@PLCC20 [(SA001A)]	XC17V02@PLCC44
[(SA244)]	
XC17V02@TQFP44 [(SA245A)]	XC17V04@PLCC20
[(SA001A)]	
XC17V04@PLCC44 [(SA244)]	XC17V04@TQFP44
[(SA245A)]	
XC17V08@PLCC44 [(SA244)]	XC17V08@TQFP44
[(SA245A)]	
XC17V16@PLCC44 [(SA244)]	XC17V16@TQFP44
[(SA245A)]	

YMC

E (E) PROM / FRAM / NVRAM

Y24LC01	Y24LC01@SOIC8
[(SA602A)]	
Y24LC01@TSSOP8 [(SA026)]	
Y24LC02	
Y24LC02@SOIC8 [(SA602A)]	Y24LC02@TSSOP8
[(SA026)]	
Y24LC02A	Y24LC02A@SOIC8
[(SA602A)]	
Y24LC02A@TSSOP8 [(SA026)]	
Y24LC04	
Y24LC04@SOIC8 [(SA602A)]	Y24LC04@TSSOP8
[(SA026)]	
Y24LC08	Y24LC08@SOIC8
[(SA602A)]	
Y24LC08@TSSOP8 [(SA026)]	
Y24LC16	

Y24LC16@SOIC8 [(SA602A)]	Y24LC16@TSSOP8
[(SA026)]	
Y24LC32	Y24LC32@SOIC8
[(SA602A)]	
Y24LC32@TSSOP8 [(SA026)]	
Y24LC64	
Y24LC64@SOIC8 [(SA602A)]	Y24LC64@TSSOP8
[(SA026)]	
Y54LC64	Y54LC64@SOIC8
[(SA602A)]	
Y54LC64@TSSOP8 [(SA026)]	Y93LC46
(08bit)	
Y93LC46(08bit)@SOIC8 [(SA602A)]	Y93LC46(08bit)@TSSOP8
[(SA026)]	
Y93LC46(16bit)	Y93LC46(16bit)@SOIC8
[(SA602A)]	
Y93LC46(16bit)@TSSOP8 [(SA026)]	Y93LC66
(08bit)	
Y93LC66(08bit)@SOIC8 [(SA602A)]	Y93LC66(08bit)@TSSOP8
[(SA026)]	
Y93LC66(16bit)	Y93LC66(16bit)@SOIC8
[(SA602A)]	
Y93LC66(16bit)@TSSOP8 [(SA026)]	Y93LC86
(08bit)	
Y93LC86(08bit)@SOIC8 [(SA602A)]	Y93LC86(08bit)@TSSOP8
[(SA026)]	
Y93LC86(16bit)	Y93LC86(16bit)@SOIC8
[(SA602A)]	
Y93LC86(16bit)@TSSOP8 [(SA026)]	

YSS

E (E) PROM/FRAM/NVRAM

Y25F05@SOP8 [(SA602A)]	Y25F05@VQFN8
[(SA683)]	
Y25F10@SOP8 [(SA602A)]	Y25F10@VQFN8
[(SA683)]	

ZILOG

MICROCONTROLLER

Z86733	Z86733@PLCC28
[(SA008A)]	
Z86733@SOIC28 [(SA404)]	
Z86743	
Z86743@PLCC44 [(SA244)]	
Z86C0208PEC	
Z86C0208PSC	Z86C0208SEC@SOIC18
[(SA404)]	
Z86C0208SSC@SOIC18 [(SA404)]	
Z86E02	
Z86E02@SOIC18 [(SA404)]	
Z86E03	
Z86E03@SOIC18 [(SA404)]	
Z86E04	
Z86E04@SOIC18 [(SA404)]	
Z86E0412PEC	
Z86E0412PEC1903	
Z86E0412PSC1866	
Z86E0412PSC1903	Z86E0412SEC
[(SA404)]	
Z86E0412SEC1903 [(SA404)]	Z86E0412SSC1866
[(SA404)]	
Z86E0412SSC1903 [(SA404)]	
Z86E06	
Z86E06@SOIC18 [(SA404)]	
Z86E07	
Z86E07@SOIC18 [(SA404)]	
Z86E08	
Z86E08@SOIC18 [(SA404)]	
Z86E0812PEC	
Z86E0812PEC1903	
Z86E0812PSC1866	
Z86E0812PSC1903	Z86E0812SEC
[(SA404)]	
Z86E0812SEC1903 [(SA404)]	Z86E0812SSC1866
[(SA404)]	
Z86E0812SSC1903 [(SA404)]	
Z86E122	
Z86E122@SOIC20 [(SA404)]	
Z86E123	
Z86E123@SOIC20 [(SA404)]	

Z86E124
Z86E124@SOIC20 [(SA404)]
Z86E125
Z86E125@SOIC20 [(SA404)]
Z86E126
Z86E126@SOIC20 [(SA404)]
Z86E132
Z86E132@SOIC28 [(SA404)]
Z86E133
Z86E133@SOIC28 [(SA404)]
Z86E134
Z86E134@SOIC28 [(SA404)]
Z86E135
Z86E135@SOIC28 [(SA404)]
Z86E136
Z86E136@SOIC28 [(SA404)]
Z86E142
Z86E142@TQFP44 [(SA245A)]
Z86E143
Z86E143@TQFP44 [(SA245A)]
Z86E144
Z86E144@TQFP44 [(SA245A)]
Z86E145
Z86E145@TQFP44 [(SA245A)]
Z86E146
Z86E146@TQFP44 [(SA245A)]
Z86E15
Z86E21 Z86E21@PLCC44
[(SA244)]
Z86E21@TQFP44 [(SA245A)]
Z86E2112
Z86E2112@PLCC44 [(SA244)] Z86E2112@TQFP44
[(SA245A)]
Z86E2116 Z86E2116@PLCC44
[(SA244)]
Z86E2116@TQFP44 [(SA245A)]
Z86E23
Z86E23@PLCC44 [(SA244)] Z86E23@TQFP44
[(SA245A)]
Z86E2312 Z86E2312@PLCC44
[(SA244)]
Z86E2312@TQFP44 [(SA245A)]
Z86E2316

Z86E2316@PLCC44 [(SA244)]	Z86E2316@TQFP44
[(SA245A)]	
Z86E3016PEC	
Z86E3016PSC	
Z86E3016SEC@SOIC28 [(SA404)]	Z86E3016SSC@SOIC28
[(SA404)]	
Z86E3016VEC@PLCC28 [(SA008A)]	Z86E3016VSC@PLCC28
[(SA008A)]	
Z86E3016VSG@PLCC28 [(SA008A)]	
Z86E3116PEC	
Z86E3116PSC	Z86E3116SEC@SOIC28
[(SA404)]	
Z86E3116SSC@SOIC28 [(SA404)]	Z86E3116VEC@PLCC28
[(SA008A)]	
Z86E3116VSC@PLCC28 [(SA008A)]	Z86E3116VSG@PLCC28
[(SA008A)]	
Z86E33	Z86E33@PLCC28
[(SA008A)]	
Z86E33@SOIC28 [(SA404)]	
Z86E34	
Z86E34@PLCC28 [(SA008A)]	Z86E34@SOIC28
[(SA404)]	
Z86E4016FEC@TQFP44 [(SA245A)]	Z86E4016FSC@TQFP44
[(SA245A)]	
Z86E4016PEC	
Z86E4016PSC	
Z86E4016VEC@PLCC44 [(SA244)]	Z86E4016VSC@PLCC44
[(SA244)]	
Z86E4016VSG@PLCC44 [(SA244)]	
Z86E43	
Z86E43@PLCC44 [(SA244)]	Z86E43@TQFP44
[(SA245A)]	
Z86E44	Z86E44@PLCC44
[(SA244)]	
Z86E44@TQFP44 [(SA245A)]	Z86E6116ASG@TQFP44
[(SA245A)]	
Z86E6116PSC	Z86E6116VSC@PLCC44
[(SA244)]	
Z86E6120ASG@TQFP44 [(SA245A)]	
Z86E6120PSC	
Z86E6120VSC@PLCC44 [(SA244)]	Z86E61FSC@TQFP44
[(SA245A)]	
Z86E61PSC	Z86E61VSC@PLCC44

[(SA244)]	
Z86E6316ASG@TQFP44 [(SA245A)]	
Z86E6316PSC	
Z86E6316VSC@PLCC44 [(SA244)]	Z86E6320ASG@TQFP44
[(SA245A)]	
Z86E6320PSC	Z86E6320VSC@PLCC44
[(SA244)]	
Z86E63FSC@TQFP44 [(SA245A)]	
Z86E63PSC	
Z86E63VSC@PLCC44 [(SA244)]	
Z86E72	
Z86E72@PLCC44 [(SA244)]	Z86E72@TQFP44
[(SA245A)]	
Z86E73	Z86E73@PLCC44
[(SA244)]	
Z86E73@TQFP44 [(SA245A)]	
Z86E83	
Z86E83@PLCC28 [(SA008A)]	Z86E83@SOIC28
[(SA404)]	
Z86L0208PEC	
Z86L0208PSC	
Z86L0208SEC@SOIC18 [(SA404)]	Z86L0208SSC@SOIC18
[(SA404)]	
Z89371	Z89371@PLCC44
[(SA244)]	
Z89371@TQFP44 [(SA245A)]	
Z89371B	
Z89371B@PLCC44 [(SA244)]	Z89371B@TQFP44
[(SA245A)]	
Z8F0113PB005EC	
Z8F0113PB005EG	
Z8F0113PB005SC	
Z8F0113PB005SG	
Z8F0113QB005EC@QFN8 [(SA683)]	Z8F0113QB005EG@QFN8
[(SA683)]	
Z8F0113QB005SC@QFN8 [(SA683)]	Z8F0113QB005SG@QFN8
[(SA683)]	
Z8F0113SB005EC@SOIC8 [(SA602A)]	Z8F0113SB005EG@SOIC8
[(SA602A)]	
Z8F0113SB005SC@SOIC8 [(SA602A)]	Z8F0113SB005SG@SOIC8
[(SA602A)]	
Z8F011APB020EC	
Z8F011APB020EG	

Z8F011APB020SC	
Z8F011APB020SG	
Z8F011AQB020EC@QFN8 [(SA683)]	Z8F011AQB020EG@QFN8
[(SA683)]	
Z8F011AQB020SC@QFN8 [(SA683)]	Z8F011AQB020SG@QFN8
[(SA683)]	
Z8F011ASB020EC@SOIC8 [(SA602A)]	Z8F011ASB020EG@SOIC8
[(SA602A)]	
Z8F011ASB020SC@SOIC8 [(SA602A)]	Z8F011ASB020SG@SOIC8
[(SA602A)]	
Z8F0123PB005EC	
Z8F0123PB005EG	
Z8F0123PB005SC	
Z8F0123PB005SG	
Z8F0123QB005EC@QFN8 [(SA683)]	Z8F0123QB005EG@QFN8
[(SA683)]	
Z8F0123QB005SC@QFN8 [(SA683)]	Z8F0123QB005SG@QFN8
[(SA683)]	
Z8F0123SB005EC@SOIC8 [(SA602A)]	Z8F0123SB005EG@SOIC8
[(SA602A)]	
Z8F0123SB005SC@SOIC8 [(SA602A)]	Z8F0123SB005SG@SOIC8
[(SA602A)]	
Z8F012APB020EC	
Z8F012APB020EG	
Z8F012APB020SC	
Z8F012APB020SG	
Z8F012AQB020EC@QFN8 [(SA683)]	Z8F012AQB020EG@QFN8
[(SA683)]	
Z8F012AQB020SC@QFN8 [(SA683)]	Z8F012AQB020SG@QFN8
[(SA683)]	
Z8F012ASB020EC@SOIC8 [(SA602A)]	Z8F012ASB020EG@SOIC8
[(SA602A)]	
Z8F012ASB020SC@SOIC8 [(SA602A)]	Z8F012ASB020SG@SOIC8
[(SA602A)]	
Z8F0213PB005EC	
Z8F0213PB005EG	
Z8F0213PB005SC	
Z8F0213PB005SG	
Z8F0213QB005EC@QFN8 [(SA683)]	Z8F0213QB005EG@QFN8
[(SA683)]	
Z8F0213QB005SC@QFN8 [(SA683)]	Z8F0213QB005SG@QFN8
[(SA683)]	
Z8F0213SB005EC@SOIC8 [(SA602A)]	Z8F0213SB005EG@SOIC8

[(SA602A)]	
Z8F0213SB005SC@SOIC8 [(SA602A)]	Z8F0213SB005SG@SOIC8
[(SA602A)]	
Z8F021APB020EC	
Z8F021APB020EG	
Z8F021APB020SC	
Z8F021APB020SG	
Z8F021AQB020EC@QFN8 [(SA683)]	Z8F021AQB020EG@QFN8
[(SA683)]	
Z8F021AQB020SC@QFN8 [(SA683)]	Z8F021AQB020SG@QFN8
[(SA683)]	
Z8F021ASB020EC@SOIC8 [(SA602A)]	Z8F021ASB020EG@SOIC8
[(SA602A)]	
Z8F021ASB020SC@SOIC8 [(SA602A)]	Z8F021ASB020SG@SOIC8
[(SA602A)]	
Z8F0223PB005EC	
Z8F0223PB005EG	
Z8F0223PB005SC	
Z8F0223PB005SG	
Z8F0223QB005EC@QFN8 [(SA683)]	Z8F0223QB005EG@QFN8
[(SA683)]	
Z8F0223QB005SC@QFN8 [(SA683)]	Z8F0223QB005SG@QFN8
[(SA683)]	
Z8F0223SB005EC@SOIC8 [(SA602A)]	Z8F0223SB005EG@SOIC8
[(SA602A)]	
Z8F0223SB005SC@SOIC8 [(SA602A)]	Z8F0223SB005SG@SOIC8
[(SA602A)]	
Z8F022APB020EC	
Z8F022APB020EG	
Z8F022APB020SC	
Z8F022APB020SG	
Z8F022AQB020EC@QFN8 [(SA683)]	Z8F022AQB020EG@QFN8
[(SA683)]	
Z8F022AQB020SC@QFN8 [(SA683)]	Z8F022AQB020SG@QFN8
[(SA683)]	
Z8F022ASB020EC@SOIC8 [(SA602A)]	Z8F022ASB020EG@SOIC8
[(SA602A)]	
Z8F022ASB020SC@SOIC8 [(SA602A)]	Z8F022ASB020SG@SOIC8
[(SA602A)]	
Z8F0413PB005EC	
Z8F0413PB005EG	
Z8F0413PB005SC	
Z8F0413PB005SG	

Z8F0413QB005EC@QFN8 [(SA683)]	Z8F0413QB005EG@QFN8
[(SA683)]	
Z8F0413QB005SC@QFN8 [(SA683)]	Z8F0413QB005SG@QFN8
[(SA683)]	
Z8F0413SB005EC@SOIC8 [(SA602A)]	Z8F0413SB005EG@SOIC8
[(SA602A)]	
Z8F0413SB005SC@SOIC8 [(SA602A)]	Z8F0413SB005SG@SOIC8
[(SA602A)]	
Z8F041APB020EC	
Z8F041APB020EG	
Z8F041APB020SC	
Z8F041APB020SG	
Z8F041AQB020EC@QFN8 [(SA683)]	Z8F041AQB020EG@QFN8
[(SA683)]	
Z8F041AQB020SC@QFN8 [(SA683)]	Z8F041AQB020SG@QFN8
[(SA683)]	
Z8F041ASB020EC@SOIC8 [(SA602A)]	Z8F041ASB020EG@SOIC8
[(SA602A)]	
Z8F041ASB020SC@SOIC8 [(SA602A)]	Z8F041ASB020SG@SOIC8
[(SA602A)]	
Z8F0423PB005EC	
Z8F0423PB005EG	
Z8F0423PB005SC	
Z8F0423PB005SG	
Z8F0423QB005EC@QFN8 [(SA683)]	Z8F0423QB005EG@QFN8
[(SA683)]	
Z8F0423QB005SC@QFN8 [(SA683)]	Z8F0423QB005SG@QFN8
[(SA683)]	
Z8F0423SB005EC@SOIC8 [(SA602A)]	Z8F0423SB005EG@SOIC8
[(SA602A)]	
Z8F0423SB005SC@SOIC8 [(SA602A)]	Z8F0423SB005SG@SOIC8
[(SA602A)]	
Z8F042APB020EC	
Z8F042APB020EG	
Z8F042APB020SC	
Z8F042APB020SG	
Z8F042AQB020EC@QFN8 [(SA683)]	Z8F042AQB020EG@QFN8
[(SA683)]	
Z8F042AQB020SC@QFN8 [(SA683)]	Z8F042AQB020SG@QFN8
[(SA683)]	
Z8F042ASB020EC@SOIC8 [(SA602A)]	Z8F042ASB020EG@SOIC8
[(SA602A)]	
Z8F042ASB020SC@SOIC8 [(SA602A)]	Z8F042ASB020SG@SOIC8

[(SA602A)]	
Z8F0813PB005EC	
Z8F0813PB005EG	
Z8F0813PB005SC	
Z8F0813PB005SG	
Z8F0813QB005EC@QFN8 [(SA683)]	Z8F0813QB005EG@QFN8
[(SA683)]	
Z8F0813QB005SC@QFN8 [(SA683)]	Z8F0813QB005SG@QFN8
[(SA683)]	
Z8F0813SB005EC@SOIC8 [(SA602A)]	Z8F0813SB005EG@SOIC8
[(SA602A)]	
Z8F0813SB005SC@SOIC8 [(SA602A)]	Z8F0813SB005SG@SOIC8
[(SA602A)]	
Z8F081APB020EC	
Z8F081APB020EG	
Z8F081APB020SC	
Z8F081APB020SG	
Z8F081AQB020EC@QFN8 [(SA683)]	Z8F081AQB020EG@QFN8
[(SA683)]	
Z8F081AQB020SC@QFN8 [(SA683)]	Z8F081AQB020SG@QFN8
[(SA683)]	
Z8F081ASB020EC@SOIC8 [(SA602A)]	Z8F081ASB020EG@SOIC8
[(SA602A)]	
Z8F081ASB020SC@SOIC8 [(SA602A)]	Z8F081ASB020SG@SOIC8
[(SA602A)]	
Z8F0823PB005EC	
Z8F0823PB005EG	
Z8F0823PB005SC	
Z8F0823PB005SG	
Z8F0823QB005EC@QFN8 [(SA683)]	Z8F0823QB005EG@QFN8
[(SA683)]	
Z8F0823QB005SC@QFN8 [(SA683)]	Z8F0823QB005SG@QFN8
[(SA683)]	
Z8F0823SB005EC@SOIC8 [(SA602A)]	Z8F0823SB005EG@SOIC8
[(SA602A)]	
Z8F0823SB005SC@SOIC8 [(SA602A)]	Z8F0823SB005SG@SOIC8
[(SA602A)]	
Z8F082APB020EC	
Z8F082APB020EG	
Z8F082APB020SC	
Z8F082APB020SG	
Z8F082AQB020EC@QFN8 [(SA683)]	Z8F082AQB020EG@QFN8
[(SA683)]	

Z8F082AQB020SC@QFN8 [(SA683)]
[(SA683)]
Z8F082ASB020EC@SOIC8 [(SA602A)]
[(SA602A)]
Z8F082ASB020SC@SOIC8 [(SA602A)]
[(SA602A)]

Z8F082AQB020SG@QFN8

Z8F082ASB020EG@SOIC8

Z8F082ASB020SG@SOIC8

ZMD

E(E) PROM/FRAM/NVRAM

U62256
U6264
U6264@SOIC28 [(SA630)]
U6264A
U6264A@SOIC28 [(SA630)]
[(SA630)]
U62H256S@SOIC28 [(SA630)]
[(SA630)]
U630H16
[(SA630)]
U630H64
[(SA630)]
U631H16
[(SA404)]
U631H16@SOIC28 [(SA630)]
U631H256
U631H256@SOIC28 [(SA630)]
U631H64
U631H64@SOIC28 [(SA630)]
U632H16
U632H16@SOIC28 [(SA630)]
U632H64
U632H64@SOIC28 [(SA630)]
U634H256
U634H256@SOIC32 [(SA630)]
U635H16
U635H16@SOIC24 [(SA404)]
U635H256
U635H256@SOIC28 [(SA630)]
U635H64
U635H64@SOIC28 [(SA630)]

U62H256A@SOIC28

U62H64SA@SOIC28

U630H16@SOIC28

U630H64@SOIC28

U631H16@SOIC24

U63716

U637256

U63764

U637H256

UL62H256A@SOIC28

[(SA630)]

UL631H256@SOIC28 [(SA630)]

UL631H256@TSOP32

[(SA410T)]

UL634H256@SOIC32 [(SA630)]

UL634H256@TSOP32

[(SA410T)]

UL635H256@SOIC28 [(SA630)]

UL635H256@TSOP32

[(SA410T)]