

## DEVICE LIST 5/18/2009

Total Manufacturers 186

Total Devices 34577

<a href="#">ACT</a>	<a href="#">ACTRANS</a>	<a href="#">ADVANCE GROUP</a>	<a href="#">ALI</a>
<a href="#">(Acer)</a>			
<a href="#">ALL 24 SERIES(ISP)</a>		<a href="#">ALLIANCE</a>	
<a href="#">ALTERA</a>			
<a href="#">AMD</a>	<a href="#">AMI SEMICONDUCTOR</a>		
<a href="#">AMIC</a>			
<a href="#">ANACHIP</a>	<a href="#">APLUS FLASH</a>	<a href="#">ARTSCHIP</a>	<a href="#">ASAHI KASEI</a>
<a href="#">(AKM)</a>			
<a href="#">ASD</a>	<a href="#">ASI</a>	<a href="#">ASP</a>	
<a href="#">ATC</a>			
<a href="#">ATMEL</a>	<a href="#">ATMEL W&amp;M</a>	<a href="#">ATMEL-CUSTOMER</a>	
<a href="#">AUSTIN</a>			
<a href="#">BELLING-SYSTRON</a>	<a href="#">BENCHMARQ</a>	<a href="#">BMT</a>	
<a href="#">BOSEN</a>			
<a href="#">BRIGHT</a>	<a href="#">CATALYST</a>	<a href="#">CELESTICA</a>	
<a href="#">CERAMATE</a>			
<a href="#">CFeon</a>	<a href="#">CHINA CORE</a>	<a href="#">CHINGIS</a>	
<a href="#">CHIPCON</a>			
<a href="#">CHIPSWINNER</a>	<a href="#">CORERIVER</a>	<a href="#">CWI</a>	
<a href="#">CYGNAL</a>			
<a href="#">CYPRESS</a>	<a href="#">DALLAS</a>	<a href="#">DENSE-PAC</a>	
<a href="#">DEUTRON</a>			
<a href="#">EFST</a>	<a href="#">ELECTRONIC ARRAYS</a>		
<a href="#">EM</a>			
<a href="#">EMTC</a>	<a href="#">EON</a>	<a href="#">EPSON</a>	
<a href="#">ESMT</a>			
<a href="#">EXCELSEMI</a>	<a href="#">EXEL</a>	<a href="#">FAIRCHILD</a>	
<a href="#">FORCE TECHNOLOGIES</a>		<a href="#">FORWARD</a>	
<a href="#">FREESCALE</a>			

<a href="#">Fremont Micro Devices</a>		<a href="#">FUJITSU</a>	
<a href="#">GENCORE</a>			
<a href="#">GENERAL(GI)</a>	<a href="#">GENERIC</a>	<a href="#">GIGADEVICE</a>	
<a href="#">GOAL</a>			
<a href="#">GREENWICH</a>	<a href="#">HAIER</a>	<a href="#">HARRIS</a>	
<a href="#">HITACHI</a>			
<a href="#">HOLTEK</a>	<a href="#">HONGKONG</a>	<a href="#">HYNIX</a>	<a href="#">HYNIX-</a>
<a href="#">CUSTOMER</a>			
<a href="#">HYUNDAI</a>	<a href="#">ICE</a>	<a href="#">ICMIC</a>	
<a href="#">ICSI</a>			
<a href="#">ICT</a>	<a href="#">IDT</a>	<a href="#">IMT</a>	
<a href="#">INTEL</a>			
<a href="#">INTEL-CUSTOMER</a>	<a href="#">INTELSIL</a>	<a href="#">ISSI</a>	
<a href="#">ITHINKO</a>			
<a href="#">LATTICE</a>	<a href="#">LG Semicon</a>	<a href="#">LINKSMART</a>	
<a href="#">MACRONIX</a>			
<a href="#">MAXIM</a>	<a href="#">MAXWELL</a>	<a href="#">MEGAWIN</a>	
<a href="#">MEMOCOM</a>			
<a href="#">MICON</a>	<a href="#">MICROCHIP</a>	<a href="#">MICRON</a>	
<a href="#">MICRONAS</a>			
<a href="#">MICRON-CUSTOMER</a>	<a href="#">MITSUBISHI</a>	<a href="#">MOSEL-VITELIC</a>	
<a href="#">MOSTEK</a>			
<a href="#">MOTOROLA</a>	<a href="#">MYSON</a>	<a href="#">NEC</a>	
<a href="#">NEXFLASH</a>			
<a href="#">NJRC</a>	<a href="#">NOVATEK</a>	<a href="#">NSC</a>	
<a href="#">NTE</a>			
<a href="#">NUMONYX</a>	<a href="#">NUVOTON</a>	<a href="#">NXP</a>	
<a href="#">OKI</a>			
<a href="#">ON Semiconductor</a>	<a href="#">PARALLAX</a>	<a href="#">PFLASH(MSTAR)</a>	
<a href="#">PHILIPS</a>			
<a href="#">PJ</a>	<a href="#">PMC</a>	<a href="#">PSS</a>	
<a href="#">PTC</a>			
<a href="#">QIXIN</a>	<a href="#">Quick Pulse</a>	<a href="#">RAMTRON</a>	
<a href="#">RATO</a>			
<a href="#">RAYDIUM</a>	<a href="#">RENESAS</a>	<a href="#">RICOH</a>	
<a href="#">ROCKWELL</a>			
<a href="#">ROHM</a>	<a href="#">SAIFUN</a>	<a href="#">SAMSUNG</a>	<a href="#">SAMSUNG-</a>
<a href="#">CUSTOMER</a>			

<a href="#">SANYO</a>	<a href="#">SCENIX</a>	<a href="#">SEEQ</a>	
<a href="#">SEIKO</a>			
<a href="#">SGS-THOMSON</a>	<a href="#">SHARP</a>	<a href="#">SHARP-CUSTOMER</a>	
<a href="#">SIEMENS</a>			
<a href="#">SIGNETICS</a>	<a href="#">Silicon Laboratories</a>		
<a href="#">SILICON7</a>			
<a href="#">SIMTEK</a>	<a href="#">SMOS</a>	<a href="#">SONIX</a>	
<a href="#">SONY</a>			
<a href="#">SPACE ELECTRONICS[SEI]</a>		<a href="#">SPANSION</a>	
<a href="#">SPANSION-CUSTOMER</a>		<a href="#">SSSC</a>	
<a href="#">SST</a>			
<a href="#">ST</a>	<a href="#">STC</a>	<a href="#">ST-CUSTOMER</a>	
<a href="#">SUMMIT</a>			
<a href="#">SUNPLUS</a>	<a href="#">SYNCOMS</a>	<a href="#">SYNERTEK</a>	
<a href="#">SYNTEK</a>			
<a href="#">TECHCODE</a>	<a href="#">TEKMOS</a>	<a href="#">TEMIC</a>	
<a href="#">TI</a>			
<a href="#">TMC</a>	<a href="#">TOPRO</a>	<a href="#">TOSHIBA</a>	<a href="#">TOSHIBA-</a>
<a href="#">CUSTOMER</a>			
<a href="#">TURBO IC</a>	<a href="#">UBICOM</a>	<a href="#">UMC</a>	
<a href="#">UTRON</a>			
<a href="#">VANTIS</a>	<a href="#">VERSACHIPS</a>	<a href="#">VLSI</a>	
<a href="#">WELTREND</a>			
<a href="#">WHITE ELECTRONIC DESIGNS</a>		<a href="#">WINBOND</a>	
<a href="#">WSI</a>			
<a href="#">XELTEK</a>	<a href="#">XICOR</a>	<a href="#">XILINX</a>	<a href="#">XILINX-</a>
<a href="#">CUSTOMER</a>			
<a href="#">YMC</a>	<a href="#">YSS</a>	<a href="#">ZHIXIN</a>	
<a href="#">ZILOG</a>			
<a href="#">ZMD</a>			

## ACT

### E ( E ) PROM / FRAM / NVRAM

93LC46 ( 08bit )

93LC46 ( 08bit ) @ SOIC8

[ (SA602A) ]	
93LC46(16bit)	93LC46(16bit)@SOIC8
[ (SA602A) ]	
93LC56(08bit)	93LC56(08bit)@SOIC8
[ (SA602A) ]	
93LC56(16bit)	93LC56(16bit)@SOIC8
[ (SA602A) ]	
93LC66(08bit)	93LC66(08bit)@SOIC8
[ (SA602A) ]	
93LC66(16bit)	93LC66(16bit)@SOIC8
[ (SA602A) ]	
93LC86(08bit)	93LC86(08bit)@SOIC8
[ (SA602A) ]	
93LC86(16bit)	93LC86(16bit)@SOIC8
[ (SA602A) ]	

## ACTRANS

### E (E) PROM/FRAM/NVRAM

AC25010@SOIC8 [ (SA602A) ]	AC25512@SOIC8
[ (SA602A) ]	
AC25LC010@SOIC8 [ (SA602A) ]	AC25LC512@SOIC8
[ (SA602A) ]	
AC39LV010@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AC39LV010@PLCC32 [ (SA015A1T) ]	AC39LV010@VSOP32
[ (SA620) ]	
AC39LV020@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AC39LV020@PLCC32 [ (SA015A1T) ]	AC39LV020@VSOP32
[ (SA620) ]	
AC39LV040@PLCC32 [ (SA015A1T) ]	AC39LV040@VSOP32
[ (SA620) ]	
AC39LV080@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AC39LV080@TSOP40 [ (SA409T) ]	AC39LV088@TSOP48 [ (SA247-B005) ]
AC39LV512@PLCC32 [ (SA015A1T) ]	AC39LV512@VSOP32
[ (SA620) ]	
AC39VF800@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AC39VF800@TSOP48 [ (SA247-B005) ]	

## ADVANCE GROUP

**E ( E ) PROM / FRAM / NVRAM**

AF24BC01 [ ( SA602A ) ]	AF24BC01@SOIC8
AF24BC01@TSOP8 [ ( SA026 ) ]	
AF24BC02 AF24BC02@SOIC8 [ ( SA602A ) ]	AF24BC02@TSOP8
[ ( SA026 ) ]	
AF24BC04 [ ( SA602A ) ]	AF24BC04@SOIC8
AF24BC04@TSOP8 [ ( SA026 ) ]	
AF24BC08 AF24BC08@SOIC8 [ ( SA602A ) ]	AF24BC08@TSOP8
[ ( SA026 ) ]	
AF24BC16 [ ( SA602A ) ]	AF24BC16@SOIC8
AF24BC16@TSOP8 [ ( SA026 ) ]	
AF24C128 AF24C128@SOIC8 [ ( SA602A ) ]	AF24C128@TSOP8
[ ( SA026 ) ]	
AF24C256 [ ( SA602A ) ]	AF24C256@SOIC8
AF24C256@TSOP8 [ ( SA026 ) ]	
AF24C32 AF24C32@SOIC8 [ ( SA602A ) ]	AF24C32@TSOP8
[ ( SA026 ) ]	
AF24C64 [ ( SA602A ) ]	AF24C64@SOIC8
AF24C64@TSOP8 [ ( SA026 ) ]	AF93C46
( 08bit )	
AF93C46 ( 08bit ) @SOIC8 [ ( SA602A ) ]	AF93C46 ( 08bit ) @TSOP8
[ ( SA026 ) ]	
AF93C46 ( 16bit ) [ ( SA602A ) ]	AF93C46 ( 16bit ) @SOIC8
AF93C46 ( 16bit ) @TSOP8 [ ( SA026 ) ]	AF93C56
( 08bit )	
AF93C56 ( 08bit ) @SOIC8 [ ( SA602A ) ]	AF93C56 ( 08bit ) @TSOP8
[ ( SA026 ) ]	
AF93C56 ( 16bit ) [ ( SA602A ) ]	AF93C56 ( 16bit ) @SOIC8
AF93C56 ( 16bit ) @TSOP8 [ ( SA026 ) ]	AF93C66
( 08bit )	

AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8
[(SA026)]	
AF93C66(16bit)	AF93C66(16bit)@SOIC8
[(SA602A)]	
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86
(08bit)	
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8
[(SA026)]	
AF93C86(16bit)	AF93C86(16bit)@SOIC8
[(SA602A)]	
AF93C86(16bit)@TSOP8 [(SA026)]	

## MICROCONTROLLER

A1000A2	A1000A2@PLCC44
[(SA244)]	
A1000A2@PQFP44 [(SA245A)]	
A1000A3	
A1000A3@PLCC44 [(SA244)]	A1000A3@PQFP44
[(SA245A)]	
AG1001@SDIP42 [(SA028)]	
AG89F516	
AG89F516@PLCC44 [(SA244)]	AG89F516@PQFP44
[(SA245A)]	
AG89F54	AG89F54@PLCC44
[(SA244)]	
AG89F54@PQFP44 [(SA245A)]	
AG89P51	
AG89P51@PLCC44 [(SA244)]	AG89P51@PQFP44
[(SA675)]	
AG89P516	AG89P516@PLCC44
[(SA244)]	
AG89P516@PQFP44 [(SA675)]	
AG89P51A	
AG89P51A@PLCC44 [(SA244)]	AG89P51A@PQFP44
[(SA675)]	
AG89P52	AG89P52@PLCC44
[(SA244)]	
AG89P52@PQFP44 [(SA675)]	

## ALI(Acer)

## **E ( E ) PROM / FRAM / NVRAM**

M8720  
[ ( SA015A1T ) ]

M8720@PLCC32

## **MICROCONTROLLER**

M6759  
[ ( SA244 ) ]  
M6759@TQFP44 [ ( SA245A ) ]

M6759@PLCC44

## **ALL 24 SERIES(ISP)**

### **E ( E ) PROM / FRAM / NVRAM**

24C01 ( ISP ) [ ISP-HEADER01 ]  
HEADER01 ]  
24C04 ( ISP ) [ ISP-HEADER01 ]  
HEADER01 ]  
24C128 ( ISP ) [ ISP-HEADER01 ]  
HEADER01 ]  
24C256 ( ISP ) [ ISP-HEADER01 ]  
HEADER01 ]  
24C64 ( ISP ) [ ISP-HEADER01 ]

24C02 ( ISP ) [ ISP-  
24C08 ( ISP ) [ ISP-  
24C16 ( ISP ) [ ISP-  
24C32 ( ISP ) [ ISP-

## **ALLIANCE**

### **E ( E ) PROM / FRAM / NVRAM**

AS29F200@PSOP44 [ ( SA638-B006 ) ]  
B005 ) ]  
AS29F200B@PSOP44 [ ( SA638-B006 ) ]  
B005 ) ]  
AS29F200T@PSOP44 [ ( SA638-B006 ) ]  
B005 ) ]

AS29F200@TSOP48 [ ( SA247-  
AS29F200B@TSOP48 [ ( SA247-  
AS29F200T@TSOP48 [ ( SA247-

## **ALTERA**

**E ( E ) PROM / FRAM / NVRAM**

EPC1 ( LC ) @ PLCC20 [ ( SA001A ) ]	EPC1 ( LI ) @ PLCC20
[ ( SA001A ) ]	
EPC1 ( PC )	EPC1
( PI )	
EPC1441 ( LC ) @ PLCC20 [ ( SA001A ) ]	EPC1441 ( LI ) @ PLCC20
[ ( SA001A ) ]	
EPC1441 ( PC )	EPC1441
( PI )	
EPC1441 ( TC ) @ TQFP32 [ ( SA663 ) ]	EPC1441 ( TI ) @ TQFP32
[ ( SA663 ) ]	
EPC2 ( LC ) @ PLCC20 [ ( SA001A ) ]	EPC2 ( LI ) @ PLCC20
[ ( SA001A ) ]	
EPC2 ( TC ) @ TQFP32 [ ( SA663 ) ]	EPC2 ( TI ) @ TQFP32
[ ( SA663 ) ]	
EPCS16SI16@SOIC16 [ ( SA404 ) ]	EPCS16SI8N@SOIC8
[ ( SA602A ) ]	
EPCS1SI8@SOIC8 [ ( SA602A ) ]	EPCS4SI8@SOIC8
[ ( SA602A ) ]	
EPCS64SI16@SOIC16 [ ( SA404 ) ]	

**PLD**

EP310	EP310@PLCC20
[ ( SA001A ) ]	
EP320	EP320@PLCC20
[ ( SA001A ) ]	
EP330	EP330@PLCC20
[ ( SA001A ) ]	
EP600	EP600@PLCC28
[ ( SA008A ) ]	
EP600@SOIC24 [ ( SA404 ) ]	
EP600I	EP600I@SOIC24
EP600I@PLCC28 [ ( SA008A ) ]	
[ ( SA404 ) ]	
EP610	EP610@PLCC28
[ ( SA008A ) ]	
EP610@SOIC24 [ ( SA404 ) ]	
EP610A	EP610A@SOIC24
EP610A@PLCC28 [ ( SA008A ) ]	



[ (SA404) ]  
 EP610I EP610I@PLCC28  
 [ (SA008A) ]  
 EP610I@SOIC24 [ (SA404) ]  
 EP610T  
 EP610T@PLCC28 [ (SA008A) ] EP610T@SOIC24  
 [ (SA404) ]  
 EP630 EP630@PLCC28  
 [ (SA008A) ]  
 EP630@SOIC24 [ (SA404) ]  
 EP900  
 EP900@PLCC44 [ (SA244) ]  
 EP900I  
 EP900I@PLC44 [ (SA244) ]  
 EP910  
 EP910@PLCC44 [ (SA244) ]  
 EP910A  
 EP910A@PLCC44 [ (SA244) ]  
 EP910I  
 EP910I@PLCC44 [ (SA244) ]  
 EP910T  
 EP910T@PLCC44 [ (SA244) ] EP63032A@PLCC44  
 [ (SA244) ]  
 EPM3032A@TQFP44 [ (SA245A) ] EP63064A@PLCC44  
 [ (SA244) ]  
 EPM3064A@TQFP44 [ (SA245A) ] EP67032@PLCC44  
 [ (SA244) ]  
 EPM7032@TQFP44 [ (SA245A) ]  
 EPM7032AE@JLCC44 (7032 mode) [ (SA244) ]  
 EPM7032AE@PLCC44 (7032 mode) [ (SA244) ]  
 EPM7032AE@PLCC44 (7032AE mode) [ (SA244) ]  
 EPM7032AE@PLCC44 (7032S mode) [ (SA244) ]  
 EPM7032AE@PQFP44 (7032 mode) [ (SA245A) ]  
 EPM7032AE@TQFP44 (7032 mode) [ (SA245A) ]  
 EPM7032AE@TQFP44 (7032AE mode) [ (SA245A) ]  
 EPM7032AE@TQFP44 (7032S mode) [ (SA245A) ]  
 EPM7032B@PLCC44 (7032AE mode) [ (SA244) ]  
 EPM7032B@PLCC44 (7032B mode) [ (SA244) ]  
 EPM7032B@PLCC44 (7032S mode) [ (SA244) ]  
 EPM7032B@TQFP44 (7032AE mode) [ (SA245A) ]  
 EPM7032B@TQFP44 (7032B mode) [ (SA245A) ]  
 EPM7032B@TQFP44 (7032S mode) [ (SA245A) ]  
 EPM7032B@TQFP48 (7032AE mode) [ (SA248) ]

EPM7032B@TQFP48	(7032B mode)	[(SA248)]
EPM7032B@TQFP48	(7032S mode)	[(SA248)]
EPM7032S@PLCC44	(7032 mode)	[(SA244)]
EPM7032S@PLCC44	(7032S mode)	[(SA244)]
EPM7032S@TQFP44	(7032 mode)	[(SA245A)]
EPM7032S@TQFP44	(7032S mode)	[(SA245A)]
EPM7032V@PLCC44	[(SA244)]	EPM7032V@TQFP44
[(SA245A)]		
EPM7064@PLCC44	[(SA244)]	EPM7064@TQFP44
[(SA245A)]		
EPM7064AE@PLCC44	(7064S)(ISP)	[ISP-HEADER01]
EPM7064AE@PLCC44	(7064AE mode)	[(SA244)]
EPM7064AE@PLCC44	(7064AE)(ISP)	[ISP-HEADER01]
EPM7064AE@PLCC44	(7064S mode)	[(SA244)]
EPM7064AE@TQFP44	(7064S)(ISP)	[ISP-HEADER01]
EPM7064AE@TQFP44	(7064AE mode)	[(SA245A)]
EPM7064AE@TQFP44	(7064AE)(ISP)	[ISP-HEADER01]
EPM7064AE@TQFP44	(7064S mode)	[(SA245A)]
EPM7064B@PLCC44	(7064AE mode)	[(SA244)]
EPM7064B@PLCC44	(7064B mode)	[(SA244)]
EPM7064B@PLCC44	(7064S mode)	[(SA244)]
EPM7064B@TQFP44	(7064AE mode)	[(SA245A)]
EPM7064B@TQFP44	(7064B mode)	[(SA245A)]
EPM7064B@TQFP44	(7064S mode)	[(SA245A)]
EPM7064B@TQFP48	(7064AE mode)	[(SA248)]
EPM7064B@TQFP48	(7064B mode)	[(SA248)]
EPM7064B@TQFP48	(7064S mode)	[(SA248)]
EPM7064S@PLCC44	(7064 mode)	[(SA244)]
EPM7064S@PLCC44	(7064S mode)	[(SA244)]
EPM7064S@TQFP44	(7064 mode)	[(SA245A)]
EPM7064S@TQFP44	(7064S mode)	[(SA245A)]

## AMD

### E(E) PROM/FRAM/NVRAM

1736		1736@SOIC8
[(SA602A)]		
1765		1765@SOIC8
[(SA602A)]		
AM25FL005D@SOIC8	[(SA602A)]	AM25FL005D@USON8
[(SA683)]		

AM25FL010D@SOIC8 [(SA602A)]	AM25FL010D@USON8
[(SA683)]	
AM25FL016A@SOIC16 [(SA404)]	
AM25FL016A@SOIC16(ISP) [ISP-HEADER01]	
AM25FL016A@WSON8 [(SA684)]	
AM25FL016A@WSON8(ISP) [ISP-HEADER01]	
AM25FL020D@SOIC8 [(SA602A)]	AM25FL020D@USON8
[(SA683)]	
AM25FL032A@SOIC16 [(SA404)]	
AM25FL032A@SOIC16(ISP) [ISP-HEADER01]	
AM25FL032A@WSON8 [(SA684)]	
AM25FL032A@WSON8(ISP) [ISP-HEADER01]	
AM25FL040D@SOIC8 [(SA602A)]	AM25FL040D@USON8
[(SA683)]	
AM25FL080D@SOIC8 [(SA602A)]	AM25FL080D@USON8
[(SA683)]	
AM27128	AM27128
(DC)	
AM27128(DC)@PLCC32 [(SA015A1T)]	AM27128@PLCC32
[(SA015A1T)]	
AM27128A	AM27128A
(F)	
AM27128A(F)@PLCC32 [(SA015A1T)]	AM27128A
(PC)	
AM27128A(PC)@PLCC32 [(SA015A1T)]	AM27128A@PLCC32
[(SA015A1T)]	
AM2716	
AM2716B	
AM27256	AM27256@PLCC32
[(SA015A1T)]	
AM27256AP	AM27256AP@PLCC32
[(SA015A1T)]	
AM27256F	AM27256F@PLCC32
[(SA015A1T)]	
AM27256PC	AM27256PC@PLCC32
[(SA015A1T)]	
AM2732	
AM2732A	
AM2732B	
AM27512	
AM27512@PLCC32 [(SA015A1T)]	
AM27512DC	
AM27512DC@PLCC32 [(SA015A1T)]	

AM27512F	
AM27512F@PLCC32 [(SA015A1T)]	
AM27512PC	
AM27512PC@PLCC32 [(SA015A1T)]	
AM27513	
AM2764	AM2764@PLCC32
[(SA015A1T)]	
AM2764A	AM2764A
(DC)	
AM2764A(DC)@PLCC32 [(SA015A1T)]	AM2764A
(DCB)	
AM2764A(DI)	AM2764A
(DIB)	
AM2764A(F)	AM2764A(F)@PLCC32
[(SA015A1T)]	
AM2764A(JC)	AM2764A
(LC)	
AM2764A(LCB)	AM2764A
(LE)	
AM2764A(LEB)	AM2764A
(PC)	
AM2764A(PC)@PLCC32 [(SA015A1T)]	AM2764A@PLCC32
[(SA015A1T)]	
AM27C010	AM27C010@PLCC32
[(SA015A1T)]	
AM27C010@TSOP32 [(SA410T)]	
AM27C020	
AM27C020@PLCC32 [(SA015A1T)]	AM27C020@TSOP32
[(SA410T)]	
AM27C040	AM27C040@PLCC32
[(SA015A1T)]	
AM27C040@TSOP32 [(SA410T)]	
AM27C080	
AM27C080@PLCC32 [(SA015A1T)]	AM27C080@TSOP32
[(SA410T)]	
AM27C100	AM27C100@PLCC32
[(SA015A1T)]	
AM27C100@TSOP32 [(SA410T)]	
AM27C1024	
AM27C1024@PLCC44 [(SA244)]	
AM27C128	
AM27C128@PLCC32 [(SA015A1T)]	
AM27C2048	

AM27C2048@PLCC44 [(SA244)]	AM27C2048@TSOP40
[(SA409T)]	
AM27C256	AM27C256
(F)	
AM27C256(F)@PLCC32 [(SA015A1T)]	AM27C256
(PC)	
AM27C256(PC)@PLCC32 [(SA015A1T)]	AM27C256@PLCC32
[(SA015A1T)]	
AM27C400	AM27C400@PLCC44
[(SA244)]	
AM27C4096	AM27C4096@PLCC44
[(SA244)]	
AM27C512	AM27C512
(P)	
AM27C512(P)@PLCC32 [(SA015A1T)]	AM27C512@PLCC32
[(SA015A1T)]	
AM27C64	AM27C64@PLCC32
[(SA015A1T)]	
AM27H010	AM27H010@PLCC32
[(SA015A1T)]	
AM27H010@TSOP32 [(SA410T)]	
AM27H256	
AM27H256@PLCC32 [(SA015A1T)]	
AM27HB010	
AM27HB010@PLCC32 [(SA015A1T)]	AM27HB010@TSOP32
[(SA410T)]	
AM27LV010	AM27LV010@PLCC32
[(SA015A1T)]	
AM27LV010@TSOP32 [(SA410T)]	
AM27LV010B	
AM27LV010B@PLCC32 [(SA015A1T)]	AM27LV010B@TSOP32
[(SA410T)]	
AM27LV020	AM27LV020@PLCC32
[(SA015A1T)]	
AM27LV020@TSOP32 [(SA410T)]	
AM27LV020B	
AM27LV020B@PLCC32 [(SA015A1T)]	AM27LV020B@TSOP32
[(SA410T)]	
AM2816A	
AM2817A	
AM2817A@PLCC32 [(SA015A1T)]	AM2817A@SOIC28
[(SA404)]	
AM2864A	AM2864A

(E)	
AM2864A(E)@PLCC32 [(SA015A1T)]	AM2864A@PLCC32
[(SA015A1T)]	
AM2864B	AM2864B
(E)	
AM2864B(E)@PLCC32 [(SA015A1T)]	AM2864B@PLCC32
[(SA015A1T)]	
AM28F001	AM28F001@PLCC32
[(SA015A1T)]	
AM28F001@TSOP32 [(SA410T)]	
AM28F010	
AM28F010@PLCC32 [(SA015A1T)]	AM28F010@TSOP32
[(SA410T)]	
AM28F010A	AM28F010A@PLCC32
[(SA015A1T)]	
AM28F010A@TSOP32 [(SA410T)]	
AM28F020	
AM28F020@PLCC32 [(SA015A1T)]	AM28F020@TSOP32
[(SA410T)]	
AM28F020A	AM28F020A@PLCC32
[(SA015A1T)]	
AM28F020A@TSOP32 [(SA410T)]	
AM28F256	
AM28F256@PLCC32 [(SA015A1T)]	AM28F256@TSOP32
[(SA410T)]	
AM28F256A	AM28F256A@PLCC32
[(SA015A1T)]	
AM28F256A@TSOP32 [(SA410T)]	
AM28F512	
AM28F512(F)	AM28F512(F)@PLCC32
[(SA015A1T)]	
AM28F512(F)@TSOP32 [(SA410T)]	AM28F512@PLCC32
[(SA015A1T)]	
AM28F512@TSOP32 [(SA410T)]	
AM28F512A	
AM28F512A(F)	AM28F512A(F)@PLCC32
[(SA015A1T)]	
AM28F512A(F)@TSOP32 [(SA410T)]	AM28F512A@PLCC32
[(SA015A1T)]	
AM28F512A@TSOP32 [(SA410T)]	
AM29BL162CB@SSOP56 [(SA629A-B022)]	
AM29BL802CB@SSOP56 [(SA629A-B022)]	
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]	

AM29DL161DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL161DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL161DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL161DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL161DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL161DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL161DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL161DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL161DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29DL163DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29DL163DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]

AM29DL164DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL320GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL320GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL320GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL320GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL320GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL322GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL322GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL322GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL322GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]



AM29DL323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL323GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL323GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL323GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL323GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL324GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL324GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL324GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL324GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BT@PLCC44 [ ( SA638-B006 ) ]  
AM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL640D@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL640G@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL640G@TSOP48 [ ( SA247-B005 ) ]  
AM29DL642G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL800B@PSOP44 [ ( SA638-B006 ) ]      AM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29DL800BB@PSOP44 [ ( SA638 ) ]  
AM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29DL800BT@PSOP44 [ ( SA638 ) ]  
AM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800T@PSOP44 [ ( SA638-B006 ) ]      AM29DL800T@TSOP48 [ ( SA247-B005 ) ]

AM29DS163CB@TSOP48 [ (SA247-B005) ]  
 AM29DS163CT@TSOP48 [ (SA247-B005) ]  
 AM29DS163DB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DS163DB@TSOP48 [ (SA247-B005) ]  
 AM29DS163DT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DS163DT@TSOP48 [ (SA247-B005) ]  
 AM29DS323DB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DS323DB@TSOP48 [ (SA247-B005) ]  
 AM29DS323DT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DS323DT@TSOP48 [ (SA247-B005) ]  
 AM29F002B AM29F002B@PLCC32  
 [ (SA015A1T) ]  
 AM29F002B@TSOP32 [ (SA410T) ]  
 AM29F002BB AM29F002BB@TSOP32  
 AM29F002BB@PLCC32 [ (SA015A1T) ]  
 [ (SA410T) ]  
 AM29F002BT AM29F002BT@PLCC32  
 [ (SA015A1T) ]  
 AM29F002BT@TSOP32 [ (SA410T) ]  
 AM29F002NB AM29F002NB@TSOP32  
 AM29F002NB@PLCC32 [ (SA015A1T) ]  
 [ (SA410T) ]  
 AM29F002NBB AM29F002NBB@PLCC32  
 [ (SA015A1T) ]  
 AM29F002NBB@TSOP32 [ (SA410T) ]  
 AM29F002NBT AM29F002NBT@TSOP32  
 AM29F002NBT@PLCC32 [ (SA015A1T) ]  
 [ (SA410T) ]  
 AM29F002NT AM29F002NT@PLCC32  
 [ (SA015A1T) ]  
 AM29F002NT@TSOP32 [ (SA410T) ]  
 AM29F002T AM29F002T@TSOP32  
 AM29F002T@PLCC32 [ (SA015A1T) ]  
 [ (SA410T) ]  
 AM29F004BB@PLCC32 [ (SA015A1T) ] AM29F004BB@TSOP32  
 [ (SA410T) ]  
 AM29F004BT@PLCC32 [ (SA015A1T) ] AM29F004BT@TSOP32  
 [ (SA410T) ]  
 AM29F010 AM29F010@PLCC32  
 [ (SA015A1T) ]  
 AM29F010@TSOP32 [ (SA410T) ]  
 AM29F010A AM29F010A@TSOP32  
 AM29F010A@PLCC32 [ (SA015A1T) ]

[ (SA410T) ]	
AM29F010B	AM29F010B@PLCC32
[ (SA015A1T) ]	
AM29F010B@TSOP32 [ (SA410T) ]	AM29F016@PSOP44
[ (SA638) ]	
AM29F016@TSOP40 [ (SA409T) ]	AM29F016@TSOP48 [ (SA247-B005) ]
AM29F016B(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016B@PSOP44 [ (SA638) ]	AM29F016B@TSOP40
[ (SA409T) ]	
AM29F016B@TSOP48 [ (SA247-B005) ]	
AM29F016D(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016D@PSOP44 [ (SA638) ]	AM29F016D@TSOP40
[ (SA409T) ]	
AM29F016D@TSOP48 [ (SA247-B005) ]	AM29F017B@TSOP48 [ (SA247-B005) ]
AM29F017D@TSOP40 [ (SA409T) ]	AM29F017D@TSOP48 [ (SA247-B005) ]
AM29F032B@PSOP44 [ (SA638) ]	AM29F032B@TSOP40
[ (SA409T) ]	
AM29F040	AM29F040@PLCC32
[ (SA015A1T) ]	
AM29F040@TSOP32 [ (SA410T) ]	
AM29F040A	
AM29F040A@PLCC32 [ (SA015A1T) ]	AM29F040A@TSOP32
[ (SA410T) ]	
AM29F040B	
AM29F040B(Reverse)@TSOP32 [ (SA410T) ]	
AM29F040B@PLCC32 [ (SA015A1T) ]	AM29F040B@TSOP32
[ (SA410T) ]	
AM29F080@PSOP44 [ (SA638) ]	AM29F080@TSOP40
[ (SA409T) ]	
AM29F080B@PSOP44 [ (SA638) ]	AM29F080B@TSOP40
[ (SA409T) ]	
AM29F100BE@PSOP44 [ (SA638-B006) ]	AM29F100BE@TSOP48 [ (SA247-B005) ]
AM29F100BS@PSOP44 [ (SA638-B006) ]	AM29F100BS@TSOP48 [ (SA247-B005) ]
AM29F100TE@PSOP44 [ (SA638-B006) ]	AM29F100TE@TSOP48 [ (SA247-B005) ]
AM29F100TS@PSOP44 [ (SA638-B006) ]	AM29F100TS@TSOP48 [ (SA247-B005) ]
AM29F160DB@TSOP48 [ (SA247-B005) ]	AM29F160DT@TSOP48 [ (SA247-

B005) ]  
AM29F200AB@PSOP44 [ ( SA638-B006 ) ] AM29F200AB@TSOP48 [ ( SA247-B005 ) ]  
AM29F200AT@PSOP44 [ ( SA638-B006 ) ] AM29F200AT@TSOP48 [ ( SA247-B005 ) ]  
AM29F200BB@PSOP44 [ ( SA638-B006 ) ] AM29F200BB@TSOP48 [ ( SA247-B005 ) ]  
AM29F200BE@PSOP44 [ ( SA638-B006 ) ] AM29F200BE@TSOP48 [ ( SA247-B005 ) ]  
AM29F200BS@PSOP44 [ ( SA638-B006 ) ] AM29F200BS@TSOP48 [ ( SA247-B005 ) ]  
AM29F200BT@PSOP44 [ ( SA638-B006 ) ] AM29F200BT@TSOP48 [ ( SA247-B005 ) ]  
AM29F200TE@PSOP44 [ ( SA638-B006 ) ] AM29F200TE@TSOP48 [ ( SA247-B005 ) ]  
AM29F200TS@PSOP44 [ ( SA638-B006 ) ] AM29F200TS@TSOP48 [ ( SA247-B005 ) ]  
AM29F400AB@PSOP44 [ ( SA638-B006 ) ] AM29F400AB@TSOP48 [ ( SA247-B005 ) ]  
AM29F400AT@PSOP44 [ ( SA638-B006 ) ] AM29F400AT@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BB@PSOP44 [ ( SA638-B006 ) ] AM29F400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BBE@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BBE@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BBF@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BBF@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BBS@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BBS@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BE@PSOP44 [ ( SA638-B006 ) ] AM29F400BE@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BF@PSOP44 [ ( SA638-B006 ) ] AM29F400BF@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BS@PSOP44 [ ( SA638-B006 ) ] AM29F400BS@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BT@PSOP44 [ ( SA638-B006 ) ] AM29F400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BTE@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BTE@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BTF@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BTF@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BTS@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BTS@TSOP48 [ ( SA247-B005 ) ]

AM29F800B@PSOP44 [(SA638-B006)] AM29F800B@TSOP48 [(SA247-B005)]  
AM29F800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29F800BB@PSOP44 [(SA638-B006)] AM29F800BB@TSOP48 [(SA247-B005)]  
AM29F800BBF@PSOP44 [(SA638-B006)]  
AM29F800BBF@TSOP48 [(SA247-B005)]  
AM29F800BF@PSOP44 [(SA638-B006)] AM29F800BF@TSOP48 [(SA247-B005)]  
AM29F800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29F800BT@PSOP44 [(SA638-B006)] AM29F800BT@TSOP48 [(SA247-B005)]  
AM29F800BTF@PSOP44 [(SA638-B006)]  
AM29F800BTF@TSOP48 [(SA247-B005)]  
AM29F800T@PSOP44 [(SA638-B006)] AM29F800T@TSOP48 [(SA247-B005)]  
AM29F800TB@PSOP44 [(SA638-B006)] AM29F800TB@TSOP48 [(SA247-B005)]  
AM29F800TF@PSOP44 [(SA638-B006)] AM29F800TF@TSOP48 [(SA247-B005)]  
AM29LL800B@TSOP48 [(SA247-B005)]  
AM29LL800BB@TSOP48 [(SA247-B005)]  
AM29LL800BT@TSOP48 [(SA247-B005)]  
AM29LL800T@TSOP48 [(SA247-B005)] AM29LV001BB@PLCC32  
[(SA015A1T)]  
AM29LV001BB@TSOP32 [(SA410T)] AM29LV001BT@PLCC32  
[(SA015A1T)]  
AM29LV001BT@TSOP32 [(SA410T)] AM29LV002@TSOP40  
[(SA409T)]  
AM29LV002B@TSOP40 [(SA409T)] AM29LV002BB@TSOP40  
[(SA409T)]  
AM29LV002BT@TSOP40 [(SA409T)] AM29LV004B@PSOP44  
[(SA638)]  
AM29LV004B@TSOP40 [(SA409T)] AM29LV004BB@TSOP40  
[(SA409T)]  
AM29LV004BT@TSOP40 [(SA409T)] AM29LV004T@PSOP44  
[(SA638)]  
AM29LV004T@TSOP40 [(SA409T)] AM29LV008B@PSOP44  
[(SA638)]  
AM29LV008B@TSOP40 [(SA409T)] AM29LV008BB@TSOP40  
[(SA409T)]  
AM29LV008BT@TSOP40 [(SA409T)] AM29LV008T@PSOP44  
[(SA638)]

AM29LV008T@TSOP40 [ (SA409T) ] AM29LV010B@PLCC32  
[ (SA015A1T) ]  
AM29LV010B@TSOP32 [ (SA410T) ] AM29LV017B@TSOP40  
[ (SA409T) ]  
AM29LV017D@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29LV017D@TSOP40 [ (SA409T) ] AM29LV020B@PLCC32  
[ (SA015A1T) ]  
AM29LV020B@TSOP32 [ (SA410T) ]  
AM29LV033C@FBGA63 [ (SA642A-B026A-Y096N001) ]  
AM29LV033C@TSOP40 [ (SA409T) ]  
AM29LV033MU@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29LV033MU@TSOP40 [ (SA409T) ] AM29LV040B@PLCC32  
[ (SA015A1T) ]  
AM29LV040B@TSOP32 [ (SA410T) ] AM29LV040E@PLCC32  
[ (SA015A1T) ]  
AM29LV040E@TSOP32 [ (SA410T) ] AM29LV040J@PLCC32  
[ (SA015A1T) ]  
AM29LV040J@TSOP32 [ (SA410T) ]  
AM29LV065D@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV065D@TSOP48 [ (SA247-B005) ]  
AM29LV065MU@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV065MU@TSOP48 [ (SA247-B005) ]  
AM29LV080@TSOP40 [ (SA409T) ] AM29LV081@TSOP40  
[ (SA409T) ]  
AM29LV081B@TSOP40 [ (SA409T) ] AM29LV116BB@TSOP40  
[ (SA409T) ]  
AM29LV116BT@TSOP40 [ (SA409T) ] AM29LV116DB@TSOP40  
[ (SA409T) ]  
AM29LV116DT@TSOP40 [ (SA409T) ]  
AM29LV128MH@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
AM29LV128MH@TSOP56 [ (SA628-B067) ]  
AM29LV128ML@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
AM29LV128ML@TSOP56 [ (SA628-B067) ]  
AM29LV160BB@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160BB@PSOP44 [ (SA638) ]  
AM29LV160BB@TSOP48 [ (SA247-B005) ]  
AM29LV160BT@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160BT@PSOP44 [ (SA638) ]  
AM29LV160BT@TSOP48 [ (SA247-B005) ]  
AM29LV160DB (REVERSE)@TSOP48 [ (SA247-B005) ]  
AM29LV160DB@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160DB@PSOP44 [ (SA638) ]  
AM29LV160DB@TSOP48 [ (SA247-B005) ]

AM29LV160DT(REVERSE)@TSOP48 [(SA247-B005)]  
AM29LV160DT@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160DT@PSOP44 [(SA638)]  
AM29LV160DT@TSOP48 [(SA247-B005)]  
AM29LV160MB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV160MB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29LV160MB@PSOP44 [(SA638)]  
AM29LV160MB@TSOP48 [(SA247-B005)]  
AM29LV160MT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV160MT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29LV160MT@PSOP44 [(SA638)]  
AM29LV160MT@TSOP48 [(SA247-B005)]  
AM29LV200B@PSOP44 [(SA638-B006)] AM29LV200B@TSOP48 [(SA247-B005)]  
AM29LV200BB@PSOP44 [(SA638-B006)]  
AM29LV200BB@TSOP48 [(SA247-B005)]  
AM29LV200BE@PSOP44 [(SA638-B006)]  
AM29LV200BE@TSOP48 [(SA247-B005)]  
AM29LV200BF@PSOP44 [(SA638-B006)]  
AM29LV200BF@TSOP48 [(SA247-B005)]  
AM29LV200BS@PSOP44 [(SA638-B006)]  
AM29LV200BS@TSOP48 [(SA247-B005)]  
AM29LV200BT@PSOP44 [(SA638-B006)]  
AM29LV200BT@TSOP48 [(SA247-B005)]  
AM29LV200T@PSOP44 [(SA638-B006)] AM29LV200T@TSOP48 [(SA247-B005)]  
AM29LV200TE@PSOP44 [(SA638-B006)]  
AM29LV200TE@TSOP48 [(SA247-B005)]  
AM29LV200TF@PSOP44 [(SA638-B006)]  
AM29LV200TF@TSOP48 [(SA247-B005)]  
AM29LV200TS@PSOP44 [(SA638-B006)]  
AM29LV200TS@TSOP48 [(SA247-B005)]  
AM29LV256MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV256MH@TSOP56 [(SA628-B067)]  
AM29LV256ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV256ML@TSOP56 [(SA628-B067)]  
AM29LV320DB@FBGA48 [(SA642E-B026A-T072F001)]  
AM29LV320DB@TSOP48 [(SA247-B005)]  
AM29LV320DT@FBGA48 [(SA642E-B026A-T072F001)]  
AM29LV320DT@TSOP48 [(SA247-B005)]  
AM29LV320FB@TSOP48 [(SA247-B005)]  
AM29LV320FT@TSOP48 [(SA247-B005)]  
AM29LV320MB@FBGA48 [(SA642HH-B026A-T048F001Y)]

AM29LV320MB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MH@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320ML@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320MT@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29LV320MT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400B@PSOP44 [ ( SA638-B006 ) ]      AM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400T@PSOP44 [ ( SA638-B006 ) ]      AM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640DH@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DL@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640DU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640GU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640GU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640MB@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MH@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640ML@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640MT@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MU@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV641DH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GHR@TSOP48 [ ( SA247-B005 ) ]



AM29LV641GL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641MH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641ML@TSOP48 [ ( SA247-B005 ) ]  
AM29LV642G@FBGA64 [ ( SA655A-B038A-T064N001 ) ]  
AM29LV652D@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV800B@PSOP44 [ ( SA638-B006 ) ]      AM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800DB(WB)@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800DB(WC)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29LV800DB@PSOP44 [ ( SA638 ) ]  
AM29LV800DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800DT(WB)@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800DT(WC)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29LV800DT@PSOP44 [ ( SA638 ) ]  
AM29LV800DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800T@PSOP44 [ ( SA638-B006 ) ]      AM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
AM29PDS322DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29PDS322DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29PL160CB@PSOP44 [ ( SA638-B006 ) ]  
AM29PL160CB@TSOP48 [ ( SA247-B005 ) ]  
AM29PL160CT@PSOP44 [ ( SA638-B006 ) ]  
AM29PL160CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL160CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29SL160CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL160CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29SL160CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL400CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL400CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DBUF@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DBVG@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]

AM29SL800DBVU@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29SL800DBWA@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
AM29SL800DBWC@FBGA48 [ (SA642R-B026A-W080F001N) ]  
AM29SL800DT@TSOP48 [ (SA247-B005) ]  
AM29SL800DTUF@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DTV@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DTVU@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29SL800DTWA@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
AM29SL800DTWC@FBGA48 [ (SA642R-B026A-W080F001N) ]  
AM9716  
AM9732  
AM9732A  
AM9764  
AM9764@PLCC32 [ (SA015A1T) ]  
BS128HD8V(AM29BDS128HD)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HD9V(AM29BDS128HD)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HE8V(AM29BDS128HE)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HE9V(AM29BDS128HE)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HF8V(AM29BDS128HF)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HF9V(AM29BDS128HF)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS640HD8V(AM29BDS640HD)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HD9V(AM29BDS640HD)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HE8V(AM29BDS640HE)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HE9V(AM29BDS640HE)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HF8V(AM29BDS640HF)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HF9V(AM29BDS640HF)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
DS42514(AM29DL163DB)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42515(AM29DL164)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42516(AM29DL324)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42546(AM29DL163)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42553(AM29DL323)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42585(AM29DL323D)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42587(AM29DL324D)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42629(AM29DL640G)@VFBGA48 [ (SA634A-B005A-Y048F001) ]  
DS42677(AM29LV128MH/L)@FBGA88 [ (SA642A-B058A-Y096N001) ]  
DS42678(AM29LV320MT)@FBGA67 [ (SA642E-B041A-T072F001) ]  
DS42689(AM29LV320MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
DS42690(AM29LV320MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
DS42695(AM29LV320MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
DS42696(AM29LV320MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
DS42701(AM29LV640MU)@FBGA88 [ (SA642W-B116A-W088F001Y) ]  
DS42725(AM50DL128CH)@FBGA88 [ (SA642A-B062A-Y096F001) ]  
DS42772A(AM29LV640M)@FBGA88 [ (SA642W-B116A-W088F001Y) ]

M410000000 (AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000001 (AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000002 (AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000003 (AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000004 (AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000005 (AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000006 (AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000007 (AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000008 (AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000009 (AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000A (AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000B (AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000C (AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000D (AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000E (AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000F (AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000G (AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000000H (AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001W (AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001X (AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001Y (AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001Z (AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000020 (AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000021 (AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000022 (AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000023 (AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000024 (AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000025 (AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000026 (AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000027 (AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002L (AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002M (AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002N (AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002O (AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002P (AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002Q (AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002R (AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002S (AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002T (AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002U (AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002V (AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002W (AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003D (AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]

M41000003E (AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003F (AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003G (AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000095 (AM41LV3204MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000096 (AM41LV3204MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000009B (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000009C (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000009D (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000000 (AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000001 (AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000004 (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000005 (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000006 (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000007 (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000I (AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000J (AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000K (AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000L (AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000M (AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000N (AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000O (AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000P (AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000Q (AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000R (AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000S (AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000T (AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000U (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000V (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000W (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000X (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001A (AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001B (AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001C (AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001D (AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001E (AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001F (AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001G (AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001H (AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001I (AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001J (AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001K (AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001L (AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001M (AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]

M42000001N (AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001O (AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001P (AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000022 (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000023 (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000024 (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000025 (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000026 (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000027 (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000028 (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000029 (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002A (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002B (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002C (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002D (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002U (AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002V (AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002Y (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000002Z (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000030 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000031 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000032 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000033 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000034 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000035 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000004Y (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000004Z (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000050 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000051 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000052 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000053 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000054 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000055 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000005M (AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005N (AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005W (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005X (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005Y (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005Z (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000060 (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000061 (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000070 (AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000071 (AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]

M420000072 (AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000073 (AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000074 (AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000075 (AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000076 (AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000077 (AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000078 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000079 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000000 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000001 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000008 (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000009 (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000A (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000B (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000S (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000T (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000U (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000V (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001C (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001D (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001E (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001F (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001W (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001X (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Y (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Z (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000000 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000001 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000G (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000H (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000J (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000K (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000L (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000M (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000N (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000O (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000P (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000Q (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000R (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000S (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000T (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000U (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000001A (AM49DL320BGB)@FBGA73 [(SA642A-B032A-Y096F001)]

M49000001B (AM49DL320BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000001Y (AM49PDL640AG)@FBGA73 [ ( SA642A-B032A-Y096N001 ) ]  
M49000001Z (AM49PDL640AG)@FBGA73 [ ( SA642A-B032A-Y096N001 ) ]  
M490000025 (AM49DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000026 (AM49DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000028 (AM49PDL127BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000029 (AM49PDL127BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002I (AM49PDL127AH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002J (AM49PDL127AH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002T (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002U (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002V (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002X (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000030 (AM49PDL129BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000031 (AM49PDL129BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000032 (AM49DL3208GB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000032 (AM49DL3208GT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000034 (AM49DL3208GT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000035 (AM49DL3208GB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003A (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003B (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003C (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003D (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003E (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003F (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003G (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003H (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003I (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003J (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003X (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003Y (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003Z (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000004A (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000004B (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004C (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004D (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004E (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004H (AM49LV128BMH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004J (AM49LV128BML)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004K (AM49LV128BMH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004L (AM49LV128BML)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004S (AM49LV128BMaH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004T (AM49LV128BMaL)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]

M49000004U(AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004V(AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]  
M4900000K(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M4900000L(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000000(AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000001(AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000008(AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]  
M500000009(AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004J(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004K(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004L(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004M(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004N(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004P(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M550000000(AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]  
M550000001(AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]  
PDL127H53V(AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H63V(AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H68V(AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H88V(AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H53V(AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H63V(AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H68V(AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H88V(AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]

## PLD

M4A3-32/32@PLCC44 [(SA244)]	M4A3-32/32@TQFP44
[(SA245A)]	
M4A3-32/32@TQFP48 [(SA248)]	M4A3-64/32@PLCC44
[(SA244)]	
M4A3-64/32@TQFP44 [(SA245A)]	M4A3-64/32@TQFP48
[(SA248)]	
M4A5-32/32@PLCC44 [(SA244)]	M4A5-32/32@TQFP44
[(SA245A)]	
M4A5-32/32@TQFP48 [(SA248)]	M4A5-64/32@PLCC44
[(SA244)]	
M4A5-64/32@TQFP44 [(SA245A)]	M4A5-64/32@TQFP48
[(SA248)]	
PALC16L8Q	PALC16L8Q@PLCC20
[(SA001A)]	
PALC16L8Z	PALC16L8Z@PLCC20



[ (SA001A) ]	
PALC16R4Q	PALC16R4Q@PLCC20
[ (SA001A) ]	
PALC16R4Z	PALC16R4Z@PLCC20
[ (SA001A) ]	
PALC16R6Q	PALC16R6Q@PLCC20
[ (SA001A) ]	
PALC16R6Z	PALC16R6Z@PLCC20
[ (SA001A) ]	
PALC16R8Q	PALC16R8Q@PLCC20
[ (SA001A) ]	
PALC16R8Z	PALC16R8Z@PLCC20
[ (SA001A) ]	
PALCE16V8H	PALCE16V8H@PLCC20
[ (SA001A) ]	
PALCE16V8H@SOIC20 [ (SA404) ]	
PALCE16V8Q	
PALCE16V8Q@PLCC20 [ (SA001A) ]	PALCE16V8Q@SOIC20
[ (SA404) ]	
PALCE16V8Z	PALCE16V8Z@PLCC20
[ (SA001A) ]	
PALCE16V8Z@SOIC20 [ (SA404) ]	
PALCE20RA10	
PALCE20RA10@PLCC28 [ (SA008A) ]	PALCE20RA10@SOIC24
[ (SA404) ]	
PALCE20RA10H	PALCE20RA10H@PLCC28
[ (SA008A) ]	
PALCE20RA10H@SOIC24 [ (SA404) ]	
PALCE20RA10Q	
PALCE20RA10Q@PLCC28 [ (SA008A) ]	PALCE20RA10Q@SOIC24
[ (SA404) ]	
PALCE20V8H	PALCE20V8H@PLCC28
[ (SA008A) ]	
PALCE20V8H@SOIC24 [ (SA404) ]	
PALCE20V8Q	
PALCE20V8Q@PLCC28 [ (SA008A) ]	PALCE20V8Q@SOIC24
[ (SA404) ]	
PALCE22V10H	PALCE22V10H@PLCC28
[ (SA008A) ]	
PALCE22V10H@SOIC24 [ (SA404) ]	
PALCE22V10Q	
PALCE22V10Q@PLCC28 [ (SA008A) ]	PALCE22V10Q@SOIC24
[ (SA404) ]	

PALCE22V10Z  
[ (SA008A) ]  
PALCE22V10Z@SOIC24 [ (SA404) ]  
PALLV16V8  
PALLV16V8@PLCC20 [ (SA001A) ]  
[ (SA404) ]  
PALLV16V8Z  
[ (SA001A) ]  
PALLV16V8Z@SOIC20 [ (SA404) ]

PALCE22V10Z@PLCC28  
  
  
  
PALLV16V8@SOIC20  
  
PALLV16V8Z@PLCC20

## MICROCONTROLLER

AM87C51  
[ (SA244) ]  
AM87C51@TQFP44 [ (SA245A) ]  
AM87C521  
AM87C521@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
AM87C541  
[ (SA244) ]  
AM87C541@TQFP44 [ (SA245A) ]

AM87C51@PLCC44  
  
  
  
AM87C521@TQFP44  
  
AM87C541@PLCC44

## AMI SEMICONDUCTOR

### E (E) PROM / FRAM / NVRAM

N256S0818HDA  
[ (SA602A) ]  
N256S0818HDA@TSSOP8 [ (SA026) ]  
N256S0830HDA  
N256S0830HDA@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
N64S0818HDA  
[ (SA602A) ]  
N64S0818HDA@TSSOP8 [ (SA026) ]  
N64S0830HDA  
N64S0830HDA@SOIC8 [ (SA602A) ]  
[ (SA026) ]

N256S0818HDA@SOIC8  
  
  
  
N256S0830HDA@TSSOP8  
  
N64S0818HDA@SOIC8  
  
  
N64S0830HDA@TSSOP8

## AMIC

**E (E) PROM/FRAM/NVRAM**

A25L010 [ (SA602A) ]	A25L010[150mil]@SOP8
A25L010[209mil]@SOP8 [ (SA605A) ]	
A25L016 A25L016@SOP8 [ (SA023A) ]	
A25L020 A25L020[150mil]@SOP8 [ (SA602A) ]	A25L020[209mil]@SOP8
[ (SA605A) ]	
A25L032 [ (SA023A) ]	A25L032@SOP8
A25L040 [ (SA683) ]	A25L040@QFN8
A25L040@SOP16 [ (SA404) ]	A25L040@SOP8
[ (SA602A) ]	
A25L05P(Bottom) [ (SA683) ]	A25L05P(Bottom)@QFN8
A25L05P(Bottom)[150mil]@SOP8 [ (SA602A) ]	
A25L05P(Bottom)[209mil]@SOP8 [ (SA605A) ]	
A25L05P(Top) [ (SA683) ]	A25L05P(Top)@QFN8
A25L05P(Top)[150mil]@SOP8 [ (SA602A) ]	
A25L05P(Top)[209mil]@SOP8 [ (SA605A) ]	
A25L080 [ (SA683) ]	A25L080@QFN8
A25L080@SOP16 [ (SA404) ]	A25L080@SOP8
[ (SA023A) ]	
A25L10P(Bottom) [ (SA683) ]	A25L10P(Bottom)@QFN8
A25L10P(Bottom)[150mil]@SOP8 [ (SA602A) ]	
A25L10P(Bottom)[209mil]@SOP8 [ (SA605A) ]	
A25L10P(Top) [ (SA683) ]	A25L10P(Top)@QFN8
A25L10P(Top)[150mil]@SOP8 [ (SA602A) ]	
A25L10P(Top)[209mil]@SOP8 [ (SA605A) ]	
A25L16P(Bottom)@QFN8 [ (SA683) ]	
A25L16P(Bottom)@QFN8(ISP) [ISP-HEADER01]	
A25L16P(Bottom)@SOP16 [ (SA404) ]	
A25L16P(Bottom)@SOP16(ISP) [ISP-HEADER01]	
A25L16P(Bottom)@SOP8 [ (SA023A) ]	
A25L16P(Bottom)@SOP8(ISP) [ISP-HEADER01]	

A25L16P(Top)@QFN8 [(SA683)]  
A25L16P(Top)@QFN8(ISP) [ISP-HEADER01]  
A25L16P(Top)@SOP16 [(SA404)]  
A25L16P(Top)@SOP16(ISP) [ISP-HEADER01]  
A25L16P(Top)@SOP8 [(SA023A)]  
A25L16P(Top)@SOP8(ISP) [ISP-HEADER01]  
A25L20P(Bottom) A25L20P(Bottom)@QFN8  
[(SA683)]  
A25L20P(Bottom)[150mil]@SOP8 [(SA602A)]  
A25L20P(Bottom)[209mil]@SOP8 [(SA605A)]  
A25L20P(Top) A25L20P(Top)@QFN8  
[(SA683)]  
A25L20P(Top)[150mil]@SOP8 [(SA602A)]  
A25L20P(Top)[209mil]@SOP8 [(SA605A)]  
A25L40P(Bottom Boot)  
A25L40P(Bottom Boot)@QFN8 [(SA683)]  
A25L40P(Bottom Boot)@SOP16 [(SA404)]  
A25L40P(Bottom Boot)@SOP8 [(SA602A)]  
A25L40P(Top Boot) A25L40P(Top Boot)@QFN8  
[(SA683)]  
A25L40P(Top Boot)@SOP16 [(SA404)]  
A25L40P(Top Boot)@SOP8 [(SA602A)]  
A25L42P(Bottom Boot)  
A25L42P(Bottom Boot)@QFN8 [(SA683)]  
A25L42P(Bottom Boot)@SOP16 [(SA404)]  
A25L42P(Bottom Boot)@SOP8 [(SA602A)]  
A25L42P(Top Boot) A25L42P(Top Boot)@QFN8  
[(SA683)]  
A25L42P(Top Boot)@SOP16 [(SA404)]  
A25L42P(Top Boot)@SOP8 [(SA602A)]  
A25L512 A25L512[150mil]@SOP8  
[(SA602A)]  
A25L512[209mil]@SOP8 [(SA605A)]  
A25L80P A25L80P@SOP16  
A25L80P@QFN8 [(SA683)]  
[(SA404)]  
A25L80P@SOP8 [(SA023A)] A25L82P(Bottom  
Boot)  
A25L82P(Bottom Boot)@QFN8 [(SA683)]  
A25L82P(Bottom Boot)@SOP16 [(SA404)]  
A25L82P(Bottom Boot)@SOP8 [(SA023A)]  
A25L82P(Top Boot) A25L82P(Top Boot)@QFN8  
[(SA683)]

A25L82P(Top Boot)@SOP16 [(SA404)]	
A25L82P(Top Boot)@SOP8 [(SA023A)]	
A25LS080	A25LS080@QFN8
[(SA683)]	
A25LS080@SOP16 [(SA404)]	A25LS080@SOP8
[(SA023A)]	
A27020	A27020@PLCC32
[(SA015A1T)]	
A27020@TSOP32 [(SA410T)]	
A27020L	
A27020L@PLCC32 [(SA015A1T)]	A27020L@TSOP32
[(SA410T)]	
A275308	A275308@PLCC32
[(SA015A1T)]	
A276308	A276308
(E)	
A276308(E)@PLCC32 [(SA015A1T)]	A276308(E)@SOIC28
[(SA404)]	
A276308@PLCC32 [(SA015A1T)]	A276308@SOIC28
[(SA404)]	
A276308A	A276308A
(L)	
A276308A(L)@PLCC32 [(SA015A1T)]	A276308A(L)@SOIC28
[(SA404)]	
A276308A@PLCC32 [(SA015A1T)]	A276308A@SOIC28
[(SA404)]	
A277308	A277308@PLCC32
[(SA015A1T)]	
A277308A	A277308A@PLCC32
[(SA015A1T)]	
A278308	A278308@PLCC32
[(SA015A1T)]	
A278308A	A278308A
(L)	
A278308A(L)@PLCC32 [(SA015A1T)]	A278308A@PLCC32
[(SA015A1T)]	
A279308	A279308@PLCC32
[(SA015A1T)]	
A290011T	A290011T@PLCC32
[(SA015A1T)]	
A290011T@TSOP32 [(SA410T)]	
A290011U	
A290011U@PLCC32 [(SA015A1T)]	A290011U@TSOP32

[ (SA410T) ]	
A29001T	A29001T@PLCC32
[ (SA015A1T) ]	
A29001T@TSOP32 [ (SA410T) ]	
A29001U	
A29001U@PLCC32 [ (SA015A1T) ]	A29001U@TSOP32
[ (SA410T) ]	
A290021T	A290021T@PLCC32
[ (SA015A1T) ]	
A290021T@TSOP32 [ (SA410T) ]	
A290021U	
A290021U@PLCC32 [ (SA015A1T) ]	A290021U@TSOP32
[ (SA410T) ]	
A29002T	A29002T@PLCC32
[ (SA015A1T) ]	
A29002T@TSOP32 [ (SA410T) ]	
A29002U	
A29002U@PLCC32 [ (SA015A1T) ]	A29002U@TSOP32
[ (SA410T) ]	
A29010	A29010@PLCC32
[ (SA015A1T) ]	
A29010@TSOP32 [ (SA410T) ]	
A29040	
A29040@PLCC32 [ (SA015A1T) ]	A29040@TSOP32
[ (SA410T) ]	
A29040A	A29040A@PLCC32
[ (SA015A1T) ]	
A29040A@TSOP32 [ (SA410T) ]	
A29040B	
A29040B@PLCC32 [ (SA015A1T) ]	A29040B@TSOP32
[ (SA410T) ]	
A29400TM@PSOP44 [ (SA638) ]	A29400TV@TSOP48 [ (SA247-
B005) ]	
A29400UM@PSOP44 [ (SA638) ]	A29400UV@TSOP48 [ (SA247-
B005) ]	
A29512	A29512@PLCC32
[ (SA015A1T) ]	
A29512@TSOP32 [ (SA410T) ]	
A29512A	
A29512A@PLCC32 [ (SA015A1T) ]	A29512A@TSOP32
[ (SA410T) ]	
A29800TM@PSOP44 [ (SA638) ]	A29800TV@TSOP48 [ (SA247-
B005) ]	

A29800UM@PSOP44 [ (SA638) ]                      A29800UV@TSOP48 [ (SA247-  
 B005) ]  
 A29DL162TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL162TV@TSOP48 [ (SA247-B005) ]  
 A29DL162UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL162UV@TSOP48 [ (SA247-B005) ]  
 A29DL163TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL163TV@TSOP48 [ (SA247-B005) ]  
 A29DL163UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL163UV@TSOP48 [ (SA247-B005) ]  
 A29DL164TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL164TV@TSOP48 [ (SA247-B005) ]  
 A29DL164UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL164UV@TSOP48 [ (SA247-B005) ]  
 A29DL320FTV@TSOP48 [ (SA247-B005) ]  
 A29DL320FUV@TSOP48 [ (SA247-B005) ]  
 A29DL322TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL322TV@TSOP48 [ (SA247-B005) ]  
 A29DL322UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL322UV@TSOP48 [ (SA247-B005) ]  
 A29DL323TG(New)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL323TG@FBGA63 [ (SA642A-B026A-Y096F001) ]  
 A29DL323TV(New)@TSOP48 [ (SA247-B005) ]  
 A29DL323TV@TSOP48 [ (SA247-B005) ]  
 A29DL323UG(New)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL323UG@FBGA63 [ (SA642A-B026A-Y096F001) ]  
 A29DL323UV(New)@TSOP48 [ (SA247-B005) ]  
 A29DL323UV@TSOP48 [ (SA247-B005) ]  
 A29DL324TG(New)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL324TG@FBGA63 [ (SA642A-B026A-Y096F001) ]  
 A29DL324TV(New)@TSOP48 [ (SA247-B005) ]  
 A29DL324TV@TSOP48 [ (SA247-B005) ]  
 A29DL324UG(New)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29DL324UG@FBGA63 [ (SA642A-B026A-Y096F001) ]  
 A29DL324UV(New)@TSOP48 [ (SA247-B005) ]  
 A29DL324UV@TSOP48 [ (SA247-B005) ]              A29L004ATL@PLCC32  
 [ (SA015A1T) ]  
 A29L004ATV@TSOP32 [ (SA410T) ]                      A29L004ATW@TSOP40  
 [ (SA409T) ]  
 A29L004ATY@VSOP32 [ (SA620) ]                      A29L004AUL@PLCC32  
 [ (SA015A1T) ]  
 A29L004AUV@TSOP32 [ (SA410T) ]                      A29L004AUW@TSOP40  
 [ (SA409T) ]

A29L004AUY@VSOP32 [ (SA620) ]                      A29L004T@PLCC32  
 [ (SA015A1T) ]  
 A29L004T@TSOP32 [ (SA410T) ]                      A29L004T@TSOP40  
 [ (SA409T) ]  
 A29L004T@VSOP32 [ (SA620) ]                      A29L004U@PLCC32  
 [ (SA015A1T) ]  
 A29L004U@TSOP32 [ (SA410T) ]                      A29L004U@TSOP40  
 [ (SA409T) ]  
 A29L004U@VSOP32 [ (SA620) ]                      A29L008ATV@TSOP40  
 [ (SA409T) ]  
 A29L008AUV@TSOP40 [ (SA409T) ]                      A29L008T@TSOP40  
 [ (SA409T) ]  
 A29L008U@TSOP40 [ (SA409T) ]  
 A29L040  
 A29L040@PLCC32 [ (SA015A1T) ]                      A29L040@TSOP32  
 [ (SA410T) ]  
 A29L040@VSOP32 [ (SA620) ]  
 A29L160ATG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29L160ATM@PSOP44 [ (SA638) ]                      A29L160ATV@TSOP48 [ (SA247-  
 B005) ]  
 A29L160AUG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29L160AUM@PSOP44 [ (SA638) ]                      A29L160AUV@TSOP48 [ (SA247-  
 B005) ]  
 A29L160BTG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29L160BTGB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29L160BTM@PSOP44 [ (SA638) ]                      A29L160BTV@TSOP48 [ (SA247-  
 B005) ]  
 A29L160BUG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29L160BUGB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29L160BUM@PSOP44 [ (SA638) ]                      A29L160BUV@TSOP48 [ (SA247-  
 B005) ]  
 A29L160HTG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 A29L160HTV@TSOP48 [ (SA247-B005) ]  
 A29L160HUG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 A29L160HUV@TSOP48 [ (SA247-B005) ]  
 A29L160TG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 A29L160TM@PSOP44 [ (SA638) ]                      A29L160TV@TSOP48 [ (SA247-  
 B005) ]  
 A29L160UG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 A29L160UM@PSOP44 [ (SA638) ]                      A29L160UV@TSOP48 [ (SA247-  
 B005) ]  
 A29L320ATG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 A29L320ATV@TSOP48 [ (SA247-B005) ]



A29L320AUG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L320AUV@TSOP48 [ ( SA247-B005 ) ]  
A29L400ATG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L400ATM@PSOP44 [ ( SA638 ) ]                      A29L400ATV@TSOP48 [ ( SA247-B005 ) ]  
A29L400AUG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L400AUM@PSOP44 [ ( SA638 ) ]                      A29L400AUV@TSOP48 [ ( SA247-B005 ) ]  
A29L400TG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L400TM@PSOP44 [ ( SA638 ) ]                      A29L400TV@TSOP48 [ ( SA247-B005 ) ]  
A29L400UG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L400UM@PSOP44 [ ( SA638 ) ]                      A29L400UV@TSOP48 [ ( SA247-B005 ) ]  
A29L800ATG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L800ATM@PSOP44 [ ( SA638 ) ]                      A29L800ATV@TSOP48 [ ( SA247-B005 ) ]  
A29L800AUG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L800AUM@PSOP44 [ ( SA638 ) ]                      A29L800AUV@TSOP48 [ ( SA247-B005 ) ]  
A29L800HTG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L800HTM@PSOP44 [ ( SA638 ) ]                      A29L800HTV@TSOP48 [ ( SA247-B005 ) ]  
A29L800HUG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L800HUM@PSOP44 [ ( SA638 ) ]                      A29L800HUV@TSOP48 [ ( SA247-B005 ) ]  
A29L800TG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L800TM@PSOP44 [ ( SA638 ) ]                      A29L800TV@TSOP48 [ ( SA247-B005 ) ]  
A29L800UG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L800UM@PSOP44 [ ( SA638 ) ]                      A29L800UV@TSOP48 [ ( SA247-B005 ) ]  
A49LF004@PLCC32 [ ( SA015A1T ) ]                      A49LF004@VSOP32  
[ ( SA620 ) ]  
A49LF004M@PLCC32 [ ( SA015A1T ) ]                      A49LF004M@VSOP32  
[ ( SA620 ) ]  
A49LF040ATL@PLCC32 [ ( SA015A1T ) ]                      A49LF040ATX@VSOP32  
[ ( SA620 ) ]  
A49LF040ATY@VSOP32 [ ( SA620 ) ]                      A49LF040TL@PLCC32  
[ ( SA015A1T ) ]  
A49LF040TX@VSOP32 [ ( SA620 ) ]                      A50FW040@PLCC32  
[ ( SA015A1T ) ]  
A50FW040@VSOP32 [ ( SA620 ) ]                      A50FW040M@PLCC32

[(SA015A1T)]  
 A50FW040M@VSOP32 [(SA620)] A50LPW040@PLCC32  
 [(SA015A1T)]  
 A50LPW040@TSOP32 [(SA410T)]  
 A617308  
 A617308@TSOP32 [(SA410T)]  
 A61L5308  
 A61L5308@TSOP28 [(SA430T)] A623308  
 (M)  
 A623308(R)@TSOP28 [(SA430T)] A623308(V)@TSOP28  
 [(SA430T)]  
 A625308(M) A625308(R)@TSOP28  
 [(SA430T)]  
 A625308(V)@TSOP28 [(SA430T)]  
 A62L256  
 A62L256(M) A62L256(R)@TSOP28  
 [(SA430T)]  
 A62L256(V)@TSOP28 [(SA430T)] A62S6308  
 (M)  
 A62S6308(X)@TSOP32 [(SA410T)] A62S7308A  
 (M)  
 A62S7308A(X)@TSOP32 [(SA410T)] A62S8308A  
 (M)  
 A62S8308A(X)@TSOP32 [(SA410T)] A62W5308  
 (M)  
 A62W5308(R)@TSOP28 [(SA430T)] A62W5308(V)@TSOP28  
 [(SA430T)]  
 A81L801TG@FBGA69 [(SA642A-B078A-Y096F001Y)]  
 A81L801UG@FBGA69 [(SA642A-B078A-Y096F001Y)]  
 A82DL1622TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1622UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1624TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1624UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1632TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1632UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1634TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1634UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1642TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1642UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1644TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL1644UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 A82DL32216TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL32216UG@FBGA69 [(SA642A-B254A-Y096F001Y)]

A82DL3224TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3224UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3228TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3228UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL32316TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL32316UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3234TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3234UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3238TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3238UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL32416TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL32416UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3244TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3244UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3248TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3248UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]

## ANACHIP

### E ( E ) PROM / FRAM / NVRAM

27CX010	27CX010@PLCC32
[ ( SA015A1T ) ]	
27CX010@TSOP32 [ ( SA410T ) ]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[ ( SA602A ) ]	
93C46A	93C46A@SOIC8
[ ( SA602A ) ]	
93C56A	93C56A@SOIC8
[ ( SA602A ) ]	
93C66A	93C66A@SOIC8
[ ( SA602A ) ]	
93CX46	93CX46@SOIC8
[ ( SA602A ) ]	
93CX56	93CX56@SOIC8

[ (SA602A) ]	
93CX66	93CX66@SOIC8
[ (SA602A) ]	
AM24LC02	AM24LC02@SOIC8
[ (SA602A) ]	
AM24LC02@TSSOP8 [ (SA026) ]	
AM24LC04	
AM24LC04@SOIC8 [ (SA602A) ]	AM24LC04@TSSOP8
[ (SA026) ]	
AM24LC08	AM24LC08@SOIC8
[ (SA602A) ]	
AM24LC08@TSSOP8 [ (SA026) ]	
AM24LC16	
AM24LC16@SOIC8 [ (SA602A) ]	AM24LC16@TSSOP8
[ (SA026) ]	
AM24LC21	AM24LC21@SOIC8
[ (SA602A) ]	
AM24LC21@TSSOP8 [ (SA026) ]	
AM24LC21B	
AM24LC21B@SOIC8 [ (SA602A) ]	AM24LC21B@TSSOP8
[ (SA026) ]	
AM93LC46(08bit)	AM93LC46(08bit)@SOIC8
[ (SA602A) ]	
AM93LC46(08bit)@TSOP8 [ (SA026) ]	AM93LC46
(16bit)	
AM93LC46(16bit)@SOIC8 [ (SA602A) ]	AM93LC46(16bit)@TSOP8
[ (SA026) ]	
AM93LC56(08bit)	AM93LC56(08bit)@SOIC8
[ (SA602A) ]	
AM93LC56(08bit)@TSOP8 [ (SA026) ]	AM93LC56
(16bit)	
AM93LC56(16bit)@SOIC8 [ (SA602A) ]	AM93LC56(16bit)@TSOP8
[ (SA026) ]	
AM93LC66(08bit)	AM93LC66(08bit)@SOIC8
[ (SA602A) ]	
AM93LC66(08bit)@TSOP8 [ (SA026) ]	AM93LC66
(16bit)	
AM93LC66(16bit)@SOIC8 [ (SA602A) ]	AM93LC66(16bit)@TSOP8
[ (SA026) ]	
AM93LC86(08bit)	AM93LC86(08bit)@SOIC8
[ (SA602A) ]	
AM93LC86(08bit)@TSOP8 [ (SA026) ]	AM93LC86
(16bit)	

AM93LC86(16bit)@SOIC8 [(SA602A)]  
[(SA026)]

AM93LC86(16bit)@TSOP8

## PLD

PA7024

[(SA008A)]

PA7024(JN)@PLCC28 [(SA008A)]

[(SA404)]

PA7128

[(SA008A)]

PA7128@SOIC28 [(SA404)]

PA7140

PA7140@PLCC44 [(SA244)]

[(SA245A)]

PA7536

[(SA008A)]

PA7536@SOIC28 [(SA404)]

PA7540

PA7540(J)@PLCC28 [(SA008A)]

[(SA008A)]

PA7572

[(SA244)]

PA7572@TQFP44 [(SA245A)]

PEEL18CV8Z

PEEL18CV8Z@PLCC20 [(SA001A)]

[(SA404)]

PEEL18CV8Z@TSOP20 [(SA026)]

PEEL18LV8Z

PEEL18LV8Z@PLCC20 [(SA001A)]

[(SA404)]

PEEL18LV8Z@TSOP20 [(SA026)]

PEEL22CV10A

PEEL22CV10A@PLCC28 [(SA008A)]

[(SA404)]

PEEL22CV10A@TSOP24 [(SA026)]

+

PEEL22CV10A+@PLCC28 [(SA008A)]

[(SA404)]

PEEL22CV10A+@TSOP24 [(SA026)]

+

PEEL22CV10A++@PLCC28 [(SA008A)]

PA7024(J)@PLCC28

PA7024@SOIC24

PA7128@PLCC28

PA7140@TQFP44

PA7536@PLCC28

PA7540(JN)@PLCC28

PA7572@PLCC44

PEEL18CV8Z@SOIC20

PEEL18LV8Z@SOIC20

PEEL22CV10A@SOIC24

PEEL22CV10A

PEEL22CV10A+@SOIC24

PEEL22CV10A+

PEEL22CV10A++@SOIC24

[ (SA404) ]	
PEEL22CV10A++@TSOP24 [ (SA026) ]	
PEEL22CV10AZ	
PEEL22CV10AZ@PLCC28 [ (SA008A) ]	PEEL22CV10AZ@SOIC24
[ (SA404) ]	
PEEL22CV10AZ@TSOP24 [ (SA026) ]	PEEL22CV10AZ
+	
PEEL22CV10AZ+@PLCC28 [ (SA008A) ]	PEEL22CV10AZ+@SOIC24
[ (SA404) ]	
PEEL22CV10AZ+@TSOP24 [ (SA026) ]	PEEL22CV10AZ+
+	
PEEL22CV10AZ++@PLCC28 [ (SA008A) ]	PEEL22CV10AZ++@SOIC24
[ (SA404) ]	
PEEL22CV10AZ++@TSOP24 [ (SA026) ]	
PEEL22LV10AZ	
PEEL22LV10AZ@PLCC28 [ (SA008A) ]	PEEL22LV10AZ@SOIC24
[ (SA404) ]	
PEEL22LV10AZ@TSOP24 [ (SA026) ]	PEEL22LV10AZ
+	
PEEL22LV10AZ+@PLCC28 [ (SA008A) ]	PEEL22LV10AZ+@SOIC24
[ (SA404) ]	
PEEL22LV10AZ+@TSOP24 [ (SA026) ]	PEEL22LV10AZ+
+	
PEEL22LV10AZ++@PLCC28 [ (SA008A) ]	PEEL22LV10AZ++@SOIC24
[ (SA404) ]	
PEEL22LV10AZ++@TSOP24 [ (SA026) ]	

## APLUS FLASH

### E (E) PROM / FRAM / NVRAM

AF24BC01	AF24BC01@SOIC8
[ (SA602A) ]	
AF24BC01@TSSOP8 [ (SA026) ]	
AF24BC02	
AF24BC02@SOIC8 [ (SA602A) ]	AF24BC02@TSSOP8
[ (SA026) ]	
AF24BC04	AF24BC04@SOIC8
[ (SA602A) ]	
AF24BC04@TSSOP8 [ (SA026) ]	
AF24BC08	
AF24BC08@SOIC8 [ (SA602A) ]	AF24BC08@TSSOP8

[ (SA026) ]	
AF24BC128	AF24BC128@SOIC8
[ (SA602A) ]	
AF24BC128@TSOP8 [ (SA026) ]	
AF24BC16	
AF24BC16@SOIC8 [ (SA602A) ]	AF24BC16@TSSOP8
[ (SA026) ]	
AF24BC256	AF24BC256@SOIC8
[ (SA602A) ]	
AF24BC256@TSOP8 [ (SA026) ]	
AF24BC32	
AF24BC32@SOIC8 [ (SA602A) ]	AF24BC32@TSOP8
[ (SA026) ]	
AF24BC64	AF24BC64@SOIC8
[ (SA602A) ]	
AF24BC64@TSOP8 [ (SA026) ]	
AF24C128	
AF24C128@SOIC8 [ (SA602A) ]	AF24C128@TSOP8
[ (SA026) ]	
AF24C256	AF24C256@SOIC8
[ (SA602A) ]	
AF24C256@TSOP8 [ (SA026) ]	
AF24C32	
AF24C32@SOIC8 [ (SA602A) ]	AF24C32@TSOP8
[ (SA026) ]	
AF24C64	AF24C64@SOIC8
[ (SA602A) ]	
AF24C64@TSOP8 [ (SA026) ]	
AF25BC128	
AF25BC128@SOIC8 [ (SA602A) ]	AF25BC128@TSOP8
[ (SA026) ]	
AF25BC256	AF25BC256@SOIC8
[ (SA602A) ]	
AF25BC256@TSOP8 [ (SA026) ]	AF93BC46
(08bit)	
AF93BC46(08bit)@SOIC8 [ (SA602A) ]	AF93BC46(08bit)@TSOP8
[ (SA026) ]	
AF93BC46(16bit)	AF93BC46(16bit)@SOIC8
[ (SA602A) ]	
AF93BC46(16bit)@TSOP8 [ (SA026) ]	AF93BC56
(08bit)	
AF93BC56(08bit)@SOIC8 [ (SA602A) ]	AF93BC56(08bit)@TSOP8
[ (SA026) ]	

AF93BC56(16bit) [(SA602A)]	AF93BC56(16bit)@SOIC8
AF93BC56(16bit)@TSOP8 [(SA026)] (08bit)	AF93BC66
AF93BC66(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93BC66(08bit)@TSOP8
AF93BC66(16bit) [(SA602A)]	AF93BC66(16bit)@SOIC8
AF93BC66(16bit)@TSOP8 [(SA026)] (08bit)	AF93BC86
AF93BC86(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93BC86(08bit)@TSOP8
AF93BC86(16bit) [(SA602A)]	AF93BC86(16bit)@SOIC8
AF93BC86(16bit)@TSOP8 [(SA026)] (08bit)	AF93C46
AF93C46(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C46(08bit)@TSOP8
AF93C46(16bit) [(SA602A)]	AF93C46(16bit)@SOIC8
AF93C46(16bit)@TSOP8 [(SA026)] (08bit)	AF93C56
AF93C56(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C56(08bit)@TSOP8
AF93C56(16bit) [(SA602A)]	AF93C56(16bit)@SOIC8
AF93C56(16bit)@TSOP8 [(SA026)] (08bit)	AF93C66
AF93C66(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C66(08bit)@TSOP8
AF93C66(16bit) [(SA602A)]	AF93C66(16bit)@SOIC8
AF93C66(16bit)@TSOP8 [(SA026)] (08bit)	AF93C86
AF93C86(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C86(08bit)@TSOP8
AF93C86(16bit) [(SA602A)]	AF93C86(16bit)@SOIC8
AF93C86(16bit)@TSOP8 [(SA026)]	

## ARTSCHIP



**E ( E ) PROM / FRAM / NVRAM**

24AA02	24AA02@MSOP8
[ ( SA666 ) ]	
24AA02@SOIC8 [ ( SA602A ) ]	24AA02@SOT5
[ ( SA698 ) ]	
24AA02@TSSOP8 [ ( SA026 ) ]	
24LC01A	
24LC01A@SOIC8 [ ( SA602A ) ]	24LC01A@SOT5
[ ( SA698 ) ]	
24LC01A@TSSOP8 [ ( SA026 ) ]	
24LC01B	
24LC01B@SOIC8 [ ( SA602A ) ]	24LC01B@SOT5
[ ( SA698 ) ]	
24LC01B@TSSOP8 [ ( SA026 ) ]	
24LC02A	
24LC02A@SOIC8 [ ( SA602A ) ]	24LC02A@SOT5
[ ( SA698 ) ]	
24LC02A@TSSOP8 [ ( SA026 ) ]	
24LC02B	
24LC02B@MSOP8 [ ( SA666 ) ]	24LC02B@SOIC8
[ ( SA602A ) ]	
24LC02B@SOT5 [ ( SA698 ) ]	24LC02B@TSSOP8
[ ( SA026 ) ]	
24LC04A	24LC04A@SOIC8
[ ( SA602A ) ]	
24LC04A@SOT5 [ ( SA698 ) ]	24LC04A@TSSOP8
[ ( SA026 ) ]	
24LC04B	24LC04B@MSOP8
[ ( SA666 ) ]	
24LC04B@SOIC8 [ ( SA602A ) ]	24LC04B@SOT5
[ ( SA698 ) ]	
24LC04B@TSSOP8 [ ( SA026 ) ]	
24LC08A	
24LC08A@SOIC8 [ ( SA602A ) ]	24LC08A@SOT5
[ ( SA698 ) ]	
24LC08A@TSSOP8 [ ( SA026 ) ]	
24LC08B	
24LC08B@MSOP8 [ ( SA666 ) ]	24LC08B@SOIC8
[ ( SA602A ) ]	
24LC08B@SOT5 [ ( SA698 ) ]	24LC08B@TSSOP8
[ ( SA026 ) ]	
24LC16A	24LC16A@SOIC8

[ (SA602A) ]	
24LC16A@SOT5 [ (SA698) ]	24LC16A@TSSOP8
[ (SA026) ]	
24LC256B	24LC256B@MSOP8
[ (SA666) ]	
24LC256B@SOIC8 [ (SA602A) ]	24LC256B@TSSOP8
[ (SA026) ]	
24LC32	24LC32@SOIC14
[ (SA026) ]	
24LC32@SOIC8 [ (SA602A) ]	24LC32@TSSOP8
[ (SA026) ]	
24LC64	24LC64@SOIC14
[ (SA026) ]	
24LC64@SOIC8 [ (SA602A) ]	24LC64@TSSOP8
[ (SA026) ]	

## ASAHI KASEI(AKM)

### E (E) PROM/FRAM/NVRAM

AK27CX161	
AK27CX162	
AK27CX321	
AK27CX322	
AK27CX641	
AK27CX642	
AK6002A(F)@SOP8 [ (SA602A) ]	AK6002A(V)@TSSOP8
[ (SA026) ]	
AK6003A(V)@TSSOP8 [ (SA026) ]	AK6004A(F)@SOP8
[ (SA602A) ]	
AK6004A(M)@SSOP8 [ (SA605A) ]	AK6008A(F)@SOP8
[ (SA602A) ]	
AK6010A(F)@SOP8 [ (SA602A) ]	AK6012A(F)@SOP8
[ (SA602A) ]	
AK6416A(M)@SSOP8 [ (SA026) ]	AK6416C(F)@SOP8
[ (SA602A) ]	
AK6420A(F)@SOP8 [ (SA602A) ]	AK6420A(M)@SSOP8
[ (SA605A) ]	
AK6420B(H)@MSOP8 [ (SA666) ]	AK6440A(F)@SOP8
[ (SA602A) ]	
AK6440A(M)@SSOP8 [ (SA605A) ]	AK6440B(H)@MSOP8
[ (SA666) ]	

AK6480A(F)@SOP8 [(SA602A)] [(SA605A)]	AK6480A(M)@SSOP8
AK6480B(H)@MSOP8 [(SA666)] [(SA602A)]	AK6480C(F)@SOP8
AK6480C(H)@MSOP8 [(SA666)] @SON8	AK6480C(L)
AK6480C(M)@SSOP8 [(SA605A)] [(SA666)]	AK6481C(H)@MSOP8
AK6481C(M)@SSOP8 [(SA605A)] [(SA666)]	AK6508C(T)@MSOP8
AK6508C(U)@USON8 @SONW8	AK6510C(L)
AK6510C(M)@SSOP8 [(SA026)] @SONW8	AK6512C(L)
AK6512C(M)@SSOP8 [(SA026)] [(SA602A)]	AK6514C(F)@SOP8
AK6514C(N)@QFN20 [(SA692)] [(SA602A)]	AK6516C(F)@SOP8
AK93C10A(F)@SOP8 [(SA602A)] [(SA026)]	AK93C41A(V)@TSSOP8
AK93C45 [(SA602A)]	AK93C45(F)@SOP8
AK93C45A(F)@SOP8 [(SA602A)] [(SA602A)]	AK93C45A(NF)@SOP8
AK93C45A(V)@TSSOP8 [(SA026)] [(SA666)]	AK93C45B(H)@MSOP8
AK93C45B(L)@SON8 [(SA666)]	AK93C45C(T)@MSOP8
AK93C45C(U)@USON8 AK93C45L	
AK93C45L(F)@SOP8 [(SA602A)] AK93C46	
AK93C46(F)@SOP8 [(SA602A)] [(SA602A)]	AK93C46A(F)@SOP8
AK93C46A(NF)@SOP8 [(SA602A)] [(SA026)]	AK93C46A(V)@TSSOP8
AK93C46B(H)@MSOP8 [(SA666)] @SON8	AK93C46B(L)
AK93C46C(T)@MSOP8 [(SA666)] @USON8	AK93C46C(U)
AK93C46L [(SA602A)]	AK93C46L(F)@SOP8
AK93C51A(V)@TSSOP8 [(SA026)]	

AK93C55

AK93C55(F)@SOP8 [(SA602A)]

[(SA602A)]

AK93C55A(NF)@SOP8 [(SA602A)]

[(SA026)]

AK93C55B(H)@MSOP8 [(SA666)]

@SON8

AK93C55C(T)@MSOP8 [(SA666)]

@USON8

AK93C55L

[(SA602A)]

AK93C56

[(SA602A)]

AK93C56A(F)@SOP8 [(SA602A)]

[(SA602A)]

AK93C56A(V)@TSSOP8 [(SA026)]

[(SA666)]

AK93C56B(L)@SON8

[(SA666)]

AK93C56C(U)@USON8

AK93C56L

AK93C56L(F)@SOP8 [(SA602A)]

[(SA026)]

AK93C65

[(SA602A)]

AK93C65A(F)@SOP8 [(SA602A)]

[(SA602A)]

AK93C65A(V)@TSSOP8 [(SA026)]

[(SA666)]

AK93C65B(L)@SON8

[(SA666)]

AK93C65C(U)@USON8

AK93C65L

AK93C65L(F)@SOP8 [(SA602A)]

AK93C66

AK93C66(F)@SOP8 [(SA602A)]

[(SA602A)]

AK93C66A(NF)@SOP8 [(SA602A)]

[(SA026)]

AK93C66B(H)@MSOP8 [(SA666)]

@SON8

AK93C66C(T)@MSOP8 [(SA666)]

@USON8

AK93C55A(F)@SOP8

AK93C55A(V)@TSSOP8

AK93C55B(L)

AK93C55C(U)

AK93C55L(F)@SOP8

AK93C56(F)@SOP8

AK93C56A(NF)@SOP8

AK93C56B(H)@MSOP8

AK93C56C(T)@MSOP8

AK93C61A(V)@TSSOP8

AK93C65(F)@SOP8

AK93C65A(NF)@SOP8

AK93C65B(H)@MSOP8

AK93C65C(T)@MSOP8

AK93C66A(F)@SOP8

AK93C66A(V)@TSSOP8

AK93C66B(L)

AK93C66C(U)

AK93C66L [ (SA602A) ]	AK93C66L ( F )@SOP8
AK93C75 [ (SA602A) ]	AK93C75 ( F )@SOP8
AK93C75A ( F )@SOP8 [ (SA602A) ] [ (SA602A) ]	AK93C75A ( NF )@SOP8
AK93C75A ( V )@TSSOP8 [ (SA026) ] [ (SA666) ]	AK93C75B ( H )@MSOP8
AK93C75L [ (SA602A) ]	AK93C75L ( F )@SOP8
AK93C85 [ (SA602A) ]	AK93C85 ( F )@SOP8
AK93C85L [ (SA602A) ]	AK93C85L ( F )@SOP8
AK93C95A ( F )@SOP8 [ (SA602A) ] [ (SA026) ]	AK9822 ( M )@SSOP8
AK9824 ( M )@SSOP8 [ (SA026) ] [ (SA602) ]	AK9844@SOIC14

## ASD

### E ( E ) PROM / FRAM / NVRAM

AE29F1008  
AE29F2008

## ASI

### E ( E ) PROM / FRAM / NVRAM

AS58C1001 [ (SA015A1T) ]	AS58C1001@PLCC32
AS58C1001@SSOP32 [ (SA438T) ]	

## ASP

### MICROCONTROLLER

AP827C51	AP827C51@PLCC44
----------	-----------------

[ (SA244) ]	
AP827C52	AP827C52@PLCC44
[ (SA244) ]	
AP827C54	AP827C54@PLCC44
[ (SA244) ]	
AP827C58	AP827C58@PLCC44
[ (SA244) ]	

## ATC

### E (E) PROM / FRAM / NVRAM

ATC24C02	ATC24C02@SOIC8
[ (SA602A) ]	
ATC24C02@TSSOP8 [ (SA026) ]	
ATC24C04	
ATC24C04@SOIC8 [ (SA602A) ]	ATC24C04@TSSOP8
[ (SA026) ]	
ATC24C08	ATC24C08@SOIC8
[ (SA602A) ]	
ATC24C08@TSSOP8 [ (SA026) ]	
ATC24C16	
ATC24C16@SOIC8 [ (SA602A) ]	ATC24C16@TSSOP8
[ (SA026) ]	
ATC24LC02	ATC24LC02@SOIC8
[ (SA602A) ]	
ATC24LC02@TSSOP8 [ (SA026) ]	
ATC24LC02A	
ATC24LC02A@SOIC8 [ (SA602A) ]	ATC24LC02A@TSSOP8
[ (SA026) ]	
ATC24LC04	ATC24LC04@SOIC8
[ (SA602A) ]	
ATC24LC04@TSSOP8 [ (SA026) ]	
ATC24LC08	
ATC24LC08@SOIC8 [ (SA602A) ]	ATC24LC08@TSSOP8
[ (SA026) ]	
ATC24LC16	ATC24LC16@SOIC8
[ (SA602A) ]	
ATC24LC16@TSSOP8 [ (SA026) ]	ATC93C46
(08bit)	
ATC93C46(08bit)@SOIC8 [ (SA602A) ]	ATC93C46
(16bit)	

ATC93C46(16bit)@SOIC8 [(SA602A)]  
ATC93C46R(08bit)@SOIC8 [(SA602A)]  
ATC93C46R(16bit)@SOIC8 [(SA602A)]  
ATC93C56(08bit) ATC93C56(08bit)@SOIC8  
[(SA602A)]  
ATC93C56(16bit) ATC93C56(16bit)@SOIC8  
[(SA602A)]  
ATC93C56R(08bit)@SOIC8 [(SA602A)]  
ATC93C56R(16bit)@SOIC8 [(SA602A)]  
ATC93C66(08bit) ATC93C66(08bit)@SOIC8  
[(SA602A)]  
ATC93C66(16bit) ATC93C66(16bit)@SOIC8  
[(SA602A)]  
ATC93C66R(08bit)@SOIC8 [(SA602A)]  
ATC93C66R(16bit)@SOIC8 [(SA602A)]  
ATC93LC46(08bit)  
ATC93LC46(08bit)@SOIC8 [(SA602A)]  
ATC93LC46(16bit)  
ATC93LC46(16bit)@SOIC8 [(SA602A)]  
ATC93LC46R(08bit)@SOIC8 [(SA602A)]  
ATC93LC46R(16bit)@SOIC8 [(SA602A)]  
ATC93LC56(08bit)  
ATC93LC56(08bit)@SOIC8 [(SA602A)]  
ATC93LC56(16bit)  
ATC93LC56(16bit)@SOIC8 [(SA602A)]  
ATC93LC56R(08bit)@SOIC8 [(SA602A)]  
ATC93LC56R(16bit)@SOIC8 [(SA602A)]  
ATC93LC66(08bit)  
ATC93LC66(08bit)@SOIC8 [(SA602A)]  
ATC93LC66(16bit)  
ATC93LC66(16bit)@SOIC8 [(SA602A)]  
ATC93LC66R(08bit)@SOIC8 [(SA602A)]  
ATC93LC66R(16bit)@SOIC8 [(SA602A)]

## ATMEL

### E (E) PROM/FRAM/NVRAM

AT17C002@PLCC20 [(SA001A)] AT17C002@PLCC44  
[(SA244)]  
AT17C002@SOIC20 [(SA404)] AT17C002@TQFP44  
[(SA245A)]

AT17C002A@PLCC20 [(SA001A)]	AT17C002A@TQFP32
[(SA663)]	
AT17C010	AT17C010@PLCC20
[(SA001A)]	
AT17C010A	AT17C010A@PLCC20
[(SA001A)]	
AT17C040@PLCC44 [(SA244)]	AT17C040@TQFP44
[(SA245A)]	
AT17C128	AT17C128@PLCC20
[(SA001A)]	
AT17C128@SOIC20 [(SA404)]	AT17C128@SOIC8
[(SA602A)]	
AT17C128A@PLCC20 [(SA001A)]	
AT17C256	
AT17C256@PLCC20 [(SA001A)]	AT17C256@SOIC20
[(SA404)]	
AT17C256@SOIC8 [(SA602A)]	AT17C256A@PLCC20
[(SA001A)]	
AT17C512	AT17C512@PLCC20
[(SA001A)]	
AT17C512A	AT17C512A@PLCC20
[(SA001A)]	
AT17C65	AT17C65@PLCC20
[(SA001A)]	
AT17C65@SOIC20 [(SA404)]	AT17C65@SOIC8
[(SA602A)]	
AT17C65A@PLCC20 [(SA001A)]	AT17F040@LAP8
[(SA760)]	
AT17F040@PLCC20 [(SA001A)]	
AT17F040@PLCC20(Virtex Pinout) [(SA001A)]	
AT17F040A@LAP8 [(SA760)]	AT17F040A@PLCC20
[(SA001A)]	
AT17F040A@TQFP32 [(SA663)]	AT17F080@LAP8
[(SA760)]	
AT17F080@PLCC20 [(SA001A)]	AT17F080@PLCC44
[(SA244)]	
AT17F080@TQFP44 [(SA245A)]	AT17F080A@LAP8
[(SA760)]	
AT17F080A@PLCC20 [(SA001A)]	AT17F080A@TQFP32
[(SA001A)]	
AT17F16@LAP8 [(SA760)]	AT17F16@PLCC20
[(SA001A)]	
AT17F16@PLCC44 [(SA244)]	AT17F16@TQFP44



[ (SA245A) ]	
AT17F16A@LAP8 [ (SA760) ]	AT17F16A@PLCC20
[ (SA001A) ]	
AT17F32@PLCC44 [ (SA244) ]	AT17F32A@PLCC44
[ (SA244) ]	
AT17LV002@PLCC20 [ (SA001A) ]	AT17LV002@PLCC44
[ (SA244) ]	
AT17LV002@SOIC20 [ (SA404) ]	AT17LV002@TQFP44
[ (SA245A) ]	
AT17LV002A@PLCC20 [ (SA001A) ]	AT17LV002A@TQFP32
[ (SA663) ]	
AT17LV010	AT17LV010@PLCC20
[ (SA001A) ]	
AT17LV010A	AT17LV010A@PLCC20
[ (SA001A) ]	
AT17LV040@PLCC44 [ (SA244) ]	AT17LV040@TQFP44
[ (SA245A) ]	
AT17LV128	AT17LV128@PLCC20
[ (SA001A) ]	
AT17LV128@SOIC20 [ (SA404) ]	AT17LV128@SOIC8
[ (SA602A) ]	
AT17LV128A@PLCC20 [ (SA001A) ]	
AT17LV256	
AT17LV256@PLCC20 [ (SA001A) ]	AT17LV256@SOIC20
[ (SA404) ]	
AT17LV256@SOIC8 [ (SA602A) ]	AT17LV256A@PLCC20
[ (SA001A) ]	
AT17LV512	AT17LV512@PLCC20
[ (SA001A) ]	
AT17LV512A	AT17LV512A@PLCC20
[ (SA001A) ]	
AT17LV65	AT17LV65@PLCC20
[ (SA001A) ]	
AT17LV65@SOIC20 [ (SA404) ]	AT17LV65@SOIC8
[ (SA602A) ]	
AT17LV65A@PLCC20 [ (SA001A) ]	AT17N002@SOIC20
[ (SA404) ]	
AT17N002@TQFP44 [ (SA245A) ]	
AT17N010	
AT17N010@SOIC20 [ (SA404) ]	AT17N040@TQFP44
[ (SA245A) ]	
AT17N256	AT17N256@SOIC20
[ (SA404) ]	

AT17N256@SOIC8 [(SA602A)]	
AT17N512	
AT17N512@SOIC20 [(SA404)]	
AT24C01	
AT24C01@MSOP8 [(SA666)]	AT24C01@SOIC8
[(SA602A)]	
AT24C01@TSSOP8 [(SA026)]	
AT24C01A	
AT24C01A@MAP8 [(SA724)]	AT24C01A@SOIC8
[(SA602A)]	
AT24C01A@SOT23-5 [(SA717)]	AT24C01A@TSSOP8
[(SA026)]	
AT24C01B	
AT24C01B@dBGA2	
AT24C01B@MAP8 [(SA724)]	AT24C01B@SOIC8
[(SA602A)]	
AT24C01B@SOT23 [(SA717)]	AT24C01B@TSSOP8
[(SA026)]	
AT24C02	AT24C02@SOIC8
[(SA602A)]	
AT24C02@TSSOP8 [(SA026)]	
AT24C02A	
AT24C02A@SOIC8 [(SA602A)]	AT24C02A@TSSOP8
[(SA026)]	
AT24C02B	
AT24C02B@dBGA2	
AT24C02B@MAP8 [(SA724)]	AT24C02B@SOIC8
[(SA602A)]	
AT24C02B@SOT23 [(SA717)]	AT24C02B@TSSOP8
[(SA026)]	
AT24C04	AT24C04@MAP8
[(SA724)]	
AT24C04@SOIC8 [(SA602A)]	AT24C04@SOT23-5
[(SA717)]	
AT24C04@TSSOP8 [(SA026)]	
AT24C04A	
AT24C04A@MAP8 [(SA724)]	AT24C04A@SOIC8
[(SA602A)]	
AT24C04A@TSSOP8 [(SA026)]	
AT24C08	
AT24C08@MAP8 [(SA724)]	AT24C08@SOIC8
[(SA602A)]	
AT24C08@TSSOP8 [(SA026)]	

AT24C08A

AT24C08A@MAP8 [(SA724)]

[(SA602A)]

AT24C08A@TSSOP8 [(SA026)]

AT24C1024

AT24C1024@LAP8 [(SA724)]

[(SA684)]

AT24C1024@SOIC8 [(SA023A)]

(1.8V)

AT24C1024B(1.8V)@LAP8 [(SA724)]

[(SA684)]

AT24C1024B(1.8V)@SOIC8 [(SA023A)]

AT24C1024B(1.8V)@TSSOP8 [(SA026)]

AT24C1024B(2.5V)

[(SA724)]

AT24C1024B(2.5V)@SAP8 [(SA684)]

AT24C1024B(2.5V)@SOIC8 [(SA023A)]

AT24C1024B(2.5V)@TSSOP8 [(SA026)]

AT24C11

[(SA602A)]

AT24C11@TSSOP8 [(SA026)]

(1.8V)

AT24C128(1.8V)@MAP8 [(SA724)]

[(SA683)]

AT24C128(1.8V)@SOIC8 [(SA602A)]

[(SA026)]

AT24C128(2.7V)

[(SA724)]

AT24C128(2.7V)@SAP8 [(SA683)]

[(SA602A)]

AT24C128(2.7V)@TSSOP8 [(SA026)]

AT24C128B

AT24C128B@MAP8 [(SA724)]

[(SA683)]

AT24C128B@SOIC8 [(SA602A)]

[(SA026)]

AT24C16

[(SA602A)]

AT24C16@TSSOP8 [(SA026)]

AT24C164

AT24C164@SOIC8 [(SA602A)]

AT24C16A

AT24C16A@MAP8 [(SA724)]

AT24C08A@SOIC8

AT24C1024@SAP8

AT24C1024B

AT24C1024B(1.8V)@SAP8

AT24C1024B(2.5V)@LAP8

AT24C11@SOIC8

AT24C128

AT24C128(1.8V)@SAP8

AT24C128(1.8V)@TSSOP8

AT24C128(2.7V)@MAP8

AT24C128(2.7V)@SOIC8

AT24C128B@SAP8

AT24C128B@TSSOP8

AT24C16@SOIC8

AT24C16A@SOIC8

[ (SA602A) ]	
AT24C16A@TSSOP8 [ (SA026) ]	
AT24C16B	
AT24C16B@MAP8 [ (SA724) ]	AT24C16B@SOIC8
[ (SA602A) ]	
AT24C16B@TSSOP8 [ (SA026) ]	
AT24C21	
AT24C21@SOIC8 [ (SA602A) ]	AT24C256
(1.8V)	
AT24C256(1.8V)@MAP8 [ (SA724) ]	AT24C256(1.8V)@SAP8
[ (SA683) ]	
AT24C256(1.8V)@SOIC8 [ (SA602A) ]	AT24C256(1.8V)@TSSOP8
[ (SA026) ]	
AT24C256(2.7V)	
[ (SA724) ]	AT24C256(2.7V)@MAP8
AT24C256(2.7V)@SAP8 [ (SA683) ]	AT24C256(2.7V)@SOIC8
[ (SA602A) ]	
AT24C256(2.7V)@TSSOP8 [ (SA026) ]	
AT24C256B	
AT24C256B@MAP8 [ (SA724) ]	AT24C256B@SAP8
[ (SA683) ]	
AT24C256B@SOIC8 [ (SA602A) ]	AT24C256B@TSSOP8
[ (SA026) ]	
AT24C32	
[ (SA602A) ]	AT24C32@SOIC8
AT24C32@TSSOP8 [ (SA026) ]	
AT24C32A	
AT24C32A@MAP8 [ (SA724) ]	AT24C32A@SOIC8
[ (SA602A) ]	
AT24C32A@TSSOP8 [ (SA026) ]	
AT24C32C	
AT24C32C@dBGA8 [ (BBBB) ]	AT24C32C@MAP8
[ (SA724) ]	
AT24C32C@SAP8 [ (SA683) ]	AT24C32C@SOIC8
[ (SA602A) ]	
AT24C32C@TSSOP8 [ (SA026) ]	AT24C512
(1.8V)	
AT24C512(1.8V)@LAP8 [ (SA684) ]	AT24C512(1.8V)@SAP8
[ (SA683) ]	
AT24C512(1.8V)@SOIC8 [ (SA602A) ]	AT24C512(1.8V)@TSSOP8
[ (SA026) ]	
AT24C512(2.7V)	
[ (SA684) ]	AT24C512(2.7V)@LAP8

AT24C512(2.7V)@SAP8 [(SA683)]	AT24C512(2.7V)@SOIC8
[(SA602A)]	
AT24C512(2.7V)@TSSOP8 [(SA026)]	
AT24C512B	
AT24C512B@LAP8 [(SA684)]	AT24C512B@SAP8
[(SA683)]	
AT24C512B@SOIC8 [(SA602A)]	AT24C512B@TSSOP8
[(SA026)]	
AT24C64	AT24C64@SOIC8
[(SA602A)]	
AT24C64@TSSOP8 [(SA026)]	
AT24C64A	
AT24C64A@MAP8 [(SA724)]	AT24C64A@SOIC8
[(SA602A)]	
AT24C64A@TSSOP8 [(SA026)]	
AT24C64B	
AT24C64B@SOIC8 [(SA602A)]	AT24C64B@TSSOP8
[(SA026)]	
AT24C64C	AT24C64C@dBGA8
[(BBBB)]	
AT24C64C@MAP8 [(SA724)]	AT24C64C@SAP8
[(SA683)]	
AT24C64C@SOIC8 [(SA602A)]	AT24C64C@TSSOP8
[(SA026)]	
AT24CS128	AT24CS128@SOIC8
[(SA602A)]	
AT24HC02B	AT24HC02B@SOIC8
[(SA602A)]	
AT24HC02B@TSSOP8 [(SA026)]	AT24RF08AN@SOIC8
[(SA602A)]	
AT24RF08AT@TSSOP14 [(SA026)]	AT24RF08BN@SOIC8
[(SA602A)]	
AT24RF08BT@TSSOP14 [(SA026)]	AT24RF08CN@SOIC8
[(SA602A)]	
AT24RF08CT@TSSOP14 [(SA026)]	
AT25010	
AT25010@SOIC8 [(SA602A)]	
AT25010A	
AT25010A@SOIC8 [(SA602A)]	AT25010A@TSSOP8
[(SA026)]	
AT25020	AT25020@SOIC8
[(SA602A)]	
AT25020A	AT25020A@SOIC8

[ (SA602A) ]  
AT25020A@TSSOP8 [ (SA026) ]  
AT25040  
AT25040 (ISP) [ ISP-HEADER01 ] AT25040@SOIC8  
[ (SA602A) ]  
AT25040@SOIC8 (ISP) [ ISP-HEADER01 ]  
AT25040A AT25040A (ISP) [ ISP-  
HEADER01 ]  
AT25040A@SOIC8 [ (SA602A) ]  
AT25040A@SOIC8 (ISP) [ ISP-HEADER01 ]  
AT25080 AT25080@SOIC8  
[ (SA602A) ]  
AT25080@TSSOP14 [ (SA026) ] AT25080@TSSOP20  
[ (SA026) ]  
AT25080A AT25080A@SOIC8  
[ (SA602A) ]  
AT25080A@TSSOP14 [ (SA026) ]  
AT25080B  
AT25080B@dBGA8 [ (BBBB) ] AT25080B@MAP8  
[ (SA724) ]  
AT25080B@SOIC8 [ (SA602A) ] AT25080B@TSSOP8  
[ (SA026) ]  
AT25128 AT25128@SOIC16  
[ (SA602) ]  
AT25128@SOIC8 [ (SA602A) ] AT25128@TSSOP14  
[ (SA026) ]  
AT25128@TSSOP20 [ (SA026) ]  
AT25128A  
AT25128A@dBGA8 [ (BBBB) ] AT25128A@SAP8  
[ (SA683) ]  
AT25128A@SOIC8 (4.0) [ (SA602A) ] AT25128A@SOIC8 (5.4)  
[ (SA605A) ]  
AT25128A@TSSOP14 [ (SA026) ] AT25128A@TSSOP8  
[ (SA026) ]  
AT25160 AT25160@SOIC8  
[ (SA602A) ]  
AT25160@TSSOP14 [ (SA026) ] AT25160@TSSOP20  
[ (SA026) ]  
AT25160A AT25160A@SOIC8  
[ (SA602A) ]  
AT25160A@TSSOP14 [ (SA026) ]  
AT25160B  
AT25160B@dBGA8 [ (BBBB) ] AT25160B@MAP8

[ (SA724) ]	
AT25160B@SOIC8 [ (SA602A) ]	AT25160B@TSSOP8
[ (SA026) ]	
AT25256	AT25256@SOIC16
[ (SA602) ]	
AT25256@SOIC8 [ (SA602A) ]	AT25256@TSSOP14
[ (SA026) ]	
AT25256@TSSOP20 [ (SA026) ]	
AT25256A	
AT25256A@dBGA8 [ (BBBB) ]	AT25256A@SAP8
[ (SA683) ]	
AT25256A@SOIC8(4.0) [ (SA602A) ]	AT25256A@SOIC8(5.4)
[ (SA605A) ]	
AT25256A@TSSOP14 [ (SA026) ]	AT25256A@TSSOP8
[ (SA026) ]	
AT25320	AT25320@SOIC8
[ (SA602A) ]	
AT25320@TSSOP14 [ (SA026) ]	AT25320@TSSOP20
[ (SA026) ]	
AT25320A	AT25320A@SOIC8
[ (SA602A) ]	
AT25320A@TSSOP14 [ (SA026) ]	
AT25320B	
AT25320B@dBGA8 [ (BBBB) ]	AT25320B@MAP8
[ (SA724) ]	
AT25320B@SOIC8 [ (SA602A) ]	AT25320B@TSSOP8
[ (SA026) ]	
AT25640	AT25640@SOIC8
[ (SA602A) ]	
AT25640@TSSOP14 [ (SA026) ]	AT25640@TSSOP20
[ (SA026) ]	
AT25640A	AT25640A@SOIC8
[ (SA602A) ]	
AT25640A@TSSOP14 [ (SA026) ]	
AT25640B	
AT25640B@dBGA8 [ (BBBB) ]	AT25640B@MAP8
[ (SA724) ]	
AT25640B@SOIC8 [ (SA602A) ]	AT25640B@TSSOP8
[ (SA026) ]	
AT25DF021@SOIC8 [ (SA602A) ]	AT25DF021@UDFN8
[ (SA683) ]	
AT25DF041A@MLF8 [ (SA683) ]	AT25DF041A@SOIC8(4.0)
[ (SA602A) ]	

AT25DF041A@SOIC8(5.4) [(SA605A)] [(SA602A)]	AT25DF081@SOIC8
AT25DF081@UDFN8 [(SA683)] [(SA683)]	AT25DF161@MLF8
AT25DF161@SOIC8(4.0) [(SA602A)] [(SA605A)]	AT25DF161@SOIC8(5.4)
AT25DF321@SOIC16 [(SA404)] [(SA605A)]	AT25DF321@SOIC8
AT25DF641@SOIC16 [(SA404)] [(SA683)]	AT25DF641@VDFN8
AT25F1024 [(SA605A)]	AT25F1024(W)@SOIC8
AT25F1024(W)@VQFPN8 [(SA684)] [(SA602A)]	AT25F1024@SOIC8
AT25F1024@VQFPN8 [(SA683)]	
AT25F1024A	
AT25F1024A(W)@SOIC8 [(SA605A)] [(SA684)]	AT25F1024A(W)@VQFPN8
AT25F1024A@SOIC8 [(SA602A)] [(SA683)]	AT25F1024A@VQFPN8
AT25F2048 [(SA605A)]	AT25F2048(W)@SOIC8
AT25F2048(W)@VQFPN8 [(SA684)] [(SA602A)]	AT25F2048@SOIC8
AT25F2048@VQFPN8 [(SA683)]	
AT25F2048A	
AT25F2048A(W)@SOIC8 [(SA605A)] [(SA684)]	AT25F2048A(W)@VQFPN8
AT25F2048A@SOIC8 [(SA602A)] [(SA683)]	AT25F2048A@VQFPN8
AT25F4096 [(SA605A)]	AT25F4096(W)@SOIC8
AT25F4096(W)@VQFPN8 [(SA684)] [(SA602A)]	AT25F4096@SOIC8
AT25F4096@VQFPN8 [(SA683)]	
AT25F4096A	
AT25F4096A(W)@SOIC8 [(SA605A)] [(SA684)]	AT25F4096A(W)@VQFPN8
AT25F4096A@SOIC8 [(SA602A)] [(SA683)]	AT25F4096A@VQFPN8
AT25F512 [(SA605A)]	AT25F512(W)@SOIC8
AT25F512(W)@VQFPN8 [(SA684)]	AT25F512@SOIC8



[ (SA602A) ]	
AT25F512@VQFPN8 [ (SA683) ]	
AT25F512A	
AT25F512A(W)@SOIC8 [ (SA605A) ]	AT25F512A(W)@VQFPN8
[ (SA684) ]	
AT25F512A@SOIC8 [ (SA602A) ]	AT25F512A@VQFPN8
[ (SA683) ]	
AT25FS010@SAP8 [ (SA683) ]	AT25FS010@SOIC8
[ (SA602A) ]	
AT25FS040@SAP8 [ (SA683) ]	AT25FS040@SOIC8
[ (SA602A) ]	
AT25HP256	AT25HP256(W)@VQFPN8
[ (SA684) ]	
AT25HP256@SOIC16 [ (SA404) ]	AT25HP256@SOIC8
[ (SA602A) ]	
AT25HP256@VQFPN8 [ (SA683) ]	
AT25HP512	
AT25HP512(W)@VQFPN8 [ (SA684) ]	AT25HP512@SOIC16
[ (SA404) ]	
AT25HP512@SOIC8 [ (SA602A) ]	AT25HP512@VQFPN8
[ (SA683) ]	
AT25P1024@SOIC20 [ (SA404) ]	AT25P1024@VQFPN8
[ (SA684) ]	
AT26DF041@MLF8 [ (SA683) ]	AT26DF041@SOIC8(4.0)
[ (SA602A) ]	
AT26DF041@SOIC8(5.4) [ (SA605A) ]	AT26DF081@SOIC8(4.0)
[ (SA602A) ]	
AT26DF081@SOIC8(5.4) [ (SA605A) ]	AT26DF081A@SOIC8(4.0)
[ (SA602A) ]	
AT26DF081A@SOIC8(5.4) [ (SA605A) ]	AT26DF161@MLF8
[ (SA683) ]	
AT26DF161@SOIC8 [ (SA605A) ]	AT26DF161A@MLF8
[ (SA683) ]	
AT26DF161A@SOIC8 [ (SA605A) ]	AT26DF321@MLF8(5*6mm)
[ (SA683) ]	
AT26DF321@MLF8(6*8mm) [ (SA684) ]	AT26DF321@SOIC16
[ (SA404) ]	
AT26DF321@SOIC8 [ (SA605A) ]	AT26F004@MLF8
[ (SA683) ]	
AT26F004@SOIC8(4.0) [ (SA602A) ]	AT26F004@SOIC8(5.4)
[ (SA605A) ]	
AT27011	AT27011@PLCC32
[ (SA015A1T) ]	

AT27256	
AT2732A	
AT27BV010	AT27BV010@PLCC32
[(SA015A1T)]	
AT27BV010@TSOP32	[(SA620)]
AT27BV020	
AT27BV020@PLCC32	[(SA015A1T)]
[(SA620)]	AT27BV020@TSOP32
AT27BV040	
[(SA015A1T)]	AT27BV040@PLCC32
AT27BV040@TSOP32	[(SA620)]
[(SA244)]	AT27BV1024@PLCC44
AT27BV1024@TSOP40	[(SA623)]
AT27BV256	
AT27BV256@PLCC32	[(SA015A1T)]
[(SA430T)]	AT27BV256@TSOP28
AT27BV4096	
[(SA244)]	AT27BV4096@PLCC44
AT27BV4096@TSOP40	[(SA623)]
AT27BV512	
AT27BV512@PLCC32	[(SA015A1T)]
[(SA630)]	AT27BV512@SOIC28
AT27BV512@TSOP28	[(SA430T)]
[(SA404)]	AT27BV520@SOIC20
AT27BV520@TSOP28	[(SA430T)]
[(SA026)]	AT27BV520@TSSOP20
AT27C010	
[(SA015A1T)]	AT27C010@PLCC32
AT27C010@TSOP32	[(SA410T)]
AT27C010L	
AT27C010L@PLCC32	[(SA015A1T)]
[(SA410T)]	AT27C010L@TSOP32
AT27C020	
[(SA015A1T)]	AT27C020@PLCC32
AT27C020@TSOP32	[(SA410T)]
AT27C040	
AT27C040@PLCC32	[(SA015A1T)]
[(SA410T)]	AT27C040@TSOP32
AT27C080	
[(SA015A1T)]	AT27C080@PLCC32
AT27C080@TSOP32	[(SA410T)]
AT27C1024	
AT27C1024@PLCC44	[(SA244)]
	AT27C1024@TSOP40

[ (SA623) ]	
AT27C1024L	AT27C1024L@PLCC44
[ (SA244) ]	
AT27C128	AT27C128@PLCC32
[ (SA015A1T) ]	
AT27C2048	AT27C2048@PLCC44
[ (SA244) ]	
AT27C2048@TSOP40 [ (SA623) ]	
AT27C256	
AT27C256@PLCC32 [ (SA015A1T) ]	
AT27C256R	
AT27C256R@PLCC32 [ (SA015A1T) ]	AT27C256R@SOIC28
[ (SA630) ]	
AT27C256R@TSOP28 [ (SA430T) ]	
AT27C4096	
AT27C4096@PLCC44 [ (SA244) ]	AT27C4096@TSOP40
[ (SA623) ]	
AT27C512	AT27C512@PLCC32
[ (SA015A1T) ]	
AT27C512R	AT27C512R@PLCC32
[ (SA015A1T) ]	
AT27C512R@SOIC28 [ (SA630) ]	AT27C512R@TSOP28
[ (SA430T) ]	
AT27C513	AT27C513@PLCC32
[ (SA015A1T) ]	
AT27C513@SOIC28 [ (SA630) ]	
AT27C513R	
AT27C513R@PLCC32 [ (SA015A1T) ]	AT27C513R@SOIC28
[ (SA630) ]	
AT27C515	AT27C515@PLCC32
[ (SA015A1T) ]	
AT27C516	AT27C516@PLCC44
[ (SA244) ]	
AT27C516@TSOP40 [ (SA623) ]	AT27C520@SOIC20
[ (SA404) ]	
AT27C520@TSOP28 [ (SA430T) ]	AT27C520@TSSOP20
[ (SA026) ]	
AT27C64	
AT27C800	
AT27C800@PLCC44 [ (SA244) ]	AT27C800@PSOP44
[ (SA638) ]	
AT27HC1024	AT27HC1024@PLCC44
[ (SA244) ]	

AT27HC256 [ (SA015A1T) ]	AT27HC256@PLCC32
AT27HC256L [ (SA015A1T) ]	AT27HC256L@PLCC32
AT27HC256R [ (SA015A1T) ]	AT27HC256R@PLCC32
AT27HC256RL [ (SA015A1T) ]	AT27HC256RL@PLCC32
AT27HC64 [ (SA015A1T) ]	AT27HC64@PLCC32
AT27HC641 [ (SA008A) ]	AT27HC641@PLCC28
AT27HC641R [ (SA008A) ]	AT27HC641R@PLCC28
AT27HC642 [ (SA008A) ]	AT27HC642@PLCC28
AT27HC642R [ (SA008A) ]	AT27HC642R@PLCC28
AT27HC64L [ (SA015A1T) ]	AT27HC64L@PLCC32
AT27LV010 [ (SA015A1T) ]	AT27LV010@PLCC32
AT27LV010@TSOP32 [ (SA620) ]	
AT27LV010A [ (SA620) ]	
AT27LV010A@PLCC32 [ (SA015A1T) ]	AT27LV010A@TSOP32
AT27LV020A [ (SA015A1T) ]	
AT27LV020A@TSOP32 [ (SA620) ]	AT27LV020A@PLCC32
AT27LV040 [ (SA620) ]	
AT27LV040@PLCC32 [ (SA015A1T) ]	AT27LV040@TSOP32
AT27LV040A [ (SA015A1T) ]	
AT27LV040A@TSOP32 [ (SA620) ]	AT27LV040A@PLCC32
AT27LV1024 [ (SA244) ]	
AT27LV256A [ (SA630) ]	
AT27LV256A@PLCC32 [ (SA015A1T) ]	AT27LV256A@SOIC28
AT27LV256A@TSOP28 [ (SA430T) ]	
AT27LV256R [ (SA015A1T) ]	
AT27LV256R@PLCC32 [ (SA015A1T) ]	AT27LV256R@SOIC28

[ ( SA630 ) ]  
 AT27LV256R@TSOP28 [ ( SA430T ) ]  
 AT27LV4096  
 AT27LV4096@PLCC44 [ ( SA244 ) ]  
 AT27LV512A  
 AT27LV512A@PLCC32 [ ( SA015A1T ) ] AT27LV512A@SOIC28  
 [ ( SA630 ) ]  
 AT27LV512A@TSOP28 [ ( SA430T ) ]  
 AT27LV512R  
 AT27LV512R@PLCC32 [ ( SA015A1T ) ] AT27LV512R@TSOP28  
 [ ( SA430T ) ]  
 AT27LV520@SOIC20 [ ( SA404 ) ] AT27LV520@TSOP28  
 [ ( SA430T ) ]  
 AT27LV520@TSSOP20 [ ( SA026 ) ]  
 AT27LV800  
 AT27LV800@PSOP44 [ ( SA638 ) ]  
 AT28BV16  
 AT28BV16@PLCC32 [ ( SA015A1T ) ] AT28BV16@SOIC24  
 [ ( SA404 ) ]  
 AT28BV16@TSOP28 [ ( SA430T ) ]  
 AT28BV256  
 AT28BV256@PLCC32 [ ( SA015A1T ) ] AT28BV256@SOIC28  
 [ ( SA404 ) ]  
 AT28BV256@TSOP28 [ ( SA430T ) ]  
 AT28BV64  
 AT28BV64@PLCC32 [ ( SA015A1T ) ] AT28BV64@SOIC28  
 [ ( SA404 ) ]  
 AT28BV64@TSOP28 [ ( SA430T ) ]  
 AT28BV64B  
 AT28BV64B@PLCC32 [ ( SA015A1T ) ] AT28BV64B@SOIC28  
 [ ( SA404 ) ]  
 AT28BV64B@TSOP28 [ ( SA430T ) ]  
 AT28C010  
 AT28C010@PLCC32 [ ( SA015A1T ) ] AT28C010@PLCC44  
 [ ( SA244 ) ]  
 AT28C010@TSOP32 [ ( SA410T ) ]  
 AT28C010E  
 AT28C010E@PLCC32 [ ( SA015A1T ) ] AT28C010E@PLCC44  
 [ ( SA244 ) ]  
 AT28C010E@TSOP32 [ ( SA410T ) ]  
 AT28C04  
 AT28C04@PLCC32 [ ( SA015A1T ) ]  
 AT28C040

AT28C040@PLCC32 [(SA015A1T)]	
AT28C04E	
AT28C04E@PLCC32 [(SA015A1T)]	
AT28C04F	
AT28C04F@PLCC32 [(SA015A1T)]	
AT28C16	
AT28C16@PLCC32 [(SA015A1T)]	AT28C16@SOIC24
[(SA404)]	
AT28C16@TSOP28 [(SA430T)]	
AT28C16E	
AT28C16E@PLCC32 [(SA015A1T)]	
AT28C16F	
AT28C16F@PLCC32 [(SA015A1T)]	
AT28C17	
AT28C17@PLCC32 [(SA015A1T)]	AT28C17@SOIC28
[(SA404)]	
AT28C17E	AT28C17E@PLCC32
[(SA015A1T)]	
AT28C17F	AT28C17F@PLCC32
[(SA015A1T)]	
AT28C256	AT28C256@PLCC32
[(SA015A1T)]	
AT28C256@SOIC28 [(SA404)]	AT28C256@TSOP28
[(SA430T)]	
AT28C256E	AT28C256E@PLCC32
[(SA015A1T)]	
AT28C256F	AT28C256F@PLCC32
[(SA015A1T)]	
AT28C64	AT28C64@PLCC32
[(SA015A1T)]	
AT28C64@SOIC28 [(SA404)]	AT28C64@TSOP28
[(SA430T)]	
AT28C64B	AT28C64B@PLCC32
[(SA015A1T)]	
AT28C64B@SOIC28 [(SA404)]	AT28C64B@TSOP28
[(SA430T)]	
AT28C64E	AT28C64E@PLCC32
[(SA015A1T)]	
AT28C64E@TSOP28 [(SA430T)]	
AT28C64F	
AT28C64F@PLCC32 [(SA015A1T)]	AT28C64F@TSOP28
[(SA430T)]	
AT28C64X	AT28C64X@PLCC32

[ (SA015A1T) ]	
AT28C64X@SOIC28 [ (SA404) ]	AT28C64X@TSOP28
[ (SA430T) ]	
AT28HC04	
AT28HC16	
AT28HC16L	
AT28HC191	
AT28HC191L	
AT28HC256	
AT28HC256@PLCC32 [ (SA015A1T) ]	AT28HC256@TSOP28
[ (SA430T) ]	
AT28HC256E	AT28HC256E@PLCC32
[ (SA015A1T) ]	
AT28HC256F	AT28HC256F@PLCC32
[ (SA015A1T) ]	
AT28HC256L	AT28HC256L@PLCC32
[ (SA015A1T) ]	
AT28HC256LE	AT28HC256LE@PLCC32
[ (SA015A1T) ]	
AT28HC291	AT28HC291@PLCC28
[ (SA008A) ]	
AT28HC291L	AT28HC291L@PLCC28
[ (SA008A) ]	
AT28HC64	AT28HC64@PLCC32
[ (SA015A1T) ]	
AT28HC64@TSOP28 [ (SA430T) ]	
AT28HC64B	
AT28HC64B@PLCC32 [ (SA015A1T) ]	AT28HC64B@SOIC28
[ (SA404) ]	
AT28HC64B@TSOP28 [ (SA430T) ]	
AT28HC64BF	
AT28HC64BF@PLCC32 [ (SA015A1T) ]	AT28HC64BF@SOIC28
[ (SA404) ]	
AT28HC64BF@TSOP28 [ (SA430T) ]	
AT28HC64L	
AT28HC64L@PLCC32 [ (SA015A1T) ]	AT28HC64L@TSOP28
[ (SA430T) ]	
AT28LV010	AT28LV010@PLCC32
[ (SA015A1T) ]	
AT28LV010@TSOP32 [ (SA410T) ]	
AT28LV256	
AT28LV256@PLCC32 [ (SA015A1T) ]	AT28LV256@TSOP28
[ (SA430T) ]	

AT28LV64 [ (SA015A1T) ]	AT28LV64@PLCC32
AT28LV64B [ (SA015A1T) ]	AT28LV64B@PLCC32
AT28LV64B@SOIC28 [ (SA404) ] [ (SA430T) ]	AT28LV64B@TSOP28
AT28MC010 [ (SA015A1T) ]	AT28MC010@PLCC32
AT28MC010@PLCC44 [ (SA244) ] [ (SA410T) ]	AT28MC010@TSOP32
AT28MC020 [ (SA015A1T) ]	AT28MC020@PLCC32
AT28MC020@PLCC44 [ (SA244) ] [ (SA410T) ]	AT28MC020@TSOP32
AT28MC040 [ (SA015A1T) ]	AT28MC040@PLCC32
AT28MC040@PLCC44 [ (SA244) ] [ (SA410T) ]	AT28MC040@TSOP32
AT28PC64 [ (SA015A1T) ]	AT28PC64@PLCC32
AT28PC64@TSOP28 [ (SA430T) ]	
AT28PC64E [ (SA015A1T) ]	AT28PC64E@TSOP28
AT28PC64E@PLCC32 [ (SA015A1T) ] [ (SA430T) ]	
AT29BV010A@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT29BV010A@TSOP32
AT29BV020@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT29BV020@TSOP32
AT29BV040A@TSOP32 [ (SA410T) ]	
AT29C010 [ (SA015A1T) ]	AT29C010@TSOP32
AT29C010@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	
AT29C010A [ (SA015A1T) ]	AT29C010A@PLCC32
AT29C010A@TSOP32 [ (SA410T) ]	
AT29C020 [ (SA015A1T) ]	AT29C020@TSOP32
AT29C020@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	
AT29C040 [ (SA015A1T) ]	AT29C040@PLCC32
AT29C040@TSOP32 [ (SA410T) ]	
AT29C040A [ (SA015A1T) ]	AT29C040A@TSOP32
AT29C040A@PLCC32 [ (SA015A1T) ]	



[ (SA410T) ]	
AT29C1024@PLCC44 [ (SA244) ]	AT29C1024@TSOP48 [ (SA247-
B005) ]	
AT29C256	AT29C256@PLCC32
[ (SA015A1T) ]	
AT29C256@TSOP28 [ (SA430T) ]	
AT29C257	
AT29C257@PLCC32 [ (SA015A1T) ]	
AT29C512	
AT29C512@PLCC32 [ (SA015A1T) ]	AT29C512@TSOP32
[ (SA410T) ]	
AT29LV010	AT29LV010@PLCC32
[ (SA015A1T) ]	
AT29LV010@TSOP32 [ (SA410T) ]	AT29LV010A@PLCC32
[ (SA015A1T) ]	
AT29LV010A@TSOP32 [ (SA410T) ]	
AT29LV020	
AT29LV020@PLCC32 [ (SA015A1T) ]	AT29LV020@TSOP32
[ (SA410T) ]	
AT29LV040@TSOP32 [ (SA410T) ]	
AT29LV040A	
AT29LV040A@PLCC32 [ (SA015A1T) ]	AT29LV040A@TSOP32
[ (SA410T) ]	
AT29LV1024@PLCC44 [ (SA244) ]	AT29LV1024@TSOP48 [ (SA247-
B005) ]	
AT29LV256	AT29LV256@PLCC32
[ (SA015A1T) ]	
AT29LV256@TSOP28 [ (SA430T) ]	
AT29LV512	
AT29LV512@PLCC32 [ (SA015A1T) ]	AT29LV512@TSOP32
[ (SA410T) ]	
AT32C16	AT32C16@PLCC44
[ (SA244) ]	
AT34C02	AT34C02@SOIC8
[ (SA602A) ]	
AT34C02@TSSOP8 [ (SA026) ]	
AT34C02B	
AT34C02B@SOIC8 [ (SA602A) ]	AT34C02B@TSSOP8
[ (SA026) ]	
AT34C02C	AT34C02C@dBGA8
[ (BBBB) ]	
AT34C02C@MAP8 [ (SA724) ]	AT34C02C@SOIC8
[ (SA602A) ]	

AT34C02C@TSSOP8 [(SA026)]  
AT45BCM021D(page256)@SOIC8 [(SA605A)]  
AT45BCM021D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45BCM021D(page264)@SOIC8 [(SA605A)]  
AT45BCM021D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45D011@PLCC32 [(SA015A1T)] AT45D011@SOIC8  
[(SA605A)]  
AT45D011@TSSOP14 [(SA026)] AT45D021@PLCC32  
[(SA015A1T)]  
AT45D021@SOIC28 [(SA630)] AT45D021@TSOP28  
[(SA430T)]  
AT45D041@PLCC32 [(SA015A1T)] AT45D041@SOIC28  
[(SA630)]  
AT45D041@TSOP28 [(SA430T)] AT45D081@SOIC28  
[(SA630)]  
AT45D081@TSOP32 [(SA410T)] AT45D161@PLCC32  
[(SA015A1T)]  
AT45D161@SOIC28 [(SA630)] AT45D161@TSOP28  
[(SA430T)]  
AT45DB011@PLCC32 [(SA015A1T)] AT45DB011@SOIC8  
[(SA605A)]  
AT45DB011@TSSOP14 [(SA026)] AT45DB011B@PLCC32  
[(SA015A1T)]  
AT45DB011B@PLCC32(ISP) [ISP-HEADER01]  
AT45DB011B@SOIC8 [(SA605A)]  
AT45DB011B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB011B@TSSOP14 [(SA026)]  
AT45DB011B@TSSOP14(ISP) [ISP-HEADER01]  
AT45DB011D(page264)@QFN8 [(SA683)]  
AT45DB011D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB011D(page264)@SOIC8 [(SA023A)]  
AT45DB011D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB021@PLCC32 [(SA015A1T)] AT45DB021@SOIC28  
[(SA630)]  
AT45DB021@TSOP28 [(SA430T)] AT45DB021A@PLCC32  
[(SA015A1T)]  
AT45DB021A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB021A@SOIC28 [(SA630)]  
AT45DB021A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB021A@TSOP28 [(SA430T)]  
AT45DB021A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB021B@CBGA9 [(SA677A-B089A-K080F001N)]  
AT45DB021B@CBGA9(ISP) [ISP-HEADER01]

AT45DB021B@SOIC28 [(SA630)]  
AT45DB021B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB021B@SOIC8 [(SA023A)]  
AT45DB021B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB021B@TSOP28 [(SA430T)]  
AT45DB021B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB021D6(page264)@CASON8 [(SA683)]  
AT45DB021D6(page264)@CASON8(ISP) [ISP-HEADER01]  
AT45DB021D6(page264)@SOIC8 [(SA023A)]  
AT45DB021D6(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041@PLCC32 [(SA015A1T)] AT45DB041@SOIC28  
[(SA630)]  
AT45DB041@TSOP28 [(SA430T)] AT45DB041A@PLCC32  
[(SA015A1T)]  
AT45DB041A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB041A@SOIC28 [(SA630)]  
AT45DB041A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB041A@TSOP28 [(SA430T)]  
AT45DB041A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB041B@CASON8 [(SA684)] AT45DB041B@CASON8(ISP)  
[(SA684)]  
AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB041B@CBGA14(ISP) [ISP-HEADER01]  
AT45DB041B@SOIC28 [(SA630)]  
AT45DB041B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB041B@SOIC8 [(SA605A)]  
AT45DB041B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041B@TSOP28 [(SA430T)]  
AT45DB041B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB041D(page256)@QFN8 [(SA683)]  
AT45DB041D(page256)@QFN8(ISP) [ISP-HEADER01]  
AT45DB041D(page256)@SOIC8 [(SA605A)]  
AT45DB041D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041D(page264)@QFN8 [(SA683)]  
AT45DB041D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB041D(page264)@SOIC8 [(SA605A)]  
AT45DB041D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081@SOIC28 [(SA630)] AT45DB081@TSOP32  
[(SA410T)]  
AT45DB081A@PLCC32 [(SA015A1T)]  
AT45DB081A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB081A@SOIC28 [(SA630)]  
AT45DB081A@SOIC28(ISP) [ISP-HEADER01]

AT45DB081A@TSOP28 [(SA430T)]  
AT45DB081A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8(ISP)  
[(SA684)]  
AT45DB081B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB081B@CBGA14(ISP) [ISP-HEADER01]  
AT45DB081B@SOIC28 [(SA630)]  
AT45DB081B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB081B@SOIC8 [(SA605A)]  
AT45DB081B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081B@TSOP28 [(SA430T)]  
AT45DB081B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB081D(page256)@MLF8 [(SA683)]  
AT45DB081D(page256)@QFN8(ISP) [ISP-HEADER01]  
AT45DB081D(page256)@SOIC8 [(SA023A)]  
AT45DB081D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081D(page264)@MLF8 [(SA683)]  
AT45DB081D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB081D(page264)@SOIC8 [(SA023A)]  
AT45DB081D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB161@PLCC32 [(SA015A1T)] AT45DB161@SOIC28  
[(SA630)]  
AT45DB161@TSOP28 [(SA430T)]  
AT45DB161B@CASON8(ISP) [ISP-HEADER01]  
AT45DB161B@CASON8 [(SA684)] AT45DB161B@SOIC28  
[(SA630)]  
AT45DB161B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB161B@TSOP28 [(SA430T)]  
AT45DB161B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB161D(page512)@QFN8 [(SA683)]  
AT45DB161D(page512)@QFN8(ISP) [ISP-HEADER01]  
AT45DB161D(page512)@SOIC8 [(SA605A)]  
AT45DB161D(page512)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB161D(page512)@TSOP28 [(SA430T)]  
AT45DB161D(page512)@TSOP28(ISP) [ISP-HEADER01]  
AT45DB161D(page528)@QFN8 [(SA683)]  
AT45DB161D(page528)@QFN8(ISP) [ISP-HEADER01]  
AT45DB161D(page528)@SOIC8 [(SA605A)]  
AT45DB161D(page528)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB161D(page528)@TSOP28 [(SA430T)]  
AT45DB161D(page528)@TSOP28(ISP) [ISP-HEADER01]  
AT45DB321@TSOP32 [(SA410T)] AT45DB321B@SOIC28  
[(SA630)]

AT45DB321B@SOIC28 (ISP) [ISP-HEADER01]  
AT45DB321B@TSOP32 [(SA410T)]  
AT45DB321B@TSOP32 (ISP) [ISP-HEADER01]  
AT45DB321C@CAS0N8 [(SA684)]  
AT45DB321C@CAS0N8 (ISP) [ISP-HEADER01]  
AT45DB321C@SOIC28 [(SA630)]  
AT45DB321C@SOIC28 (ISP) [ISP-HEADER01]  
AT45DB321C@TSOP28 [(SA430T)]  
AT45DB321C@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB321D(page512)@QFN8 [(SA683)]  
AT45DB321D(page512)@QFN8 (ISP) [ISP-HEADER01]  
AT45DB321D(page512)@SOIC8 [(SA023A)]  
AT45DB321D(page512)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB321D(page512)@TSOP28 [(SA430T)]  
AT45DB321D(page512)@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB321D(page528)@QFN8 [(SA683)]  
AT45DB321D(page528)@QFN8 (ISP) [ISP-HEADER01]  
AT45DB321D(page528)@SOIC8 [(SA023A)]  
AT45DB321D(page528)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB321D(page528)@TSOP28 [(SA430T)]  
AT45DB321D(page528)@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB642@TSOP40 [(SA409T)]  
AT45DB642@TSOP40 (ISP) [ISP-HEADER01]  
AT45DB642D(page1024)@CAS0N8 [(SA684)]  
AT45DB642D(page1024)@CAS0N8 (ISP) [(ISP-HEADER01)]  
AT45DB642D(page1024)@TSOP28 [(SA430)]  
AT45DB642D(page1024)@TSOP28 (ISP) [(ISP-HEADER01)]  
AT45DB642D(page1056)@CAS0N8 [(SA684)]  
AT45DB642D(page1056)@CAS0N8 (ISP) [(ISP-HEADER01)]  
AT45DB642D(page1056)@TSOP28 [(SA430)]  
AT45DB642D(page1056)@TSOP28 (ISP) [(ISP-HEADER01)]  
AT45DCB002 [(CARD005-B005)] AT45DCB002 (ISP) [ISP-  
HEADER01]  
AT45DCB004 [(CARD005-B005)] AT45DCB004 (ISP) [ISP-  
HEADER01]  
AT45DCB004C [(CARD005-B005)] AT45DCB004C (ISP) [ISP-  
HEADER01]  
AT45DCB008 [(CARD005-B005)] AT45DCB008 (ISP) [ISP-  
HEADER01]  
AT45DCB008D4(page1024) [(CARD005-B005)]  
AT45DCB008D4(page1024) (ISP) [(ISP-HEADER01)]  
AT45DCB008D6(page1056) [(CARD005-B005)]  
AT45DCB008D6(page1056) (ISP) [(ISP-HEADER01)]

AT49BV001 [(SA015A1T)]	AT49BV001@PLCC32
AT49BV001@TSOP32 [(SA410T)] [(SA620)]	AT49BV001@VSOP32
AT49BV001A [(SA015A1T)]	AT49BV001A@PLCC32
AT49BV001A@TSOP32 [(SA410T)] [(SA620)]	AT49BV001A@VSOP32
AT49BV001AN [(SA015A1T)]	AT49BV001AN@PLCC32
AT49BV001AN@TSOP32 [(SA410T)] [(SA620)]	AT49BV001AN@VSOP32
AT49BV001ANT [(SA015A1T)]	AT49BV001ANT@PLCC32
AT49BV001ANT@TSOP32 [(SA410T)] [(SA620)]	AT49BV001ANT@VSOP32
AT49BV001AT [(SA015A1T)]	AT49BV001AT@PLCC32
AT49BV001AT@TSOP32 [(SA410T)] [(SA620)]	AT49BV001AT@VSOP32
AT49BV001N [(SA015A1T)]	AT49BV001N@PLCC32
AT49BV001N@TSOP32 [(SA410T)] [(SA620)]	AT49BV001N@VSOP32
AT49BV001NT [(SA015A1T)]	AT49BV001NT@PLCC32
AT49BV001NT@TSOP32 [(SA410T)] [(SA620)]	AT49BV001NT@VSOP32
AT49BV001T [(SA015A1T)]	AT49BV001T@PLCC32
AT49BV001T@TSOP32 [(SA410T)] [(SA620)]	AT49BV001T@VSOP32
AT49BV002 [(SA015A1T)]	AT49BV002@PLCC32
AT49BV002@TSOP32 [(SA410T)] [(SA620)]	AT49BV002@VSOP32
AT49BV002A [(SA015A1T)]	AT49BV002A@PLCC32
AT49BV002A@TSOP32 [(SA410T)] [(SA620)]	AT49BV002A@VSOP32
AT49BV002AN [(SA015A1T)]	AT49BV002AN@PLCC32
AT49BV002AN@TSOP32 [(SA410T)]	AT49BV002AN@VSOP32

[ (SA620) ]	
AT49BV002ANT	AT49BV002ANT@PLCC32
[ (SA015A1T) ]	
AT49BV002ANT@TSOP32 [ (SA410T) ]	AT49BV002ANT@VSOP32
[ (SA620) ]	
AT49BV002AT	AT49BV002AT@PLCC32
[ (SA015A1T) ]	
AT49BV002AT@TSOP32 [ (SA410T) ]	AT49BV002AT@VSOP32
[ (SA620) ]	
AT49BV002N	AT49BV002N@PLCC32
[ (SA015A1T) ]	
AT49BV002N@TSOP32 [ (SA410T) ]	AT49BV002N@VSOP32
[ (SA620) ]	
AT49BV002NT	AT49BV002NT@PLCC32
[ (SA015A1T) ]	
AT49BV002NT@TSOP32 [ (SA410T) ]	AT49BV002NT@VSOP32
[ (SA620) ]	
AT49BV002T	AT49BV002T@PLCC32
[ (SA015A1T) ]	
AT49BV002T@TSOP32 [ (SA410T) ]	AT49BV002T@VSOP32
[ (SA620) ]	
AT49BV008@TSOP40 [ (SA409T) ]	AT49BV008A@TSOP40
[ (SA409T) ]	
AT49BV008A@uBGA48 [ (SA634) ]	AT49BV008AT@TSOP40
[ (SA409T) ]	
AT49BV008AT@uBGA48 [ (SA634) ]	
AT49BV010	
AT49BV010@PLCC32 [ (SA015A1T) ]	AT49BV010@TSOP32
[ (SA410T) ]	
AT49BV020	AT49BV020@PLCC32
[ (SA015A1T) ]	
AT49BV020@TSOP32 [ (SA410T) ]	
AT49BV040	
AT49BV040@PLCC32 [ (SA015A1T) ]	AT49BV040@TSOP32
[ (SA410T) ]	
AT49BV040A@PLCC32 [ (SA015A1T) ]	AT49BV040A@TSOP32
[ (SA410T) ]	
AT49BV040A@VSOP32 [ (SA620) ]	
AT49BV040B@PLCC32 [ (SA015A1T-B001) ]	
AT49BV040B@TSOP32 [ (SA410T-B003) ]	
AT49BV040B@VSOP32 [ (SA620-B005) ]	
AT49BV040T	
AT49BV040T@PLCC32 [ (SA015A1T) ]	AT49BV040T@TSOP32

[ (SA410T) ]  
AT49BV080@PSOP44 [ (SA638) ] AT49BV080@TSOP40  
[ (SA409T) ]  
AT49BV080T@PSOP44 [ (SA638) ] AT49BV080T@TSOP40  
[ (SA409T) ]  
AT49BV1024A@TSOP40 [ (SA623) ] AT49BV160@TSOP48 [ (SA247-B005) ]  
AT49BV160@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604@TSOP48 [ (SA247-B005) ]  
AT49BV1604@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604A@TSOP48 [ (SA247-B005) ]  
AT49BV1604A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604AT@TSOP48 [ (SA247-B005) ]  
AT49BV1604AT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604T@TSOP48 [ (SA247-B005) ]  
AT49BV1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160C@TSOP48 [ (SA247-B005) ]  
AT49BV160C@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160CT@TSOP48 [ (SA247-B005) ]  
AT49BV160CT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160D@TSOP48 [ (SA247-B005) ]  
AT49BV160DT@TSOP48 [ (SA247-B005) ]  
AT49BV160S@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV160ST@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV160T@TSOP48 [ (SA247-B005) ]  
AT49BV160T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV161@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV161@TSOP48 [ (SA247-B005) ]  
AT49BV1614@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614@TSOP48 [ (SA247-B005) ]  
AT49BV1614A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614A@TSOP48 [ (SA247-B005) ]  
AT49BV1614AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614AT@TSOP48 [ (SA247-B005) ]  
AT49BV1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614T@TSOP48 [ (SA247-B005) ]  
AT49BV1618@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1618@TSOP48 [ (SA247-B005) ]  
AT49BV1618T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1618T@TSOP48 [ (SA247-B005) ]  
AT49BV161T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV161T@TSOP48 [ (SA247-B005) ]  
AT49BV162A@CBGA48 [ (SA642F-B026A-T064F001) ]



AT49BV162A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV162AT@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV162AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163A@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163AT@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163D@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV2048@PSOP44 [ ( SA638 ) ]                    AT49BV2048@TSOP48 [ ( SA247-B005 ) ]  
AT49BV2048A@PSOP44 [ ( SA638 ) ]  
AT49BV2048A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV2048B@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320C@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320C@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320CT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320CT@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320D@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV320D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320DT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV320DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320S@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV320ST@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV320T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320T@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV321@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV321@TSOP48 [ ( SA247-B005 ) ]  
AT49BV3218@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV3218@TSOP48 [ ( SA247-B005 ) ]  
AT49BV3218T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV3218T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV321T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV321T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322A@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV322A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322AT@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV322AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322D@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]

AT49BV322D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322DT@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49BV322DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV4096@PSOP44 [ ( SA638 ) ] AT49BV4096@TSOP48 [ ( SA247-B005 ) ]  
AT49BV4096A@PSOP44 [ ( SA638 ) ]  
AT49BV4096A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV4096A@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV512 AT49BV512@PLCC32  
[ ( SA015A1T ) ]  
AT49BV512@TSOP32 [ ( SA410T ) ] AT49BV512@VSOP32  
[ ( SA620 ) ]  
AT49BV640D@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV640D@TSOP56 [ ( SA628-B131 ) ]  
AT49BV640DT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV640DT@TSOP56 [ ( SA628-B131 ) ]  
AT49BV640S@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV640ST@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV6416@TSOP48 [ ( SA247-B005 ) ]  
AT49BV6416T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV642D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV642DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8004@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV8004@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8004T@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV8004T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8011@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV8011@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8011T@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV8011T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV802A@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV802A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV802AT@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV802AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV802D@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV802D@TSOP48 [ ( SA247 ) ]  
AT49BV802DT@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV802DT@TSOP48 [ ( SA247 ) ] AT49BV8192@PSOP44  
[ ( SA638 ) ]  
AT49BV8192@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8192A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8192A@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV8192AT@TSOP48 [ ( SA247-B005 ) ]

AT49BV8192AT@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV8192T@PSOP44 [(SA638)]	
AT49BV8192T@TSOP48 [(SA247-B005)]	
AT49F001	AT49F001@PLCC32
[(SA015A1T)]	
AT49F001@TSOP32 [(SA410T)]	AT49F001@VSOP32
[(SA620)]	
AT49F001A	AT49F001A@PLCC32
[(SA015A1T)]	
AT49F001A@TSOP32 [(SA410T)]	AT49F001A@VSOP32
[(SA620)]	
AT49F001AN	AT49F001AN@PLCC32
[(SA015A1T)]	
AT49F001AN@TSOP32 [(SA410T)]	AT49F001AN@VSOP32
[(SA620)]	
AT49F001ANT	AT49F001ANT@PLCC32
[(SA015A1T)]	
AT49F001ANT@TSOP32 [(SA410T)]	AT49F001ANT@VSOP32
[(SA620)]	
AT49F001AT	AT49F001AT@PLCC32
[(SA015A1T)]	
AT49F001AT@TSOP32 [(SA410T)]	AT49F001AT@VSOP32
[(SA620)]	
AT49F001N	AT49F001N@PLCC32
[(SA015A1T)]	
AT49F001N@TSOP32 [(SA410T)]	AT49F001N@VSOP32
[(SA620)]	
AT49F001NT	AT49F001NT@PLCC32
[(SA015A1T)]	
AT49F001NT@TSOP32 [(SA410T)]	AT49F001NT@VSOP32
[(SA620)]	
AT49F001T	AT49F001T@PLCC32
[(SA015A1T)]	
AT49F001T@TSOP32 [(SA410T)]	AT49F001T@VSOP32
[(SA620)]	
AT49F002	AT49F002@PLCC32
[(SA015A1T)]	
AT49F002@TSOP32 [(SA410T)]	AT49F002@VSOP32
[(SA620)]	
AT49F002A	AT49F002A@PLCC32
[(SA015A1T)]	
AT49F002A@TSOP32 [(SA410T)]	AT49F002A@VSOP32
[(SA620)]	

AT49F002AN [(SA015A1T)]	AT49F002AN@PLCC32
AT49F002AN@TSOP32 [(SA410T)] [(SA620)]	AT49F002AN@VSOP32
AT49F002ANT [(SA015A1T)]	AT49F002ANT@PLCC32
AT49F002ANT@TSOP32 [(SA410T)] [(SA620)]	AT49F002ANT@VSOP32
AT49F002AT [(SA015A1T)]	AT49F002AT@PLCC32
AT49F002AT@TSOP32 [(SA410T)] [(SA620)]	AT49F002AT@VSOP32
AT49F002N [(SA015A1T)]	AT49F002N@PLCC32
AT49F002N@TSOP32 [(SA410T)] [(SA620)]	AT49F002N@VSOP32
AT49F002NT [(SA015A1T)]	AT49F002NT@PLCC32
AT49F002NT@TSOP32 [(SA410T)] [(SA620)]	AT49F002NT@VSOP32
AT49F002T [(SA015A1T)]	AT49F002T@PLCC32
AT49F002T@TSOP32 [(SA410T)] [(SA620)]	AT49F002T@VSOP32
AT49F008@TSOP40 [(SA409T)] [(SA409T)]	AT49F008A@TSOP40
AT49F008AT@TSOP40 [(SA409T)]	
AT49F010 AT49F010@PLCC32 [(SA015A1T)] [(SA410T)]	AT49F010@TSOP32
AT49F020 [(SA015A1T)]	AT49F020@PLCC32
AT49F020@TSOP32 [(SA410T)]	
AT49F040 AT49F040@PLCC32 [(SA015A1T)] [(SA410T)]	AT49F040@TSOP32
AT49F040A [(SA015A1T)]	AT49F040A@PLCC32
AT49F040A@TSOP32 [(SA410T)] [(SA638)]	AT49F080@PSOP44
AT49F080@TSOP40 [(SA409T)] [(SA638)]	AT49F080T@PSOP44
AT49F080T@TSOP40 [(SA409T)]	AT49F1024@TSOP40

[(SA623)]  
 AT49F1024A@TSOP40 [(SA623)] AT49F1025@PLCC44  
 [(SA244)]  
 AT49F1604@TSOP48 [(SA247-B005)]  
 AT49F1604@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49F1604T@TSOP48 [(SA247-B005)]  
 AT49F1604T@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49F1614@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49F1614@TSOP48 [(SA247-B005)]  
 AT49F1614T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49F1614T@TSOP48 [(SA247-B005)] AT49F2048@PSOP44  
 [(SA638)]  
 AT49F2048@TSOP48 [(SA247-B005)] AT49F2048A@PSOP44  
 [(SA638)]  
 AT49F2048A@TSOP48 [(SA247-B005)] AT49F4096@PSOP44  
 [(SA638)]  
 AT49F4096@TSOP48 [(SA247-B005)]  
 AT49F4096A@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49F4096A@PSOP44 [(SA638)] AT49F4096A@TSOP48 [(SA247-  
 B005)]  
 AT49F4096A@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49F512 AT49F512@PLCC32  
 [(SA015A1T)]  
 AT49F512@TSOP32 [(SA410T)] AT49F512@VSOP32  
 [(SA620)]  
 AT49F516@PLCC44 [(SA244)] AT49F516@TSOP40  
 [(SA623)]  
 AT49F8004@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49F8004@TSOP48 [(SA247-B005)]  
 AT49F8004T@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49F8004T@TSOP48 [(SA247-B005)]  
 AT49F8011@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49F8011@TSOP48 [(SA247-B005)]  
 AT49F8011T@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49F8011T@TSOP48 [(SA247-B005)] AT49F8192@PSOP44  
 [(SA638)]  
 AT49F8192@TSOP48 [(SA247-B005)] AT49F8192A@PSOP44  
 [(SA638)]  
 AT49F8192A@TSOP48 [(SA247-B005)] AT49F8192AT@PSOP44  
 [(SA638)]  
 AT49F8192AT@TSOP48 [(SA247-B005)]  
 AT49F8192T@PSOP44 [(SA638)] AT49F8192T@TSOP48 [(SA247-  
 B005)]

AT49HBV010 [ (SA015A1T) ]	AT49HBV010@PLCC32
AT49HBV010@TSOP32 [ (SA410T) ]	
AT49HF010 AT49HF010@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49HF010@TSOP32
AT49HLV010 [ (SA015A1T) ]	AT49HLV010@PLCC32
AT49HLV010@TSOP32 [ (SA410T) ] [ (SA015A1T) ]	AT49LH002@PLCC32
AT49LH002@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	AT49LH004@PLCC32
AT49LH004@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	AT49LH00B4@PLCC32
AT49LH00B4@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	AT49LL020@PLCC32
AT49LL020@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	AT49LL040@PLCC32
AT49LL040@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	AT49LL080@PLCC32
AT49LL080@TSOP40 [ (SA409T) ]	
AT49LV001 AT49LV001@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV001@TSOP32
AT49LV001@VSOP32 [ (SA620) ]	
AT49LV001N AT49LV001N@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV001N@TSOP32
AT49LV001N@VSOP32 [ (SA620) ]	
AT49LV001NT AT49LV001NT@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV001NT@TSOP32
AT49LV001NT@VSOP32 [ (SA620) ]	
AT49LV001T AT49LV001T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV001T@TSOP32
AT49LV001T@VSOP32 [ (SA620) ]	
AT49LV002 AT49LV002@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV002@TSOP32
AT49LV002@VSOP32 [ (SA620) ]	
AT49LV002N AT49LV002N@PLCC32 [ (SA015A1T) ]	AT49LV002N@TSOP32

[ (SA410T) ]  
 AT49LV002N@VSOP32 [ (SA620) ]  
 AT49LV002NT  
 AT49LV002NT@PLCC32 [ (SA015A1T) ] AT49LV002NT@TSOP32  
 [ (SA410T) ]  
 AT49LV002NT@VSOP32 [ (SA620) ]  
 AT49LV002T  
 AT49LV002T@PLCC32 [ (SA015A1T) ] AT49LV002T@TSOP32  
 [ (SA410T) ]  
 AT49LV002T@VSOP32 [ (SA620) ] AT49LV008@TSOP40  
 [ (SA409T) ]  
 AT49LV008A@TSOP40 [ (SA409T) ] AT49LV008A@uBGA48  
 [ (SA634) ]  
 AT49LV008AT@TSOP40 [ (SA409T) ] AT49LV008AT@uBGA48  
 [ (SA634) ]  
 AT49LV010 AT49LV010@PLCC32  
 [ (SA015A1T) ]  
 AT49LV010@TSOP32 [ (SA410T) ]  
 AT49LV020  
 AT49LV020@PLCC32 [ (SA015A1T) ] AT49LV020@TSOP32  
 [ (SA410T) ]  
 AT49LV040 AT49LV040@PLCC32  
 [ (SA015A1T) ]  
 AT49LV040@TSOP32 [ (SA410T) ]  
 AT49LV040T  
 AT49LV040T@PLCC32 [ (SA015A1T) ] AT49LV040T@TSOP32  
 [ (SA410T) ]  
 AT49LV080@PSOP44 [ (SA638) ] AT49LV080@TSOP40  
 [ (SA409T) ]  
 AT49LV080T@PSOP44 [ (SA638) ] AT49LV080T@TSOP40  
 [ (SA409T) ]  
 AT49LV1024@TSOP40 [ (SA623) ] AT49LV1024A@TSOP40  
 [ (SA623) ]  
 AT49LV1025@PLCC44 [ (SA244) ] AT49LV160@TSOP48 [ (SA247-  
 B005) ]  
 AT49LV160@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 AT49LV1604@TSOP48 [ (SA247-B005) ]  
 AT49LV1604@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 AT49LV1604T@TSOP48 [ (SA247-B005) ]  
 AT49LV1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 AT49LV161@CBGA48 [ (SA642F-B026A-T064F001) ]  
 AT49LV161@TSOP48 [ (SA247-B005) ]  
 AT49LV1614@CBGA48 [ (SA642F-B026A-T064F001) ]

AT49LV1614@TSOP48 [ ( SA247-B005 ) ]  
AT49LV1614A@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV1614A@TSOP48 [ ( SA247-B005 ) ]  
AT49LV1614AT@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV1614AT@TSOP48 [ ( SA247-B005 ) ]  
AT49LV1614T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV1614T@TSOP48 [ ( SA247-B005 ) ]  
AT49LV161T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV161T@TSOP48 [ ( SA247-B005 ) ] AT49LV2048@PSOP44  
[ ( SA638 ) ]  
AT49LV2048@TSOP48 [ ( SA247-B005 ) ] AT49LV2048A@PSOP44  
[ ( SA638 ) ]  
AT49LV2048A@TSOP48 [ ( SA247-B005 ) ]  
AT49LV2048B@TSOP48 [ ( SA247-B005 ) ]  
AT49LV320@TSOP48 [ ( SA247-B005 ) ]  
AT49LV320@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49LV320T@TSOP48 [ ( SA247-B005 ) ]  
AT49LV320T@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49LV321@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV321@TSOP48 [ ( SA247-B005 ) ]  
AT49LV3218@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV3218@TSOP48 [ ( SA247-B005 ) ]  
AT49LV3218T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV3218T@TSOP48 [ ( SA247-B005 ) ]  
AT49LV321T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV321T@TSOP48 [ ( SA247-B005 ) ]  
AT49LV4096A@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49LV4096A@PSOP44 [ ( SA638 ) ]  
AT49LV4096A@TSOP48 [ ( SA247-B005 ) ]  
AT49LV4096A@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49LV8011@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49LV8011@TSOP48 [ ( SA247-B005 ) ]  
AT49LV8011T@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49LV8011T@TSOP48 [ ( SA247-B005 ) ]  
AT49LV8192@PSOP44 [ ( SA638 ) ] AT49LV8192@TSOP48 [ ( SA247-  
B005 ) ]  
AT49LV8192A@TSOP48 [ ( SA247-B005 ) ]  
AT49LV8192A@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49LV8192AT@TSOP48 [ ( SA247-B005 ) ]  
AT49LV8192AT@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49LW040@PLCC32 [ ( SA015A1T ) ] AT49LW040@TSOP40  
[ ( SA409T ) ]  
AT49LW080@PLCC32 [ ( SA015A1T ) ] AT49LW080@TSOP40



[ ( SA409T ) ]  
AT49SV163D@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49SV163D@TSOP48 [ ( SA247-B005 ) ]  
AT49SV163DT@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49SV163DT@TSOP48 [ ( SA247-B005 ) ]  
AT49SV322A@CBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49SV322A@TSOP48 [ ( SA247-B005 ) ]  
AT49SV322AT@CBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49SV322AT@TSOP48 [ ( SA247-B005 ) ]  
AT49SV322D@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49SV322D@TSOP48 [ ( SA247-B005 ) ]  
AT49SV322DT@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49SV322DT@TSOP48 [ ( SA247-B005 ) ]  
AT49SV802A@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49SV802A@TSOP48 [ ( SA247-B005 ) ]  
AT49SV802AT@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49SV802AT@TSOP48 [ ( SA247-B005 ) ]  
AT52BC1660A@FBGA66 [ ( SA642R-B023A-T096F001Y ) ]  
AT52BC1660AT@FBGA66 [ ( SA642R-B023A-T096F001Y ) ]  
AT52BC1661A@FBGA66 [ ( SA642R-B023A-T096F001Y ) ]  
AT52BC1661AT@FBGA66 [ ( SA642R-B023A-T096F001Y ) ]  
AT52BC3221A@FBGA66 [ ( SA642R-B023A-T080F001Y ) ]  
AT52BC3221AT@FBGA66 [ ( SA642R-B023A-T080F001Y ) ]  
AT52BC3221D@FBGA66 [ ( SA642R-B023A-T080F001Y ) ]  
AT52BC3221DT@FBGA66 [ ( SA642R-B023A-T080F001Y ) ]  
AT52BC6402A@FBGA66 [ ( SA642B-B023A-Y072F001Y ) ]  
AT52BC6402AT@FBGA66 [ ( SA642B-B023A-Y072F001Y ) ]  
AT52BR1662@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1662A@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1662AT@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1662T@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1664@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1664A@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1664AT@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1664T@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1672@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1672T@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1674@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR1674T@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR3224@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR3224A@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR3224AT@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
AT52BR3224T@CBGA66 [ ( SA642E-B023A-T072F001Y ) ]

AT52BR3228@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3228A@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3228AT@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3228T@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3244@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3244T@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3248@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3248T@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR6408A@CSP66 [(SA642E-B023A-T072F001Y)]	
AT52BR6408AT@CSP66 [(SA642E-B023A-T072F001Y)]	
AT59C11	AT59C11@SOIC8
[(SA602A)]	
AT59C12	AT59C12@SOIC8
[(SA602A)]	
AT59C13	AT59C13@SOIC8
[(SA602A)]	
AT59C22	AT59C22@SOIC8
[(SA602A)]	
AT93C46(08bit)	AT93C46(08bit)@SOIC8
[(SA602A)]	
AT93C46(08bit)@TSSOP8 [(SA026)]	AT93C46
(16bit)	
AT93C46(16bit)@SOIC8 [(SA602A)]	AT93C46(16bit)@TSSOP8
[(SA026)]	
AT93C46A	AT93C46A@SOIC8
[(SA602A)]	
AT93C46A@TSSOP8 [(SA026)]	
AT93C46C	
AT93C46C@SOIC8 [(SA602A)]	AT93C46C@TSSOP8
[(SA026)]	
AT93C46D(08bit)	AT93C46D(08bit)@dBGA8
[(BBBB)]	
AT93C46D(08bit)@MAP8 [(SA724)]	AT93C46D(08bit)@SOIC8
[(SA602A)]	
AT93C46D(08bit)@TSSOP8 [(SA026)]	AT93C46D
(16bit)	
AT93C46D(16bit)@dBGA8 [(BBBB)]	AT93C46D(16bit)@MAP8
[(SA724)]	
AT93C46D(16bit)@SOIC8 [(SA602A)]	AT93C46D(16bit)@TSSOP8
[(SA026)]	
AT93C46E	AT93C46E@SOIC8
[(SA602A)]	
AT93C46E@TSSOP8 [(SA026)]	AT93C56

(08bit)	
AT93C56(08bit)@SOIC8 [(SA602A)]	AT93C56
(16bit)	
AT93C56(16bit)@SOIC8 [(SA602A)]	AT93C56A
(08bit)	
AT93C56A(08bit)@SOIC8 [(SA602A)]	AT93C56A(08bit)@TSSOP8
[(SA026)]	
AT93C56A(16bit)	AT93C56A(16bit)@SOIC8
[(SA602A)]	
AT93C56A(16bit)@TSSOP8 [(SA026)]	
AT93C57	
AT93C57@SOIC8 [(SA602A)]	AT93C66
(08bit)	
AT93C66(08bit)@SOIC8 [(SA602A)]	AT93C66
(16bit)	
AT93C66(16bit)@SOIC8 [(SA602A)]	AT93C66A
(08bit)	
AT93C66A(08bit)@SOIC8 [(SA602A)]	AT93C66A(08bit)@TSSOP8
[(SA026)]	
AT93C66A(16bit)	AT93C66A(16bit)@SOIC8
[(SA602A)]	
AT93C66A(16bit)@TSSOP8 [(SA026)]	AT93C86
(08bit)	
AT93C86(08bit)@SOIC8 [(SA602A)]	AT93C86(08bit)@TSSOP8
[(SA026)]	
AT93C86(16bit)	AT93C86(16bit)@SOIC8
[(SA602A)]	
AT93C86(16bit)@TSSOP8 [(SA026)]	AT93C86A
(08bit)	
AT93C86A(08bit)@SOIC8 [(SA602A)]	AT93C86A(08bit)@TSSOP8
[(SA026)]	
AT93C86A(16bit)	AT93C86A(16bit)@SOIC8
[(SA602A)]	
AT93C86A(16bit)@TSSOP8 [(SA026)]	

## DRAM & SRAM

AT3864L	AT3864L@TSOP28
[(SA643)]	
AT38H256	AT38H256@TSOP28
[(SA643)]	

PLD

ATF16LV8C [ (SA001A) ]	ATF16LV8C@PLCC20
ATF16LV8C@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16LV8C@TSOP20
ATF16LV8CEXT [ (SA001A) ]	ATF16LV8CEXT@PLCC20
ATF16LV8CEXT@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16LV8CEXT@TSOP20
ATF16V8B [ (SA001A) ]	ATF16V8B@PLCC20
ATF16V8B@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8B@TSOP20
ATF16V8BL [ (SA001A) ]	ATF16V8BL@PLCC20
ATF16V8BL@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8BL@TSOP20
ATF16V8BQ [ (SA001A) ]	ATF16V8BQ@PLCC20
ATF16V8BQ@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8BQ@TSOP20
ATF16V8BQL [ (SA001A) ]	ATF16V8BQL@PLCC20
ATF16V8BQL@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8BQL@TSOP20
ATF16V8C [ (SA001A) ]	ATF16V8C@PLCC20
ATF16V8C@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8C@TSOP20
ATF16V8CEXT [ (SA001A) ]	ATF16V8CEXT@PLCC20
ATF16V8CEXT@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8CEXT@TSOP20
ATF16V8CZ [ (SA001A) ]	ATF16V8CZ@PLCC20
ATF16V8CZ@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8CZ@TSOP20
ATF20V8B [ (SA008A) ]	ATF20V8B@PLCC28
ATF20V8B@SOIC24 [ (SA404) ]	
ATF20V8BL	

ATF20V8BL@PLCC28 [(SA008A)] ATF20V8BL@SOIC24  
[(SA404)]  
ATF20V8BQ ATF20V8BQ@PLCC28  
[(SA008A)]  
ATF20V8BQ@SOIC24 [(SA404)]  
ATF20V8BQL ATF20V8BQL@SOIC24  
[(SA404)]  
ATF22LV10C ATF22LV10C  
(UES)  
ATF22LV10C(UES)@PLCC28 [(SA008A)]  
ATF22LV10C(UES)@SOIC24 [(SA404)]  
ATF22LV10C(UES)@TSSOP24 [(SA643)]  
ATF22LV10C@PLCC28 [(SA008A)] ATF22LV10C@SOIC24  
[(SA404)]  
ATF22LV10C@TSSOP24 [(SA643)]  
ATF22LV10CEXT  
ATF22LV10CEXT@PLCC28 [(SA008A)] ATF22LV10CEXT@SOIC24  
[(SA404)]  
ATF22LV10CEXT@TSSOP24 [(SA643)]  
ATF22LV10CQ  
ATF22LV10CQ(UES)  
ATF22LV10CQ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CQ(UES)@SOIC24 [(SA404)]  
ATF22LV10CQ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CQ@PLCC28 [(SA008A)] ATF22LV10CQ@SOIC24  
[(SA404)]  
ATF22LV10CQ@TSSOP24 [(SA643)]  
ATF22LV10CQZ  
ATF22LV10CQZ(UES)  
ATF22LV10CQZ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CQZ(UES)@SOIC24 [(SA404)]  
ATF22LV10CQZ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CQZ@PLCC28 [(SA008A)] ATF22LV10CQZ@SOIC24  
[(SA404)]  
ATF22LV10CQZ@TSSOP24 [(SA643)]  
ATF22LV10CZ  
ATF22LV10CZ(UES)  
ATF22LV10CZ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CZ(UES)@SOIC24 [(SA404)]  
ATF22LV10CZ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CZ@PLCC28 [(SA008A)] ATF22LV10CZ@SOIC24  
[(SA404)]

ATF22LV10CZ@TSSOP24 [(SA643)]  
ATF22V10B  
ATF22V10B(UES) ATF22V10B(UES)@PLCC28  
[(SA008A)]  
ATF22V10B(UES)@SOIC24 [(SA404)] ATF22V10B@PLCC28  
[(SA008A)]  
ATF22V10B@SOIC24 [(SA404)]  
ATF22V10BL  
ATF22V10BL(UES)  
ATF22V10BL(UES)@PLCC28 [(SA008A)]  
ATF22V10BL(UES)@SOIC24 [(SA404)] ATF22V10BL@PLCC28  
[(SA008A)]  
ATF22V10BL@SOIC24 [(SA404)]  
ATF22V10BQ  
ATF22V10BQ(UES)  
ATF22V10BQ(UES)@PLCC28 [(SA008A)]  
ATF22V10BQ(UES)@SOIC24 [(SA404)] ATF22V10BQ@PLCC28  
[(SA008A)]  
ATF22V10BQ@SOIC24 [(SA404)]  
ATF22V10BQL  
ATF22V10BQL(UES)  
ATF22V10BQL(UES)@PLCC28 [(SA008A)]  
ATF22V10BQL(UES)@SOIC24 [(SA404)]  
ATF22V10BQL@PLCC28 [(SA008A)] ATF22V10BQL@SOIC24  
[(SA404)]  
ATF22V10C ATF22V10C  
(UES)  
ATF22V10C(UES)@PLCC28 [(SA008A)] ATF22V10C(UES)@SOIC24  
[(SA404)]  
ATF22V10C(UES)@TSSOP24 [(SA643)] ATF22V10C@PLCC28  
[(SA008A)]  
ATF22V10C@SOIC24 [(SA404)] ATF22V10C@TSSOP24  
[(SA643)]  
ATF22V10CEXT ATF22V10CEXT@PLCC28  
[(SA008A)]  
ATF22V10CEXT@SOIC24 [(SA404)] ATF22V10CEXT@TSSOP24  
[(SA643)]  
ATF22V10CQ ATF22V10CQ  
(UES)  
ATF22V10CQ(UES)@PLCC28 [(SA008A)]  
ATF22V10CQ(UES)@SOIC24 [(SA404)]  
ATF22V10CQ(UES)@TSSOP24 [(SA643)]  
ATF22V10CQ@PLCC28 [(SA008A)] ATF22V10CQ@SOIC24

[ (SA404) ]  
 ATF22V10CQ@TSSOP24 [ (SA643) ]  
 ATF22V10CQZ  
 ATF22V10CQZ (UES)  
 ATF22V10CQZ (UES)@PLCC28 [ (SA008A) ]  
 ATF22V10CQZ (UES)@SOIC24 [ (SA404) ]  
 ATF22V10CQZ (UES)@TSSOP24 [ (SA643) ]  
 ATF22V10CQZ@PLCC28 [ (SA008A) ]                      ATF22V10CQZ@SOIC24  
 [ (SA404) ]  
 ATF22V10CQZ@TSSOP24 [ (SA643) ]  
 ATF22V10CZ  
 ATF22V10CZ (UES)  
 ATF22V10CZ (UES)@PLCC28 [ (SA008A) ]  
 ATF22V10CZ (UES)@SOIC24 [ (SA404) ]  
 ATF22V10CZ (UES)@TSSOP24 [ (SA643) ]  
 ATF22V10CZ@PLCC28 [ (SA008A) ]                      ATF22V10CZ@SOIC24  
 [ (SA404) ]  
 ATF22V10CZ@TSSOP24 [ (SA643) ]                      ATF750C                      (ATF750C  
 mode)  
 ATF750C                      (ATV750 mode)                      ATF750C                      (ATV750B  
 mode)  
 ATF750C@PLCC28                      (ATF750C mode) [ (SA008A) ]  
 ATF750C@PLCC28                      (ATV750 mode) [ (SA008A) ]  
 ATF750C@PLCC28                      (ATV750B mode) [ (SA008A) ]  
 ATF750C@SOIC24                      (ATF750C mode) [ (SA404) ]  
 ATF750C@SOIC24                      (ATV750 mode) [ (SA404) ]  
 ATF750C@SOIC24                      (ATV750B mode) [ (SA404) ]  
 ATF750CEXT                      (ATF750C mode)  
 ATF750CEXT@PLCC28                      (ATF750C mode) [ (SA008A) ]  
 ATF750CEXT@SOIC24                      (ATF750C mode) [ (SA404) ]  
 ATF750CL                      (ATV750 mode)                      ATF750CL                      (ATV750B  
 mode)  
 ATF750CL@PLCC28                      (ATV750 mode) [ (SA008A) ]  
 ATF750CL@PLCC28                      (ATV750B mode) [ (SA008A) ]  
 ATF750CL@SOIC24                      (ATV750 mode) [ (SA404) ]  
 ATF750CL@SOIC24                      (ATV750B mode) [ (SA404) ]  
 ATF750LVC                      (ATF750C mode)                      ATF750LVC                      (ATV750  
 mode)  
 ATF750LVC                      (ATV750B mode)  
 ATF750LVC@PLCC28                      (ATF750C mode) [ (SA008A) ]  
 ATF750LVC@PLCC28                      (ATV750 mode) [ (SA008A) ]  
 ATF750LVC@PLCC28                      (ATV750B mode) [ (SA008A) ]  
 ATF750LVC@SOIC24                      (ATF750C mode) [ (SA404) ]

ATF750LVC@SOIC24 (ATV750 mode) [(SA404)]  
 ATF750LVC@SOIC24 (ATV750B mode) [(SA404)]  
 ATF750LVCEXT (ATF750C mode)  
 ATF750LVCEXT@PLCC28 (ATF750Cmode) [(SA008A)]  
 ATF750LVCEXT@SOIC24 (ATF750Cmode) [(SA404)]  
 ATF750LVCL (ATF750C mode) ATF750LVCL (ATV750 mode)  
 ATF750LVCL (ATV750B mode)  
 ATF750LVCL@PLCC28 (ATF750C mode) [(SA008A)]  
 ATF750LVCL@PLCC28 (ATV750 mode) [(SA008A)]  
 ATF750LVCL@PLCC28 (ATV750B mode) [(SA008A)]  
 ATF750LVCL@SOIC24 (ATF750C mode) [(SA404)]  
 ATF750LVCL@SOIC24 (ATV750 mode) [(SA404)]  
 ATF750LVCL@SOIC24 (ATV750B mode) [(SA404)]  
 ATV750 ATF750@PLCC28  
 [(SA008A)]  
 ATV750@SOIC24 [(SA404)]  
 ATV750B  
 ATV750B@PLCC28 [(SA008A)] ATV750B@SOIC24  
 [(SA404)]  
 ATV750BL ATV750BL@PLCC28  
 [(SA008A)]  
 ATV750BL@SOIC24 [(SA404)]  
 ATV750L  
 ATV750L@PLCC28 [(SA008A)] ATV750L@SOIC24  
 [(SA404)]

## MICROCONTROLLER

AT80F51 AT80F51@PLCC44  
 [(SA244)]  
 AT80F51@TQFP44 [(SA245A)]  
 AT80F52  
 AT80F52@PLCC44 [(SA244)] AT80F52@TQFP44  
 [(SA245A)]  
 AT87F51 AT87F51@PLCC44  
 [(SA244)]  
 AT87F51@TQFP44 [(SA245A)]  
 AT87F51RC  
 AT87F51RC@PLCC44 [(SA244)] AT87F51RC@TQFP44  
 [(SA245A)]  
 AT87F52 AT87F52@PLCC44



[ (SA244) ]	
AT87F52@TQFP44 [ (SA245A) ]	
AT87F55	
AT87F55@PLCC44 [ (SA244) ]	AT87F55@TQFP44
[ (SA245A) ]	
AT87F55WD	
[ (SA244) ]	
AT87F55WD@TQFP44 [ (SA245A) ]	AT87F55WD@PLCC44
AT87LV51	
AT87LV51@PLCC44 [ (SA244) ]	AT87LV51@TQFP44
[ (SA245A) ]	
AT87LV52	
[ (SA244) ]	
AT87LV52@TQFP44 [ (SA245A) ]	AT87LV52@PLCC44
AT89C1051	
AT89C1051@SOIC20 [ (SA404) ]	
AT89C1051U	
AT89C1051U@SOIC20 [ (SA404) ]	
AT89C2051	
AT89C2051@SOIC20 [ (SA404) ]	
AT89C2051X2	
AT89C2051X2@SOIC20 [ (SA404) ]	
AT89C4051	
AT89C4051@SOIC20 [ (SA404) ]	
AT89C51	
AT89C51@PLCC44 [ (SA244) ]	AT89C51@TQFP44
[ (SA245A) ]	
AT89C5130A@QFN32 [ (SA686) ]	AT89C5130A@SOIC28
[ (SA404) ]	
AT89C5130AM@QFN32 [ (SA686) ]	AT89C5130AM@SOIC28
[ (SA404) ]	
AT89C5131@MLF48 [ (SA696) ]	AT89C5131@SOIC28
[ (SA404) ]	
AT89C5131A@QFN32 [ (SA701) ]	AT89C5131A@SOIC28
[ (SA404) ]	
AT89C5131AL@QFN32 [ (SA701) ]	AT89C5131AL@SOIC28
[ (SA404) ]	
AT89C5131AM@QFN32 [ (SA701) ]	AT89C5131AM@SOIC28
[ (SA404) ]	
AT89C51AC2@PLCC44 [ (SA244) ]	AT89C51AC2@TQFP44
[ (SA245A) ]	
AT89C51AC3@PLCC44 [ (SA244) ]	AT89C51AC3@TQFP44
[ (SA245A) ]	

AT89C51CC01@PLCC44 [(SA244)]	AT89C51CC01@TQFP44
[(SA245A)]	
AT89C51CC03C@PLCC44 [(SA244)]	AT89C51CC03C@TQFP44
[(SA245A)]	
AT89C51CC03U@PLCC44 [(SA244)]	AT89C51CC03U@TQFP44
[(SA245A)]	
AT89C51ED2	AT89C51ED2@PLCC44
[(SA244)]	
AT89C51ED2@TQFP44 [(SA245A)]	AT89C51IC2@PLCC44
[(SA244)]	
AT89C51IC2@TQFP44 [(SA245A)]	
AT89C51ID2	
AT89C51ID2@PLCC44 [(SA244)]	AT89C51ID2@TQFP44
[(SA245A)]	
AT89C51RB2	AT89C51RB2@PLCC44
[(SA244)]	
AT89C51RB2@TQFP44 [(SA245A)]	
AT89C51RC	
AT89C51RC@PLCC44 [(SA244)]	AT89C51RC@TQFP44
[(SA245A)]	
AT89C51RC2	AT89C51RC2@PLCC44
[(SA244)]	
AT89C51RC2@TQFP44 [(SA245A)]	
AT89C51RD2	
AT89C51RD2@PLCC44 [(SA244)]	AT89C51RD2@TQFP44
[(SA245A)]	
AT89C51RE2@PLCC44 [(SA244)]	AT89C51RE2@TQFP44
[(SA675)]	
AT89C52	AT89C52@PLCC44
[(SA244)]	
AT89C52@TQFP44 [(SA245A)]	
AT89C55	
AT89C55@PLCC44 [(SA244)]	AT89C55@TQFP44
[(SA245A)]	
AT89C55WD	AT89C55WD@PLCC44
[(SA244)]	
AT89C55WD@TQFP44 [(SA245A)]	
AT89LP2051	
AT89LP2051@SOIC20 [(SA404)]	AT89LP2051@TSSOP20
[(SA026)]	
AT89LP2052	AT89LP2052(ISP) [ISP-
HEADER01]	
AT89LP2052@SOIC20 [(SA404)]	

AT89LP2052@SOIC20(ISP) [ISP-HEADER01]  
AT89LP2052@TSSOP20 [(SA026)]  
AT89LP2052@TSSOP20(ISP) [ISP-HEADER01]  
AT89LP213 AT89LP213(ISP) [ISP-  
HEADER01]  
AT89LP213@TSSOP14 [(SA026)]  
AT89LP213@TSSOP14(ISP) [ISP-HEADER01]  
AT89LP214 AT89LP214(ISP) [ISP-  
HEADER01]  
AT89LP214@TSSOP14 [(SA026)]  
AT89LP214@TSSOP14(ISP) [ISP-HEADER01]  
AT89LP216 AT89LP216(ISP) [ISP-  
HEADER01]  
AT89LP216@TSSOP16 [(SA026)]  
AT89LP216@TSSOP16(ISP) [ISP-HEADER01]  
AT89LP4051 AT89LP4051@SOIC20  
[(SA404)]  
AT89LP4051@TSSOP20 [(SA026)]  
AT89LP4052 AT89LP4052@SOIC20  
[ (SA404) ]  
AT89LP4052(ISP) [ISP-HEADER01]  
AT89LP4052@SOIC20(ISP) [ISP-HEADER01]  
AT89LP4052@TSSOP20 [(SA026)]  
AT89LP4052@TSSOP20(ISP) [ISP-HEADER01]  
AT89LP428 AT89LP428(ISP) [ISP-  
HEADER01]  
AT89LP428@PLCC32 [(SA015A1T)]  
AT89LP428@PLCC32(ISP) [ISP-HEADER01]  
AT89LP428@TQFP32 [(SA636)]  
AT89LP428@TQFP32(ISP) [ISP-HEADER01]  
AT89LP828 AT89LP828(ISP) [ISP-  
HEADER01]  
AT89LP828@PLCC32 [(SA015A1T)]  
AT89LP828@PLCC32(ISP) [ISP-HEADER01]  
AT89LP828@TQFP32 [(SA636)]  
AT89LP828@TQFP32(ISP) [ISP-HEADER01]  
AT89LS51 AT89LS51(ISP) [ISP-  
HEADER01]  
AT89LS51@PLCC44 [(SA244)]  
AT89LS51@PLCC44(ISP) [ISP-HEADER01]  
AT89LS51@TQFP44 [(SA245A)]  
AT89LS51@TQFP44(ISP) [ISP-HEADER01]  
AT89LS52 AT89LS52(ISP) [ISP-

HEADER01 ]  
AT89LS52@PLCC44 [ (SA244) ]  
AT89LS52@PLCC44(ISP) [ ISP-HEADER01 ]  
AT89LS52@TQFP44 [ (SA245A) ]  
AT89LS52@TQFP44(ISP) [ ISP-HEADER01 ]  
AT89LS53 AT89LS53(ISP) [ ISP-  
HEADER01 ]  
AT89LS53@PLCC44 [ (SA244) ]  
AT89LS53@PLCC44(ISP) [ ISP-HEADER01 ]  
AT89LS53@TQFP44 [ (SA245A) ]  
AT89LS53@TQFP44(ISP) [ ISP-HEADER01 ]  
AT89LS8252 AT89LS8252(ISP) [ ISP-  
HEADER01 ]  
AT89LS8252@PLCC44 [ (SA244) ]  
AT89LS8252@PLCC44(ISP) [ ISP-HEADER01 ]  
AT89LS8252@TQFP44 [ (SA245A) ]  
AT89LS8252@TQFP44(ISP) [ ISP-HEADER01 ]  
AT89LV51 AT89LV51@PLCC44  
[ (SA244) ]  
AT89LV51@TQFP44 [ (SA245A) ]  
AT89LV52 AT89LV52@TQFP44  
[ (SA245A) ]  
AT89LV55 AT89LV55@PLCC44  
[ (SA244) ]  
AT89LV55@TQFP44 [ (SA245A) ]  
AT89S2051  
AT89S2051@SOIC20 [ (SA404) ]  
AT89S4051  
AT89S4051@SOIC20 [ (SA404) ]  
AT89S51 AT89S51@PLCC44  
AT89S51(ISP) [ ISP-HEADER01 ]  
[ (SA244) ]  
AT89S51@PLCC44(ISP) [ ISP-HEADER01 ]  
AT89S51@TQFP44 [ (SA245A) ]  
AT89S51@TQFP44(ISP) [ ISP-HEADER01 ]  
AT89S52 AT89S52(ISP) [ ISP-  
HEADER01 ]  
AT89S52@PLCC44 [ (SA244) ]  
AT89S52@PLCC44(ISP) [ ISP-HEADER01 ]  
AT89S52@TQFP44 [ (SA245A) ]  
AT89S52@TQFP44(ISP) [ ISP-HEADER01 ]  
AT89S53 AT89S53(ISP) [ ISP-

HEADER01 ]

AT89S53@PLCC44 [ (SA244) ]

AT89S53@PLCC44( ISP) [ ISP-HEADER01 ]

AT89S53@TQFP44 [ (SA245A) ]

AT89S53@TQFP44( ISP) [ ISP-HEADER01 ]

AT89S54

AT89S54@PLCC44

[ (SA244) ]

AT89S54@TQFP44 [ (SA245A) ]

AT89S58

AT89S58@PLCC44 [ (SA244) ]

AT89S58@TQFP44

[ (SA245A) ]

AT89S64

AT89S64@PLCC44

[ (SA244) ]

AT89S64@TQFP44 [ (SA245A) ]

AT89S8252

AT89S8252( ISP) [ ISP-HEADER01 ]

AT89S8252@PLCC44

[ (SA244) ]

AT89S8252@PLCC44( ISP) [ ISP-HEADER01 ]

AT89S8252@TQFP44 [ (SA245A) ]

AT89S8252@TQFP44( ISP) [ ISP-HEADER01 ]

AT89S8253

AT89S8253( ISP) [ ISP-

HEADER01 ]

AT89S8253@PLCC44 [ (SA244) ]

AT89S8253@PLCC44( ISP) [ ISP-HEADER01 ]

AT89S8253@TQFP44 [ (SA245A) ]

AT89S8253@TQFP44( ISP) [ ISP-HEADER01 ]

AT90CAN128@QFN64( ISP) [ ISP-HEADER01 ]

AT90CAN128@TQFP64( ISP) [ ISP-HEADER01 ]

AT90CAN32@QFN64( ISP) [ ISP-HEADER01 ]

AT90CAN32@TQFP64( ISP) [ ISP-HEADER01 ]

AT90CAN64@QFN64( ISP) [ ISP-HEADER01 ]

AT90CAN64@TQFP64( ISP) [ ISP-HEADER01 ]

AT90LS2323

AT90LS2323( ISP) [ ISP-

HEADER01 ]

AT90LS2323@SOIC8 [ (SA605A) ]

AT90LS2323@SOIC8( ISP) [ ISP-HEADER01 ]

AT90LS2333

AT90LS2333( ISP) [ ISP-

HEADER01 ]

AT90LS2333@TQFP32 [ (SA663) ]

AT90LS2333@TQFP32( ISP) [ ISP-HEADER01 ]

AT90LS2343

AT90LS2343( ISP) [ ISP-

HEADER01 ]

AT90LS2343@SOIC8 [ (SA605A) ]

AT90LS2343@SOIC8(ISP) [ISP-HEADER01]  
AT90LS4433 AT90LS4433(ISP) [ISP-  
HEADER01]  
AT90LS4433@TQFP32 [(SA663)]  
AT90LS4433@TQFP32(ISP) [ISP-HEADER01]  
AT90LS4434 AT90LS4434(ISP) [ISP-  
HEADER01]  
AT90LS4434@PLCC44 [(SA244)]  
AT90LS4434@PLCC44(ISP) [ISP-HEADER01]  
AT90LS4434@TQFP44 [(SA245A)]  
AT90LS4434@TQFP44(ISP) [ISP-HEADER01]  
AT90LS8535 AT90LS8535(ISP) [ISP-  
HEADER01]  
AT90LS8535@PLCC44 [(SA244)]  
AT90LS8535@PLCC44(ISP) [ISP-HEADER01]  
AT90LS8535@TQFP44 [(SA245A)]  
AT90LS8535@TQFP44(ISP) [ISP-HEADER01]  
AT90PWM1@SOIC24 [(SA404)] AT90PWM2@SOIC24  
[(SA404)]  
AT90PWM2@SOIC24(ISP) [ISP-HEADER01]  
AT90PWM216@SOIC24 [(SA404)] AT90PWM2B@SOIC24  
[(SA404)]  
AT90PWM2B@SOIC24(ISP) [ISP-HEADER01]  
AT90PWM3@QFN32 [(SA701)]  
AT90PWM3@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3@SOIC32 [(SA715)]  
AT90PWM3@SOIC32(ISP) [ISP-HEADER01]  
AT90PWM316@QFN32 [(SA701)] AT90PWM316@SOIC32  
[(SA715)]  
AT90PWM3B@QFN32 [(SA701)]  
AT90PWM3B@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3B@SOIC32 [(SA715)]  
AT90PWM3B@SOIC32(ISP) [ISP-HEADER01]  
AT90S1200 AT90S1200(ISP) [ISP-  
HEADER01]  
AT90S1200@SOIC20 [(SA404)]  
AT90S1200@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200@SSOP20 [(SA626A)]  
AT90S1200@SSOP20(ISP) [ISP-HEADER01]  
AT90S1200A AT90S1200A(ISP) [ISP-  
HEADER01]  
AT90S1200A@SOIC20 [(SA404)]  
AT90S1200A@SOIC20(ISP) [ISP-HEADER01]

AT90S1200A@SSOP20 [(SA626A)]  
AT90S1200A@SSOP20(ISP) [ISP-HEADER01]  
AT90S2313 AT90S2313(ISP) [ISP-  
HEADER01]  
AT90S2313@SOIC20 [(SA404)]  
AT90S2313@SOIC20(ISP) [ISP-HEADER01]  
AT90S2323 AT90S2323(ISP) [ISP-  
HEADER01]  
AT90S2323@SOIC8 [(SA605A)]  
AT90S2323@SOIC8(ISP) [ISP-HEADER01]  
AT90S2333 AT90S2333(ISP) [ISP-  
HEADER01]  
AT90S2333@TQFP32 [(SA663)]  
AT90S2333@TQFP32(ISP) [ISP-HEADER01]  
AT90S2343 AT90S2343(ISP) [ISP-  
HEADER01]  
AT90S2343@SOIC8 [(SA605A)]  
AT90S2343@SOIC8(ISP) [ISP-HEADER01]  
AT90S4414 AT90S4414(ISP) [ISP-  
HEADER01]  
AT90S4414@PLCC44 [(SA244)]  
AT90S4414@PLCC44(ISP) [ISP-HEADER01]  
AT90S4414@TQFP44 [(SA245A)]  
AT90S4414@TQFP44(ISP) [ISP-HEADER01]  
AT90S4433 AT90S4433(ISP) [ISP-  
HEADER01]  
AT90S4433@TQFP32 [(SA663)]  
AT90S4433@TQFP32(ISP) [ISP-HEADER01]  
AT90S4434 AT90S4434(ISP) [ISP-  
HEADER01]  
AT90S4434@PLCC44 [(SA244)]  
AT90S4434@PLCC44(ISP) [ISP-HEADER01]  
AT90S4434@TQFP44 [(SA245A)]  
AT90S4434@TQFP44(ISP) [ISP-HEADER01]  
AT90S8515 AT90S8515(ISP) [ISP-  
HEADER01]  
AT90S8515@PLCC44 [(SA244)]  
AT90S8515@PLCC44(ISP) [ISP-HEADER01]  
AT90S8515@TQFP44 [(SA245A)]  
AT90S8515@TQFP44(ISP) [ISP-HEADER01]  
AT90S8535 AT90S8535(ISP) [ISP-  
HEADER01]  
AT90S8535@PLCC44 [(SA244)]

AT90S8535@PLCC44(ISP) [ISP-HEADER01]  
AT90S8535@TQFP44 [(SA245A)]  
AT90S8535@TQFP44(ISP) [ISP-HEADER01]  
AT90USB1286@QFN64(ISP) [ISP-HEADER01]  
AT90USB1286@TQFP64(ISP) [ISP-HEADER01]  
AT90USB1287@QFN64(ISP) [ISP-HEADER01]  
AT90USB1287@TQFP64(ISP) [ISP-HEADER01]  
AT90USB646@QFN64(ISP) [ISP-HEADER01]  
AT90USB646@TQFP64(ISP) [ISP-HEADER01]  
AT90USB647@QFN64(ISP) [ISP-HEADER01]  
AT90USB647@TQFP64(ISP) [ISP-HEADER01]  
ATAM862@SSO24 [(SA026)] ATAM893@SSO20  
[(SA026)]  
ATAM894@SSO24 [(SA026)]  
ATMEGA128@QFN64(ISP) [ISP-HEADER01]  
ATMEGA128@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA128L@QFN64(ISP) [ISP-HEADER01]  
ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA16 ATMEGA16  
(fast)  
ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44  
[(SA245A)]  
ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16@MLF44  
[(SA712)]  
ATMEGA16@MLF44(ISP) [ISP-HEADER01]  
ATMEGA16@TQFP44 [(SA245A)]  
ATMEGA16@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA161 ATMEGA161@TQFP44  
[(SA245A)]  
ATMEGA161L ATMEGA161L@TQFP44  
[(SA245A)]  
ATMEGA162 ATMEGA162(ISP) [ISP-  
HEADER01]  
ATMEGA162@MLF44 [(SA712)]  
ATMEGA162@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA162@TQFP44 [(SA245A)]  
ATMEGA162@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA162V ATMEGA162V@MLF44  
[(SA712)]  
ATMEGA162V@TQFP44 [(SA245A)]  
ATMEGA163



ATMEGA163@TQFP44 [(SA245A)]  
ATMEGA163L  
ATMEGA163L@TQFP44 [(SA245A)]  
ATMEGA164P  
ATMEGA164P@MLP44 [(SA712)] ATMEGA164P@TQFP44  
[(SA245A)]  
ATMEGA164PL ATMEGA164PL@MLP44  
[(SA712)]  
ATMEGA164PL@TQFP44 [(SA245A)]  
ATMEGA165@QFN64(ISP) [ISP-HEADER01]  
ATMEGA165@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA168 ATMEGA168(ISP) [ISP-  
HEADER01]  
ATMEGA168@MLP32 [(SA686)]  
ATMEGA168@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168@TQFP32 [(SA663)]  
ATMEGA168@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168P ATMEGA168P(ISP) [ISP-  
HEADER01]  
ATMEGA168P@MLP32 [(SA686)]  
ATMEGA168P@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168P@TQFP32 [(SA663)]  
ATMEGA168P@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168PV ATMEGA168PV(ISP) [ISP-  
HEADER01]  
ATMEGA168PV@MLP32 [(SA686)]  
ATMEGA168PV@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168PV@TQFP32 [(SA663)]  
ATMEGA168PV@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168V ATMEGA168V(ISP) [ISP-  
HEADER01]  
ATMEGA168V@MLP32 [(SA686)]  
ATMEGA168V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168V@TQFP32 [(SA663)]  
ATMEGA168V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA169@MLF64(ISP) [ISP-HEADER01]  
ATMEGA169@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA169PV@MLF64(ISP) [ISP-HEADER01]  
ATMEGA169PV@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA16L ATMEGA16L  
(fast)  
ATMEGA16L(fast)@MLF44 [(SA712)]  
ATMEGA16L(fast)@TQFP44 [(SA245A)]

ATMEGA16L( ISP) [ ISP-HEADER01] ATMEGA16L@MLF44  
 [(SA712)]  
 ATMEGA16L@MLF44( ISP) [ ISP-HEADER01]  
 ATMEGA16L@TQFP44 [(SA245A)]  
 ATMEGA16L@TQFP44( ISP) [ ISP-HEADER01]  
 ATMEGA2560@TQFP100( ISP) [ ISP-HEADER01]  
 ATMEGA2560V@TQFP100( ISP) [ ISP-HEADER01]  
 ATMEGA2561@QFN64( ISP) [ ISP-HEADER01]  
 ATMEGA2561@TQFP64( ISP) [ ISP-HEADER01]  
 ATMEGA2561V@QFN64( ISP) [ ISP-HEADER01]  
 ATMEGA2561V@TQFP64( ISP) [ ISP-HEADER01]  
 ATMEGA32 ATMEGA32( ISP) [ ISP-  
 HEADER01]  
 ATMEGA32(new) ATMEGA32(new)  
 (fast)  
 ATMEGA32(new)(fast)@MLF44 [(SA712)]  
 ATMEGA32(new)(fast)@PLCC44 [(SA244)]  
 ATMEGA32(new)(fast)@TQFP44 [(SA245A)]  
 ATMEGA32(new)@MLF44 [(SA712)] ATMEGA32(new)@PLCC44  
 [(SA244)]  
 ATMEGA32(new)@TQFP44 [(SA245A)] ATMEGA32@MLF44  
 [(SA712)]  
 ATMEGA32@MLF44( ISP) [ ISP-HEADER01]  
 ATMEGA32@PLCC44 [(SA244)] ATMEGA32@TQFP44  
 [(SA245A)]  
 ATMEGA32@TQFP44( ISP) [ ISP-HEADER01]  
 ATMEGA323 ATMEGA323@TQFP44  
 [(SA245A)]  
 ATMEGA323L ATMEGA323L@TQFP44  
 [(SA245A)]  
 ATMEGA324P ATMEGA324P@MLP44  
 [(SA712)]  
 ATMEGA324P@TQFP44 [(SA245A)]  
 ATMEGA324PL ATMEGA324PL@TQFP44  
 ATMEGA324PL@MLP44 [(SA712)]  
 [(SA245A)]  
 ATMEGA3250@TQFP100( ISP) [ ISP-HEADER01]  
 ATMEGA325P@TQFP64( ISP) [ ISP-HEADER01]  
 ATMEGA325V@QFN64( ISP) [ ISP-HEADER01]  
 ATMEGA328P ATMEGA328P( ISP) [ ISP-  
 HEADER01]  
 ATMEGA328P@MLP32 [(SA686)]  
 ATMEGA328P@MLP32( ISP) [ ISP-HEADER01]

ATMEGA328P@TQFP32 [(SA663)]  
ATMEGA328P@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA328PV ATMEGA328PV(ISP) [ISP-  
HEADER01]  
ATMEGA328PV@MLP32 [(SA686)]  
ATMEGA328PV@MLP32(ISP) [ISP-HEADER01]  
ATMEGA328PV@TQFP32 [(SA663)]  
ATMEGA328PV@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA329@QFN64(ISP) [ISP-HEADER01]  
ATMEGA3290@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA329P@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA32L ATMEGA32L(ISP) [ISP-  
HEADER01]  
ATMEGA32L(new) ATMEGA32L(new)  
(fast)  
ATMEGA32L(new)(fast)@MLF44 [(SA712)]  
ATMEGA32L(new)(fast)@PLCC44 [(SA244)]  
ATMEGA32L(new)(fast)@TQFP44 [(SA245A)]  
ATMEGA32L(new)@MLF44 [(SA712)] ATMEGA32L(new)@PLCC44  
[(SA244)]  
ATMEGA32L(new)@TQFP44 [(SA245A)] ATMEGA32L@MLF44  
[(SA712)]  
ATMEGA32L@MLF44(ISP) [ISP-HEADER01]  
ATMEGA32L@PLCC44 [(SA244)] ATMEGA32L@TQFP44  
[(SA245A)]  
ATMEGA32L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA406@LQFP48 [(SA248)]  
ATMEGA48  
ATMEGA48(ISP) [ISP-HEADER01] ATMEGA48@MLP32  
[(SA686)]  
ATMEGA48@MLP32(ISP) [ISP-HEADER01]  
ATMEGA48@TQFP32 [(SA663)]  
ATMEGA48@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA48P ATMEGA48P@MLP32  
[(SA686)]  
ATMEGA48P@TQFP32 [(SA663)]  
ATMEGA48PV ATMEGA48PV@TQFP32  
[(SA663)]  
ATMEGA48V ATMEGA48V(ISP) [ISP-  
HEADER01]  
ATMEGA48V@MLP32 [(SA686)]  
ATMEGA48V@MLP32(ISP) [ISP-HEADER01]

ATMEGA48V@TQFP32 [(SA663)]  
ATMEGA48V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA64@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA644 ATMEGA644(ISP) [ISP-  
HEADER01]  
ATMEGA644@MLF44 [(SA712)]  
ATMEGA644@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644@TQFP44 [(SA245A)]  
ATMEGA644@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644P ATMEGA644P(ISP) [ISP-  
HEADER01]  
ATMEGA644P@MLF44 [(SA712)]  
ATMEGA644P@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644P@TQFP44 [(SA245A)]  
ATMEGA644P@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644PV ATMEGA644PV(ISP) [ISP-  
HEADER01]  
ATMEGA644PV@MLF44 [(SA712)]  
ATMEGA644PV@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644PV@TQFP44 [(SA245A)]  
ATMEGA644PV@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644V ATMEGA644V(ISP) [ISP-  
HEADER01]  
ATMEGA644V@MLF44 [(SA712)]  
ATMEGA644V@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644V@TQFP44 [(SA245A)]  
ATMEGA644V@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA645@QFN64(ISP) [ISP-HEADER01]  
ATMEGA645@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA6450@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA649@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA6490@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA649V@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64L@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64L@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA8 ATMEGA8  
(fast)  
ATMEGA8(fast)@TQFP32 [(SA663)] ATMEGA8(ISP) [ISP-  
HEADER01]  
ATMEGA8@MLF32 [(SA686)]  
ATMEGA8@MLF32(ISP) [ISP-HEADER01]  
ATMEGA8@TQFP32 [(SA663)]

ATMEGA8@TQFP32( ISP) [ ISP-HEADER01 ]  
ATMEGA8515 ATMEGA8515  
( fast )  
ATMEGA8515( fast )@PLCC44 [ ( SA244 ) ]  
ATMEGA8515( fast )@TQFP44 [ ( SA245A ) ]  
ATMEGA8515( ISP) [ ISP-HEADER01 ] ATMEGA8515@PLCC44  
[ ( SA244 ) ]  
ATMEGA8515@PLCC44( ISP) [ ISP-HEADER01 ]  
ATMEGA8515@TQFP44 [ ( SA245A ) ]  
ATMEGA8515@TQFP44( ISP) [ ISP-HEADER01 ]  
ATMEGA8515L ATMEGA8515L  
( fast )  
ATMEGA8515L( fast )@PLCC44 [ ( SA244 ) ]  
ATMEGA8515L( fast )@TQFP44 [ ( SA245A ) ]  
ATMEGA8515L( ISP) [ ISP-HEADER01 ] ATMEGA8515L@PLCC44  
[ ( SA244 ) ]  
ATMEGA8515L@PLCC44( ISP) [ ISP-HEADER01 ]  
ATMEGA8515L@TQFP44 [ ( SA245A ) ]  
ATMEGA8515L@TQFP44( ISP) [ ISP-HEADER01 ]  
ATMEGA8535 ATMEGA8535  
( fast )  
ATMEGA8535( fast )@MLF44 [ ( SA712 ) ]  
ATMEGA8535( fast )@PLCC44 [ ( SA244 ) ]  
ATMEGA8535( fast )@TQFP44 [ ( SA245A ) ]  
ATMEGA8535( ISP) [ ISP-HEADER01 ] ATMEGA8535@PLCC44  
[ ( SA244 ) ]  
ATMEGA8535@PLCC44( ISP) [ ISP-HEADER01 ]  
ATMEGA8535@TQFP44 [ ( SA245A ) ]  
ATMEGA8535@TQFP44( ISP) [ ISP-HEADER01 ]  
ATMEGA8535L ATMEGA8535L  
( fast )  
ATMEGA8535L( fast )@MLF44 [ ( SA712 ) ]  
ATMEGA8535L( fast )@PLCC44 [ ( SA244 ) ]  
ATMEGA8535L( fast )@TQFP44 [ ( SA245A ) ]  
ATMEGA8535L( ISP) [ ISP-HEADER01 ] ATMEGA8535L@PLCC44  
[ ( SA244 ) ]  
ATMEGA8535L@PLCC44( ISP) [ ISP-HEADER01 ]  
ATMEGA8535L@TQFP44 [ ( SA245A ) ]  
ATMEGA8535L@TQFP44( ISP) [ ISP-HEADER01 ]  
ATMEGA88 ATMEGA88( ISP) [ ISP-  
HEADER01 ]  
ATMEGA88@MLP32 [ ( SA686 ) ]  
ATMEGA88@MLP32( ISP) [ ISP-HEADER01 ]

ATMEGA88@TQFP32 [(SA663)]  
ATMEGA88@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA88P ATMEGA88P@MLP32  
[(SA686)]  
ATMEGA88P@TQFP32 [(SA663)]  
ATMEGA88PV  
ATMEGA88PV@MLP32 [(SA686)] ATMEGA88PV@TQFP32  
[(SA663)]  
ATMEGA88V ATMEGA88V(ISP) [ISP-  
HEADER01]  
ATMEGA88V@MLP32 [(SA686)]  
ATMEGA88V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA88V@TQFP32 [(SA663)]  
ATMEGA88V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA8L ATMEGA8L  
(fast)  
ATMEGA8L(fast)@TQFP32 [(SA663)] ATMEGA8L(ISP) [ISP-  
HEADER01]  
ATMEGA8L@MLF32 [(SA686)]  
ATMEGA8L@MLF32(ISP) [ISP-HEADER01]  
ATMEGA8L@TQFP32 [(SA663)]  
ATMEGA8L@TQFP32(ISP) [ISP-HEADER01]  
ATtiny10 ATtiny10(ISP) [ISP-  
HEADER01]  
ATtiny10@SOIC8 [(SA605A)]  
ATtiny10@SOIC8(ISP) [ISP-HEADER01]  
ATtiny11 ATtiny11(ISP) [ISP-  
HEADER01]  
ATtiny11@SOIC8 [(SA605A)]  
ATtiny11@SOIC8(ISP) [ISP-HEADER01]  
ATtiny11L ATtiny11L(ISP) [ISP-  
HEADER01]  
ATtiny11L@SOIC8 [(SA605A)]  
ATtiny11L@SOIC8(ISP) [ISP-HEADER01]  
ATtiny12 ATtiny12(ISP) [ISP-  
HEADER01]  
ATtiny12@SOIC8 [(SA605A)]  
ATtiny12@SOIC8(ISP) [ISP-HEADER01]  
ATtiny12L ATtiny12L(ISP) [ISP-  
HEADER01]  
ATtiny12L@SOIC8 [(SA605A)]  
ATtiny12L@SOIC8(ISP) [ISP-HEADER01]  
ATtiny12V ATtiny12V(ISP) [ISP-

```

HEADER01 ]
ATtiny12V@SOIC8 [(SA605A)]
ATtiny12V@SOIC8(ISP) [ISP-HEADER01]
ATtiny13                               ATtiny13
(Fuse)
ATtiny13(Fuse)@QFN10 [(SA695A)]       ATtiny13(Fuse)@QFN20
[(SA692)]
ATtiny13(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13(ISP) [ISP-HEADER01]          ATtiny13@QFN10
[(SA695A)]
ATtiny13@QFN10(ISP) [ISP-HEADER01]
ATtiny13@QFN20 [(SA692)]
ATtiny13@QFN20(ISP) [ISP-HEADER01]
ATtiny13@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
ATtiny13@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
ATtiny13V                               ATtiny13V
(Fuse)
ATtiny13V(Fuse)@QFN10 [(SA695A)]       ATtiny13V(Fuse)@QFN20
[(SA692)]
ATtiny13V(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13V(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13V(ISP) [ISP-HEADER01]          ATtiny13V@QFN10
[(SA695A)]
ATtiny13V@QFN10(ISP) [ISP-HEADER01]
ATtiny13V@QFN20 [(SA692)]
ATtiny13V@QFN20(ISP) [ISP-HEADER01]
ATtiny13V@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13V@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
ATtiny13V@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13V@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
ATtiny15                               ATtiny15(ISP) [ISP-
HEADER01]
ATtiny15@SOIC8 [(SA605A)]
ATtiny15@SOIC8(ISP) [ISP-HEADER01]
ATtiny15L                               ATtiny15L(ISP) [ISP-
HEADER01]
ATtiny15L@SOIC8 [(SA605A)]
ATtiny15L@SOIC8(ISP) [ISP-HEADER01]
ATtiny2313                             ATtiny2313(ISP) [ISP-
HEADER01]

```

ATtiny2313@MLF20 [(SA692)]  
ATtiny2313@MLF20(ISP) [ISP-HEADER01]  
ATtiny2313@SOIC20 [(SA404)]  
ATtiny2313@SOIC20(ISP) [ISP-HEADER01]  
ATtiny2313V  
ATtiny2313V(ISP) [ISP-  
HEADER01]  
ATtiny2313V@MLF20 [(SA692)]  
ATtiny2313V@MLF20(ISP) [ISP-HEADER01]  
ATtiny2313V@SOIC20 [(SA404)]  
ATtiny2313V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny24  
ATtiny24  
(Fuse)  
ATtiny24(Fuse)@QFN20 [(SA692)]  
ATtiny24(Fuse)@SOIC14  
[(SA602)]  
ATtiny24(ISP) [ISP-HEADER01]  
ATtiny24@QFN20  
[(SA692)]  
ATtiny24@QFN20(ISP) [ISP-HEADER01]  
ATtiny24@SOIC14 [(SA602)]  
ATtiny24@SOIC14(ISP) [ISP-HEADER01]  
ATtiny24V  
ATtiny24V  
(Fuse)  
ATtiny24V(Fuse)@QFN20 [(SA692)]  
ATtiny24V(Fuse)@SOIC14  
[(SA602)]  
ATtiny24V(ISP) [ISP-HEADER01]  
ATtiny24V@QFN20  
[(SA692)]  
ATtiny24V@QFN20(ISP) [ISP-HEADER01]  
ATtiny24V@SOIC14 [(SA602)]  
ATtiny24V@SOIC14(ISP) [ISP-HEADER01]  
ATtiny25  
ATtiny25(ISP) [ISP-  
HEADER01]  
ATtiny25@QFN20 [(SA692)]  
ATtiny25@QFN20(ISP) [ISP-HEADER01]  
ATtiny25@SOIC8 [(SA023A)]  
ATtiny25@SOIC8(ISP) [ISP-HEADER01]  
ATtiny26  
ATtiny26(ISP) [ISP-  
HEADER01]  
ATtiny26(new)  
ATtiny26(new)(ISP) [ISP-HEADER01]  
ATtiny26(new)@QFN32 [(SA686)]  
ATtiny26(new)@SOIC20  
[(SA404)]  
ATtiny26(new)@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26(new)@TSSOP20 [(SA026)]  
ATtiny26(new)@TSSOP20(ISP) [ISP-HEADER01]



ATtiny26@QFN32 [(SA686)] ATtiny26@SOIC20  
[(SA404)]  
ATtiny26@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26@TSSOP20 [(SA026)]  
ATtiny26@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny261 ATtiny261(ISP) [ISP-  
HEADER01]  
ATtiny261@MLP32 [(SA686)]  
ATtiny261@MLP32(ISP) [ISP-HEADER01]  
ATtiny261@SOIC20 [(SA404)]  
ATtiny261@SOIC20(ISP) [ISP-HEADER01]  
ATtiny261V ATtiny261V(ISP) [ISP-  
HEADER01]  
ATtiny261V@MLP32 [(SA686)]  
ATtiny261V@MLP32(ISP) [ISP-HEADER01]  
ATtiny261V@SOIC20 [(SA404)]  
ATtiny261V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L ATtiny26L(ISP) [ISP-  
HEADER01]  
ATtiny26L(new)  
ATtiny26L(new)(ISP) [ISP-HEADER01]  
ATtiny26L(new)@QFN32 [(SA686)] ATtiny26L(new)@SOIC20  
[(SA404)]  
ATtiny26L(new)@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L(new)@TSSOP20 [(SA026)]  
ATtiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny26L@QFN32 [(SA686)] ATtiny26L@SOIC20  
[(SA404)]  
ATtiny26L@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L@TSSOP20 [(SA026)]  
ATtiny26L@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny28L ATtiny28L@TQFP32  
[(SA663)]  
ATtiny28V ATtiny28V@TQFP32  
[(SA663)]  
ATtiny44 ATtiny44(ISP) [ISP-  
HEADER01]  
ATtiny44@QFN20 [(SA692)]  
ATtiny44@QFN20(ISP) [ISP-HEADER01]  
ATtiny44@SOIC14 [(SA602)]  
ATtiny44@SOIC14(ISP) [ISP-HEADER01]  
ATtiny45  
ATtiny45(ISP)(12V) [ISP-HEADER01]

ATtiny45(ISP)(5V) [ISP-HEADER01]      ATtiny45@QFN20  
[(SA692)]  
ATtiny45@QFN20(ISP)(12V) [ISP-HEADER01]  
ATtiny45@QFN20(ISP)(5V) [ISP-HEADER01]  
ATtiny45@SOIC8 [(S605)]  
ATtiny45@SOIC8(ISP)(12V) [ISP-HEADER01]  
ATtiny45@SOIC8(ISP)(5V) [ISP-HEADER01]  
ATtiny461      ATtiny461(ISP) [ISP-  
HEADER01]  
ATtiny461@MLP32 [(SA686)]  
ATtiny461@MLP32(ISP) [ISP-HEADER01]  
ATtiny461@SOIC20 [(SA404)]  
ATtiny461@SOIC20(ISP) [ISP-HEADER01]  
ATtiny461V      ATtiny461V(ISP) [ISP-  
HEADER01]  
ATtiny461V@MLP32 [(SA686)]  
ATtiny461V@MLP32(ISP) [ISP-HEADER01]  
ATtiny461V@SOIC20 [(SA404)]  
ATtiny461V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny48      ATtiny48@MLF32  
[(SA686)]  
ATtiny48@TQFP32 [(SA663)]  
ATtiny48V      ATtiny48V@TQFP32  
ATtiny48V@MLF32 [(SA686)]  
[(SA663)]  
ATtiny84      ATtiny84(ISP) [ISP-  
HEADER01]  
ATtiny84@QFN20 [(SA692)]  
ATtiny84@QFN20(ISP) [ISP-HEADER01]  
ATtiny84@SOIC14 [(SA602)]  
ATtiny84@SOIC14(ISP) [ISP-HEADER01]  
ATtiny85      ATtiny85@QFN20  
ATtiny85(ISP)(12V) [ISP-HEADER01]  
ATtiny85(ISP)(5V) [ISP-HEADER01]  
[(SA692)]  
ATtiny85@QFN20(ISP)(12V) [ISP-HEADER01]  
ATtiny85@QFN20(ISP)(5V) [ISP-HEADER01]  
ATtiny85@SOIC8 [(S605)]  
ATtiny85@SOIC8(ISP)(12V) [ISP-HEADER01]  
ATtiny85@SOIC8(ISP)(5V) [ISP-HEADER01]  
ATtiny861      ATtiny861(ISP) [ISP-  
HEADER01]  
ATtiny861@MLP32 [(SA686)]

ATtiny861@MLP32(ISP) [ISP-HEADER01]  
ATtiny861@SOIC20 [(SA404)]  
ATtiny861@SOIC20(ISP) [ISP-HEADER01]  
ATtiny861V ATTtiny861V(ISP) [ISP-  
HEADER01]  
ATtiny861V@MLP32 [(SA686)]  
ATtiny861V@MLP32(ISP) [ISP-HEADER01]  
ATtiny861V@SOIC20 [(SA404)]  
ATtiny861V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny88 ATTtiny88@MLF32  
[(SA686)]  
ATtiny88@TQFP32 [(SA663)]  
ATtiny88V  
ATtiny88V@MLF32 [(SA686)] ATTtiny88V@TQFP32  
[(SA663)]  
T89F64 ATTtiny88V@TQFP32  
[(SA244)] T89F64@PLCC44  
T89F64@TQFP44 [(SA245A)]

## ATMEL W&M

### MICROCONTROLLER

AT89C5115@PLCC28 [(SA008A)] ATT89C5115@SOIC28  
[(SA404)]  
AT89C5115@TQFP32 [(SA663)] ATT89C51CC02@PLCC28  
[(SA008A)]  
AT89C51CC02@SOIC28 [(SA404)] ATT89C51CC02@TQFP32  
[(SA663)]  
T89C5115@PLCC28 [(SA008A)] T89C5115@SOIC28  
[(SA404)]  
T89C5115@TQFP32 [(SA663)] T89C51AC2@PLCC44  
[(SA244)]  
T89C51AC2@TQFP44 [(SA245A)] T89C51CC01@PLCC44  
[(SA244)]  
T89C51CC01@TQFP44 [(SA245A)] T89C51CC02@PLCC28  
[(SA008A)]  
T89C51CC02@SOIC24 [(SA404)] T89C51CC02@SOIC28  
[(SA404)]  
T89C51CC02@TQFP32 [(SA663)] T89C51IB2@PLCC44  
[(SA244)]  
T89C51IB2@TQFP44 [(SA245A)] T89C51IC2@PLCC44

[ ( SA244 ) ]  
T89C51IC2@TQFP44 [ ( SA245A ) ]  
T89C51RB2  
T89C51RB2@PLCC44 [ ( SA244 ) ] T89C51RB2@TQFP44  
[ ( SA245A ) ]  
T89C51RC2 T89C51RC2@PLCC44  
[ ( SA244 ) ]  
T89C51RC2@TQFP44 [ ( SA245A ) ]  
T89C51RD2  
T89C51RD2@PLCC44 [ ( SA244 ) ] T89C51RD2@TQFP44  
[ ( SA245A ) ]  
T89F64 T89F64@PLCC44  
[ ( SA244 ) ]  
T89F64@TQFP44 [ ( SA245A ) ]  
TS87C51RB2  
TS87C51RB2@PLCC44 [ ( SA244 ) ] TS87C51RB2@TQFP44  
[ ( SA245A ) ]  
TS87C51RC2 TS87C51RC2@PLCC44  
[ ( SA244 ) ]  
TS87C51RC2@TQFP44 [ ( SA245A ) ]  
TS87C51RD2  
TS87C51RD2@PLCC44 [ ( SA244 ) ] TS87C51RD2@TQFP44  
[ ( SA245A ) ]  
TS87C51U2 TS87C51U2@PLCC44  
[ ( SA244 ) ]  
TS87C51U2@TQFP44 [ ( SA245A ) ]  
TS87C52X2  
TS87C52X2@PLCC44 [ ( SA244 ) ] TS87C52X2@TQFP44  
[ ( SA245A ) ]  
TS87C54X2 TS87C54X2@PLCC44  
[ ( SA244 ) ]  
TS87C54X2@TQFP44 [ ( SA245A ) ]  
TS87C58X2  
TS87C58X2@PLCC44 [ ( SA244 ) ] TS87C58X2@TQFP44  
[ ( SA245A ) ]  
TSC87251A1@PLCC44 [ ( SA244 ) ]  
TSC87251G1  
TSC87251G1@PLCC44 [ ( SA244 ) ]  
TSC87251G1A  
TSC87251G1A@PLCC44 [ ( SA244 ) ]  
TSC87251G2D  
TSC87251G2D@PLCC44 [ ( SA244 ) ] TSC87251G2D@TQFP44  
[ ( SA245A ) ]

TSC87C51

[ ( SA244 ) ]

TSC87C51@TQFP44 [ ( SA245A ) ]

TSC87C51@PLCC44

## ATMEL-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

AT24C01

AT24C02

AT24C04

AT24C08

AT24C16

## AUSTIN

### E ( E ) PROM / FRAM / NVRAM

AS8E512K8

[ ( SA661 ) ]

AS8E512K8@SOJ32

## BELLING-SYSTRON

### MICROCONTROLLER

CM5001

## BENCHMARQ

### E ( E ) PROM / FRAM / NVRAM

BQ4010

BQ4010Y

BQ4011

BQ4011Y

BQ4013

BQ4013Y

BQ4014

BQ4014Y  
BQ4015  
BQ4015Y  
BQ4832Y  
BQ4842Y

## BMT

### E ( E ) PROM / FRAM / NVRAM

BM29LV160B@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
BM29LV160B@TSOP48 [ ( SA247-B005 ) ]  
BM29LV160T@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
BM29LV160T@TSOP48 [ ( SA247-B005 ) ]

## BOSEN

### E ( E ) PROM / FRAM / NVRAM

M28W320FST@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640FSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
PC28F640P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
PC28F640P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
S71WS256NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
SST39VF800@TSOP48 [ ( SA247 ) ]  
SST39VF800A@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST39VF800A@TSOP48 [ ( SA247 ) ]                   SST39VF800Q@TSOP48  
[ ( SA247 ) ]

## BRIGHT

### E ( E ) PROM / FRAM / NVRAM

BM29F040 [ ( SA015A1T ) ]	BM29F040@PLCC32
BM29F040@TSOP32 [ ( SA410T ) ]	BM29F400B@PSOP44 [ ( SA638- B006 ) ]
BM29F400B@TSOP48 [ ( SA247-B005 ) ]	BM29F400T@PSOP44 [ ( SA638-

B006 ) ]  
 BM29F400T@TSOP48 [ ( SA247-B005 ) ]

## CATALYST

### E ( E ) PROM / FRAM / NVRAM

CAT1021 ( L )	CAT1021
( P )	
CAT1021 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1021 ( S ) @ SOIC8
[ ( SA602A ) ]	
CAT1021 ( U ) @ TSSOP8 [ ( SA026 ) ]	CAT1021 ( V ) @ SOIC8
[ ( SA602A ) ]	
CAT1021 ( Y ) @ TSSOP8 [ ( SA026 ) ]	CAT1021 ( Z ) @ MSOP8
[ ( SA026 ) ]	
CAT1022 ( L )	CAT1022
( P )	
CAT1022 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1022 ( S ) @ SOIC8
[ ( SA602A ) ]	
CAT1022 ( U ) @ TSSOP8 [ ( SA026 ) ]	CAT1022 ( V ) @ SOIC8
[ ( SA602A ) ]	
CAT1022 ( Y ) @ TSSOP8 [ ( SA026 ) ]	CAT1022 ( Z ) @ MSOP8
[ ( SA026 ) ]	
CAT1023 ( L )	CAT1023
( P )	
CAT1023 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1023 ( S ) @ SOIC8
[ ( SA602A ) ]	
CAT1023 ( U ) @ TSSOP8 [ ( SA026 ) ]	CAT1023 ( V ) @ SOIC8
[ ( SA602A ) ]	
CAT1023 ( Y ) @ TSSOP8 [ ( SA026 ) ]	CAT1023 ( Z ) @ MSOP8
[ ( SA026 ) ]	
CAT1024 ( L )	CAT1024
( P )	
CAT1024 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1024 ( S ) @ SOIC8
[ ( SA602A ) ]	
CAT1024 ( U ) @ TSSOP8 [ ( SA026 ) ]	CAT1024 ( V ) @ SOIC8
[ ( SA602A ) ]	
CAT1024 ( Y ) @ TSSOP8 [ ( SA026 ) ]	CAT1024 ( Z ) @ MSOP8
[ ( SA026 ) ]	
CAT1025 ( L )	CAT1025
( P )	
CAT1025 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1025 ( S ) @ SOIC8

[ (SA602A) ]	
CAT1025(U)@TSSOP8 [ (SA026) ]	CAT1025(V)@SOIC8
[ (SA602A) ]	
CAT1025(Y)@TSSOP8 [ (SA026) ]	CAT1025(Z)@MSOP8
[ (SA026) ]	
CAT1026(L)	CAT1026
(P)	
CAT1026(R)@MSOP8 [ (SA026) ]	CAT1026(S)@SOIC8
[ (SA602A) ]	
CAT1026(U)@TSSOP8 [ (SA026) ]	CAT1026(V)@SOIC8
[ (SA602A) ]	
CAT1026(Y)@TSSOP8 [ (SA026) ]	CAT1026(Z)@MSOP8
[ (SA026) ]	
CAT1027(L)	CAT1027
(P)	
CAT1027(R)@MSOP8 [ (SA026) ]	CAT1027(S)@SOIC8
[ (SA602A) ]	
CAT1027(U)@TSSOP8 [ (SA026) ]	CAT1027(V)@SOIC8
[ (SA602A) ]	
CAT1027(Y)@TSSOP8 [ (SA026) ]	CAT1027(Z)@MSOP8
[ (SA026) ]	
CAT1161(J)@SOIC8 [ (SA602A) ]	CAT1161
(P)	
CAT1162(J)@SOIC8 [ (SA602A) ]	CAT1162
(P)	
CAT1163(J)@SOIC8 [ (SA602A) ]	CAT1163
(P)	
CAT1320	CAT1320@SOIC8
[ (SA602A) ]	
CAT1320@TDFN8	CAT1320@TSSOP8
[ (SA026) ]	
CAT1321	CAT1321@SOIC8
[ (SA602A) ]	
CAT1321@TDFN8	CAT1321@TSSOP8
[ (SA026) ]	
CAT14002@SOIC8 [ (SA602A) ]	CAT14004@SOIC8
[ (SA602A) ]	
CAT14008@SOIC8 [ (SA602A) ]	CAT14016@SOIC8
[ (SA602A) ]	
CAT15002@SOIC8 [ (SA602A) ]	CAT15004@SOIC8
[ (SA602A) ]	
CAT15008@SOIC8 [ (SA602A) ]	CAT15016@SOIC8
[ (SA602A) ]	



CAT1640 [ (SA602A) ] CAT1640@TDFN8 [ (SA026) ] CAT1641 [ (SA602A) ] CAT1641@TDFN8 [ (SA026) ] CAT2210 [ (SA404) ] CAT2210I [ (SA404) ] CAT2212 [ (SA404) ] CAT2212I [ (SA404) ] CAT22C10 [ (SA404) ] CAT22C10I [ (SA404) ] CAT22C12 [ (SA404) ] CAT22C12I [ (SA404) ] CAT24AC128 [ (SA602A) ] CAT24AC128@TSSOP14 [ (SA026) ] [ (SA724) ] CAT24C00 [ (SA602A) ] CAT24C00@TSSOP8 [ (SA026) ] CAT24C01 CAT24C01@SOIC14 [ (SA602) ] [ (SA602A) ] CAT24C01@TSSOP8 [ (SA026) ] [ (SA602A) ] CAT24C01B(L) (P) CAT24C01B(R)@MSOP8 [ (SA026) ] [ (SA026) ] CAT24C01B(W)@SOIC8 [ (SA602A) ] [ (SA026) ] CAT24C01B(Z)@MSOP8 [ (SA026) ]	CAT1640@SOIC8  CAT1640@TSSOP8  CAT1641@SOIC8  CAT1641@TSSOP8  CAT2210@SOIC16  CAT2210I@SOIC16  CAT2212@SOIC20  CAT2212I@SOIC20  CAT22C10@SOIC16  CAT22C10I@SOIC16  CAT22C12@SOIC20  CAT22C12I@SOIC20  CAT24AC128@SOIC8  CAT24AC128@UDFN8  CAT24C00@SOIC8  CAT24C01@SOIC8  CAT24C01B(J)@SOIC8  CAT24C01B  CAT24C01B(U)@TSSOP8  CAT24C01B(Y)@TSSOP8
--	---

CAT24C02  
CAT24C02@SOIC14 [ (SA602) ]  
[ (SA602A) ]  
CAT24C02@TSSOP8 [ (SA026) ]  
CAT24C021  
CAT24C022  
CAT24C023  
CAT24C03  
CAT24C03@SOIC8  
[ (SA602A) ]  
CAT24C03@TSSOP8 [ (SA026) ]  
CAT24C04  
CAT24C04@SOIC14 [ (SA602) ]  
[ (SA602A) ]  
CAT24C04@TSSOP8 [ (SA026) ]  
CAT24C041  
CAT24C042  
CAT24C043  
CAT24C05  
CAT24C05@SOIC8  
[ (SA602A) ]  
CAT24C05@TSSOP8 [ (SA026) ]  
CAT24C08  
CAT24C08@SOIC14 [ (SA602) ]  
[ (SA602A) ]  
CAT24C08@TSSOP8 [ (SA026) ]  
CAT24C081  
CAT24C082  
CAT24C083  
CAT24C08I  
CAT24C08I@SOIC8  
[ (SA602A) ]  
CAT24C09  
CAT24C09@SOIC8  
[ (SA602A) ]  
CAT24C09@TSSOP8 [ (SA026) ]  
CAT24C128  
CAT24C128@SOIC8 [ (SA602A) ]  
[ (SA724) ]  
CAT24C16  
CAT24C16@SOIC14  
[ (SA602) ]  
CAT24C16@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
CAT24C161  
CAT24C162  
CAT24C163  
CAT24C164

CAT24C164@SOIC8 [(SA602A)]	CAT24C164@TSSOP8
[(SA026)]	
CAT24C16I	CAT24C16I@SOIC8
[(SA602A)]	
CAT24C208(J)@SOIC8 [(SA602A)]	CAT24C208
(L)	
CAT24C208(P)	CAT24C208(R)@MSOP8
[(SA666)]	
CAT24C208(U)@TSSOP8 [(SA026)]	CAT24C208(W)@SOIC8
[(SA602A)]	
CAT24C208(Y)@TSSOP8 [(SA026)]	CAT24C208(Z)@MSOP8
[(SA666)]	
CAT24C21	CAT24C21@SOIC8
[(SA602A)]	
CAT24C21@TSSOP8 [(SA026)]	
CAT24C256	
CAT24C256@SOIC8 [(SA602A)]	CAT24C256@TDFN8
[(SA683)]	
CAT24C256@TSSOP8 [(SA026)]	
CAT24C32	
CAT24C32@SOIC8 [(SA602A)]	
CAT24C44	
CAT24C44@SOIC8 [(SA602A)]	
CAT24C64	
CAT24C64@SOIC8 [(SA602A)]	
CAT24F32	
CAT24F32@SOIC8 [(SA602A)]	CAT24F32@TSSOP8
[(SA026)]	
CAT24F32A	CAT24F32A@SOIC8
[(SA602A)]	
CAT24F32A@TSSOP8 [(SA026)]	
CAT24FC01	
CAT24FC01@SOIC14 [(SA602)]	CAT24FC01@SOIC8
[(SA602A)]	
CAT24FC01@TSSOP8 [(SA026)]	
CAT24FC02	
CAT24FC02@SOIC14 [(SA602)]	CAT24FC02@SOIC8
[(SA602A)]	
CAT24FC02@TSSOP8 [(SA026)]	
CAT24FC16	
CAT24FC16@SOIC14 [(SA602)]	CAT24FC16@SOIC8
[(SA602A)]	
CAT24FC16@TSSOP8 [(SA026)]	

CAT24FC17	
CAT24FC17@SOIC8 [(SA602A)]	CAT24FC17@TSSOP8
[(SA026)]	
CAT24FC256	CAT24FC256@SOIC8
[(SA602A)]	
CAT24FC256@TDFN8 [(SA683)]	CAT24FC256@TSSOP8
[(SA026)]	
CAT24FC32	CAT24FC32@SOIC8
[(SA602A)]	
CAT24FC32@TDFN8 [(SA683)]	CAT24FC32@TSSOP8
[(SA026)]	
CAT24FC64	CAT24FC64@SOIC8
[(SA602A)]	
CAT24FC64@TDFN8 [(SA683)]	CAT24FC64@TSSOP8
[(SA026)]	
CAT24FC65	CAT24FC65@SOIC8
[(SA602A)]	
CAT24FC65@TDFN8 [(SA683)]	CAT24FC65@TSSOP8
[(SA026)]	
CAT24FC66	CAT24FC66@SOIC8
[(SA602A)]	
CAT24FC66@TDFN8 [(SA683)]	CAT24FC66@TSSOP8
[(SA026)]	
CAT24LC02	CAT24LC02@SOIC8
[(SA602A)]	
CAT24LC02@TSSOP8 [(SA026)]	
CAT24WC01	
CAT24WC01@SOIC8 [(SA602A)]	CAT24WC01@TSSOP8
[(SA026)]	
CAT24WC02	CAT24WC02@SOIC8
[(SA602A)]	
CAT24WC02@TSSOP8 [(SA026)]	
CAT24WC03	
CAT24WC03@SOIC8 [(SA602A)]	CAT24WC03@TSSOP8
[(SA026)]	
CAT24WC04	CAT24WC04@SOIC8
[(SA602A)]	
CAT24WC04@TSSOP8 [(SA026)]	
CAT24WC05	
CAT24WC05@SOIC8 [(SA602A)]	CAT24WC05@TSSOP8
[(SA026)]	
CAT24WC08	CAT24WC08@SOIC8
[(SA602A)]	

CAT24WC08@TSSOP8 [(SA026)]	
CAT24WC09	
CAT24WC09@SOIC8 [(SA602A)]	CAT24WC09@TSSOP8
[(SA026)]	
CAT24WC128	
[(SA602A)]	CAT24WC128@SOIC8
CAT24WC129	
[(SA602A)]	CAT24WC129@SOIC8
CAT24WC16	
[(SA602A)]	CAT24WC16@SOIC8
CAT24WC16@TSSOP8 [(SA026)]	
CAT24WC164	
CAT24WC164@SOIC8 [(SA602A)]	CAT24WC164@TSSOP8
[(SA026)]	
CAT24WC17	
[(SA602A)]	CAT24WC17@SOIC8
CAT24WC17@TSSOP8 [(SA026)]	
CAT24WC256	
CAT24WC256@SOIC8 [(SA602A)]	CAT24WC256@TDFN8
[(SA683)]	
CAT24WC256@TSSOP8 [(SA026)]	
CAT24WC257	
CAT24WC257@SOIC8 [(SA605A)]	
CAT24WC32	
CAT24WC32@SOIC8 [(SA602A)]	
CAT24WC33	
CAT24WC33@SOIC8 [(SA602A)]	
CAT24WC64	
CAT24WC64@SOIC8 [(SA602A)]	
CAT24WC65	
CAT24WC65@SOIC8 [(SA602A)]	
CAT24WC66	
CAT24WC66@SOIC8 [(SA602A)]	
CAT25010	
CAT25010(S)@SOIC8 [(SA605A)]	CAT25010(U)@TSSOP8
[(SA602A)]	
CAT25020	
[(SA605A)]	CAT25020(S)@SOIC8
CAT25020(U)@TSSOP8 [(SA602A)]	
CAT25040	
CAT25040(S)@SOIC8 [(SA605A)]	CAT25040(U)@TSSOP8
[(SA602A)]	
CAT25080	CAT25080@SOIC8

[ (SA602A) ]  
CAT25080@TDFN8 [ (SA724) ] CAT25080@TSSOP8  
[ (SA026) ]  
CAT25080@UDFN8 [ (BBBB) ]  
CAT25128  
CAT25128@SOIC8[150 mil] [ (SA602A) ]  
CAT25128@SOIC8[208 mil] [ (SA605A) ]  
CAT25128@TDFN8 [ (SA724) ] CAT25128@TSSOP8  
[ (SA026) ]  
CAT25160 CAT25160@SOIC8  
[ (SA602A) ]  
CAT25160@TDFN8 [ (SA724) ] CAT25160@TSSOP8  
[ (SA026) ]  
CAT25160@UDFN8 [ (BBBB) ]  
CAT25256  
CAT25256@SOIC8[150 mil] [ (SA602A) ]  
CAT25256@SOIC8[208 mil] [ (SA605A) ]  
CAT25256@TDFN8 [ (SA602A) ] CAT25256@TSSOP8  
[ (SA026) ]  
CAT25320 CAT25320@SOIC8  
[ (SA602A) ]  
CAT25320@TDFN8 [ (SA724) ] CAT25320@TSSOP8  
[ (SA026) ]  
CAT25640 CAT25640@SOIC8  
[ (SA602A) ]  
CAT25640@TDFN8 [ (SA724) ] CAT25640@TSSOP8  
[ (SA026) ]  
CAT25C01 CAT25C01@SOIC16  
[ (SA602) ]  
CAT25C01@SOIC8 [ (SA602A) ] CAT25C01@TSSOP14  
[ (SA026) ]  
CAT25C01@TSSOP8 [ (SA026) ]  
CAT25C02  
CAT25C02@SOIC16 [ (SA602) ] CAT25C02@SOIC8  
[ (SA602A) ]  
CAT25C02@TSSOP14 [ (SA026) ] CAT25C02@TSSOP8  
[ (SA026) ]  
CAT25C03 CAT25C03@SOIC8  
[ (SA602A) ]  
CAT25C03@TSSOP14 [ (SA026) ] CAT25C03@TSSOP8  
[ (SA026) ]  
CAT25C04 CAT25C04@SOIC16  
[ (SA602) ]

CAT25C04@SOIC8 [(SA602A)]	CAT25C04@TSSOP14
[(SA026)]	
CAT25C04@TSSOP8 [(SA026)]	
CAT25C05	
CAT25C05@SOIC8 [(SA602A)]	CAT25C05@TSSOP14
[(SA026)]	
CAT25C05@TSSOP8 [(SA026)]	
CAT25C08	
CAT25C08@SOIC16 [(SA602)]	CAT25C08@SOIC8
[(SA602A)]	
CAT25C08@TSSOP14 [(SA026)]	CAT25C08@TSSOP8
[(SA026)]	
CAT25C09	CAT25C09@SOIC8
[(SA602A)]	
CAT25C09@TSSOP14 [(SA026)]	CAT25C09@TSSOP8
[(SA026)]	
CAT25C11	CAT25C11@SOIC8
[(SA602A)]	
CAT25C11@TSSOP14 [(SA026)]	CAT25C11@TSSOP8
[(SA026)]	
CAT25C128	CAT25C128@SOIC16
[(SA602)]	
CAT25C128@SOIC8[150 mil] [(SA602A)]	
CAT25C128@SOIC8[208 mil] [(SA605A)]	
CAT25C128@TSSOP14 [(SA026)]	CAT25C128@TSSOP20
[(SA026)]	
CAT25C16	CAT25C16@SOIC16
[(SA602)]	
CAT25C16@SOIC8 [(SA602A)]	CAT25C16@TSSOP14
[(SA026)]	
CAT25C16@TSSOP8 [(SA026)]	
CAT25C17	
CAT25C17@SOIC8 [(SA602A)]	CAT25C17@TSSOP14
[(SA026)]	
CAT25C17@TSSOP8 [(SA026)]	
CAT25C256	
CAT25C256@SOIC16 [(SA602)]	
CAT25C256@SOIC8[150 mil] [(SA602A)]	
CAT25C256@SOIC8[208 mil] [(SA605A)]	
CAT25C256@TSSOP14 [(SA026)]	CAT25C256@TSSOP20
[(SA026)]	
CAT25C32	CAT25C32@SOIC8
[(SA602A)]	

CAT25C32@TSSOP14 [(SA026)]	CAT25C32@TSSOP20
[(SA026)]	
CAT25C33	CAT25C33@SOIC8
[(SA602A)]	
CAT25C33@TSSOP14 [(SA026)]	
CAT25C64	
CAT25C64@SOIC8 [(SA602A)]	CAT25C64@TSSOP14
[(SA026)]	
CAT25C64@TSSOP20 [(SA026)]	
CAT25C65	
CAT25C65@SOIC8 [(SA602A)]	CAT25C65@TSSOP14
[(SA026)]	
CAT27010	CAT27010@PLCC32
[(SA015A1T)]	
CAT27010@TSOP32 [(SA410T)]	
CAT27128A	
CAT27256	
CAT27512	
CAT27512@PLCC32 [(SA015A1T)]	
CAT2764A	
CAT27C16A	
CAT27C210	
CAT27C210@PLCC44 [(SA244)]	
CAT27HC256	
CAT27HC256@PLCC32 [(SA015A1T)]	
CAT27HC256I	
CAT27HC256I@PLCC32 [(SA015A1T)]	
CAT28C16A	
CAT28C16A@PLCC32 [(SA015A1T)]	CAT28C16A@SOIC24
[(SA404)]	
CAT28C16AI	CAT28C16AI@PLCC32
[(SA015A1T)]	
CAT28C16AI@SOIC24 [(SA404)]	
CAT28C17A	
CAT28C17A@PLCC32 [(SA015A1T)]	
CAT28C17AI	
CAT28C17AI@PLCC32 [(SA015A1T)]	
CAT28C256	
CAT28C256@PLCC32 [(SA015A1T)]	CAT28C256@TSOP28
[(SA430T)]	
CAT28C256I	CAT28C256I@PLCC32
[(SA015A1T)]	
CAT28C256I@TSOP28 [(SA430T)]	



CAT28C257	
CAT28C257@PLCC32 [(SA015A1T)]	CAT28C257@TSOP28
[(SA430T)]	
CAT28C512	CAT28C512@PLCC32
[(SA015A1T)]	
CAT28C512@TSOP32 [(SA410T)]	CAT28C512@TSOP40
[(SA409T)]	
CAT28C513@PLCC32 [(SA015A1T)]	
CAT28C64A	
CAT28C64A@PLCC32 [(SA015A1T)]	CAT28C64A@SOIC28
[(SA404)]	
CAT28C64AI	CAT28C64AI@PLCC32
[(SA015A1T)]	
CAT28C64AI@SOIC28 [(SA404)]	
CAT28C64B	
CAT28C64B@PLCC32 [(SA015A1T)]	CAT28C64B@TSOP28
[(SA430T)]	
CAT28C64BI	CAT28C64BI@PLCC32
[(SA015A1T)]	
CAT28C64BI@TSOP28 [(SA430T)]	
CAT28C65B	
CAT28C65B@PLCC32 [(SA015A1T)]	CAT28C65B@TSOP28
[(SA430T)]	
CAT28C65BI	CAT28C65BI@PLCC32
[(SA015A1T)]	
CAT28C65BI@TSOP28 [(SA430T)]	CAT28F001N-B@PLCC32
[(SA015A1T)]	
CAT28F001N-T@PLCC32 [(SA015A1T)]	CAT28F001P-
B	
CAT28F001P-T	CAT28F001T-B@TSOP32
[(SA410T)]	
CAT28F001T-T@TSOP32 [(SA410T)]	
CAT28F002	
CAT28F002@TSOP40 [(SA409T)]	
CAT28F010	
CAT28F010@PLCC32 [(SA015A1T)]	CAT28F010@TSOP32
[(SA410T)]	
CAT28F010I	CAT28F010I@PLCC32
[(SA015A1T)]	
CAT28F010I@TSOP32 [(SA410T)]	
CAT28F020	
CAT28F020(REVERSE)@TSOP32 [(SA410T)]	
CAT28F020@PLCC32 [(SA015A1T)]	CAT28F020@TSOP32

[ (SA410T) ]	
CAT28F020I	CAT28F020I@PLCC32
[ (SA015A1T) ]	
CAT28F020I@TSOP32 [ (SA410T) ]	
CAT28F102	
CAT28F102@PLCC44 [ (SA244) ]	CAT28F102@TSOP40
[ (SA409T) ]	
CAT28F512	CAT28F512@PLCC32
[ (SA015A1T) ]	
CAT28F512@TSOP32 [ (SA410T) ]	
CAT28F512I	
CAT28F512I@PLCC32 [ (SA015A1T) ]	CAT28F512I@TSOP32
[ (SA410T) ]	
CAT28LV256	CAT28LV256@PLCC32
[ (SA015A1T) ]	
CAT28LV256@TSOP28 [ (SA430T) ]	
CAT28LV64	
CAT28LV64@PLCC32 [ (SA015A1T) ]	CAT28LV64@TSOP28
[ (SA430T) ]	
CAT28LV65	CAT28LV65@PLCC32
[ (SA015A1T) ]	
CAT28LV65@TSOP28 [ (SA430T) ]	CAT33C101
(08bit)	
CAT33C101(08bit)@SOIC8 [ (SA602A) ]	
CAT33C101(16bit)	
CAT33C101(16bit)@SOIC8 [ (SA602A) ]	
CAT33C101H(08bit)	
CAT33C101H(08bit)@SOIC8 [ (SA602A) ]	
CAT33C101H(16bit)	
CAT33C101H(16bit)@SOIC8 [ (SA602A) ]	
CAT33C101I(08bit)	
CAT33C101I(08bit)@SOIC8 [ (SA602A) ]	
CAT33C101I(16bit)	
CAT33C101I(16bit)@SOIC8 [ (SA602A) ]	
CAT33C104(08bit)	
CAT33C104(08bit)@SOIC8 [ (SA602A) ]	
CAT33C104(16bit)	
CAT33C104(16bit)@SOIC8 [ (SA602A) ]	
CAT33C104I(08bit)	
CAT33C104I(08bit)@SOIC8 [ (SA602A) ]	
CAT33C104I(16bit)	
CAT33C104I(16bit)@SOIC8 [ (SA602A) ]	
CAT34AC02	CAT34AC02@SOIC8

[ (SA602A) ]	
CAT34AC02@TSSOP8 [ (SA026) ]	
CAT34C02	
CAT34C02@SOIC8 [ (SA602A) ]	CAT34C02@TDFN8
[ (SA694) ]	
CAT34C02@TSSOP8 [ (SA026) ]	
CAT34FC02	
CAT34FC02@SOIC8 [ (SA602A) ]	CAT34FC02@TDFN8
[ (SA694) ]	
CAT34FC02@TSSOP8 [ (SA026) ]	
CAT34RC02	
CAT34RC02@SOIC8 [ (SA602A) ]	CAT34RC02@TDFN8
[ (SA694) ]	
CAT34RC02@TSSOP8 [ (SA026) ]	
CAT34WC02	
CAT34WC02@SOIC8 [ (SA602A) ]	CAT34WC02@TDFN8
[ (SA694) ]	
CAT34WC02@TSSOP8 [ (SA026) ]	
CAT35C102	
CAT35C102H	
CAT35C102I	
CAT35C104(08bit)	
CAT35C104(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104(16bit)	
CAT35C104(16bit)@SOIC8 [ (SA602A) ]	
CAT35C104H(08bit)	
CAT35C104H(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104I(08bit)	
CAT35C104I(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104I(16bit)	
CAT35C104I(16bit)@SOIC8 [ (SA602A) ]	
CAT59C11	CAT59C11@SOIC8
[ (SA602A) ]	
CAT59C11A	CAT59C11A@SOIC8
[ (SA602A) ]	
CAT59C11H	CAT59C11H@SOIC8
[ (SA602A) ]	
CAT59C11I	CAT59C11I@SOIC8
[ (SA602A) ]	
CAT64LC10(J)@SOIC8 [ (SA602A) ]	CAT64LC10
(P)	
CAT64LC10(S)@SOIC8 [ (SA602A) ]	CAT64LC10(U)@TSSOP8
[ (SA026) ]	

CAT64LC10(UR)@TSSOP8 [(SA026)]	CAT64LC20(J)@SOIC8
[(SA602A)]	
CAT64LC20(P)	CAT64LC20(S)@SOIC8
[(SA602A)]	
CAT64LC20(U)@TSSOP8 [(SA026)]	CAT64LC20(UR)@TSSOP8
[(SA026)]	
CAT64LC40(J)@SOIC8 [(SA602A)]	CAT64LC40
(P)	
CAT64LC40(S)@SOIC8 [(SA602A)]	CAT64LC40(U)@TSSOP8
[(SA026)]	
CAT64LC40(UR)@TSSOP8 [(SA026)]	CAT93C46
(08bit)	
CAT93C46(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C46(16bit)	
CAT93C46(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(16bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(U)@TSSOP8 [(SA026)]	
CAT93C46A	CAT93C56
(08bit)	
CAT93C56(08bit)@SOIC8 [(SA602A)]	CAT93C56
(16bit)	
CAT93C56(16bit)@SOIC8 [(SA602A)]	
CAT93C56A	
CAT93C57	CAT93C66
(08bit)	
CAT93C66(08bit)@SOIC8 [(SA602A)]	CAT93C66(08bit)@TSSOP8
[(SA026)]	
CAT93C66(16bit)	CAT93C66(16bit)@SOIC8
[(SA602A)]	
CAT93C66(16bit)@TSSOP8 [(SA026)]	
CAT93C66A	
CAT93C76(08bit)	
CAT93C76(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C76(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C76(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C76(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C76(16bit)	
CAT93C76(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C76(16bit)(K)@SOIC8 [(SA605A)]	

CAT93C76(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(08bit)  
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(16bit)  
CAT93C86(16bit)(J)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(08bit)  
CAT93H46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(16bit)  
CAT93H46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(08bit)  
CAT93HC46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93HC46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93HC46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93HC46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(16bit)  
CAT93HC46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93HC46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93HC46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93HC46(16bit)(U)@TSSOP8 [(SA026)]

## DRAM & SRAM

CAT71C256 [(SA643)]	CAT71C256@TSOP28
CAT71C256L [(SA643)]	CAT71C256L@TSOP28

## CELESTICA

## E ( E ) PROM / FRAM / NVRAM

SST49LF160C@TSOP40 [ ( SA409T ) ]

## CERAMATE

### E ( E ) PROM / FRAM / NVRAM

24LC02 [ ( SA602A ) ]	24LC02@SOIC8
24LC02@TSSOP8 [ ( SA026 ) ]	
24LC08 24LC08@SOIC8 [ ( SA602A ) ]	24LC08@TSSOP8
[ ( SA026 ) ]	
24LC16 [ ( SA602A ) ]	24LC16@SOIC8
24LC16@TSSOP8 [ ( SA026 ) ]	
24LLC02 24LLC02@SOIC8 [ ( SA602A ) ]	24LLC02@TSSOP8
[ ( SA026 ) ]	
24LLC08 [ ( SA602A ) ]	24LLC08@SOIC8
24LLC08@TSSOP8 [ ( SA026 ) ]	
93LC46 93LC46@SOIC8 [ ( SA602A ) ]	
93LC46R 93LC46R@SOIC8 [ ( SA602A ) ]	
93LC56 93LC56@SOIC8 [ ( SA602A ) ]	
93LC66 93LC66@SOIC8 [ ( SA602A ) ]	

## CFeon

### E ( E ) PROM / FRAM / NVRAM

EN29LV800BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]

EN29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800CB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800CB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800CT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800CT@TSOP48 [ ( SA247-B005 ) ]

## CHINA CORE

### MICROCONTROLLER

CCM89C51 [ ( SA244 ) ]	CCM89C51@PLCC44
CCM89C51@TQFP44 [ ( SA245A ) ]	
CCM89C52 CCM89C52@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	CCM89C52@TQFP44

## CHINGIS

### E ( E ) PROM / FRAM / NVRAM

PM24C64 [ ( SA602A ) ]	PM24C64@SOIC8
PM24C64@TSOP8 [ ( SA026 ) ] [ ( SA023A ) ]	PM25LV010 ( B ) @SOIC8
PM25LV010 ( Q ) @WSON8 [ ( SA683 ) ] [ ( SA602A ) ]	PM25LV010 ( S ) @SOIC8
PM25LV010A@SOIC8 [ ( SA602A ) ] [ ( SA683 ) ]	PM25LV010A@WSON8
PM25LV016@SOIC8 [ ( SA605A ) ] [ ( SA683 ) ]	PM25LV016@WSON8
PM25LV016A@SOIC8 [ ( SA605A ) ] [ ( SA683 ) ]	PM25LV016A@WSON8
PM25LV020 ( B ) @SOIC8 [ ( SA023A ) ] [ ( SA683 ) ]	PM25LV020 ( Q ) @WSON8
PM25LV020 ( S ) @SOIC8 [ ( SA602A ) ] [ ( SA023A ) ]	PM25LV040 ( B ) @SOIC8
PM25LV040 ( Q ) @WSON8 [ ( SA683 ) ] [ ( SA602A ) ]	PM25LV040 ( S ) @SOIC8
PM25LV080@SOIC8 [ ( SA605A ) ]	PM25LV080@WSON8

[ (SA683) ]	
PM25LV080A@SOIC8 [ (SA605A) ]	PM25LV080A@WSON8
[ (SA683) ]	
PM25LV512(B)@SOIC8 [ (SA023A) ]	PM25LV512(Q)@WSON8
[ (SA683) ]	
PM25LV512(S)@SOIC8 [ (SA602A) ]	
PM29F002B	
PM29F002B@PLCC32 [ (SA015A1T) ]	
PM29F002T	
PM29F002T@PLCC32 [ (SA015A1T) ]	
PM29F004B	
PM29F004B@PLCC32 [ (SA015A1T) ]	
PM29F004T	
PM29F004T@PLCC32 [ (SA015A1T) ]	
PM29LV002B	
PM29LV002B@PLCC32 [ (SA015A1T) ]	PM29LV002B@VSOP32
[ (SA620) ]	
PM29LV002T	PM29LV002T@PLCC32
[ (SA015A1T) ]	
PM29LV002T@VSOP32 [ (SA620) ]	PM29LV004B@PLCC32
[ (SA015A1T) ]	
PM29LV004B@VSOP32 [ (SA620) ]	PM29LV004T@PLCC32
[ (SA015A1T) ]	
PM29LV004T@VSOP32 [ (SA620) ]	PM29LV104RB@PLCC32
[ (SA015A1T) ]	
PM29LV104RB@VSOP32 [ (SA620) ]	PM29LV104RT@PLCC32
[ (SA015A1T) ]	
PM29LV104RT@VSOP32 [ (SA620) ]	
PM37LV512	
PM37LV512@PLCC32 [ (SA015A1T) ]	PM37LV512@VSOP32
[ (SA620) ]	
PM39F010	PM39F010@PLCC32
[ (SA015A1T) ]	
PM39F010@VSOP32 [ (SA620) ]	
PM39F020	
PM39F020@PLCC32 [ (SA015A1T) ]	PM39F020@VSOP32
[ (SA620) ]	
PM39F040	PM39F040@PLCC32
[ (SA015A1T) ]	
PM39F040@VSOP32 [ (SA620) ]	PM39LV010@PLCC32
[ (SA015A1T) ]	
PM39LV010@VSOP32 [ (SA620) ]	PM39LV010R@PLCC32
[ (SA015A1T) ]	



PM39LV010R@VSOP32 [ (SA620) ] [ (SA015A1T) ]	PM39LV020@PLCC32
PM39LV020@VSOP32 [ (SA620) ] [ (SA015A1T) ]	PM39LV040@PLCC32
PM39LV040@VSOP32 [ (SA620) ] [ (SA015A1T) ]	PM39LV512@PLCC32
PM39LV512@VSOP32 [ (SA620) ] [ (SA015A1T) ]	PM39LV512R@PLCC32
PM39LV512R@VSOP32 [ (SA620) ] [ (SA015A1T) ]	PM49FL002T@PLCC32
PM49FL002T@VSOP32 [ (SA620) ]	
PM49FL004T(Low)@PLCC32 [ (SA015A1T-B001) ]	
PM49FL004T(Low)@VSOP32 [ (SA620-B005) ]	
PM49FL004T@PLCC32 [ (SA015A1T) ] [ (SA620) ]	PM49FL004T@VSOP32
PM49FL008T@PLCC32 [ (SA015A1T) ] [ (SA620) ]	PM49FL008T@VSOP32
PM49LP002T@PLCC32 [ (SA015A1T) ] [ (SA620) ]	PM49LP002T@VSOP32

## CHIPCON

### MICROCONTROLLER

CC1010@TQFP64(ISP) [ISP-HEADER01]

## CHIPSWINNER

### E(E) PROM/FRAM/NVRAM

CW24C02 [ (SA602A) ]	CW24C02@SOIC8
CW24C04 [ (SA602A) ]	CW24C04@SOIC8
CW24C08 [ (SA602A) ]	CW24C08@SOIC8
CW24C16 [ (SA602A) ]	CW24C16@SOIC8
CW24C32 [ (SA602A) ]	CW24C32@SOIC8

CW24C64  
[ ( SA602A ) ]

CW24C64@SOIC8

## MICROCONTROLLER

CW88CS028@SDIP28 [ ( SA653 ) ]  
[ ( SA653 ) ]

CW88CS032@SDIP32

CW88CS128@SDIP28 [ ( SA653 ) ]  
[ ( SA653 ) ]

CW88CS132@SDIP32

CW89F1050

CW89F2050

CW89F4050@SDIP28 [ ( SA653 ) ]  
[ ( SA404 ) ]

CW89F4050@SOP28

CW89F52

[ ( SA675 ) ]

CW89F52@LQFP44

CW89F54

[ ( SA675 ) ]

CW89F54@LQFP44

## CORERIVER

### E ( E ) PROM / FRAM / NVRAM

CR24C02LI  
[ ( SA602 ) ]

CR24C02WI@SOIC8

CR24C08LI  
[ ( SA602 ) ]

CR24C08WI@SOIC8

CR24C16LI  
[ ( SA602 ) ]

CR24C16WI@SOIC8

CR24C256LI  
[ ( SA602 ) ]

CR24C256WI@SOIC8

CR24C32LI  
[ ( SA602 ) ]

CR24C32WI@SOIC8

CR24C64LI  
[ ( SA602 ) ]

CR24C64WI@SOIC8

## CWI

### E ( E ) PROM / FRAM / NVRAM

39LV040@VSOP32 [(SA620)]

**CYGNAL****MICROCONTROLLER**

C8051F000@TQFP64(ISP) [(PEP+S616)]  
 C8051F001@TQFP48(ISP) [(SA248)] C8051F002@TQFP32(ISP)  
 [(SA663)]  
 C8051F005@TQFP64(ISP) [(PEP+S616)]  
 C8051F006@TQFP48(ISP) [(SA248)] C8051F007@TQFP32(ISP)  
 [(SA663)]  
 C8051F010@TQFP64(ISP) [(PEP+S616)]  
 C8051F011@TQFP48(ISP) [(SA248)] C8051F012@TQFP32(ISP)  
 [(SA663)]  
 C8051F015@TQFP64(ISP) [(PEP+S616)]  
 C8051F016@TQFP48(ISP) [(SA248)] C8051F017@TQFP32(ISP)  
 [(SA663)]  
 C8051F018@TQFP64(ISP) [(PEP+S616)]  
 C8051F019@TQFP48(ISP) [(SA248)]  
 C8051F020@TQFP100(ISP) [ISP-HEADER01]  
 C8051F021@TQFP64(ISP) [ISP-HEADER01]  
 C8051F022@TQFP100(ISP) [ISP-HEADER01]  
 C8051F023@TQFP64(ISP) [ISP-HEADER01]  
 C8051F040@TQFP100(ISP) [ISP-HEADER01]  
 C8051F041@TQFP64(ISP) [ISP-HEADER01]  
 C8051F042@TQFP100(ISP) [ISP-HEADER01]  
 C8051F043@TQFP64(ISP) [ISP-HEADER01]  
 C8051F044@TQFP100(ISP) [ISP-HEADER01]  
 C8051F045@TQFP64(ISP) [ISP-HEADER01]  
 C8051F046@TQFP100(ISP) [ISP-HEADER01]  
 C8051F047@TQFP64(ISP) [ISP-HEADER01]  
 C8051F206@TQFP48 [(SA248)] C8051F220@TQFP48  
 [(SA248)]  
 C8051F221@TQFP32 [(SA663)] C8051F226@TQFP48  
 [(SA248)]  
 C8051F230@TQFP48 [(SA248)] C8051F231@TQFP32  
 [(SA663)]  
 C8051F236@TQFP48 [(SA248)] C8051F300  
 [(SA695A)]  
 C8051F301 [(SA695A)] C8051F302  
 [(SA695A)]

C8051F303 [(SA695A)]	C8051F304
[(SA695A)]	
C8051F305 [(SA695A)]	C8051F310@TQFP32
[(SA663)]	
C8051F310-GQ@TQFP32 [(SA663)]	C8051F311@QFN28 [(SA697-
B006)]	
C8051F311-GM@QFN28 [(SA697-B006)]	
C8051F312@TQFP32 [(SA663)]	C8051F312-GQ@TQFP32
[(SA663)]	
C8051F313@QFN28 [(SA697-B006)]	
C8051F313-GM@QFN28 [(SA697-B006)]	
C8051F314@TQFP32 [(SA663)]	C8051F314-GQ@TQFP32
[(SA663)]	
C8051F315@QFN28 [(SA697-B006)]	
C8051F315-GM@QFN28 [(SA697-B006)]	
C8051F316-GM@QFN24 [(SA710-B006)]	
C8051F317-GM@QFN24 [(SA710-B006)]	
C8051F320@TQFP32 [(SA663)]	C8051F321@QFN28 [(SA697-
B006)]	
C8051F326@QFN28 [(SA697-B006)]	
C8051F326-GQ@QFN28 [(SA697-B006)]	
C8051F327@QFN28 [(SA697-B006)]	
C8051F327-GQ@QFN28 [(SA697-B006)]	
C8051F330@MLP20 [(SA692)]	
C8051F330D	
C8051F331@MLP20 [(SA692)]	C8051F332-GM@MLP20
[(SA692)]	
C8051F333-GM@MLP20 [(SA692)]	C8051F334-GM@MLP20
[(SA692)]	
C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20
[(SA692)]	
C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24
[(SA710)]	
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48
[(SA248)]	
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32
[(SA663)]	
C8051F343-GQ@LQFP32 [(SA663)]	C8051F344-GQ@TQFP48
[(SA248)]	
C8051F345-GQ@TQFP48 [(SA248)]	C8051F346-GQ@LQFP32
[(SA663)]	
C8051F347-GQ@LQFP32 [(SA663)]	C8051F350-GQ@LQFP32
[(SA663)]	

C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F360@QFP48 [(SA248)]	C8051F361@QFP32
[(SA663)]	
C8051F362@QFN28 [(SA697)]	C8051F363@QFP48
[(SA248)]	
C8051F364@QFP32 [(SA663)]	C8051F365@QFN28
[(SA697)]	
C8051F366@QFP32 [(SA663)]	C8051F367@QFN28
[(SA697)]	
C8051F368@QFP32 [(SA663)]	C8051F369@QFN28
[(SA697)]	
C8051F410-GQ@LQFP32 [(SA663)]	C8051F411-GM@QFN28
[(SA697)]	
C8051F412-GQ@LQFP32 [(SA663)]	C8051F413-GM@QFN28
[(SA697)]	
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10
[(SA695A)]	
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10
[(SA695A)]	
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10
[(SA695A)]	
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20
[(SA026)]	
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20
[(SA026)]	
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20
[(SA026)]	
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20
[(SA026)]	
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20
[(SA026)]	
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20
[(SA026)]	
C8051F610-GQ@QFP32 [(SA663)]	
C8051F611-GM@QFN28 [(SA697-B006)]	
C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	

SI8250@LQFP32 [(SA663)]  
 [(SA697)]  
 SI8251@LQFP32 [(SA663)]  
 [(SA697)]  
 SI8252@LQFP32 [(SA663)]  
 [(SA697)]

SI8250@QFN28  
 SI8251@QFN28  
 SI8252@QFN28

## CYPRESS

### E(E)PROM/FRAM/NVRAM

CY14B256L@SOIC32 [(SA715)]

CY27C010

CY27C010@PLCC32 [(SA015A1T)]  
 [(SA410T)]

CY27C020  
 [(SA015A1T)]

CY27C020@TSOP32 [(SA410T)]

CY27C040

CY27C040@PLCC32 [(SA015A1T)]  
 [(SA410T)]

CY27C128  
 [(SA015A1T)]

CY27C256  
 [(SA015A1T)]

CY27C256@TSOP28 [(SA430T)]

CY27C512

CY27C512@PLCC32 [(SA015A1T)]  
 [(SA430T)]

CY27H010  
 [(SA015A1T)]

CY27H010@TSOP32 [(SA410T)]

CY27H256

CY27H256@PLCC32 [(SA015A1T)]  
 [(SA430T)]

CY27H512  
 [(SA015A1T)]

CY27H512@TSOP28 [(SA430T)]

CY7C225A

CY7C225A@PLCC28 [(SA008A)]

CY7C243

CY7C243@PLCC28 [(SA008A)]

CY27C010@TSOP32

CY27C020@PLCC32

CY27C040@TSOP32

CY27C128@PLCC32

CY27C256@PLCC32

CY27C512@TSOP28

CY27H010@PLCC32

CY27H256@TSOP28

CY27H512@PLCC32

CY7C244  
CY7C244@PLCC28 [(SA008A)]  
CY7C245  
CY7C245@PLCC28 [(SA008A)]  
CY7C245A  
CY7C245A@PLCC28 [(SA008A)]  
CY7C251  
CY7C251@PLCC32 [(SA015A1T)]  
CY7C254  
CY7C254@PLCC32 [(SA015A1T)]  
CY7C256  
CY7C256@PLCC32 [(SA015A1T)]  
CY7C261  
CY7C261@PLCC28 [(SA008A)]  
CY7C263  
CY7C263@PLCC28 [(SA008A)]  
CY7C264  
CY7C264@PLCC28 [(SA008A)]  
CY7C265  
CY7C265@PLCC28 [(SA008A)]  
CY7C266  
CY7C266@PLCC32 [(SA015A1T)]  
CY7C268  
CY7C268@PLCC32 [(SA015A1T)]  
CY7C271  
CY7C271@PLCC32 [(SA015A1T)]  
CY7C271A  
CY7C271A@PLCC32 [(SA015A1T)]  
CY7C274  
CY7C274@PLCC32 [(SA015A1T)]  
[(SA244)]  
CY7C276(25JC)@PLCC44 [(SA244)]  
[(SA244)]  
CY7C281  
[(SA008A)]  
CY7C281A  
[(SA008A)]  
CY7C282  
[(SA008A)]  
CY7C282A  
[(SA008A)]  
CY7C285  
[(SA015A1T)]

CY7C276(25HC)@PLCC44  
CY7C276(30JC)@PLCC44  
CY7C281@PLCC28  
CY7C281A@PLCC28  
CY7C282@PLCC28  
CY7C282A@PLCC28  
CY7C285@PLCC32

CY7C286 [ (SA015A1T) ]	CY7C286@PLCC32
CY7C287 [ (SA015A1T) ]	CY7C287@PLCC32
CY7C291 [ (SA008A) ]	CY7C291@PLCC28
CY7C291A [ (SA008A) ]	CY7C291A@PLCC28
CY7C292 [ (SA008A) ]	CY7C292@PLCC28
CY7C292A [ (SA008A) ]	CY7C292A@PLCC28
CY7C293A [ (SA008A) ]	CY7C293A@PLCC28
CY8C9520@SSOP28 [ (SA626A) ] [ (SA669) ]	CY8C9540@SSOP48

**DRAM & SRAM**

CY62128@SOIC32 [ (SA687) ] [ (SA661) ]	CY62128@SOJ32
CY62128@VSOP32 [ (SA620) ] [ (SA687) ]	CY62128L@SOIC32
CY62128L@SOJ32 [ (SA661) ] [ (SA620) ]	CY62128L@VSOP32
CY62128LL@SOIC32 [ (SA687) ] [ (SA661) ]	CY62128LL@SOJ32
CY62128LL@VSOP32 [ (SA620) ] [ (SA645) ]	CY7C1011@TSOP44
CY7C1020@TSOP44 [ (SA645) ] [ (SA645) ]	CY7C1021@TSOP44
CY7C1049@SOJ36 [ (SA027) ] [ (SA645) ]	CY7C1049@TSOP44
CY7C107 [ (SA661) ]	CY7C107@SOJ28
CY7C147 CY7C167 CY7C167@PLCC20 [ (SA001A) ] CY7C167A CY7C167A@PLCC20 [ (SA001A) ]	
CY7C185 CY7C185@SOIC28 [ (SA404) ]	CY7C185@SOJ28



[ (SA646) ]  
CY7C186  
CY7C187  
CY7C187@SOJ24 [ (SA646) ]  
CY7C187A  
CY7C187A@SOJ24 [ (SA646) ]  
CY7C193  
CY7C193@SOJ28 [ (SA646) ]  
CY7C199  
CY7C199@PLCC28 [ (SA008A) ] CY7C199@SOJ28  
[ (SA646) ]  
CY7C199@TSOP28 [ (SA430T) ]

**PLD**

CY2291@SOIC20 [ (SA404) ] CY2292@SOIC16  
[ (SA602) ]  
CY2295@SSOP28 [ (SA626A) ] CY37032@PLCC44  
[ (SA244) ]  
CY37032@TQFP44 [ (SA245A) ] CY37032V@PLCC44  
[ (SA244) ]  
CY37032V@TQFP44 [ (SA245A) ] CY37064@PLCC44  
[ (SA244) ]  
CY37064@PLCC44 (ISP) [ ISP-HEADER01 ]  
CY37064@TQFP44 [ (SA245A) ]  
CY37064@TQFP44 (ISP) [ ISP-HEADER01 ]  
CY37064V@PLCC44 [ (SA244) ]  
CY37064V@PLCC44 (ISP) [ ISP-HEADER01 ]  
CY37064V@TQFP44 [ (SA245A) ]  
CY37064V@TQFP44 (ISP) [ ISP-HEADER01 ]  
CY7C371@PLCC44 [ (SA244) ] CY7C371@TQFP44  
[ (SA245A) ]  
CY7C371I@PLCC44 [ (SA244) ] CY7C371I@TQFP44  
[ (SA245A) ]  
CY7C372@PLCC44 [ (SA244) ] CY7C372@TQFP44  
[ (SA245A) ]  
CY7C372I@PLCC44 [ (SA244) ] CY7C372I@TQFP44  
[ (SA245A) ]  
PALC16L8 PALC16L8@PLCC20  
[ (SA001A) ]  
PALC16L8L PALC16L8L@PLCC20  
[ (SA001A) ]

PALC16R4 [ (SA001A) ]	PALC16R4@PLCC20
PALC16R4L [ (SA001A) ]	PALC16R4L@PLCC20
PALC16R6 [ (SA001A) ]	PALC16R6@PLCC20
PALC16R6L [ (SA001A) ]	PALC16R6L@PLCC20
PALC16R8 [ (SA001A) ]	PALC16R8@PLCC20
PALC16R8L [ (SA001A) ]	PALC16R8L@PLCC20
PALC22V10 [ (SA008A) ]	PALC22V10@PLCC28
PALC22V10A [ (SA008A) ]	PALC22V10A@PLCC28
PALC22V10B [ (SA008A) ]	PALC22V10B@PLCC28
PALC22V10D [ (SA008A) ]	PALC22V10D@PLCC28
PALC22V10L [ (SA008A) ]	PALC22V10L@PLCC28
PALCE16V8 [ (SA001A) ]	PALCE16V8@PLCC20
PALCE20V8 [ (SA008A) ]	PALCE20V8@PLCC28
PALCE20V8L [ (SA008A) ]	PALCE20V8L@PLCC28
PALCE22V10 [ (SA008A) ]	PALCE22V10@PLCC28

## MICROCONTROLLER

CY7C63722 [ (SA404) ]	CY7C63722@SOIC18
CY7C63722C [ (SA404) ]	CY7C63722C@SOIC18
CY7C63723 [ (SA404) ]	CY7C63723@SOIC18
CY7C63723C [ (SA404) ]	CY7C63723C@SOIC18
CY7C63742	CY7C63742@QSOP24

[ (SA674) ]	
CY7C63742@SOIC24 [ (SA404) ]	
CY7C63742C	
CY7C63742C@QSOP24 [ (SA674) ]	CY7C63742C@SOIC24
[ (SA404) ]	
CY7C63743	
[ (SA674) ]	
CY7C63743@SOIC24 [ (SA404) ]	CY7C63743@QSOP24
CY7C63743C	
CY7C63743C@QSOP24 [ (SA674) ]	CY7C63743C@SOIC24
[ (SA404) ]	
CY7C63813	
[ (SA404) ]	CY7C63813@SOIC18

## DALLAS

### E ( E ) PROM / FRAM / NVRAM

DS1073M-100	DS1073M-
60	
DS1073M-66	DS1073M-
80	
DS1073Z-100@SOIC8 [ (SA602A) ]	DS1073Z-60@SOIC8
[ (SA602A) ]	
DS1073Z-66@SOIC8 [ (SA602A) ]	DS1073Z-80@SOIC8
[ (SA602A) ]	
DS1077LZ-40@SOIC8 [ (SA602A) ]	DS1077LZ-50@SOIC8
[ (SA602A) ]	
DS1077LZ-60@SOIC8 [ (SA602A) ]	DS1077LZ-66@SOIC8
[ (SA602A) ]	
DS1077Z-40@SOIC8 [ (SA602A) ]	DS1077Z-50@SOIC8
[ (SA602A) ]	
DS1077Z-60@SOIC8 [ (SA602A) ]	DS1077Z-66@SOIC8
[ (SA602A) ]	
DS1220AB	
DS1220AD	
DS1220Y	
DS1225AB	
DS1225AD	
DS1225D	
DS1225E	
DS1225Y	

DS1230AB  
DS1230W  
DS1230Y  
DS1235AB  
DS1235Y  
DS1243Y  
DS1244  
DS1244Y  
DS1245AB  
DS1245EE  
DS1245P  
DS1245W  
DS1245Y  
DS1248P  
DS1248W  
DS1248Y  
DS1249AB  
DS1249W  
DS1249Y  
DS1250AB  
DS1250W  
DS1250Y  
DS1251AB  
DS1251W  
DS1251Y  
DS1256P  
DS1256W  
DS1256Y  
DS1258AB  
DS1258W  
DS1258Y  
DS1265AB  
DS1265W  
DS1265Y  
DS1270AB  
DS1270W  
DS1270Y  
DS1284  
DS1284N  
[ (SA008A) ]  
DS1284QN@PLCC28 [ (SA008A) ]  
DS1286  
DS1286I

DS1284Q@PLCC28

DS1287  
DS1287A  
DS12887  
DS12887A  
DS12C887  
DS12C887A  
DS1330AB  
DS1330WP  
DS1330Y  
DS1345AB  
DS1345P  
DS1345W  
DS1345Y  
DS1350AB  
DS1350P  
DS1350W  
DS1350Y  
DS1386 ( 32K )  
( 8K )  
DS14285  
DS14287  
DS1485  
[ ( SA630 ) ]  
DS1486  
DS1488  
DS1553  
DS1553W  
DS1554  
DS1554W  
DS1556  
DS1630AB  
DS1630Y  
DS1642  
DS1643  
DS1644  
DS1644P  
DS1645AB  
DS1645EE  
DS1645Y  
DS1646  
DS1647  
DS1647LPM  
DS1650AB

DS1386

DS1485@SOIC28

DS1650Y	DS1687-
3	
DS1687-5	DS17287-
3	
DS17287-5	
DS1742	
DS1742W	
DS1743	
DS1743P	
DS1743W	
DS1743WP	
DS1744	
DS1744P	
DS1744W	
DS1744WP	
DS1746	
DS1747	
DS1747P	
DS1747W	
DS1747WP	
DS17487-3	DS17487-
5	
DS17887-3	DS17887-
5	
DS2406@TO-92	
DS2406P@TSOC6	
DS2430A@TO-92	DS2430AP@TSOC6
[ (SA602A) ]	
DS2431@TO-92	DS2431P@TSOC6
[ (SA602A) ]	
DS2432P@TSOC6 [ (SA602A) ]	DS2433@PR-
35	
DS2433S(3.9)@SOIC8 [ (SA602A) ]	DS2433S(5.5)@SOIC8
[ (SA605A) ]	
DS2502	DS2502P@TSOC6
[ (SA602A) ]	
DS2502S@SOIC8 [ (SA602A) ]	
DS2502UNW	
DS2502UNW@SOIC8 [ (SA602A) ]	DS2502UNW@TSOC6
[ (SA602A) ]	
DS2506	DS2506S@SOIC8
[ (SA023A) ]	
DS4510@uSOP10	DS4520@TSSOP16

[ ( SA026 ) ]  
DS4550@TSSOP20 [ ( SA026 ) ]

## MICROCONTROLLER

DS87C520 [ ( SA244 ) ] DS87C520@TQFP44 [ ( SA245A ) ] DS89C420 DS89C420 ( rev . A ) [ ( SA244 ) ] DS89C420 ( rev . A ) @ TQFP44 [ ( SA245A ) ] DS89C420@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ] DS89C430 [ ( SA244 ) ] DS89C430@TQFP44 [ ( SA245A ) ] DS89C440 DS89C440@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ] DS89C450 [ ( SA244 ) ] DS89C450@TQFP44 [ ( SA245A ) ]	DS87C520@PLCC44    DS89C420 ( rev . A ) @ PLCC44   DS89C420@TQFP44  DS89C430@PLCC44   DS89C440@TQFP44  DS89C450@PLCC44
--	--

## DENSE-PAC

### E ( E ) PROM / FRAM / NVRAM

DPV27C101 [ ( SA015A1T ) ] DPV27C256 [ ( SA015A1T ) ] DPV27C512 [ ( SA015A1T ) ]	DPV27C101@PLCC32  DPV27C256@PLCC32  DPV27C512@PLCC32
---	--

## DEUTRON

### E ( E ) PROM / FRAM / NVRAM

AC25LV010 [ (SA602A) ]	AC25LV010@SOIC8
AC25LV512 [ (SA602A) ]	AC25LV512@SOIC8
P439LV010@PLCC32 [ (SA015A1T) ] [ (SA620) ]	P439LV010@VSOP32
P439LV040@PLCC32 [ (SA015A1T) ] [ (SA620) ]	P439LV040@VSOP32
P439LV088@TSOP48 [ (SA247-B005) ] B005) ]	P439VF800@TSOP48 [ (SA247-

## EFST

### E ( E ) PROM / FRAM / NVRAM

EM25LV010@SOIC8 [ (SA602A) ] [ (SA684) ]	EM25LV010@VFQFPN8
EM25LV512@SOIC8 [ (SA602A) ] [ (SA684) ]	EM25LV512@VFQFPN8
F25L004A@SOIC8 [ (SA602A) ] F49B002UA	
F49B002UA@PLCC32 [ (SA015A1T) ] [ (SA015A1T) ]	F49L004BA@PLCC32
F49L004BA@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	F49L004UA@PLCC32
F49L004UA@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	F49L040A@PLCC32
F49L040A@VSOP32 [ (SA620) ] B005) ]	F49L400BA@TSOP48 [ (SA247-
F49L400UA@TSOP48 [ (SA247-B005) ] [ (SA247) ]	F49L800BA@TSOP48
F49L800UA@TSOP48 [ (SA247) ]	

## ELECTRONIC ARRAYS

### E ( E ) PROM / FRAM / NVRAM

EA2716



**EM****MICROCONTROLLER**

```

EM6503@SOIC24 [(SA404)]
EM6503@SOIC24(ISP) [ISP-HEADER01]
EM6504@SOIC24 [(SA404)]
EM6504@SOIC24(ISP) [ISP-HEADER01]
EM6505@SOIC24 [(SA404)]
EM6505@SOIC24(ISP) [ISP-HEADER01]
EM6517@SOIC28 [(SA404)]
EM6517@SOIC28(ISP) [ISP-HEADER01]
EM6520@TQFP44 [(SA245A)]
EM6520@TQFP44(ISP) [ISP-HEADER01]
EM6521@TQFP52(ISP) [ISP-HEADER01]
EM6522@TQFP64(ISP) [ISP-HEADER01]
EM6540@SOIC18 [(SA404)]
EM6540@SOIC18(ISP) [ISP-HEADER01]
EM6580                                EM6580(ISP) [ISP-
HEADER01]
EM6580@SOIC14 [(SA602)]
EM6580@SOIC14(ISP) [ISP-HEADER01]
EM6580@SOIC8 [(SA602A)]              EM6580@SOIC8(ISP) [ISP-
HEADER01]
EM6580@TSSOP14 [(SA026)]
EM6580@TSSOP14(ISP) [ISP-HEADER01]
EM6812_2K                              EM6812_2K(ISP) [ISP-
HEADER01]
EM6812_2K@SOIC24 [(SA404)]
EM6812_2K@SOIC24(ISP) [ISP-HEADER01]
EM6812_2K@TSSOP24 [(SA026)]
EM6812_2K@TSSOP24(ISP) [ISP-HEADER01]
EM6812_4K                              EM6812_4K(ISP) [ISP-
HEADER01]
EM6812_4K@SOIC24 [(SA404)]
EM6812_4K@SOIC24(ISP) [ISP-HEADER01]
EM6812_4K@TSSOP24 [(SA026)]
EM6812_4K@TSSOP24(ISP) [ISP-HEADER01]
EM6812_8K                              EM6812_8K(ISP) [ISP-
HEADER01]
EM6812_8K@SOIC24 [(SA404)]
EM6812_8K@SOIC24(ISP) [ISP-HEADER01]
EM6812_8K@TSSOP24 [(SA026)]

```

EM6812\_8K@TSSOP24 (ISP) [ISP-HEADER01]

## EMTC

### E (E) PROM / FRAM / NVRAM

EM24C02 [ (SA602A) ]	EM24C02@SOIC8
EM24C02@TSSOP8 [ (SA026) ]	
EM24C04 EM24C04@SOIC8 [ (SA602A) ]	EM24C04@TSSOP8
[ (SA026) ]	
EM24C08 [ (SA602A) ]	EM24C08@SOIC8
EM24C08@TSSOP8 [ (SA026) ]	
EM24C16 EM24C16@SOIC8 [ (SA602A) ]	EM24C16@TSSOP8
[ (SA026) ]	
EM25SL512@SOIC8 [ (SA602A) ]	
EM29SF002AB EM29SF002AB@PLCC32 [ (SA015A1T) ]	EM29SF002AB@TSOP32
[ (SA410T) ]	
EM29SF002AT [ (SA015A1T) ]	EM29SF002AT@PLCC32
EM29SF002AT@TSOP32 [ (SA410T) ]	
EM29SF002NAB EM29SF002NAB@PLCC32 [ (SA015A1T) ]	EM29SF002NAB@TSOP32
[ (SA410T) ]	
EM29SF002NAT [ (SA015A1T) ]	EM29SF002NAT@PLCC32
EM29SF002NAT@TSOP32 [ (SA410T) ]	

## EON

### E (E) PROM / FRAM / NVRAM

EN25B05 (Bottom Boot)@SOP8(4.0) [ (SA602A) ]  
EN25B05 (Bottom Boot)@SOP8(5.4) [ (SA605A) ]  
EN25B05 (Bottom Boot)@VDFN8 [ (SA683) ]  
EN25B05 (Top Boot)@SOP8(4.0) [ (SA602A) ]

EN25B05(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B05(Top Boot)@VDFN8 [(SA683)]  
EN25B10(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B10(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B10(Bottom Boot)@VDFN8 [(SA683)]  
EN25B10(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B10(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B10(Top Boot)@VDFN8 [(SA683)]  
EN25B16(Bottom Boot)@SOP8 [(SA605A)]  
EN25B16(Bottom Boot)@SOP8(ISP) [ISP-HEADER01]  
EN25B16(Bottom Boot)@VFQFN8(ISP) [ISP-HEADER01]  
EN25B16(Bottom Boot)@VFQFPN8 [(SA684)]  
EN25B16(Top Boot)@SOP8 [(SA605A)]  
EN25B16(Top Boot)@SOP8(ISP) [ISP-HEADER01]  
EN25B16(Top Boot)@VFQFN8(ISP) [ISP-HEADER01]  
EN25B16(Top Boot)@VFQFPN8 [(SA684)]  
EN25B20(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B20(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B20(Bottom Boot)@VDFN8 [(SA683)]  
EN25B20(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B20(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B20(Top Boot)@VDFN8 [(SA683)]  
EN25B32(Bottom Boot)@SOIC16 [(SA404)]  
EN25B32(Bottom Boot)@SOIC16(ISP) [(SA404)]  
EN25B32(Bottom Boot)@SOP8 [(SA605A)]  
EN25B32(Bottom Boot)@SOP8(ISP) [(SA605A)]  
EN25B32(Bottom Boot)@VDFN8 [(SA684)]  
EN25B32(Bottom Boot)@VDFN8(ISP) [(SA684)]  
EN25B32(Top Boot)@SOIC16 [(SA404)]  
EN25B32(Top Boot)@SOIC16(ISP) [(SA404)]  
EN25B32(Top Boot)@SOP8 [(SA605A)]  
EN25B32(Top Boot)@SOP8(ISP) [(SA605A)]  
EN25B32(Top Boot)@VDFN8 [(SA684)]  
EN25B32(Top Boot)@VDFN8(ISP) [(SA684)]  
EN25B40(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B40(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B40(Bottom Boot)@VDFN8 [(SA683)]  
EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B40(Top Boot)@VDFN8 [(SA683)]  
EN25B64(Bottom Boot)@SOIC16 [(SA404)]  
EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]  
EN25B64(Bottom Boot)@VDFN8 [(SA683)]

EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]	
EN25B64(Top Boot)@SOIC16 [(SA404)]	
EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]	
EN25B64(Top Boot)@VDFN8 [(SA683)]	
EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]	
EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]	
EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]	
EN25B80(Bottom Boot)@VDFN8 [(SA683)]	
EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]	
EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]	
EN25B80(Top Boot)@VDFN8 [(SA683)]	
EN25D16 [(SA404)]	EN25D16@SOP16
EN25D16@SOP8 [(SA605A)] [(SA684)]	EN25D16@VDFN8
EN25D80 [(SA605A)]	EN25D80@SOP8
EN25D80@VDFN8 [(SA683)] [(SA602A)]	EN25F05@SOP8(4.0)
EN25F05@SOP8(5.4) [(SA605A)] [(SA683)]	EN25F05@VDFN8
EN25F10@SOP8(4.0) [(SA602A)] [(SA605A)]	EN25F10@SOP8(5.4)
EN25F10@VDFN8 [(SA683)]	
EN25F16@SOP16 [(SA404)] [(SA605A)]	EN25F16@SOP8
EN25F16@VDFN8 [(SA684)] [(SA605A)]	EN25F20@SOP8
EN25F20@VDFN8 [(SA683)]	
EN25F32@SOIC16 [(SA404)] [(SA605A)]	EN25F32@SOP8
EN25F32@VDFN8 [(SA684)] [(SA602A)]	EN25F40@SOP8(150mil)
EN25F40@SOP8(209mil) [(SA605A)] [(SA683)]	EN25F40@VDFN8
EN25F80 [(SA605A)]	EN25F80@SOP8
EN25F80@VDFN8 [(SA683)] [(SA602A)]	EN25LF05@SOP8(4.0)
EN25LF05@SOP8(5.4) [(SA605A)] [(SA683)]	EN25LF05@VDFN8

EN25LF10@SOP8(4.0) [(SA602A)]	EN25LF10@SOP8(5.4)
[(SA605A)]	
EN25LF10@VDFN8 [(SA683)]	EN25LV010@SOIC8
[(SA602A)]	
EN25LV010@VFQFPN8 [(SA684)]	EN25LV020@SOIC8
[(SA602A)]	
EN25LV020@VFQFPN8 [(SA684)]	EN25LV040@SOIC8
[(SA602A)]	
EN25LV040@VFQFPN8 [(SA684)]	EN25LV080@SOIC8
[(SA602A)]	
EN25LV080@VFQFPN8 [(SA684)]	EN25LV160@SOIC8
[(SA602A)]	
EN25LV160@SOIC8(ISP) [ISP-HEADER01]	
EN25LV160@VFQFPN8 [(SA683)]	
EN25LV160@VFQFPN8(ISP) [ISP-HEADER01]	
EN25LV512@SOIC8 [(SA602A)]	EN25LV512@VFQFPN8
[(SA684)]	
EN25P05@SOP8(4.0) [(SA602A)]	EN25P05@SOP8(5.4)
[(SA605A)]	
EN25P05@VDFN8 [(SA683)]	EN25P10@SOP8(4.0)
[(SA602A)]	
EN25P10@SOP8(5.4) [(SA605A)]	EN25P10@VDFN8
[(SA683)]	
EN25P16@SOP8 [(SA605A)]	EN25P16@SOP8(ISP) [ISP-
HEADER01]	
EN25P16@VFQFPN8 [(SA684)]	
EN25P16@VFQFPN8(ISP) [ISP-HEADER01]	
EN25P20@SOP8(4.0) [(SA602A)]	EN25P20@SOP8(5.4)
[(SA605A)]	
EN25P20@VDFN8 [(SA683)]	EN25P32@SOIC16
[(SA404)]	
EN25P32@SOIC16(ISP) [(SA404)]	EN25P32@SOP8
[(SA605A)]	
EN25P32@SOP8(ISP) [(SA605A)]	EN25P32@VDFN8
[(SA684)]	
EN25P32@VDFN8(ISP) [(SA684)]	EN25P40@SOP8(4.0)
[(SA602A)]	
EN25P40@SOP8(5.4) [(SA605A)]	EN25P40@VDFN8
[(SA683)]	
EN25P64@SOIC16 [(SA404)]	
EN25P64@SOIC16(ISP) [ISP-HEADER01]	
EN25P64@VDFN8 [(SA683)]	
EN25P64@VDFN8(ISP) [ISP-HEADER01]	

EN25P80@SOP8(4.0) [(SA602A)]	EN25P80@SOP8(5.4)
[(SA605A)]	
EN25P80@VDFN8 [(SA683)]	EN25S16@SOP8
[(SA605A)]	
EN25S16@VFQFPN8 [(SA684)]	
EN25S32(Bottom Boot)@SOIC16 [(SA404)]	
EN25S32(Bottom Boot)@SOIC16(ISP) [(SA404)]	
EN25S32(Bottom Boot)@SOP8 [(SA605A)]	
EN25S32(Bottom Boot)@SOP8(ISP) [(SA605A)]	
EN25S32(Bottom Boot)@VDFN8 [(SA684)]	
EN25S32(Bottom Boot)@VDFN8(ISP) [(SA684)]	
EN25S32(Top Boot)@SOIC16 [(SA404)]	
EN25S32(Top Boot)@SOIC16(ISP) [(SA404)]	
EN25S32(Top Boot)@SOP8 [(SA605A)]	
EN25S32(Top Boot)@SOP8(ISP) [(SA605A)]	
EN25S32(Top Boot)@VDFN8 [(SA684)]	
EN25S32(Top Boot)@VDFN8(ISP) [(SA684)]	
EN25T16@SOP8 [(SA605A)]	EN25T16@VFQFPN8
[(SA684)]	
EN25T80	EN25T80@SOP8
[(SA605A)]	
EN25T80@VDFN8 [(SA683)]	
EN27C010	
EN27C010@PLCC32 [(SA015A1T)]	
EN27C512	
EN27C512@PLCC32 [(SA015A1T)]	
EN29F002AB	
EN29F002AB@PLCC32 [(SA015A1T)]	EN29F002AB@TSOP32
[(SA410T)]	
EN29F002ANB	EN29F002ANB@PLCC32
[(SA015A1T)]	
EN29F002ANB@TSOP32 [(SA410T)]	
EN29F002ANT	
EN29F002ANT@PLCC32 [(SA015A1T)]	EN29F002ANT@TSOP32
[(SA410T)]	
EN29F002AT	EN29F002AT@PLCC32
[(SA015A1T)]	
EN29F002AT@TSOP32 [(SA410T)]	
EN29F002B	
EN29F002B@PLCC32 [(SA015A1T)]	EN29F002B@TSOP32
[(SA410T)]	
EN29F002NB	EN29F002NB@PLCC32
[(SA015A1T)]	

EN29F002NB@TSOP32 [(SA410T)]	
EN29F002NT	
EN29F002NT@PLCC32 [(SA015A1T)]	EN29F002NT@TSOP32
[(SA410T)]	
EN29F002T	EN29F002T@PLCC32
[(SA015A1T)]	
EN29F002T@TSOP32 [(SA410T)]	
EN29F010	
EN29F010@PLCC32 [(SA015A1T)]	EN29F010@TSOP32
[(SA410T)]	
EN29F010@VSOP32 [(SA620)]	
EN29F040	
EN29F040@PLCC32 [(SA015A1T)]	EN29F040@TSOP32
[(SA410T)]	
EN29F040A	EN29F040A@PLCC32
[(SA015A1T)]	
EN29F040A@TSOP32 [(SA410T)]	EN29F080@TSOP40
[(SA409T)]	
EN29F512	EN29F512@PLCC32
[(SA015A1T)]	
EN29F512@TSOP32 [(SA410T)]	EN29F512@VSOP32
[(SA620)]	
EN29F800B@TSOP48 [(SA247-B005)]	EN29F800T@TSOP48 [(SA247-
B005)]	
EN29LV010@PLCC32 [(SA015A1T)]	EN29LV010@TSOP32
[(SA410T)]	
EN29LV010@VSOP32 [(SA620)]	EN29LV040@PLCC32
[(SA015A1T)]	
EN29LV040@TSOP32 [(SA410T)]	EN29LV040@VSOP32
[(SA620)]	
EN29LV040A@PLCC32 [(SA015A1T)]	EN29LV040A@TSOP32
[(SA410T)]	
EN29LV040A@VSOP32 [(SA620)]	
EN29LV160AB@FBGA48 [(SA642G-B026A-T048F001Y)]	
EN29LV160AB@TSOP48 [(SA247-B005)]	
EN29LV160AT@FBGA48 [(SA642G-B026A-T048F001Y)]	
EN29LV160AT@TSOP48 [(SA247-B005)]	
EN29LV160B@FBGA48 [(SA642G-B026A-T048F001Y)]	
EN29LV160B@TSOP48 [(SA247-B005)]	
EN29LV160T@FBGA48 [(SA642G-B026A-T048F001Y)]	
EN29LV160T@TSOP48 [(SA247-B005)]	
EN29LV320AB@FBGA48 [(SA642G-B026A-T048F001Y)]	
EN29LV320AB@TSOP48 [(SA247-B005)]	

EN29LV320AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV320AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV320B@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV320B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV320T@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV320T@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400AB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400AB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400T@TSOP48 [ ( SA247-B005 ) ] EN29LV512@PLCC32  
[ ( SA015A1T ) ]  
EN29LV512@TSOP32 [ ( SA410T ) ] EN29LV512@VSOP32  
[ ( SA620 ) ]  
EN29LV640B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640H@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640H@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640L@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640L@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640T@TSOP48 [ ( SA247-B005 ) ]  
EN29LV641H@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
EN29LV641H@TSOP48 [ ( SA247-B005 ) ]  
EN29LV641L@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
EN29LV641L@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800AB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800AB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BB(Low)@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BT(Low)@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800CB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800CB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800CT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]



EN29LV800CT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800T@TSOP48 [ ( SA247-B005 ) ]  
EN29PL032@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29PL032@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN29PL032@TSOP48 [ ( SA247-B005 ) ]  
EN29PL064@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29PL064@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN29PL064@TSOP48 [ ( SA247-B005 ) ]  
EN29SL160B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL160B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL160T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL160T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL400B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL400B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL400T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL400T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL800B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL800B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL800T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL800T@TSOP48 [ ( SA247-B005 ) ]  
EN71PL03280@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN71PL032A0@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN71PL064A0@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN71PL064B0@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]

## EPSON

### E ( E ) PROM / FRAM / NVRAM

S1H0H324B2B1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H324B2T1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H326B2B1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H326B2T1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H328B2B2@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H328B2T2@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J642B2B3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J642B2T3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J646B2B3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J646B2T3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J648B2B2@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J648B2T2@FBGA68 [ ( SA642E-B023A-T072F001 ) ]

**ESMT****E (E) PROM/FRAM/NVRAM**

EM25LV010@SOIC8 [(SA602A)]	EM25LV010@VFQFPN8
[(SA684)]	
EM25LV512@SOIC8 [(SA602A)]	EM25LV512@VFQFPN8
[(SA684)]	
F25L004AB	
F25L004AB@SOIC8(150mil) [(SA602A)]	
F25L004AB@SOIC8(200mil) [(SA605A)]	
F25L004AT	
F25L004AT@SOIC8(150mil) [(SA602A)]	
F25L004AT@SOIC8(200mil) [(SA605A)]	
F25L008AB@SOIC8 [(SA605A)]	F25L008AT@SOIC8
[(SA605A)]	
F25L016AB@SOIC8 [(SA605A)]	F25L016AT@SOIC8
[(SA605A)]	
F25L04UA@SOIC8 [(SA602A)]	
F25L08PA(AAI-PROGRAM)@SOIC8 [(SA605A)]	
F25L08PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]	
F25L16PA(AAI-PROGRAM)@SOIC8 [(SA605A)]	
F25L16PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]	
F25L32PA@SOIC16 [(SA404)]	F25L32PA@SOIC8
[(SA605A)]	
F49B002UA	F49B002UA@PLCC32
[(SA015A1T)]	
F49L004BA@PLCC32 [(SA015A1T)]	F49L004BA@TSOP40
[(SA409T)]	
F49L004UA@PLCC32 [(SA015A1T)]	F49L004UA@TSOP40
[(SA409T)]	
F49L040A@PLCC32 [(SA015A1T)]	F49L040A@VSOP32
[(SA620)]	
F49L160BA@TSOP48 [(SA247)]	F49L160UA@TSOP48
[(SA247)]	
F49L320BA@TSOP48 [(SA247)]	F49L320UA@TSOP48
[(SA247)]	
F49L400BA@TSOP48 [(SA247-B005)]	F49L400UA@TSOP48 [(SA247-
B005)]	
F49L800BA@TSOP48 [(SA247)]	F49L800UA@TSOP48
[(SA247)]	
FM91L01604BA@FBGA56 [(SA642P-B207A-W056F001Y)]	

FM91L01604UA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L03208BA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L03208BIA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L03208UA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L03208UIA@FBGA56 [(SA642P-B207A-W056F001Y)]

## EXCELSEMI

### E (E) PROM / FRAM / NVRAM

ES25M16 [(SA404)]	ES25M16@SOP16
ES25M16@SOP8[150 mil] [(SA602A)] [(SA605A)]	ES25M16@SOP8[208 mil]
ES25M40 [(SA404)]	ES25M40@SOP16
ES25M40@SOP8[150 mil] [(SA602A)] [(SA605A)]	ES25M40@SOP8[208 mil]
ES25M80 [(SA404)]	ES25M80@SOP16
ES25M80@SOP8[150 mil] [(SA602A)] [(SA605A)]	ES25M80@SOP8[208 mil]
ES25P16@SOP8 [(SA605A)] [(SA605A)]	ES25P40@SOP8
ES25P80@SOP8 [(SA605A)]	
ES29LV160DB@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160DB@PSOP44 [(SA638)]	
ES29LV160DB@TSOP48 [(SA247-B005)]	
ES29LV160DT@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160DT@PSOP44 [(SA638)]	
ES29LV160DT@TSOP48 [(SA247-B005)]	
ES29LV160EB@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160EB@TSOP48 [(SA247-B005)]	
ES29LV160ET@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160ET@TSOP48 [(SA247-B005)]	
ES29LV160FB@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160FB@TSOP48 [(SA247-B005)]	
ES29LV160FT@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160FT@TSOP48 [(SA247-B005)]	
ES29LV320DB@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV320DB@TSOP48 [(SA247-B005)]	
ES29LV320DT@FBGA48 [(SA642G-B026A-T048F001Y)]	

ES29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320FB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320FT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800DB@PSOP44 [ ( SA638 ) ]  
ES29LV800DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800DT@PSOP44 [ ( SA638 ) ]  
ES29LV800DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800ET@TSOP48 [ ( SA247-B005 ) ]

## EXEL

### E ( E ) PROM / FRAM / NVRAM

XL24C01A  
XL24C02  
XL24C04  
XL24C16  
XL24C16@SOIC8 [ ( SA602A ) ]  
XL24C32  
XL28C256  
XL28C256@PLCC32  
[ ( SA015A1T ) ]  
XL28C256@TSOP28 [ ( SA430T ) ]  
XL9010

XL9010(F) [(SA602A)]  
XL9020  
XL9020(F) [(SA602A)]  
XL9040  
XL9040(F) [(SA602A)]  
XL9346  
XL9346@SOIC8 [(SA602A)]  
XL93CS56  
XL93CS56@SOIC8 [(SA602A)] XL93CS56@TSSOP8  
[(SA026)]  
XL93CS66 XL93CS66@SOIC8  
[(SA602A)]  
XL93CS66@TSSOP8 [(SA026)]  
XL93LC46  
XL93LC46@SOIC8 [(SA602A)]  
XL93LC46A  
XL93LC46A@SOIC8 [(SA602A)]  
XL93LC56  
XL93LC56@SOIC8 [(SA602A)]  
XL93LC56A  
XL93LC56A@SOIC8 [(SA602A)]  
XL93LC66A  
XL93LC66A@SOIC8 [(SA602A)]  
XL9764  
XLE28C16A XLE28C16A@PLCC32  
[(SA015A1T)]  
XLE28C16B XLE28C16B@PLCC32  
[(SA015A1T)]  
XLE28C16B@SOIC24 [(SA404)]  
XLM28C16A  
XLM28C16A@PLCC32 [(SA015A1T)]  
XLM46C15  
XLM46P15  
XLS2804A  
XLS2816A XLS2816A@PLCC32  
[(SA015A1T)]  
XLS2817A  
XLS28C16A  
XLS28C16A@PLCC32 [(SA015A1T)]  
XLS28C16B  
XLS28C16B@PLCC32 [(SA015A1T)] XLS28C16B@SOIC24  
[(SA404)]  
XLS28C64B XLS28C64B@PLCC32

[ ( SA015A1T ) ]  
XLS28C64B@SOIC28 [ ( SA404 ) ]  
XLS46C15  
XLS46P15  
XLS93C46  
XLS93C46@SOIC8 [ ( SA602A ) ]  
XLS93C56  
XLS93C56@SOIC8 [ ( SA602A ) ]  
XLS93C66  
XLS93C66@SOIC8 [ ( SA602A ) ]  
XLS93CS46  
XLS93CS46@SOIC8 [ ( SA602A ) ]  
[ ( SA026 ) ]  
XLS93LC06  
[ ( SA602A ) ]  
XLS93LC66  
[ ( SA602A ) ]

XLS93CS46@TSSOP8  
  
XLS93LC06@SOIC8  
  
XLS93LC66@SOIC8

## PLD

XLE78C800P-25  
35  
XLE78C800P-45  
25  
XLE78C800S-35  
45  
XLM78C800S-35  
45  
XLS78C800P-25  
35  
XLS78C800P-45  
25  
XLS78C800S-35  
45

XLE78C800P-  
  
XLE78C800S-  
  
XLE78C800S-  
  
XLM78C800S-  
  
XLS78C800P-  
  
XLS78C800S-  
  
XLS78C800S-

## FAIRCHILD

### E ( E ) PROM / FRAM / NVRAM

FM24C02 ( M8 ) @SOIC8 [ ( SA602A ) ]  
[ ( SA026 ) ]

FM24C02 ( MT8 ) @TSSOP8

FM24C02(N) [(SA602A)]	FM24C03(M8)@SOIC8
FM24C03(MT8)@TSSOP8 [(SA026)] (N)	FM24C03
FM24C04(M8)@SOIC8 [(SA602A)] [(SA026)]	FM24C04(MT8)@TSSOP8
FM24C04(N) [(SA602A)]	FM24C05(M8)@SOIC8
FM24C05(MT8)@TSSOP8 [(SA026)] (N)	FM24C05
FM24C08(M8)@SOIC8 [(SA602A)] [(SA026)]	FM24C08(MT8)@TSSOP8
FM24C08(N) [(SA602A)]	FM24C09(M8)@SOIC8
FM24C09(MT8)@TSSOP8 [(SA026)] (N)	FM24C09
FM24C128(MT8)@TSSOP8 [(SA026)] [(SA602A)]	FM24C128(MW8)@SOIC8
FM24C128(N) [(SA602A)]	FM24C16(M8)@SOIC8
FM24C16(MT8)@TSSOP8 [(SA026)] (N)	FM24C16
FM24C17(M8)@SOIC8 [(SA602A)] [(SA026)]	FM24C17(MT8)@TSSOP8
FM24C17(N) [(SA602A)]	FM24C256(M8)@SOIC8
FM24C256(N) [(SA602A)]	FM24C32(M8)@SOIC8
FM24C32(N)	
FM27C010	
FM27C010@PLCC32 [(SA015A1T)] [(SA410T)]	FM27C010@TSOP32
FM27C040 [(SA015A1T)]	FM27C040@PLCC32
FM27C040@TSOP32 [(SA410T)]	
FM27C256	
FM27C256@PLCC32 [(SA015A1T)]	
FM27C256Q	
FM27C256Q@PLCC32 [(SA015A1T)]	
FM27C512	
FM27C512@PLCC32 [(SA015A1T)]	
FM93C06(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C06(M8)(16bit)@SOIC8 [(SA602A)]	

FM93C06(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C06(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C06(N)(08bit) FM93C06(N)  
 (16bit)  
 FM93C14(16bit) FM93C46(M8)@SOIC8  
 [(SA602A)]  
 FM93C46(MT8)@TSSOP8 [(SA026)] FM93C46  
 (N)  
 FM93C46A(M8)(08bit)@SOIC8 [(SA602A)]  
 FM93C46A(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C46A(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C46A(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C46A(N)(08bit) FM93C46A(N)  
 (16bit)  
 FM93C56(M8)@SOIC8 [(SA602A)] FM93C56(MT8)@TSSOP8  
 [(SA026)]  
 FM93C56(N)  
 FM93C56A(M8)(08bit)@SOIC8 [(SA602A)]  
 FM93C56A(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C56A(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C56A(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C56A(N)(08bit) FM93C56A(N)  
 (16bit)  
 FM93C66(M8)@SOIC8 [(SA602A)] FM93C66(MT8)@TSSOP8  
 [(SA026)]  
 FM93C66(N)  
 FM93C66A(M8)(08bit)@SOIC8 [(SA602A)]  
 FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C66A(N)(08bit) FM93C66A(N)  
 (16bit)  
 FM93C76(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C76(N)(16bit)  
 FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]  
 FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C76A(N)(08bit) FM93C76A(N)  
 (16bit)  
 FM93C86(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]



FM93C86(N)(16bit)	
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86A(N)(08bit)	FM93C86A(N)
(16bit)	
FM93CS06(M8)@SOIC8 [(SA602A)]	FM93CS06(MT8)@TSSOP8
[(SA026)]	
FM93CS06(N)	FM93CS46(M8)@SOIC8
[(SA602A)]	
FM93CS46(MT8)@TSSOP8 [(SA026)]	FM93CS46
(N)	
FM93CS56(M8)@SOIC8 [(SA602A)]	FM93CS56(MT8)@TSSOP8
[(SA026)]	
FM93CS56(N)	FM93CS66(M8)@SOIC8
[(SA602A)]	
FM93CS66(MT8)@TSSOP8 [(SA026)]	FM93CS66
(N)	
FM93S46(M8)@SOIC8 [(SA602A)]	FM93S46(MT8)@TSSOP8
[(SA026)]	
FM93S46(N)	FM93S56(M8)@SOIC8
[(SA602A)]	
FM93S56(MT8)@TSSOP8 [(SA026)]	FM93S56
(N)	
FM93S66(M8)@SOIC8 [(SA602A)]	FM93S66(MT8)@TSSOP8
[(SA026)]	
FM93S66(N)	
MM2716	
MM2716E	NM24C02(M8)@SOIC8
[(SA602A)]	
NM24C02(MT8)@TSSOP8 [(SA026)]	NM24C02
(N)	
NM24C02L(M8)@SOIC8 [(SA602A)]	NM24C02L(MT8)@TSSOP8
[(SA026)]	
NM24C02L(N)	NM24C03(M8)@SOIC8
[(SA602A)]	
NM24C03(MT8)@TSSOP8 [(SA026)]	NM24C03
(N)	
NM24C04(M8)@SOIC8 [(SA602A)]	NM24C04(MT8)@TSSOP8
[(SA026)]	
NM24C04(N)	NM24C05(M8)@SOIC8
[(SA602A)]	

NM24C05 (MT8)@TSSOP8 [(SA026)] (N)	NM24C05
NM24C08 (M8)@SOIC8 [(SA602A)] [(SA026)]	NM24C08 (MT8)@TSSOP8
NM24C08 (N) [(SA602A)]	NM24C09 (M8)@SOIC8
NM24C09 (MT8)@TSSOP8 [(SA026)] (N)	NM24C09
NM24C16 (M8)@SOIC8 [(SA602A)] [(SA026)]	NM24C16 (MT8)@TSSOP8
NM24C16 (N) [(SA602A)]	NM24C17 (M8)@SOIC8
NM24C17 (MT8)@TSSOP8 [(SA026)] (N)	NM24C17
NM24C65 (M8)SOIC8 [(SA602A)] (N)	NM24C65
NM27C010 [(SA015A1T)]	NM27C010@PLCC32
NM27C010@TSOP32 [(SA410T)]	
NM27C020 NM27C020@PLCC32 [(SA015A1T)] [(SA410T)]	NM27C020@TSOP32
NM27C020Q [(SA015A1T)]	NM27C020Q@PLCC32
NM27C020Q@TSOP32 [(SA410T)]	
NM27C040 NM27C040@PLCC32 [(SA015A1T)] [(SA410T)]	NM27C040@TSOP32
NM27C128 [(SA015A1T)]	NM27C128@PLCC32
NM27C210 [(SA244)]	NM27C210@PLCC44
NM27C240 [(SA244)]	NM27C240@PLCC44
NM27C256 [(SA015A1T)]	NM27C256@PLCC32
NM27C512 [(SA015A1T)]	NM27C512@PLCC32
NM27C64Q [(SA015A1T)]	NM27C64Q@PLCC32
NM27LC256 [(SA015A1T)]	NM27LC256@PLCC32
NM27LC512	NM27LC512@PLCC32

[ (SA015A1T) ]	
NM27LV010	NM27LV010@PLCC32
[ (SA015A1T) ]	
NM27LV010@TSOP32 [ (SA410T) ]	
NM27LV210	
NM27LV210@PLCC44 [ (SA244) ]	
NM27LV512	
NM27LV512@PLCC32 [ (SA015A1T) ]	
NM27P040	
NM27P040@PLCC32 [ (SA015A1T) ]	NM27P040@TSOP32
[ (SA410T) ]	
NM27P210	NM27P210@PLCC44
[ (SA244) ]	
NM27P512	NM27P512@PLCC32
[ (SA015A1T) ]	
NM93C66(M8)(16bit)@SOIC8 [ (SA602A) ]	
NM93C66(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NM93C66(N)(16bit)	NM93CS06(M8)@SOIC8
[ (SA602A) ]	
NM93CS06(MT8)@TSSOP8 [ (SA026) ]	NM93CS06
(N)	
NM93CS46(M8)@SOIC8 [ (SA602A) ]	NM93CS46(MT8)@TSSOP8
[ (SA026) ]	
NM93CS46(N)	NM93CS56(M8)@SOIC8
[ (SA602A) ]	
NM93CS56(MT8)@TSSOP8 [ (SA026) ]	NM93CS56
(N)	
NM93CS66(M8)@SOIC8 [ (SA602A) ]	NM93CS66(MT8)@TSSOP8
[ (SA026) ]	
NM93CS66(N)	
NMC2732	
NMC27C010	NMC27C010@PLCC32
[ (SA015A1T) ]	
NMC27C010@TSOP32 [ (SA410T) ]	
NMC27C1024	
NMC27C1024@PLCC44 [ (SA244) ]	
NMC27C128B	
NMC27C128B@PLCC32 [ (SA015A1T) ]	
NMC27C128BN	
NMC27C128BN@PLCC32 [ (SA015A1T) ]	
NMC27C128BQ	
NMC27C128BQ@PLCC32 [ (SA015A1T) ]	
NMC27C128CQ	

NMC27C16  
NMC27C16BQ  
NMC27C16BQE  
NMC27C16H  
NMC27C16HQ  
NMC27C16Q  
NMC27C256 NMC27C256@PLCC32  
[ (SA015A1T) ]  
NMC27C256B NMC27C256B@PLCC32  
[ (SA015A1T) ]  
NMC27C256Q NMC27C256Q@PLCC32  
[ (SA015A1T) ]  
NMC27C32  
NMC27C32B  
NMC27C32BQ  
NMC27C32E  
NMC27C32EH  
NMC27C32H  
NMC27C512 NMC27C512@PLCC32  
[ (SA015A1T) ]  
NMC27C512A NMC27C512A@PLCC32  
[ (SA015A1T) ]  
NMC27C512AN NMC27C512AN@PLCC32  
[ (SA015A1T) ]  
NMC27C64 NMC27C64  
(BN)  
NMC27C64(N)  
NMC27CP128  
NMC87C257Q NMC87C257Q@PLCC32  
[ (SA015A1T) ]  
NMC87C257V NMC87C257V@PLCC32  
[ (SA015A1T) ]  
NMC9346(M8)(16bit)@SOIC8 [(SA602A)]  
NMC9346(MT8)(16bit)@TSSOP8 [(SA026)]  
NMC9346(N)(16bit)  
NMC93C46(M8)(16bit)@SOIC8 [(SA602A)]  
NMC93C46(MT8)(16bit)@TSSOP8 [(SA026)]  
NMC93C46(N)(16bit)  
NMC93C46A(M8)(16bit)@SOIC8 [(SA602A)]  
NMC93C46A(MT8)(16bit)@TSSOP8 [(SA026)]  
NMC93C46A(N)(16bit)  
NMC93C56(M8)(16bit)@SOIC8 [(SA602A)]  
NMC93C56(MT8)(16bit)@TSSOP8 [(SA026)]

NMC93C56(N)(16bit)	
NMC93C66(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C66(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C66(N)(16bit)	NMC93CS06(M8)@SOIC8
[(SA602A)]	
NMC93CS06(MT8)@TSSOP8 [(SA026)]	NMC93CS06
(N)	
NMC93CS46(M8)@SOIC8 [(SA602A)]	NMC93CS46(MT8)@TSSOP8
[(SA026)]	
NMC93CS46(N)	NMC93CS56(M8)@SOIC8
[(SA602A)]	
NMC93CS56(MT8)@TSSOP8 [(SA026)]	NMC93CS56
(N)	
NMC93CS66(M8)@SOIC8 [(SA602A)]	NMC93CS66(MT8)@TSSOP8
[(SA026)]	
NMC93CS66(N)	
NMC9817	

## DRAM & SRAM

F1600	F1600@SOJ24
[(SA646)]	
F1601	F1601@SOJ24
[(SA646)]	
F1620	
F1621	

## MICROCONTROLLER

ACE1001(M8)@SOIC8 [(SA602A)]	ACE1001(M8X)@SOIC8
[(SA602A)]	
ACE1001(MT8)@TSSOP8 [(SA026)]	ACE1001(MT8X)@TSSOP8
[(SA026)]	
ACE1001E(M8)@SOIC8 [(SA602A)]	ACE1001E(M8X)@SOIC8
[(SA602A)]	
ACE1001E(MT8)@TSSOP8 [(SA026)]	ACE1001E(MT8X)@TSSOP8
[(SA026)]	
ACE1001L(M8)@SOIC8 [(SA602A)]	ACE1001L(M8X)@SOIC8
[(SA602A)]	
ACE1001L(MT8)@TSSOP8 [(SA026)]	ACE1001L(MT8X)@TSSOP8
[(SA026)]	

ACE1101(EMT8)@TSSOP8 [(SA026)]	ACE1101(EMT8X)@TSSOP8
[(SA026)]	
ACE1101(EN)	ACE1101
(EN14)	
ACE1101(LMT8)@TSSOP8 [(SA026)]	ACE1101(LMT8X)@TSSOP8
[(SA026)]	
ACE1101(LN)	ACE1101
(LN14)	
ACE1101(MT8)@TSSOP8 [(SA026)]	ACE1101(MT8X)@TSSOP8
[(SA026)]	
ACE1101(N)	ACE1101
(N14)	
ACE1101(VMT8)@TSSOP8 [(SA026)]	ACE1101(VMT8X)@TSSOP8
[(SA026)]	
ACE1101(VN)	ACE1101
(VN14)	
ACE1101B(EMT8)@TSSOP8 [(SA026)]	ACE1101B(EMT8X)@TSSOP8
[(SA026)]	
ACE1101B(EN)	ACE1101B
(EN14)	
ACE1101B(MT8)@TSSOP8 [(SA026)]	ACE1101B(MT8X)@TSSOP8
[(SA026)]	
ACE1101B(N)	ACE1101B
(N14)	
ACE1101B(VMT8)@TSSOP8 [(SA026)]	ACE1101B(VMT8X)@TSSOP8
[(SA026)]	
ACE1101B(VN)	ACE1101B
(VN14)	
ACE1202(dip14)	ACE1202
(dip8)	
ACE1202(M14)@SOIC14 [(SA602)]	ACE1202(M8)@SOIC8
[(SA602A)]	
ACE12022(dip14)	ACE12022
(dip8)	
ACE12022(M14)@SOIC14 [(SA602)]	ACE12022(M8)@SOIC8
[(SA602A)]	
ACE12022B(dip14)	ACE12022B
(dip8)	
ACE12022B(M14)@SOIC14 [(SA602)]	ACE12022B(M8)@SOIC8
[(SA602A)]	
ACE12022BE(dip14)	ACE12022BE
(dip8)	
ACE12022BE(M14)@SOIC14 [(SA602)]	ACE12022BE(M8)@SOIC8

[ (SA602A) ]	
ACE12022BV(dip14)	ACE12022BV
(dip8)	
ACE12022BV(M14)@SOIC14 [ (SA602) ]	ACE12022BV(M8)@SOIC8
[ (SA602A) ]	
ACE12022E(dip14)	ACE12022E
(dip8)	
ACE12022E(M14)@SOIC14 [ (SA602) ]	ACE12022E(M8)@SOIC8
[ (SA602A) ]	
ACE1202B(dip14)	ACE1202B
(dip8)	
ACE1202B(M14)@SOIC14 [ (SA602) ]	ACE1202B(M8)@SOIC8
[ (SA602A) ]	
ACE1202BE(dip14)	ACE1202BE
(dip8)	
ACE1202BE(M14)@SOIC14 [ (SA602) ]	ACE1202BE(M8)@SOIC8
[ (SA602A) ]	
ACE1202BV(dip14)	ACE1202BV
(dip8)	
ACE1202BV(M14)@SOIC14 [ (SA602) ]	ACE1202BV(M8)@SOIC8
[ (SA602A) ]	
ACE1202E(dip14)	ACE1202E
(dip8)	
ACE1202E(M14)@SOIC14 [ (SA602) ]	ACE1202E(M8)@SOIC8
[ (SA602A) ]	
ACE1202L(dip14)	ACE1202L
(dip8)	
ACE1202L(M14)@SOIC14 [ (SA602) ]	ACE1202L(M8)@SOIC8
[ (SA602A) ]	
ACE1202V(dip8)	ACE1202V(M14)@SOIC14
[ (SA602) ]	
ACE1202V(M8)@SOIC8 [ (SA602A) ]	ACE1501(EM)@SOIC14
[ (SA602) ]	
ACE1501(EM8)@SOIC8 [ (SA602A) ]	ACE1501(EM8X)@SOIC8
[ (SA602A) ]	
ACE1501(EMT)@TSOP14 [ (SA026) ]	ACE1501(EMT8)@TSSOP8
[ (SA026) ]	
ACE1501(EMT8X)@TSSOP8 [ (SA026) ]	ACE1501(EMTX)@TSOP14
[ (SA026) ]	
ACE1501(EMX)@SOIC14 [ (SA602) ]	ACE1501
(EN)	
ACE1501(EN14)	ACE1501(VM)@SOIC14
[ (SA602) ]	

ACE1501(VM8)@SOIC8 [(SA602A)] [(SA602A)]	ACE1501(VM8X)@SOIC8
ACE1501(VMT)@TSOP14 [(SA026)] [(SA026)]	ACE1501(VMT8)@TSSOP8
ACE1501(VMT8X)@TSSOP8 [(SA026)] [(SA026)]	ACE1501(VMTX)@TSOP14
ACE1501(VMX)@SOIC14 [(SA602)] (VN)	ACE1501
ACE1501(VN14) [(SA602)]	ACE1502(EM)@SOIC14
ACE1502(EM8)@SOIC8 [(SA602A)] [(SA026)]	ACE1502(EMT)@TSOP14
ACE1502(EMT8)@TSSOP8 [(SA026)] (EN)	ACE1502
ACE1502(EN14) [(SA602)]	ACE1502(VM)@SOIC14
ACE1502(VM8)@SOIC8 [(SA602A)] [(SA026)]	ACE1502(VMT)@TSOP14
ACE1502(VMT8)@TSSOP8 [(SA026)] (VN)	ACE1502
ACE1502(VN14) [(SA602A)]	ACE8000(M8)@SOIC8
ACE8000(M8X)@SOIC8 [(SA602A)] [(SA602A)]	ACE8000E(M8)@SOIC8
ACE8000E(M8X)@SOIC8 [(SA602A)] [(SA602A)]	ACE8001(M8)@SOIC8
ACE8001(M8X)@SOIC8 [(SA602A)] [(SA026)]	ACE8001(MT8)@TSSOP8
ACE8001(MT8X)@TSSOP8 [(SA026)] [(SA602A)]	ACE8001E(M8)@SOIC8
ACE8001E(M8X)@SOIC8 [(SA602A)] [(SA026)]	ACE8001E(MT8)@TSSOP8
ACE8001E(MT8X)@TSSOP8 [(SA026)] [(SA602A)]	FMS7401L(EM8X)@SOIC8
FMS7401L(EMT8X)@TSSOP8 [(SA026)] [(SA026)]	FMS7401L(EMTX)@TSSOP14
FMS7401L(EMX)@SOIC14 [(SA602)] (EN)	FMS7401L
FMS7401L(EN14) (VN)	FMS7401L
FMS7401L(VN14)	



# FORCE TECHNOLOGIES

## E ( E ) PROM / FRAM / NVRAM

FT24C01 [ ( SA602A ) ] FT24C01@TSOP8 [ ( SA026 ) ] FT24C01A FT24C01A@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] FT24C02 [ ( SA602A ) ] FT24C02@TSSOP8 [ ( SA026 ) ] FT24C02A FT24C02A@SOP8 [ ( SA602A ) ] [ ( SA026 ) ] FT24C04 [ ( SA602A ) ] FT24C04@TSSOP8 [ ( SA026 ) ] FT24C04A FT24C04A@SOP8 [ ( SA602A ) ] [ ( SA026 ) ] FT24C08 [ ( SA602A ) ] FT24C08@TSOP8 [ ( SA026 ) ] FT24C08A FT24C08A@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] FT24C128 [ ( SA602A ) ] FT24C128@TSOP8 [ ( SA026 ) ] FT24C128A FT24C128A@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] FT24C16 [ ( SA602A ) ] FT24C16@TSOP8 [ ( SA026 ) ] FT24C16A FT24C16A@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] FT24C256 [ ( SA602A ) ] FT24C256@TSOP8 [ ( SA026 ) ]	FT24C01@SOIC8    FT24C01A@TSOP8  FT24C02@SOP8   FT24C02A@TSSOP8  FT24C04@SOP8   FT24C04A@TSSOP8  FT24C08@SOIC8   FT24C08A@TSOP8  FT24C128@SOIC8  FT24C128A@TSOP8  FT24C16@SOIC8  FT24C16A@TSOP8  FT24C256@SOIC8
--	--

FT24C256A	
FT24C256A@SOIC8 [(SA602A)]	FT24C256A@TSOP8
[(SA026)]	
FT24C32	FT24C32@SOIC8
[(SA602A)]	
FT24C32@TSOP8 [(SA026)]	
FT24C32A	
FT24C32A@SOIC8 [(SA602A)]	FT24C32A@TSOP8
[(SA026)]	
FT24C64	FT24C64@SOIC8
[(SA602A)]	
FT24C64@TSOP8 [(SA026)]	
FT24C64A	
FT24C64A@SOIC8 [(SA602A)]	FT24C64A@TSOP8
[(SA026)]	
FT27C010	FT27C010@PLCC32
[(SA015A1T)]	
FT27C010@TSOP32 [(SA410T)]	
FT27C020	
FT27C020@PLCC32 [(SA015A1T)]	FT27C020@TSOP32
[(SA410T)]	
FT27C040	FT27C040@PLCC32
[(SA015A1T)]	
FT27C040@TSOP32 [(SA410T)]	
FT27C16	
FT27C256	FT27C256@PLCC32
[(SA015A1T)]	
FT27C64	FT27C64@PLCC32
[(SA015A1T)]	
FT27HC256	FT27HC256@PLCC32
[(SA015A1T)]	
FT27HC64	FT27HC64@PLCC32
[(SA015A1T)]	
FT28C010	FT28C010@JLCC32
[(SA412A)]	
FT28C010@PLCC32 [(SA015A1T)]	FT28C010@PLCC44
[(SA244)]	
FT28C010@TSOP32 [(SA410T)]	
FT28C010E	
FT28C010E@JLCC32 [(SA412A)]	FT28C010E@PLCC32
[(SA015A1T)]	
FT28C010E@PLCC44 [(SA244)]	FT28C010E@TSOP32
[(SA410T)]	

FT28C020 [ (SA412A) ]	FT28C020@JLCC32
FT28C020@PLCC32 [ (SA015A1T) ] [ (SA244) ]	FT28C020@PLCC44
FT28C020@TSOP32 [ (SA410T) ]	
FT28C040 FT28C040@JLCC32 [ (SA412A) ] [ (SA015A1T) ]	FT28C040@PLCC32
FT28C040@PLCC44 [ (SA244) ] [ (SA410T) ]	FT28C040@TSOP32
FT28C16 [ (SA015A1T) ]	FT28C16@PLCC32
FT28C256 [ (SA412A) ]	FT28C256@JLCC32
FT28C256@PLCC32 [ (SA015A1T) ] [ (SA404) ]	FT28C256@SOIC28
FT28C256@TSOP28 [ (SA430T) ]	
FT28C256B FT28C256B@JLCC32 [ (SA412A) ] [ (SA015A1T) ]	FT28C256B@PLCC32
FT28C256B@SOIC28 [ (SA404) ] [ (SA430T) ]	FT28C256B@TSOP28
FT28C64 [ (SA015A1T) ]	FT28C64@PLCC32
FT28C64@SOIC28 [ (SA404) ] [ (SA430T) ]	FT28C64@TSOP28
FT28C64B [ (SA412A) ]	FT28C64B@JLCC32
FT28C64B@PLCC32 [ (SA015A1T) ] [ (SA404) ]	FT28C64B@SOIC28
FT28C64B@TSOP28 [ (SA430T) ]	
FT28C64X FT28C64X@PLCC32 [ (SA015A1T) ] [ (SA404) ]	FT28C64X@SOIC28
FT28C64X@TSOP28 [ (SA430T) ]	
FT28HC64 FT28HC64@PLCC32 [ (SA015A1T) ] [ (SA430T) ]	FT28HC64@TSOP28
FT58C1001 [ (SA438T) ]	FT58C1001@SSOP32
FT58C1001@VSOP32 [ (SA620) ]	

## FORWARD

### E ( E ) PROM / FRAM / NVRAM

24LC01 [ ( SA602A ) ]	24LC01@SOIC8
24LC02 [ ( SA602A ) ]	24LC02@SOIC8
24LC04 [ ( SA602A ) ]	24LC04@SOIC8
24LC08 [ ( SA602A ) ]	24LC08@SOIC8
24LC16 [ ( SA602A ) ]	24LC16@SOIC8
24LC32 [ ( SA602A ) ]	24LC32@SOIC8
24LC64 [ ( SA602A ) ]	24LC64@SOIC8

## FREESCALE

### MICROCONTROLLER

MC56F8011VFAE@QFP32 [ ( SA663+B005 ) ]
MC56F8013VFAE@QFP32 [ ( SA663+B005 ) ]
MC56F8014VFAE@QFP32 [ ( SA663+B005 ) ]
MC56F8023MFAE@QFP32 [ ( SA663+B005 ) ]
MC56F8023VFAE@QFP32 [ ( SA663+B005 ) ]
MC56F8025VLD@QFP44 [ ( SA245A+B005 ) ]
MC56F8036MFAE@QFP48 [ ( SA248+B005 ) ]
MC56F8036VFAE@QFP48 [ ( SA248+B005 ) ]
MC56F8037VLH@QFP64 [ ( PEP+S616 ) ]
MC68HC908AP16CB(S)@SDIP42 [ ( SA028 ) ]
MC68HC908AP16CB@SDIP42 [ ( SA028 ) ]
MC68HC908AP16CFA(S)@LQFP48 [ ( SA248 ) ]
MC68HC908AP16CFA@LQFP48 [ ( SA248 ) ]
MC68HC908AP16CFB(S)@TQFP44 [ ( SA675 ) ]
MC68HC908AP16CFB@TQFP44 [ ( SA675 ) ]
MC68HC908AP32CB(S)@SDIP42 [ ( SA028 ) ]
MC68HC908AP32CB@SDIP42 [ ( SA028 ) ]
MC68HC908AP32CFA(S)@LQFP48 [ ( SA248 ) ]

MC68HC908AP32CFA@LQFP48 [(SA248)]  
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP32CFB@TQFP44 [(SA675)]  
MC68HC908AP64CB@SDIP42 [(SA028)]  
MC68HC908AP64CFA@LQFP48 [(SA248)]  
MC68HC908AP64CFB@TQFP44 [(SA675)]  
MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
MC68HC908AP8CB@SDIP42 [(SA028)]  
MC68HC908AP8CFA(S)@@LQFP48 [(SA248)]  
MC68HC908AP8CFA@@LQFP48 [(SA248)]  
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP8CFB@TQFP44 [(SA675)]  
MC68HC908EY16CFA@TQFP32 [(SA663)]  
MC68HC908EY16MFA@TQFP32 [(SA663)]  
MC68HC908EY16VFA@TQFP32 [(SA663)]  
MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32  
[(SA663)]  
MC68HC908EY8VFA@TQFP32 [(SA663)]  
MC68HC908GP32  
MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44  
[(SA675)]  
MC68HC908GR16CFA@TQFP48 [(SA248)]  
MC68HC908GR16CFJ@TQFP32 [(SA663)]  
MC68HC908GR16MFA@TQFP48 [(SA248)]  
MC68HC908GR16MFJ@TQFP32 [(SA663)]  
MC68HC908GR16VFA@TQFP48 [(SA248)]  
MC68HC908GR16VFJ@TQFP32 [(SA663)]  
MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32  
[(SA663)]  
MC68HC908GR4CP MC68HC908GR4MDW@SOIC28  
[(SA404)]  
MC68HC908GR4MFA@TQFP32 [(SA663)]  
MC68HC908GR4MP  
MC68HC908GR4VDW@SOIC28 [(SA404)] MC68HC908GR4VFA@TQFP32  
[(SA663)]  
MC68HC908GR4VP MC68HC908GR8CDW@SOIC28  
[(SA404)]  
MC68HC908GR8CFA@TQFP32 [(SA663)]  
MC68HC908GR8CP  
MC68HC908GR8MDW@SOIC28 [(SA404)] MC68HC908GR8MFA@TQFP32  
[(SA663)]  
MC68HC908GR8MP MC68HC908GR8VDW@SOIC28  
[(SA404)]

MC68HC908GR8VFA@TQFP32 [ (SA663) ]  
MC68HC908GR8VP  
MC68HC908JK1CDW@SOIC20 [ (SA404) ]  
MC68HC908JK1CP  
MC68HC908JK1ECDW@SOIC20 [ (SA404) ]  
MC68HC908JK1ECP  
MC68HC908JK1EMDW@SOIC20 [ (SA404) ]  
MC68HC908JK1EMP  
[ (SA404) ] MC68HC908JK1MDW@SOIC20  
MC68HC908JK1MP  
[ (SA404) ] MC68HC908JK3CDW@SOIC20  
MC68HC908JK3CP  
MC68HC908JK3ECDW@SOIC20 [ (SA404) ]  
MC68HC908JK3ECP  
MC68HC908JK3EMDW@SOIC20 [ (SA404) ]  
MC68HC908JK3EMP  
[ (SA404) ] MC68HC908JK3MDW@SOIC20  
MC68HC908JK3MP  
[ (SA404) ] MC68HC908JL3CDW@SOIC28  
MC68HC908JL3CFA@TQFP48 [ (SA248) ]  
MC68HC908JL3CP  
MC68HC908JL3ECDW@SOIC28 [ (SA404) ]  
MC68HC908JL3ECFA@TQFP48 [ (SA248) ]  
MC68HC908JL3ECP  
MC68HC908JL3EMDW@SOIC28 [ (SA404) ]  
MC68HC908JL3EMFA@TQFP48 [ (SA248) ]  
MC68HC908JL3EMP  
[ (SA404) ] MC68HC908JL3MDW@SOIC28  
MC68HC908JL3MFA@TQFP48 [ (SA248) ]  
MC68HC908JL3MP  
MC68HC908LB8CDWE(S)@SOIC20 MC68HC908LB8CPE  
(S)  
MC68HC908LB8MDWE(S)@SOIC20 MC68HC908LB8MPE  
(S)  
MC68HC908LB8VDWE(S)@SOIC20 MC68HC908LB8VPE  
(S)  
MC68HC908QT1ACFQE@DFN8 [ (SA744-B006) ]  
MC68HC908QT1AMFQE@DFN8 [ (SA744-B006) ]  
MC68HC908QT1AVFQE@DFN8 [ (SA744-B006) ]  
MC68HC908QT1CDW@SOIC8 [ (SA605A) ]  
MC68HC908QT1CFQ@DFN8 [ (SA744-B006) ]  
MC68HC908QT1CP  
[ (SA605A) ] MC68HC908QT1MDW@SOIC8

MC68HC908QT1MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT1MP [(SA605A)] MC68HC908QT1VDW@SOIC8  
MC68HC908QT1VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT1VP  
MC68HC908QT2ACFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2AMFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2AVFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2CDW@SOIC8 [(SA605A)]  
MC68HC908QT2CFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2CP [(SA605A)] MC68HC908QT2MDW@SOIC8  
MC68HC908QT2MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2MP [(SA605A)] MC68HC908QT2VDW@SOIC8  
MC68HC908QT2VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2VP  
MC68HC908QT4ACFQE@DFN8 [(SA744-B006)]  
MC68HC908QT4AMFQE@DFN8 [(SA744-B006)]  
MC68HC908QT4AVFQE@DFN8 [(SA744-B006)]  
MC68HC908QT4CDW@SOIC8 [(SA605A)]  
MC68HC908QT4CFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4CP [(SA605A)] MC68HC908QT4MDW@SOIC8  
MC68HC908QT4MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4MP [(SA605A)] MC68HC908QT4VDW@SOIC8  
MC68HC908QT4VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4VP  
MC68HC908QY1CDT@TSSOP16 [(SA026)]  
MC68HC908QY1CDW@SOIC16 [(SA404)]  
MC68HC908QY1CP  
MC68HC908QY1MDT@TSSOP16 [(SA026)]  
MC68HC908QY1MDW@SOIC16 [(SA404)]  
MC68HC908QY1MP  
MC68HC908QY1VDT@TSSOP16 [(SA026)]  
MC68HC908QY1VDW@SOIC16 [(SA404)]  
MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [(SA026)]  
MC68HC908QY2CDW@SOIC16 [(SA404)]  
MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [(SA026)]  
MC68HC908QY2MDW@SOIC16 [(SA404)]

MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [ (SA026) ]  
MC68HC908QY2VDW@SOIC16 [ (SA404) ]  
MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [ (SA026) ]  
MC68HC908QY4CDW@SOIC16 [ (SA404) ]  
MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [ (SA026) ]  
MC68HC908QY4MDW@SOIC16 [ (SA404) ]  
MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [ (SA026) ]  
MC68HC908QY4VDW@SOIC16 [ (SA404) ]  
MC68HC908QY4VP  
MC68HRC908JK1CDW@SOIC20 [ (SA404) ]  
MC68HRC908JK1CP  
MC68HRC908JK1ECDW@SOIC20 [ (SA404) ]  
MC68HRC908JK1ECP  
MC68HRC908JK1EMDW@SOIC20 [ (SA404) ]  
MC68HRC908JK1EMP  
MC68HRC908JK1MDW@SOIC20 [ (SA404) ]  
MC68HRC908JK1MP  
MC68HRC908JK3CDW@SOIC20 [ (SA404) ]  
MC68HRC908JK3CP  
MC68HRC908JK3ECDW@SOIC20 [ (SA404) ]  
MC68HRC908JK3ECP  
MC68HRC908JK3EMDW@SOIC20 [ (SA404) ]  
MC68HRC908JK3EMP  
MC68HRC908JK3MDW@SOIC20 [ (SA404) ]  
MC68HRC908JK3MP  
MC68HRC908JL3CDW@SOIC28 [ (SA404) ]  
MC68HRC908JL3CFA@TQFP48 [ (SA248) ]  
MC68HRC908JL3CP  
MC68HRC908JL3ECDW@SOIC28 [ (SA404) ]  
MC68HRC908JL3ECFA@TQFP48 [ (SA248) ]  
MC68HRC908JL3ECP  
MC68HRC908JL3EMDW@SOIC28 [ (SA404) ]  
MC68HRC908JL3EMFA@TQFP48 [ (SA248) ]  
MC68HRC908JL3EMP  
MC68HRC908JL3MDW@SOIC28 [ (SA404) ]  
MC68HRC908JL3MFA@TQFP48 [ (SA248) ]  
MC68HRC908JL3MP  
[ (SA028) ]  
MC908AP16CBE@SDIP42  
MC908AP16CFAE@LQFP48 [ (SA248) ]  
MC908AP16CFBE@TQFP44



[ (SA675) ]	
MC908AP32CBE@SDIP42 [ (SA028) ]	MC908AP32CFAE@LQFP48
[ (SA248) ]	
MC908AP32CFBE@TQFP44 [ (SA675) ]	MC908AP64CBE@SDIP42
[ (SA028) ]	
MC908AP64CFAE@LQFP48 [ (SA248) ]	MC908AP64CFBE@TQFP44
[ (SA675) ]	
MC908AP8CBE@SDIP42 [ (SA028) ]	MC908AP8CFAE@@LQFP48
[ (SA248) ]	
MC908AP8CFBE@TQFP44 [ (SA675) ]	MC908EY16ACFJE@TQFP32
[ (SA663) ]	
MC908EY16AKFJE@TQFP32 [ (SA663) ]	MC908EY16AMFJE@TQFP32
[ (SA663) ]	
MC908EY16AVFJE@TQFP32 [ (SA663) ]	MC908EY8ACFJE@TQFP32
[ (SA663) ]	
MC908EY8AKFJE@TQFP32 [ (SA663) ]	MC908EY8AMFJE@TQFP32
[ (SA663) ]	
MC908EY8AVFJE@TQFP32 [ (SA663) ]	MC908JL16CDWE@SOIC28
[ (SA404) ]	
MC908JL16CFJE@LQFP32 [ (SA663) ]	
MC908JL16CPE	
MC908JL16CSPE@SDIP32 [ (SA653) ]	MC908QT1ACDWE@SOIC8
[ (SA605A) ]	
MC908QT1ACPE	MC908QT1AMDWE@SOIC8
[ (SA605A) ]	
MC908QT1AMPE	MC908QT1AVDWE@SOIC8
[ (SA605A) ]	
MC908QT1AVPE	MC908QT2ACDWE@SOIC8
[ (SA605A) ]	
MC908QT2ACPE	MC908QT2AMDWE@SOIC8
[ (SA605A) ]	
MC908QT2AMPE	MC908QT2AVDWE@SOIC8
[ (SA605A) ]	
MC908QT2AVPE	MC908QT4ACDWE@SOIC8
[ (SA605A) ]	
MC908QT4ACPE	MC908QT4AMDWE@SOIC8
[ (SA605A) ]	
MC908QT4AMPE	MC908QT4AVDWE@SOIC8
[ (SA605A) ]	
MC908QT4AVPE	MC908QY1ACDTE@TSSOP16
[ (SA026) ]	
MC908QY1ACDWE@SOIC16 [ (SA404) ]	
MC908QY1ACPE	

MC908QY1AMDTE@TSSOP16 [(SA026)] MC908QY1AMDWE@SOIC16  
[(SA404)]  
MC908QY1AMPE MC908QY1AVDTE@TSSOP16  
[(SA026)]  
MC908QY1AVDWE@SOIC16 [(SA404)]  
MC908QY1AVPE  
MC908QY2ACDTE@TSSOP16 [(SA026)] MC908QY2ACDWE@SOIC16  
[(SA404)]  
MC908QY2ACPE MC908QY2AMDTE@TSSOP16  
[(SA026)]  
MC908QY2AMDWE@SOIC16 [(SA404)]  
MC908QY2AMPE  
MC908QY2AVDTE@TSSOP16 [(SA026)] MC908QY2AVDWE@SOIC16  
[(SA404)]  
MC908QY2AVPE MC908QY4ACDTE@TSSOP16  
[(SA026)]  
MC908QY4ACDWE@SOIC16 [(SA404)]  
MC908QY4ACPE  
MC908QY4AMDTE@TSSOP16 [(SA026)] MC908QY4AMDWE@SOIC16  
[(SA404)]  
MC908QY4AMPE MC908QY4AVDTE@TSSOP16  
[(SA026)]  
MC908QY4AVDWE@SOIC16 [(SA404)]  
MC908QY4AVPE  
MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT16ACFD@QFN48 [(SA696-B166)]  
MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
MC9S08GT16CB@SDIP42 [(SA028-B167)]  
MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT16CFD@QFN48 [(SA696-B166)]  
MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT32CB@SDIP42 [(SA028-B167)]  
MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
MC9S08GT32CFB@LQFP44 [(SA675-B168)]

MC9S08GT32CFBE@LQFP44 [ (SA675-B168) ]  
MC9S08GT32CFD@QFN48 [ (SA696-B166) ]  
MC9S08GT32CFDE@QFN48 [ (SA696-B166) ]  
MC9S08GT8ACB@SDIP42 [ (SA028-B167) ]  
MC9S08GT8ACFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT8ACFD@QFN48 [ (SA696-B166) ]  
MC9S08GT8AMB@SDIP42 [ (SA028-B167) ]  
MC9S08GT8AMFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT8AMFD@QFN48 [ (SA696-B166) ]  
PC56F8011VF AE@QFP32 [ (SA663+B005) ]  
PC56F8013VF AE@QFP32 [ (SA663+B005) ]  
PC56F8014VF AE@QFP32 [ (SA663+B005) ]

## Fremont Micro Devices

### E (E) PROM/FRAM/NVRAM

FT24C02 [ (SA602A) ]	FT24C02@SOP8
FT24C02@TSSOP8 [ (SA026) ]	
FT24C02A	
FT24C02A@SOP8 [ (SA602A) ]	FT24C02A@TSSOP8
[ (SA026) ]	
FT24C04	FT24C04@SOP8
[ (SA602A) ]	
FT24C04@TSSOP8 [ (SA026) ]	
FT24C04A	
FT24C04A@SOP8 [ (SA602A) ]	FT24C04A@TSSOP8
[ (SA026) ]	
FT24C08	FT24C08@SOP8
[ (SA602A) ]	
FT24C08@TSSOP8 [ (SA026) ]	
FT24C08A	
FT24C08A@SOP8 [ (SA602A) ]	FT24C08A@TSSOP8
[ (SA026) ]	
FT24C1024	FT24C1024@SOP8
[ (SA023A) ]	
FT24C1024@TSSOP8 [ (SA026) ]	
FT24C1024A	
FT24C1024A@SOP8 [ (SA023A) ]	FT24C1024A@TSSOP8
[ (SA026) ]	
FT24C128	FT24C128@SOP8

[ (SA602A) ]	
FT24C128@TSSOP8 [ (SA026) ]	
FT24C128A	
FT24C128A@SOP8 [ (SA602A) ]	FT24C128A@TSSOP8
[ (SA026) ]	
FT24C16	
[ (SA602A) ]	
FT24C16@TSSOP8 [ (SA026) ]	FT24C16@SOP8
FT24C16A	
FT24C16A@SOP8 [ (SA602A) ]	FT24C16A@TSSOP8
[ (SA026) ]	
FT24C256	
[ (SA602A) ]	
FT24C256@TSSOP8 [ (SA026) ]	FT24C256@SOP8
FT24C256A	
FT24C256A@SOP8 [ (SA602A) ]	FT24C256A@TSSOP8
[ (SA026) ]	
FT24C32	
[ (SA602A) ]	
FT24C32@TSSOP8 [ (SA026) ]	FT24C32@SOP8
FT24C32A	
FT24C32A@SOP8 [ (SA602A) ]	FT24C32A@TSSOP8
[ (SA026) ]	
FT24C512	
[ (SA602A) ]	
FT24C512@TSSOP8 [ (SA026) ]	FT24C512@SOP8
FT24C512A	
FT24C512A@SOP8 [ (SA602A) ]	FT24C512A@TSSOP8
[ (SA026) ]	
FT24C64	
[ (SA602A) ]	
FT24C64@TSSOP8 [ (SA026) ]	FT24C64@SOP8
FT24C64A	
FT24C64A@SOP8 [ (SA602A) ]	FT24C64A@TSSOP8
[ (SA026) ]	
FT34C02	
[ (SA602A) ]	
FT34C02@TSSOP8 [ (SA026) ]	FT34C02@SOP8
FT34C02A	
FT34C02A@SOP8 [ (SA602A) ]	FT34C02A@TSSOP8
[ (SA026) ]	
FT93C46(08bit)	
[ (SA602A) ]	FT93C46(08bit)@SOP8

FT93C46(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C46
FT93C46(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C46(16bit)@TSSOP8
FT93C46A(08bit) [(SA602A)]	FT93C46A(08bit)@SOP8
FT93C46A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C46A
FT93C46A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C46A(16bit)@TSSOP8
FT93C56(08bit) [(SA602A)]	FT93C56(08bit)@SOP8
FT93C56(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C56
FT93C56(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C56(16bit)@TSSOP8
FT93C56A(08bit) [(SA602A)]	FT93C56A(08bit)@SOP8
FT93C56A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C56A
FT93C56A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C56A(16bit)@TSSOP8
FT93C66(08bit) [(SA602A)]	FT93C66(08bit)@SOP8
FT93C66(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66
FT93C66(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66(16bit)@TSSOP8
FT93C66A(08bit) [(SA602A)]	FT93C66A(08bit)@SOP8
FT93C66A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66A
FT93C66A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66A(16bit)@TSSOP8
FT93C86(08bit) [(SA602A)]	FT93C86(08bit)@SOP8
FT93C86(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C86
FT93C86(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C86(16bit)@TSSOP8
FT93C86A(08bit) [(SA602A)]	FT93C86A(08bit)@SOP8
FT93C86A(08bit)@TSSOP8 [(SA026)]	FT93C86A

(16bit)

FT93C86A(16bit)@SOP8 [(SA602A)] FT93C86A(16bit)@TSSOP8  
[(SA026)]

## FUJITSU

### E ( E ) PROM / FRAM / NVRAM

MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21183DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21183EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21183EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21184DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21184EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21184EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21191DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21191EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21191EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21192DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21192EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21192EM@FBGA56 [(SA642C-B032A-Y056F001)]

MB84VD21193DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD22180FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22180FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22181A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22181EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22182A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22182EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22182EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22183EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22184EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22190FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22190FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22191A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22191EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22192A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22192EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22192EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22193EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22194EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22280FE@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22282EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22283EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22284EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22290FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]

MB84VD22292EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22293EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22294EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22386EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22387EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22388EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22396EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22397EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22398EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23180FM@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD23280EA@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280EE@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280FA@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381EJ@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381HJ@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23481FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VF5F5FF4J2@BGA107 [ ( SA642D-B062A-Y088F001 ) ]  
MB84VP23481FK@FBGA65 [ ( SA642JJ-B032A-W064F001Y ) ]  
MB84VP24481HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MB84VP24491HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MB85R256@SOP28 [ ( SA630 ) ] MB85R256@TSOP28  
[ ( SA430T ) ]  
MB85R256A@SOP28 [ ( SA630 ) ] MB85R256A@TSOP28  
[ ( SA430T ) ]  
MBM271001 MBM271001@PLCC32  
[ ( SA015A1T ) ]  
MBM271001@TSOP32 [ ( SA410T ) ]  
MBM27128  
MBM27128@PLCC32 [ ( SA015A1T ) ]  
MBM2716  
MBM2716H  
MBM27256  
MBM27256@PLCC32 [ ( SA015A1T ) ]  
MBM2732  
MBM2732A  
MBM2764  
MBM2764@PLCC32 [ ( SA015A1T ) ]  
MBM27C1000  
MBM27C1000@PLCC32 [ ( SA015A1T ) ] MBM27C1000@TSOP32  
[ ( SA410T ) ]  
MBM27C1001 MBM27C1001@PLCC32  
[ ( SA015A1T ) ]



MBM27C1001@TSOP32 [ (SA410T) ]  
MBM27C1024  
MBM27C1024@PLCC44 [ (SA244) ]  
MBM27C1028  
MBM27C1028@PLCC32 [ (SA015A1T) ]  
MBM27C128  
MBM27C128@PLCC32 [ (SA015A1T) ]  
MBM27C128P  
MBM27C128P@PLCC32 [ (SA015A1T) ]  
MBM27C2000  
MBM27C2000@PLCC32 [ (SA015A1T) ] MBM27C2000@TSOP32  
[ (SA410T) ]  
MBM27C2001 MBM27C2001@PLCC32  
[ (SA015A1T) ]  
MBM27C2001@TSOP32 [ (SA410T) ]  
MBM27C2048  
MBM27C256 MBM27C256@PLCC32  
[ (SA015A1T) ]  
MBM27C256A MBM27C256A@PLCC32  
[ (SA015A1T) ]  
MBM27C256AP MBM27C256AP@PLCC32  
[ (SA015A1T) ]  
MBM27C256H MBM27C256H@PLCC32  
[ (SA015A1T) ]  
MBM27C32A  
MBM27C4001  
MBM27C4001@PLCC32 [ (SA015A1T) ] MBM27C4001@TSOP32  
[ (SA410T) ]  
MBM27C4096  
MBM27C512  
MBM27C512@PLCC32 [ (SA015A1T) ]  
MBM27C512P  
MBM27C512P@PLCC32 [ (SA015A1T) ]  
MBM27C64  
MBM27C64@PLCC32 [ (SA015A1T) ]  
MBM28C64  
MBM28C65  
MBM28F010  
MBM28F010@PLCC32 [ (SA015A1T) ] MBM28F010@TSOP32  
[ (SA410T) ]  
MBM29DL161BD@FBGA48 [ (SA642B-B026A-Y072F001) ]  
MBM29DL161BD@TSOP48 [ (SA247-B005) ]  
MBM29DL161BE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL161TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL161TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL321TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322TD@TSOP48 [ ( SA247-B005 ) ]

MBM29DL322TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400BC@PSOP44 [ ( SA638 ) ]  
MBM29DL400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400TC@PSOP44 [ ( SA638 ) ]  
MBM29DL400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL640E@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29DL640E@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL64DF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]

MBM29DL64DF@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800B@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800BA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 MBM29DL800BA@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800BB@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800BT@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800T@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800TA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 MBM29DL800TA@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DS163BE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
 MBM29DS163BE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DS163TE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
 MBM29DS163TE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29F001B MBM29F001B@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F001B@TSOP32 [ ( SA410T ) ]  
 MBM29F001T MBM29F001T@TSOP32  
 MBM29F001T@PLCC32 [ ( SA015A1T ) ]  
 [ ( SA410T ) ]  
 MBM29F002B MBM29F002B@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F002B@TSOP32 [ ( SA410T ) ]  
 MBM29F002NB MBM29F002NB@TSOP32  
 MBM29F002NB@PLCC32 [ ( SA015A1T ) ]  
 [ ( SA410T ) ]  
 MBM29F002NT MBM29F002NT@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F002NT@TSOP32 [ ( SA410T ) ]  
 MBM29F002T MBM29F002T@TSOP32  
 MBM29F002T@PLCC32 [ ( SA015A1T ) ]  
 [ ( SA410T ) ]  
 MBM29F010 MBM29F010@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F010@TSOP32 [ ( SA410T ) ]  
 MBM29F010A MBM29F010A@TSOP32  
 MBM29F010A@PLCC32 [ ( SA015A1T ) ]  
 [ ( SA410T ) ]  
 MBM29F016@PSOP44 [ ( SA638 ) ] MBM29F016@TSOP40  
 [ ( SA409T ) ]

MBM29F016@TSOP48 [(SA247-B005)]	MBM29F016A@PSOP44
[(SA638)]	
MBM29F016A@TSOP40 [(SA409T)]	MBM29F016A@TSOP48 [(SA247-
B005)]	
MBM29F016B@PSOP44 [(SA638)]	MBM29F016B@TSOP40
[(SA409T)]	
MBM29F016B@TSOP48 [(SA247-B005)]	MBM29F017B@TSOP48 [(SA247-
MBM29F017D@TSOP40 [(SA409T)]	MBM29F017D@TSOP48 [(SA247-
B005)]	
MBM29F032B@PSOP44 [(SA638)]	MBM29F032B@TSOP40
[(SA409T)]	
MBM29F033C@TSOP40 [(SA409T)]	
MBM29F040	
MBM29F040@PLCC32 [(SA015A1T)]	MBM29F040@TSOP32
[(SA410T)]	
MBM29F040B	MBM29F040B@PLCC32
[(SA015A1T)]	
MBM29F040B@TSOP32 [(SA410T)]	MBM29F040C@PLCC32
[(SA015A1T)]	
MBM29F040C@TSOP32 [(SA410T)]	MBM29F080@PSOP44
[(SA638)]	
MBM29F080@TSOP40 [(SA409T)]	MBM29F080A@TSOP48 [(SA247-
B005)]	
MBM29F080B@PSOP44 [(SA638)]	MBM29F080B@TSOP40
[(SA409T)]	
MBM29F100B@PSOP44 [(SA638-B006)]	MBM29F100B@TSOP48 [(SA247-
B005)]	
MBM29F100T@PSOP44 [(SA638-B006)]	MBM29F100T@TSOP48 [(SA247-
B005)]	
MBM29F160BE@TSOP48 [(SA247-B005)]	
MBM29F160TE@TSOP48 [(SA247-B005)]	
MBM29F200AB@PSOP44 [(SA638-B006)]	
MBM29F200AB@TSOP48 [(SA247-B005)]	
MBM29F200AT@PSOP44 [(SA638-B006)]	
MBM29F200AT@TSOP48 [(SA247-B005)]	
MBM29F200B@PSOP44 [(SA638-B006)]	MBM29F200B@TSOP48 [(SA247-
B005)]	
MBM29F200T@PSOP44 [(SA638-B006)]	MBM29F200T@TSOP48 [(SA247-
B005)]	
MBM29F400AB@PSOP44 [(SA638-B006)]	
MBM29F400AB@TSOP48 [(SA247-B005)]	
MBM29F400AT@PSOP44 [(SA638-B006)]	

MBM29F400AT@TSOP48 [(SA247-B005)]	
MBM29F400B@PSOP44 [(SA638-B006)]	MBM29F400B@TSOP48 [(SA247-B005)]
MBM29F400BB@PSOP44 [(SA638-B006)]	
MBM29F400BB@TSOP48 [(SA247-B005)]	
MBM29F400BT@PSOP44 [(SA638-B006)]	
MBM29F400BT@TSOP48 [(SA247-B005)]	
MBM29F400T@PSOP44 [(SA638-B006)]	MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)]	MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BA@PSOP44 [(SA638-B006)]	
MBM29F800BA@TSOP48 [(SA247-B005)]	
MBM29F800BB@PSOP44 [(SA638-B006)]	
MBM29F800BB@TSOP48 [(SA247-B005)]	
MBM29F800BT@PSOP44 [(SA638-B006)]	
MBM29F800BT@TSOP48 [(SA247-B005)]	
MBM29F800T@PSOP44 [(SA638-B006)]	MBM29F800T@TSOP48 [(SA247-B005)]
MBM29F800TA@PSOP44 [(SA638-B006)]	
MBM29F800TA@TSOP48 [(SA247-B005)]	
MBM29LL800B@TSOP48 [(SA247-B005)]	
MBM29LL800BB@TSOP48 [(SA247-B005)]	
MBM29LL800BT@TSOP48 [(SA247-B005)]	
MBM29LL800T@TSOP48 [(SA247-B005)]	
MBM29LV001B@PLCC32 [(SA015A1T)]	MBM29LV001BB@PLCC32 [(SA015A1T)]
MBM29LV001BB@TSOP32 [(SA410T)]	MBM29LV001BC@PLCC32 [(SA015A1T)]
MBM29LV001BC@TSOP32 [(SA410T)]	MBM29LV001BT@PLCC32 [(SA015A1T)]
MBM29LV001BT@TSOP32 [(SA410T)]	MBM29LV001T@TSOP32 [(SA410T)]
MBM29LV001TC@PLCC32 [(SA015A1T)]	MBM29LV001TC@TSOP32 [(SA410T)]
MBM29LV002B@TSOP40 [(SA409T)]	MBM29LV002T@TSOP40 [(SA409T)]
MBM29LV004B@PSOP44 [(SA638)]	MBM29LV004B@TSOP40 [(SA409T)]
MBM29LV004BB@TSOP40 [(SA409T)]	MBM29LV004BT@TSOP40 [(SA409T)]
MBM29LV004T@PSOP44 [(SA638)]	MBM29LV004T@TSOP40 [(SA409T)]

MBM29LV008B@PSOP44 [ (SA638) ] [ (SA409T) ]	MBM29LV008B@TSOP40
MBM29LV008BB@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV008BT@TSOP40
MBM29LV008T@PSOP44 [ (SA638) ] [ (SA409T) ]	MBM29LV008T@TSOP40
MBM29LV016/B@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV016/T@TSOP40
MBM29LV016B@TSOP40 [ (SA409T) ]	
MBM29LV017@FBGA48 [ (SA642O-B026A-T064F001) ]	
MBM29LV017@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV017B@TSOP40
MBM29LV017E@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV033C@TSOP40
MBM29LV080@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV081@TSOP40
MBM29LV081B@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV116B@TSOP40
MBM29LV160B@SON46 [ (SA631) ] ( * )	MBM29LV160B@SON46
MBM29LV160BB@PSOP44 [ (SA638-B006) ]	
MBM29LV160BB@TSOP48 [ (SA247-B005) ]	
MBM29LV160BE@FBGA48 [ (SA642B-B026A-Y072F001) ]	
MBM29LV160BE@TSOP48 [ (SA247-B005) ]	
MBM29LV160BM@FBGA48 [ (SA642B-B026A-Y072F001) ]	
MBM29LV160BM@TSOP48 [ (SA247-B005) ]	
MBM29LV160BT@PSOP44 [ (SA638-B006) ]	
MBM29LV160BT@TSOP48 [ (SA247-B005) ]	
MBM29LV160T@SON46 [ (SA631) ] ( * )	MBM29LV160T@SON46
MBM29LV160TE@FBGA48 [ (SA642B-B026A-Y072F001) ]	
MBM29LV160TE@TSOP48 [ (SA247-B005) ]	
MBM29LV160TM@FBGA48 [ (SA642B-B026A-Y072F001) ]	
MBM29LV160TM@TSOP48 [ (SA247-B005) ]	
MBM29LV200B@PSOP44 [ (SA638-B006) ]	
MBM29LV200B@TSOP48 [ (SA247-B005) ]	
MBM29LV200BB@PSOP44 [ (SA638-B006) ]	
MBM29LV200BB@TSOP48 [ (SA247-B005) ]	
MBM29LV200BC@PSOP44 [ (SA638) ]	
MBM29LV200BC@TSOP48 [ (SA247-B005) ]	
MBM29LV200BT@PSOP44 [ (SA638-B006) ]	
MBM29LV200BT@TSOP48 [ (SA247-B005) ]	
MBM29LV200T@PSOP44 [ (SA638-B006) ]	

MBM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200TC@PSOP44 [ ( SA638 ) ]  
MBM29LV200TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400BC@PSOP44 [ ( SA638 ) ]  
MBM29LV400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400TC@PSOP44 [ ( SA638 ) ]  
MBM29LV400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV650UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV651UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV652UE@FGBA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29LV800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800B@SON46 [ ( SA631 ) ] MBM29LV800B@SON46  
( \* )  
MBM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BA@PSOP44 [ ( SA638 ) ]  
MBM29LV800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BE@PSOP44 [ ( SA638 ) ]  
MBM29LV800BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800T@SON46 [ ( SA631 ) ] MBM29LV800T@SON46  
( \* )  
MBM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]



MBM29LV800TA@PSOP44 [ ( SA638 ) ]  
 MBM29LV800TA@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV800TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29LV800TE@PSOP44 [ ( SA638 ) ]  
 MBM29LV800TE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PDS323B@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29PDS323T@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29PL12LM@TSOP56 [ ( SA628-B102 ) ]  
 MBM29PL160BD@PSOP44 [ ( SA638 ) ]  
 MBM29PL160BD@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL160TD@PSOP44 [ ( SA638 ) ]  
 MBM29PL160TD@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL32BM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 MBM29PL32BM@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL32TM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 MBM29PL32TM@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL64LM@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL64LM@TSOP56 [ ( SA628-B067 ) ]  
 MBM29QM12DH@FBGA88 [ ( SA642J-B101A-W080F001 ) ]  
 MBM29QM12DH@TSOP56 [ ( SA628-B097 ) ]  
 MBM29SL160BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29SL160BD@TSOP48 [ ( SA247-B005 ) ]  
 MBM29SL160TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29SL160TD@TSOP48 [ ( SA247-B005 ) ]  
 MBM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
 MBM29SL800BT@TSOP48 [ ( SA247-B005 ) ]

## DRAM & SRAM

MB81C78A MB81C78A@SOIC28  
 [ ( SA630 ) ]

## MICROCONTROLLER

MB89F202@SDIP32 [ ( SA653 ) ] MB89F202@SSOP34  
 [ ( SA689 ) ]  
 MB89F202RA@QFP32 [ ( SA663 ) ] MB89F202RA@SDIP32  
 [ ( SA653 ) ]  
 MB89F202RA@SSOP34 [ ( SA689 ) ] MB89F482AS@LQFP44  
 [ ( SA245A ) ]  
 MB89F482AS@SDIP42 [ ( SA028 ) ] MB89F482AW@LQFP44

[ ( SA245A ) ]  
MB89F482AW@SDIP42 [ ( SA028 ) ] MB89F482HS@LQFP44  
[ ( SA245A ) ]  
MB89F482HS@SDIP42 [ ( SA028 ) ] MB89F482HW@LQFP44  
[ ( SA245A ) ]  
MB89F482HW@SDIP42 [ ( SA028 ) ]  
MB89P195  
MB89P195(F)@SOIC28 [ ( SA630 ) ]  
MB89P195AP  
MB89P195AP(F)@SOIC28 [ ( SA630 ) ]  
MB89P195P  
MB89P195P(F)@SOIC28 [ ( SA630 ) ]

## GENCORE

### MICROCONTROLLER

GC87C520A0 GC87C520A0@PLCC44  
[ ( SA244 ) ]  
GC87C520A0@TQFP44 [ ( SA245A ) ]  
GC87C520G0  
GC87C520G0@PLCC44 [ ( SA244 ) ] GC87C520G0@TQFP44  
[ ( SA245A ) ]

## GENERAL(GI)

### E ( E ) PROM / FRAM / NVRAM

27256  
27C128  
27C128@PLCC32 [ ( SA015A1T ) ]  
27C256  
27C256@PLCC32 [ ( SA015A1T ) ]  
27C512  
27C513  
27C64  
27C64@PLCC32 [ ( SA015A1T ) ]  
27HC191  
27HC291  
27HC64

27HC641  
 27HC641L  
 27HC64L  
 28C04  
 28C04A  
 28C04F  
 28C16  
 28C16A  
 28C16F  
 28C17  
 28C17F  
 ER5911  
 ER5911@SOIC8 [(SA602A)]  
 GI5911  
 GI5911@SOIC8 [(SA602A)]  
 GI59C11  
 GI59C11@SOIC8 [(SA602A)]  
 GI59C12  
 GI59C12@SOIC8 [(SA602A)]  
 GR27C513

## GENERIC

### E (E) PROM/FRAM/NVRAM

27128(21V) (12.5V)	27128A
2716(25V) (12.5V)	27256
2732(25V) (21V)	2732A
2732B(12.5V) (12.5V)	27512
27512(21V) (21V)	2764
2764A(12.5V) (12.5V)	27C128
27C128(21V) (25V)	27C16
27C256(12.5V) (25V)	27C32
27C512(12.5V)	27C64

( 12.5V )  
27C64 ( 21V )

## GIGADEVICE

### E ( E ) PROM / FRAM / NVRAM

GD25D40 HEADER01 ]	GD25D40 ( ISP ) [ ISP-
GD25D40@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25D40@SOP8 ( ISP ) [ ISP-
GD25D80 HEADER01 ]	GD25D80 ( ISP ) [ ISP-
GD25D80@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25D80@SOP8 ( ISP ) [ ISP-
GD25F40 HEADER01 ]	GD25F40 ( ISP ) [ ISP-
GD25F40@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25F40@SOP8 ( ISP ) [ ISP-
GD25F80 HEADER01 ]	GD25F80 ( ISP ) [ ISP-
GD25F80@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25F80@SOP8 ( ISP ) [ ISP-
GD25T80 HEADER01 ]	GD25T80 ( ISP ) [ ISP-
GD25T80@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25T80@SOP8 ( ISP ) [ ISP-

## GOAL

### MICROCONTROLLER

VRS1000 [ ( SA244 ) ]	VRS1000@PLCC44
VRS1000@TQFP44 [ ( SA245A ) ]	
VRS1050 VRS1050@PLCC44 [ ( SA244 ) ] [ ( SA675 ) ]	VRS1050@TQFP44
VRS1100 [ ( SA244 ) ]	VRS1100@PLCC44

VRS1100@TQFP44 [ ( SA245A ) ]

VRS540

VRS540@PLCC44 [ ( SA244 ) ]

[ ( SA245A ) ]

VRS550

[ ( SA244 ) ]

VRS550@TQFP44 [ ( SA245A ) ]

VRS560

VRS560@PLCC44 [ ( SA244 ) ]

[ ( SA245A ) ]

VRS570

[ ( SA244 ) ]

VRS570@TQFP44 [ ( SA245A ) ]

VRS580

VRS580@PLCC44 [ ( SA244 ) ]

[ ( SA245A ) ]

VRS700

[ ( SA244 ) ]

VRS700@TQFP44 [ ( SA245A ) ]

VRS900

VRS900@PLCC44 [ ( SA244 ) ]

[ ( SA245A ) ]

VRS540@TQFP44

VRS550@PLCC44

VRS560@TQFP44

VRS570@PLCC44

VRS580@TQFP44

VRS700@PLCC44

VRS900@TQFP44

## GREENWICH

### E ( E ) PROM / FRAM / NVRAM

GR27128

GR27256

GR27512

GR2764

## HAIER

### MICROCONTROLLER

HCM87CP311SP@SDIP42 [ ( SA028 ) ]

HR6P59P2DL

HR6P59P2SL@SOP14 [ ( SA602 ) ]

HR6P60P2DL

HR6P60P2DL-A  
 HR6P60P2EL  
 HR6P60P2EL-A HR6P60P2SL@SOP20  
 [ (SA404) ]  
 HR6P60P2SL@SSOP20 [ (SA626A) ] HR6P60P2SL-A@SOP20  
 [ (SA404) ]  
 HR6P60P2SL-A@SSOP20 [ (SA626A) ] HR6P60P2XL@SOP18  
 [ (SA404) ]  
 HR6P60P2XL-A@SOP18 [ (SA404) ] HR6P60P2YL@SOP14  
 [ (SA404) ]  
 HR6P60P2YL-A@SOP14 [ (SA404) ]  
 HR6P62P4D  
 HR6P62P4DH  
 HR6P62P4DHL  
 HR6P62P4DHL( INTOSC ) HR6P62P4DHL-  
 D  
 HR6P62P4DHL-D( INTOSC )  
 HR6P62P4NHL( INTOSC )@SSOP20 [ (SA626A) ]  
 HR6P62P4NHL@SSOP20 [ (SA626A) ]  
 HR6P62P4NHL-D( INTOSC )@SSOP20 [ (SA626A) ]  
 HR6P62P4NHL-D@SSOP20 [ (SA626A) ]  
 HR6P62P4RHL( INTOSC )@SSOP20 [ (SA626A) ]  
 HR6P62P4RHL@SSOP20 [ (SA626A) ]  
 HR6P62P4RHL-D( INTOSC )@SSOP20 [ (SA626A) ]  
 HR6P62P4RHL-D@SSOP20 [ (SA626A) ] HR6P62P4SH@SOP20 [ (SA404  
 +B003) ]  
 HR6P62P4SHL( INTOSC )@SOP20 [ (SA404) ]  
 HR6P62P4SHL@SOP20 [ (SA404) ]  
 HR6P62P4SHL-D( INTOSC )@SOP20 [ (SA404) ]  
 HR6P62P4SHL-D@SOP20 [ (SA404) ]  
 HR6P62P4XHL( INTOSC )@SOP18 [ (SA404) ]  
 HR6P62P4XHL@SOP18 [ (SA404) ]  
 HR6P62P4XHL-D( INTOSC )@SOP18 [ (SA404) ]  
 HR6P62P4XHL-D@SOP18 [ (SA404) ] HR6P62P4YHL@SOIC14  
 [ (SA602) ]  
 HR6P62P4YHL-D@SOP14 [ (SA602) ]  
 HR6P67P4D  
 HR6P67P4DL HR6P67P4DL-  
 B  
 HR6P67P4SL@SOP14 [ (SA404+B003) ]  
 HR6P67P4SL-B@SOP14 [ (SA404+B003) ]  
 HR6P71F8D HR6P71F8D  
 ( REVERSE )

HR6P71F8S(REVERSE)@SOP20 [(SA404)]  
 HR6P71F8S@SOP20 [(SA404)]  
 HR6P72P4D  
 HR6P72P4DL HR6P72P4S@SOP28  
 [(SA404)]  
 HR6P72P4SL@SOP28 [(SA404+B003)]  
 HR6P73P8DB  
 HR6P73P8DBL HR6P73P8SB@SOP28  
 [(SA404)]  
 HR6P73P8SBL@SOP28 [(SA404-B003)]  
 HR6P73PGD  
 HR6P73PGDH  
 HR6P73PGDHL  
 HR6P73PGS@SOP28 [(SA404+B003)] HR6P73PGSH@SOP28  
 [(SA404)]  
 HR6P73PGSHL@SOP28 [(SA404-B003)]  
 HR6P76PGD  
 HR6P76PGDL HR6P76PGS@SOP28  
 [(SA404)]  
 HR6P76PGSL@SOP28 [(SA404-B003)]  
 HR6P77PGD  
 HR6P77PGDL HR6P77PGL@LQFP44 [(SA245-  
 B005)]  
 HR6P77PGLL@LQFP44 [(SA245-B005)] HR6P78P4SL@SOP32 [(SA715  
 +B006)]  
 HR6P90FGD HR6P90FGS@SOP28  
 [(SA404)]  
 HR6P90FHD HR6P90FHS@SOP28  
 [(SA404)]  
 HR6P91FGS@SOP32 [(SA715)] HR6P91FHS@SOP32  
 [(SA715)]  
 HR6P92FGD HR6P92FGL@LQFP44  
 [(SA245A)]  
 HR6P92FHD HR6P92FHL@LQFP44  
 [(SA245A)]  
 HR6P95F8D HR6P95F8S@SOP28  
 [(SA404)]  
 HR6P97FGD HR6P97FGD  
 (EEPROM)  
 HR6P97FGD(EEPROM)(ISP) [ISP-HEADER01]  
 HR6P97FGD(ISP) [ISP-HEADER01]  
 HR6P97FGS(EEPROM)@SOP28 [(SA404)]  
 HR6P97FGS(EEPROM)@SOP28(ISP) [ISP-HEADER01]

HR6P97FGS@SOP28 [(SA404)]  
HR6P97FGS@SOP28(ISP) [ISP-HEADER01]  
HR6P98FGD HR6P98FGD  
(EEPROM)  
HR6P98FGD(EEPROM)(ISP) [ISP-HEADER01]  
HR6P98FGD(ISP) [ISP-HEADER01]  
HR6P98FGL(EEPROM)@LQFP44 [(SA245A)]  
HR6P98FGL(EEPROM)@LQFP44(ISP) [ISP-HEADER01]  
HR6P98FGL@LQFP44 [(SA245A)]  
HR6P98FGL@LQFP44(ISP) [ISP-HEADER01]  
HR7T46P8V@SDIP42 [(SA028)] HR7T46PGV@SDIP42 [(SA028  
+B005)]  
HR7T47P8L@LQFP44 [(SA245A)] HR7T47PGL@LQFP44 [(SA245A  
+B005)]

## HARRIS

### DRAM & SRAM

HM6516 HM6516@PLCC32  
[(SA015A1T)]  
HM65162 HM65162@PLCC32  
[(SA015A1T)]  
HM65642 HM65642@TSOP28  
[(SA643)]

## HITACHI

### E(E)PROM/FRAM/NVRAM

HN27128AG  
HN27128AP  
HN27256G  
HN27256P  
HN27512G  
HN27512P  
HN27C101AG  
HN27C101AP  
HN27C101G  
HN27C101P



HN27C1024HG HN27C1024HG@PLCC44  
[ (SA244) ]  
HN27C256AG  
HN27C256FP  
HN27C256G  
HN27C256HG  
HN27C301AG  
HN27C301AP  
HN27C301G  
HN27C301P  
HN27C4000FP  
HN27C4000G  
HN27C4001 HN27C4001@TSOP32  
[ (SA410T) ]  
HN27C4001G  
HN27C4096A  
HN27C4096A@PLCC44 [ (SA244) ]  
HN27C4096FP  
HN27C4096FP@PLCC44 [ (SA244) ]  
HN27C4096G  
HN27C4096G@PLCC44 [ (SA244) ]  
HN27C512G  
HN27C512G@PLCC32 [ (SA015A1T) ]  
HN27C64G  
HN28F101 HN28F101@PLCC32  
[ (SA015A1T) ]  
HN28F101@SOP32 [ (SA438T) ] HN28F101@TSOP32  
[ (SA410T) ]  
HN29A128A0A@CSP95 [ (SA642A-B066A-Y096N001) ]  
HN29A128A0A@TSOP48 [ (SA247-B005) ]  
HN29V128A0A@CSP95 [ (SA642A-B066A-Y096N001) ]  
HN29V128A0A@TSOP48 [ (SA247-B005) ]  
HN29V128A0E@CSP95 [ (SA642A-B066A-Y096N001) ]  
HN29V51211@TSOP48 [ (SA247-B005) ]  
HN462716G  
HN462732G HN48016  
(P)  
HN4827128G  
HN4827128P  
HN482732AG  
HN482764G  
HN482764P HN58064(FP)@SOIC28  
[ (SA404) ]

HN58064(P) [(SA438T)]	HN58C1001(FP)@SSOP32
HN58C1001(P) [(SA620)]	HN58C1001(T)@VSOP32
HN58C256A(FP)@SOP28 [(SA630)] (P)	HN58C256A
HN58C256A(T)@TSOP28 [(SA643)] [(SA620)]	HN58C257A(T)@TSOP32
HN58C65(FP)@SOIC28 [(SA404)] (P)	HN58C65
HN58C66 [(SA630)]	HN58C66@SOP28
HN58C66@TSOP28 [(SA430T)]	
HN58V24256 HN58V24256@SOIC8 [(SA602A)] [(SA026)]	HN58V24256@TSSOP14
HN58V24512 [(SA602A)]	HN58V24512@SOIC8
HN58V256A [(SA430T)]	HN58V256A@TSOP28
HN58V65A [(SA630)]	HN58V65A@SOIC28
HN58V65A@TSOP28 [(SA430T)]	
HN58V66A HN58V66A@SOIC28 [(SA630)] [(SA430T)]	HN58V66A@TSOP28
HN58W241000 [(SA602A)]	HN58W241000@SOIC8
HN58X2402 [(SA602A)]	HN58X2402@SOIC8
HN58X2402@TSSOP8 [(SA026)]	
HN58X2404 HN58X2404@SOIC8 [(SA602A)] [(SA026)]	HN58X2404@TSSOP8
HN58X2408 [(SA602A)]	HN58X2408@SOIC8
HN58X2408@TSSOP8 [(SA026)]	
HN58X24128 HN58X24128@SOIC8 [(SA602A)]	
HN58X2416 HN58X2416@SOIC8 [(SA602A)] [(SA026)]	HN58X2416@TSSOP8
HN58X24256	HN58X24256@SOIC8

[ ( SA602A ) ]	
HN58X2432	HN58X2432@SOIC8
[ ( SA602A ) ]	
HN58X2432@TSSOP8 [ ( SA026 ) ]	
HN58X24512	
HN58X24512@SOIC8 [ ( SA602A ) ]	
HN58X2464	
HN58X2464@SOIC8 [ ( SA602A ) ]	HN58X2464@TSSOP8
[ ( SA026 ) ]	
HN58X2502@SOIC8 [ ( SA602A ) ]	HN58X2502@TSSOP8
[ ( SA026 ) ]	
HN58X2504@SOIC8 [ ( SA602A ) ]	HN58X2504@TSSOP8
[ ( SA026 ) ]	
HN58X25128@SOIC8 [ ( SA602A ) ]	HN58X25128@TSSOP14
[ ( SA026 ) ]	
HN58X25256@SOIC8 [ ( SA602A ) ]	HN58X25256@TSSOP14
[ ( SA026 ) ]	
HN58X2532@SOIC8 [ ( SA602A ) ]	HN58X2532@TSSOP8
[ ( SA026 ) ]	
HN58X2564@SOIC8 [ ( SA602A ) ]	HN58X2564@TSSOP8
[ ( SA026 ) ]	
HT29VB800@TSOP48 [ ( SA247-B005 ) ]	HT29VT800@TSOP48 [ ( SA247-B005 ) ]
HT29WB800@TSOP48 [ ( SA247-B005 ) ]	HT29WT800@TSOP48 [ ( SA247-B005 ) ]
V128128A0E@CSP95 [ ( SA642A-B105A-Y096N001 ) ]	

## DRAM & SRAM

HM6116	HM6116@PLCC32
[ ( SA015A1T ) ]	
HM6116A	HM6116A@PLCC32
[ ( SA015A1T ) ]	
HM6208	HM6208@SOJ24
[ ( SA646 ) ]	
HM6208H	HM6208H@SOJ24
[ ( SA646 ) ]	
HM62256	HM62256@TSOP28
[ ( SA643 ) ]	
HM62256B	HM62256B@TSOP28
[ ( SA643 ) ]	
HM624256	HM624256@SOJ28

[ ( SA646 ) ]	
HM6264A	HM6264A@TSOP28
[ ( SA643 ) ]	
HM6267	
HM6268	
HM628128	HM628128@TSOP32
[ ( SA410T ) ]	
HM628128A	HM628128A@TSOP32
[ ( SA410T ) ]	
HM62832	HM62832@TSOP28
[ ( SA643 ) ]	
HM62832H	HM62832H@TSOP28
[ ( SA643 ) ]	
HM628512	HM628512@TSOP32
[ ( SA729 ) ]	
HM6287	
HM6287HP	
HM6288	HM6288@SOJ22
[ ( SA646 ) ]	
HM65256B	HM65256B@TSOP28
[ ( SA643 ) ]	
HM658128	HM658128@TSOP32
[ ( SA410T ) ]	
HM66204	HM66204@TSOP32
[ ( SA410T ) ]	
HM6707	HM6707@SOJ24
[ ( SA646 ) ]	
HM6707A	HM6707A@SOJ24
[ ( SA646 ) ]	
HM6708	HM6708@SOJ24
[ ( SA646 ) ]	
HM6708A	HM6708A@SOJ24
[ ( SA646 ) ]	
HM6716	HM6716@PLCC32
[ ( SA015A1T ) ]	
HM6787	
HM6787HP	
HM6788	HM6788@SOJ22
[ ( SA646 ) ]	
HM6788H	HM6788H@SOJ22
[ ( SA646 ) ]	
HM6788HA	HM6788HA@SOJ22
[ ( SA646 ) ]	

## MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)]	HD4074344@SOIC28
[(SA404)]	
HD4074394@SDIP28 [(SA022A)]	HD4074394@SOIC28
[(SA404)]	
HD64F3694FX@TQFP48 [(SA671)]	HD64F3694FY@TQFP48
[(SA248)]	
HD64F3694GFX@TQFP48 [(SA671)]	HD64F3694GFY@TQFP48
[(SA248)]	

## HOLTEK

### E (E) PROM / FRAM / NVRAM

HT24C01	HT24C01@SOIC8
[(SA602A)]	
HT24C02	HT24C02@SOIC8
[(SA602A)]	
HT24C04	HT24C04@SOIC8
[(SA602A)]	
HT24C08	
HT24C16	
HT24LC01	HT24LC01@SOIC8
[(SA602A)]	
HT24LC01@TSSOP8 [(SA026)]	
HT24LC02	
HT24LC02@SOIC8 [(SA602A)]	HT24LC02@TSSOP8
[(SA026)]	
HT24LC04	HT24LC04@SOIC8
[(SA602A)]	
HT24LC08	HT24LC08@SOIC8
[(SA602A)]	
HT24LC16	HT24LC16@SOIC8
[(SA602A)]	
HT24LC32	HT24LC32@SOIC8
[(SA602A)]	
HT24LC64	HT24LC64@SOIC8
[(SA602A)]	
HT25LC512@SOIC8 [(SA602A)]	

HT27C010	
HT27C010@PLCC32 [(SA015A1T)]	HT27C010@TSOP32
[(SA410T)]	
HT27C020	HT27C020@PLCC32
[(SA015A1T)]	
HT27C020@TSOP32 [(SA410T)]	
HT27C040	
HT27C040@PLCC32 [(SA015A1T)]	HT27C040@TSOP32
[(SA410T)]	
HT27C4096	HT27C4096@PLCC44
[(SA244)]	
HT27C512	HT27C512@PLCC32
[(SA015A1T)]	
HT27C512@TSOP28 [(SA430T)]	
HT27LC010	
HT27LC010@PLCC32 [(SA015A1T)]	HT27LC010@TSOP32
[(SA410T)]	
HT27LC020	HT27LC020@PLCC32
[(SA015A1T)]	
HT27LC020@TSOP32 [(SA410T)]	
HT27LC040	
HT27LC040@PLCC32 [(SA015A1T)]	HT27LC040@TSOP32
[(SA410T)]	
HT27LC4096	HT27LC4096@PLCC44
[(SA244)]	
HT27LC512	HT27LC512@PLCC32
[(SA015A1T)]	
HT27LC512@TSOP28 [(SA430T)]	HT93C46
(16bit)	
HT93C46(16bit)@SOP8-A [(SA602A)]	HT93C46(16bit)@SOP8-B
[(SA602A)]	
HT93C46(16bit)@TSSOP8 [(SA026)]	HT93C56
(16bit)	
HT93C56(16bit)@SOP8-A [(SA602A)]	HT93C56(16bit)@SOP8-B
[(SA602A)]	
HT93C56(16bit)@TSSOP8 [(SA026)]	HT93C66
(16bit)	
HT93C66(16bit)@SOP8-A [(SA602A)]	HT93C66(16bit)@SOP8-B
[(SA602A)]	
HT93C66(16bit)@TSSOP8 [(SA026)]	HT93LC46A
(08bit)	
HT93LC46A(08bit)@SOP8-A [(SA602A)]	
HT93LC46A(08bit)@SOP8-B [(SA602A)]	

HT93LC46A(08bit)@TSSOP8 [(SA026)]  
HT93LC46A(16bit)  
HT93LC46A(16bit)@SOP8-A [(SA602A)]  
HT93LC46A(16bit)@SOP8-B [(SA602A)]  
HT93LC46A(16bit)@TSSOP8 [(SA026)]  
HT93LC46B(08bit)  
HT93LC46B(08bit)@SOP8-A [(SA602A)]  
HT93LC46B(08bit)@SOP8-B [(SA602A)]  
HT93LC46B(08bit)@TSSOP8 [(SA026)]  
HT93LC46B(16bit)  
HT93LC46B(16bit)@SOP8-A [(SA602A)]  
HT93LC46B(16bit)@SOP8-B [(SA602A)]  
HT93LC46B(16bit)@TSSOP8 [(SA026)]  
HT93LC56A(08bit)  
HT93LC56A(08bit)@SOP8-A [(SA602A)]  
HT93LC56A(08bit)@SOP8-B [(SA602A)]  
HT93LC56A(08bit)@TSSOP8 [(SA026)]  
HT93LC56A(16bit)  
HT93LC56A(16bit)@SOP8-A [(SA602A)]  
HT93LC56A(16bit)@SOP8-B [(SA602A)]  
HT93LC56A(16bit)@TSSOP8 [(SA026)]  
HT93LC56B(08bit)  
HT93LC56B(08bit)@SOP8-A [(SA602A)]  
HT93LC56B(08bit)@SOP8-B [(SA026)]  
HT93LC56B(08bit)@TSSOP8 [(SA026)]  
HT93LC56B(16bit)  
HT93LC56B(16bit)@SOP8-A [(SA602A)]  
HT93LC56B(16bit)@SOP8-B [(SA602A)]  
HT93LC56B(16bit)@TSSOP8 [(SA026)]  
HT93LC66A(08bit)  
HT93LC66A(08bit)@SOP8-A [(SA602A)]  
HT93LC66A(08bit)@SOP8-B [(SA602A)]  
HT93LC66A(08bit)@TSSOP8 [(SA026)]  
HT93LC66A(16bit)  
HT93LC66A(16bit)@SOP8-A [(SA602A)]  
HT93LC66A(16bit)@SOP8-B [(SA602A)]  
HT93LC66A(16bit)@TSSOP8 [(SA026)]  
HT93LC66B(08bit)  
HT93LC66B(08bit)@SOP8-A [(SA602A)]  
HT93LC66B(08bit)@SOP8-B [(SA026)]  
HT93LC66B(08bit)@TSSOP8 [(SA026)]  
HT93LC66B(16bit)  
HT93LC66B(16bit)@SOP8-A [(SA602A)]

HT93LC66B(16bit)@SOP8-B [(SA602A)]	
HT93LC66B(16bit)@TSSOP8 [(SA026)]	
HT93LC76(08bit)	
HT93LC76(08bit)@SOP8-A [(SA602A)]	
HT93LC76(08bit)@SOP8-B [(SA602A)]	
HT93LC76(08bit)@TSSOP8 [(SA026)]	HT93LC76
(16bit)	
HT93LC76(16bit)@SOP8-A [(SA602A)]	
HT93LC76(16bit)@SOP8-B [(SA602A)]	
HT93LC76(16bit)@TSSOP8 [(SA026)]	HT93LC86
(08bit)	
HT93LC86(08bit)@SOP8-A [(SA602A)]	
HT93LC86(08bit)@SOP8-B [(SA602A)]	
HT93LC86(08bit)@TSSOP8 [(SA026)]	HT93LC86
(16bit)	
HT93LC86(16bit)@SOP8-A [(SA602A)]	
HT93LC86(16bit)@SOP8-B [(SA602A)]	
HT93LC86(16bit)@TSSOP8 [(SA026)]	

## MICROCONTROLLER

HT46R22	HT46R22@SOP24
[(SA404)]	
HT46R23(dip24)	HT46R23
(dip28)	
HT46R23@SOP24 [(SA404)]	HT46R23@SOP28
[(SA404)]	
HT46R24	HT46R24@SOP28
[(SA404)]	
HT46R24@SSOP48 [(SA669)]	HT46R46
(dip18)	
HT46R46(dip20)	HT46R46@SOP18
[(SA404)]	
HT46R46@SOP20 [(SA404)]	HT46R46E
(dip18)	
HT46R46E@SOP18 [(SA404)]	HT46R46-
H	
HT46R46-H@SOP18 [(SA404)]	HT46R47
(dip18)	
HT46R47(dip20)	HT46R47@SOP18
[(SA404)]	
HT46R47@SOP20 [(SA404)]	HT46R47@SSOP20



[(SA674)]	
HT46R47E(dip18)	HT46R47E@SOP18
[(SA404)]	
HT46R47-H	HT46R47-H@SOP18
[(SA404)]	
HT46R48(dip20)	HT46R48
(dip24)	
HT46R48@SOP20 [(SA404)]	HT46R48@SOP24
[(SA404)]	
HT46R48@SSOP24 [(SA674)]	HT46R48E
(dip24)	
HT46R48E@SOP24 [(SA404)]	HT46R48E@SSOP24
[(SA674)]	
HT46R51A(dip18)	HT46R51A@SOP20
[(SA404)]	
HT46R51A@SSOP20 [(SA674)]	HT46R52A
(dip18)	
HT46R52A@SOP20 [(SA404)]	HT46R52A@SSOP20
[(SA674)]	
HT46R53A(dip28)	HT46R53A@SOP28
[(SA404)]	
HT46R54A(dip28)	HT46R54A@SOP28
[(SA404)]	
HT46R65@PQFP100 [(PEP+S427)]	HT46R65@SSOP56
[(SA669)]	
HT46R71D@SSOP48 [(SA669)]	
HT46RB70	
HT46RB70@SOP28 [(SA404)]	HT46RB70@SSOP48
[(SA669)]	
HT46RU22(dip24)	HT46RU22@SOP24
[(SA404)]	
HT46RU22@SSOP24 [(SA674)]	HT47R10A@QFP44
[(SA245)]	
HT48R05A	HT48R05A@SOP16
[(SA026)]	
HT48R05A@SOP18 [(SA404)]	
HT48R06A	
HT48R06A@SOP16 [(SA026)]	HT48R06A@SOP18
[(SA404)]	
HT48R07A	HT48R07A@SOP24
[(SA404)]	
HT48R07A@SSOP24 [(SA674)]	
HT48R08A	

HT48R08A@SOP16 [(SA026)]	HT48R08A@SOP18
[(SA404)]	
HT48R09A	HT48R09A@SOP24
[(SA404)]	
HT48R09A@SSOP24 [(SA674)]	
HT48R10A	
HT48R10A@SOP24 [(SA404)]	HT48R30A
(dip24)	
HT48R30A(dip28)	HT48R30A@SOP24
[(SA404)]	
HT48R30A@SOP28 [(SA404)]	
HT48R50A	
HT48R50A@SOP28 [(SA404)]	HT48R50A@SSOP48
[(SA669)]	
HT48R52A@QFP44 [(SA245A)]	HT48R70A@SSOP48
[(SA669)]	
HT48RA0-1	HT48RA0-1@SOP24
[(SA404)]	
HT48RA0-2	HT48RA0-2@SOP20
[(SA404)]	
HT48RA0-2@SSOP20 [(SA674)]	HT48RA0-
3	
HT48RA0-3@SOP20 [(SA404)]	HT48RA1@SOP28
[(SA404)]	
HT48RA1@SSOP28 [(SA626A)]	HT48RA3
(dip28)	
HT48RA3@SOP28 [(SA404)]	HT48RA3@SSOP28
[(SA626A)]	
HT48RA5(dip28)	HT48RA5@SOP28
[(SA404)]	
HT48RA5@SSOP28 [(SA626A)]	
HT48RB50	
HT48RB50@SOP28 [(SA404)]	HT48RB50@SSOP48
[(SA669)]	
HT48RB8@SOP28 [(SA404)]	HT48RB8@SSOP48
[(SA669)]	
HT49R30A@SSOP48 [(SA669)]	HT49R50A@SSOP48
[(SA669)]	
HT49RV5@SSOP56 [(SA669)]	HT82A821R@SOP24
[(SA404)]	
HT82A821R@SSOP24 [(SA674)]	HT82A822R@SSOP48
[(SA669)]	
HT82A832R@QFP48 [(SA248)]	HT82A832R@SSOP48

[ (SA669) ]	
HT82K68E	HT82K68E@SOP20
[ (SA404) ]	
HT82K68E@SOP28 [ (SA404) ]	HT82K68E@SSOP48
[ (SA669) ]	
HT82K94E@SSOP48 [ (SA669) ]	HT82K95E@SOP20
[ (SA404) ]	
HT82K95E@SOP28 [ (SA404) ]	HT82K95E@SSOP48
[ (SA669) ]	
HT82K96E(dip20)	HT82K96E
(dip40)	
HT82K96E@SOP20 [ (SA404) ]	HT82K96E@SOP28
[ (SA404) ]	
HT82K96E@SSOP48 [ (SA669) ]	HT82M99E
(dip18)	
HT82M99E(dip20)	HT82M99E@SOP18
[ (SA404) ]	
HT82M99E@SOP20 [ (SA404) ]	HT82M9AE@SOP20
[ (SA404) ]	
HT82M9AE@SOP24 [ (SA404) ]	HT82M9AE@SSOP20
[ (SA674) ]	
HT82M9AE@SSOP24 [ (SA674) ]	HT82M9BE@SOP24
[ (SA404) ]	
HT82M9BE@SOP28 [ (SA404) ]	HT82M9BE@SSOP24
[ (SA674) ]	
HT82M9BE@SSOP28 [ (SA626A) ]	HT95A100@SOP28
[ (SA404) ]	
HT95A10P@SOP28 [ (SA404) ]	HT95A200@SSOP48
[ (SA669) ]	
HT95A20P@SSOP48 [ (SA669) ]	HT95A300@SSOP48
[ (SA669) ]	
HT95A30P@SSOP48 [ (SA669) ]	

## HONGKONG

### E (E) PROM/FRAM/NVRAM

HK1215  
HK1225  
HK1235  
HK1245  
HK1255

HK1265  
HK1275  
HK1285  
HK1295  
HK12A5  
HK12B5  
OKS1225  
OKS1235  
OKS1245  
OKS1255  
OKS1265  
OKS1275  
OKS1285  
OKS1295  
OKS12A5  
OKS12B5

## **HYNIX**

### **E ( E ) PROM / FRAM / NVRAM**

H8ACS0EJ0MCP@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
HY2764  
HY27C64A  
HY27SF081G2A@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
HY27UA081G1M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF081G2A@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
HY27UF081G2A@TSOP48 [ ( SA247-B005 ) ]  
HY27UF081G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2A@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2B@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF084G2B@TSOP48 [ ( SA247-B005 ) ]  
HY27UF084G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UG082G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UG088G5M@TSOP48 [ ( SA247+B005 ) ]  
HY27US08121M@TSOP48 [ ( SA247-B005 ) ]  
HY27US081G1M@USOP48 [ ( SA765-B005 ) ]  
HY27US08281A@TSOP48 [ ( SA247-B005 ) ]  
HY27US08561A@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
HY27US08561A@TSOP48 [ ( SA247-B005 ) ]  
HY27US08561M@TSOP48 [ ( SA247-B005 ) ]

HY27UT084G2M@TSOP48 [ ( SA247-B005 ) ]  
 HY27UT088G2A@TSOP48 [ ( SA247-B005 ) ]  
 HY27UT088G2M@TSOP48 [ ( SA247-B005 ) ]  
 HY27UV08BG5M@TSOP48 [ ( SA247-B005 ) ]  
 HY29DL162BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DL162BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DL162TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DL162TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DL163BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DL163BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DL163TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DL163TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DS162BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DS162BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DS162TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DS162TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DS163BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DS163BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DS163TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DS163TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F002T HY29F002T@PLCC32  
 [ ( SA015A1T ) ]  
 HY29F002T@TSOP32 [ ( SA410T ) ]  
 HY29F040  
 HY29F040@PLCC32 [ ( SA015A1T ) ] HY29F040@TSOP32  
 [ ( SA410T ) ]  
 HY29F040A HY29F040A@PLCC32  
 [ ( SA015A1T ) ]  
 HY29F040A@TSOP32 [ ( SA410T ) ] HY29F080@TSOP40  
 [ ( SA409T ) ]  
 HY29F200B@PSOP44 [ ( SA638-B006 ) ] HY29F200B@TSOP48 [ ( SA247-B005 ) ]  
 HY29F200T@PSOP44 [ ( SA638-B006 ) ] HY29F200T@TSOP48 [ ( SA247-B005 ) ]  
 HY29F400ABG@PSOP44 [ ( SA638 ) ]  
 HY29F400ABT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F400ATG@PSOP44 [ ( SA638 ) ]  
 HY29F400ATT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F400BG@PSOP44 [ ( SA638 ) ] HY29F400BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F400TG@PSOP44 [ ( SA638 ) ] HY29F400TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F800ABG@PSOP44 [ ( SA638 ) ]

HY29F800ABT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F800ATG@PSOP44 [ ( SA638 ) ]  
 HY29F800ATT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F800BG@PSOP44 [ ( SA638 ) ] HY29F800BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F800TG@PSOP44 [ ( SA638 ) ] HY29F800TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29LV160BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29LV160BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29LV160TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29LV160TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29LV320BF@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
 HY29LV320BF@FBGA63 [ ( SA642E-B026A-T072F001 ) ]  
 HY29LV320BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29LV320TF@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
 HY29LV320TF@FBGA63 [ ( SA642E-B026A-T072F001 ) ]  
 HY29LV320TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29LV400BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29LV400TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29LV400TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29LV800BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29LV800BG@PSOP44 [ ( SA638 ) ]  
 HY29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29LV800TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29LV800TG@PSOP44 [ ( SA638 ) ]  
 HY29LV800TT@TSOP48 [ ( SA247-B005 ) ]  
 HY93C46 HY93C46@SOIC8  
 [ ( SA602A ) ]  
 HY93C56 HY93C56@SOIC8  
 [ ( SA602A ) ]  
 HY93C66 HY93C66@SOIC8  
 [ ( SA602A ) ]  
 HY93C76 HY93C76@SOIC8  
 [ ( SA602A ) ]  
 HY93C86 HY93C86@SOIC8  
 [ ( SA602A ) ]  
 HYC0SEF0MF3P@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
 HYC0SEH0AF3P@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
 HYD0SEE0MF2P@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
 HYD0SFE0BF1P@BGA149 [ ( SA700I-B308-T149F001Y ) ]  
 HYD0SFG0MF1P@BGA149 [ ( SA700I-B308-T149F001Y ) ]  
 HYG0SEG0MF2P@FBGA107 [ ( SA642V-B133-T096F001Y ) ]

HYG0UEG0MF2P@FBGA107 [ (SA642V-B133-T096F001Y) ]

**DRAM & SRAM**

HY62256A [ (SA643) ]	HY62256A@TSOP28
HY6264A [ (SA643) ]	HY6264A@TSOP28
HY628100A [ (SA438T) ]	HY628100A@SOP32
HY628100A@TSOP32 [ (SA410T) ]	
HY628100B HY628100B@SOP32 [ (SA438T) ]	HY628100B@TSOP32
[ (SA410T) ]	
HY628400 [ (SA438T) ]	HY628400@SOP32
HY628400@TSOP32 [ (SA410T) ]	
HY628400A HY628400A@SOP32 [ (SA438T) ]	HY628400A@TSOP32
[ (SA410T) ]	
HY62CT08081E [ (SA438T) ]	HY62CT08081E@SOP28
HY62CT08081E@TSOP28 [ (SA643) ]	
HY62KT08081E HY62KT08081E@SOP28 [ (SA438T) ]	HY62KT08081E@TSOP28
[ (SA643) ]	
HY62U8100B [ (SA438T) ]	HY62U8100B@SOP32
HY62U8100B@TSOP32 [ (SA410T) ]	
HY62U8200B HY62U8200B@SOP32 [ (SA438T) ]	HY62U8200B@TSOP32
[ (SA410T) ]	
HY62U8400A [ (SA438T) ]	HY62U8400A@SOP32
HY62U8400A@TSOP32 [ (SA410T) ]	
HY62UT08081E HY62UT08081E@SOP28 [ (SA438T) ]	HY62UT08081E@TSOP28
[ (SA643) ]	
HY62V8100B [ (SA438T) ]	HY62V8100B@SOP32
HY62V8100B@TSOP32 [ (SA410T) ]	
HY62V8200B	

HY62V8200B@SOP32 [(SA438T)]  
[(SA410T)]  
HY62V8400A  
[(SA438T)]  
HY62V8400A@TSOP32 [(SA410T)]  
HY62VT08081E  
HY62VT08081E@SOP28 [(SA438T)]  
[(SA643)]  
HY62WT08081E  
[(SA438T)]  
HY62WT08081E@TSOP28 [(SA643)]

HY62V8200B@TSOP32  
  
HY62V8400A@SOP32  
  
HY62VT08081E@TSOP28  
  
HY62WT08081E@SOP28

## MICROCONTROLLER

GMS97C1051  
[(SA404)]  
GMS97C2051  
[(SA404)]  
GMS97C51  
[(SA244)]  
GMS97C51@TQFP44 [(SA245A)]  
GMS97C52  
GMS97C52@PLCC44 [(SA244)]  
[(SA245A)]  
GMS97C54  
[(SA244)]  
GMS97C54@TQFP44 [(SA245A)]  
GMS97C56  
GMS97C56@PLCC44 [(SA244)]  
[(SA245A)]  
GMS97C58  
[(SA244)]  
GMS97C58@TQFP44 [(SA245A)]  
GMS97L1051  
GMS97L1051@SOIC20 [(SA404)]  
GMS97L2051  
GMS97L2051@SOIC20 [(SA404)]  
GMS97L51  
GMS97L51@PLCC44 [(SA244)]  
[(SA245A)]  
GMS97L52  
[(SA244)]

GMS97C1051@SOIC20  
  
GMS97C2051@SOIC20  
  
GMS97C51@PLCC44  
  
GMS97C52@TQFP44  
  
GMS97C54@PLCC44  
  
GMS97C56@TQFP44  
  
GMS97C58@PLCC44  
  
GMS97L51@TQFP44  
  
GMS97L52@PLCC44



GMS97L52@TQFP44 [ ( SA245A ) ]	
GMS97L54	
GMS97L54@PLCC44 [ ( SA244 ) ]	GMS97L54@TQFP44
[ ( SA245A ) ]	
GMS97L56	GMS97L56@PLCC44
[ ( SA244 ) ]	
GMS97L56@TQFP44 [ ( SA245A ) ]	
GMS97L58	
GMS97L58@PLCC44 [ ( SA244 ) ]	GMS97L58@TQFP44
[ ( SA245A ) ]	
GMS99C52	GMS99C52@PLCC44
[ ( SA244 ) ]	
GMS99C52@TQFP44 [ ( SA245A ) ]	
GMS99C58	
GMS99C58@PLCC44 [ ( SA244 ) ]	GMS99C58@TQFP44
[ ( SA245A ) ]	
HMS99C52	HMS99C52@PLCC44
[ ( SA244 ) ]	
HMS99C52@TQFP44 [ ( SA245A ) ]	
HMS99C58	
HMS99C58@PLCC44 [ ( SA244 ) ]	HMS99C58@TQFP44
[ ( SA245A ) ]	

## **HYNIX-CUSTOMER**

### **E ( E ) PROM / FRAM / NVRAM**

HY27UF081G2A(DD)@TSOP48 [ ( SA247-B005 ) ]  
HY27UF081G2A(DD5)@TSOP48 [ ( SA247+B005 ) ]  
HY27UF081G2A(MLT)@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2A(AMLOGIC)@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2A(MLT)@TSOP48 [ ( SA247-B005 ) ]  
HY27UF084G2M(YH)@TSOP48 [ ( SA247-B005 ) ]  
HY27US08281A(WS)@TSOP48 [ ( SA247-B005 ) ]  
HY27UT088G2A(64M)@TSOP48 [ ( SA247-B005 ) ]  
HY27UT088G2M(OMB)@TSOP48 [ ( SA247-B005 ) ]

## **HYUNDAI**

### **E ( E ) PROM / FRAM / NVRAM**

HY2764

HY27C64A

HY29DL162BF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DL162BT@TSOP48 [ (SA247-B005) ]

HY29DL162TF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DL162TT@TSOP48 [ (SA247-B005) ]

HY29DL163BF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DL163BT@TSOP48 [ (SA247-B005) ]

HY29DL163TF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DL163TT@TSOP48 [ (SA247-B005) ]

HY29DS162BF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DS162BT@TSOP48 [ (SA247-B005) ]

HY29DS162TF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DS162TT@TSOP48 [ (SA247-B005) ]

HY29DS163BF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DS163BT@TSOP48 [ (SA247-B005) ]

HY29DS163TF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DS163TT@TSOP48 [ (SA247-B005) ]

HY29F002T

HY29F002T@PLCC32

[ (SA015A1T) ]

HY29F002T@TSOP32 [ (SA410T) ]

HY29F040

HY29F040@PLCC32 [ (SA015A1T) ]

HY29F040@TSOP32

[ (SA410T) ]

HY29F040A

HY29F040A@PLCC32

[ (SA015A1T) ]

HY29F040A@TSOP32 [ (SA410T) ]

HY29F080@TSOP40

[ (SA409T) ]

HY29F200B@PSOP44 [ (SA638-B006) ]

HY29F200B@TSOP48 [ (SA247-

B005) ]

HY29F200T@PSOP44 [ (SA638-B006) ]

HY29F200T@TSOP48 [ (SA247-

B005) ]

HY29F400ABG@PSOP44 [ (SA638) ]

HY29F400ABT@TSOP48 [ (SA247-B005) ]

HY29F400ATG@PSOP44 [ (SA638) ]

HY29F400ATT@TSOP48 [ (SA247-B005) ]

HY29F400BG@PSOP44 [ (SA638) ]

HY29F400BT@TSOP48 [ (SA247-

B005) ]

HY29F400TG@PSOP44 [ (SA638) ]

HY29F400TT@TSOP48 [ (SA247-

B005) ]

HY29F800ABG@PSOP44 [ (SA638) ]

HY29F800ABT@TSOP48 [ (SA247-B005) ]

HY29F800ATG@PSOP44 [ (SA638) ]

HY29F800ATT@TSOP48 [ ( SA247-B005 ) ]	
HY29F800BG@PSOP44 [ ( SA638 ) ]	HY29F800BT@TSOP48 [ ( SA247-B005 ) ]
HY29F800TG@PSOP44 [ ( SA638 ) ]	HY29F800TT@TSOP48 [ ( SA247-B005 ) ]
HY29LV160BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]	
HY29LV160BT@TSOP48 [ ( SA247-B005 ) ]	
HY29LV160TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]	
HY29LV160TT@TSOP48 [ ( SA247-B005 ) ]	
HY29LV320BF@FBGA48 [ ( SA642E-B026A-T072F001 ) ]	
HY29LV320BF@FBGA63 [ ( SA642E-B026A-T072F001 ) ]	
HY29LV320BT@TSOP48 [ ( SA247-B005 ) ]	
HY29LV320TF@FBGA48 [ ( SA642E-B026A-T072F001 ) ]	
HY29LV320TF@FBGA63 [ ( SA642E-B026A-T072F001 ) ]	
HY29LV320TT@TSOP48 [ ( SA247-B005 ) ]	
HY29LV400BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]	
HY29LV400BT@TSOP48 [ ( SA247-B005 ) ]	
HY29LV400TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]	
HY29LV400TT@TSOP48 [ ( SA247-B005 ) ]	
HY29LV800BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]	
HY29LV800BG@PSOP44 [ ( SA638 ) ]	
HY29LV800BT@TSOP48 [ ( SA247-B005 ) ]	
HY29LV800TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]	
HY29LV800TG@PSOP44 [ ( SA638 ) ]	
HY29LV800TT@TSOP48 [ ( SA247-B005 ) ]	
HY93C46 [ ( SA602A ) ]	HY93C46@SOIC8
HY93C56 [ ( SA602A ) ]	HY93C56@SOIC8
HY93C66 [ ( SA602A ) ]	HY93C66@SOIC8
HY93C76 [ ( SA602A ) ]	HY93C76@SOIC8
HY93C86 [ ( SA602A ) ]	HY93C86@SOIC8

**DRAM & SRAM**

HY62256A [ ( SA643 ) ]	HY62256A@TSOP28
HY6264A [ ( SA643 ) ]	HY6264A@TSOP28

HY628100A [(SA438T)]	HY628100A@SOP32
HY628100A@TSOP32 [(SA410T)]	
HY628100B HY628100B@SOP32 [(SA438T)] [(SA410T)]	HY628100B@TSOP32
HY628400 [(SA438T)]	HY628400@SOP32
HY628400@TSOP32 [(SA410T)]	
HY628400A HY628400A@SOP32 [(SA438T)] [(SA410T)]	HY628400A@TSOP32
HY62CT08081E [(SA438T)]	HY62CT08081E@SOP28
HY62CT08081E@TSOP28 [(SA643)]	
HY62KT08081E HY62KT08081E@SOP28 [(SA438T)] [(SA643)]	HY62KT08081E@TSOP28
HY62U8100B [(SA438T)]	HY62U8100B@SOP32
HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B HY62U8200B@SOP32 [(SA438T)] [(SA410T)]	HY62U8200B@TSOP32
HY62U8400A [(SA438T)]	HY62U8400A@SOP32
HY62U8400A@TSOP32 [(SA410T)]	
HY62UT08081E HY62UT08081E@SOP28 [(SA438T)] [(SA643)]	HY62UT08081E@TSOP28
HY62V8100B [(SA438T)]	HY62V8100B@SOP32
HY62V8100B@TSOP32 [(SA410T)]	
HY62V8200B HY62V8200B@SOP32 [(SA438T)] [(SA410T)]	HY62V8200B@TSOP32
HY62V8400A [(SA438T)]	HY62V8400A@SOP32
HY62V8400A@TSOP32 [(SA410T)]	
HY62VT08081E HY62VT08081E@SOP28 [(SA438T)] [(SA643)]	HY62VT08081E@TSOP28
HY62WT08081E	HY62WT08081E@SOP28

[ ( SA438T ) ]  
HY62WT08081E@TSOP28 [ ( SA643 ) ]

## MICROCONTROLLER

GMS97C1051 [ ( SA404 ) ]	GMS97C1051@SOIC20
GMS97C2051 [ ( SA404 ) ]	GMS97C2051@SOIC20
GMS97C51 [ ( SA244 ) ]	GMS97C51@PLCC44
GMS97C51@TQFP44 [ ( SA245A ) ]	
GMS97C52 GMS97C52@PLCC44 [ ( SA244 ) ]	GMS97C52@TQFP44
[ ( SA245A ) ]	
GMS97C54 [ ( SA244 ) ]	GMS97C54@PLCC44
GMS97C54@TQFP44 [ ( SA245A ) ]	
GMS97C56 GMS97C56@PLCC44 [ ( SA244 ) ]	GMS97C56@TQFP44
[ ( SA245A ) ]	
GMS97C58 [ ( SA244 ) ]	GMS97C58@PLCC44
GMS97C58@TQFP44 [ ( SA245A ) ]	
GMS97L1051 GMS97L1051@SOIC20 [ ( SA404 ) ]	
GMS97L2051 GMS97L2051@SOIC20 [ ( SA404 ) ]	
GMS97L51 GMS97L51@PLCC44 [ ( SA244 ) ]	GMS97L51@TQFP44
[ ( SA245A ) ]	
GMS97L52 [ ( SA244 ) ]	GMS97L52@PLCC44
GMS97L52@TQFP44 [ ( SA245A ) ]	
GMS97L54 GMS97L54@PLCC44 [ ( SA244 ) ]	GMS97L54@TQFP44
[ ( SA245A ) ]	
GMS97L56 [ ( SA244 ) ]	GMS97L56@PLCC44
GMS97L56@TQFP44 [ ( SA245A ) ]	
GMS97L58 GMS97L58@PLCC44 [ ( SA244 ) ]	GMS97L58@TQFP44

[ ( SA245A ) ]	
GMS99C52	GMS99C52@PLCC44
[ ( SA244 ) ]	
GMS99C52@TQFP44 [ ( SA245A ) ]	
GMS99C58	
GMS99C58@PLCC44 [ ( SA244 ) ]	GMS99C58@TQFP44
[ ( SA245A ) ]	
HMS99C52	HMS99C52@PLCC44
[ ( SA244 ) ]	
HMS99C52@TQFP44 [ ( SA245A ) ]	
HMS99C58	
HMS99C58@PLCC44 [ ( SA244 ) ]	HMS99C58@TQFP44
[ ( SA245A ) ]	

## ICE

### E ( E ) PROM / FRAM / NVRAM

ICE25P05	ICE25P05@SOIC8
[ ( SA602A ) ]	
ICE27C010	ICE27C010@PLCC32
[ ( SA015A1T ) ]	
ICE27C010@TSOP32 [ ( SA410T ) ]	
ICE27C020	
ICE27C020@PLCC32 [ ( SA015A1T ) ]	ICE27C020@TSOP32
[ ( SA410T ) ]	
ICE27C512	ICE27C512@PLCC32
[ ( SA015A1T ) ]	
ICE27C512@TSOP28 [ ( SA430T ) ]	
ICE27LC010	
ICE27LC010@PLCC32 [ ( SA015A1T ) ]	ICE27LC010@TSOP32
[ ( SA410T ) ]	
ICE27LC020	ICE27LC020@PLCC32
[ ( SA015A1T ) ]	
ICE27LC020@TSOP32 [ ( SA410T ) ]	
ICE27LC512	
ICE27LC512@PLCC32 [ ( SA015A1T ) ]	ICE27LC512@TSOP28
[ ( SA430T ) ]	
ICE28LF010	ICE28LF010@PLCC32
[ ( SA015A1T ) ]	
ICE37C512	ICE37C512@PLCC32
[ ( SA015A1T ) ]	

ICE37C512@TSOP32 [ (SA410T) ]  
ICE37LC512  
ICE37LC512@PLCC32 [ (SA015A1T) ] ICE37LC512@TSOP32  
[ (SA410T) ]

## ICMIC

### E ( E ) PROM / FRAM / NVRAM

X76F101 X76F101@SOIC8  
[ (SA602A) ]  
X76F400@SOIC8 [ (SA602A) ] X76F400@TSSOP8  
[ (SA026) ]

## ICSI

### E ( E ) PROM / FRAM / NVRAM

IC71V08F32AS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32CS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32CS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32CS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32CS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32DS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32DS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32DS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32DS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32ES04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32ES04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32ES08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32ES08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32FS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32FS04@FBGA73 [ (SA642A-B032A-Y096F001) ]

IC71V08F32FS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V08F32FS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32AS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32AS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32AS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32AS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32BS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32BS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32BS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32BS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32CS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32CS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32CS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32CS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32DS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32DS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32DS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32DS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32ES04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32ES04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32ES08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32ES08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32FS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32FS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32FS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32FS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32GS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32GS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32HS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32HS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F64IP16@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F64IS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

**MICROCONTROLLER**

IC89LV51A IC89LV51A@PLCC44  
 [ ( SA244 ) ]  
 IC89LV51A@TQFP44 [ ( SA245A ) ]  
 IC89LV52A IC89LV52A@TQFP44  
 IC89LV52A@PLCC44 [ ( SA244 ) ]  
 [ ( SA245A ) ]  
 IS89C51A IS89C51A@PLCC44



[ ( SA244 ) ]	
IS89C51A@TQFP44 [ ( SA245A ) ]	
IS89C52A	
IS89C52A@PLCC44 [ ( SA244 ) ]	IS89C52A@TQFP44
[ ( SA245A ) ]	
IS89C54	IS89C54@PLCC44
[ ( SA244 ) ]	
IS89C54@TQFP44 [ ( SA245A ) ]	
IS89C58	
IS89C58@PLCC44 [ ( SA244 ) ]	IS89C58@TQFP44
[ ( SA245A ) ]	
IS89C64	IS89C64@PLCC44
[ ( SA244 ) ]	
IS89C64@TQFP44 [ ( SA245A ) ]	
IS89E54	
IS89E54@PLCC44 [ ( SA244 ) ]	IS89E54@TQFP44
[ ( SA245A ) ]	
IS89E58	IS89E58@PLCC44
[ ( SA244 ) ]	
IS89E58@TQFP44 [ ( SA245A ) ]	
IS89E64	
IS89E64@PLCC44 [ ( SA244 ) ]	IS89E64@TQFP44
[ ( SA245A ) ]	

## ICT

### E ( E ) PROM / FRAM / NVRAM

27CX010	27CX010@PLCC32
[ ( SA015A1T ) ]	
27CX010@TSOP32 [ ( SA410T ) ]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[ ( SA602A ) ]	
93C46A	93C46A@SOIC8
[ ( SA602A ) ]	

93C56A	93C56A@SOIC8
[ (SA602A) ]	
93C66A	93C66A@SOIC8
[ (SA602A) ]	
93CX46	93CX46@SOIC8
[ (SA602A) ]	
93CX56	93CX56@SOIC8
[ (SA602A) ]	
93CX66	93CX66@SOIC8
[ (SA602A) ]	

## PLD

PA7024	PA7024(J)@PLCC28
[ (SA008A) ]	
PA7024(JN)@PLCC28 [ (SA008A) ]	PA7024@SOIC24
[ (SA404) ]	
PA7128	PA7128@PLCC28
[ (SA008A) ]	
PA7128@SOIC28 [ (SA404) ]	
PA7140	
PA7140@PLCC44 [ (SA244) ]	PA7140@TQFP44
[ (SA245A) ]	
PA7536	PA7536@PLCC28
[ (SA008A) ]	
PA7536@SOIC28 [ (SA404) ]	
PA7540	
PA7540(J)@PLCC28 [ (SA008A) ]	PA7540(JN)@PLCC28
[ (SA008A) ]	
PA7572	PA7572@PLCC44
[ (SA244) ]	
PA7572@TQFP44 [ (SA245A) ]	
PEEL18CV8Z	
PEEL18CV8Z@PLCC20 [ (SA001A) ]	PEEL18CV8Z@SOIC20
[ (SA404) ]	
PEEL18CV8Z@TSOP20 [ (SA026) ]	
PEEL18LV8Z	
PEEL18LV8Z@PLCC20 [ (SA001A) ]	PEEL18LV8Z@SOIC20
[ (SA404) ]	
PEEL18LV8Z@TSOP20 [ (SA026) ]	
PEEL22CV10	
PEEL22CV10@PLCC28 [ (SA008A) ]	

PEEL22CV10A

PEEL22CV10A@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10A@TSOP24 [(SA026)]

+

PEEL22CV10A+@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10A+@TSOP24 [(SA026)]

+

PEEL22CV10A++@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10A++@TSOP24 [(SA026)]

PEEL22CV10AZ

PEEL22CV10AZ@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10AZ@TSOP24 [(SA026)]

+

PEEL22CV10AZ+@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10AZ+@TSOP24 [(SA026)]

+

PEEL22CV10AZ++@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10AZ++@TSOP24 [(SA026)]

PEEL22LV10AZ

PEEL22LV10AZ@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ@TSOP24 [(SA026)]

+

PEEL22LV10AZ+@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ+@TSOP24 [(SA026)]

+

PEEL22LV10AZ++@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ++@TSOP24 [(SA026)]

PEEL22CV10A@SOIC24

PEEL22CV10A

PEEL22CV10A+@SOIC24

PEEL22CV10A+

PEEL22CV10A++@SOIC24

PEEL22CV10AZ@SOIC24

PEEL22CV10AZ

PEEL22CV10AZ+@SOIC24

PEEL22CV10AZ+

PEEL22CV10AZ++@SOIC24

PEEL22LV10AZ@SOIC24

PEEL22LV10AZ

PEEL22LV10AZ+@SOIC24

PEEL22LV10AZ+

PEEL22LV10AZ++@SOIC24

## IDT

### E(E) PROM/FRAM/NVRAM

ICS280@TSSOP16 [(SA026)]

ICS281@TSSOP16

[ ( SA026 ) ]

**IMT****E ( E ) PROM / FRAM / NVRAM**

IM29F001B [ ( SA015A1T ) ]	IM29F001B@PLCC32
IM29F001B@TSOP32 [ ( SA410T ) ] [ ( SA620 ) ]	IM29F001B@VSOP32
IM29F001T [ ( SA015A1T ) ]	IM29F001T@PLCC32
IM29F001T@TSOP32 [ ( SA410T ) ] [ ( SA620 ) ]	IM29F001T@VSOP32
IM29F002B [ ( SA015A1T ) ]	IM29F002B@PLCC32
IM29F002B@TSOP32 [ ( SA410T ) ] [ ( SA620 ) ]	IM29F002B@VSOP32
IM29F002T [ ( SA015A1T ) ]	IM29F002T@PLCC32
IM29F002T@TSOP32 [ ( SA410T ) ] [ ( SA620 ) ]	IM29F002T@VSOP32
IM29F004B [ ( SA015A1T ) ]	IM29F004B@PLCC32
IM29F004B@TSOP32 [ ( SA410T ) ] [ ( SA620 ) ]	IM29F004B@VSOP32
IM29F004T [ ( SA015A1T ) ]	IM29F004T@PLCC32
IM29F004T@TSOP32 [ ( SA410T ) ] [ ( SA620 ) ]	IM29F004T@VSOP32
IM29LV004B [ ( SA015A1T ) ]	IM29LV004B@PLCC32
IM29LV004B@TSOP32 [ ( SA410T ) ] [ ( SA620 ) ]	IM29LV004B@VSOP32
IM29LV004T [ ( SA015A1T ) ]	IM29LV004T@PLCC32
IM29LV004T@TSOP32 [ ( SA410T ) ] [ ( SA620 ) ]	IM29LV004T@VSOP32
IM29LV400B@PSOP44 [ ( SA638 ) ] B005 ) ]	IM29LV400B@TSOP48 [ ( SA247-
IM29LV400T@PSOP44 [ ( SA638 ) ] B005 ) ]	IM29LV400T@TSOP48 [ ( SA247-

**INTEL****E (E) PROM/FRAM/NVRAM**

27010	27010@PLCC32
[ (SA015A1T) ]	
27010@TSOP32 [ (SA410T) ]	
27128	
27128A	
27128B	
2716	
27210	
27256	
2732	
2732A	
27512	
2764	
2764A	
27C010	27C010@PLCC32
[ (SA015A1T) ]	
27C010@TSOP32 [ (SA410T) ]	
27C010A	
27C010A@PLCC32 [ (SA015A1T) ]	27C010A@TSOP32
[ (SA410T) ]	
27C020	27C020@PLCC32
[ (SA015A1T) ]	
27C020@TSOP32 [ (SA410T) ]	
27C040	
27C040@PLCC32 [ (SA015A1T) ]	27C040@TSOP32
[ (SA410T) ]	
27C100	27C100@PLCC32
[ (SA015A1T) ]	
27C100@TSOP32 [ (SA410T) ]	
27C128	
27C128@PLCC32 [ (SA015A1T) ]	
27C210	
27C210@PLCC44 [ (SA244) ]	
27C220	
27C220@PLCC44 [ (SA244) ]	
27C240	
27C240@PLCC44 [ (SA244) ]	

27C256  
27C256@PLCC32 [ (SA015A1T) ]  
27C400  
27C400@PLCC44 [ (SA244) ]  
27C512  
27C512@PLCC32 [ (SA015A1T) ]  
27C64  
27C64@PLCC32 [ (SA015A1T) ]  
27C800  
27S512  
2816A  
2817A  
2864A  
68C257  
68C257@PLCC32  
[ (SA015A1T) ]  
87C256  
87C257  
87C257@PLCC32 [ (SA015A1T) ]  
87C64  
D27011  
D27513  
D27C011  
D27C513  
D28F256  
D28F256A  
D28F512  
DA28F016SA@SSOP56 [ (SA629A-B013) ]  
DA28F016SV@SSOP56 [ (SA629A-B013) ]  
DA28F320J5(low)@SSOP56 [ (SA629-B013) ]  
DA28F320J5@SSOP56 [ (SA629A-B013) ]  
DA28F320J5A(low)@SSOP56 [ (SA629-B013) ]  
DA28F320J5A@SSOP56 [ (SA629A-B013) ]  
DA28F640J5@SSOP56 [ (SA629A-B013) ]  
DA28F640J5A@SSOP56 [ (SA629A-B013) ]  
DD28F032SA@TSOP56 [ (SA628-B011) ]  
DT28F016SA@SSOP56 [ (SA629A-B013) ]  
DT28F016SA@TSOP56 [ (SA628-B011) ]  
DT28F016SV@SSOP56 [ (SA629A-B013) ]  
DT28F016SV@TSOP56 [ (SA628-B011) ]  
DT28F160F3B@SSOP56 [ (SA629A-B015) ]  
DT28F160F3T@SSOP56 [ (SA629A-B015) ]  
DT28F160S3@SSOP56 [ (SA629A-B013) ]  
DT28F160S5@SSOP56 [ (SA629A-B013) ]

DT28F320J5@SSOP56 [(SA629A-B013)]	
DT28F320J5A@SSOP56 [(SA629A-B013)]	
DT28F320S3@SSOP56 [(SA629A-B013)]	
DT28F320S5@SSOP56 [(SA629A-B013)]	
DT28F640J5@SSOP56 [(SA629A-B013)]	
DT28F640J5A@SSOP56 [(SA629A-B013)]	
DT28F800F3B@SSOP56 [(SA629A-B015)]	
DT28F800F3T@SSOP56 [(SA629A-B015)]	
E28F001BX-B@TSOP32 [(SA410T)]	E28F001BX-T@TSOP32
[(SA410T)]	
E28F002BCT@TSOP40 [(SA409T)]	E28F002BEB@TSOP40
[(SA409T)]	
E28F002BET@TSOP40 [(SA409T)]	E28F002BLB@TSOP40
[(SA409T)]	
E28F002BLT@TSOP40 [(SA409T)]	E28F002BVB@TSOP40
[(SA409T)]	
E28F002BVT@TSOP40 [(SA409T)]	E28F002BXB@TSOP40
[(SA409T)]	
E28F002BXT@TSOP40 [(SA409T)]	E28F004B5B@TSOP40
[(SA409T)]	
E28F004B5T@TSOP40 [(SA409T)]	E28F004BEB@TSOP40
[(SA409T)]	
E28F004BET@TSOP40 [(SA409T)]	E28F004BLB@TSOP40
[(SA409T)]	
E28F004BLT@TSOP40 [(SA409T)]	E28F004BVB@TSOP40
[(SA409T)]	
E28F004BVT@TSOP40 [(SA409T)]	E28F004BXB@TSOP40
[(SA409T)]	
E28F004BXT@TSOP40 [(SA409T)]	E28F004S3@TSOP40
[(SA409T)]	
E28F004S5@TSOP40 [(SA409T)]	E28F004SC@TSOP40
[(SA409T)]	
E28F008BEB@TSOP40 [(SA409T)]	E28F008BET@TSOP40
[(SA409T)]	
E28F008BLB@TSOP40 [(SA409T)]	E28F008BLT@TSOP40
[(SA409T)]	
E28F008BVB@TSOP40 [(SA409T)]	E28F008BVT@TSOP40
[(SA409T)]	
E28F008BXB@TSOP40 [(SA409T)]	E28F008BXT@TSOP40
[(SA409T)]	
E28F008S3@TSOP40 [(SA409T)]	E28F008S5@TSOP40
[(SA409T)]	
E28F008SA@TSOP40 [(SA409T)]	E28F008SA-L@TSOP40

[ (SA409T) ]	
E28F008SC@TSOP40 [ (SA409T) ]	E28F010@TSOP32
[ (SA410T) ]	
E28F016S3@TSOP40 [ (SA409T) ]	E28F016S5@TSOP40
[ (SA409T) ]	
E28F016SA@TSOP56 [ (SA628-B011) ]	E28F016SC@TSOP40
[ (SA409T) ]	
E28F016SV@TSOP56 [ (SA628-B011) ]	E28F020@TSOP32
[ (SA410T) ]	
E28F128J3A@TSOP56 [ (SA628-B018) ]	E28F200B5B@TSOP48 [ (SA247-
B005) ]	
E28F200B5T@TSOP48 [ (SA247-B005) ]	E28F200BVB@TSOP56 [ (SA628-
B012) ]	
E28F200BVT@TSOP56 [ (SA628-B012) ]	E28F200BXB@TSOP56 [ (SA628-
B012) ]	
E28F200BXT@TSOP56 [ (SA628-B012) ]	E28F200CVB@TSOP48 [ (SA247-
B005) ]	
E28F200CVT@TSOP48 [ (SA247-B005) ]	E28F256@TSOP32
[ (SA410T) ]	
E28F256A@TSOP32 [ (SA410T) ]	E28F320J3A@TSOP56 [ (SA628-
B018) ]	
E28F320J5(low)@TSOP56 [ (SA628-B011) ]	
E28F320J5@TSOP56 [ (SA628-B011) ]	
E28F320J5A(low)@TSOP56 [ (SA628-B011) ]	
E28F320J5A@TSOP56 [ (SA628-B011) ]	E28F400B5B@TSOP48 [ (SA247-
B005) ]	
E28F400B5T@TSOP48 [ (SA247-B005) ]	E28F400BVB@TSOP56 [ (SA628-
B012) ]	
E28F400BVT@TSOP56 [ (SA628-B012) ]	E28F400BXB@TSOP56 [ (SA628-
B012) ]	
E28F400BXT@TSOP56 [ (SA628-B012) ]	E28F400CVB@TSOP48 [ (SA247-
B005) ]	
E28F400CVT@TSOP48 [ (SA247-B005) ]	E28F512@TSOP32
[ (SA410T) ]	
E28F640J3A@TSOP56 [ (SA628-B018) ]	E28F800B5B@TSOP48 [ (SA247-
B005) ]	
E28F800B5T@TSOP48 [ (SA247-B005) ]	E28F800CEB@TSOP48 [ (SA247-
B005) ]	
E28F800CET@TSOP48 [ (SA247-B005) ]	E28F800CVB@TSOP48 [ (SA247-
B005) ]	
E28F800CVT@TSOP48 [ (SA247-B005) ]	E82802AA@TSOP40
[ (SA409T) ]	
E82802AB@TSOP40 [ (SA409T) ]	E82802AC@TSOP40



[ (SA409T) ]  
F28F010@TSOP32 [ (SA410T) ]  
F28F020(REVERSE)@TSOP32 [ (SA410T) ]  
F28F020@TSOP32 [ (SA410T) ] F28F256@TSOP32  
[ (SA410T) ]  
F28F256A@TSOP32 [ (SA410T) ] F28F512@TSOP32  
[ (SA410T) ]  
G28F640J5@uBGA56 [ (SA644A-B028A-Y072F001Y) ]  
G28F640J5A@uBGA56 [ (SA644A-B028A-Y072F001Y) ]  
GE28F008B3BA@uBGA48 [ (SA634) ] GE28F008B3TA@uBGA48  
[ (SA634) ]  
GE28F128K18C@FBGA56 [ (SA656D-B085A-T056F001Y) ]  
GE28F128K3C@FBGA56 [ (SA656D-B085A-T056F001Y) ]  
GE28F128L18B@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
GE28F128L18T@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
GE28F128L30B@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
GE28F128L30T@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
GE28F128W18BC(NO EFP)@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
GE28F128W18BC@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
GE28F128W18BD(NO EFP)@VFBGA56 [ (SA656E-B085A-W056F001) ]  
GE28F128W18BD@VFBGA56 [ (SA656E-B085A-W056F001) ]  
GE28F128W18TC(NO EFP)@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
GE28F128W18TC@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
GE28F128W18TD(NO EFP)@VFBGA56 [ (SA656E-B085A-W056F001) ]  
GE28F128W18TD@VFBGA56 [ (SA656E-B085A-W056F001) ]  
GE28F128W30BC(NO EFP)@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
GE28F128W30BC@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
GE28F128W30BD(NO EFP)@VFBGA56 [ (SA656E-B085A-W056F001) ]  
GE28F128W30BD@VFBGA56 [ (SA656E-B085A-W056F001) ]  
GE28F128W30TC(NO EFP)@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
GE28F128W30TC@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
GE28F128W30TD(NO EFP)@VFBGA56 [ (SA656E-B085A-W056F001) ]  
GE28F128W30TD@VFBGA56 [ (SA656E-B085A-W056F001) ]  
GE28F160B3B@uBGA48 [ (SA634A-B005A-Y048F001Y) ]  
GE28F160B3BC@uBGA48 [ (SA634A-B005A-Y048F001Y) ]  
GE28F160B3BD@uBGA48 [ (SA634A-B005A-Y048F001Y) ]  
GE28F160B3T@uBGA48 [ (SA634A-B005A-Y048F001Y) ]  
GE28F160B3TC@uBGA48 [ (SA634A-B005A-Y048F001Y) ]  
GE28F160B3TD@uBGA48 [ (SA634A-B005A-Y048F001Y) ]  
GE28F160C3BC(Moto)@VFBGA48 [ (SA714A-B026A-M046F001Y) ]  
GE28F160C3BC@VFBGA48 [ (SA634A-B005A-Y048F001) ]  
GE28F160C3BD(Moto)@VFBGA48 [ (SA714A-B026A-M046F001Y) ]  
GE28F160C3BD@VFBGA48 [ (SA634A-B005A-Y048F001) ]

GE28F160C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F256K18C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256K3C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256L18B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L18T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F320B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3TC@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3A@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320W18BC(NO EFP)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BE(SLOW)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W30BC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]

GE28F640J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640K18C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640K3C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640L18B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L18T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640W18BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W30BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F800B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3BA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F800C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3TA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GT28F016C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F016C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F128W30BC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30BD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3BA@uBGA48 [(SA634A-B005A-Y048F001)]

GT28F160C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F320B3T@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F800B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F800B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
JS28F128J3C@TSOP56 [(SA628-B018)]  
JS28F128J3D@TSOP56 [(SA628-B018)]  
JS28F128P30B@TSOP56 [(SA628-B131)]  
JS28F128P30T@TSOP56 [(SA628-B131)]  
JS28F128P33B@TSOP56 [(SA628-B131)]  
JS28F128P33T@TSOP56 [(SA628-B131)]  
JS28F160B3BD@TSOP48 [(SA247-B005)]  
JS28F160B3TD@TSOP48 [(SA247-B005)]  
JS28F160C3BD@TSOP48 [(SA247-B005)]  
JS28F160C3TD@TSOP48 [(SA247-B005)]  
JS28F256P30B@TSOP56 [(SA628-B131)]  
JS28F256P30T@TSOP56 [(SA628-B131)]  
JS28F256P33B@TSOP56 [(SA628-B131)]  
JS28F256P33T@TSOP56 [(SA628-B131)]  
JS28F320B3BD@TSOP48 [(SA247-B005)]  
JS28F320B3TD@TSOP48 [(SA247-B005)]  
JS28F320C3BD@TSOP48 [(SA247-B005)]  
JS28F320C3TD@TSOP48 [(SA247-B005)]  
JS28F320J3C@TSOP56 [(SA628-B018)]  
JS28F320J3D@TSOP56 [(SA628-B018)]  
JS28F640J3C@TSOP56 [(SA628-B018)]  
JS28F640J3D@TSOP56 [(SA628-B018)]  
JS28F640P30B(Low)@TSOP56 [(SA628-B131)]  
JS28F640P30B@TSOP56 [(SA628-B131)]  
JS28F640P30T@TSOP56 [(SA628-B131)]  
JS28F640P33B@TSOP56 [(SA628-B131)]  
JS28F640P33T@TSOP56 [(SA628-B131)]  
JS28F800C3BD@TSOP48 [(SA247-B005)]  
JS28F800C3TD@TSOP48 [(SA247-B005)]  
JZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]

LZ38F4060L0YBB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
LZ38F4060L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
M28F010 M28F010@PLCC32  
[(SA015A1T)]  
M28F010@TSOP32 [(SA410T)] N28F001BN-B@PLCC32  
[(SA015A1T)]  
N28F001BN-T@PLCC32 [(SA015A1T)] N28F001BX-B@PLCC32  
[(SA015A1T)]  
N28F001BX-T@PLCC32 [(SA015A1T)] N28F010@PLCC32  
[(SA015A1T)]  
N28F020@PLCC32 [(SA015A1T)] N28F256@PLCC32  
[(SA015A1T)]  
N28F256A@PLCC32 [(SA015A1T)] N28F512@PLCC32  
[(SA015A1T)]  
N82802AA@PLCC32 [(SA015A1T)] N82802AB@PLCC32  
[(SA015A1T)]  
N82802AC@PLCC32 [(SA015A1T)]  
NZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
NZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
NZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
NZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
P27011  
P27128A  
P27128A@PLCC32 [(SA015A1T)]  
P27128B  
P27128B@PLCC32 [(SA015A1T)]  
P27256  
P27256@PLCC32 [(SA015A1T)]  
P27512  
P27513  
P2764A  
P2764A@PLCC32 [(SA015A1T)]  
P27C011  
P27C128 P27C128@PLCC32  
[(SA015A1T)]  
P27C256 P27C256@PLCC32  
[(SA015A1T)]  
P27C513  
P27C64  
P27C64@PLCC32 [(SA015A1T)] P28F001BX-  
B  
P28F001BX-T P28F002BCT@TSOP40  
[(SA409T)]

P28F010  
P28F020  
P28F256  
P28F256A  
P28F512  
P87C64  
P87C64@PLCC32 [ (SA015A1T) ] PA28F004S3@PSOP44  
[ (SA638) ]  
PA28F004S5@PSOP44 [ (SA638) ] PA28F004SC@PSOP44  
[ (SA638) ]  
PA28F008S3@PSOP44 [ (SA638) ] PA28F008S5@PSOP44  
[ (SA638) ]  
PA28F008SA@PSOP44 [ (SA638) ] PA28F008SA-L@PSOP44  
[ (SA638) ]  
PA28F008SC@PSOP44 [ (SA638) ] PA28F016S3@PSOP44  
[ (SA638) ]  
PA28F016S5@PSOP44 [ (SA638) ] PA28F016SC@PSOP44  
[ (SA638) ]  
PA28F200B5B@PSOP44 [ (SA638) ] PA28F200B5T@PSOP44  
[ (SA638) ]  
PA28F200BVB@PSOP44 [ (SA638) ] PA28F200BVT@PSOP44  
[ (SA638) ]  
PA28F200BXB@PSOP44 [ (SA638) ] PA28F200BXT@PSOP44  
[ (SA638) ]  
PA28F400B5B@PSOP44 [ (SA638) ] PA28F400B5T@PSOP44  
[ (SA638) ]  
PA28F400BVB@PSOP44 [ (SA638) ] PA28F400BVT@PSOP44  
[ (SA638) ]  
PA28F400BXB@PSOP44 [ (SA638) ] PA28F400BXT@PSOP44  
[ (SA638) ]  
PA28F800B5B@PSOP44 [ (SA638) ] PA28F800B5T@PSOP44  
[ (SA638) ]  
PA28F800BVB@PSOP44 [ (SA638) ] PA28F800BVT@PSOP44  
[ (SA638) ]  
PC28F128J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F128J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F128P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F128P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F128P33B@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F128P33T@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F160C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F160C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F256P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]

PC28F256P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
PC28F256P33B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
PC28F256P33T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
PC28F320C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
PC28F320C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
PC28F320J3C@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
PC28F320J3D@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
PC28F640J3C@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
PC28F640J3D@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
PC28F640P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
PC28F640P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
PC28F640P33B@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
PC28F640P33T@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
PC28F800C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
PC28F800C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
PF38F1020W0YBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1020W0YTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030C0ZBL0@FBGA72 [ ( SA642R-B041A-T096F001Y ) ]  
PF38F1030C0ZTL0@FBGA72 [ ( SA642R-B041A-T096F001Y ) ]  
PF38F1030W0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0YBQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0YBQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F1030W0YCQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F1030W0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0YTQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0YTQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F1030W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F1030W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0ZTQ0 ( SLOW )@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2020W0ZBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2020W0ZTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YCQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YTQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]

PF38F2030W0YTQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0ZBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0ZTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YCQ1@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YCQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YUQ1@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F2040W0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040L0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040M0Y1QE@FBGA88 [ ( SA642R-B303A-T096F001Y ) ]  
PF38F3040M0Y3QE@FBGA88 [ ( SA642R-B303A-T096F001Y ) ]  
PF38F3050L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YBQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YTQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3050L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3350LLZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F3350W0ZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F3350WWZDQ1@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F4050L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]



PF38F4050L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4055L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4055L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4060L0YBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YBB1@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YTB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YTB1@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4450LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4466LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4466LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF48F2000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F2000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F2000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F2000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F3000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F3000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F3000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F3000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F3000W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF48F3000W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF48F3000W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF48F3000W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF48F3300W0YBQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF48F3300W0YDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF48F3300W0YTQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF48F4000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F4000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F4000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F4000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F4040LVYBQ0 ( BEEP ) @FBGA88 [ ( SA642A-B113A-Y096F001 ) ]

PF48F4040LVYBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F5000M0Y1B0@FBGA105 [(SA664F-B301A-W108F001N)]  
PH28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18BE(SLOW)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
QB25F016S33B60@SOIC8 [(SA605A)] QB25F016S33T60@SOIC8  
[(SA605A)]  
QB25F160S33B60@SOIC16 [(SA404)] QB25F160S33T60@SOIC16  
[(SA404)]  
QB25F320S33B60@SOIC16 [(SA404)] QB25F320S33T60@SOIC16  
[(SA404)]  
QB25F640S33B60@SOIC16 [(SA404)] QB25F640S33T60@SOIC16  
[(SA404)]  
QH25F016S33B60@SOIC8 [(SA605A)] QH25F016S33T60@SOIC8  
[(SA605A)]

QH25F160S33B60@SOIC16 [(SA404)] QH25F160S33T60@SOIC16  
[(SA404)]  
QH25F320S33B60@SOIC16 [(SA404)] QH25F320S33T60@SOIC16  
[(SA404)]  
QH25F640S33B60@SOIC16 [(SA404)] QH25F640S33T60@SOIC16  
[(SA404)]  
RC28F128J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F128J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F128K18C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128K3C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F160C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F256J3A@FBGA96 [(SA642A-B273-Y096N001N)]  
RC28F256J3C@FBGA64 [(SA655M-B054A-T064F001Y)]  
RC28F256K18C@FBGA64 [(SA655L-B286A-T064F001Y)]  
RC28F256K3C@FBGA64 [(SA655L-B286A-T064F001Y)]  
RC28F256P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P33B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P33T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F320C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F320J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F320J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F640C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F640C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F640J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F640J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F640J3D@FBGA64 [(SA655A-B054A-T064F001Y)]

RC28F640K18C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640K3C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P33B@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F640P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F800C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RD28F1602C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1602C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1604C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1604C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3208C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3208C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F6408W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD38F1010C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010W0YTL0@FBGA67 [(SA642E-B041A-T072F001N)]  
RD38F1020C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]

RD38F1030W0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F1030W0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F1030W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F1030W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2010W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2010W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2010W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2010W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2020W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0ZBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0ZTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0YBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YBQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YBQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0YTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YTQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YTQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0ZBQ0 (NO EFP)@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZBQ1 (NO EFP)@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0ZTQ0 (NO EFP)@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZTQ1 (NO EFP)@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2040W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2220W0YBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220W0YDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220W0YTYQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]

RD38F2220WWZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220WWZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220WWZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWYBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWYDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWYTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWYBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWYDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWYTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWZDQ1@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD38F2240WWZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F3040L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F3040L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F3040L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YBQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YTQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F3050L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F3340LLYDQ1@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
RD38F3350LLZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F3350W0ZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F3350WWZDQ1@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F4050L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]

RD38F4050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4450LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD48F2000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F2000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F2000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F2000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F2000W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2100W0YBQ0@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2100W0YDQE@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2100W0YTQ0@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2200W0YBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0YDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0YTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F3000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F3000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F3000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F3000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F3000W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]

RD48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F4040LVYBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
TB28F004S3@PSOP44 [(SA638)] TB28F004S5@PSOP44  
[(SA638)]  
TB28F004SC@PSOP44 [(SA638)] TB28F008S3@PSOP44  
[(SA638)]  
TB28F008S5@PSOP44 [(SA638)] TB28F008SA@PSOP44  
[(SA638)]  
TB28F008SA-L@PSOP44 [(SA638)] TB28F008SC@PSOP44  
[(SA638)]  
TB28F016S3@PSOP44 [(SA638)] TB28F016S5@PSOP44  
[(SA638)]  
TB28F016SC@PSOP44 [(SA638)] TB28F200B5B@PSOP44  
[(SA638)]  
TB28F200B5T@PSOP44 [(SA638)] TB28F200BVB@PSOP44  
[(SA638)]  
TB28F200BVT@PSOP44 [(SA638)] TB28F200BXB@PSOP44  
[(SA638)]  
TB28F200BXT@PSOP44 [(SA638)] TB28F400B5B@PSOP44  
[(SA638)]  
TB28F400B5T@PSOP44 [(SA638)] TB28F400BVB@PSOP44  
[(SA638)]  
TB28F400BVT@PSOP44 [(SA638)] TB28F400BXB@PSOP44  
[(SA638)]  
TB28F400BXT@PSOP44 [(SA638)] TB28F800B5B@PSOP44  
[(SA638)]  
TB28F800B5T@PSOP44 [(SA638)] TB28F800BVB@PSOP44  
[(SA638)]  
TB28F800BVT@PSOP44 [(SA638)] TE28F002BEB@TSOP40



[ (SA409T) ]  
TE28F002BET@TSOP40 [ (SA409T) ] TE28F002BVB@TSOP40  
[ (SA409T) ]  
TE28F002BVT@TSOP40 [ (SA409T) ] TE28F002BXB@TSOP40  
[ (SA409T) ]  
TE28F002BXT@TSOP40 [ (SA409T) ] TE28F004BEB@TSOP40  
[ (SA409T) ]  
TE28F004BET@TSOP40 [ (SA409T) ] TE28F004BVB@TSOP40  
[ (SA409T) ]  
TE28F004BVT@TSOP40 [ (SA409T) ] TE28F004BXB@TSOP40  
[ (SA409T) ]  
TE28F004BXT@TSOP40 [ (SA409T) ] TE28F004S3@TSOP40  
[ (SA409T) ]  
TE28F004S5@TSOP40 [ (SA409T) ] TE28F004SC@TSOP40  
[ (SA409T) ]  
TE28F008B3B@TSOP40 [ (SA409T) ] TE28F008B3BA@TSOP40  
[ (SA409T) ]  
TE28F008B3T@TSOP40 [ (SA409T) ] TE28F008B3TA@TSOP40  
[ (SA409T) ]  
TE28F008BEB@TSOP40 [ (SA409T) ] TE28F008BET@TSOP40  
[ (SA409T) ]  
TE28F008BVB@TSOP40 [ (SA409T) ] TE28F008BVT@TSOP40  
[ (SA409T) ]  
TE28F008C3BA@TSOP40 [ (SA409T) ] TE28F008C3TA@TSOP40  
[ (SA409T) ]  
TE28F008S3@TSOP40 [ (SA409T) ] TE28F008S5@TSOP40  
[ (SA409T) ]  
TE28F008SA@TSOP40 [ (SA409T) ] TE28F008SA-L@TSOP40  
[ (SA409T) ]  
TE28F008SC@TSOP40 [ (SA409T) ] TE28F016B3B@TSOP40  
[ (SA409T) ]  
TE28F016B3T@TSOP40 [ (SA409T) ] TE28F016C3BA@TSOP40  
[ (SA409T) ]  
TE28F016C3TA@TSOP40 [ (SA409T) ] TE28F016S3@TSOP40  
[ (SA409T) ]  
TE28F016S5@TSOP40 [ (SA409T) ] TE28F016SC@TSOP40  
[ (SA409T) ]  
TE28F128J3C@TSOP56 [ (SA628-B018) ]  
TE28F128J3D@TSOP56 [ (SA628-B018) ]  
TE28F128P30B@TSOP56 [ (SA628-B131) ]  
TE28F128P30T@TSOP56 [ (SA628-B131) ]  
TE28F128P33B@TSOP56 [ (SA628-B131) ]  
TE28F128P33T@TSOP56 [ (SA628-B131) ]

TE28F160B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F160B3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F160B3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F160B3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F160B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F160B3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F160B3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F160B3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F160C3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F160C3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F160C3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F160C3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F160C3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F160C3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F160F3B@TSOP56 [ ( SA628-B014 ) ]  
TE28F160F3T@TSOP56 [ ( SA628-B014 ) ]  
TE28F160S3@TSOP56 [ ( SA628-B011 ) ]      TE28F160S5@TSOP56 [ ( SA628-B011 ) ]  
TE28F200B5B@TSOP48 [ ( SA247-B005 ) ]  
TE28F200B5T@TSOP48 [ ( SA247-B005 ) ]  
TE28F200BVB@TSOP56 [ ( SA628-B012 ) ]  
TE28F200BVT@TSOP56 [ ( SA628-B012 ) ]  
TE28F200BXB@TSOP56 [ ( SA628-B012 ) ]  
TE28F200BXT@TSOP56 [ ( SA628-B012 ) ]  
TE28F200CEB@TSOP56 [ ( SA628-B012 ) ]  
TE28F200CET@TSOP56 [ ( SA628-B012 ) ]  
TE28F200CVB@TSOP48 [ ( SA247-B005 ) ]  
TE28F200CVT@TSOP48 [ ( SA247-B005 ) ]  
TE28F256J3C@TSOP56 [ ( SA628-B018 ) ]  
TE28F256P30B@TSOP56 [ ( SA628-B131 ) ]  
TE28F256P30T@TSOP56 [ ( SA628-B131 ) ]  
TE28F256P33B@TSOP56 [ ( SA628-B131 ) ]  
TE28F256P33T@TSOP56 [ ( SA628-B131 ) ]  
TE28F320B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3BC@TSOP48 [ ( SA247-B005 ) ]

TE28F320C3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320J3C@TSOP56 [ ( SA628-B018 ) ]  
TE28F320J3D@TSOP56 [ ( SA628-B018 ) ]  
TE28F400B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B5B@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B5T@TSOP48 [ ( SA247-B005 ) ]  
TE28F400BVB@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BVT@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BXB@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BXT@TSOP56 [ ( SA628-B012 ) ]  
TE28F400CEB@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CET@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CVB@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CVT@TSOP48 [ ( SA247-B005 ) ]  
TE28F640B3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640B3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640C3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640C3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640J3C@TSOP56 [ ( SA628-B018 ) ]  
TE28F640J3D@TSOP56 [ ( SA628-B018 ) ]  
TE28F640P30B@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P30T@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P33B@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P33T@TSOP56 [ ( SA628-B131 ) ]  
TE28F800B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B5B@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B5T@TSOP48 [ ( SA247-B005 ) ]  
TE28F800C3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F800C3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F800C3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F800C3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F800CEB@TSOP48 [ ( SA247-B005 ) ]  
TE28F800CET@TSOP48 [ ( SA247-B005 ) ]  
TE28F800CVB@TSOP48 [ ( SA247-B005 ) ]  
TE28F800CVT@TSOP48 [ ( SA247-B005 ) ]  
TE28F800F3B@TSOP56 [ ( SA628-B014 ) ]

TE28F800F3T@TSOP56 [ ( SA628-B014 ) ]

**PLD**

5C031 [ ( SA001A ) ]	5C031@PLCC20
5C032 [ ( SA001A ) ]	5C032@PLCC20
5C090 [ ( SA244 ) ]	5C090@PLCC44
85C090 [ ( SA244 ) ]	85C090-P44
85C220 [ ( SA001A ) ]	85C220@PLCC20
IPLD910 [ ( SA244 ) ]	IPLD910-P44

**MICROCONTROLLER**

8751BH [ ( SA244 ) ]	8751BH@PLCC44
8752BH [ ( SA244 ) ]	8752BH@PLCC44
8796BH@PLCC68 ( * ) [ ( SA648-B6803 ) ]	8796JF@PLCC68 ( * ) [ ( SA648-B6803 ) ]
8797BH@PGA68 ( * ) [ ( SA650-B6804 ) ]	8797BH@PLCC68 ( * ) [ ( SA648-B6803 ) ]
8797JF@PGA68 ( * ) [ ( SA650-B6804 ) ]	8797JF@PLCC68 ( * ) [ ( SA648-B6803 ) ]
87C151SA [ ( SA244 ) ]	87C151SA@PLCC44
87C151SB [ ( SA244 ) ]	87C151SB@PLCC44
87C196CA@PLCC68 ( * ) [ ( SA648-B6805 ) ]	
87C196JQ@PLCC52 ( * ) [ ( SA647-B5201 ) ]	
87C196JR@PLCC52 ( * ) [ ( SA647-B5201 ) ]	
87C196JT@PLCC52 ( * ) [ ( SA647-B5201 ) ]	
87C196JV@PLCC52 ( * ) [ ( SA647-B5201 ) ]	
87C196KB@PLCC68 ( * ) [ ( SA648-B6801 ) ]	
87C196KC@PLCC68 ( * ) [ ( SA648-B6801 ) ]	
87C196KD@PLCC68 ( * ) [ ( SA648-B6801 ) ]	

87C196KQ@PLCC68(\*) [(SA648-B6802)]  
87C196KR@PLCC68(\*) [(SA648-B6802)]  
87C196KS@PLCC68(\*) [(SA648-B6802)]  
87C196KT@PLCC68(\*) [(SA648-B6802)]  
87C196LA@PLCC52(\*) [(SA647-B5201)]  
87C196MC@PLCC84(\*) [(SA649-B8401)]  
87C196MC@PQFP80(\*) [(TA026-B006)]  
87C196MC@SDIP64(\*) [(SA651)]  
87C196MH@PLCC84(\*) [(SA649-B8401)]  
87C196MH@PQFP80(\*) [(TA026-B006)]  
87C196MH@SDIP64(\*) [(SA651)]  
87C251SA  
87C251SA@PLCC44 [(SA244)]  
87C251SB  
87C251SB@PLCC44 [(SA244)]  
87C251SP  
87C251SP@PLCC44 [(SA244)]  
87C251SQ  
87C251SQ@PLCC44 [(SA244)]  
87C51  
87C51@PLCC44 [(SA244)] 87C51@TQFP44  
[(SA245A)]  
87C51FA 87C51FA@PLCC44  
[(SA244)]  
87C51FA@TQFP44 [(SA245A)]  
87C51FB 87C51FB@TQFP44  
87C51FB@PLCC44 [(SA244)]  
[(SA245A)]  
87C51FC 87C51FC@PLCC44  
[(SA244)]  
87C51FC@TQFP44 [(SA245A)]  
87C51RA 87C51RA@TQFP44  
87C51RA@PLCC44 [(SA244)]  
[(SA245A)]  
87C51RB 87C51RB@PLCC44  
[(SA244)]  
87C51RB@TQFP44 [(SA245A)]  
87C51RC 87C51RC@TQFP44  
87C51RC@PLCC44 [(SA244)]  
[(SA245A)]  
87C52 87C52@PLCC44  
[(SA244)]  
87C52@TQFP44 [(SA245A)]

87C54	
87C54@PLCC44 [ ( SA244 ) ]	87C54@TQFP44
[ ( SA245A ) ]	
87C58	87C58@PLCC44
[ ( SA244 ) ]	
87C58@TQFP44 [ ( SA245A ) ]	87L51FA@PLCC44
[ ( SA244 ) ]	
87L51FA@TQFP44 [ ( SA245A ) ]	87L51FB@PLCC44
[ ( SA244 ) ]	
87L51FB@TQFP44 [ ( SA245A ) ]	87L51FC@PLCC44
[ ( SA244 ) ]	
87L51FC@TQFP44 [ ( SA245A ) ]	87L52@PLCC44
[ ( SA244 ) ]	
87L52@TQFP44 [ ( SA245A ) ]	87L54@PLCC44
[ ( SA244 ) ]	
87L54@TQFP44 [ ( SA245A ) ]	87L58@PLCC44
[ ( SA244 ) ]	
87L58@TQFP44 [ ( SA245A ) ]	

## INTEL-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

TE28F800C3TD@TSOP48 [ ( SA247-B005 ) ]

## INTELSIL

### E ( E ) PROM / FRAM / NVRAM

HS-6617RH	HS-6617RH@SOIC24
[ ( SA404 ) ]	
HS-6617RH-T	HS-6617RH-T@SOIC24
[ ( SA404 ) ]	
HS-6883RH	HS-6883RH@SOIC24
[ ( SA404 ) ]	
HS-6883RH-T	HS-6883RH-T@SOIC24
[ ( SA404 ) ]	

## ISSI

**E ( E ) PROM / FRAM / NVRAM**

IS24C01	IS24C01@MSOP8
[ ( SA666 ) ]	
IS24C01@SOIC8 [ ( SA602A ) ]	IS24C01@TSSOP8
[ ( SA026 ) ]	
IS24C01B	IS24C01B@MSOP8
[ ( SA666 ) ]	
IS24C01B@SOIC8 [ ( SA602A ) ]	IS24C01B@TSSOP8
[ ( SA026 ) ]	
IS24C02	IS24C02@MSOP8
[ ( SA666 ) ]	
IS24C02@SOIC8 [ ( SA602A ) ]	IS24C02@TSSOP8
[ ( SA026 ) ]	
IS24C02A	
IS24C02A@DFN8	
IS24C02A@MSOP8 [ ( SA666 ) ]	IS24C02A@SOIC8
[ ( SA602A ) ]	
IS24C02A@TSSOP8 [ ( SA026 ) ]	
IS24C02B	
IS24C02B@DFN8	IS24C02B@MSOP8
[ ( SA666 ) ]	
IS24C02B@SOIC8 [ ( SA602A ) ]	IS24C02B@TSSOP8
[ ( SA026 ) ]	
IS24C02C	
IS24C02C@DFN8	
IS24C02C@MSOP8 [ ( SA666 ) ]	IS24C02C@SOIC8
[ ( SA602A ) ]	
IS24C02C@TSSOP8 [ ( SA026 ) ]	
IS24C04	
IS24C04@MSOP8 [ ( SA666 ) ]	IS24C04@SOIC8
[ ( SA602A ) ]	
IS24C04@TSSOP8 [ ( SA026 ) ]	
IS24C04A	
IS24C04A@DFN8	IS24C04A@MSOP8
[ ( SA666 ) ]	
IS24C04A@SOIC8 [ ( SA602A ) ]	IS24C04A@TSSOP8
[ ( SA026 ) ]	
IS24C08	IS24C08@MSOP8
[ ( SA666 ) ]	
IS24C08@SOIC8 [ ( SA602A ) ]	IS24C08@TSSOP8
[ ( SA026 ) ]	

IS24C08A	
IS24C08A@DFN8	
IS24C08A@MSOP8 [(SA666)]	IS24C08A@SOIC8
[(SA602A)]	
IS24C08A@TSSOP8 [(SA026)]	
IS24C128	
IS24C128@SOIC8 [(SA602A)]	IS24C128@TSSOP14
[(SA026)]	
IS24C16	IS24C16@MSOP8
[(SA666)]	
IS24C16@SOIC8 [(SA602A)]	IS24C16@TSSOP8
[(SA026)]	
IS24C16A	IS24C16A@MSOP8
[(SA666)]	
IS24C16A@SOIC8 [(SA602A)]	IS24C16A@TSSOP8
[(SA026)]	
IS24C256	IS24C256@SOIC8
[(SA602A)]	
IS24C256@TSSOP14 [(SA026)]	
IS24C256A	
IS24C256A@SOIC8 [(SA602A)]	IS24C256A@TSSOP14
[(SA026)]	
IS24C32	IS24C32@SOIC8
[(SA602A)]	
IS24C32@TSSOP8 [(SA026)]	
IS24C32A	
IS24C32A@MSOP8 [(SA666)]	IS24C32A@SOIC8
[(SA602A)]	
IS24C32A@TSSOP8 [(SA026)]	
IS24C32B	
IS24C32B@SOIC8 [(SA602A)]	IS24C32B@TSSOP8
[(SA026)]	
IS24C64	IS24C64@SOIC8
[(SA602A)]	
IS24C64@TSSOP8 [(SA026)]	
IS24C64A	
IS24C64A@MSOP8 [(SA666)]	IS24C64A@SOIC8
[(SA602A)]	
IS24C64A@TSSOP8 [(SA026)]	
IS24C64B	
IS24C64B@SOIC8 [(SA602A)]	IS24C64B@TSSOP8
[(SA026)]	
IS24L128	



IS24L128@SOIC8 (150mil) [(SA602A)]	
IS24L128@SOIC8 (200mil) [(SA605A)]	
IS24L256	
IS24L256@SOIC8 (150mil) [(SA602A)]	
IS24L256@SOIC8 (200mil) [(SA605A)]	
IS25C01	IS25C01@SOIC8
[(SA602A)]	
IS25C01@TSSOP8 [(SA026)]	
IS25C02	
IS25C02@SOIC8 [(SA602A)]	IS25C02@TSSOP8
[(SA026)]	
IS25C04	IS25C04@SOIC8
[(SA602A)]	
IS25C04@TSSOP8 [(SA026)]	
IS25C08	
IS25C08@SOIC8 [(SA602A)]	IS25C08@TSSOP8
[(SA026)]	
IS25C128@SOIC8 [(SA602A)]	IS25C128@TSSOP8
[(SA026)]	
IS25C16	IS25C16@SOIC8
[(SA602A)]	
IS25C16@TSSOP8 [(SA026)]	IS25C256@SOIC8
[(SA602A)]	
IS25C256@TSSOP8 [(SA026)]	
IS25C32A	
IS25C32A@SOIC8 [(SA602A)]	IS25C32A@TSSOP8
[(SA026)]	
IS25C64A	IS25C64A@SOIC8
[(SA602A)]	
IS25C64A@TSSOP8 [(SA026)]	
IS27C010	
IS27C010@PLCC32 [(SA015A1T)]	IS27C010@TSOP32
[(SA410T)]	
IS27C020	IS27C020@PLCC32
[(SA015A1T)]	
IS27C020@TSOP32 [(SA410T)]	
IS27C256	
IS27C256@PLCC32 [(SA015A1T)]	
IS27C512	
IS27C512@PLCC32 [(SA015A1T)]	IS27C512@TSOP28
[(SA430T)]	
IS27HC010	IS27HC010@PLCC32
[(SA015A1T)]	

IS27HC010@TSOP32 [(SA410T)]  
IS27HC020  
IS27HC020@PLCC32 [(SA015A1T)] IS27HC020@TSOP32  
[(SA410T)]  
IS27HC256 IS27HC256@PLCC32  
[(SA015A1T)]  
IS27HC512 IS27HC512@PLCC32  
[(SA015A1T)]  
IS27HC512@TSOP28 [(SA430T)]  
IS27LV010  
IS27LV010@PLCC32 [(SA015A1T)] IS27LV010@TSOP32  
[(SA410T)]  
IS27LV512 IS27LV512@PLCC32  
[(SA015A1T)]  
IS27LV512@TSOP28 [(SA430T)]  
IS28F010  
IS28F010@PLCC32 [(SA015A1T)] IS28F010@TSOP32  
[(SA410T)]  
IS28F010A IS28F010A@PLCC32  
[(SA015A1T)]  
IS28F010A@TSOP32 [(SA410T)]  
IS28F020  
IS28F020@PLCC32 [(SA015A1T)] IS28F020@TSOP32  
[(SA410T)]  
IS29F010 IS29F010@PLCC32  
[(SA015A1T)]  
IS29F010@TSOP32 [(SA410T)]  
IS34C02  
IS34C02@MSOP8 [(SA666)] IS34C02@SOIC8  
[(SA602A)]  
IS34C02@TSSOP8 [(SA026)]  
IS34C02B@DFN8  
IS34C02B@TSSOP8 [(SA026)]  
IS71V08F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]

IS71V08F64GS08@FBGA101 [ (SA642C-B032A-Y056F001) ]  
 IS71V08F64GS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32AS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32B04@FBGA56 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32B04@FBGA59 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32BS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32CS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32DS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32ES08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32ESB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32EST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32FS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32GSB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32GST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32T04@FBGA56 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F32T04@FBGA59 [ (SA642A-B032A-Y096F001) ]  
 IS71V16F64GS08@FBGA101 [ (SA642C-B032A-Y056F001) ]  
 IS71V16F64GS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71VPCF32AS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71VPCF32BS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71VPCF32CS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71VPCF32DS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71VPCF32ES04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71VPCF32FS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IS71VPCF64GS08@FBGA73 [ (SA642C-B032A-Y056F001) ]  
 IS75V16F64GS16@FBGA65 [ (SA642C-B032A-Y056F001) ]  
 IS75V16F64GS32@FBGA65 [ (SA642C-B032A-Y056F001) ]  
 IS93C46 IS93C46@SOIC8  
 [ (SA602A) ]  
 IS93C46A(08bit) IS93C46A(08bit)@SOIC8  
 [ (SA602A) ]  
 IS93C46A(08bit)@TSSOP8 [ (SA026) ] IS93C46A  
 (16bit)  
 IS93C46A(16bit)@SOIC8 [ (SA602A) ] IS93C46A(16bit)@TSSOP8  
 [ (SA026) ]  
 IS93C46B IS93C46B@SOIC8  
 [ (SA602A) ]  
 IS93C46B@TSSOP8 [ (SA026) ] IS93C46D  
 (08bit)  
 IS93C46D(08bit)@SOIC8 [ (SA602A) ] IS93C46D(08bit)@TSSOP8  
 [ (SA026) ]  
 IS93C46D(16bit) IS93C46D(16bit)@SOIC8  
 [ (SA602A) ]

IS93C46D(16bit)@TSSOP8 [(SA026)]	
IS93C56	
IS93C56@SOIC8 [(SA602A)]	IS93C56A
(08bit)	
IS93C56A(08bit)@SOIC8 [(SA602A)]	IS93C56A(08bit)@TSSOP8
[(SA026)]	
IS93C56A(16bit)	IS93C56A(16bit)@SOIC8
[(SA602A)]	
IS93C56A(16bit)@TSSOP8 [(SA026)]	
IS93C66	
IS93C66@SOIC8 [(SA602A)]	IS93C66A
(08bit)	
IS93C66A(08bit)@SOIC8 [(SA602A)]	IS93C66A(08bit)@TSSOP8
[(SA026)]	
IS93C66A(16bit)	IS93C66A(16bit)@SOIC8
[(SA602A)]	
IS93C66A(16bit)@TSSOP8 [(SA026)]	IS93C76A
(08bit)	
IS93C76A(08bit)@SOIC8 [(SA602A)]	IS93C76A(08bit)@TSSOP8
[(SA026)]	
IS93C76A(16bit)	IS93C76A(16bit)@SOIC8
[(SA602A)]	
IS93C76A(16bit)@TSSOP8 [(SA026)]	IS93C86A
(08bit)	
IS93C86A(08bit)@SOIC8 [(SA602A)]	IS93C86A(08bit)@TSSOP8
[(SA026)]	
IS93C86A(16bit)	IS93C86A(16bit)@SOIC8
[(SA602A)]	
IS93C86A(16bit)@TSSOP8 [(SA026)]	

## DRAM & SRAM

IS61C1024	IS61C1024(300m)@SOJ32
[(SA646)]	
IS61C1024(400m)@SOJ32 [(SA661)]	IS61C1024@TSOP32
[(SA410T)]	
IS61C1024L	IS61C1024L(300m)@SOJ32
[(SA646)]	
IS61C1024L(400m)@SOJ32 [(SA661)]	IS61C1024L@TSOP32
[(SA410T)]	
IS61C256AH	IS61C256AH@SOJ28
[(SA646)]	

IS61C256AH@TSOP28 [(SA430T)]	
IS61C512	
IS61C512(300m)@SOJ32 [(SA646)]	IS61C512(400m)@SOJ32
[(SA661)]	
IS61C512@TSOP32 [(SA410T)]	
IS61C64AH	
IS61C64AH@SOJ28 [(SA646)]	IS61C64AH@TSOP28
[(SA430T)]	
IS61LV256	IS61LV256@SOJ28
[(SA646)]	
IS61LV256@TSOP28 [(SA430T)]	
IS61M256	
IS61M256@SOJ28 [(SA646)]	IS61M256@TSOP28
[(SA430T)]	
IS62C1024	IS62C1024(300m)@SOJ32
[(SA646)]	
IS62C1024(400m)@SOJ32 [(SA661)]	IS62C1024@TSOP32
[(SA410T)]	
IS62C256	IS62C256@SOJ28
[(SA646)]	
IS62C256@TSOP28 [(SA430T)]	
IS62C512	
IS62C512(300m)@SOJ32 [(SA646)]	IS62C512(400m)@SOJ32
[(SA661)]	
IS62C512@TSOP32 [(SA410T)]	
IS62C64	
IS62C64@SOJ28 [(SA646)]	IS62C64@TSOP28
[(SA430T)]	
IS62LV256	IS62LV256@SOJ28
[(SA646)]	
IS62LV256@TSOP28 [(SA430T)]	

## MICROCONTROLLER

IS89C51A	IS89C51A@PLCC44
[(SA244)]	
IS89C51A@TQFP44 [(SA245A)]	
IS89C52A	
IS89C52A@PLCC44 [(SA244)]	IS89C52A@TQFP44
[(SA245A)]	

# ITHINKO

## MICROCONTROLLER

AX5012 [ (SA404) ]	AX5012 (5.0V)@SOP24
AX5012 (5.5V)@SOP24 [ (SA404) ] [ (SA404) ]	AX5012 (6.0V)@SOP24
AX5012@SOP24 [ (SA404) ]	
AX5012@SOP32	

# LATTICE

## PLD

GAL16LV8 [ (SA001A) ]	GAL16LV8@PLCC20
GAL16LV8C [ (SA001A) ]	GAL16LV8C@PLCC20
GAL16LV8D [ (SA001A) ]	GAL16LV8D@PLCC20
GAL16LV8Z [ (SA001A) ]	GAL16LV8Z@PLCC20
GAL16LV8ZD [ (SA001A) ]	GAL16LV8ZD@PLCC20
GAL16V8 [ (SA001A) ]	GAL16V8@PLCC20
GAL16V8@SOIC20 [ (SA404) ]	
GAL16V8A GAL16V8A@PLCC20 [ (SA001A) ] [ (SA404) ]	GAL16V8A@SOIC20
GAL16V8B [ (SA001A) ]	GAL16V8B@PLCC20
GAL16V8B@SOIC20 [ (SA404) ]	
GAL16V8C GAL16V8C@PLCC20 [ (SA001A) ] [ (SA404) ]	GAL16V8C@SOIC20
GAL16V8D [ (SA001A) ]	GAL16V8D@PLCC20
GAL16V8D@SOIC20 [ (SA404) ]	
GAL16V8Z	

GAL16V8Z@PLCC20 [(SA001A)]	GAL16V8Z@SOIC20
[(SA404)]	
GAL18V10	GAL18V10@PLCC20
[(SA001A)]	
GAL18V10B	GAL18V10B@PLCC20
[(SA001A)]	
GAL20LV8	GAL20LV8@PLCC28
[(SA008A)]	
GAL20LV8Z	GAL20LV8Z@PLCC28
[(SA008A)]	
GAL20LV8ZD	GAL20LV8ZD@PLCC28
[(SA008A)]	
GAL20RA10	GAL20RA10@PLCC28
[(SA008A)]	
GAL20RA10B	GAL20RA10B@PLCC28
[(SA008A)]	
GAL20V8	GAL20V8@PLCC28
[(SA008A)]	
GAL20V8A	GAL20V8A@PLCC28
[(SA008A)]	
GAL20V8B	GAL20V8B@PLCC28
[(SA008A)]	
GAL20V8C	GAL20V8C@PLCC28
[(SA008A)]	
GAL20V8Z	GAL20V8Z@PLCC28
[(SA008A)]	
GAL20XV10	GAL20XV10@PLCC28
[(SA008A)]	
GAL20XV10B	GAL20XV10B@PLCC28
[(SA008A)]	
GAL22LV10C	GAL22LV10C@PLCC28
[(SA008A)]	
GAL22LV10C@SOIC24 [(SA404)]	GAL22LV10C@TSOP24
[(SA643)]	
GAL22LV10D	GAL22LV10D@PLCC28
[(SA008A)]	
GAL22LV10D@SOIC24 [(SA404)]	GAL22LV10D@TSOP24
[(SA643)]	
GAL22LV10Z	GAL22LV10Z@PLCC28
[(SA008A)]	
GAL22LV10Z@SOIC24 [(SA404)]	GAL22LV10Z@TSOP24
[(SA643)]	
GAL22LV10ZD	GAL22LV10ZD@PLCC28

[ (SA008A) ]	
GAL22LV10ZD@SOIC24 [ (SA404) ]	GAL22LV10ZD@TSOP24
[ (SA643) ]	
GAL22V10	GAL22V10@PLCC28
[ (SA008A) ]	
GAL22V10@SOIC24 [ (SA404) ]	
GAL22V10A	
GAL22V10A@PLCC28 [ (SA008A) ]	GAL22V10A@SOIC24
[ (SA404) ]	
GAL22V10B	GAL22V10B@PLCC28
[ (SA008A) ]	
GAL22V10B@SOIC24 [ (SA404) ]	
GAL22V10BQ	
GAL22V10BQ@PLCC28 [ (SA008A) ]	GAL22V10BQ@SOIC24
[ (SA404) ]	
GAL22V10C	GAL22V10C@PLCC28
[ (SA008A) ]	
GAL22V10C@SOIC24 [ (SA404) ]	
GAL22V10D	
GAL22V10D@PLCC28 [ (SA008A) ]	GAL22V10D@SOIC24
[ (SA404) ]	
GAL26CLV12	GAL26CLV12@PLCC28
[ (SA008A) ]	
GAL26CLV12@SOIC28 [ (SA404) ]	GAL26CLV12@TSOP28
[ (SA643) ]	
GAL26CLV12B	GAL26CLV12B@PLCC28
[ (SA008A) ]	
GAL26CLV12B@SOIC28 [ (SA404) ]	GAL26CLV12B@TSOP28
[ (SA643) ]	
GAL26CLV12C	GAL26CLV12C@PLCC28
[ (SA008A) ]	
GAL26CLV12C@SOIC28 [ (SA404) ]	GAL26CLV12C@TSOP28
[ (SA643) ]	
GAL26CLV12D	GAL26CLV12D@PLCC28
[ (SA008A) ]	
GAL26CLV12D@SOIC28 [ (SA404) ]	GAL26CLV12D@TSOP28
[ (SA643) ]	
GAL26CLV12Z	GAL26CLV12Z@PLCC28
[ (SA008A) ]	
GAL26CLV12Z@SOIC28 [ (SA404) ]	GAL26CLV12Z@TSOP28
[ (SA643) ]	
GAL26CLV12ZD	GAL26CLV12ZD@PLCC28
[ (SA008A) ]	



GAL26CLV12ZD@SOIC28 [(SA404)]                    GAL26CLV12ZD@TSOP28  
[(SA643)]  
GAL26CV12    GAL26CV12@PLCC28  
[(SA008A)]  
GAL26CV12B                                         GAL26CV12B@PLCC28  
[(SA008A)]  
GAL26CV12C                                         GAL26CV12C@PLCC28  
[(SA008A)]  
GAL26V12C                                         GAL26V12C@PLCC28  
[(SA008A)]  
ispGAL22LV10                                      ispGAL22LV10(ISP) [ISP-  
HEADER01]  
ispGAL22LV10@PLCC28 [(SA008A)]  
ispGAL22LV10@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10@SSOP28 [(SA626A)]  
ispGAL22LV10@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10A  
ispGAL22LV10A(ISP) [ISP-HEADER01]  
ispGAL22LV10A@PLCC28 [(SA008A)]  
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10A@SSOP28 [(SA626A)]  
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10B  
ispGAL22LV10B(ISP) [ISP-HEADER01]  
ispGAL22LV10B@PLCC28 [(SA008A)]  
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10B@SSOP28 [(SA626A)]  
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10C  
ispGAL22LV10C(ISP) [ISP-HEADER01]  
ispGAL22LV10C@PLCC28 [(SA008A)]  
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10C@SSOP28 [(SA626A)]  
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10D  
ispGAL22LV10D(ISP) [ISP-HEADER01]  
ispGAL22LV10D@PLCC28 [(SA008A)]  
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10D@SSOP28 [(SA626A)]  
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22V10AB@PLCC28 [(SA008A)]                ispGAL22V10AB@QFN32  
[(SA686)]  
ispGAL22V10AC@PLCC28 [(SA008A)]                ispGAL22V10AC@QFN32

[(SA686)]  
 ispGAL22V10AV@PLCC28 [(SA008A)]      ispGAL22V10AV@QFN32  
 [(SA686)]  
 ispGAL22V10C(UES)@PLCC28 [(SA008A)]  
 ispGAL22V10C@PLCC28 [(SA008A)]      ispLSI1016@PLCC44  
 [(SA244)]  
 ispLSI1016@TQFP44 [(SA245A)]      ispLSI1016E@PLCC44  
 [(SA244)]  
 ispLSI1016E@TQFP44 [(SA245A)]      ispLSI1016EA@PLCC44  
 [(SA244)]  
 ispLSI1016EA@TQFP44 [(SA245A)]      ispLSI2032@PLCC44  
 [(SA244)]  
 ispLSI2032@TQFP44 [(SA245A)]      ispLSI2032A@PLCC44  
 [(SA244)]  
 ispLSI2032A@TQFP44 [(SA245A)]      ispLSI2032A@TQFP48  
 [(SA248)]  
 ispLSI2032E@PLCC44 [(SA244)]      ispLSI2032E@TQFP44  
 [(SA245A)]  
 ispLSI2032E@TQFP48 [(SA248)]      ispLSI2032V@PLCC44  
 [(SA244)]  
 ispLSI2032V@TQFP44 [(SA245A)]      ispLSI2032V@TQFP48  
 [(SA248)]  
 ispLSI2032VE@PLCC44 [(SA244)]      ispLSI2032VE@TQFP44  
 [(SA245A)]  
 ispLSI2064A@PLCC44 [(SA244)]      ispLSI2064A@TQFP44  
 [(SA245A)]  
 ispLSI2064V@PLCC44 [(SA244)]      ispLSI2064V@TQFP44  
 [(SA245A)]  
 ispLSI2064VE@PLCC44 [(SA244)]      ispLSI2064VE@TQFP44  
 [(SA245A)]  
 LC4032B@TQFP44 [(SA245A)]  
 LC4032B@TQFP44(ISP) [ISP-HEADER01]  
 LC4032B@TQFP48 [(SA248)]  
 LC4032B@TQFP48(ISP) [ISP-HEADER01]  
 LC4032C@TQFP44 [(SA245A)]  
 LC4032C@TQFP44(ISP) [ISP-HEADER01]  
 LC4032C@TQFP48 [(SA248)]  
 LC4032C@TQFP48(ISP) [ISP-HEADER01]  
 LC4032V@TQFP44 [(SA245A)]  
 LC4032V@TQFP44(ISP) [ISP-HEADER01]  
 LC4032V@TQFP48 [(SA248)]  
 LC4032V@TQFP48(ISP) [ISP-HEADER01]  
 LC4032ZC@csBGA56 [(SA699+B161)]

LC4032ZC@csBGA56(ISP) [ISP-HEADER01]  
LC4032ZC@TQFP48 [(SA248)]  
LC4032ZC@TQFP48(ISP) [ISP-HEADER01]  
LC4032ZE@TQFP48 [(SA248)]  
LC4032ZE@TQFP48(ISP) [ISP-HEADER01]  
LC4064B@TQFP44 [(SA245A)]  
LC4064B@TQFP44(ISP) [ISP-HEADER01]  
LC4064B@TQFP48 [(SA248)]  
LC4064B@TQFP48(ISP) [ISP-HEADER01]  
LC4064C@TQFP44 [(SA245A)]  
LC4064C@TQFP44(ISP) [ISP-HEADER01]  
LC4064C@TQFP48 [(SA248)]  
LC4064C@TQFP48(ISP) [ISP-HEADER01]  
LC4064V@TQFP44 [(SA245A)]  
LC4064V@TQFP44(ISP) [ISP-HEADER01]  
LC4064V@TQFP48 [(SA248)]  
LC4064V@TQFP48(ISP) [ISP-HEADER01]  
LC4064ZC@TQFP48 [(SA248)] LC4064ZE@TQFP48  
[(SA248)]  
LCMXO1200C-FT256(ISP) [ISP-HEADER01]  
LCMXO1200C-FT324(ISP) [ISP-HEADER01]  
LCMXO1200C-FTN256(ISP) [ISP-HEADER01]  
LCMXO1200C-FTN324(ISP) [ISP-HEADER01]  
LCMXO1200C-M100(ISP) [ISP-HEADER01]  
LCMXO1200C-M132(ISP) [ISP-HEADER01]  
LCMXO1200C-MN100(ISP) [ISP-HEADER01]  
LCMXO1200C-MN132(ISP) [ISP-HEADER01]  
LCMXO1200C-T100(ISP) [ISP-HEADER01]  
LCMXO1200C-T144(ISP) [ISP-HEADER01]  
LCMXO1200C-TN100(ISP) [ISP-HEADER01]  
LCMXO1200C-TN144(ISP) [ISP-HEADER01]  
LCMXO1200E-FT256(ISP) [ISP-HEADER01]  
LCMXO1200E-FT324(ISP) [ISP-HEADER01]  
LCMXO1200E-FTN256(ISP) [ISP-HEADER01]  
LCMXO1200E-FTN324(ISP) [ISP-HEADER01]  
LCMXO1200E-M100(ISP) [ISP-HEADER01]  
LCMXO1200E-M132(ISP) [ISP-HEADER01]  
LCMXO1200E-MN100(ISP) [ISP-HEADER01]  
LCMXO1200E-MN132(ISP) [ISP-HEADER01]  
LCMXO1200E-T100(ISP) [ISP-HEADER01]  
LCMXO1200E-T144(ISP) [ISP-HEADER01]  
LCMXO1200E-TN100(ISP) [ISP-HEADER01]  
LCMXO1200E-TN144(ISP) [ISP-HEADER01]

LCMXO2280C-FT256( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-FT324( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-FTN256( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-FTN324( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-M100( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-M132( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-MN100( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-MN132( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-T100( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-T144( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-TN100( ISP) [ ISP-HEADER01 ]  
LCMXO2280C-TN144( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-FT256( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-FT324( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-FTN256( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-FTN324( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-M100( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-M132( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-MN100( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-MN132( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-T100( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-T144( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-TN100( ISP) [ ISP-HEADER01 ]  
LCMXO2280E-TN144( ISP) [ ISP-HEADER01 ]  
LCMXO256C-FT256( ISP) [ ISP-HEADER01 ]  
LCMXO256C-FT324( ISP) [ ISP-HEADER01 ]  
LCMXO256C-FTN256( ISP) [ ISP-HEADER01 ]  
LCMXO256C-FTN324( ISP) [ ISP-HEADER01 ]  
LCMXO256C-M100( ISP) [ ISP-HEADER01 ]  
LCMXO256C-M132( ISP) [ ISP-HEADER01 ]  
LCMXO256C-MN100( ISP) [ ISP-HEADER01 ]  
LCMXO256C-MN132( ISP) [ ISP-HEADER01 ]  
LCMXO256C-T100( ISP) [ ISP-HEADER01 ]  
LCMXO256C-T144( ISP) [ ISP-HEADER01 ]  
LCMXO256C-TN100( ISP) [ ISP-HEADER01 ]  
LCMXO256C-TN144( ISP) [ ISP-HEADER01 ]  
LCMXO256E-FT256( ISP) [ ISP-HEADER01 ]  
LCMXO256E-FT324( ISP) [ ISP-HEADER01 ]  
LCMXO256E-FTN256( ISP) [ ISP-HEADER01 ]  
LCMXO256E-FTN324( ISP) [ ISP-HEADER01 ]  
LCMXO256E-M100( ISP) [ ISP-HEADER01 ]  
LCMXO256E-M132( ISP) [ ISP-HEADER01 ]  
LCMXO256E-MN100( ISP) [ ISP-HEADER01 ]

LCMXO256E-MN132( ISP) [ ISP-HEADER01 ]  
LCMXO256E-T100( ISP) [ ISP-HEADER01 ]  
LCMXO256E-T144( ISP) [ ISP-HEADER01 ]  
LCMXO256E-TN100( ISP) [ ISP-HEADER01 ]  
LCMXO256E-TN144( ISP) [ ISP-HEADER01 ]  
LCMXO640C-FT256( ISP) [ ISP-HEADER01 ]  
LCMXO640C-FT324( ISP) [ ISP-HEADER01 ]  
LCMXO640C-FTN256( ISP) [ ISP-HEADER01 ]  
LCMXO640C-FTN324( ISP) [ ISP-HEADER01 ]  
LCMXO640C-M100( ISP) [ ISP-HEADER01 ]  
LCMXO640C-M132( ISP) [ ISP-HEADER01 ]  
LCMXO640C-MN100( ISP) [ ISP-HEADER01 ]  
LCMXO640C-MN132( ISP) [ ISP-HEADER01 ]  
LCMXO640C-T100( ISP) [ ISP-HEADER01 ]  
LCMXO640C-T144( ISP) [ ISP-HEADER01 ]  
LCMXO640C-TN100( ISP) [ ISP-HEADER01 ]  
LCMXO640C-TN144( ISP) [ ISP-HEADER01 ]  
LCMXO640E-FT256( ISP) [ ISP-HEADER01 ]  
LCMXO640E-FT324( ISP) [ ISP-HEADER01 ]  
LCMXO640E-FTN256( ISP) [ ISP-HEADER01 ]  
LCMXO640E-FTN324( ISP) [ ISP-HEADER01 ]  
LCMXO640E-M100( ISP) [ ISP-HEADER01 ]  
LCMXO640E-M132( ISP) [ ISP-HEADER01 ]  
LCMXO640E-MN100( ISP) [ ISP-HEADER01 ]  
LCMXO640E-MN132( ISP) [ ISP-HEADER01 ]  
LCMXO640E-T100( ISP) [ ISP-HEADER01 ]  
LCMXO640E-T144( ISP) [ ISP-HEADER01 ]  
LCMXO640E-TN100( ISP) [ ISP-HEADER01 ]  
LCMXO640E-TN144( ISP) [ ISP-HEADER01 ]  
LFXP10C-3F256C( ISP) [ ISP-HEADER01 ]  
LFXP10C-3F256I( ISP) [ ISP-HEADER01 ]  
LFXP10C-3F388C( ISP) [ ISP-HEADER01 ]  
LFXP10C-3F388I( ISP) [ ISP-HEADER01 ]  
LFXP10C-3FN256C( ISP) [ ISP-HEADER01 ]  
LFXP10C-3FN256I( ISP) [ ISP-HEADER01 ]  
LFXP10C-3FN388C( ISP) [ ISP-HEADER01 ]  
LFXP10C-3FN388I( ISP) [ ISP-HEADER01 ]  
LFXP10C-4F256C( ISP) [ ISP-HEADER01 ]  
LFXP10C-4F256I( ISP) [ ISP-HEADER01 ]  
LFXP10C-4F388C( ISP) [ ISP-HEADER01 ]  
LFXP10C-4F388I( ISP) [ ISP-HEADER01 ]  
LFXP10C-4FN256C( ISP) [ ISP-HEADER01 ]  
LFXP10C-4FN256I( ISP) [ ISP-HEADER01 ]

LFXP10C-4FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-4F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-4F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-4F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-4F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-4FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-4FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-4FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-4FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-5F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-5F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-5F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-5F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-5FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-5FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-5FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-5FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3FN388C ( ISP ) [ ISP-HEADER01 ]

LFXP15C-3FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-3FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-4FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15C-5FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-3FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-4F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-4F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-4F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-4F388I ( ISP ) [ ISP-HEADER01 ]

LFXP15E-4F484C( ISP) [ ISP-HEADER01 ]  
LFXP15E-4F484I( ISP) [ ISP-HEADER01 ]  
LFXP15E-4FN256C( ISP) [ ISP-HEADER01 ]  
LFXP15E-4FN256I( ISP) [ ISP-HEADER01 ]  
LFXP15E-4FN388C( ISP) [ ISP-HEADER01 ]  
LFXP15E-4FN388I( ISP) [ ISP-HEADER01 ]  
LFXP15E-4FN484C( ISP) [ ISP-HEADER01 ]  
LFXP15E-4FN484I( ISP) [ ISP-HEADER01 ]  
LFXP15E-5F256C( ISP) [ ISP-HEADER01 ]  
LFXP15E-5F256I( ISP) [ ISP-HEADER01 ]  
LFXP15E-5F388C( ISP) [ ISP-HEADER01 ]  
LFXP15E-5F388I( ISP) [ ISP-HEADER01 ]  
LFXP15E-5F484C( ISP) [ ISP-HEADER01 ]  
LFXP15E-5F484I( ISP) [ ISP-HEADER01 ]  
LFXP15E-5FN256C( ISP) [ ISP-HEADER01 ]  
LFXP15E-5FN256I( ISP) [ ISP-HEADER01 ]  
LFXP15E-5FN388C( ISP) [ ISP-HEADER01 ]  
LFXP15E-5FN388I( ISP) [ ISP-HEADER01 ]  
LFXP15E-5FN484C( ISP) [ ISP-HEADER01 ]  
LFXP15E-5FN484I( ISP) [ ISP-HEADER01 ]  
LFXP20C-3F256C( ISP) [ ISP-HEADER01 ]  
LFXP20C-3F256I( ISP) [ ISP-HEADER01 ]  
LFXP20C-3F388C( ISP) [ ISP-HEADER01 ]  
LFXP20C-3F388I( ISP) [ ISP-HEADER01 ]  
LFXP20C-3F484C( ISP) [ ISP-HEADER01 ]  
LFXP20C-3F484I( ISP) [ ISP-HEADER01 ]  
LFXP20C-3FN256C( ISP) [ ISP-HEADER01 ]  
LFXP20C-3FN256I( ISP) [ ISP-HEADER01 ]  
LFXP20C-3FN388C( ISP) [ ISP-HEADER01 ]  
LFXP20C-3FN388I( ISP) [ ISP-HEADER01 ]  
LFXP20C-3FN484C( ISP) [ ISP-HEADER01 ]  
LFXP20C-3FN484I( ISP) [ ISP-HEADER01 ]  
LFXP20C-4F256C( ISP) [ ISP-HEADER01 ]  
LFXP20C-4F256I( ISP) [ ISP-HEADER01 ]  
LFXP20C-4F388C( ISP) [ ISP-HEADER01 ]  
LFXP20C-4F388I( ISP) [ ISP-HEADER01 ]  
LFXP20C-4F484C( ISP) [ ISP-HEADER01 ]  
LFXP20C-4F484I( ISP) [ ISP-HEADER01 ]  
LFXP20C-4FN256C( ISP) [ ISP-HEADER01 ]  
LFXP20C-4FN256I( ISP) [ ISP-HEADER01 ]  
LFXP20C-4FN388C( ISP) [ ISP-HEADER01 ]  
LFXP20C-4FN388I( ISP) [ ISP-HEADER01 ]  
LFXP20C-4FN484C( ISP) [ ISP-HEADER01 ]



LFXP20C-4FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-4FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5F484I ( ISP ) [ ISP-HEADER01 ]

LFXP20E-5FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-5FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3Q208C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3Q208I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3QN208C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3QN208I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3T100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3T100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3T144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3T144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3TN100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3TN100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3TN144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-3TN144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4Q208C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4Q208I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4QN208C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4QN208I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4T100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4T100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4T144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4T144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4TN100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4TN100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4TN144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-4TN144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5Q208C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5Q208I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5QN208C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5QN208I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5T100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5T100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5T144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5T144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5TN100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5TN100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5TN144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3C-5TN144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-3Q208C ( ISP ) [ ISP-HEADER01 ]

LFXP3E-3Q208I (ISP) [ISP-HEADER01]  
LFXP3E-3QN208C (ISP) [ISP-HEADER01]  
LFXP3E-3QN208I (ISP) [ISP-HEADER01]  
LFXP3E-3T100C (ISP) [ISP-HEADER01]  
LFXP3E-3T100I (ISP) [ISP-HEADER01]  
LFXP3E-3T144C (ISP) [ISP-HEADER01]  
LFXP3E-3T144I (ISP) [ISP-HEADER01]  
LFXP3E-3TN100C (ISP) [ISP-HEADER01]  
LFXP3E-3TN100I (ISP) [ISP-HEADER01]  
LFXP3E-3TN144C (ISP) [ISP-HEADER01]  
LFXP3E-3TN144I (ISP) [ISP-HEADER01]  
LFXP3E-4Q208C (ISP) [ISP-HEADER01]  
LFXP3E-4Q208I (ISP) [ISP-HEADER01]  
LFXP3E-4QN208C (ISP) [ISP-HEADER01]  
LFXP3E-4QN208I (ISP) [ISP-HEADER01]  
LFXP3E-4T100C (ISP) [ISP-HEADER01]  
LFXP3E-4T100I (ISP) [ISP-HEADER01]  
LFXP3E-4T144C (ISP) [ISP-HEADER01]  
LFXP3E-4T144I (ISP) [ISP-HEADER01]  
LFXP3E-4TN100C (ISP) [ISP-HEADER01]  
LFXP3E-4TN100I (ISP) [ISP-HEADER01]  
LFXP3E-4TN144C (ISP) [ISP-HEADER01]  
LFXP3E-4TN144I (ISP) [ISP-HEADER01]  
LFXP3E-5Q208C (ISP) [ISP-HEADER01]  
LFXP3E-5Q208I (ISP) [ISP-HEADER01]  
LFXP3E-5QN208C (ISP) [ISP-HEADER01]  
LFXP3E-5QN208I (ISP) [ISP-HEADER01]  
LFXP3E-5T100C (ISP) [ISP-HEADER01]  
LFXP3E-5T100I (ISP) [ISP-HEADER01]  
LFXP3E-5T144C (ISP) [ISP-HEADER01]  
LFXP3E-5T144I (ISP) [ISP-HEADER01]  
LFXP3E-5TN100C (ISP) [ISP-HEADER01]  
LFXP3E-5TN100I (ISP) [ISP-HEADER01]  
LFXP3E-5TN144C (ISP) [ISP-HEADER01]  
LFXP3E-5TN144I (ISP) [ISP-HEADER01]  
LFXP6C-3F256C (ISP) [ISP-HEADER01]  
LFXP6C-3F256I (ISP) [ISP-HEADER01]  
LFXP6C-3FN256C (ISP) [ISP-HEADER01]  
LFXP6C-3FN256I (ISP) [ISP-HEADER01]  
LFXP6C-3Q208C (ISP) [ISP-HEADER01]  
LFXP6C-3Q208I (ISP) [ISP-HEADER01]  
LFXP6C-3QN208C (ISP) [ISP-HEADER01]  
LFXP6C-3QN208I (ISP) [ISP-HEADER01]

LFXP6C-3T144C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3T144I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3TN144C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3TN144I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4F256C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4F256I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4FN256C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4FN256I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4Q208C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4Q208I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4QN208C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4QN208I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4T144C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4T144I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4TN144C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4TN144I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5F256C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5F256I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5FN256C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5FN256I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5Q208C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5Q208I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5QN208C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5QN208I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5T144C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5T144I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5TN144C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5TN144I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3F256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3F256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3FN256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3FN256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3Q208C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3Q208I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3QN208C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3QN208I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3T144C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3T144I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3TN144C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3TN144I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4F256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4F256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4FN256C( ISP ) [ ISP-HEADER01 ]

LFXP6E-4FN256I (ISP) [ISP-HEADER01]	
LFXP6E-4Q208C (ISP) [ISP-HEADER01]	
LFXP6E-4Q208I (ISP) [ISP-HEADER01]	
LFXP6E-4QN208C (ISP) [ISP-HEADER01]	
LFXP6E-4QN208I (ISP) [ISP-HEADER01]	
LFXP6E-4T144C (ISP) [ISP-HEADER01]	
LFXP6E-4T144I (ISP) [ISP-HEADER01]	
LFXP6E-4TN144C (ISP) [ISP-HEADER01]	
LFXP6E-4TN144I (ISP) [ISP-HEADER01]	
LFXP6E-5F256C (ISP) [ISP-HEADER01]	
LFXP6E-5F256I (ISP) [ISP-HEADER01]	
LFXP6E-5FN256C (ISP) [ISP-HEADER01]	
LFXP6E-5FN256I (ISP) [ISP-HEADER01]	
LFXP6E-5Q208C (ISP) [ISP-HEADER01]	
LFXP6E-5Q208I (ISP) [ISP-HEADER01]	
LFXP6E-5QN208C (ISP) [ISP-HEADER01]	
LFXP6E-5QN208I (ISP) [ISP-HEADER01]	
LFXP6E-5T144C (ISP) [ISP-HEADER01]	
LFXP6E-5T144I (ISP) [ISP-HEADER01]	
LFXP6E-5TN144C (ISP) [ISP-HEADER01]	
LFXP6E-5TN144I (ISP) [ISP-HEADER01]	
M4A3-32/32@PLCC44 [(SA244)]	M4A3-32/32@TQFP44
[(SA245A)]	
M4A3-32/32@TQFP48 [(SA248)]	M4A3-64/32@PLCC44
[(SA244)]	
M4A3-64/32@TQFP44 [(SA245A)]	M4A3-64/32@TQFP48
[(SA248)]	
M4A5-32/32@PLCC44 [(SA244)]	M4A5-32/32@TQFP44
[(SA245A)]	
M4A5-32/32@TQFP48 [(SA248)]	M4A5-64/32@PLCC44
[(SA244)]	
M4A5-64/32@TQFP44 [(SA245A)]	M4A5-64/32@TQFP48
[(SA248)]	
MACH110@PLCC44 [(SA244)]	
PALCE20RA10	
PALCE20RA10@PLCC28 [(SA008A)]	PALCE20RA10@SOIC24
[(SA404)]	
PALCE20RA10H	PALCE20RA10H@PLCC28
[(SA008A)]	
PALCE20RA10H@SOIC24 [(SA404)]	
PALCE20RA10Q	
PALCE20RA10Q@PLCC28 [(SA008A)]	PALCE20RA10Q@SOIC24
[(SA404)]	

PALCE22V10H [ (SA008A) ]	PALCE22V10H@PLCC28
PALCE22V10H@SOIC24 [ (SA404) ]	
PALCE22V10Q PALCE22V10Q@PLCC28 [ (SA008A) ]	PALCE22V10Q@SOIC24
[ (SA404) ]	
PALCE22V10Z [ (SA008A) ]	PALCE22V10Z@PLCC28
PALCE22V10Z@SOIC24 [ (SA404) ]	

## LG Semicon

### DRAM & SRAM

GM76C256CL [ (SA430T) ]	GM76C256CL@SSOP28
GM76C256CL@TSOP28 [ (SA630) ]	
GM76C256CLL GM76C256CLL@SSOP28 [ (SA430T) ]	GM76C256CLL@TSOP28
[ (SA630) ]	
GM76C8128CL [ (SA438T) ]	GM76C8128CL@SSOP32
GM76C8128CL@TSOP32 [ (SA410T) ]	GM76C8128CL@VSOP32
[ (SA620) ]	
GM76C8128CLL [ (SA438T) ]	GM76C8128CLL@SSOP32
GM76C8128CLL@TSOP32 [ (SA410T) ]	GM76C8128CLL@VSOP32
[ (SA620) ]	
GM76C88AL [ (SA430T) ]	GM76C88AL@SSOP28
GM76C88AL@TSOP28 [ (SA643) ]	
GM76U256CL GM76U256CL@SSOP28 [ (SA430T) ]	GM76U256CL@TSOP28
[ (SA643) ]	
GM76U256CLL [ (SA430T) ]	GM76U256CLL@SSOP28
GM76U256CLL@TSOP28 [ (SA643) ]	
GM76U8128CL GM76U8128CL@SSOP32 [ (SA438T) ]	GM76U8128CL@TSOP32
[ (SA410T) ]	
GM76U8128CL@VSOP32 [ (SA620) ]	
GM76U8128CLL	

GM76U8128CLL@SSOP32 [(SA438T)]	GM76U8128CLL@TSOP32
[(SA410T)]	
GM76U8128CLL@VSOP32 [(SA620)]	
GM76U8128DL	
GM76U8128DL@SSOP32 [(SA438T)]	GM76U8128DL@TSOP32
[(SA410T)]	
GM76U8128DL@VSOP32 [(SA620)]	
GM76U8128DLL	
GM76U8128DLL@SSOP32 [(SA438T)]	GM76U8128DLL@TSOP32
[(SA410T)]	
GM76U8128DLL@VSOP32 [(SA620)]	
GM76U8512L	
GM76U8512L@SSOP32 [(SA438T)]	GM76U8512L@TSOP32
[(SA410T)]	
GM76U8512L@VSOP32 [(SA620)]	
GM76U8512LL	
GM76U8512LL@SSOP32 [(SA438T)]	GM76U8512LL@TSOP32
[(SA410T)]	
GM76U8512LL@VSOP32 [(SA620)]	
GM76V256CL	
GM76V256CL@SSOP28 [(SA430T)]	GM76V256CL@TSOP28
[(SA630)]	
GM76V256CLL	
[(SA430T)]	GM76V256CLL@SSOP28
GM76V256CLL@TSOP28 [(SA630)]	
GM76V8128CL	
GM76V8128CL@SSOP32 [(SA438T)]	GM76V8128CL@TSOP32
[(SA410T)]	
GM76V8128CL@VSOP32 [(SA620)]	
GM76V8128CLL	
GM76V8128CLL@SSOP32 [(SA438T)]	GM76V8128CLL@TSOP32
[(SA410T)]	
GM76V8128CLL@VSOP32 [(SA620)]	
GM76V8128DL	
GM76V8128DL@SSOP32 [(SA438T)]	GM76V8128DL@TSOP32
[(SA410T)]	
GM76V8128DL@VSOP32 [(SA620)]	
GM76V8128DLL	
GM76V8128DLL@SSOP32 [(SA438T)]	GM76V8128DLL@TSOP32
[(SA410T)]	
GM76V8128DLL@VSOP32 [(SA620)]	
GM76V8512L	
GM76V8512L@SSOP32 [(SA438T)]	GM76V8512L@TSOP32

[ ( SA410T ) ]	
GM76V8512L@VSOP32 [ ( SA620 ) ]	
GM76V8512LL	
GM76V8512LL@SSOP32 [ ( SA438T ) ]	GM76V8512LL@TSOP32
[ ( SA410T ) ]	
GM76V8512LL@VSOP32 [ ( SA620 ) ]	
GM77C8128A	
GM77C8128A@SSOP32 [ ( SA438T ) ]	GM77C8128A@TSOP32
[ ( SA410T ) ]	
GM77C8128A@VSOP32 [ ( SA620 ) ]	

## MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20
[ ( SA404 ) ]	
GMS97C2051	GMS97C2051@SOIC20
[ ( SA404 ) ]	
GMS97C51	GMS97C51@PLCC44
[ ( SA244 ) ]	
GMS97C51@TQFP44 [ ( SA245A ) ]	
GMS97C52	
GMS97C52@PLCC44 [ ( SA244 ) ]	GMS97C52@TQFP44
[ ( SA245A ) ]	
GMS97C54	GMS97C54@PLCC44
[ ( SA244 ) ]	
GMS97C54@TQFP44 [ ( SA245A ) ]	
GMS97C56	
GMS97C56@PLCC44 [ ( SA244 ) ]	GMS97C56@TQFP44
[ ( SA245A ) ]	
GMS97C58	GMS97C58@PLCC44
[ ( SA244 ) ]	
GMS97C58@TQFP44 [ ( SA245A ) ]	
GMS97L1051	
GMS97L1051@SOIC20 [ ( SA404 ) ]	
GMS97L2051	
GMS97L2051@SOIC20 [ ( SA404 ) ]	
GMS97L51	
GMS97L51@PLCC44 [ ( SA244 ) ]	GMS97L51@TQFP44
[ ( SA245A ) ]	
GMS97L52	GMS97L52@PLCC44
[ ( SA244 ) ]	
GMS97L52@TQFP44 [ ( SA245A ) ]	



GMS97L54	
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44
[(SA245A)]	
GMS97L56	GMS97L56@PLCC44
[(SA244)]	
GMS97L56@TQFP44 [(SA245A)]	
GMS97L58	
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44
[(SA245A)]	
GMS99C52	GMS99C52@PLCC44
[(SA244)]	
GMS99C52@TQFP44 [(SA245A)]	
GMS99C58	
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44
[(SA245A)]	

## LINKSMART

### E (E) PROM/FRAM/NVRAM

L24C02	L24C02@SSOP8
[(SA602A)]	
L24C02@TSOP8 [(SA026)]	
L24C04	
L24C04@SSOP8 [(SA602A)]	L24C04@TSOP8
[(SA026)]	
L29004C	L29004C@PLCC32
[(SA015A1T)]	
L29004C@TSOP32 [(SA620)]	L29S160F@TSOP48 [(SA247-
B005)]	
L29S160F-B@TSOP48 [(SA247-B005)]	L29S400F@PSOP44
[(SA638)]	
L29S400F@TSOP48 [(SA247-B005)]	L29S400F-B@PSOP44
[(SA638)]	
L29S400F-B@TSOP48 [(SA247-B005)]	L29S800F@TSOP48 [(SA247-
B005)]	
L29S800F-B@TSOP48 [(SA247-B005)]	L29W800E@TSOP48 [(SA247-
B005)]	
L29W800E-B@TSOP48 [(SA247-B005)]	
LST28001	
LST28001@PLCC32 [(SA015A1T)]	LST28001@TSOP32
[(SA620)]	

LST28002 LST28002@PLCC32  
 [(SA015A1T)]  
 LST28002@TSOP32 [(SA620)]  
 LST28004  
 LST28004@PLCC32 [(SA015A1T)] LST28004@TSOP32  
 [(SA620)]

## MACRONIX

### E(E) PROM/FRAM/NVRAM

KH25L1005 KH25L1005(ISP) [ISP-  
 HEADER01]  
 KH25L1005@SON8 [(SA683)]  
 KH25L1005@SON8(ISP) [ISP-HEADER01]  
 KH25L1005@SOP8 [(SA602A)]  
 KH25L1005@SOP8(ISP) [ISP-HEADER01]  
 KH25L1005A KH25L1005A@SON8  
 [(SA683)]  
 KH25L1005A@SOP8 [(SA602A)]  
 KH25L12805D@SON8(Fast Mode) [(SA684)]  
 KH25L12805D@SOP16(Fast Mode) [(SA404)]  
 KH25L12805N@SOP16 [(SA404)]  
 KH25L12805N@SOP16(Fast Mode) [(SA404)]  
 KH25L1602@SOP28 [(SA630)] KH25L1605@SON8  
 [(SA684)]  
 KH25L1605@SON8(Fast Mode) [(SA684)]  
 KH25L1605@SOP16 [(SA404)]  
 KH25L1605@SOP16(Fast Mode) [(SA404)]  
 KH25L1605A@SON8 [(SA684)]  
 KH25L1605A@SON8(Fast Mode) [(SA684)]  
 KH25L1605A@SOP16 [(SA404)]  
 KH25L1605A@SOP16(Fast Mode) [(SA404)]  
 KH25L1605A@SOP8 [(SA023A)]  
 KH25L1605A@SOP8(Fast Mode) [(SA023A)]  
 KH25L1605D@SON8 [(SA684)]  
 KH25L1605D@SON8(Fast Mode) [(SA683)]  
 KH25L1605D@SOP16 [(SA404)]  
 KH25L1605D@SOP16(Fast Mode) [(SA404)]  
 KH25L1605D@SOP8(150)(Fast Mode) [(SA602A)]  
 KH25L1605D@SOP8(200)(Fast Mode) [(SA605B)]  
 KH25L1636DM1I@SOP8 [(SA602A)] KH25L1636DM2I@SOP8

[(SA605B)]  
 KH25L1636DMI@SOP16 [(SA404)] KH25L1636DZNI@WSON8  
 [(SA683)]  
 KH25L2005 KH25L2005(ISP) [ISP-  
 HEADER01]  
 KH25L2005@SON8 [(SA683)]  
 KH25L2005@SON8(ISP) [ISP-HEADER01]  
 KH25L2005@SOP8 [(SA602A)]  
 KH25L2005@SOP8(ISP) [ISP-HEADER01]  
 KH25L2025 KH25L2025@SON8  
 [(SA683)]  
 KH25L2025@SOP8 [(SA602A)] KH25L3202@SOP32  
 [(SA438T)]  
 KH25L3205@SOP16 [(SA404)]  
 KH25L3205@SOP16(Fast Mode) [(SA404)]  
 KH25L3205@SOP8 [(SA023A)]  
 KH25L3205@SOP8(Fast Mode) [(SA023A)]  
 KH25L3205A@SON8 [(SA684)]  
 KH25L3205A@SON8(Fast Mode) [(SA684)]  
 KH25L3205A@SOP16 [(SA404)]  
 KH25L3205A@SOP16(Fast Mode) [(SA404)]  
 KH25L3205A@SOP8 [(SA023A)]  
 KH25L3205A@SOP8(Fast Mode) [(SA023A)]  
 KH25L3205D@SON8(Fast Mode) [(SA683)]  
 KH25L3205D@SOP16 [(SA404)]  
 KH25L3205D@SOP16(Fast Mode) [(SA404)]  
 KH25L3205D@SOP8 [(SA023A)]  
 KH25L3205D@SOP8(Fast Mode) [(SA605B)]  
 KH25L3236DM2I@SOP8 [(SA605B)] KH25L3236DMI@SOP16  
 [(SA404)]  
 KH25L3236DZNI@WSON8 [(SA683)]  
 KH25L4005  
 KH25L4005(150mil)@SOP8 [(SA602A)]  
 KH25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005(209mil)@SOP8 [(SA023A)]  
 KH25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005(ISP) [ISP-HEADER01] KH25L4005@SON8  
 [(SA683)]  
 KH25L4005@SON8(ISP) [ISP-HEADER01]  
 KH25L4005A  
 KH25L4005A(150mil)@SOP8 [(SA602A)]  
 KH25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005A(209mil)@SOP8 [(SA023A)]

KH25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005A(ISP) [ISP-HEADER01] KH25L4005A@SON8  
[(SA683)]  
KH25L4005A@SON8(ISP) [ISP-HEADER01]  
KH25L4025A  
KH25L4025A(150mil)@SOP8 [(SA602A)]  
KH25L4025A(209mil)@SOP8 [(SA023A)]  
KH25L4025A@SON8 [(SA683)] KH25L512@SON8  
[(SA683)]  
KH25L512@SOP8 [(SA602A)]  
KH25L512A  
KH25L512A@SON8 [(SA683)] KH25L512A@SOP8  
[(SA602A)]  
KH25L6402@SOP32 [(SA438T)] KH25L6402A@SOP28  
[(SA630)]  
KH25L6405@SOP16 [(SA404)]  
KH25L6405@SOP16(Fast Mode) [(SA404)]  
KH25L6405@SOP8 [(SA023A)]  
KH25L6405@SOP8(Fast Mode) [(SA023A)]  
KH25L6405D@SON8(Fast Mode) [(SA684)]  
KH25L6405D@SOP16 [(SA404)]  
KH25L6405D@SOP16(Fast Mode) [(SA404)]  
KH25L6405D@SOP8 [(SA023A)]  
KH25L8005  
KH25L8005(150mil)@SOP8 [(SA602A)]  
KH25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L8005(209mil)@SOP8 [(SA023A)]  
KH25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L8005(ISP) [ISP-HEADER01] KH25L8005@SON8  
[(SA683)]  
KH25L8005@SON8(ISP) [ISP-HEADER01]  
KH25L802@SOP28 [(SA630)]  
KH25L8025  
KH25L8025(150mil)@SOP8 [(SA602A)]  
KH25L8025(209mil)@SOP8 [(SA023A)]  
KH25L8025@SON8 [(SA683)]  
KH25L8036D  
KH25L8036D@SOP16 [(SA404)]  
KH25L8036D@SOP8[150 mil] [(SA602A)]  
KH25L8036D@SOP8[200 mil] [(SA023A)]  
KH25L8036D@WSON8 [(SA683)] KH29LV004CB@PLCC32  
[(SA015A1T)]  
KH29LV004CB@TSOP40 [(SA409T)] KH29LV004CT@PLCC32

[(SA015A1T)]  
 KH29LV004CT@TSOP40 [(SA409T)] KH29LV008CB@TSOP40  
 [(SA409T)]  
 KH29LV008CT@TSOP40 [(SA409T)]  
 KH29LV040C  
 KH29LV040C@PLCC32 [(SA015A1T)]  
 KH29LV160CBT@TSOP48 [(SA247-B005)]  
 KH29LV160CTT@TSOP48 [(SA247-B005)]  
 KH29LV320CBT@TSOP48 [(SA247-B005)]  
 KH29LV320CTT@TSOP48 [(SA247-B005)]  
 KH29LV320DBT@TSOP48 [(SA247-B005)]  
 KH29LV320DTT@TSOP48 [(SA247-B005)]  
 KH29LV400CBT@TSOP48 [(SA247-B005)]  
 KH29LV400CTT@TSOP48 [(SA247-B005)]  
 KH29LV640DBT@TSOP48 [(SA247-B005)]  
 KH29LV640DTT@TSOP48 [(SA247-B005)]  
 KH29LV800CBT@TSOP48 [(SA247-B005)]  
 KH29LV800CTT@TSOP48 [(SA247-B005)]  
 MX25L1005 MX25L1005(ISP) [ISP-  
 HEADER01]  
 MX25L1005@SON8 [(SA683)]  
 MX25L1005@SON8(ISP) [ISP-HEADER01]  
 MX25L1005@SOP8 [(SA602A)]  
 MX25L1005@SOP8(ISP) [ISP-HEADER01]  
 MX25L1005A MX25L1005A@SON8  
 [(SA683)]  
 MX25L1005A@SOP8 [(SA602A)]  
 MX25L12805D@SON8(Fast Mode) [(SA684)]  
 MX25L12805D@SOP16(Fast Mode) [(SA404)]  
 MX25L12805N@SOP16 [(SA404)]  
 MX25L12805N@SOP16(Fast Mode) [(SA404)]  
 MX25L1602@SOP28 [(SA630)] MX25L1605@SON8  
 [(SA684)]  
 MX25L1605@SON8(Fast Mode) [(SA684)]  
 MX25L1605@SOP16 [(SA404)]  
 MX25L1605@SOP16(Fast Mode) [(SA404)]  
 MX25L1605A@SON8 [(SA684)]  
 MX25L1605A@SON8(Fast Mode) [(SA684)]  
 MX25L1605A@SOP16 [(SA404)]  
 MX25L1605A@SOP16(Fast Mode) [(SA404)]  
 MX25L1605A@SOP8 [(SA023A)]  
 MX25L1605A@SOP8(Fast Mode) [(SA023A)]  
 MX25L1605D@SON8 [(SA684)]

MX25L1605D@SON8(Fast Mode) [(SA683)]  
MX25L1605D@SOP16 [(SA404)]  
MX25L1605D@SOP16(Fast Mode) [(SA404)]  
MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]  
MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]  
MX25L1615D@SOP16 [(SA404)] MX25L1615D@SOP8  
[(SA023A)]  
MX25L1635DM1I@SOP8 [(SA602A)] MX25L1635DM2I@SOP8  
[(SA605B)]  
MX25L1635DMI@SOP16 [(SA404)] MX25L1635DZNI@WSON8  
[(SA683)]  
MX25L1636DM1I@SOP8 [(SA602A)] MX25L1636DM2I@SOP8  
[(SA605B)]  
MX25L1636DMI@SOP16 [(SA404)] MX25L1636DZNI@WSON8  
[(SA683)]  
MX25L2005 MX25L2005(ISP) [ISP-  
HEADER01]  
MX25L2005@SON8 [(SA683)]  
MX25L2005@SON8(ISP) [ISP-HEADER01]  
MX25L2005@SOP8 [(SA602A)]  
MX25L2005@SOP8(ISP) [ISP-HEADER01]  
MX25L2025 MX25L2025@SON8  
[(SA683)]  
MX25L2025@SOP8 [(SA602A)] MX25L3202@SOP32  
[(SA438T)]  
MX25L3205@SOP16 [(SA404)]  
MX25L3205@SOP16(Fast Mode) [(SA404)]  
MX25L3205@SOP8 [(SA023A)]  
MX25L3205@SOP8(Fast Mode) [(SA023A)]  
MX25L3205A@SON8 [(SA684)]  
MX25L3205A@SON8(Fast Mode) [(SA684)]  
MX25L3205A@SOP16 [(SA404)]  
MX25L3205A@SOP16(Fast Mode) [(SA404)]  
MX25L3205A@SOP16(Parallel Mode) [(SA404)]  
MX25L3205A@SOP8 [(SA023A)]  
MX25L3205A@SOP8(Fast Mode) [(SA023A)]  
MX25L3205D@SON8(Fast Mode) [(SA683)]  
MX25L3205D@SOP16 [(SA404)]  
MX25L3205D@SOP16(Fast Mode) [(SA404)]  
MX25L3205D@SOP8 [(SA023A)]  
MX25L3205D@SOP8(Fast Mode) [(SA605B)]  
MX25L3215D@SOP16 [(SA404)] MX25L3215D@SOP8  
[(SA023A)]

MX25L3235DM2I@SOP8 [(SA605B)] MX25L3235DMI@SOP16  
[(SA404)]  
MX25L3235DZNI@WSON8 [(SA683)] MX25L3236DM2I@SOP8  
[(SA605B)]  
MX25L3236DMI@SOP16 [(SA404)] MX25L3236DZNI@WSON8  
[(SA683)]  
MX25L3237D@SOP16 [(SA404)] MX25L3237D@WSON8  
[(SA683)]  
MX25L4005  
MX25L4005(150mil)@SOP8 [(SA602A)]  
MX25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005(209mil)@SOP8 [(SA023A)]  
MX25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005(ISP) [ISP-HEADER01] MX25L4005@SON8  
[(SA683)]  
MX25L4005@SON8(ISP) [ISP-HEADER01]  
MX25L4005A  
MX25L4005A(150mil)@SOP8 [(SA602A)]  
MX25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(209mil)@SOP8 [(SA023A)]  
MX25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(ISP) [ISP-HEADER01] MX25L4005A@SON8  
[(SA683)]  
MX25L4005A@SON8(ISP) [ISP-HEADER01]  
MX25L4025A  
MX25L4025A(150mil)@SOP8 [(SA602A)]  
MX25L4025A(209mil)@SOP8 [(SA023A)]  
MX25L4025A@SON8 [(SA683)] MX25L512@SON8  
[(SA683)]  
MX25L512@SOP8 [(SA602A)]  
MX25L512A  
MX25L512A@SON8 [(SA683)] MX25L512A@SOP8  
[(SA602A)]  
MX25L6402@SOP32 [(SA438T)] MX25L6402A@SOP28  
[(SA630)]  
MX25L6405@SOP16 [(SA404)]  
MX25L6405@SOP16(Fast Mode) [(SA404)]  
MX25L6405@SOP8 [(SA023A)]  
MX25L6405@SOP8(Fast Mode) [(SA023A)]  
MX25L6405D@SON8(Fast Mode) [(SA684)]  
MX25L6405D@SOP16 [(SA404)]  
MX25L6405D@SOP16(Fast Mode) [(SA404)]  
MX25L6405D@SOP8 [(SA023A)] MX25L6415D@SOP16

[(SA404)]  
 MX25L6415D@SOP8 [(SA023A)] MX25L6445E@SOP16  
 [(SA404)]  
 MX25L6445E@SOP8 [(SA023A)] MX25L6445E@WSON8  
 [(SA684)]  
 MX25L6455E@SOP16 [(SA404)]  
 MX25L8005  
 MX25L8005(150mil)@SOP8 [(SA602A)]  
 MX25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 MX25L8005(209mil)@SOP8 [(SA023A)]  
 MX25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 MX25L8005(ISP) [ISP-HEADER01] MX25L8005@SON8  
 [(SA683)]  
 MX25L8005@SON8(ISP) [ISP-HEADER01]  
 MX25L802@SOP28 [(SA630)]  
 MX25L8025  
 MX25L8025(150mil)@SOP8 [(SA602A)]  
 MX25L8025(209mil)@SOP8 [(SA023A)]  
 MX25L8025@SON8 [(SA683)]  
 MX25L8036D  
 MX25L8036D@SOP16 [(SA602A)]  
 MX25L8036D@SOP8[150 mil] [(SA602A)]  
 MX25L8036D@SOP8[200 mil] [(SA023A)]  
 MX25L8036D@WSON8 [(SA683)] MX25U1635@SOIC8  
 [(SA602A)]  
 MX25U1635@USON8(4\*4mm) [(SA744)] MX25U1635@USON8(6\*5mm)  
 [(SA683)]  
 MX25U4035@SOIC8 [(SA602A)] MX25U4035@USON8(4\*4mm)  
 [(SA744)]  
 MX25U4035@USON8(6\*5mm) [(SA683)] MX25U8035@SOIC8  
 [(SA602A)]  
 MX25U8035@USON8(4\*4mm) [(SA744)] MX25U8035@USON8(6\*5mm)  
 [(SA683)]  
 MX25V512@USON8 [(SA724)]  
 MX26C1000B  
 MX26C1000B@PLCC32 [(SA015A1T)] MX26C1000B@SOIC32  
 [(SA603)]  
 MX26C1000B@TSOP32 [(SA410T)]  
 MX26C2000B  
 MX26C2000B@PLCC32 [(SA015A1T)] MX26C2000B@SOIC32  
 [(SA603)]  
 MX26C2000B@TSOP32 [(SA410T)]  
 MX26C512A



MX26C512A@PLCC32 [(SA015A1T)] MX26C512A@SOIC28  
[(SA630)]  
MX26C512A@TSOP28 [(SA430T)]  
MX26F128J3TC@TSOP56 [(SA628-B018)]  
MX26F128J3XC@CSP64 [(SA655A-B054A-T064F001)]  
MX26F640J3TC@TSOP56 [(SA628-B018)]  
MX26F640J3XC@CSP64 [(SA655A-B054A-T064F001)]  
MX26L12711MC@PSOP44 [(SA638)] MX26L12811MC@PSOP44  
[(SA638)]  
MX26L6419T@TSOP48 [(SA247-B005)] MX26L6420@PSOP44  
[(SA638)]  
MX26L6420@TSOP48 [(SA247-B005)] MX26LV004B@PLCC32  
[(SA015A1T)]  
MX26LV004B@TSOP40 [(SA409T)] MX26LV004T@PLCC32  
[(SA015A1T)]  
MX26LV004T@TSOP40 [(SA409T)] MX26LV008B@TSOP40  
[(SA409T)]  
MX26LV008T@TSOP40 [(SA409T)]  
MX26LV040(QC)@PLCC32 [(SA015A1T)]  
MX26LV040(TC)@TSOP32 [(SA410T)]  
MX26LV160BT@TSOP48 [(SA247-B005)]  
MX26LV160BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV160BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV160TT@TSOP48 [(SA247-B005)]  
MX26LV160TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV160TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400BT@TSOP48 [(SA247-B005)]  
MX26LV400BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400TT@TSOP48 [(SA247-B005)]  
MX26LV400TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV800BM@PSOP44 [(SA638)]  
MX26LV800BT@TSOP48 [(SA247-B005)]  
MX26LV800BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800TM@PSOP44 [(SA638)]  
MX26LV800TT@TSOP48 [(SA247-B005)]  
MX26LV800TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX27C1000 MX27C1000@PLCC32  
[(SA015A1T)]  
MX27C1000@SOIC32 [(SA603)] MX27C1000@TSOP32

[ (SA410T) ]	
MX27C1000A	MX27C1000A@PLCC32
[ (SA015A1T) ]	
MX27C1000A@SOIC32 [ (SA603) ]	MX27C1000A@TSOP32
[ (SA410T) ]	
MX27C1001	MX27C1001@PLCC32
[ (SA015A1T) ]	
MX27C1001@SOIC32 [ (SA603) ]	MX27C1001@TSOP32
[ (SA410T) ]	
MX27C1024	MX27C1024@PLCC44
[ (SA244) ]	
MX27C1024@TSOP40 [ (SA409T) ]	
MX27C1024A	
MX27C1024A@PLCC44 [ (SA244) ]	MX27C1024A@TSOP40
[ (SA409T) ]	
MX27C1024B	MX27C1024B@PLCC44
[ (SA244) ]	
MX27C1024B@TSOP40 [ (SA409T) ]	
MX27C1100	
MX27C2000	MX27C2000@PLCC32
[ (SA015A1T) ]	
MX27C2000@SOIC32 [ (SA603) ]	MX27C2000@TSOP32
[ (SA410T) ]	
MX27C2000A	MX27C2000A@PLCC32
[ (SA015A1T) ]	
MX27C2000A@SOIC32 [ (SA603) ]	MX27C2000A@TSOP32
[ (SA410T) ]	
MX27C2048	MX27C2048@PLCC44
[ (SA244) ]	
MX27C2048@TSOP40 [ (SA409T) ]	
MX27C2100	
MX27C256	MX27C256@PLCC32
[ (SA015A1T) ]	
MX27C4000	MX27C4000@PLCC32
[ (SA015A1T) ]	
MX27C4000@SOIC32 [ (SA603) ]	MX27C4000@TSOP32
[ (SA410T) ]	
MX27C4000A	MX27C4000A@PLCC32
[ (SA015A1T) ]	
MX27C4000A@SOIC32 [ (SA603) ]	MX27C4000A@TSOP32
[ (SA410T) ]	
MX27C4096	MX27C4096@PLCC44
[ (SA244) ]	

MX27C4100	
MX27C4111	
MX27C512	MX27C512@PLCC32
[ (SA015A1T) ]	
MX27C516	MX27C516@PLCC44
[ (SA244) ]	
MX27C516@TSOP40 [ (SA409T) ]	
MX27C8000	
MX27C8000@PLCC32 [ (SA015A1T) ]	MX27C8000@SOIC32
[ (SA603) ]	
MX27C8000@TSOP32 [ (SA410T) ]	
MX27C8000A	
MX27C8000A@PLCC32 [ (SA015A1T) ]	MX27C8000A@SOIC32
[ (SA603) ]	
MX27C8000A@TSOP32 [ (SA410T) ]	
MX27C8100	
MX27C8100@PSOP44 [ (SA638) ]	
MX27C8111	
MX27C8111@PSOP44 [ (SA638) ]	
MX27L1000	
MX27L1000@PLCC32 [ (SA015A1T) ]	MX27L1000@TSOP32
[ (SA410T) ]	
MX27L2000	MX27L2000@PLCC32
[ (SA015A1T) ]	
MX27L2000@TSOP32 [ (SA410T) ]	
MX27L256	
MX27L256@PLCC32 [ (SA015A1T) ]	MX27L256@TSOP32
[ (SA430T) ]	
MX27L4000	MX27L4000@PLCC32
[ (SA015A1T) ]	
MX27L4000@TSOP32 [ (SA410T) ]	
MX27L4096	
MX27L4096@PLCC44 [ (SA244) ]	
MX27L512	
MX27L512@PLCC32 [ (SA015A1T) ]	MX27L512@TSOP28
[ (SA430T) ]	
MX28F002B@TSOP40 [ (SA409T) ]	MX28F002T@TSOP40
[ (SA409T) ]	
MX28F1000	MX28F1000@PLCC32
[ (SA015A1T) ]	
MX28F1000@SOP32 [ (SA603) ]	MX28F1000@TSOP32
[ (SA410T) ]	
MX28F1000P	MX28F1000P@PLCC32

[ (SA015A1T) ]  
 MX28F1000P@TSOP32 [ (SA410T) ]  
 MX28F160C3BT@TSOP48 [ (SA247-B005) ]  
 MX28F160C3BX@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 MX28F160C3TT@TSOP48 [ (SA247-B005) ]  
 MX28F160C3TX@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 MX28F2000 MX28F2000@PLCC32  
 [ (SA015A1T) ]  
 MX28F2000@TSOP32 [ (SA410T) ]  
 MX28F2000P  
 MX28F2000P@PLCC32 [ (SA015A1T) ] MX28F2000P@TSOP32  
 [ (SA410T) ]  
 MX28F2100B@PSOP44 [ (SA638) ] MX28F2100B@TSOP48 [ (SA247-B005) ]  
 MX28F2100T@PSOP44 [ (SA638) ] MX28F2100T@TSOP48 [ (SA247-B005) ]  
 MX28F4000 MX28F4000@PLCC32  
 [ (SA015A1T) ]  
 MX28F4000@TSOP32 [ (SA410T) ]  
 MX28F640C3BT@TSOP48 [ (SA247-B005) ]  
 MX28F640C3BX@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 MX28F640C3TT@TSOP48 [ (SA247-B005) ]  
 MX28F640C3TX@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 MX29F001B MX29F001B@PLCC32  
 [ (SA015A1T) ]  
 MX29F001B@TSOP32 [ (SA410T) ]  
 MX29F001T  
 MX29F001T@PLCC32 [ (SA015A1T) ] MX29F001T@TSOP32  
 [ (SA410T) ]  
 MX29F002B MX29F002B@PLCC32  
 [ (SA015A1T) ]  
 MX29F002B@TSOP32 [ (SA410T) ]  
 MX29F002NB  
 MX29F002NB@PLCC32 [ (SA015A1T) ] MX29F002NB@TSOP32  
 [ (SA410T) ]  
 MX29F002NT MX29F002NT@PLCC32  
 [ (SA015A1T) ]  
 MX29F002NT@TSOP32 [ (SA410T) ]  
 MX29F002T  
 MX29F002T@PLCC32 [ (SA015A1T) ] MX29F002T@TSOP32  
 [ (SA410T) ]  
 MX29F004B MX29F004B@PLCC32  
 [ (SA015A1T) ]

MX29F004B@TSOP32 [(SA410T)]	
MX29F004T	
MX29F004T@PLCC32 [(SA015A1T)]	MX29F004T@TSOP32
[(SA410T)]	
MX29F016@PSOP44 [(SA638)]	MX29F016@TSOP40
[(SA409T)]	
MX29F016@TSOP48 [(SA247-B005)]	
MX29F022B	
MX29F022B@PLCC32 [(SA015A1T)]	MX29F022B@TSOP32
[(SA410T)]	
MX29F022NB	MX29F022NB@PLCC32
[(SA015A1T)]	
MX29F022NB@TSOP32 [(SA410T)]	
MX29F022NT	
MX29F022NT@PLCC32 [(SA015A1T)]	MX29F022NT@TSOP32
[(SA410T)]	
MX29F022T	MX29F022T@PLCC32
[(SA015A1T)]	
MX29F022T@TSOP32 [(SA410T)]	
MX29F040	
MX29F040@PLCC32 [(SA015A1T)]	MX29F040@TSOP32
[(SA410T)]	
MX29F040C	MX29F040C@PLCC32
[(SA015A1T)]	
MX29F040C@TSOP32 [(SA410T)]	MX29F080@PSOP44
[(SA638)]	
MX29F080@TSOP40 [(SA409T)]	MX29F100B@PSOP44 [(SA638-
B006)]	
MX29F100B@TSOP48 [(SA247-B005)]	MX29F100T@PSOP44 [(SA638-
B006)]	
MX29F100T@TSOP48 [(SA247-B005)]	MX29F1610@PSOP44
[(SA638)]	
MX29F1610@TSOP48 [(SA247-B005)]	MX29F1610A@PSOP44
[(SA638)]	
MX29F1610A@TSOP48 [(SA247-B005)]	MX29F1610B@TSOP48 [(SA247-
B005)]	
MX29F1611@PSOP44 [(SA638)]	
MX29F1615	
MX29F200B@PSOP44 [(SA638-B006)]	MX29F200B@TSOP48 [(SA247-
B005)]	
MX29F200CB@PSOP44 [(SA638)]	MX29F200CB@TSOP48 [(SA247-
B005)]	
MX29F200CT@PSOP44 [(SA638)]	MX29F200CT@TSOP48 [(SA247-

B005) ]  
MX29F200T@PSOP44 [ (SA638-B006) ]                      MX29F200T@TSOP48 [ (SA247-B005) ]  
B005) ]  
MX29F4000    MX29F400B@PSOP44 [ (SA638-B006) ]  
B006) ]  
MX29F400B@TSOP48 [ (SA247-B005) ]                      MX29F400CB@PSOP44 [ (SA638) ]  
[ (SA638) ]  
MX29F400CB@TSOP48 [ (SA247-B005) ]                      MX29F400CT@PSOP44 [ (SA638) ]  
[ (SA638) ]  
MX29F400CT@TSOP48 [ (SA247-B005) ]                      MX29F400T@PSOP44 [ (SA638-B006) ]  
B006) ]  
MX29F400T@TSOP48 [ (SA247-B005) ]                      MX29F800B@PSOP44 [ (SA638-B006) ]  
B006) ]  
MX29F800B@TSOP48 [ (SA247-B005) ]                      MX29F800T@PSOP44 [ (SA638-B006) ]  
B006) ]  
MX29F800T@TSOP48 [ (SA247-B005) ]                      MX29L1611@PSOP44 [ (SA638) ]  
[ (SA638) ]  
MX29L1611@TSOP48 [ (SA247-B005) ]  
MX29L1611G  
MX29L3211@PSOP44 [ (SA638) ]                                      MX29L3211@TSOP48 [ (SA247-B005) ]  
B005) ]  
MX29LA128MB@TSOP56 [ (SA628-B102) ]  
MX29LA128MT@TSOP56 [ (SA628-B102) ]  
MX29LA129MH@TSOP56 [ (SA628-B018) ]  
MX29LA129ML@TSOP56 [ (SA628-B018) ]  
MX29LA320MB@CFBGA48 [ (SA642G-B026A-T048F001Y) ]  
MX29LA320MB@TSOP48 [ (SA247-B005) ]  
MX29LA320MT@CFBGA48 [ (SA642G-B026A-T048F001Y) ]  
MX29LA320MT@TSOP48 [ (SA247-B005) ]  
MX29LA321MB@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
MX29LA321MB@TSOP56 [ (SA628-B018) ]  
MX29LA321MH@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
MX29LA321MH@TSOP56 [ (SA628-B018) ]  
MX29LA321ML@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
MX29LA321ML@TSOP56 [ (SA628-B018) ]  
MX29LA321MT@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
MX29LA321MT@TSOP56 [ (SA628-B018) ]  
MX29LV002CB@PLCC32 [ (SA015A1T) ]                      MX29LV002CB@TSOP32 [ (SA410T) ]  
MX29LV002CT@PLCC32 [ (SA015A1T) ]                      MX29LV002CT@TSOP32 [ (SA410T) ]  
MX29LV002NCB@PLCC32 [ (SA015A1T) ]                      MX29LV002NCB@TSOP32 [ (SA410T) ]

MX29LV002NCT@PLCC32 [(SA015A1T)]	MX29LV002NCT@TSOP32
[(SA410T)]	
MX29LV004B@PLCC32 [(SA015A1T)]	MX29LV004B@TSOP40
[(SA409T)]	
MX29LV004CB@PLCC32 [(SA015A1T)]	MX29LV004CB@TSOP40
[(SA409T)]	
MX29LV004CT@PLCC32 [(SA015A1T)]	MX29LV004CT@TSOP40
[(SA409T)]	
MX29LV004T@PLCC32 [(SA015A1T)]	MX29LV004T@TSOP40
[(SA409T)]	
MX29LV008B@TSOP40 [(SA409T)]	MX29LV008BB@TSOP40
[(SA409T)]	
MX29LV008BT@TSOP40 [(SA409T)]	MX29LV008CB@TSOP40
[(SA409T)]	
MX29LV008CT@TSOP40 [(SA409T)]	MX29LV008T@TSOP40
[(SA409T)]	
MX29LV017AT@TSOP40 [(SA409T)]	
MX29LV017AX@CSP48 [(SA642G-B026A-T048F001)]	
MX29LV017BT@TSOP40 [(SA409T)]	
MX29LV017BX@CSP48 [(SA642G-B026A-T048F001)]	
MX29LV033T@TSOP40 [(SA409T)]	MX29LV040@PLCC32
[(SA015A1T)]	
MX29LV040@TSOP32 [(SA410T)]	MX29LV040C@PLCC32
[(SA015A1T)]	
MX29LV040C@TSOP32 [(SA410T)]	
MX29LV065BT@TSOP48 [(SA247-B005)]	
MX29LV065BXB@FBGA63 [(SA642M-B026A-W048F001)]	
MX29LV065M@TSOP48 [(SA247-B005)]	MX29LV081@TSOP40
[(SA409T)]	
MX29LV128DB@TSOP48 [(SA247-B005)]	
MX29LV128DB@TSOP56 [(SA628-B102)]	
MX29LV128DT@TSOP48 [(SA247-B005)]	
MX29LV128DT@TSOP56 [(SA628-B102)]	
MX29LV128MB@TSOP56 [(SA628-B102)]	
MX29LV128MH@TSOP56 [(SA628-B102)]	
MX29LV128ML@TSOP56 [(SA628-B102)]	
MX29LV128MT@TSOP56 [(SA628-B102)]	
MX29LV160AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]	
MX29LV160AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]	
MX29LV160AB@PSOP44 [(SA638)]	
MX29LV160AB@TSOP48 [(SA247-B005)]	
MX29LV160AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]	
MX29LV160AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]	

MX29LV160AT@PSOP44 [(SA638)]  
MX29LV160AT@TSOP48 [(SA247-B005)]  
MX29LV160B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160B@PSOP44 [(SA638)] MX29LV160B@TSOP48 [(SA247-B005)]  
MX29LV160BB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB@PSOP44 [(SA638)]  
MX29LV160BB@TSOP48 [(SA247-B005)]  
MX29LV160BT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT@PSOP44 [(SA638)]  
MX29LV160BT@TSOP48 [(SA247-B005)]  
MX29LV160CBM@PSOP44 [(SA638)]  
MX29LV160CBT@TSOP48 [(SA247-B005)]  
MX29LV160CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTM@PSOP44 [(SA638)]  
MX29LV160CTT@TSOP48 [(SA247-B005)]  
MX29LV160CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DBT@TSOP48 [(SA247-B005)]  
MX29LV160DBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DTT@TSOP48 [(SA247-B005)]  
MX29LV160DTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T@PSOP44 [(SA638)] MX29LV160T@TSOP48 [(SA247-B005)]  
MX29LV320ABT@TSOP48 [(SA247-B005)]  
MX29LV320ABXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ABXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ATT@TSOP48 [(SA247-B005)]  
MX29LV320ATXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ATXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320BT@TSOP48 [(SA247-B005)]  
MX29LV320BXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320BXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320CBB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CBE@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CBT@TSOP48 [(SA247-B005)]  
MX29LV320CTB@FBGA48 [(SA642G-B026A-T048F001Y)]



MX29LV320CTE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320DBB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DBE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320DTB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DTE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320MB@CFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320MB@PSOP44 [ ( SA638 ) ]  
MX29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
MX29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
MX29LV320MT@CFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320MT@PSOP44 [ ( SA638 ) ]  
MX29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320TT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320TXB@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320TXE@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV321DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV321DBXB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV321DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV321DTXB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400B@PSOP44 [ ( SA638 ) ]                      MX29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400BX(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400BX(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400CBM@PSOP44 [ ( SA638 ) ]  
MX29LV400CBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400CBXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CBXE(0.4)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CTM@PSOP44 [ ( SA638 ) ]  
MX29LV400CTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400CTXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CTXE(0.4)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400T@PSOP44 [ ( SA638 ) ]                      MX29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400TX(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400TX(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV640BBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640BBXB@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
MX29LV640BT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640BTT@TSOP48 [ ( SA247-B005 ) ]

MX29LV640BTXB@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
MX29LV640BUT@TSOP48 [ (SA247-B005) ]  
MX29LV640BUXB@FBGA63 [ (SA642M-B026A-W048F001) ]  
MX29LV640BXB@FBGA63 [ (SA642C-B026A-Y056F001) ]  
MX29LV640BXC@FBGA64 [ (SA655A-B044A-T064F001) ]  
MX29LV640DBT@TSOP48 [ (SA247-B005) ]  
MX29LV640DBX@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
MX29LV640DTT@TSOP48 [ (SA247-B005) ]  
MX29LV640DTX@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
MX29LV640EBT@TSOP48 [ (SA247-B005) ]  
MX29LV640EBX@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
MX29LV640ETT@TSOP48 [ (SA247-B005) ]  
MX29LV640ETX@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
MX29LV640MB@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
MX29LV640MB@TSOP48 [ (SA247-B005) ]  
MX29LV640MH@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
MX29LV640MH@TSOP56 [ (SA628-B067) ]  
MX29LV640ML@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
MX29LV640ML@TSOP56 [ (SA628-B067) ]  
MX29LV640MT@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
MX29LV640MT@TSOP48 [ (SA247-B005) ]  
MX29LV640TT@TSOP48 [ (SA247-B005) ]  
MX29LV640TXB@FBGA63 [ (SA642C-B026A-Y056F001) ]  
MX29LV640TXC@FBGA64 [ (SA655A-B044A-T064F001) ]  
MX29LV641MH@TSOP48 [ (SA247-B005) ]  
MX29LV641ML@TSOP48 [ (SA247-B005) ]  
MX29LV800AB(0.3)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV800AB(0.4)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV800AB@PSOP44 [ (SA638) ]  
MX29LV800AB@TSOP48 [ (SA247-B005) ]  
MX29LV800AT(0.3)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV800AT(0.4)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV800AT@PSOP44 [ (SA638) ]  
MX29LV800AT@TSOP48 [ (SA247-B005) ]  
MX29LV800B(0.3)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV800B(0.4)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV800B@PSOP44 [ (SA638) ] MX29LV800B@TSOP48 [ (SA247-B005) ]  
MX29LV800CBM@PSOP44 [ (SA638) ]  
MX29LV800CBT(Low)@TSOP48 [ (SA247-B005) ]  
MX29LV800CBT@TSOP48 [ (SA247-B005) ]  
MX29LV800CBXB(0.3)@CSP48 [ (SA642G-B026A-T048F001Y) ]  
MX29LV800CBXE(0.4)@CSP48 [ (SA642G-B026A-T048F001Y) ]

MX29LV800CTM@PSOP44 [(SA638)]  
MX29LV800CTT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CTT@TSOP48 [(SA247-B005)]  
MX29LV800CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T@PSOP44 [(SA638)] MX29LV800T@TSOP48 [(SA247-B005)]  
MX29LW160BT@TSOP48 [(SA247-B005)]  
MX29LW160BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW160TT@TSOP48 [(SA247-B005)]  
MX29LW160TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161BT@TSOP48 [(SA247-B005)]  
MX29LW161BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161TT@TSOP48 [(SA247-B005)]  
MX29LW161TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320BT@TSOP48 [(SA247-B005)]  
MX29LW320BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320TT@TSOP48 [(SA247-B005)]  
MX29LW320TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321BT@TSOP48 [(SA247-B005)]  
MX29LW321BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321TT@TSOP48 [(SA247-B005)]  
MX29LW321TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29SL800CB@TSOP48 [(SA247-B005)]  
MX29SL800CBXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
MX29SL800CT@TSOP48 [(SA247-B005)]  
MX29SL800CTXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CTXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CTXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
MX69F1602C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69F1602C3TX@FBGA72 [(SA642E-B041A-T072F001)]

MX69F1604C3BX@FBGA72 [ (SA642E-B041A-T072F001) ]  
MX69F1604C3TX@FBGA72 [ (SA642E-B041A-T072F001) ]  
MX69LW162BXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW162TXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW164BXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW164TXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW322BXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW322TXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW324BXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW324TXB@CSP69 [ (SA642A-B032A-Y096F001) ]

## MICROCONTROLLER

MX10E8050I  
[ (SA244) ]  
MX10E8050I@TQFP44 [ (SA245A) ]  
[ (SA244) ]  
MX10EXA@TQFP44 [ (SA245A) ]  
MX10F201FC@TQFP100(\*) [ (TA010-B006) ]  
MX10F202FC@TQFP100(\*) [ (TA010-B006) ]  
MX10FLCD  
MX10FMAXD  
MX10FMAXD@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
MX10E8050I@PLCC44  
MX10EXA@PLCC44  
MX10FMAXD@TQFP44

## MAXIM

### E ( E ) PROM / FRAM / NVRAM

DS1220AB  
DS1220AD  
DS1220Y  
DS1225AB  
DS1225AD  
DS1225D  
DS1225E  
DS1225Y  
DS1230AB  
DS1230W  
DS1230Y  
DS1235AB

DS1235Y  
DS1243Y  
DS1244  
DS1244Y  
DS1245AB  
DS1245EE  
DS1245P  
DS1245W  
DS1245Y  
DS1248P  
DS1248W  
DS1248Y  
DS1249AB  
DS1249W  
DS1249Y  
DS1250AB  
DS1250W  
DS1250Y  
DS1251AB  
DS1251W  
DS1251Y  
DS1256P  
DS1256W  
DS1256Y  
DS1258AB  
DS1258W  
DS1258Y  
DS1265AB  
DS1265W  
DS1265Y  
DS1270AB  
DS1270W  
DS1270Y  
DS1284  
DS1284N  
[ (SA008A) ]  
DS1284QN@PLCC28 [ (SA008A) ]  
DS1286  
DS1286I  
DS1287  
DS1287A  
DS12887  
DS12887A

DS1284Q@PLCC28

DS12C887  
DS12C887A  
( 32K)  
DS1386 ( 8K)  
DS1485  
DS1485@SOIC28 [ ( SA630 ) ]  
DS1488  
DS1553  
DS1553W  
DS1554  
DS1554W  
DS1556  
DS1642  
DS1643  
DS1644  
DS1644P  
DS1645AB  
DS1645EE  
DS1645Y  
DS1646  
DS1647  
DS1647LPM  
DS1650AB  
DS1650Y  
3  
DS1687-5  
3  
DS17287-5  
DS1742  
DS1742W  
DS1743  
DS1743P  
DS1743W  
DS1743WP  
DS1744  
DS1744P  
DS1744W  
DS1744WP  
DS1746  
DS1747  
DS1747P  
DS1747W  
DS1747WP

DS1386

DS1687-

DS17287-

DS17487-3	DS17487-
5	
DS17887-3	DS17887-
5	
DS2430A@TO-92	DS2430AP@TSOC6
[ (SA602A) ]	
DS2431@TO-92	DS2431P@TSOC6
[ (SA602A) ]	
DS2432P@TSOC6 [ (SA602A) ]	DS2433@PR-
35	
DS2433S(3.9)@SOIC8 [ (SA602A) ]	DS2433S(5.5)@SOIC8
[ (SA605A) ]	
DS2502	DS2502P@TSOC6
[ (SA602A) ]	
DS2502S@SOIC8 [ (SA602A) ]	
DS2502UNW	
DS2502UNW@SOIC8 [ (SA602A) ]	DS2502UNW@TSOC6
[ (SA602A) ]	
DS2506	DS2506S@SOIC8
[ (SA023A) ]	
DS4510@uSOP10	DS4520@TSSOP16
[ (SA026) ]	
DS4550@TSSOP20 [ (SA026) ]	

## MICROCONTROLLER

DS87C520	DS87C520@PLCC44
[ (SA244) ]	
DS87C520@TQFP44 [ (SA245A) ]	DS89C420(rev.
A)	
DS89C420(rev.A)@PLCC44 [ (SA244) ]	
DS89C420(rev.A)@TQFP44 [ (SA245A) ]	

## MAXWELL

### E (E) PROM / FRAM / NVRAM

27C010T@LDFP32 [ (SA438T) ]	
28C010	
28C010@PLCC32 [ (SA015A1T) ]	28C010@TSOP32
[ (SA438T) ]	

28C010T [ (SA015A1T) ] 28C010T@TSOP32 [ (SA438T) ] 28C011 28C011@PLCC32 [ (SA015A1T) ] [ (SA438T) ] 28C011T [ (SA015A1T) ] 28C011T@TSOP32 [ (SA438T) ]	28C010T@PLCC32   28C011@TSOP32  28C011T@PLCC32
--	---

## MEGAWIN

### E ( E ) PROM / FRAM / NVRAM

MM25SB512@SOIC8 [ (SA602A) ] MM29F040 MM29F040@PLCC32 [ (SA015A1T) ] [ (SA410T) ] MM29LF040 [ (SA015A1T) ] MM29LF040@TSOP32 [ (SA410T) ]	MM29F040@TSOP32  MM29LF040@PLCC32
--	---

### MICROCONTROLLER

MPC89L516X2 [ (SA244) ] MPC89L516X2@TQFP44 [ (SA245A) ] MPC89L556X2 MPC89L556X2@PLCC44 [ (SA244) ] [ (SA245A) ]	MPC89L516X2@PLCC44  MPC89L556X2@TQFP44
--	--

## MEMOCOM

### E ( E ) PROM / FRAM / NVRAM

KI01602AB (Ga1) @FBGA66 [ (SA642R-B023A-T096F001Y) ] KI01602AB (Gb1) @FBGA66 [ (SA642E-B023A-T072001Y) ] KI01602AT (Ga1) @FBGA66 [ (SA642R-B023A-T096F001Y) ] KI01602AT (Gb1) @FBGA66 [ (SA642E-B023A-T072001Y) ]	
--	--



KI01604AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI01604AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI01604AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI01604AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI01608AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI01608AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI01608AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI01608AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03204AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03204AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03204AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03204AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03204BB@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03204BT@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03208AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03208AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03208AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03208AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03208BB@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03208BT@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KS01602AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01602AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01604AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01604AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03204AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03204AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03204CB@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03204CT@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03208AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03208AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03208BB@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03208BT@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KSP3216BB@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KSP3216BT@FBGA56 [(SA642P-B207A-W056F001Y)]

## MICON

### MICROCONTROLLER

MDT10P21(dip18)	MDT10P21
(dip20)	
MDT10P21(dip22)	MDT10P21@SOP18

[ (SA404A) ]	
MDT10P21@SOP20 [ (SA404A) ]	MDT10P21@SOP24
[ (SA404A) ]	
MDT10P22(dip18)	MDT10P22
(dip20)	
MDT10P22(dip22)	MDT10P22@SOP18
[ (SA404A) ]	
MDT10P22@SOP20 [ (SA404A) ]	MDT10P22@SOP24
[ (SA404A) ]	
MDT10P23(dip18)	MDT10P23
(dip20)	
MDT10P23(dip22)	MDT10P23@SOP18
[ (SA404A) ]	
MDT10P23@SOP20 [ (SA404A) ]	MDT10P23@SOP24
[ (SA404A) ]	
MDT10P61	MDT10P61@SOP18
[ (SA404A) ]	
MDT10P61@SSOP20 [ (SA626A) ]	
MDT2005	
MDT2005@SOP18 [ (SA404A) ]	MDT2005@SSOP20
[ (SA626A) ]	
MDT2010	MDT2010@SOP18
[ (SA404A) ]	
MDT2010@SSOP20 [ (SA626A) ]	
MDT2020	
MDT2020@SOP28 [ (SA404A) ]	MDT2020@SSOP28
[ (SA626A) ]	
MDT2030	MDT2030@SOP18
[ (SA404A) ]	
MDT2030@SSOP20 [ (SA626A) ]	
MDT2050	
MDT2050@SOP18 [ (SA404A) ]	MDT2050@SSOP20
[ (SA626A) ]	
MDT2051	MDT2051@SOP18
[ (SA404A) ]	
MDT2051@SSOP20 [ (SA626A) ]	
MDT2060	
MDT2060@SOP18 [ (SA404A) ]	MDT2060@SSOP20
[ (SA626A) ]	

## MICROCHIP

**E ( E ) PROM / FRAM / NVRAM**

24AA00	24AA00@SOIC8
[ ( SA602A ) ]	
24AA00@SOT-23 [ ( SA717 ) ]	24AA00@TSSOP8
[ ( SA026 ) ]	
24AA01	24AA01@SOIC8
[ ( SA602A ) ]	
24AA01@TSSOP8 [ ( SA026 ) ]	
24AA014	
24AA014@SOIC8 [ ( SA602A ) ]	24AA014@TSSOP8
[ ( SA026 ) ]	
24AA02	24AA02@DFN8
[ ( SA694 ) ]	
24AA02@MSOP8 [ ( SA666 ) ]	24AA02@SOIC8
[ ( SA602A ) ]	
24AA02@SOT-23-5 [ ( SA717 ) ]	24AA02@TSSOP8
[ ( SA026 ) ]	
24AA024	24AA024@DFN8
[ ( SA694 ) ]	
24AA024@MSOP8 [ ( SA666 ) ]	24AA024@SOIC8
[ ( SA602A ) ]	
24AA024@TSSOP8 [ ( SA026 ) ]	
24AA025	
24AA025@DFN8 [ ( SA694 ) ]	24AA025@MSOP8
[ ( SA666 ) ]	
24AA025@SOIC8 [ ( SA602A ) ]	24AA025@TSSOP8
[ ( SA026 ) ]	
24AA04	24AA04@SOIC8
[ ( SA602A ) ]	
24AA04@TSSOP8 [ ( SA026 ) ]	
24AA08	
24AA08@SOIC8 [ ( SA602A ) ]	24AA08@TSSOP8
[ ( SA026 ) ]	
24AA1025	24AA1025@SOIC8
[ ( SA602A ) ]	
24AA1025@TSSOP8 [ ( SA026 ) ]	
24AA128	
24AA128@MSOP8 [ ( SA666 ) ]	24AA128@SOIC8
[ ( SA602A ) ]	
24AA128@TSSOP14 [ ( SA026 ) ]	24AA128@TSSOP8
[ ( SA026 ) ]	
24AA16	24AA16@SOIC8

[ (SA602A) ]	
24AA16@TSSOP8 [ (SA026) ]	
24AA164	
24AA164@SOIC8 [ (SA602A) ]	24AA164@TSSOP8
[ (SA026) ]	
24AA174	
24AA174@SOIC8	
[ (SA602A) ]	
24AA174@TSSOP8 [ (SA026) ]	
24AA256	
24AA256@MSOP8 [ (SA666) ]	24AA256@SOIC8
[ (SA605A) ]	
24AA256@TSSOP14 [ (SA026) ]	24AA256@TSSOP8
[ (SA026) ]	
24AA32	
24AA32 (Rotated)@TSSOP8	
[ (SA026) ]	
24AA32@MSOP8 [ (SA666) ]	24AA32@SOIC8
[ (SA602A) ]	
24AA32@TSSOP8 [ (SA026) ]	
24AA32A	
24AA32A (Rotated)@TSSOP8 [ (SA026) ]	
24AA32A@MSOP8 [ (SA666) ]	24AA32A@SOIC8
[ (SA602A) ]	
24AA32A@TSSOP8 [ (SA026) ]	
24AA512	
24AA512@DFN8 [ (SA683) ]	24AA512@SOIC8
[ (SA605A) ]	
24AA512@TSSOP14 [ (SA602) ]	
24AA515	
24AA515@SOIC8 [ (SA605A) ]	
24AA52	
24AA52@DFN8 [ (SA694) ]	24AA52@MSOP8
[ (SA666) ]	
24AA52@SOIC8 [ (SA602A) ]	24AA52@TSSOP8
[ (SA026) ]	
24AA64	
24AA64 (Rotated)@TSSOP8	
[ (SA026) ]	
24AA64@MSOP8 [ (SA666) ]	24AA64@SOIC8
[ (SA602A) ]	
24AA64@TSSOP8 [ (SA026) ]	
24AA65	
24AA65@SOIC8 [ (SA602A) ]	24AA65@TSSOP8
[ (SA026) ]	
24C00	24C00@SOIC8

[ ( SA602A ) ]	
24C00@SOT-23 [ ( SA717 ) ]	24C00@TSSOP8
[ ( SA026 ) ]	
24C01	
24C01A	
24C01A@SOIC8 [ ( SA602A ) ]	
24C01C	
24C01C@SOIC8 [ ( SA602A ) ]	24C01C@TSSOP8
[ ( SA026 ) ]	
24C02	
24C02A	
24C02A@SOIC8 [ ( SA602A ) ]	
24C02C	
24C02C@SOIC8 [ ( SA602A ) ]	24C02C@TSSOP8
[ ( SA026 ) ]	
24C04	
24C04A	
24C04A@SOIC8 [ ( SA602A ) ]	24C04A@TSSOP8
[ ( SA026 ) ]	
24C08	24C08@SOIC8
[ ( SA602A ) ]	
24C08B	24C08B@SOIC8
[ ( SA602A ) ]	
24C16	24C16@SOIC8
[ ( SA602A ) ]	
24C16B	24C16B@SOIC8
[ ( SA602A ) ]	
24C32	24C32@SOIC8
[ ( SA602A ) ]	
24C64	24C64@SOIC8
[ ( SA602A ) ]	
24C64@TSSOP8 [ ( SA026 ) ]	
24C65	
24C65@SOIC8 [ ( SA602A ) ]	
24FC1025	
24FC1025@SOIC8 [ ( SA602A ) ]	24FC1025@TSSOP8
[ ( SA026 ) ]	
24FC128	24FC128@MSOP8
[ ( SA666 ) ]	
24FC128@SOIC8 [ ( SA602A ) ]	24FC128@TSSOP14
[ ( SA026 ) ]	
24FC128@TSSOP8 [ ( SA026 ) ]	
24FC256	

24FC256@MSOP8 [(SA666)]	24FC256@SOIC8
[(SA605A)]	
24FC256@TSSOP14 [(SA026)]	24FC256@TSSOP8
[(SA026)]	
24FC32	24FC32@SOIC8
[(SA602A)]	
24FC512	24FC512@DFN8
[(SA683)]	
24FC512@SOIC8 [(SA605A)]	24FC512@TSSOP14
[(SA602)]	
24FC515	24FC515@SOIC8
[(SA605A)]	
24FC65	24FC65@SOIC8
[(SA605A)]	
24LC00	24LC00@SOIC8
[(SA602A)]	
24LC00@SOT-23 [(SA717)]	24LC00@TSSOP8
[(SA026)]	
24LC01	
24LC014	
24LC014@SOIC8 [(SA602A)]	24LC014@TSSOP8
[(SA026)]	
24LC01B	24LC01B@SOIC8
[(SA602A)]	
24LC01B@TSSOP8 [(SA026)]	
24LC02	
24LC024	24LC024@SOIC8
[(SA602A)]	
24LC024@TSSOP8 [(SA026)]	
24LC025	
24LC025@SOIC8 [(SA602A)]	24LC025@TSSOP8
[(SA026)]	
24LC02B	24LC02B@DFN8
[(SA694)]	
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8
[(SA602A)]	
24LC02B@SOT-23-5 [(SA717)]	24LC02B@TSSOP8
[(SA026)]	
24LC04	
24LC04B	
24LC04B@SOIC8 [(SA602A)]	24LC04B@TSSOP8
[(SA026)]	
24LC08	

24LC08B	
24LC08B@SOIC8 [(SA602A)]	24LC08B@TSSOP8
[(SA026)]	
24LC1025	24LC1025@SOIC8
[(SA602A)]	
24LC1025@TSSOP8 [(SA026)]	
24LC128	
24LC128@MSOP8 [(SA666)]	24LC128@SOIC8
[(SA605A)]	
24LC128@TSSOP14 [(SA026)]	24LC128@TSSOP8
[(SA026)]	
24LC16	24LC16@MSOP8
[(SA605A)]	
24LC16@SOIC8 [(SA602A)]	
24LC164	
24LC164@SOIC8 [(SA602A)]	
24LC16B	
24LC16B@SOIC8 [(SA602A)]	24LC16B@TSSOP8
[(SA026)]	
24LC174	24LC174@SOIC8
[(SA602A)]	
24LC21	24LC21@SOIC8
[(SA602A)]	
24LC21A	24LC21A@SOIC8
[(SA602A)]	
24LC22A	24LC22A@SOIC8
[(SA602A)]	
24LC256	24LC256@MSOP8
[(SA666)]	
24LC256@SOIC8 [(SA605A)]	24LC256@TSSOP14
[(SA026)]	
24LC256@TSSOP8 [(SA026)]	
24LC32	
24LC32@SOIC8 [(SA602A)]	
24LC32A	
24LC32A@SOIC8 [(SA602A)]	24LC32A@TSSOP8
[(SA026)]	
24LC512	24LC512@DFN8
[(SA683)]	
24LC512@SOIC8 [(SA605A)]	24LC512@TSSOP14
[(SA602)]	
24LC515	24LC515@SOIC8
[(SA605A)]	

24LC64	24LC64 (Rotated)@TSSOP8
[(SA026)]	
24LC64@MSOP8 [(SA605A)]	24LC64@SOIC8
[(SA602A)]	
24LC64@TSSOP8 [(SA026)]	
24LC65	
24LC65@SOIC8 [(SA602A)]	
24LCS21	
24LCS21@SOIC8 [(SA602A)]	
24LCS21A	
24LCS21A@SOIC8 [(SA602A)]	
24LCS22	
24LCS22@SOIC8 [(SA602A)]	
24LCS22A	
24LCS22A@SOIC8 [(SA602A)]	
24LCS52	
24LCS52@DFN8 [(SA694)]	24LCS52@MSOP8
[(SA666)]	
24LCS52@SOIC8 [(SA602A)]	24LCS52@TSSOP8
[(SA026)]	
25AA010A	25AA010A@DFN8
[(SA683)]	
25AA010A@MSOP8 [(SA605A)]	25AA010A@SOIC8
[(SA602A)]	
25AA010A@SOT-23 [(SA698)]	25AA010A@TSSOP8
[(SA026)]	
25AA010A[X-Rotated]@TSSOP8 [(SA026)]	
25AA020A	25AA020A@DFN8
[(SA683)]	
25AA020A@MSOP8 [(SA605A)]	25AA020A@SOIC8
[(SA602A)]	
25AA020A@SOT-23 [(SA698)]	25AA020A@TSSOP8
[(SA026)]	
25AA020A[X-Rotated]@TSSOP8 [(SA026)]	
25AA040	25AA040@SOIC8
[(SA602A)]	
25AA040@TSSOP8 [(SA026)]	
25AA040A	
25AA040A@DFN8 [(SA683)]	25AA040A@MSOP8
[(SA605A)]	
25AA040A@SOIC8 [(SA602A)]	25AA040A@SOT-23
[(SA698)]	
25AA040A@TSSOP8 [(SA026)]	



25AA040A[X-Rotated]@TSSOP8 [(SA026)]	
25AA080	25AA080@SOIC8
[(SA602A)]	
25AA080A	25AA080A@MSOP8
[(SA605A)]	
25AA080A@SOIC8 [(SA602A)]	25AA080A@TSSOP8
[(SA026)]	
25AA080B	25AA080B@MSOP8
[(SA605A)]	
25AA080B@SOIC8 [(SA602A)]	25AA080B@TSSOP8
[(SA026)]	
25AA1024	25AA1024@DFN8
[(SA683)]	
25AA1024@SOIC8 [(SA602A)]	25AA1024@SOIJ8
[(SA605)]	
25AA160	25AA160@SOIC8
[(SA602A)]	
25AA160A	25AA160A@MSOP8
[(SA605A)]	
25AA160A@SOIC8 [(SA602A)]	25AA160A@TSSOP8
[(SA026)]	
25AA160B	25AA160B@MSOP8
[(SA605A)]	
25AA160B@SOIC8 [(SA602A)]	25AA160B@TSSOP8
[(SA026)]	
25AA256	25AA256@DFN8
[(SA683)]	
25AA256@SOIC8(4.0) [(SA602A)]	25AA256@SOIC8(5.4)
[(SA605A)]	
25AA256@TSSOP8 [(SA026)]	
25AA256[X-Rotated]@TSSOP8 [(SA026)]	
25AA320	25AA320@SOIC8
[(SA602A)]	
25AA320@TSSOP14 [(SA026)]	25AA320@TSSOP8
[(SA026)]	
25AA512	25AA512@DFN8
[(SA683)]	
25AA512@SOIC8 [(SA602A)]	25AA512@SOIJ8
[(SA605)]	
25AA640	25AA640@SOIC8
[(SA602A)]	
25AA640@TSSOP8 [(SA026)]	
25C040	

25C040@SOIC8 [(SA602A)]	25C040@TSSOP8
[(SA026)]	
25C080	25C080@SOIC8
[(SA602A)]	
25C160	25C160@SOIC8
[(SA602A)]	
25C320	25C320@SOIC8
[(SA602A)]	
25C320@TSSOP14 [(SA026)]	25C320@TSSOP8
[(SA026)]	
25C640	25C640@SOIC8
[(SA602A)]	
25C640@TSSOP8 [(SA026)]	
25LC010A	
25LC010A@DFN8 [(SA683)]	25LC010A@MSOP8
[(SA605A)]	
25LC010A@SOIC8 [(SA602A)]	25LC010A@SOT-23
[(SA698)]	
25LC010A@TSSOP8 [(SA026)]	
25LC010A[X-Rotated]@TSSOP8 [(SA026)]	
25LC020A	25LC020A@DFN8
[(SA683)]	
25LC020A@MSOP8 [(SA605A)]	25LC020A@SOIC8
[(SA602A)]	
25LC020A@SOT-23 [(SA698)]	25LC020A@TSSOP8
[(SA026)]	
25LC020A[X-Rotated]@TSSOP8 [(SA026)]	
25LC040	25LC040@SOIC8
[(SA602A)]	
25LC040@TSSOP8 [(SA026)]	
25LC040A	
25LC040A@DFN8 [(SA683)]	25LC040A@MSOP8
[(SA605A)]	
25LC040A@SOIC8 [(SA602A)]	25LC040A@SOT-23
[(SA698)]	
25LC040A@TSSOP8 [(SA026)]	
25LC040A[X-Rotated]@TSSOP8 [(SA026)]	
25LC080	25LC080@SOIC8
[(SA602A)]	
25LC080A	25LC080A@MSOP8
[(SA605A)]	
25LC080A@SOIC8 [(SA602A)]	25LC080A@TSSOP8
[(SA026)]	

25LC080B [ (SA605A) ]	25LC080B@MSOP8
25LC080B@SOIC8 [ (SA602A) ] [ (SA026) ]	25LC080B@TSSOP8
25LC1024 [ (SA683) ]	25LC1024@DFN8
25LC1024@SOIC8 [ (SA602A) ] [ (SA605) ]	25LC1024@SOIJ8
25LC160 [ (SA602A) ]	25LC160@SOIC8
25LC160A [ (SA605A) ]	25LC160A@MSOP8
25LC160A@SOIC8 [ (SA602A) ] [ (SA026) ]	25LC160A@TSSOP8
25LC160B [ (SA605A) ]	25LC160B@MSOP8
25LC160B@SOIC8 [ (SA602A) ] [ (SA026) ]	25LC160B@TSSOP8
25LC256 [ (SA683) ]	25LC256@DFN8
25LC256@SOIC8(4.0) [ (SA602A) ] [ (SA605A) ]	25LC256@SOIC8(5.4)
25LC256@TSSOP8 [ (SA026) ]	
25LC256[X-Rotated]@TSSOP8 [ (SA026) ]	
25LC320 [ (SA602A) ]	25LC320(SN)@SOIC8
25LC320@TSSOP14 [ (SA026) ] [ (SA026) ]	25LC320@TSSOP8
25LC512 [ (SA683) ]	25LC512@DFN8
25LC512@SOIC8 [ (SA602A) ] [ (SA605) ]	25LC512@SOIJ8
25LC640 [ (SA602A) ]	25LC640@SOIC8
25LC640@TSSOP8 [ (SA026) ]	
27256	
27256@PLCC32 [ (SA015A1T) ]	
27C128	
27C128@PLCC32 [ (SA015A1T) ]	
27C128A	
27C128A@PLCC32 [ (SA015A1T) ]	
27C256	
27C256@PLCC32 [ (SA015A1T) ]	

27C32A  
27C512 27C512@PLCC32  
[(SA015A1T)]  
27C512A 27C512A@PLCC32  
[(SA015A1T)]  
27C513  
27C64  
27C64@PLCC32 [(SA015A1T)] 27C64@SOIC28  
[(SA404)]  
27HC1616 27HC1616@PLCC44  
[(SA244)]  
27HC1616L 27HC1616L@PLCC44  
[(SA244)]  
27HC191 27HC191@PLCC28  
[(SA008A)]  
27HC191@SOIC24 [(SA404)]  
27HC256  
27HC256@PLCC32 [(SA015A1T)]  
27HC256L  
27HC256L@PLCC32 [(SA015A1T)]  
27HC291  
27HC291@PLCC28 [(SA008A)] 27HC291@SOIC24  
[(SA404)]  
27HC416  
27HC64  
27HC64@PLCC32 [(SA015A1T)] 27HC64@SOIC28  
[(SA404)]  
27HC641 27HC641@PLCC28  
[(SA008A)]  
27HC641@SOIC24 [(SA404)]  
27HC641L  
27HC641L@PLCC28 [(SA008A)] 27HC641L@SOIC24  
[(SA404)]  
27HC64L 27HC64L@PLCC32  
[(SA015A1T)]  
27HC64L@SOIC28 [(SA404)]  
27LV256  
27LV256@PLCC32 [(SA015A1T)]  
27LV64  
2817  
2864  
2864@PLCC32 [(SA015A1T)]  
28C04

28C04@PLCC32 [ (SA015A1T) ]	28C04@SOIC24
[ (SA404) ]	
28C04A	28C04A@PLCC32
[ (SA015A1T) ]	
28C04A@SOIC24 [ (SA404) ]	
28C04AF	
28C04AF@PLCC32 [ (SA015A1T) ]	28C04AF@SOIC24
[ (SA404) ]	
28C04F	28C04F@PLCC32
[ (SA015A1T) ]	
28C04F@SOIC24 [ (SA404) ]	
28C16	
28C16@PLCC32 [ (SA015A1T) ]	28C16@SOIC24
[ (SA404) ]	
28C16A	28C16A@PLCC32
[ (SA015A1T) ]	
28C16A@SOIC24 [ (SA404) ]	
28C16AF	
28C16AF@PLCC32 [ (SA015A1T) ]	28C16AF@SOIC24
[ (SA404) ]	
28C16F	28C16F@PLCC32
[ (SA015A1T) ]	
28C16F@SOIC24 [ (SA404) ]	
28C17	
28C17@PLCC32 [ (SA015A1T) ]	28C17@SOIC28
[ (SA404) ]	
28C17A	28C17A@PLCC32
[ (SA015A1T) ]	
28C17A@SOIC28 [ (SA404) ]	
28C17AF	
28C17AF@PLCC32 [ (SA015A1T) ]	28C17AF@SOIC28
[ (SA404) ]	
28C17F	28C17F@PLCC32
[ (SA015A1T) ]	
28C17F@SOIC28 [ (SA404) ]	
28C256	
28C256@PLCC32 [ (SA015A1T) ]	
28C256F	
28C256F@PLCC32 [ (SA015A1T) ]	
28C64A	
28C64A@PLCC32 [ (SA015A1T) ]	28C64A@SOIC28
[ (SA404) ]	
28C64A@TSOP32 [ (SA410T) ]	

28C64AF	
28C64AF@PLCC32 [(SA015A1T)]	28C64AF@SOIC28
[(SA404)]	
28LV64A	28LV64A@PLCC32
[(SA015A1T)]	
28LV64A@SOIC28 [(SA404)]	
28PC64	
28PC64@PLCC32 [(SA015A1T)]	
59C11	
59C11@SOIC8 [(SA602A)]	
85C72	
85C72@SOIC8 [(SA602A)]	
85C82	
85C82@SOIC8 [(SA602A)]	
85C92	
85C92@SOIC8 [(SA602A)]	93AA46
(08bit)	
93AA46(08bit)@SOIC8 [(SA602A)]	93AA46
(16bit)	
93AA46(16bit)@SOIC8 [(SA602A)]	93AA46A
(08bit)	
93AA46A(08bit)@DFN8 [(BBBB)]	93AA46A(08bit)@MSOP8
[(SA666)]	
93AA46A(08bit)@SOIC8 [(SA602A)]	93AA46A(08bit)@SOT-23
[(SA717)]	
93AA46A(08bit)@TSSOP8 [(SA026)]	93AA46B
(16bit)	
93AA46B(16bit)@DFN8 [(BBBB)]	93AA46B(16bit)@MSOP8
[(SA666)]	
93AA46B(16bit)@SOIC8 [(SA602A)]	93AA46B(16bit)@SOT-23
[(SA717)]	
93AA46B(16bit)@TSSOP8 [(SA026)]	93AA46C
(08bit)	
93AA46C(08bit)@DFN8 [(BBBB)]	93AA46C(08bit)@MSOP8
[(SA666)]	
93AA46C(08bit)@SOIC8 [(SA602A)]	93AA46C(08bit)@TSSOP8
[(SA026)]	
93AA46C(16bit)	93AA46C(16bit)@DFN8
[(BBBB)]	
93AA46C(16bit)@MSOP8 [(SA666)]	93AA46C(16bit)@SOIC8
[(SA602A)]	
93AA46C(16bit)@TSSOP8 [(SA026)]	93AA56
(08bit)	

93AA56(08bit)@SOIC8 [(SA602A)] (16bit)	93AA56
93AA56(16bit)@SOIC8 [(SA602A)] (08bit)	93AA56A
93AA56A(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA56A(08bit)@MSOP8
93AA56A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA56A(08bit)@SOT-23
93AA56A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA56B
93AA56B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA56B(16bit)@MSOP8
93AA56B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA56B(16bit)@SOT-23
93AA56B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA56C
93AA56C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA56C(08bit)@MSOP8
93AA56C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA56C(08bit)@TSSOP8
93AA56C(16bit) [(BBBB)]	93AA56C(16bit)@DFN8
93AA56C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA56C(16bit)@SOIC8
93AA56C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA66
93AA66(08bit)@SOIC8 [(SA602A)] (16bit)	93AA66
93AA66(16bit)@SOIC8 [(SA602A)] (08bit)	93AA66A
93AA66A(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA66A(08bit)@MSOP8
93AA66A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA66A(08bit)@SOT-23
93AA66A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA66B
93AA66B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA66B(16bit)@MSOP8
93AA66B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA66B(16bit)@SOT-23
93AA66B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA66C
93AA66C(08bit)@DFN8 [(BBBB)]	93AA66C(08bit)@MSOP8

[(SA666)]	
93AA66C(08bit)@SOIC8 [(SA602A)]	93AA66C(08bit)@TSSOP8
[(SA026)]	
93AA66C(16bit)	93AA66C(16bit)@DFN8
[(BBBB)]	
93AA66C(16bit)@MSOP8 [(SA666)]	93AA66C(16bit)@SOIC8
[(SA602A)]	
93AA66C(16bit)@TSSOP8 [(SA026)]	93AA76
(08bit)	
93AA76(08bit)@SOIC8 [(SA602A)]	93AA76
(16bit)	
93AA76(16bit)@SOIC8 [(SA602A)]	93AA76A
(08bit)	
93AA76A(08bit)@DFN8 [(BBBB)]	93AA76A(08bit)@MSOP8
[(SA666)]	
93AA76A(08bit)@SOIC8 [(SA602A)]	93AA76A(08bit)@SOT-23
[(SA717)]	
93AA76A(08bit)@TSSOP8 [(SA026)]	93AA76B
(16bit)	
93AA76B(16bit)@DFN8 [(BBBB)]	93AA76B(16bit)@MSOP8
[(SA666)]	
93AA76B(16bit)@SOIC8 [(SA602A)]	93AA76B(16bit)@SOT-23
[(SA717)]	
93AA76B(16bit)@TSSOP8 [(SA026)]	93AA76C
(08bit)	
93AA76C(08bit)@DFN8 [(BBBB)]	93AA76C(08bit)@MSOP8
[(SA666)]	
93AA76C(08bit)@SOIC8 [(SA602A)]	93AA76C(08bit)@TSSOP8
[(SA026)]	
93AA76C(16bit)	93AA76C(16bit)@DFN8
[(BBBB)]	
93AA76C(16bit)@MSOP8 [(SA666)]	93AA76C(16bit)@SOIC8
[(SA602A)]	
93AA76C(16bit)@TSSOP8 [(SA026)]	93AA86
(08bit)	
93AA86(08bit)@SOIC8 [(SA602A)]	93AA86
(16bit)	
93AA86(16bit)@SOIC8 [(SA602A)]	93AA86A
(08bit)	
93AA86A(08bit)@DFN8 [(BBBB)]	93AA86A(08bit)@MSOP8
[(SSA666)]	
93AA86A(08bit)@SOIC8 [(SA602A)]	93AA86A(08bit)@SOT-23
[(SA717)]	



93AA86A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA86B
93AA86B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA86B(16bit)@MSOP8
93AA86B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA86B(16bit)@SOT-23
93AA86B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA86C
93AA86C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA86C(08bit)@MSOP8
93AA86C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA86C(08bit)@TSSOP8
93AA86C(16bit) [(BBBB)]	93AA86C(16bit)@DFN8
93AA86C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA86C(16bit)@SOIC8
93AA86C(16bit)@TSSOP8 [(SA026)] (08bit)	93C06
93C06(08bit)@SOIC8 [(SA602A)] (16bit)	93C06
93C06(16bit)@SOIC8 [(SA602A)] (08bit)	93C46
93C46(08bit)@SOIC8 [(SA602A)] (16bit)	93C46
93C46(16bit)@SOIC8 [(SA602A)] (08bit)	93C46A
93C46A(08bit)@DFN8 [(BBBB)] [(SA666)]	93C46A(08bit)@MSOP8
93C46A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C46A(08bit)@SOT-23
93C46A(08bit)@TSSOP8 [(SA026)] (16bit)	93C46B
93C46B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C46B(16bit)@MSOP8
93C46B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C46B(16bit)@SOT-23
93C46B(16bit)@TSSOP8 [(SA026)] (08bit)	93C46C
93C46C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C46C(08bit)@MSOP8
93C46C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C46C(08bit)@TSSOP8
93C46C(16bit)	93C46C(16bit)@DFN8

[ (BBBB) ]	
93C46C(16bit)@MSOP8 [ (SA666) ]	93C46C(16bit)@SOIC8
[ (SA602A) ]	
93C46C(16bit)@TSSOP8 [ (SA026) ]	93C56
(08bit)	
93C56(08bit)@SOIC8 [ (SA602A) ]	93C56
(16bit)	
93C56(16bit)@SOIC8 [ (SA602A) ]	93C56A
(08bit)	
93C56A(08bit)@DFN8 [ (BBBB) ]	93C56A(08bit)@MSOP8
[ (SA666) ]	
93C56A(08bit)@SOIC8 [ (SA602A) ]	93C56A(08bit)@SOT-23
[ (SA717) ]	
93C56A(08bit)@TSSOP8 [ (SA026) ]	93C56B
(16bit)	
93C56B(16bit)@DFN8 [ (BBBB) ]	93C56B(16bit)@MSOP8
[ (SA666) ]	
93C56B(16bit)@SOIC8 [ (SA602A) ]	93C56B(16bit)@SOT-23
[ (SA717) ]	
93C56B(16bit)@TSSOP8 [ (SA026) ]	93C56C
(08bit)	
93C56C(08bit)@DFN8 [ (BBBB) ]	93C56C(08bit)@MSOP8
[ (SA666) ]	
93C56C(08bit)@SOIC8 [ (SA602A) ]	93C56C(08bit)@TSSOP8
[ (SA026) ]	
93C56C(16bit)	93C56C(16bit)@DFN8
[ (BBBB) ]	
93C56C(16bit)@MSOP8 [ (SA666) ]	93C56C(16bit)@SOIC8
[ (SA602A) ]	
93C56C(16bit)@TSSOP8 [ (SA026) ]	93C66
(08bit)	
93C66(08bit)@SOIC8 [ (SA602A) ]	93C66
(16bit)	
93C66(16bit)@SOIC8 [ (SA602A) ]	93C66A
(08bit)	
93C66A(08bit)@DFN8 [ (BBBB) ]	93C66A(08bit)@MSOP8
[ (SA666) ]	
93C66A(08bit)@SOIC8 [ (SA602A) ]	93C66A(08bit)@SOT-23
[ (SA717) ]	
93C66A(08bit)@TSSOP8 [ (SA026) ]	93C66B
(16bit)	
93C66B(16bit)@DFN8 [ (BBBB) ]	93C66B(16bit)@MSOP8
[ (SA666) ]	

93C66B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C66B(16bit)@SOT-23
93C66B(16bit)@TSSOP8 [(SA026)] (08bit)	93C66C
93C66C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C66C(08bit)@MSOP8
93C66C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C66C(08bit)@TSSOP8
93C66C(16bit) [(BBBB)]	93C66C(16bit)@DFN8
93C66C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C66C(16bit)@SOIC8
93C66C(16bit)@TSSOP8 [(SA026)] (08bit)	93C76
93C76(08bit)@SOIC8 [(SA602A)] (16bit)	93C76
93C76(16bit)@SOIC8 [(SA602A)] (08bit)	93C76A
93C76A(08bit)@DFN8 [(BBBB)] [(SA666)]	93C76A(08bit)@MSOP8
93C76A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C76A(08bit)@SOT-23
93C76A(08bit)@TSSOP8 [(SA026)] (16bit)	93C76B
93C76B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C76B(16bit)@MSOP8
93C76B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C76B(16bit)@SOT-23
93C76B(16bit)@TSSOP8 [(SA026)] (08bit)	93C76C
93C76C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C76C(08bit)@MSOP8
93C76C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C76C(08bit)@TSSOP8
93C76C(16bit) [(BBBB)]	93C76C(16bit)@DFN8
93C76C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C76C(16bit)@SOIC8
93C76C(16bit)@TSSOP8 [(SA026)] (08bit)	93C86
93C86(08bit)@SOIC8 [(SA602A)] (16bit)	93C86
93C86(16bit)@SOIC8 [(SA602A)]	93C86A

(08bit)

93C86A(08bit)@DFN8 [(BBBB)]

93C86A(08bit)@MSOP8

[(SSA666)]

93C86A(08bit)@SOIC8 [(SA602A)]

93C86A(08bit)@SOT-23

[(SA717)]

93C86A(08bit)@TSSOP8 [(SA026)]

93C86B

(16bit)

93C86B(16bit)@DFN8 [(BBBB)]

93C86B(16bit)@MSOP8

[(SA666)]

93C86B(16bit)@SOIC8 [(SA602A)]

93C86B(16bit)@SOT-23

[(SA717)]

93C86B(16bit)@TSSOP8 [(SA026)]

93C86C

(08bit)

93C86C(08bit)@DFN8 [(BBBB)]

93C86C(08bit)@MSOP8

[(SA666)]

93C86C(08bit)@SOIC8 [(SA602A)]

93C86C(08bit)@TSSOP8

[(SA026)]

93C86C(16bit)

93C86C(16bit)@DFN8

[(BBBB)]

93C86C(16bit)@MSOP8 [(SA666)]

93C86C(16bit)@SOIC8

[(SA602A)]

93C86C(16bit)@TSSOP8 [(SA026)]

93LC46

(08bit)

93LC46(08bit)@SOIC8 [(SA602A)]

93LC46

(16bit)

93LC46(16bit)@SOIC8 [(SA602A)]

93LC46A

(08bit)

93LC46A(08bit)@DFN8 [(BBBB)]

93LC46A(08bit)@MSOP8

[(SA666)]

93LC46A(08bit)@SOIC8 [(SA602A)]

93LC46A(08bit)@SOT-23

[(SA717)]

93LC46A(08bit)@TSSOP8 [(SA026)]

93LC46B

(16bit)

93LC46B(16bit)@DFN8 [(BBBB)]

93LC46B(16bit)@MSOP8

[(SA666)]

93LC46B(16bit)@SOIC8 [(SA602A)]

93LC46B(16bit)@SOT-23

[(SA717)]

93LC46B(16bit)@TSSOP8 [(SA026)]

93LC46BX

93LC46BX@SOIC8 [(SA602A)]

93LC46C

(08bit)

93LC46C(08bit)@DFN8 [(BBBB)]

93LC46C(08bit)@MSOP8

[(SA666)]

93LC46C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93LC46C(08bit)@TSSOP8
93LC46C(16bit) [(BBBB)]	93LC46C(16bit)@DFN8
93LC46C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC46C(16bit)@SOIC8
93LC46C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC56
93LC56(08bit)@SOIC8 [(SA602A)] (16bit)	93LC56
93LC56(16bit)@SOIC8 [(SA602A)] (08bit)	93LC56A
93LC56A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC56A(08bit)@MSOP8
93LC56A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC56A(08bit)@SOT-23
93LC56A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC56B
93LC56B(16bit)@DFN8 [(BBBB)] [(SA666)]	93LC56B(16bit)@MSOP8
93LC56B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93LC56B(16bit)@SOT-23
93LC56B(16bit)@TSSOP8 [(SA026)]	
93LC56BX	
93LC56BX@SOIC8 [(SA602A)] (08bit)	93LC56C
93LC56C(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC56C(08bit)@MSOP8
93LC56C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93LC56C(08bit)@TSSOP8
93LC56C(16bit) [(BBBB)]	93LC56C(16bit)@DFN8
93LC56C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC56C(16bit)@SOIC8
93LC56C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC66
93LC66(08bit)@SOIC8 [(SA602A)] (16bit)	93LC66
93LC66(16bit)@SOIC8 [(SA602A)] (08bit)	93LC66A
93LC66A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC66A(08bit)@MSOP8
93LC66A(08bit)@SOIC8 [(SA602A)]	93LC66A(08bit)@SOT-23

[(SA717)]	
93LC66A(08bit)@TSSOP8 [(SA026)]	93LC66B
(16bit)	
93LC66B(16bit)@DFN8 [(BBBB)]	93LC66B(16bit)@MSOP8
[(SA666)]	
93LC66B(16bit)@SOIC8 [(SA602A)]	93LC66B(16bit)@SOT-23
[(SA717)]	
93LC66B(16bit)@TSSOP8 [(SA026)]	
93LC66BX	
93LC66BX@SOIC8 [(SA602A)]	93LC66C
(08bit)	
93LC66C(08bit)@DFN8 [(BBBB)]	93LC66C(08bit)@MSOP8
[(SA666)]	
93LC66C(08bit)@SOIC8 [(SA602A)]	93LC66C(08bit)@TSSOP8
[(SA026)]	
93LC66C(16bit)	93LC66C(16bit)@DFN8
[(BBBB)]	
93LC66C(16bit)@MSOP8 [(SA666)]	93LC66C(16bit)@SOIC8
[(SA602A)]	
93LC66C(16bit)@TSSOP8 [(SA026)]	93LC76
(08bit)	
93LC76(08bit)@SOIC8 [(SA602A)]	93LC76
(16bit)	
93LC76(16bit)@SOIC8 [(SA602A)]	93LC76A
(08bit)	
93LC76A(08bit)@DFN8 [(BBBB)]	93LC76A(08bit)@MSOP8
[(SA666)]	
93LC76A(08bit)@SOIC8 [(SA602A)]	93LC76A(08bit)@SOT-23
[(SA717)]	
93LC76A(08bit)@TSSOP8 [(SA026)]	93LC76B
(16bit)	
93LC76B(16bit)@DFN8 [(BBBB)]	93LC76B(16bit)@MSOP8
[(SA666)]	
93LC76B(16bit)@SOIC8 [(SA602A)]	93LC76B(16bit)@SOT-23
[(SA717)]	
93LC76B(16bit)@TSSOP8 [(SA026)]	93LC76C
(08bit)	
93LC76C(08bit)@DFN8 [(BBBB)]	93LC76C(08bit)@MSOP8
[(SA666)]	
93LC76C(08bit)@SOIC8 [(SA602A)]	93LC76C(08bit)@TSSOP8
[(SA026)]	
93LC76C(16bit)	93LC76C(16bit)@DFN8
[(BBBB)]	

93LC76C(16bit)@MSOP8 [(SA666)]	93LC76C(16bit)@SOIC8
[(SA602A)]	
93LC76C(16bit)@TSSOP8 [(SA026)]	93LC86
(08bit)	
93LC86(08bit)@SOIC8 [(SA602A)]	93LC86
(16bit)	
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86A
(08bit)	
93LC86A(08bit)@DFN8 [(BBBB)]	93LC86A(08bit)@MSOP8
[(SSA666)]	
93LC86A(08bit)@SOIC8 [(SA602A)]	93LC86A(08bit)@SOT-23
[(SA717)]	
93LC86A(08bit)@TSSOP8 [(SA026)]	93LC86B
(16bit)	
93LC86B(16bit)@DFN8 [(BBBB)]	93LC86B(16bit)@MSOP8
[(SA666)]	
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23
[(SA717)]	
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C
(08bit)	
93LC86C(08bit)@DFN8 [(BBBB)]	93LC86C(08bit)@MSOP8
[(SA666)]	
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8
[(SA026)]	
93LC86C(16bit)	93LC86C(16bit)@DFN8
[(BBBB)]	
93LC86C(16bit)@MSOP8 [(SA666)]	93LC86C(16bit)@SOIC8
[(SA602A)]	
93LC86C(16bit)@TSSOP8 [(SA026)]	
93LCS46	
93LCS46@SOIC14 [(SA026)]	93LCS46@SOIC8
[(SA602A)]	
93LCS56	93LCS56@SOIC14
[(SA026)]	
93LCS56@SOIC8 [(SA602A)]	
93LCS66	
93LCS66@SOIC14 [(SA026)]	93LCS66@SOIC8
[(SA602A)]	
ER5911	ER5911@SOIC8
[(SA602A)]	
HCS101	HCS101SN@SOIC8
[(SA602A)]	
HCS200	HCS200SN@SOIC8

[ (SA602A) ]  
HCS300 HCS300SN@SOIC8  
[ (SA602A) ]  
HCS301 HCS301SN@SOIC8  
[ (SA602A) ]  
HCS320 HCS320SN@SOIC8  
[ (SA602A) ]  
HCS360 HCS360SN@SOIC8  
[ (SA602A) ]  
HCS361 HCS361SN@SOIC8  
[ (SA602A) ]

## MICROCONTROLLER

MCP25020  
MCP25020(150mil)@SOIC14 [ (SA602) ]  
MCP25020(150mil)@SOIC14(ISP) [ ISP-HEADER01 ]  
MCP25020(208mil)@SOIC14 [ (SA404) ]  
MCP25020(208mil)@SOIC14(ISP) [ ISP-HEADER01 ]  
MCP25020(ISP) [ ISP-HEADER01 ]  
MCP25025  
MCP25025(150mil)@SOIC14 [ (SA602) ]  
MCP25025(150mil)@SOIC14(ISP) [ ISP-HEADER01 ]  
MCP25025(208mil)@SOIC14 [ (SA404) ]  
MCP25025(208mil)@SOIC14(ISP) [ ISP-HEADER01 ]  
MCP25025(ISP) [ ISP-HEADER01 ]  
MCP25050  
MCP25050(150mil)@SOIC14 [ (SA602) ]  
MCP25050(150mil)@SOIC14(ISP) [ ISP-HEADER01 ]  
MCP25050(208mil)@SOIC14 [ (SA404) ]  
MCP25050(208mil)@SOIC14(ISP) [ ISP-HEADER01 ]  
MCP25050(ISP) [ ISP-HEADER01 ]  
MCP25055  
MCP25055(150mil)@SOIC14 [ (SA602) ]  
MCP25055(150mil)@SOIC14(ISP) [ ISP-HEADER01 ]  
MCP25055(208mil)@SOIC14 [ (SA404) ]  
MCP25055(208mil)@SOIC14(ISP) [ ISP-HEADER01 ]  
MCP25055(ISP) [ ISP-HEADER01 ]  
PIC10F200  
PIC10F200(ISP) [ ISP-HEADER01 ] PIC10F200@SOT6  
[ (SA717) ]  
PIC10F200@SOT6(ISP) [ ISP-HEADER01 ]



```

PIC10F202                                PIC10F202(ISP) [ISP-
HEADER01]
PIC10F202@SOT6 [(SA717)]
PIC10F202@SOT6(ISP) [ISP-HEADER01]
PIC10F204                                PIC10F204(ISP) [ISP-
HEADER01]
PIC10F204@SOT6 [(SA717)]
PIC10F204@SOT6(ISP) [ISP-HEADER01]
PIC10F206                                PIC10F206(ISP) [ISP-
HEADER01]
PIC10F206@SOT6 [(SA717)]
PIC10F206@SOT6(ISP) [ISP-HEADER01]
PIC10F220                                PIC10F220(ISP) [ISP-
HEADER01]
PIC10F220@SOT6 [(SA717)]
PIC10F220@SOT6(ISP) [ISP-HEADER01]
PIC10F222                                PIC10F222(ISP) [ISP-
HEADER01]
PIC10F222@SOT6 [(SA717)]
PIC10F222@SOT6(ISP) [ISP-HEADER01]
PIC12C508                                PIC12C508(ISP) [ISP-
HEADER01]
PIC12C508@SOIC8 [(SA605A)]
PIC12C508@SOIC8(ISP) [ISP-HEADER01]
PIC12C508A                                PIC12C508A(ISP) [ISP-
HEADER01]
PIC12C508A(SM)@SOIC8 [(SA605A)]
PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C508A(SN)@SOIC8 [(SA602A)]
PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509                                PIC12C509(ISP) [ISP-
HEADER01]
PIC12C509(SM)@SOIC8 [(SA605A)]
PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509(SN)@SOIC8 [(SA602A)]
PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A                                PIC12C509A(ISP) [ISP-
HEADER01]
PIC12C509A(SM)@SOIC8 [(SA605A)]
PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A(SN)@SOIC8 [(SA602A)]
PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A@DFN8 [(SA683)]

```

PIC12C509A@DFN8 (ISP) [ISP-HEADER01]  
PIC12C671 PIC12C671 (ISP) [ISP-  
HEADER01]  
PIC12C671@DFN8 [(SA683)]  
PIC12C671@DFN8 (ISP) [ISP-HEADER01]  
PIC12C671@SOIC8 [(SA605A)]  
PIC12C671@SOIC8 (ISP) [ISP-HEADER01]  
PIC12C672 PIC12C672 (ISP) [ISP-  
HEADER01]  
PIC12C672@DFN8 [(SA683)]  
PIC12C672@DFN8 (ISP) [ISP-HEADER01]  
PIC12C672@SOIC8 [(SA605A)]  
PIC12C672@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE518 PIC12CE518 (ISP) [ISP-  
HEADER01]  
PIC12CE518@SOIC8 [(SA605A)]  
PIC12CE518@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE519 PIC12CE519 (ISP) [ISP-  
HEADER01]  
PIC12CE519 (SM)@SOIC8 [(SA605A)]  
PIC12CE519 (SM)@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE519 (SN)@SOIC8 [(SA602A)]  
PIC12CE519 (SN)@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE673 PIC12CE673 (ISP) [ISP-  
HEADER01]  
PIC12CE673@SOIC8 [(SA605A)]  
PIC12CE673@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE674 PIC12CE674 (ISP) [ISP-  
HEADER01]  
PIC12CE674@SOIC8 [(SA605A)]  
PIC12CE674@SOIC8 (ISP) [ISP-HEADER01]  
PIC12F508 PIC12F508 (ISP) [ISP-  
HEADER01]  
PIC12F508@MSOP8 [(SA666)]  
PIC12F508@MSOP8 (ISP) [ISP-HEADER01]  
PIC12F508@SOIC8 [(SA602)]  
PIC12F508@SOIC8 (ISP) [ISP-HEADER01]  
PIC12F509 PIC12F509 (ISP) [ISP-  
HEADER01]  
PIC12F509@MSOP8 [(SA666)]  
PIC12F509@MSOP8 (ISP) [ISP-HEADER01]  
PIC12F509@SOIC8 [(SA602)]  
PIC12F509@SOIC8 (ISP) [ISP-HEADER01]

PIC12F510 PIC12F510(ISP) [ISP-  
HEADER01]  
PIC12F510@MSOP8 [(SA666)]  
PIC12F510@MSOP8(ISP) [ISP-HEADER01]  
PIC12F510@SOIC8 [(SA605A)]  
PIC12F510@SOIC8(ISP) [ISP-HEADER01]  
PIC12F609 PIC12F609(ISP) [ISP-  
HEADER01]  
PIC12F609@DFN8 [(BBBB)]  
PIC12F609@DFN8(ISP) [ISP-HEADER01]  
PIC12F609@SOIC8 [(SA602A)]  
PIC12F609@SOIC8(ISP) [ISP-HEADER01]  
PIC12F615 PIC12F615(ISP) [ISP-  
HEADER01]  
PIC12F615@DFN8 [(BBBB)]  
PIC12F615@DFN8(ISP) [ISP-HEADER01]  
PIC12F615@SOIC8 [(SA602A)]  
PIC12F615@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629 PIC12F629(ISP) [ISP-  
HEADER01]  
PIC12F629(SM)@SOIC8 [(SA605A)]  
PIC12F629(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629(SN)@SOIC8 [(SA602A)]  
PIC12F629(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629@DFN8 [(SA683)]  
PIC12F629@DFN8(ISP) [ISP-HEADER01]  
PIC12F635 PIC12F635(ISP) [ISP-  
HEADER01]  
PIC12F635(MD)@DFN8 [(SA744)]  
PIC12F635(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(MF)@DFN8 [(SA683)]  
PIC12F635(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(SM)@SOIC8 [(SA605A)]  
PIC12F635(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F635(SN)@SOIC8 [(SA602A)]  
PIC12F635(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675 PIC12F675(ISP) [ISP-  
HEADER01]  
PIC12F675(SM)@SOIC8 [(SA605A)]  
PIC12F675(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675(SN)@SOIC8 [(SA602A)]  
PIC12F675(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675@DFN8 [(SA683)]

PIC12F675@DFN8(ISP) [ISP-HEADER01]  
PIC12F675@SSOP20 [(SA626A)]  
PIC12F675@SSOP20(ISP) [ISP-HEADER01]  
PIC12F683 PIC12F683(ISP) [ISP-  
HEADER01]  
PIC12F683(MD)@DFN8 [(SA744)]  
PIC12F683(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(MF)@DFN8 [(SA683)]  
PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(SM)@SOIC8 [(SA605A)]  
PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F683(SN)@SOIC8 [(SA602A)]  
PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV609 PIC12HV609(ISP) [ISP-  
HEADER01]  
PIC12HV609@DFN8 [(BBBB)]  
PIC12HV609@DFN8(ISP) [ISP-HEADER01]  
PIC12HV609@SOIC8 [(SA602A)]  
PIC12HV609@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV615 PIC12HV615(ISP) [ISP-  
HEADER01]  
PIC12HV615@DFN8 [(BBBB)]  
PIC12HV615@DFN8(ISP) [ISP-HEADER01]  
PIC12HV615@SOIC8 [(SA602A)]  
PIC12HV615@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508 PIC12LC508(ISP) [ISP-  
HEADER01]  
PIC12LC508@SOIC8 [(SA605A)]  
PIC12LC508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A PIC12LC508A(ISP) [ISP-  
HEADER01]  
PIC12LC508A(SM)@SOIC8 [(SA605A)]  
PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A(SN)@SOIC8 [(SA602A)]  
PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509 PIC12LC509(ISP) [ISP-  
HEADER01]  
PIC12LC509(SM)@SOIC8 [(SA605A)]  
PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509(SN)@SOIC8 [(SA602A)]  
PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A PIC12LC509A(ISP) [ISP-  
HEADER01]

PIC12LC509A(SM)@SOIC8 [(SA605A)]  
PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A(SN)@SOIC8 [(SA602A)]  
PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC671 PIC12LC671(ISP) [ISP-  
HEADER01]  
PIC12LC671@DFN8 [(SA683)]  
PIC12LC671@DFN8(ISP) [ISP-HEADER01]  
PIC12LC671@SOIC8 [(SA605A)]  
PIC12LC671@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC672 PIC12LC672(ISP) [ISP-  
HEADER01]  
PIC12LC672@DFN8 [(SA683)]  
PIC12LC672@DFN8(ISP) [ISP-HEADER01]  
PIC12LC672@SOIC8 [(SA605A)]  
PIC12LC672@SOIC8(ISP) [ISP-HEADER01]  
PIC12LF508 PIC12LF508(ISP) [ISP-  
HEADER01]  
PIC12LF508@MSOP8 [(SA666)]  
PIC12LF508@MSOP8(ISP) [ISP-HEADER01]  
PIC12LF508@SOIC8 [(SA602)]  
PIC12LF508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LF509 PIC12LF509(ISP) [ISP-  
HEADER01]  
PIC12LF509@MSOP8 [(SA666)]  
PIC12LF509@MSOP8(ISP) [ISP-HEADER01]  
PIC12LF509@SOIC8 [(SA602)]  
PIC12LF509@SOIC8(ISP) [ISP-HEADER01]  
PIC14000 PIC14000(ISP) [ISP-  
HEADER01]  
PIC14000@SOIC28 [(SA404)]  
PIC14000@SOIC28(ISP) [ISP-HEADER01]  
PIC14000@SSOP28 [(SA626A)]  
PIC14000@SSOP28(ISP) [ISP-HEADER01]  
PIC16C432 PIC16C432(ISP) [ISP-  
HEADER01]  
PIC16C432@SSOP20 [(SA626A)]  
PIC16C432@SSOP20(ISP) [ISP-HEADER01]  
PIC16C433 PIC16C433(ISP) [ISP-  
HEADER01]  
PIC16C433@SOIC18 [(SA404)]  
PIC16C433@SOIC18(ISP) [ISP-HEADER01]  
PIC16C505 PIC16C505@SOIC14

[(SA602)]  
 PIC16C52 PIC16C52@SOIC18  
 [(SA404)]  
 PIC16C54 PIC16C54@SOIC18  
 [(SA404)]  
 PIC16C54A PIC16C54A@SOIC18  
 [(SA404)]  
 PIC16C54A@SSOP20 [(SA626A)]  
 PIC16C54B  
 PIC16C54B@SOIC18 [(SA404)] PIC16C54B@SSOP20  
 [(SA626A)]  
 PIC16C54C PIC16C54C@SOIC18  
 [(SA404)]  
 PIC16C54C@SSOP20 [(SA626A)]  
 PIC16C55  
 PIC16C55@SOIC28 [(SA404)]  
 PIC16C554  
 PIC16C554(ISP) [ISP-HEADER01] PIC16C554@SOIC18  
 [(SA404)]  
 PIC16C554@SOIC18(ISP) [ISP-HEADER01]  
 PIC16C554@SSOP20 [(SA626A)]  
 PIC16C554@SSOP20(ISP) [ISP-HEADER01]  
 PIC16C556 PIC16C556(ISP) [ISP-  
 HEADER01]  
 PIC16C556@SOIC18 [(SA404)]  
 PIC16C556@SOIC18(ISP) [ISP-HEADER01]  
 PIC16C558 PIC16C558(ISP) [ISP-  
 HEADER01]  
 PIC16C558@SOIC18 [(SA404)]  
 PIC16C558@SOIC18(ISP) [ISP-HEADER01]  
 PIC16C558@SSOP20 [(SA626A)]  
 PIC16C558@SSOP20(ISP) [ISP-HEADER01]  
 PIC16C55A PIC16C55A@SOIC28  
 [(SA404)]  
 PIC16C55A@SSOP28 [(SA626A)]  
 PIC16C56  
 PIC16C56@SOIC18 [(SA404)]  
 PIC16C56A  
 PIC16C56A@SOIC18 [(SA404)] PIC16C56A@SSOP20  
 [(SA626A)]  
 PIC16C57 PIC16C57@SOIC28  
 [(SA404)]  
 PIC16C57@SSOP28 [(SA626A)]

PIC16C57C

PIC16C57C@SOIC28 [(SA404)]

[(SA626A)]

PIC16C58

[(SA404)]

PIC16C58A

[(SA404)]

PIC16C58A@SSOP20 [(SA626A)]

PIC16C58B

PIC16C58B@SOIC18 [(SA404)]

[(SA626A)]

PIC16C61

HEADER01]

PIC16C61@SOIC18 [(SA404)]

PIC16C61@SOIC18(ISP) [ISP-HEADER01]

PIC16C62

HEADER01]

PIC16C62@SOIC28 [(SA404)]

PIC16C62@SOIC28(ISP) [ISP-HEADER01]

PIC16C62@SSOP28 [(SA626A)]

PIC16C62@SSOP28(ISP) [ISP-HEADER01]

PIC16C620

HEADER01]

PIC16C620@SOIC18 [(SA404)]

PIC16C620@SOIC18(ISP) [ISP-HEADER01]

PIC16C620A

HEADER01]

PIC16C620A@SOIC18 [(SA404)]

PIC16C620A@SOIC18(ISP) [ISP-HEADER01]

PIC16C620A@SSOP20 [(SA626A)]

PIC16C620A@SSOP20(ISP) [ISP-HEADER01]

PIC16C621

HEADER01]

PIC16C621@SOIC18 [(SA404)]

PIC16C621@SOIC18(ISP) [ISP-HEADER01]

PIC16C621A

HEADER01]

PIC16C621A@SOIC18 [(SA404)]

PIC16C621A@SOIC18(ISP) [ISP-HEADER01]

PIC16C621A@SSOP20 [(SA626A)]

PIC16C621A@SSOP20(ISP) [ISP-HEADER01]

PIC16C622

HEADER01]

PIC16C57C@SSOP28

PIC16C58@SOIC18

PIC16C58A@SOIC18

PIC16C58B@SSOP20

PIC16C61(ISP) [ISP-

PIC16C62(ISP) [ISP-

PIC16C620(ISP) [ISP-

PIC16C620A(ISP) [ISP-

PIC16C621(ISP) [ISP-

PIC16C621A(ISP) [ISP-

PIC16C622(ISP) [ISP-

PIC16C622@SOIC18 [(SA404)]  
PIC16C622@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A PIC16C622A(ISP) [ISP-  
HEADER01]  
PIC16C622A@SOIC18 [(SA404)]  
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A@SSOP20 [(SA626A)]  
PIC16C622A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C625 PIC16C625(ISP) [ISP-  
HEADER01]  
PIC16C625@SOIC18 [(SA404)]  
PIC16C625@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62A PIC16C62A(ISP) [ISP-  
HEADER01]  
PIC16C62A@SOIC28 [(SA404)]  
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62A@SSOP28 [(SA626A)]  
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C62B PIC16C62B(ISP) [ISP-  
HEADER01]  
PIC16C62B@SOIC28 [(SA404)]  
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62B@SSOP28 [(SA626A)]  
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C63 PIC16C63(ISP) [ISP-  
HEADER01]  
PIC16C63@SOIC28 [(SA404)]  
PIC16C63@SOIC28(ISP) [ISP-HEADER01]  
PIC16C63A PIC16C63A(ISP) [ISP-  
HEADER01]  
PIC16C63A@SOIC28 [(SA404)]  
PIC16C63A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C63A@SSOP28 [(SA626A)]  
PIC16C63A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C64 PIC16C64(ISP) [ISP-  
HEADER01]  
PIC16C64@PLCC44 [(SA244)]  
PIC16C64@PLCC44(ISP) [ISP-HEADER01]  
PIC16C64@TQFP44 [(SA245A)]  
PIC16C64@TQFP44(ISP) [ISP-HEADER01]  
PIC16C641 PIC16C641@SOIC28  
[(SA404)]  
PIC16C641@SSOP28 [(SA626A)]



PIC16C642  
 PIC16C642@SOIC28 [(SA404)] PIC16C642@SSOP28  
 [(SA626A)]  
 PIC16C64A PIC16C64A(ISP) [ISP-  
 HEADER01]  
 PIC16C64A@PLCC44 [(SA244)]  
 PIC16C64A@PLCC44(ISP) [ISP-HEADER01]  
 PIC16C64A@TQFP44 [(SA245A)]  
 PIC16C64A@TQFP44(ISP) [ISP-HEADER01]  
 PIC16C65 PIC16C65(ISP) [ISP-  
 HEADER01]  
 PIC16C65@PLCC44 [(SA244)]  
 PIC16C65@PLCC44(ISP) [ISP-HEADER01]  
 PIC16C65@TQFP44 [(SA245A)]  
 PIC16C65@TQFP44(ISP) [ISP-HEADER01]  
 PIC16C65A PIC16C65A(ISP) [ISP-  
 HEADER01]  
 PIC16C65A@PLCC44 [(SA244)]  
 PIC16C65A@PLCC44(ISP) [ISP-HEADER01]  
 PIC16C65A@TQFP44 [(SA245A)]  
 PIC16C65A@TQFP44(ISP) [ISP-HEADER01]  
 PIC16C65B PIC16C65B(ISP) [ISP-  
 HEADER01]  
 PIC16C65B@PLCC44 [(SA244)]  
 PIC16C65B@PLCC44(ISP) [ISP-HEADER01]  
 PIC16C65B@TQFP44 [(SA245A)]  
 PIC16C65B@TQFP44(ISP) [ISP-HEADER01]  
 PIC16C66 PIC16C66(ISP) [ISP-  
 HEADER01]  
 PIC16C66@SOIC28 [(SA404)]  
 PIC16C66@SOIC28(ISP) [ISP-HEADER01]  
 PIC16C661 PIC16C661@PLCC44  
 [(SA244)]  
 PIC16C661@TQFP44 [(SA245A)]  
 PIC16C662  
 PIC16C662@PLCC44 [(SA244)] PIC16C662@TQFP44  
 [(SA245A)]  
 PIC16C67 PIC16C67(ISP) [ISP-  
 HEADER01]  
 PIC16C67@PLCC44 [(SA244)]  
 PIC16C67@PLCC44(ISP) [ISP-HEADER01]  
 PIC16C67@TQFP44 [(SA245A)]  
 PIC16C67@TQFP44(ISP) [ISP-HEADER01]

PIC16C70 PIC16C70(ISP) [ISP-  
HEADER01]  
PIC16C70@SOIC18 [(SA404)]  
PIC16C70@SOIC18(ISP) [ISP-HEADER01]  
PIC16C71 PIC16C71(ISP) [ISP-  
HEADER01]  
PIC16C71@SOIC18 [(SA404)]  
PIC16C71@SOIC18(ISP) [ISP-HEADER01]  
PIC16C710 PIC16C710(ISP) [ISP-  
HEADER01]  
PIC16C710@SOIC18 [(SA404)]  
PIC16C710@SOIC18(ISP) [ISP-HEADER01]  
PIC16C710@SSOP20 [(SA626A)]  
PIC16C710@SSOP20(ISP) [ISP-HEADER01]  
PIC16C711 PIC16C711(ISP) [ISP-  
HEADER01]  
PIC16C711@SOIC18 [(SA404)]  
PIC16C711@SOIC18(ISP) [ISP-HEADER01]  
PIC16C711@SSOP20 [(SA626A)]  
PIC16C711@SSOP20(ISP) [ISP-HEADER01]  
PIC16C712 PIC16C712(ISP) [ISP-  
HEADER01]  
PIC16C712@SOIC18 [(SA404)]  
PIC16C712@SOIC18(ISP) [ISP-HEADER01]  
PIC16C712@SSOP20 [(SA626A)]  
PIC16C712@SSOP20(ISP) [ISP-HEADER01]  
PIC16C715 PIC16C715@SOIC18  
[(SA404)]  
PIC16C715@SSOP20 [(SA626A)]  
PIC16C716 PIC16C716@SOIC18  
PIC16C716(ISP) [ISP-HEADER01]  
[(SA404)]  
PIC16C716@SOIC18(ISP) [ISP-HEADER01]  
PIC16C716@SSOP20 [(SA626A)]  
PIC16C716@SSOP20(ISP) [ISP-HEADER01]  
PIC16C717 PIC16C717(ISP) [ISP-  
HEADER01]  
PIC16C717@SOIC18 [(SA404)]  
PIC16C717@SOIC18(ISP) [ISP-HEADER01]  
PIC16C717@SSOP20 [(SA626A)]  
PIC16C717@SSOP20(ISP) [ISP-HEADER01]  
PIC16C71A PIC16C71A(ISP) [ISP-  
HEADER01]

PIC16C71A@SOIC18 [(SA404)]  
PIC16C71A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C72 PIC16C72(ISP) [ISP-  
HEADER01]  
PIC16C72@SOIC28 [(SA404)]  
PIC16C72@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72@SSOP28 [(SA626A)]  
PIC16C72@SSOP28(ISP) [ISP-HEADER01]  
PIC16C72A PIC16C72A(ISP) [ISP-  
HEADER01]  
PIC16C72A@SOIC28 [(SA404)]  
PIC16C72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72A@SSOP28 [(SA626A)]  
PIC16C72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C73 PIC16C73(ISP) [ISP-  
HEADER01]  
PIC16C73@SOIC28 [(SA404)]  
PIC16C73@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73A PIC16C73A(ISP) [ISP-  
HEADER01]  
PIC16C73A@SOIC28 [(SA404)]  
PIC16C73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B PIC16C73B(ISP) [ISP-  
HEADER01]  
PIC16C73B@SOIC28 [(SA404)]  
PIC16C73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B@SSOP28 [(SA626A)]  
PIC16C73B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C74 PIC16C74(ISP) [ISP-  
HEADER01]  
PIC16C74@PLCC44 [(SA244)]  
PIC16C74@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74@TQFP44 [(SA245A)]  
PIC16C74@TQFP44(ISP) [ISP-HEADER01]  
PIC16C745 PIC16C745(ISP) [ISP-  
HEADER01]  
PIC16C745@SOIC28 [(SA404)]  
PIC16C745@SOIC28(ISP) [ISP-HEADER01]  
PIC16C74A PIC16C74A(ISP) [ISP-  
HEADER01]  
PIC16C74A@PLCC44 [(SA244)]  
PIC16C74A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74A@TQFP44 [(SA245A)]

PIC16C74A@TQFP44 (ISP) [ISP-HEADER01]  
PIC16C74B PIC16C74B(ISP) [ISP-  
HEADER01]  
PIC16C74B@MQFP44 [(SA675)]  
PIC16C74B@MQFP44(ISP) [ISP-HEADER01]  
PIC16C74B@PLCC44 [(SA244)]  
PIC16C74B@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74B@TQFP44 [(SA245A)]  
PIC16C74B@TQFP44(ISP) [ISP-HEADER01]  
PIC16C76 PIC16C76(ISP) [ISP-  
HEADER01]  
PIC16C76@SOIC28 [(SA404)]  
PIC16C76@SOIC28(ISP) [ISP-HEADER01]  
PIC16C765 PIC16C765(ISP) [ISP-  
HEADER01]  
PIC16C765@PLCC44 [(SA244)]  
PIC16C765@PLCC44(ISP) [ISP-HEADER01]  
PIC16C765@TQFP44 [(SA245A)]  
PIC16C765@TQFP44(ISP) [ISP-HEADER01]  
PIC16C77 PIC16C77(ISP) [ISP-  
HEADER01]  
PIC16C77@PLCC44 [(SA244)]  
PIC16C77@PLCC44(ISP) [ISP-HEADER01]  
PIC16C77@TQFP44 [(SA245A)]  
PIC16C77@TQFP44(ISP) [ISP-HEADER01]  
PIC16C770 PIC16C770(ISP) [ISP-  
HEADER01]  
PIC16C770@SOIC20 [(SA404)]  
PIC16C770@SOIC20(ISP) [ISP-HEADER01]  
PIC16C770@SSOP20 [(SA626A)]  
PIC16C770@SSOP20(ISP) [ISP-HEADER01]  
PIC16C771 PIC16C771(ISP) [ISP-  
HEADER01]  
PIC16C771@SOIC20 [(SA404)]  
PIC16C771@SOIC20(ISP) [ISP-HEADER01]  
PIC16C771@SSOP20 [(SA626A)]  
PIC16C771@SSOP20(ISP) [ISP-HEADER01]  
PIC16C773 PIC16C773(ISP) [ISP-  
HEADER01]  
PIC16C773@SOIC28 [(SA404)]  
PIC16C773@SOIC28(ISP) [ISP-HEADER01]  
PIC16C773@SSOP28 [(SA626A)]  
PIC16C773@SSOP28(ISP) [ISP-HEADER01]

PIC16C774 PIC16C774(ISP) [ISP-  
HEADER01]  
PIC16C774@PLCC44 [(SA244)]  
PIC16C774@PLCC44(ISP) [ISP-HEADER01]  
PIC16C774@TQFP44 [(SA675)]  
PIC16C774@TQFP44(ISP) [ISP-HEADER01]  
PIC16C781 PIC16C781(ISP) [ISP-  
HEADER01]  
PIC16C781@SOIC20 [(SA404)]  
PIC16C781@SOIC20(ISP) [ISP-HEADER01]  
PIC16C781@SSOP20 [(SA626A)]  
PIC16C781@SSOP20(ISP) [ISP-HEADER01]  
PIC16C782 PIC16C782(ISP) [ISP-  
HEADER01]  
PIC16C782@SOIC20 [(SA404)]  
PIC16C782@SOIC20(ISP) [ISP-HEADER01]  
PIC16C782@SSOP20 [(SA626A)]  
PIC16C782@SSOP20(ISP) [ISP-HEADER01]  
PIC16C84 PIC16C84(ISP) [ISP-  
HEADER01]  
PIC16C84@SOIC18 [(SA404)]  
PIC16C84@SOIC18(ISP) [ISP-HEADER01]  
PIC16C923@PLCC68(\*) [(SA648-B6807)]  
PIC16C923@PLCC68(ISP) [ISP-HEADER01]  
PIC16C923@SDIP64(ISP) [ISP-HEADER01]  
PIC16C923@TQFP64(ISP) [ISP-HEADER01]  
PIC16C924@PLCC68(\*) [(SA648-B6807)]  
PIC16C924@PLCC68(ISP) [ISP-HEADER01]  
PIC16C924@SDIP64(ISP) [ISP-HEADER01]  
PIC16C924@TQFP64(ISP) [ISP-HEADER01]  
PIC16C925@PLCC68(\*) [(SA648-B6807)]  
PIC16C925@PLCC68(ISP) [ISP-HEADER01]  
PIC16C925@TQFP64(ISP) [ISP-HEADER01]  
PIC16C926@PLCC68(\*) [(SA648-B6807)]  
PIC16C926@PLCC68(ISP) [ISP-HEADER01]  
PIC16C926@TQFP64(ISP) [ISP-HEADER01]  
PIC16CE623 PIC16CE623(ISP) [ISP-  
HEADER01]  
PIC16CE623@SOIC18 [(SA404)]  
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE624 PIC16CE624(ISP) [ISP-  
HEADER01]  
PIC16CE624@SOIC18 [(SA404)]

PIC16CE624@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625 PIC16CE625(ISP) [ISP-  
HEADER01]  
PIC16CE625@SOIC18 [(SA404)]  
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625@SSOP20 [(SA626A)]  
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]  
PIC16CR83 PIC16CR83(ISP) [ISP-  
HEADER01]  
PIC16CR83@SOIC18 [(SA404)]  
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]  
PIC16CR84 PIC16CR84(ISP) [ISP-  
HEADER01]  
PIC16CR84@SOIC18 [(SA404)]  
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F505 PIC16F505(ISP) [ISP-  
HEADER01]  
PIC16F505@SOIC14 [(SA602)]  
PIC16F505@SOIC14(ISP) [ISP-HEADER01]  
PIC16F505@TSSOP14 [(SA026)]  
PIC16F505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F506 PIC16F506(ISP) [ISP-  
HEADER01]  
PIC16F506@SOIC14 [(SA602)]  
PIC16F506@SOIC14(ISP) [ISP-HEADER01]  
PIC16F506@TSSOP14 [(SA026)]  
PIC16F506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F526 PIC16F526@SOIC14  
[(SA602)]  
PIC16F526@TSSOP14 [(SA026)]  
PIC16F54 PIC16F54@SOIC18  
[(SA404)]  
PIC16F54@SOIC18(ISP) [ISP-HEADER01]  
PIC16F54@SSOP20 [(SA626A)]  
PIC16F54@SSOP20(ISP) [ISP-HEADER01]  
PIC16F57 PIC16F57(ISP) [ISP-  
HEADER01]  
PIC16F57@SOIC28 [(SA404)]  
PIC16F57@SOIC28(ISP) [ISP-HEADER01]  
PIC16F57@SSOP28 [(SA626A)]  
PIC16F57@SSOP28(ISP) [ISP-HEADER01]  
PIC16F59 PIC16F59(ISP) [ISP-

HEADER01 ]  
PIC16F59@PLCC44 [ (SA244) ]  
PIC16F59@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16F59@TQFP44 [ (SA245A) ]  
PIC16F59@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16F610 PIC16F610(ISP) [ ISP-  
HEADER01 ]  
PIC16F610@QFN16 [ (SA727) ]  
PIC16F610@QFN16(ISP) [ ISP-HEADER01 ]  
PIC16F610@SOIC14 [ (SA602) ]  
PIC16F610@SOIC14(ISP) [ ISP-HEADER01 ]  
PIC16F610@TSSOP14 [ (SA026) ]  
PIC16F610@TSSOP14(ISP) [ ISP-HEADER01 ]  
PIC16F616 PIC16F616(ISP) [ ISP-  
HEADER01 ]  
PIC16F616@QFN16 [ (SA727) ]  
PIC16F616@QFN16(ISP) [ ISP-HEADER01 ]  
PIC16F616@SOIC14 [ (SA602) ]  
PIC16F616@SOIC14(ISP) [ ISP-HEADER01 ]  
PIC16F616@TSSOP14 [ (SA026) ]  
PIC16F616@TSSOP14(ISP) [ ISP-HEADER01 ]  
PIC16F627 PIC16F627(ISP) [ ISP-  
HEADER01 ]  
PIC16F627@SOIC18 [ (SA404) ]  
PIC16F627@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16F627@SSOP20 [ (SA626A) ]  
PIC16F627@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16F627A PIC16F627A(ISP) [ ISP-  
HEADER01 ]  
PIC16F627A@SOIC18 [ (SA404) ]  
PIC16F627A@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16F627A@SSOP20 [ (SA626A) ]  
PIC16F627A@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16F628 PIC16F628(ISP) [ ISP-  
HEADER01 ]  
PIC16F628@SOIC18 [ (SA404) ]  
PIC16F628@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16F628@SSOP20 [ (SA626A) ]  
PIC16F628@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16F628A PIC16F628A(ISP) [ ISP-  
HEADER01 ]  
PIC16F628A@SOIC18 [ (SA404) ]  
PIC16F628A@SOIC18(ISP) [ ISP-HEADER01 ]

PIC16F628A@SSOP20 [(SA626A)]  
PIC16F628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F630 PIC16F630(ISP) [ISP-  
HEADER01]  
PIC16F630@SOIC14 [(SA602)]  
PIC16F630@SOIC14(ISP) [ISP-HEADER01]  
PIC16F630@TSSOP14 [(SA026)]  
PIC16F630@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F631 PIC16F631(ISP) [ISP-  
HEADER01]  
PIC16F631@QFN20 [(SA692)]  
PIC16F631@QFN20(ISP) [ISP-HEADER01]  
PIC16F631@SOIC20 [(SA404)]  
PIC16F631@SOIC20(ISP) [ISP-HEADER01]  
PIC16F631@SSOP20 [(SA626A)]  
PIC16F631@SSOP20(ISP) [ISP-HEADER01]  
PIC16F636 PIC16F636(ISP) [ISP-  
HEADER01]  
PIC16F636@QFN16 [(SA727)]  
PIC16F636@QFN16(ISP) [ISP-HEADER01]  
PIC16F636@SOIC14 [(SA602)]  
PIC16F636@SOIC14(ISP) [ISP-HEADER01]  
PIC16F636@TSSOP14 [(SA026)]  
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F639 PIC16F639(ISP) [ISP-  
HEADER01]  
PIC16F639@QFN20 [(SA692)]  
PIC16F639@QFN20(ISP) [ISP-HEADER01]  
PIC16F639@SOIC20 [(SA404)]  
PIC16F639@SOIC20(ISP) [ISP-HEADER01]  
PIC16F639@SSOP20 [(SA626A)]  
PIC16F639@SSOP20(ISP) [ISP-HEADER01]  
PIC16F648A PIC16F648A(ISP) [ISP-  
HEADER01]  
PIC16F648A@SOIC18 [(SA404)]  
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F648A@SSOP20 [(SA626A)]  
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F676 PIC16F676(ISP) [ISP-  
HEADER01]  
PIC16F676@SOIC14 [(SA602)]  
PIC16F676@SOIC14(ISP) [ISP-HEADER01]  
PIC16F676@TSSOP14 [(SA026)]



PIC16F676@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F677 PIC16F677(ISP) [ISP-  
HEADER01]  
PIC16F677@QFN20 [(SA692)]  
PIC16F677@QFN20(ISP) [ISP-HEADER01]  
PIC16F677@SOIC20 [(SA404)]  
PIC16F677@SOIC20(ISP) [ISP-HEADER01]  
PIC16F677@SSOP20 [(SA626A)]  
PIC16F677@SSOP20(ISP) [ISP-HEADER01]  
PIC16F684 PIC16F684(ISP) [ISP-  
HEADER01]  
PIC16F684@QFN16 [(SA727)]  
PIC16F684@QFN16(ISP) [ISP-HEADER01]  
PIC16F684@SOIC14 [(SA602)]  
PIC16F684@SOIC14(ISP) [ISP-HEADER01]  
PIC16F684@TSSOP14 [(SA026)]  
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F685 PIC16F685(ISP) [ISP-  
HEADER01]  
PIC16F685@QFN20 [(SA692)]  
PIC16F685@QFN20(ISP) [ISP-HEADER01]  
PIC16F685@SOIC20 [(SA404)]  
PIC16F685@SOIC20(ISP) [ISP-HEADER01]  
PIC16F685@SSOP20 [(SA626A)]  
PIC16F685@SSOP20(ISP) [ISP-HEADER01]  
PIC16F687 PIC16F687(ISP) [ISP-  
HEADER01]  
PIC16F687@QFN20 [(SA692)]  
PIC16F687@QFN20(ISP) [ISP-HEADER01]  
PIC16F687@SOIC20 [(SA404)]  
PIC16F687@SOIC20(ISP) [ISP-HEADER01]  
PIC16F687@SSOP20 [(SA626A)]  
PIC16F687@SSOP20(ISP) [ISP-HEADER01]  
PIC16F688 PIC16F688(ISP) [ISP-  
HEADER01]  
PIC16F688@QFN16 [(SA727)]  
PIC16F688@QFN16(ISP) [ISP-HEADER01]  
PIC16F688@SOIC14 [(SA602)]  
PIC16F688@SOIC14(ISP) [ISP-HEADER01]  
PIC16F688@TSSOP14 [(SA026)]  
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F689 PIC16F689(ISP) [ISP-  
HEADER01]

PIC16F689@QFN20 [(SA692)]  
PIC16F689@QFN20(ISP) [ISP-HEADER01]  
PIC16F689@SOIC20 [(SA404)]  
PIC16F689@SOIC20(ISP) [ISP-HEADER01]  
PIC16F689@SSOP20 [(SA626A)]  
PIC16F689@SSOP20(ISP) [ISP-HEADER01]  
PIC16F690 PIC16F690(ISP) [ISP-  
HEADER01]  
PIC16F690@QFN20 [(SA692)]  
PIC16F690@QFN20(ISP) [ISP-HEADER01]  
PIC16F690@SOIC20 [(SA404)]  
PIC16F690@SOIC20(ISP) [ISP-HEADER01]  
PIC16F690@SSOP20 [(SA626A)]  
PIC16F690@SSOP20(ISP) [ISP-HEADER01]  
PIC16F716 PIC16F716(ISP) [ISP-  
HEADER01]  
PIC16F716@SOIC18 [(SA404)]  
PIC16F716@SOIC18(ISP) [ISP-HEADER01]  
PIC16F716@SSOP20 [(SA626A)]  
PIC16F716@SSOP20(ISP) [ISP-HEADER01]  
PIC16F72 PIC16F72(ISP) [ISP-  
HEADER01]  
PIC16F72@QFN28 [(SA685-B006)]  
PIC16F72@QFN28(ISP) [ISP-HEADER01]  
PIC16F72@SOIC28 [(SA404)]  
PIC16F72@SOIC28(ISP) [ISP-HEADER01]  
PIC16F72@SSOP28 [(SA626A)]  
PIC16F72@SSOP28(ISP) [ISP-HEADER01]  
PIC16F722 PIC16F722@QFN28 [(SA685-  
B006)]  
PIC16F722@SOIC28 [(SA404)] PIC16F722@SSOP28  
[(SA626A)]  
PIC16F723 PIC16F723@QFN28 [(SA685-  
B006)]  
PIC16F723@SOIC28 [(SA404)] PIC16F723@SSOP28  
[(SA626A)]  
PIC16F724 PIC16F724@QFN44  
[(SA737)]  
PIC16F724@TQFP44 [(SA245A)]  
PIC16F726 PIC16F726@SOIC28  
PIC16F726@QFN28 [(SA685-B006)]  
[(SA404)]  
PIC16F726@SSOP28 [(SA626A)]

PIC16F727  
PIC16F727@QFN44 [(SA737)]  
[(SA245A)]  
PIC16F73  
HEADER01]  
PIC16F73@SOIC28 [(SA404)]  
PIC16F73@SOIC28(ISP) [ISP-HEADER01]  
PIC16F73@SSOP28 [(SA626A)]  
PIC16F73@SSOP28(ISP) [ISP-HEADER01]  
PIC16F737  
HEADER01]  
PIC16F737@SOIC28 [(SA404)]  
PIC16F737@SOIC28(ISP) [ISP-HEADER01]  
PIC16F737@SSOP28 [(SA626A)]  
PIC16F737@SSOP28(ISP) [ISP-HEADER01]  
PIC16F74  
HEADER01]  
PIC16F74@PLCC44 [(SA244)]  
PIC16F74@PLCC44(ISP) [ISP-HEADER01]  
PIC16F74@TQFP44 [(SA245A)]  
PIC16F74@TQFP44(ISP) [ISP-HEADER01]  
PIC16F747  
HEADER01]  
PIC16F747@TQFP44 [(SA245A)]  
PIC16F747@TQFP44(ISP) [ISP-HEADER01]  
PIC16F76  
HEADER01]  
PIC16F76@SOIC28 [(SA404)]  
PIC16F76@SOIC28(ISP) [ISP-HEADER01]  
PIC16F76@SSOP28 [(SA626A)]  
PIC16F76@SSOP28(ISP) [ISP-HEADER01]  
PIC16F767  
HEADER01]  
PIC16F767@SOIC28 [(SA404)]  
PIC16F767@SOIC28(ISP) [ISP-HEADER01]  
PIC16F767@SSOP28 [(SA626A)]  
PIC16F767@SSOP28(ISP) [ISP-HEADER01]  
PIC16F77  
HEADER01]  
PIC16F77@PLCC44 [(SA244)]  
PIC16F77@PLCC44(ISP) [ISP-HEADER01]  
PIC16F77@TQFP44 [(SA245A)]  
PIC16F77@TQFP44(ISP) [ISP-HEADER01]

PIC16F727@TQFP44  
PIC16F73(ISP) [ISP-  
PIC16F737(ISP) [ISP-  
PIC16F74(ISP) [ISP-  
PIC16F747(ISP) [ISP-  
PIC16F76(ISP) [ISP-  
PIC16F767(ISP) [ISP-  
PIC16F77(ISP) [ISP-

PIC16F777 PIC16F777(ISP) [ISP-  
HEADER01]  
PIC16F777@TQFP44 [(SA245A)]  
PIC16F777@TQFP44(ISP) [ISP-HEADER01]  
PIC16F785 PIC16F785(ISP) [ISP-  
HEADER01]  
PIC16F785@QFN20 [(SA692)]  
PIC16F785@QFN20(ISP) [ISP-HEADER01]  
PIC16F785@SOIC20 [(SA404)]  
PIC16F785@SOIC20(ISP) [ISP-HEADER01]  
PIC16F785@SSOP20 [(SA626A)]  
PIC16F785@SSOP20(ISP) [ISP-HEADER01]  
PIC16F818 PIC16F818(ISP) [ISP-  
HEADER01]  
PIC16F818@QFN28 [(SA685-B006)]  
PIC16F818@QFN28(ISP) [ISP-HEADER01]  
PIC16F818@SOIC18 [(SA404)]  
PIC16F818@SOIC18(ISP) [ISP-HEADER01]  
PIC16F818@SSOP20 [(SA626A)]  
PIC16F818@SSOP20(ISP) [ISP-HEADER01]  
PIC16F819 PIC16F819(ISP) [ISP-  
HEADER01]  
PIC16F819@QFN28 [(SA685-B006)]  
PIC16F819@QFN28(ISP) [ISP-HEADER01]  
PIC16F819@SOIC18 [(SA404)]  
PIC16F819@SOIC18(ISP) [ISP-HEADER01]  
PIC16F819@SSOP20 [(SA626A)]  
PIC16F819@SSOP20(ISP) [ISP-HEADER01]  
PIC16F83 PIC16F83(ISP) [ISP-  
HEADER01]  
PIC16F83@SOIC18 [(SA404)]  
PIC16F83@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84 PIC16F84(ISP) [ISP-  
HEADER01]  
PIC16F84@SOIC18 [(SA404)]  
PIC16F84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A PIC16F84A(ISP) [ISP-  
HEADER01]  
PIC16F84A@SOIC18 [(SA404)]  
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A@SSOP20 [(SA626A)]  
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F87 PIC16F87(ISP) [ISP-

HEADER01 ]  
PIC16F87@QFN28 [(SA685-B006)]  
PIC16F87@QFN28(ISP) [ISP-HEADER01]  
PIC16F87@SOIC18 [(SA404)]  
PIC16F87@SOIC18(ISP) [ISP-HEADER01]  
PIC16F87@SSOP20 [(SA626A)]  
PIC16F87@SSOP20(ISP) [ISP-HEADER01]  
PIC16F870 PIC16F870(ISP) [ISP-  
HEADER01]  
PIC16F870@SOIC28 [(SA404)]  
PIC16F870@SOIC28(ISP) [ISP-HEADER01]  
PIC16F870@SSOP28 [(SA626A)]  
PIC16F870@SSOP28(ISP) [ISP-HEADER01]  
PIC16F871 PIC16F871(ISP) [ISP-  
HEADER01]  
PIC16F871@PLCC44 [(SA244)]  
PIC16F871@PLCC44(ISP) [ISP-HEADER01]  
PIC16F871@TQFP44 [(SA245A)]  
PIC16F871@TQFP44(ISP) [ISP-HEADER01]  
PIC16F872 PIC16F872(ISP) [ISP-  
HEADER01]  
PIC16F872@SOIC28 [(SA404)]  
PIC16F872@SOIC28(ISP) [ISP-HEADER01]  
PIC16F872@SSOP28 [(SA626A)]  
PIC16F872@SSOP28(ISP) [ISP-HEADER01]  
PIC16F873 PIC16F873(ISP) [ISP-  
HEADER01]  
PIC16F873@SOIC28 [(SA404)]  
PIC16F873@SOIC28(ISP) [ISP-HEADER01]  
PIC16F873A  
PIC16F873A(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@QFN28 [(SA697-B006)]  
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SOIC28 [(SA404)]  
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]

PIC16F873A@SOIC28 (ISP3.3v) (LV) [ISP-HEADER01]  
PIC16F873A@SSOP28 [(SA626A)]  
PIC16F873A@SSOP28 (ISP) (High-V) [ISP-HEADER01]  
PIC16F873A@SSOP28 (ISP) (Low-V) [ISP-HEADER01]  
PIC16F873A@SSOP28 (ISP3.3v) (HV) [ISP-HEADER01]  
PIC16F873A@SSOP28 (ISP3.3v) (LV) [ISP-HEADER01]  
PIC16F874 PIC16F874 (ISP) [ISP-  
HEADER01]  
PIC16F874@PLCC44 [(SA244)]  
PIC16F874@PLCC44 (ISP) [ISP-HEADER01]  
PIC16F874@TQFP44 [(SA245A)]  
PIC16F874@TQFP44 (ISP) [ISP-HEADER01]  
PIC16F874A  
PIC16F874A (ISP) (High-V) [ISP-HEADER01]  
PIC16F874A (ISP) (Low-V) [ISP-HEADER01]  
PIC16F874A (ISP3.3v) (HV) [ISP-HEADER01]  
PIC16F874A (ISP3.3v) (LV) [ISP-HEADER01]  
PIC16F874A@PLCC44 [(SA244)]  
PIC16F874A@PLCC44 (ISP) (High-V) [ISP-HEADER01]  
PIC16F874A@PLCC44 (ISP) (Low-V) [ISP-HEADER01]  
PIC16F874A@PLCC44 (ISP3.3v) (HV) [ISP-HEADER01]  
PIC16F874A@PLCC44 (ISP3.3v) (LV) [ISP-HEADER01]  
PIC16F874A@TQFP44 [(SA245A)]  
PIC16F874A@TQFP44 (ISP) (High-V) [ISP-HEADER01]  
PIC16F874A@TQFP44 (ISP) (Low-V) [ISP-HEADER01]  
PIC16F874A@TQFP44 (ISP3.3v) (HV) [ISP-HEADER01]  
PIC16F874A@TQFP44 (ISP3.3v) (LV) [ISP-HEADER01]  
PIC16F876 PIC16F876 (ISP) [ISP-  
HEADER01]  
PIC16F876@SOIC28 [(SA404)]  
PIC16F876@SOIC28 (ISP) [ISP-HEADER01]  
PIC16F876A  
PIC16F876A (ISP) (High-V) [ISP-HEADER01]  
PIC16F876A (ISP) (Low-V) [ISP-HEADER01]  
PIC16F876A (ISP3.3v) (HV) [ISP-HEADER01]  
PIC16F876A (ISP3.3v) (LV) [ISP-HEADER01]  
PIC16F876A@QFN28 [(SA697-B006)]  
PIC16F876A@QFN28 (ISP) (High-V) [ISP-HEADER01]  
PIC16F876A@QFN28 (ISP) (Low-V) [ISP-HEADER01]  
PIC16F876A@QFN28 (ISP3.3v) (HV) [ISP-HEADER01]  
PIC16F876A@QFN28 (ISP3.3v) (LV) [ISP-HEADER01]  
PIC16F876A@SOIC28 [(SA404)]  
PIC16F876A@SOIC28 (ISP) (High-V) [ISP-HEADER01]

PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SSOP28 [(SA626A)]  
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877 PIC16F877(ISP) [ISP-  
HEADER01]  
PIC16F877@PLCC44 [(SA244)]  
PIC16F877@PLCC44(ISP) [ISP-HEADER01]  
PIC16F877@TQFP44 [(SA245A)]  
PIC16F877@TQFP44(ISP) [ISP-HEADER01]  
PIC16F877A  
PIC16F877A(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@PLCC44 [(SA244)]  
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@TQFP44 [(SA245A)]  
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F88 PIC16F88(ISP) [ISP-  
HEADER01]  
PIC16F88@QFN28 [(SA685-B006)]  
PIC16F88@QFN28(ISP) [ISP-HEADER01]  
PIC16F88@SOIC18 [(SA404)]  
PIC16F88@SOIC18(ISP) [ISP-HEADER01]  
PIC16F88@SSOP20 [(SA626A)]  
PIC16F88@SSOP20(ISP) [ISP-HEADER01]  
PIC16F882  
PIC16F882(ISP)(High-V) [ISP-HEADER01]  
PIC16F882(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@QFN28 [(SA697-B005)]  
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]

PIC16F882@SOIC28 [(SA404)]  
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SSOP28 [(SA626A)]  
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883  
PIC16F883(ISP)(High-V) [ISP-HEADER01]  
PIC16F883(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@QFN28 [(SA697-B005)]  
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SOIC28 [(SA404)]  
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SSOP28 [(SA626A)]  
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884  
PIC16F884(ISP)(High-V) [ISP-HEADER01]  
PIC16F884(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44 [(SA712)]  
PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML) [(SA737)]  
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@TQFP44 [(SA245A)]  
PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886  
PIC16F886(ISP)(High-V) [ISP-HEADER01]  
PIC16F886(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@QFN28 [(SA697-B005)]  
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SOIC28 [(SA404)]  
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SSOP28 [(SA626A)]  
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887



PIC16F887(ISP)(High-V) [ISP-HEADER01]  
PIC16F887(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44 [(SA712)]  
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML) [(SA737)]  
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@TQFP44 [(SA245A)]  
PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F913 PIC16F913(ISP) [ISP-  
HEADER01]  
PIC16F913@QFN28 [(SA697-B006)]  
PIC16F913@QFN28(ISP) [ISP-HEADER01]  
PIC16F913@SOIC28 [(SA404)]  
PIC16F913@SOIC28(ISP) [ISP-HEADER01]  
PIC16F913@SSOP28 [(SA626A)]  
PIC16F913@SSOP28(ISP) [ISP-HEADER01]  
PIC16F914 PIC16F914(ISP) [ISP-  
HEADER01]  
PIC16F914@QFN44 [(SA712)]  
PIC16F914@QFN44(ISP) [ISP-HEADER01]  
PIC16F914@QFN44(ML) [(SA737)]  
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F914@TQFP44 [(SA245A)]  
PIC16F914@TQFP44(ISP) [ISP-HEADER01]  
PIC16F916 PIC16F916(ISP) [ISP-  
HEADER01]  
PIC16F916@QFN28 [(SA697-B006)]  
PIC16F916@QFN28(ISP) [ISP-HEADER01]  
PIC16F916@SOIC28 [(SA404)]  
PIC16F916@SOIC28(ISP) [ISP-HEADER01]  
PIC16F916@SSOP28 [(SA626A)]  
PIC16F916@SSOP28(ISP) [ISP-HEADER01]  
PIC16F917 PIC16F917(ISP) [ISP-  
HEADER01]  
PIC16F917@QFN44 [(SA712)]  
PIC16F917@QFN44(ISP) [ISP-HEADER01]  
PIC16F917@QFN44(ML) [(SA737)]  
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F917@TQFP44 [(SA245A)]  
PIC16F917@TQFP44(ISP) [ISP-HEADER01]

PIC16F946@TQFP64(ISP) [ISP-HEADER01]  
PIC16HV540 PIC16HV540@SOIC18  
[(SA404)]  
PIC16HV540@SSOP20 [(SA626A)]  
PIC16HV610  
PIC16HV610(ISP) [ISP-HEADER01] PIC16HV610@QFN16  
[(SA727)]  
PIC16HV610@QFN16(ISP) [ISP-HEADER01]  
PIC16HV610@SOIC14 [(SA602)]  
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV610@TSSOP14 [(SA026)]  
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV616 PIC16HV616(ISP) [ISP-  
HEADER01]  
PIC16HV616@QFN16 [(SA727)]  
PIC16HV616@QFN16(ISP) [ISP-HEADER01]  
PIC16HV616@SOIC14 [(SA602)]  
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV616@TSSOP14 [(SA026)]  
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV785 PIC16HV785(ISP) [ISP-  
HEADER01]  
PIC16HV785@QFN20 [(SA692)]  
PIC16HV785@QFN20(ISP) [ISP-HEADER01]  
PIC16HV785@SOIC20 [(SA404)]  
PIC16HV785@SOIC20(ISP) [ISP-HEADER01]  
PIC16HV785@SSOP20 [(SA626A)]  
PIC16HV785@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC505 PIC16LC505@SOIC14  
[(SA602)]  
PIC16LC54A PIC16LC54A@SOIC18  
[(SA404)]  
PIC16LC54A@SSOP20 [(SA626A)]  
PIC16LC54C  
PIC16LC54C@SOIC18 [(SA404)] PIC16LC54C@SSOP20  
[(SA626A)]  
PIC16LC554 PIC16LC554(ISP) [ISP-  
HEADER01]  
PIC16LC554@SOIC18 [(SA404)]  
PIC16LC554@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC558 PIC16LC558(ISP) [ISP-  
HEADER01]  
PIC16LC558@SOIC18 [(SA404)]

PIC16LC558@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC56A PIC16LC56A@SOIC18  
[(SA404)]  
PIC16LC56A@SSOP20 [(SA626A)]  
PIC16LC58A  
PIC16LC58A@SOIC18 [(SA404)] PIC16LC58A@SSOP20  
[(SA626A)]  
PIC16LC58B PIC16LC58B@SOIC18  
[(SA404)]  
PIC16LC58B@SSOP20 [(SA626A)]  
PIC16LC620  
PIC16LC620(ISP) [ISP-HEADER01] PIC16LC620@SOIC18  
[(SA404)]  
PIC16LC620@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC620A PIC16LC620A(ISP) [ISP-  
HEADER01]  
PIC16LC620A@SOIC18 [(SA404)]  
PIC16LC620A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC620A@SSOP20 [(SA626A)]  
PIC16LC620A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC621A PIC16LC621A(ISP) [ISP-  
HEADER01]  
PIC16LC621A@SOIC18 [(SA404)]  
PIC16LC621A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC621A@SSOP20 [(SA626A)]  
PIC16LC621A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC622 PIC16LC622(ISP) [ISP-  
HEADER01]  
PIC16LC622@SOIC18 [(SA404)]  
PIC16LC622@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC62A PIC16LC62A(ISP) [ISP-  
HEADER01]  
PIC16LC62A@SOIC28 [(SA404)]  
PIC16LC62A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC62A@SSOP28 [(SA626A)]  
PIC16LC62A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC62B PIC16LC62B(ISP) [ISP-  
HEADER01]  
PIC16LC62B@SOIC28 [(SA404)]  
PIC16LC62B@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC62B@SSOP28 [(SA626A)]  
PIC16LC62B@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC63 PIC16LC63(ISP) [ISP-

HEADER01 ]  
PIC16LC63@SOIC28 [ (SA404) ]  
PIC16LC63@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC63A PIC16LC63A(ISP) [ ISP-  
HEADER01 ]  
PIC16LC63A@SOIC28 [ (SA404) ]  
PIC16LC63A@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC63A@SSOP28 [ (SA626A) ]  
PIC16LC63A@SSOP28(ISP) [ ISP-HEADER01 ]  
PIC16LC64A PIC16LC64A(ISP) [ ISP-  
HEADER01 ]  
PIC16LC64A@PLCC44 [ (SA244) ]  
PIC16LC64A@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC64A@TQFP44 [ (SA245A) ]  
PIC16LC64A@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC65A PIC16LC65A(ISP) [ ISP-  
HEADER01 ]  
PIC16LC65A@PLCC44 [ (SA244) ]  
PIC16LC65A@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC65A@TQFP44 [ (SA245A) ]  
PIC16LC65A@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC65B PIC16LC65B(ISP) [ ISP-  
HEADER01 ]  
PIC16LC65B@PLCC44 [ (SA244) ]  
PIC16LC65B@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC65B@TQFP44 [ (SA245A) ]  
PIC16LC65B@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC66 PIC16LC66(ISP) [ ISP-  
HEADER01 ]  
PIC16LC66@SOIC28 [ (SA404) ]  
PIC16LC66@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC67 PIC16LC67(ISP) [ ISP-  
HEADER01 ]  
PIC16LC67@PLCC44 [ (SA244) ]  
PIC16LC67@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC67@TQFP44 [ (SA245A) ]  
PIC16LC67@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC71 PIC16LC71(ISP) [ ISP-  
HEADER01 ]  
PIC16LC71@SOIC18 [ (SA404) ]  
PIC16LC71@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC710 PIC16LC710(ISP) [ ISP-  
HEADER01 ]

PIC16LC710@SOIC18 [(SA404)]  
PIC16LC710@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC710@SSOP20 [(SA626A)]  
PIC16LC710@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC711 PIC16LC711(ISP) [ISP-  
HEADER01]  
PIC16LC711@SOIC18 [(SA404)]  
PIC16LC711@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC711@SSOP20 [(SA626A)]  
PIC16LC711@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC712 PIC16LC712(ISP) [ISP-  
HEADER01]  
PIC16LC712@SOIC18 [(SA404)]  
PIC16LC712@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC712@SSOP20 [(SA626A)]  
PIC16LC712@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC715 PIC16LC715@SOIC18  
[(SA404)]  
PIC16LC716 PIC16LC716(ISP) [ISP-  
HEADER01]  
PIC16LC716@SOIC18 [(SA404)]  
PIC16LC716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC716@SSOP20 [(SA626A)]  
PIC16LC716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC717 PIC16LC717(ISP) [ISP-  
HEADER01]  
PIC16LC717@SOIC18 [(SA404)]  
PIC16LC717@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC717@SSOP20 [(SA626A)]  
PIC16LC717@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC72 PIC16LC72(ISP) [ISP-  
HEADER01]  
PIC16LC72@SOIC28 [(SA404)]  
PIC16LC72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72@SSOP28 [(SA626A)]  
PIC16LC72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC72A PIC16LC72A(ISP) [ISP-  
HEADER01]  
PIC16LC72A@SOIC28 [(SA404)]  
PIC16LC72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72A@SSOP28 [(SA626A)]  
PIC16LC72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC73A PIC16LC73A(ISP) [ISP-

HEADER01 ]  
PIC16LC73A@SOIC28 [ (SA404) ]  
PIC16LC73A@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC73B PIC16LC73B(ISP) [ ISP-  
HEADER01 ]  
PIC16LC73B@SOIC28 [ (SA404) ]  
PIC16LC73B@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC73B@SSOP28 [ (SA626A) ]  
PIC16LC73B@SSOP28(ISP) [ ISP-HEADER01 ]  
PIC16LC74 PIC16LC74(ISP) [ ISP-  
HEADER01 ]  
PIC16LC74@PLCC44 [ (SA244) ]  
PIC16LC74@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC74@TQFP44 [ (SA245A) ]  
PIC16LC74@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC74A PIC16LC74A(ISP) [ ISP-  
HEADER01 ]  
PIC16LC74A@PLCC44 [ (SA244) ]  
PIC16LC74A@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC74A@TQFP44 [ (SA245A) ]  
PIC16LC74A@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC74B PIC16LC74B(ISP) [ ISP-  
HEADER01 ]  
PIC16LC74B@MQFP44 [ (SA675) ]  
PIC16LC74B@MQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC74B@PLCC44 [ (SA244) ]  
PIC16LC74B@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC74B@TQFP44 [ (SA245A) ]  
PIC16LC74B@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC76 PIC16LC76(ISP) [ ISP-  
HEADER01 ]  
PIC16LC76@SOIC28 [ (SA404) ]  
PIC16LC76@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC77 PIC16LC77(ISP) [ ISP-  
HEADER01 ]  
PIC16LC77@PLCC44 [ (SA244) ]  
PIC16LC77@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC773 PIC16LC773(ISP) [ ISP-  
HEADER01 ]  
PIC16LC773@SOIC28 [ (SA404) ]  
PIC16LC773@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC773@SSOP28 [ (SA626A) ]  
PIC16LC773@SSOP28(ISP) [ ISP-HEADER01 ]

PIC16LC774 PIC16LC774(ISP) [ISP-  
HEADER01]  
PIC16LC774@PLCC44 [(SA244)]  
PIC16LC774@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC774@TQFP44 [(SA675)]  
PIC16LC774@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC84 PIC16LC84(ISP) [ISP-  
HEADER01]  
PIC16LC84@SOIC18 [(SA404)]  
PIC16LC84@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC923@PLCC68(\*) [(SA648-B6807)]  
PIC16LC923@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC923@SDIP64(ISP) [ISP-HEADER01]  
PIC16LC923@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC924@PLCC68(\*) [(SA648-B6807)]  
PIC16LC924@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC924@SDIP64(ISP) [ISP-HEADER01]  
PIC16LC924@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC925@PLCC68(\*) [(SA648-B6807)]  
PIC16LC925@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC925@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC926@PLCC68(\*) [(SA648-B6807)]  
PIC16LC926@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC926@TQFP64(ISP) [ISP-HEADER01]  
PIC16LCE623@SOIC18 [(SA404)]  
PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16LCE623@SSOP20 [(SA626A)]  
PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF505 PIC16LF505(ISP) [ISP-  
HEADER01]  
PIC16LF505@SOIC14 [(SA602)]  
PIC16LF505@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF505@TSSOP14 [(SA026)]  
PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF506 PIC16LF506(ISP) [ISP-  
HEADER01]  
PIC16LF506@SOIC14 [(SA602)]  
PIC16LF506@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF506@TSSOP14 [(SA026)]  
PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF526 PIC16LF526@SOIC14  
[(SA602)]  
PIC16LF526@TSSOP14 [(SA026)]

PIC16LF54  
PIC16LF54(ISP) [ISP-HEADER01] PIC16LF54@SOIC18  
[(SA404)]  
PIC16LF54@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF54@SSOP20 [(SA626A)]  
PIC16LF54@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF57 PIC16LF57(ISP) [ISP-  
HEADER01]  
PIC16LF57@SOIC28 [(SA404)]  
PIC16LF57@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF57@SSOP28 [(SA626A)]  
PIC16LF57@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF59 PIC16LF59(ISP) [ISP-  
HEADER01]  
PIC16LF59@PLCC44 [(SA244)]  
PIC16LF59@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF59@TQFP44 [(SA245A)]  
PIC16LF59@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF627 PIC16LF627(ISP) [ISP-  
HEADER01]  
PIC16LF627@SOIC18 [(SA404)]  
PIC16LF627@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627@SSOP20 [(SA626A)]  
PIC16LF627@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF627A PIC16LF627A(ISP) [ISP-  
HEADER01]  
PIC16LF627A@SOIC18 [(SA404)]  
PIC16LF627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627A@SSOP20 [(SA626A)]  
PIC16LF627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628 PIC16LF628(ISP) [ISP-  
HEADER01]  
PIC16LF628@SOIC18 [(SA404)]  
PIC16LF628@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628@SSOP20 [(SA626A)]  
PIC16LF628@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628A PIC16LF628A(ISP) [ISP-  
HEADER01]  
PIC16LF628A@SOIC18 [(SA404)]  
PIC16LF628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628A@SSOP20 [(SA626A)]  
PIC16LF628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF631 PIC16LF631(ISP) [ISP-



HEADER01 ]  
PIC16LF631@QFN20 [(SA692)]  
PIC16LF631@QFN20(ISP) [ISP-HEADER01]  
PIC16LF631@SOIC20 [(SA404)]  
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF631@SSOP20 [(SA626A)]  
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF639 PIC16LF639(ISP) [ISP-  
HEADER01]  
PIC16LF639@QFN20 [(SA692)]  
PIC16LF639@QFN20(ISP) [ISP-HEADER01]  
PIC16LF639@SOIC20 [(SA404)]  
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF639@SSOP20 [(SA626A)]  
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF648A PIC16LF648A(ISP) [ISP-  
HEADER01]  
PIC16LF648A@SOIC18 [(SA404)]  
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF648A@SSOP20 [(SA626A)]  
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF677 PIC16LF677(ISP) [ISP-  
HEADER01]  
PIC16LF677@QFN20 [(SA692)]  
PIC16LF677@QFN20(ISP) [ISP-HEADER01]  
PIC16LF677@SOIC20 [(SA404)]  
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF677@SSOP20 [(SA626A)]  
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF685 PIC16LF685(ISP) [ISP-  
HEADER01]  
PIC16LF685@QFN20 [(SA692)]  
PIC16LF685@QFN20(ISP) [ISP-HEADER01]  
PIC16LF685@SOIC20 [(SA404)]  
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF685@SSOP20 [(SA626A)]  
PIC16LF685@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF687 PIC16LF687(ISP) [ISP-  
HEADER01]  
PIC16LF687@QFN20 [(SA692)]  
PIC16LF687@QFN20(ISP) [ISP-HEADER01]  
PIC16LF687@SOIC20 [(SA404)]  
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]

PIC16LF687@SSOP20 [(SA626A)]  
PIC16LF687@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF689 PIC16LF689(ISP) [ISP-  
HEADER01]  
PIC16LF689@QFN20 [(SA692)]  
PIC16LF689@QFN20(ISP) [ISP-HEADER01]  
PIC16LF689@SOIC20 [(SA404)]  
PIC16LF689@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF689@SSOP20 [(SA626A)]  
PIC16LF689@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF690 PIC16LF690(ISP) [ISP-  
HEADER01]  
PIC16LF690@QFN20 [(SA692)]  
PIC16LF690@QFN20(ISP) [ISP-HEADER01]  
PIC16LF690@SOIC20 [(SA404)]  
PIC16LF690@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF690@SSOP20 [(SA626A)]  
PIC16LF690@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF716 PIC16LF716(ISP) [ISP-  
HEADER01]  
PIC16LF716@SOIC18 [(SA404)]  
PIC16LF716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF716@SSOP20 [(SA626A)]  
PIC16LF716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF72 PIC16LF72(ISP) [ISP-  
HEADER01]  
PIC16LF72@QFN28 [(SA685-B006)]  
PIC16LF72@QFN28(ISP) [ISP-HEADER01]  
PIC16LF72@SOIC28 [(SA404)]  
PIC16LF72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF72@SSOP28 [(SA626A)]  
PIC16LF72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF722 PIC16LF722@QFN28 [(SA685-  
B006)]  
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28  
[(SA626A)]  
PIC16LF723 PIC16LF723@QFN28 [(SA685-  
B006)]  
PIC16LF723@SOIC28 [(SA404)] PIC16LF723@SSOP28  
[(SA626A)]  
PIC16LF724 PIC16LF724@QFN44  
[(SA737)]  
PIC16LF724@TQFP44 [(SA245A)]

PIC16LF726  
PIC16LF726@QFN28 [(SA685-B006)] PIC16LF726@SOIC28  
[(SA404)]  
PIC16LF726@SSOP28 [(SA626A)]  
PIC16LF727  
PIC16LF727@QFN44 [(SA737)] PIC16LF727@TQFP44  
[(SA245A)]  
PIC16LF73 PIC16LF73(ISP) [ISP-  
HEADER01]  
PIC16LF73@SOIC28 [(SA404)]  
PIC16LF73@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF73@SSOP28 [(SA626A)]  
PIC16LF73@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF737 PIC16LF737(ISP) [ISP-  
HEADER01]  
PIC16LF737@SOIC28 [(SA404)]  
PIC16LF737@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF737@SSOP28 [(SA626A)]  
PIC16LF737@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF74 PIC16LF74(ISP) [ISP-  
HEADER01]  
PIC16LF74@PLCC44 [(SA244)]  
PIC16LF74@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF74@TQFP44 [(SA245A)]  
PIC16LF74@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF747 PIC16LF747(ISP) [ISP-  
HEADER01]  
PIC16LF747@TQFP44 [(SA245A)]  
PIC16LF747@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF76 PIC16LF76(ISP) [ISP-  
HEADER01]  
PIC16LF76@SOIC28 [(SA404)]  
PIC16LF76@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF76@SSOP28 [(SA626A)]  
PIC16LF76@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF767 PIC16LF767(ISP) [ISP-  
HEADER01]  
PIC16LF767@SOIC28 [(SA404)]  
PIC16LF767@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF767@SSOP28 [(SA626A)]  
PIC16LF767@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF77 PIC16LF77(ISP) [ISP-  
HEADER01]

PIC16LF77@PLCC44 [(SA244)]  
PIC16LF77@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF77@TQFP44 [(SA245A)]  
PIC16LF77@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF777 PIC16LF777(ISP) [ISP-  
HEADER01]  
PIC16LF777@TQFP44 [(SA245A)]  
PIC16LF777@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF818 PIC16LF818(ISP) [ISP-  
HEADER01]  
PIC16LF818@QFN28 [(SA685-B006)]  
PIC16LF818@QFN28(ISP) [ISP-HEADER01]  
PIC16LF818@SOIC18 [(SA404)]  
PIC16LF818@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF818@SSOP20 [(SA626A)]  
PIC16LF818@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF819 PIC16LF819(ISP) [ISP-  
HEADER01]  
PIC16LF819@QFN28 [(SA685-B006)]  
PIC16LF819@QFN28(ISP) [ISP-HEADER01]  
PIC16LF819@SOIC18 [(SA404)]  
PIC16LF819@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF819@SSOP20 [(SA626A)]  
PIC16LF819@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF83 PIC16LF83(ISP) [ISP-  
HEADER01]  
PIC16LF83@SOIC18 [(SA404)]  
PIC16LF83@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84 PIC16LF84(ISP) [ISP-  
HEADER01]  
PIC16LF84@SOIC18 [(SA404)]  
PIC16LF84@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84A PIC16LF84A(ISP) [ISP-  
HEADER01]  
PIC16LF84A@SOIC18 [(SA404)]  
PIC16LF84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84A@SSOP20 [(SA626A)]  
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF87 PIC16LF87(ISP) [ISP-  
HEADER01]  
PIC16LF87@QFN28 [(SA685-B006)]  
PIC16LF87@QFN28(ISP) [ISP-HEADER01]  
PIC16LF87@SOIC18 [(SA404)]

PIC16LF87@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF87@SSOP20 [(SA626A)]  
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF870 PIC16LF870(ISP) [ISP-  
HEADER01]  
PIC16LF870@SOIC28 [(SA404)]  
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF870@SSOP28 [(SA626A)]  
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF871 PIC16LF871(ISP) [ISP-  
HEADER01]  
PIC16LF871@PLCC44 [(SA244)]  
PIC16LF871@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF871@TQFP44 [(SA245A)]  
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF872 PIC16LF872(ISP) [ISP-  
HEADER01]  
PIC16LF872@SOIC28 [(SA404)]  
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF872@SSOP28 [(SA626A)]  
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF873 PIC16LF873(ISP) [ISP-  
HEADER01]  
PIC16LF873@SOIC28 [(SA404)]  
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF873A  
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@QFN28 [(SA697-B006)]  
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SOIC28 [(SA404)]  
PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SSOP28 [(SA626A)]  
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]

PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874 PIC16LF874(ISP) [ISP-  
HEADER01]  
PIC16LF874@PLCC44 [(SA244)]  
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF874@TQFP44 [(SA245A)]  
PIC16LF874@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF874A  
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@PLCC44 [(SA244)]  
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@TQFP44 [(SA245A)]  
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876 PIC16LF876(ISP) [ISP-  
HEADER01]  
PIC16LF876@SOIC28 [(SA404)]  
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF876A  
PIC16LF876A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@QFN28 [(SA697-B006)]  
PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SOIC28 [(SA404)]  
PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SSOP28 [(SA626A)]

PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877 PIC16LF877(ISP) [ISP-  
HEADER01]  
PIC16LF877@PLCC44 [(SA244)]  
PIC16LF877@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF877@TQFP44 [(SA245A)]  
PIC16LF877@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF877A  
PIC16LF877A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@PLCC44 [(SA244)]  
PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@TQFP44 [(SA245A)]  
PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF88 PIC16LF88(ISP) [ISP-  
HEADER01]  
PIC16LF88@QFN28 [(SA685-B006)]  
PIC16LF88@QFN28(ISP) [ISP-HEADER01]  
PIC16LF88@SOIC18 [(SA404)]  
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF88@SSOP20 [(SA626A)]  
PIC16LF88@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF913 PIC16LF913(ISP) [ISP-  
HEADER01]  
PIC16LF913@QFN28 [(SA697-B006)]  
PIC16LF913@QFN28(ISP) [ISP-HEADER01]  
PIC16LF913@SOIC28 [(SA404)]  
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF913@SSOP28 [(SA626A)]  
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF914 PIC16LF914(ISP) [ISP-  
HEADER01]

PIC16LF914@QFN44 [(SA712)]  
PIC16LF914@QFN44(ISP) [ISP-HEADER01]  
PIC16LF914@QFN44(ML) [(SA737)]  
PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16LF914@TQFP44 [(SA245A)]  
PIC16LF914@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF916 PIC16LF916(ISP) [ISP-  
HEADER01]  
PIC16LF916@QFN28 [(SA697-B006)]  
PIC16LF916@QFN28(ISP) [ISP-HEADER01]  
PIC16LF916@SOIC28 [(SA404)]  
PIC16LF916@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF916@SSOP28 [(SA626A)]  
PIC16LF916@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF917 PIC16LF917(ISP) [ISP-  
HEADER01]  
PIC16LF917@QFN44 [(SA712)]  
PIC16LF917@QFN44(ISP) [ISP-HEADER01]  
PIC16LF917@QFN44(ML) [(SA737)]  
PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16LF917@TQFP44 [(SA245A)]  
PIC16LF917@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF946@TQFP64(ISP) [ISP-HEADER01]  
PIC16LV54A PIC16LV54A@SOIC18  
[(SA404)]  
PIC16LV54A@SSOP20 [(SA626A)]  
PIC16LV58A  
PIC16LV58A@SOIC18 [(SA404)] PIC16LV58A@SSOP20  
[(SA626A)]  
PIC17C42 PIC17C42@PLCC44  
[(SA244)]  
PIC17C42@TQFP44 [(SA245A)]  
PIC17C42A  
PIC17C42A@PLCC44 [(SA244)] PIC17C42A@TQFP44  
[(SA245A)]  
PIC17C43 PIC17C43@PLCC44  
[(SA244)]  
PIC17C43@TQFP44 [(SA245A)]  
PIC17C44  
PIC17C44@PLCC44 [(SA244)] PIC17C44@TQFP44  
[(SA245A)]  
PIC17LC42 PIC17LC42@PLCC44  
[(SA244)]



PIC17LC42@TQFP44 [(SA245A)]  
 PIC17LC42A  
 PIC17LC42A@PLCC44 [(SA244)] PIC17LC42A@TQFP44  
 [(SA245A)]  
 PIC17LC43 PIC17LC43@PLCC44  
 [(SA244)]  
 PIC17LC43@TQFP44 [(SA245A)]  
 PIC17LC44  
 PIC17LC44@PLCC44 [(SA244)] PIC17LC44@TQFP44  
 [(SA245A)]  
 PIC18C242 PIC18C242@SOIC28  
 [(SA404)]  
 PIC18C252 PIC18C252@SOIC28  
 [(SA404)]  
 PIC18C442 PIC18C442@PLCC44  
 [(SA244)]  
 PIC18C442@TQFP44 [(SA245A)]  
 PIC18C452  
 PIC18C452@PLCC44 [(SA244)] PIC18C452@TQFP44  
 [(SA245A)]  
 PIC18F1220 PIC18F1220(ISP) [ISP-  
 HEADER01]  
 PIC18F1220@SOIC18 [(SA404)]  
 PIC18F1220@SOIC18(ISP) [ISP-HEADER01]  
 PIC18F1220@SSOP20 [(SA626A)]  
 PIC18F1220@SSOP20(ISP) [ISP-HEADER01]  
 PIC18F1230 PIC18F1230(ISP) [ISP-  
 HEADER01]  
 PIC18F1230@QFN28 [(SA685-B006)]  
 PIC18F1230@QFN28(ISP) [ISP-HEADER01]  
 PIC18F1230@SOIC18 [(SA404)]  
 PIC18F1230@SOIC18(ISP) [ISP-HEADER01]  
 PIC18F1230@SSOP20 [(SA626A)]  
 PIC18F1230@SSOP20(ISP) [ISP-HEADER01]  
 PIC18F1320 PIC18F1320(ISP) [ISP-  
 HEADER01]  
 PIC18F1320@SOIC18 [(SA404)]  
 PIC18F1320@SOIC18(ISP) [ISP-HEADER01]  
 PIC18F1320@SSOP20 [(SA626A)]  
 PIC18F1320@SSOP20(ISP) [ISP-HEADER01]  
 PIC18F1330 PIC18F1330(ISP) [ISP-  
 HEADER01]  
 PIC18F1330@QFN28 [(SA685-B006)]

PIC18F1330@QFN28(ISP) [ISP-HEADER01]  
PIC18F1330@SOIC18 [(SA404)]  
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1330@SSOP20 [(SA626A)]  
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330-ICD@QFN28 [(SA685-B006)]  
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]  
PIC18F2220 PIC18F2220(ISP) [ISP-  
HEADER01]  
PIC18F2220@SOIC28 [(SA404)]  
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2221  
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@QFN28 [(SA685-B006)]  
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@SOIC28 [(SA404)]  
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2320 PIC18F2320(ISP) [ISP-  
HEADER01]  
PIC18F2320@SOIC28 [(SA404)]  
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2321  
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@QFN28 [(SA685-B006)]  
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@SOIC28 [(SA404)]  
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2331 PIC18F2331(ISP) [ISP-  
HEADER01]  
PIC18F2331@SOIC28 [(SA404)]  
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18F23K20  
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@QFN28 [(SA685-B006)]  
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28 [(SA404)]  
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28 [(SA626A)]  
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]

PIC18F2410  
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@QFN28 [(SA685-B006)]  
PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@SOIC28 [(SA404)]  
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F242 PIC18F242(ISP) [ISP-  
HEADER01]  
PIC18F242@SOIC28 [(SA404)]  
PIC18F242@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2420  
PIC18F2420(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2420@SOIC28 [(SA404)]  
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423  
PIC18F2423(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@QFN28 [(SA685-B006)]  
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@SOIC28 [(SA404)]  
PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2431 PIC18F2431(ISP) [ISP-  
HEADER01]  
PIC18F2431@SOIC28 [(SA404)]  
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2439 PIC18F2439(ISP) [ISP-  
HEADER01]  
PIC18F2439@SOIC28 [(SA404)]  
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2450  
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@QFN28 [(SA685-B006)]  
PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@SOIC28 [(SA404)]  
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455  
PIC18F2455(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455@SOIC28 [(SA404)]

PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458  
PIC18F2458(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SOIC28 [(SA404)]  
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SSOP28 [(SA626A)]  
PIC18F2458@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F248 PIC18F248(ISP) [ISP-  
HEADER01]  
PIC18F248@SOIC28 [(SA404)]  
PIC18F248@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2480  
PIC18F2480(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@QFN28 [(SA685-B006)]  
PIC18F2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@SOIC28 [(SA404)]  
PIC18F2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24J10 PIC18F24J10(ISP) [ISP-  
HEADER01]  
PIC18F24J10@QFN28 [(SA685-B006)]  
PIC18F24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F24J10@SOIC28 [(SA404)]  
PIC18F24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F24J10@SSOP28 [(SA626A)]  
PIC18F24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F24K20  
PIC18F24K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@QFN28 [(SA685-B006)]  
PIC18F24K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28 [(SA404)]  
PIC18F24K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28 [(SA626A)]  
PIC18F24K20@SSOP28(ISP)(High-V) [ISP-HEADER01]

PIC18F24K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2510 PIC18F2510(ISP) [ISP-  
HEADER01]  
PIC18F2510@QFN28 [(SA685-B006)]  
PIC18F2510@QFN28(ISP) [ISP-HEADER01]  
PIC18F2510@SOIC28 [(SA404)]  
PIC18F2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2515  
PIC18F2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2515@SOIC28 [(SA404)]  
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F252 PIC18F252(ISP) [ISP-  
HEADER01]  
PIC18F252@SOIC28 [(SA404)]  
PIC18F252@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2520  
PIC18F2520(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2520@SOIC28 [(SA404)]  
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523  
PIC18F2523(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@QFN28 [(SA685-B006)]  
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@SOIC28 [(SA404)]  
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525  
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525@SOIC28 [(SA404)]  
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2539 PIC18F2539(ISP) [ISP-  
HEADER01]  
PIC18F2539@SOIC28 [(SA404)]  
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2550  
PIC18F2550(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2550@SOIC28 [(SA404)]  
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553  
PIC18F2553(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SOIC28 [(SA404)]  
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SSOP28 [(SA626A)]  
PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F258 PIC18F258(ISP) [ISP-  
HEADER01]  
PIC18F258@SOIC28 [(SA404)]  
PIC18F258@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2580  
PIC18F2580(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@QFN28 [(SA685-B006)]  
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@SOIC28 [(SA404)]  
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585  
PIC18F2585(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SDIP28 [(SA022A)]  
PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SOIC28 [(SA404)]  
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25J10 PIC18F25J10(ISP) [ISP-  
HEADER01]  
PIC18F25J10@QFN28 [(SA685-B006)]  
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F25J10@SOIC28 [(SA404)]  
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F25J10@SSOP28 [(SA626A)]  
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F25K20  
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]

PIC18F25K20@QFN28 [(SA685-B006)]  
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28 [(SA404)]  
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28 [(SA626A)]  
PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610  
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610@SOIC28 [(SA404)]  
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620  
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620@SOIC28 [(SA404)]  
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680  
PIC18F2680(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SDIP28 [(SA022A)]  
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SOIC28 [(SA404)]  
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682  
PIC18F2682(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@QFN28 [(SA685)]  
PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@SOIC28 [(SA404)]  
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685  
PIC18F2685(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@QFN28 [(SA685)]  
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@SOIC28 [(SA404)]  
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F26K20  
PIC18F26K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F26K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F26K20@QFN28 [(SA685-B006)]  
PIC18F26K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F26K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F26K20@SOIC28 [(SA404)]  
PIC18F26K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F26K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F26K20@SSOP28 [(SA626A)]  
PIC18F26K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F26K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4220 PIC18F4220(ISP) [ISP-  
HEADER01]  
PIC18F4220@QFN44 [(SA712)]  
PIC18F4220@QFN44(ISP) [ISP-HEADER01]  
PIC18F4220@QFN44(ML) [(SA737)]  
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4220@TQFP44 [(SA245A)]  
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4221  
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44 [(SA712)]  
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44(ML) [(SA737)]  
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@TQFP44 [(SA245A)]  
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4320 PIC18F4320(ISP) [ISP-  
HEADER01]  
PIC18F4320@QFN44 [(SA712)]  
PIC18F4320@QFN44(ISP) [ISP-HEADER01]  
PIC18F4320@QFN44(ML) [(SA737)]  
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4320@TQFP44 [(SA245A)]  
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4321  
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44 [(SA712)]  
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44(ML) [(SA737)]  
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]



PIC18F4321@TQFP44 [(SA245A)]  
PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4331 PIC18F4331(ISP) [ISP-  
HEADER01]  
PIC18F4331@TQFP44 [(SA245A)]  
PIC18F4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18F43K20  
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44 [(SA712)]  
PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML) [(SA737)]  
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44 [(SA245A)]  
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410  
PIC18F4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44 [(SA712)]  
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44(ML) [(SA737)]  
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@TQFP44 [(SA245A)]  
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F442 PIC18F442(ISP) [ISP-  
HEADER01]  
PIC18F442@PLCC44 [(SA244)]  
PIC18F442@PLCC44(ISP) [ISP-HEADER01]  
PIC18F442@TQFP44 [(SA245A)]  
PIC18F442@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4420  
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44 [(SA712)]  
PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44(ML) [(SA737)]  
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@TQFP44 [(SA245A)]  
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423  
PIC18F4423(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]

PIC18F4423@QFN44 [(SA712)]  
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ML) [(SA737)]  
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@TQFP44 [(SA245A)]  
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4431 PIC18F4431(ISP) [ISP-  
HEADER01]  
PIC18F4431@TQFP44 [(SA245A)]  
PIC18F4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4439 PIC18F4439(ISP) [ISP-  
HEADER01]  
PIC18F4439@TQFP44 [(SA245A)]  
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4450  
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44 [(SA712)]  
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44(ML) [(SA737)]  
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@TQFP44 [(SA245A)]  
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455  
PIC18F4455(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44 [(SA712)]  
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML) [(SA737)]  
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@TQFP44 [(SA245A)]  
PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458  
PIC18F4458(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@QFN44 [(SA737)]  
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]

PIC18F4458@TQFP44 [(SA245A)]  
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F448 PIC18F448(ISP) [ISP-  
HEADER01]  
PIC18F448@PLCC44 [(SA244)]  
PIC18F448@PLCC44(ISP) [ISP-HEADER01]  
PIC18F448@TQFP44 [(SA245A)]  
PIC18F448@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4480  
PIC18F4480(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44 [(SA712)]  
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML) [(SA737)]  
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@TQFP44 [(SA245A)]  
PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44J10 PIC18F44J10(ISP) [ISP-  
HEADER01]  
PIC18F44J10@QFN44 [(SA712)]  
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F44J10@QFN44(ML) [(SA709)]  
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F44J10@TQFP44 [(SA245A)]  
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F44K20  
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44 [(SA712)]  
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML) [(SA737)]  
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44 [(SA245A)]  
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4510 PIC18F4510(ISP) [ISP-  
HEADER01]

PIC18F4510@QFN44 [(SA712)]  
PIC18F4510@QFN44(ISP) [ISP-HEADER01]  
PIC18F4510@QFN44(ML) [(SA737)]  
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4510@TQFP44 [(SA245A)]  
PIC18F4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4515  
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@QFN44 [(SA712)]  
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@QFN44(ML) [(SA737)]  
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@TQFP44 [(SA245A)]  
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F452 PIC18F452(ISP) [ISP-  
HEADER01]  
PIC18F452@PLCC44 [(SA244)]  
PIC18F452@PLCC44(ISP) [ISP-HEADER01]  
PIC18F452@TQFP44 [(SA245A)]  
PIC18F452@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4520 PIC18F4520(ISP) [ISP-  
HEADER01]  
PIC18F4520@QFN44 [(SA712)]  
PIC18F4520@QFN44(ISP) [ISP-HEADER01]  
PIC18F4520@QFN44(ML) [(SA737)]  
PIC18F4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4520@TQFP44 [(SA245A)]  
PIC18F4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4523  
PIC18F4523(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44 [(SA712)]  
PIC18F4523@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML) [(SA737)]  
PIC18F4523@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@TQFP44 [(SA245A)]  
PIC18F4523@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525  
PIC18F4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44 [(SA712)]

PIC18F4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44(ML) [(SA737)]  
PIC18F4525@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@TQFP44 [(SA245A)]  
PIC18F4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4539 PIC18F4539(ISP) [ISP-  
HEADER01]  
PIC18F4539@TQFP44 [(SA245A)]  
PIC18F4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4550  
PIC18F4550(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44 [(SA712)]  
PIC18F4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML) [(SA737)]  
PIC18F4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@TQFP44 [(SA245A)]  
PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553  
PIC18F4553(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@QFN44 [(SA737)]  
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@TQFP44 [(SA245A)]  
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F458 PIC18F458(ISP) [ISP-  
HEADER01]  
PIC18F458@PLCC44 [(SA244)]  
PIC18F458@PLCC44(ISP) [ISP-HEADER01]  
PIC18F458@TQFP44 [(SA245A)]  
PIC18F458@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4580  
PIC18F4580(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44 [(SA712)]  
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML) [(SA737)]

PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@TQFP44 [(SA245A)]  
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585  
PIC18F4585(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44 [(SA712)]  
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML) [(SA737)]  
PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@TQFP44 [(SA245A)]  
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45J10 PIC18F45J10(ISP) [ISP-  
HEADER01]  
PIC18F45J10@QFN44 [(SA712)]  
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F45J10@QFN44(ML) [(SA709)]  
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F45J10@TQFP44 [(SA245A)]  
PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F45K20  
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44 [(SA712)]  
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML) [(SA737)]  
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44 [(SA245A)]  
PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610  
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44 [(SA712)]  
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44(ML) [(SA737)]  
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]

PIC18F4610@TQFP44 [(SA245A)]  
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620  
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44 [(SA712)]  
PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44(ML) [(SA737)]  
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@TQFP44 [(SA245A)]  
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680  
PIC18F4680(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44 [(SA712)]  
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML) [(SA737)]  
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@TQFP44 [(SA245A)]  
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682  
PIC18F4682(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44 [(SA712)]  
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML) [(SA737)]  
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@TQFP44 [(SA245A)]  
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685  
PIC18F4685(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44 [(SA712)]  
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML) [(SA737)]  
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]

PIC18F4685@TQFP44 [(SA245A)]  
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F46K20  
PIC18F46K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F46K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F46K20@QFN44 [(SA712)]  
PIC18F46K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F46K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F46K20@QFN44(ML) [(SA737)]  
PIC18F46K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F46K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F46K20@TQFP44 [(SA245A)]  
PIC18F46K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F46K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J11@TQFP64(\*) [(SA732+B340)]  
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J90@TQFP64(\*) [(SA732+B340)]  
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J11@TQFP64(\*) [(SA732+B340)]  
PIC18F64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J90@TQFP64(\*) [(SA732+B340)]  
PIC18F64J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6520@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6525@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J10@TQFP64(\*) [(SA732+B340)]  
PIC18F65J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J11@TQFP64(\*) [(SA732+B340)]  
PIC18F65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J15@TQFP64(\*) [(SA732+B340)]  
PIC18F65J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J15@TQFP64(ISP)(Enable) [ISP-HEADER01]



PIC18F65J50@TQFP64(\*) [(SA732+B340)]  
PIC18F65J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J90@TQFP64(\*) [(SA732+B340)]  
PIC18F65J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J10@TQFP64(\*) [(SA732+B340)]  
PIC18F66J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J11@TQFP64(\*) [(SA732+B340)]  
PIC18F66J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J15@TQFP64(\*) [(SA732+B340)]  
PIC18F66J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J16@TQFP64(\*) [(SA732+B340)]  
PIC18F66J16@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J50@TQFP64(\*) [(SA732+B340)]  
PIC18F66J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J55@TQFP64(\*) [(SA732+B340)]  
PIC18F66J55@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J60@TQFP64(\*) [(SA732+B340)]  
PIC18F66J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J65@TQFP64(\*) [(SA732+B340)]  
PIC18F66J65@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F67J10@TQFP64(\*) [(SA732+B340)]  
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F67J11@TQFP64(\*) [(SA732+B340)]  
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J50@TQFP64(\*) [(SA732+B340)]  
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J60@TQFP64(\*) [(SA732+B340)]  
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]

PIC18F8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J55@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J65@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Enable) [ISP-HEADER01]

PIC18F87J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F96J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18F96J65@TQFP100(ISP) [ISP-HEADER01]  
PIC18F97J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18LC452 PIC18LC452@PLCC44  
[(SA244)]  
PIC18LC452@TQFP44 [(SA245A)]  
PIC18LF1220  
PIC18LF1220(ISP) [ISP-HEADER01] PIC18LF1220@SOIC18  
[(SA404)]  
PIC18LF1220@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1220@SSOP20 [(SA626A)]  
PIC18LF1220@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF1320 PIC18LF1320(ISP) [ISP-  
HEADER01]  
PIC18LF1320@SOIC18 [(SA404)]  
PIC18LF1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1320@SSOP20 [(SA626A)]  
PIC18LF1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF2220 PIC18LF2220(ISP) [ISP-  
HEADER01]  
PIC18LF2220@SOIC28 [(SA404)]  
PIC18LF2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2221  
PIC18LF2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@QFN28 [(SA685-B006)]  
PIC18LF2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@SOIC28 [(SA404)]  
PIC18LF2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2320 PIC18LF2320(ISP) [ISP-  
HEADER01]  
PIC18LF2320@SOIC28 [(SA404)]  
PIC18LF2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2321  
PIC18LF2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@QFN28 [(SA685-B006)]  
PIC18LF2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@SOIC28 [(SA404)]  
PIC18LF2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2331 PIC18LF2331(ISP) [ISP-  
HEADER01]

PIC18LF2331@SOIC28 [(SA404)]  
PIC18LF2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2410  
PIC18LF2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2410@QFN28 [(SA685-B006)]  
PIC18LF2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2410@SOIC28 [(SA404)]  
PIC18LF2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF242 PIC18LF242(ISP) [ISP-  
HEADER01]  
PIC18LF242@SOIC28 [(SA404)]  
PIC18LF242@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2420  
PIC18LF2420(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28 [(SA404)]  
PIC18LF2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2431 PIC18LF2431(ISP) [ISP-  
HEADER01]  
PIC18LF2431@SOIC28 [(SA404)]  
PIC18LF2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2439 PIC18LF2439(ISP) [ISP-  
HEADER01]  
PIC18LF2439@SOIC28 [(SA404)]  
PIC18LF2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2450  
PIC18LF2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2450@QFN28 [(SA685-B006)]  
PIC18LF2450@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2450@SOIC28 [(SA404)]  
PIC18LF2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2455  
PIC18LF2455(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28 [(SA404)]  
PIC18LF2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF248 PIC18LF248(ISP) [ISP-  
HEADER01]  
PIC18LF248@SOIC28 [(SA404)]  
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2480

PIC18LF2480(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@QFN28 [(SA685-B006)]  
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28 [(SA404)]  
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF24J10 PIC18LF24J10(ISP) [ISP-  
HEADER01]  
PIC18LF24J10@QFN28 [(SA685-B006)]  
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SOIC28 [(SA404)]  
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SSOP28 [(SA626A)]  
PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2510 PIC18LF2510(ISP) [ISP-  
HEADER01]  
PIC18LF2510@QFN28 [(SA685-B006)]  
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]  
PIC18LF2510@SOIC28 [(SA404)]  
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2515  
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2515@SOIC28 [(SA404)]  
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF252 PIC18LF252(ISP) [ISP-  
HEADER01]  
PIC18LF252@SOIC28 [(SA404)]  
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2520  
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28 [(SA404)]  
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525  
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525@SOIC28 [(SA404)]  
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2539 PIC18LF2539(ISP) [ISP-  
HEADER01]  
PIC18LF2539@SOIC28 [(SA404)]

PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2550  
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28 [(SA404)]  
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF258 PIC18LF258(ISP) [ISP-  
HEADER01]  
PIC18LF258@SOIC28 [(SA404)]  
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2580  
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@QFN28 [(SA685-B006)]  
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28 [(SA404)]  
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585  
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28 [(SA022A)]  
PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28 [(SA404)]  
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF25J10 PIC18LF25J10(ISP) [ISP-  
HEADER01]  
PIC18LF25J10@QFN28 [(SA685-B006)]  
PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SOIC28 [(SA404)]  
PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SSOP28 [(SA626A)]  
PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2610  
PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2610@SOIC28 [(SA404)]  
PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620  
PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2620@SOIC28 [(SA404)]  
PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680  
PIC18LF2680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28 [(SA022A)]  
PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28 [(SA404)]  
PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682  
PIC18LF2682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@QFN28 [(SA685)]  
PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28 [(SA404)]  
PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685  
PIC18LF2685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@QFN28 [(SA685)]  
PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28 [(SA404)]  
PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4220 PIC18LF4220(ISP) [ISP-  
HEADER01]  
PIC18LF4220@QFN44 [(SA712)]  
PIC18LF4220@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4220@QFN44(ML) [(SA737)]  
PIC18LF4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4220@TQFP44 [(SA245A)]  
PIC18LF4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4221  
PIC18LF4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44 [(SA712)]  
PIC18LF4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44(ML) [(SA737)]  
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]

PIC18LF4221@TQFP44 [(SA245A)]  
PIC18LF4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4320 PIC18LF4320(ISP) [ISP-  
HEADER01]  
PIC18LF4320@QFN44 [(SA712)]  
PIC18LF4320@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4320@QFN44(ML) [(SA737)]  
PIC18LF4320@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4320@TQFP44 [(SA245A)]  
PIC18LF4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4321  
PIC18LF4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44 [(SA712)]  
PIC18LF4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44(ML) [(SA737)]  
PIC18LF4321@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4321@TQFP44 [(SA245A)]  
PIC18LF4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4331 PIC18LF4331(ISP) [ISP-  
HEADER01]  
PIC18LF4331@TQFP44 [(SA245A)]  
PIC18LF4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4410  
PIC18LF4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4410@QFN44 [(SA712)]  
PIC18LF4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4410@QFN44(ML) [(SA737)]  
PIC18LF4410@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4410@TQFP44 [(SA245A)]  
PIC18LF4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF442 PIC18LF442(ISP) [ISP-  
HEADER01]  
PIC18LF442@PLCC44 [(SA244)]  
PIC18LF442@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF442@TQFP44 [(SA245A)]  
PIC18LF442@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4420  
PIC18LF4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44 [(SA712)]  
PIC18LF4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44(ML) [(SA737)]  
PIC18LF4420@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4420@TQFP44 [(SA245A)]



PIC18LF4420@TQFP44 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF4431 PIC18LF4431 (ISP) [ISP-  
HEADER01]  
PIC18LF4431@TQFP44 [(SA245A)]  
PIC18LF4431@TQFP44 (ISP) [ISP-HEADER01]  
PIC18LF4439 PIC18LF4439 (ISP) [ISP-  
HEADER01]  
PIC18LF4439@TQFP44 [(SA245A)]  
PIC18LF4439@TQFP44 (ISP) [ISP-HEADER01]  
PIC18LF4450  
PIC18LF4450 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44 [(SA712)]  
PIC18LF4450@QFN44 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44 (ML) [(SA737)]  
PIC18LF4450@QFN44 (ML) (ISP) (L-V) [ISP-HEADER01]  
PIC18LF4450@TQFP44 [(SA245A)]  
PIC18LF4450@TQFP44 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF4455  
PIC18LF4455 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF4455 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44 [(SA712)]  
PIC18LF4455@QFN44 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF4455@QFN44 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44 (ML) [(SA737)]  
PIC18LF4455@QFN44 (ML) (ISP) (H-V) [ISP-HEADER01]  
PIC18LF4455@QFN44 (ML) (ISP) (L-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44 [(SA245A)]  
PIC18LF4455@TQFP44 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF448 PIC18LF448 (ISP) [ISP-  
HEADER01]  
PIC18LF448@PLCC44 [(SA244)]  
PIC18LF448@PLCC44 (ISP) [ISP-HEADER01]  
PIC18LF448@TQFP44 [(SA245A)]  
PIC18LF448@TQFP44 (ISP) [ISP-HEADER01]  
PIC18LF4480  
PIC18LF4480 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF4480 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF4480@QFN44 [(SA712)]  
PIC18LF4480@QFN44 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF4480@QFN44 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF4480@QFN44 (ML) [(SA737)]  
PIC18LF4480@QFN44 (ML) (ISP) (H-V) [ISP-HEADER01]

PIC18LF4480@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4480@TQFP44 [(SA245A)]  
PIC18LF4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF44J10 PIC18LF44J10(ISP) [ISP-  
HEADER01]  
PIC18LF44J10@QFN44 [(SA712)]  
PIC18LF44J10@QFN44(ISP) [ISP-HEADER01]  
PIC18LF44J10@QFN44(ML) [(SA709)]  
PIC18LF44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF44J10@TQFP44 [(SA245A)]  
PIC18LF44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4510 PIC18LF4510(ISP) [ISP-  
HEADER01]  
PIC18LF4510@QFN44 [(SA712)]  
PIC18LF4510@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4510@QFN44(ML) [(SA737)]  
PIC18LF4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4510@TQFP44 [(SA245A)]  
PIC18LF4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4515  
PIC18LF4515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4515@QFN44 [(SA712)]  
PIC18LF4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4515@QFN44(ML) [(SA737)]  
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4515@TQFP44 [(SA245A)]  
PIC18LF4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF452 PIC18LF452(ISP) [ISP-  
HEADER01]  
PIC18LF452@PLCC44 [(SA244)]  
PIC18LF452@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF452@TQFP44 [(SA245A)]  
PIC18LF452@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4520 PIC18LF4520(ISP) [ISP-  
HEADER01]  
PIC18LF4520@QFN44 [(SA712)]  
PIC18LF4520@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4520@QFN44(ML) [(SA737)]  
PIC18LF4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4520@TQFP44 [(SA245A)]  
PIC18LF4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4525

PIC18LF4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44 [(SA712)]  
PIC18LF4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44(ML) [(SA737)]  
PIC18LF4525@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4525@TQFP44 [(SA245A)]  
PIC18LF4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4539 PIC18LF4539(ISP) [ISP-  
HEADER01]  
PIC18LF4539@TQFP44 [(SA245A)]  
PIC18LF4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4550  
PIC18LF4550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4550@QFN44 [(SA712)]  
PIC18LF4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ML) [(SA737)]  
PIC18LF4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4550@TQFP44 [(SA245A)]  
PIC18LF4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF458 PIC18LF458(ISP) [ISP-  
HEADER01]  
PIC18LF458@PLCC44 [(SA244)]  
PIC18LF458@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF458@TQFP44 [(SA245A)]  
PIC18LF458@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4580  
PIC18LF4580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4580@QFN44 [(SA712)]  
PIC18LF4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ML) [(SA737)]  
PIC18LF4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4580@TQFP44 [(SA245A)]  
PIC18LF4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585  
PIC18LF4585(ISP)(High-V) [ISP-HEADER01]

PIC18LF4585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585@QFN44 [(SA712)]  
PIC18LF4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ML) [(SA737)]  
PIC18LF4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44 [(SA245A)]  
PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF45J10 PIC18LF45J10(ISP) [ISP-  
HEADER01]  
PIC18LF45J10@QFN44 [(SA712)]  
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18LF45J10@QFN44(ML) [(SA709)]  
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF45J10@TQFP44 [(SA245A)]  
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4610  
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44 [(SA712)]  
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44(ML) [(SA737)]  
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4610@TQFP44 [(SA245A)]  
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620  
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44 [(SA712)]  
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44(ML) [(SA737)]  
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4620@TQFP44 [(SA245A)]  
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680  
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44 [(SA712)]  
PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML) [(SA737)]  
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]

PIC18LF4680@TQFP44 [(SA245A)]  
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682  
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44 [(SA712)]  
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML) [(SA737)]  
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44 [(SA245A)]  
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685  
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44 [(SA712)]  
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML) [(SA737)]  
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44 [(SA245A)]  
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6390@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF63J11@TQFP64(\*) [(SA732+B340)]  
PIC18LF63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF63J90@TQFP64(\*) [(SA732+B340)]  
PIC18LF63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6490@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF64J11@TQFP64(\*) [(SA732+B340)]  
PIC18LF64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF64J90@TQFP64(\*) [(SA732+B340)]  
PIC18LF64J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6520@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6525@TQFP64(ISP) [ISP-HEADER01]

PIC18LF6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18LF6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF65J11@TQFP64(\*) [(SA732+B340)]  
PIC18LF65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF65J90@TQFP64(\*) [(SA732+B340)]  
PIC18LF65J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18LF6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8310@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF83J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF84J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8585@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]

PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC30F2010 PIC30F2010(ISP) [ISP-  
HEADER01]  
PIC30F2010@SDIP28 [(SA022A)]  
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2010@SOIC28 [(SA404)]  
PIC30F2010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F2011(ISP) [ISP-HEADER01]  
PIC30F2011@QFN28(ISP) [ISP-HEADER01]  
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]  
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]  
PIC30F2012(ISP) [ISP-HEADER01]  
PIC30F2012@QFN28(ISP) [ISP-HEADER01]  
PIC30F2012@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2012@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3010(ISP) [ISP-HEADER01]  
PIC30F3010@QFN44(ISP) [ISP-HEADER01]  
PIC30F3010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F3010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3011(ISP) [ISP-HEADER01]  
PIC30F3011@QFN44(ISP) [ISP-HEADER01]  
PIC30F3011@QFP44(ISP) [ISP-HEADER01]  
PIC30F3012(ISP) [ISP-HEADER01]  
PIC30F3012@QFN44(ISP) [ISP-HEADER01]  
PIC30F3012@QFP44(ISP) [ISP-HEADER01]  
PIC30F3012@SDIP18(ISP) [ISP-HEADER01]  
PIC30F3012@SOIC18(ISP) [ISP-HEADER01]  
PIC30F3013(ISP) [ISP-HEADER01]  
PIC30F3013@QFN44(ISP) [ISP-HEADER01]  
PIC30F3013@QFP44(ISP) [ISP-HEADER01]  
PIC30F3013@SDIP28(ISP) [ISP-HEADER01]  
PIC30F3013@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3014(ISP) [ISP-HEADER01]  
PIC30F3014@QFN44(ISP) [ISP-HEADER01]  
PIC30F3014@QFP44(ISP) [ISP-HEADER01]  
PIC30F4011(ISP) [ISP-HEADER01]  
PIC30F4011@QFN44(ISP) [ISP-HEADER01]  
PIC30F4011@QFP44(ISP) [ISP-HEADER01]  
PIC30F4012(ISP) [ISP-HEADER01]  
PIC30F4012@QFN44(ISP) [ISP-HEADER01]  
PIC30F4012@SDIP28(ISP) [ISP-HEADER01]

PIC30F4012@SOIC28(ISP) [ISP-HEADER01]  
 PIC30F4013(ISP) [ISP-HEADER01]  
 PIC30F4013@QFN44(ISP) [ISP-HEADER01]  
 PIC30F4013@QFP44(ISP) [ISP-HEADER01]  
 PIC30F5011@QFP64(ISP) [ISP-HEADER01]  
 PIC30F5013@QFP80(ISP) [ISP-HEADER01]  
 PIC30F5015@QFP64(ISP) [ISP-HEADER01]  
 PIC30F5016@QFP80(ISP) [ISP-HEADER01]  
 PIC30F6010@QFP80(ISP) [ISP-HEADER01]  
 PIC30F6010@TQFP80(ISP) [ISP-HEADER01]  
 PIC30F6010A@QFP80(ISP) [ISP-HEADER01]  
 PIC30F6010A@TQFP80(ISP) [ISP-HEADER01]  
 PIC30F6011@QFP64(ISP) [ISP-HEADER01]  
 PIC30F6011A@QFP64(ISP) [ISP-HEADER01]  
 PIC30F6012@QFP64(ISP) [ISP-HEADER01]  
 PIC30F6012A@QFP64(ISP) [ISP-HEADER01]  
 PIC30F6013@QFP80(ISP) [ISP-HEADER01]  
 PIC30F6013A@QFP80(ISP) [ISP-HEADER01]  
 PIC30F6014@QFP80(ISP) [ISP-HEADER01]  
 PIC30F6014@TQFP80(ISP) [ISP-HEADER01]  
 PIC30F6014A@QFP80(ISP) [ISP-HEADER01]  
 PIC30F6014A@TQFP80(ISP) [ISP-HEADER01]  
 PIC30F6015@QFP64(ISP) [ISP-HEADER01]  
 PS200 PS200(ISP) [ISP-  
 HEADER01]  
 PS200@SOIC20 [(SA404)] PS200@SOIC20(ISP) [ISP-  
 HEADER01]  
 PS200@SSOP20 [(SA626A)] PS200@SSOP20(ISP) [ISP-  
 HEADER01]  
 rfPIC12C509AF@SSOP20 [(SA626A)]  
 rfPIC12C509AF@SSOP20(ISP) [ISP-HEADER01]  
 rfPIC12C509AG@SOIC18 [(SA404)]  
 rfPIC12C509AG@SOIC18(ISP) [ISP-HEADER01]  
 rfPIC12LC509AF@SSOP20 [(SA626A)]  
 rfPIC12LC509AF@SSOP20(ISP) [ISP-HEADER01]  
 rfPIC12LC509AG@SOIC18 [(SA404)]  
 rfPIC12LC509AG@SOIC18(ISP) [ISP-HEADER01]

## MICRON

### E (E) PROM/FRAM/NVRAM



MT28F002B1VG-B@TSOP40 [(SA409T)]	MT28F002B1VG-T@TSOP40
[(SA409T)]	
MT28F002B3VG-B@TSOP40 [(SA409T)]	MT28F002B3VG-T@TSOP40
[(SA409T)]	
MT28F002B5VG-B@TSOP40 [(SA409T)]	MT28F002B5VG-T@TSOP40
[(SA409T)]	
MT28F002C1VG-T@TSOP40 [(SA409T)]	MT28F002C5VG-T@TSOP40
[(SA409T)]	
MT28F002VG-B@TSOP40 [(SA409T)]	MT28F002VG-T@TSOP40
[(SA409T)]	
MT28F004B1VG-B@TSOP40 [(SA409T)]	MT28F004B1VG-T@TSOP40
[(SA409T)]	
MT28F004B3VG-B@TSOP40 [(SA409T)]	MT28F004B3VG-T@TSOP40
[(SA409T)]	
MT28F004B5VG-B@TSOP40 [(SA409T)]	MT28F004B5VG-T@TSOP40
[(SA409T)]	
MT28F004VG-B@TSOP40 [(SA409T)]	MT28F004VG-T@TSOP40
[(SA409T)]	
MT28F008B1VG-B@TSOP40 [(SA409T)]	MT28F008B1VG-T@TSOP40
[(SA409T)]	
MT28F008B3VG-B@TSOP40 [(SA409T)]	MT28F008B3VG-T@TSOP40
[(SA409T)]	
MT28F008B5VG-B@TSOP40 [(SA409T)]	MT28F008B5VG-T@TSOP40
[(SA409T)]	
MT28F016S3VG@TSOP40 [(SA409T)]	MT28F016S5VG@TSOP40
[(SA409T)]	
MT28F1284W18BQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]	
MT28F1284W18TQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]	
MT28F128J3A(FW203)(I.)@FBGA64 [(SA655A-B054A-T064F001)]	
MT28F128J3A(FW501)(I.)@FBGA64 [(SA655A-B054A-T064F001)]	
MT28F128J3A(FW502)(M.)@FBGA64 [(SA655A-B054A-T064F001)]	
MT28F128J3A(FW503)(M.)@FBGA64 [(SA655A-B054A-T064F001)]	
MT28F128J3A(INTEL)@TSOP56 [(SA628-B018)]	
MT28F128J3A(MICRON)@TSOP56 [(SA628-B018)]	
MT28F200B1SGB@PSOP44 [(SA638)]	MT28F200B1SGT@PSOP44
[(SA638)]	
MT28F200B1WGB@TSOP48 [(SA247-B005)]	
MT28F200B1WGT@TSOP48 [(SA247-B005)]	
MT28F200B3SGB@PSOP44 [(SA638)]	MT28F200B3SGT@PSOP44
[(SA638)]	
MT28F200B3WGB@TSOP48 [(SA247-B005)]	
MT28F200B3WGT@TSOP48 [(SA247-B005)]	
MT28F200B5SGB@PSOP44 [(SA638)]	MT28F200B5SGT@PSOP44

[ ( SA638 ) ]  
MT28F200B5WGB@TSOP48 [ ( SA247-B005 ) ]  
MT28F200B5WGT@TSOP48 [ ( SA247-B005 ) ]  
MT28F320J3A(FW201)(I.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F320J3A(FW204)(M.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F320J3A(FW207)(I.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F320J3A(FW208)(M.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F320J3A(INTEL)@TSOP56 [ ( SA628-B018 ) ]  
MT28F320J3A(MICRON)@TSOP56 [ ( SA628-B018 ) ]  
MT28F400B1SGB@PSOP44 [ ( SA638 ) ] MT28F400B1SGT@PSOP44  
[ ( SA638 ) ]  
MT28F400B1WGB@TSOP48 [ ( SA247-B005 ) ]  
MT28F400B1WGT@TSOP48 [ ( SA247-B005 ) ]  
MT28F400B3SGB@PSOP44 [ ( SA638 ) ] MT28F400B3SGT@PSOP44  
[ ( SA638 ) ]  
MT28F400B3WGB@TSOP48 [ ( SA247-B005 ) ]  
MT28F400B3WGT@TSOP48 [ ( SA247-B005 ) ]  
MT28F400B5SGB@PSOP44 [ ( SA638 ) ] MT28F400B5SGT@PSOP44  
[ ( SA638 ) ]  
MT28F400B5WGB@TSOP48 [ ( SA247-B005 ) ]  
MT28F400B5WGT@TSOP48 [ ( SA247-B005 ) ]  
MT28F640J3A(FW202)(I.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F640J3A(FW205)(M.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F640J3A(FW206)(I.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F640J3A(FW209)(M.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F640J3A(FW505)(I.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F640J3A(FW506)(M.)@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
MT28F640J3A(INTEL)@TSOP56 [ ( SA628-B018 ) ]  
MT28F640J3A(MICRON)@TSOP56 [ ( SA628-B018 ) ]  
MT28F800B1SGB@PSOP44 [ ( SA638 ) ] MT28F800B1SGT@PSOP44  
[ ( SA638 ) ]  
MT28F800B1WGB@TSOP48 [ ( SA247-B005 ) ]  
MT28F800B1WGT@TSOP48 [ ( SA247-B005 ) ]  
MT28F800B3SGB@PSOP44 [ ( SA638 ) ] MT28F800B3SGT@PSOP44  
[ ( SA638 ) ]  
MT28F800B3WGB@TSOP48 [ ( SA247-B005 ) ]  
MT28F800B3WGT@TSOP48 [ ( SA247-B005 ) ]  
MT28F800B5SGB@PSOP44 [ ( SA638 ) ] MT28F800B5SGT@PSOP44  
[ ( SA638 ) ]  
MT28F800B5WGB@TSOP48 [ ( SA247-B005 ) ]  
MT28F800B5WGT@TSOP48 [ ( SA247-B005 ) ]  
MT29F1G08ABAWP@TSOP48 [ ( SA247-B005 ) ]  
MT29F2G08AAAWG@TSOP48 [ ( SA247-B005 ) ]

MT29F2G08AABWP@TSOP48 [ ( SA247-B005 ) ]  
MT29F2G08AACWP@TSOP48 [ ( SA247-B005 ) ]  
MT29F4G08AAAWP@TSOP48 [ ( SA247-B005 ) ]  
MT29F4G08BAB@TSOP48 [ ( SA247-B005 ) ]  
MT29F8G08DAA@TSOP48 [ ( SA247-B005 ) ]

## DRAM & SRAM

MTSRAM@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]

## MICRONAS

### MICROCONTROLLER

SDA555XFL@SDIP52( \* ) [ ( SA627-B5603 ) ]

## MICRON-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

MT29F4G08AAAWP ( sony ) @TSOP48 [ ( SA247+B005 ) ]

## MITSUBISHI

### E ( E ) PROM / FRAM / NVRAM

M5L27128K  
M5L2716  
M5L27256K  
M5L2732  
M5L2732A  
M5L27512  
M5L27512K  
M5L2764K  
M5L27C512A  
M5M27128P  
M5M27256P  
M5M27512P

M5M2764P	
M5M27C100K	
M5M27C100K@PLCC32 [(SA015A1T)]	M5M27C100K@TSOP32
[(SA410T)]	
M5M27C100P	M5M27C100P@PLCC32
[(SA015A1T)]	
M5M27C100P@TSOP32 [(SA410T)]	
M5M27C101JK	
M5M27C101JK@PLCC32 [(SA015A1T)]	M5M27C101JK@TSOP32
[(SA410T)]	
M5M27C101K	M5M27C101K@PLCC32
[(SA015A1T)]	
M5M27C101K@TSOP32 [(SA410T)]	
M5M27C101P	
M5M27C101P@PLCC32 [(SA015A1T)]	M5M27C101P@TSOP32
[(SA410T)]	
M5M27C102K	M5M27C102K@PLCC44
[(SA244)]	
M5M27C102P	M5M27C102P@PLCC44
[(SA244)]	
M5M27C128K	
M5M27C201K	
M5M27C201K@PLCC32 [(SA015A1T)]	M5M27C201K@TSOP32
[(SA410T)]	
M5M27C202K	M5M27C202K@PLCC44
[(SA244)]	
M5M27C256(K)	M5M27C256
(P)	
M5M27C256A(FP)	M5M27C256A
(K)	
M5M27C256A(P)	
M5M27C401K	
M5M27C401K@PLCC32 [(SA015A1T)]	M5M27C401K@TSOP32
[(SA410T)]	
M5M27C402K	M5M27C512
(FP)	
M5M27C512A(FP)	M5M27C512A
(K)	
M5M27C512A(P)	
M5M28F101	
M5M28F101@PLCC32 [(SA015A1T)]	M5M28F101@SOP32
[(SA438T)]	
M5M28F101@TSOP32 [(SA410T)]	

M5M28F101A  
M5M28F101A@PLCC32 [(SA015A1T)] M5M28F101A@SOIC32  
[(SA438T)]  
M5M28F101A@TSOP32 [(SA410T)]  
M5M29FB160A@TSOP48 [(SA247-B005)]  
M5M29FB800(FP)@PSOP44 [(SA638)]  
M5M29FB800(VP)@TSOP48 [(SA247-B005)]  
M5M29FT160A@TSOP48 [(SA247-B005)]  
M5M29FT800(FP)@PSOP44 [(SA638)]  
M5M29FT800(VP)@TSOP48 [(SA247-B005)]  
M5M29GB160B(VP)@TSOP48 [(SA247-B005)]  
M5M29GB320(VP)@TSOP48 [(SA247-B005)]  
M5M29GB320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]  
M5M29GT160B(VP)@TSOP48 [(SA247-B005)]  
M5M29GT320(VP)@TSOP48 [(SA247-B005)]  
M5M29GT320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]  
M5M29JB160A@TSOP48 [(SA247-B005)]  
M5M29JT160A@TSOP48 [(SA247-B005)]  
M6M80011A M6M80011A@SOIC10  
[(SA023A)]  
M6M80011A@SOIC16 [(SA023A)]  
M6M80021  
M6M80021@SOIC10 [(SA023A)] M6M80021@SOIC16  
[(SA023A)]  
M6M80041 M6M80041@SOIC10  
[(SA023A)]  
M6MG3B641S16TP@TSOP52 [(SA657-B036)]  
M6MG3T641S16TP@TSOP52 [(SA657-B036)]  
M6MGB321S4TP@TSOP52 [(SA657-B036)]  
M6MGB321S8TP@TSOP52 [(SA657-B036)]  
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB331S8KT@TSOP52 [(SA657-B036)]  
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB641S16TP@TSOP52 [(SA657-B036)]  
M6MGB641S4TP@TSOP52 [(SA657-B036)]  
M6MGB641S8TP@TSOP52 [(SA657-B036)]  
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]  
M6MGE157S4KT@TSOP52 [(SA657-B055)]  
M6MGT321S4TP@TSOP52 [(SA657-B036)]  
M6MGT321S8TP@TSOP52 [(SA657-B036)]

M6MGT32BS4WG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGT32BS8WG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGT331S8KT@TSOP52 [ (SA657-B036) ]  
M6MGT33BS8AWG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGT641S16TP@TSOP52 [ (SA657-B036) ]  
M6MGT641S4TP@TSOP52 [ (SA657-B036) ]  
M6MGT641S8TP@TSOP52 [ (SA657-B036) ]  
M6MGT64BS4WG@CSP67 [ (SA642F-B023A-T064F001) ]  
M6MGT64BS8WG@CSP67 [ (SA642F-B023A-T064F001) ]

## MICROCONTROLLER

M30240EFCFP@QFP80 (Renesas) [ (PCA7302E1F-80) ]  
M30620EFCFP@QFP100 (Renesas) [ (PCA7412F-100) ]  
M30620ECFS@QFN100 (Renesas) [ (PCA7412L-100) ]  
M30620ECGP@LQFP100 (Renesas) [ (PCA7412G-100) ]  
M30621ECGP@QFP80 (Renesas) [ (PCA7413F-80) ]  
M30622ECTFP@QFP100 (Renesas) [ (PCA7412F-100) ]  
M30623ECTGP@QFP80 (Renesas) [ (PCA7413F-80) ]  
M306V0EEFP@QFP100 (Renesas) [ (PCA7412F-100) ]  
M306V0EEFS@QFN100 (Renesas) [ (PCA7412L-100) ]  
M306V2EEFP@QFP100 (Renesas) [ (PCA7412F-100) ]  
M306V2EEFS@QFN100 (Renesas) [ (PCA7412L-100) ]  
M34282E2GP [ (SA026) ] M34283G2GP  
[ (SA026) ]  
M34283G2GP (ISP) [ ISP-HEADER01 ]  
M34513E4FP@LQFP32 (Renesas) [ (PCA7442FPG02) ]  
M34513E4SP@SDIP32 (Renesas) [ (PCA7442SP) ]  
M34513E8FP@LQFP32 (Renesas) [ (PCA7442FPG02) ]  
M34514E8FP@SSOP42 (Renesas) [ (PCA7441) ]  
M34518E8FP@LQFP32 (Renesas) [ (PCA7442FPG02) ]  
M34518E8SP@SDIP32 (Renesas) [ (PCA7442SP) ]  
M34519E8FP@SSOP42 (Renesas) [ (PCA7441) ]  
M34524EDFP@QFP64 (Renesas) [ (PCA7448) ]  
M34551E8FP@QFP48 (Renesas) [ (PCA7414) ]  
M34554EDFP@QFP64 (Renesas) [ (PCA7448) ]  
M34570E8FP@SSOP36 (Renesas) [ (PCA7425) ]  
M34570EDFP@SSOP36 (Renesas) [ (PCA7425) ]  
M34583EDFP@LQFP32 (Renesas) [ (PCA7442FPG02) ]  
M34584EDFP@SSOP42 (Renesas) [ (PCA7441) ]  
M37150EFP@SSOP42 (Renesas) [ (PCA7450FP) ]  
M37151EFP@SSOP42 (Renesas) [ (PCA7450FP) ]

M37160EFFF@SSOP42 (Renesas) [(PCA7450FP)]  
M37161EFFF@SSOP42 (Renesas) [(PCA7450FP)]  
M37516E6HKP@QFN44 (Renesas) [(PCA7446)]  
M37516E6HP@LQFP48 (Renesas) [(PCA7419)]  
M37540E2FP@SSOP36 (Renesas) [(PCA7435FPG02)]  
M37540E2GP@LQFP32 (Renesas) [(PCA7435GPG03)]  
M37540E2SP@SDIP32 (Renesas) [(PCA7435SPG02)]  
M37540E8FP@SSOP36 (Renesas) [(PCA7435FPG02)]  
M37540E8GP@LQFP32 (Renesas) [(PCA7435GPG03)]  
M37540E8SP@SDIP32 (Renesas) [(PCA7435SPG02)]  
M37544G2A(GP)@LQFP32 [(SA663)]  
M37544G2A(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32  
[(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36  
[(SA645)]  
M37546G2(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]  
M37547G4(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20  
[(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24  
[(SA653)]  
M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24  
[(SA653)]  
M37560EFDFFP@QFP100 (Renesas) [(PCA4738F-100A)]  
M37560EFFF@QFN100 (Renesas) [(PCA4738L-100A)]  
M37560EFFF@QFP100 (Renesas) [(PCA4738F-100A)]  
M37560EFGP@LQFP100 (Renesas) [(PCA4738G-100A)]

M37630E4FP@QFP44 (Renesas) [(PCA7430)]  
M37630E4FS@QFN80 (Renesas) [(PCA7431)]  
M37640E8FP@QFP80 (Renesas) [(PCA7440FP)]  
M37640E8FS@QFN80 (Renesas) [(PCA7440FS)]  
M37733EHBFP@QFP80 (Renesas) [(PCA4774G05)]  
M37733EHBFS@QFN80 (Renesas) [(PCA4708G05)]  
M37735EHBFP@QFP80 (Renesas) [(PCA4774G05)]  
M37735EHBFS@QFN80 (Renesas) [(PCA4708G05)]  
M37736EHBGP@QFP100 (Renesas) [(PCA7422GPG02)]  
M37736EHBGS@QFN100 (Renesas) [(PCA7422GSG02)]  
M37751E6CFP@QFP80 (Renesas) [(PCA4774G05)]  
M37751E6CFS@QFN80 (Renesas) [(PCA4708G05)]  
M37751F6CFP@QFP80 (Renesas) [(PCA4774G05)]  
M38027E8DFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]  
M38027E8DSP@DIP64 (Mitsubishi) [(BBBB)]  
M38027E8DXXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]  
M38027E8DXXXSP@DIP64 (Mitsubishi) [(BBBB)]  
M38027E8FS@LCC64 (Mitsubishi) [(BBBB)]  
M38027E8SP@DIP64 (Mitsubishi) [(BBBB)]  
M38027E8SS@DIP64 (Mitsubishi) [(BBBB)]  
M38027E8-XXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]  
M38027E8-XXXSP@DIP64 (Mitsubishi) [(BBBB)]  
M38027M8-XXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]  
M38039FFFP@QFP64 (Renesas) [(PCA4738FF-64)]  
M38039FFHP@LQFP64 (Renesas) [(PCA4738HF-64)]  
M38039FFSP@SDIP64 (Renesas) [(PCA4738SF-64)]  
M38049FFFP@QFP64 (Renesas) [(PCA4738FF-64)]  
M38049FFHP@LQFP64 (Renesas) [(PCA4738HF-64)]  
M38049FFSP@SDIP64 (Renesas) [(PCA4738SF-64)]  
M38223E4FP@QFP80 (Renesas) [(PCA4738F-80A)]  
M38223E4FS@QFN80 (Renesas) [(PCA4738L-80A)]  
M38223E4GP@QFP80 (Renesas) [(PCA4738G-80A)]  
M38223E4HP@LQFP80 (Renesas) [(PCA4738H-80A)]  
M38227ECFP@QFP80 (Renesas) [(PCA4738F-80A)]  
M38227ECFS@QFN80 (Renesas) [(PCA4738L-80A)]  
M38227ECHP@LQFP80 (Renesas) [(PCA4738H-80A)]  
M38267E8FP@QFP100 (Renesas) [(PCA4738F-100A)]  
M38267E8GP@LQFP100 (Renesas) [(PCA4738G-100A)]  
M3826AEFFP@QFP100 (Renesas) [(PCA4738F-100A)]  
M3826AEFFS@QFN100 (Renesas) [(PCA4738L-100A)]  
M3826AEFGP@LQFP100 (Renesas) [(PCA4738G-100A)]  
M38504E6FP@SSOP42 (Renesas) [(PCA4738F-42A)]  
M38504E6SP@SDIP42 (Renesas) [(PCA4738S-42A)]



M38504E6SS@SDIP42 (Renesas) [(PCA4738S-42A)]  
M38514E6FP@SSOP42 (Renesas) [(PCA4738F-42A)]  
M38514E6SP@SDIP42 (Renesas) [(PCA4738S-42A)]  
M38514E6SS@SDIP42 (Renesas) [(PCA4738S-42A)]  
M38867E8AFS@QFN80 (Renesas) [(PCA4738L-80A)]  
M38867E8AHP@LQFP80 (Renesas) [(PCA4738H-80A)]  
M38869FFAGP@QFP80 (Renesas) [(PCA4738GF-80)]  
M38869FFAHP@LQFP80 (Renesas) [(PCA4738HF-80)]  
M38B79FFFP@QFP100 (Renesas) [(PCA7438FF-100)]  
M38C13E6FP@LQFP64 (Renesas) [(PCA7438F-64A)]  
M38C13E6HP@QFP64 (Renesas) [(PCA7438H-64A)]  
M38C89EFFP@LQFP144 (Renesas) [(PCA7447FP)]  
R5F21102DFP@TQFP32 [(SA663+B005)]  
R5F21102DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21103DFP@TQFP32 [(SA663+B005)]  
R5F21103DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21103FP@TQFP32 [(SA663+B005)]  
R5F21103FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21104DFP@TQFP32 [(SA663+B005)]  
R5F21104DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21104FP@TQFP32 [(SA663+B005)]  
R5F21104FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21112DFP@TQFP32 [(SA663+B005)]  
R5F21112DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21112FP@TQFP32 [(SA663+B005)]  
R5F21112FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21113DFP@TQFP32 [(SA663+B005)]  
R5F21113DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21113FP@TQFP32 [(SA663+B005)]  
R5F21113FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21114DFP@TQFP32 [(SA663+B005)]  
R5F21114DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21114FP@TQFP32 [(SA663+B005)]  
R5F21114FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21122DFP@TQFP32 [(SA663+B005)]  
R5F21122DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21122FP@TQFP32 [(SA663+B005)]  
R5F21122FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21123DFP@TQFP32 [(SA663+B005)]  
R5F21123DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21123FP@TQFP32 [(SA663+B005)]

R5F21123FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124DFP@TQFP32 [(SA663+B005)]  
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124FP@TQFP32 [(SA663+B005)]  
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132DFP@TQFP32 [(SA663+B005)]  
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132FP@TQFP32 [(SA663+B005)]  
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]  
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725-B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725-B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026-B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026-B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725-B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725-B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026-B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697-B006)]

R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697-B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026-B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725-B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725-B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21183DSP@TSSOP20 [(SA026-B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697-B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697-B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026-B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725-B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725-B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026-B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697-B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697-B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]

R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026-B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725-B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026-B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026-B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725-B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026-B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697-B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026-B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725-B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]

R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026-B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697-B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026-B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725-B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026-B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697-B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026-B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725-B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]

R5F211A1DSP@TSSOP20 [(SA026-B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026-B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725-B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026-B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697-B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697-B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026-B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725-B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026-B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697-B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697-B006)]

R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026-B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725-B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026-B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697-B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697-B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026-B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725-B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026-B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026-B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725-B005)]

R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026-B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697-B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B2SP@TSSOP20 [(SA026-B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725-B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026-B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697-B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026-B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725-B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]



R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026-B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697-B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026-B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21206JFP@TQFP48 [(SA248-B005)]  
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21206KFP@TQFP48 [(SA248-B005)]  
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207JFP@TQFP48 [(SA248-B005)]  
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207KFP@TQFP48 [(SA248-B005)]  
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208JFP@TQFP48 [(SA248-B005)]  
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208KFP@TQFP48 [(SA248-B005)]  
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AJFP@TQFP48 [(SA248-B005)]  
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AKFP@TQFP48 [(SA248-B005)]  
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CJFP@TQFP48 [(SA248-B005)]  
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]

R5F2120CKFP@TQFP48 [(SA248-B005)]  
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216JFP@TQFP48 [(SA248-B005)]  
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216KFP@TQFP48 [(SA248-B005)]  
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217JFP@TQFP48 [(SA248-B005)]  
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217KFP@TQFP48 [(SA248-B005)]  
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218JFP@TQFP48 [(SA248-B005)]  
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218KFP@TQFP48 [(SA248-B005)]  
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AJFP@TQFP48 [(SA248-B005)]  
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AKFP@TQFP48 [(SA248-B005)]  
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CJFP@TQFP48 [(SA248-B005)]  
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CKFP@TQFP48 [(SA248-B005)]  
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226JFP@TQFP48 [(SA248-B005)]  
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226KFP@TQFP48 [(SA248-B005)]  
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227JFP@TQFP48 [(SA248-B005)]  
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227KFP@TQFP48 [(SA248-B005)]

R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228JFP@TQFP48 [(SA248-B005)]  
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228KFP@TQFP48 [(SA248-B005)]  
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122AJFP@TQFP48 [(SA248-B005)]  
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122AKFP@TQFP48 [(SA248-B005)]  
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122CJFP@TQFP48 [(SA248-B005)]  
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122CKFP@TQFP48 [(SA248-B005)]  
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21236JFP@TQFP48 [(SA248-B005)]  
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21236KFP@TQFP48 [(SA248-B005)]  
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21237JFP@TQFP48 [(SA248-B005)]  
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21237KFP@TQFP48 [(SA248-B005)]  
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21238JFP@TQFP48 [(SA248-B005)]  
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21238KFP@TQFP48 [(SA248-B005)]  
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123AJFP@TQFP48 [(SA248-B005)]  
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123AKFP@TQFP48 [(SA248-B005)]  
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]

R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123CJFP@TQFP48 [(SA248-B005)]  
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123CKFP@TQFP48 [(SA248-B005)]  
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]

R5F21262DFP@QFP32 [(SA663)]  
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]  
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]  
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]  
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]  
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]  
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]

R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]  
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]  
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]  
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]

R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]  
R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]



R5F21272KFP@QFP32(single wire) [(SA663)]  
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]  
R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]  
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]  
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]  
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]  
R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]  
R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]

R5F21274NFP@QFP32 [(SA663)]  
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]  
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]  
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(single wire) [(SA663)]  
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(UART mode) [(SA663)]  
R5F21274SKFP@QFP32 [(SA663)]  
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(single wire) [(SA663)]  
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(UART mode) [(SA663)]  
R5F21274SNFP@QFP32 [(SA663)]  
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(single wire) [(SA663)]  
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(UART mode) [(SA663)]  
R5F21275DFP@QFP32 [(SA663)]  
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(single wire) [(SA663)]  
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]  
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]

R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]  
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]  
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]  
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]

R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]  
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21284SJSP@SOIC20(single wire) [(SA026)]  
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]  
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]  
R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]  
R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]

R5F21292SKSP@SOIC20 [(SA026)]  
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]  
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]  
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]  
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]  
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]  
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]

R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]



R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]

R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32 [(SA663)]  
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]  
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]  
R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026-B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)])  
R5F212H1SNSP@TSSOP20 [(SA026-B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)])  
R5F212H2SDSP@TSSOP20 [(SA725-B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]

R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)])  
R5F212H2SNSP@TSSOP20 [(SA725-B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)])  
R5F212J0SDSP@TSSOP20 [(SA026-B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)])  
R5F212J0SNSP@TSSOP20 [(SA026-B001)]  
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)])  
R5F212J1SDSP@TSSOP20 [(SA026-B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)])  
R5F212J1SNSP@TSSOP20 [(SA026-B001)]  
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)])  
R5F212K2SDFP@QFP32 [(SA663-B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SDFP@QFP32(single wire) [(SA663-B005)]  
R5F212K2SNFP@QFP32 [(SA663-B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SNFP@QFP32(single wire) [(SA663-B005)]  
R5F212K4SDFP@QFP32 [(SA663-B005)]  
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SDFP@QFP32(single wire) [(SA663-B005)]  
R5F212K4SNFP@QFP32 [(SA663-B005)]  
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SNFP@QFP32(single wire) [(SA663-B005)]  
R5F212L2SDFP@QFP32 [(SA663-B005)]  
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212L2SNFP@QFP32 [(SA663-B005)]  
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]  
R5F212L4SDFP@QFP32 [(SA663-B005)]  
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212L4SNFP@QFP32 [(SA663-B005)]  
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]

## MOSEL-VITELIC

**E ( E ) PROM / FRAM / NVRAM**

V29C31004B [ ( SA015A1T ) ]	V29C31004B@PLCC32
V29C31004B@TSOP32 [ ( SA410T ) ]	
V29C31004T V29C31004T@PLCC32 [ ( SA015A1T ) ]	V29C31004T@TSOP32
[ ( SA410T ) ]	
V29C51000B [ ( SA015A1T ) ]	V29C51000B@PLCC32
V29C51000T [ ( SA015A1T ) ]	V29C51000T@PLCC32
V29C51001B [ ( SA015A1T ) ]	V29C51001B@PLCC32
V29C51001B@TSOP32 [ ( SA410T ) ]	
V29C51001T V29C51001T@PLCC32 [ ( SA015A1T ) ]	V29C51001T@TSOP32
[ ( SA410T ) ]	
V29C51002B [ ( SA015A1T ) ]	V29C51002B@PLCC32
V29C51002B@TSOP32 [ ( SA410T ) ]	
V29C51002T V29C51002T@PLCC32 [ ( SA015A1T ) ]	V29C51002T@TSOP32
[ ( SA410T ) ]	
V29C51004B [ ( SA015A1T ) ]	V29C51004B@PLCC32
V29C51004B@TSOP32 [ ( SA410T ) ]	
V29C51004T V29C51004T@PLCC32 [ ( SA015A1T ) ]	V29C51004T@TSOP32
[ ( SA410T ) ]	
V29LC51000 [ ( SA015A1T ) ]	V29LC51000@PLCC32
V29LC51001 [ ( SA015A1T ) ]	V29LC51001@PLCC32
V29LC51002 [ ( SA015A1T ) ]	V29LC51002@PLCC32

**MICROCONTROLLER**

MSU1958 [ ( SA244 ) ]	MSU1958@PLCC44
--------------------------	----------------

MSU1958@TQFP44 [ ( SA245A ) ]  
MSU2952  
MSU2952@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
MSU2958  
[ ( SA244 ) ]  
MSU2958@TQFP44 [ ( SA245A ) ]  
MSU2964  
MSU2964@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]

MSU2952@TQFP44  
  
MSU2958@PLCC44  
  
MSU2964@TQFP44

## **MOSTEK**

### **E ( E ) PROM / FRAM / NVRAM**

ET2716  
ETC2716  
ETC2732  
MK2716  
MK2764  
MK48C02  
MK48C12  
MK48T02  
MK48T08  
MK48T12  
MK48T12B  
MK48T18  
MK48Z02  
MK48Z08  
MK48Z12  
MK48Z12B  
MK48Z18

## **MOTOROLA**

### **E ( E ) PROM / FRAM / NVRAM**

MC68764  
MC68766  
MCM2716

## DRAM & SRAM

MCM2018A [ ( SA015A1T ) ]	MCM2018A@PLCC32
MCM60256A [ ( SA630 ) ]	MCM60256A@SOIC28
MCM60256AC [ ( SA630 ) ]	MCM60256AC@SOIC28
MCM60256AV [ ( SA630 ) ]	MCM60256AV@SOIC28
MCM60L256A [ ( SA630 ) ]	MCM60L256A@SOIC28
MCM60L256AC [ ( SA630 ) ]	MCM60L256AC@SOIC28
MCM60L256AV [ ( SA630 ) ]	MCM60L256AV@SOIC28
MCM6206 [ ( SA630 ) ]	MCM6206@SOIC28
MCM6206C [ ( SA630 ) ]	MCM6206C@SOIC28
MCM6207 [ ( SA646 ) ]	MCM6207@SOJ24
MCM6207C [ ( SA646 ) ]	MCM6207C@SOJ24
MCM6208 [ ( SA646 ) ]	MCM6208@SOJ24
MCM6208C [ ( SA646 ) ]	MCM6208C@SOJ24
MCM6209 [ ( SA646 ) ]	MCM6209@SOJ28
MCM6209C [ ( SA646 ) ]	MCM6209C@SOJ28
MCM6229 [ ( SA646 ) ]	MCM6229 ( 300m )@SOJ28
MCM6229 ( 400m )@SOJ28 [ ( SA661 ) ]	
MCM6229A MCM6229A ( 300m )@SOJ28 [ ( SA646 ) ]	MCM6229A ( 400m )@SOJ28
[ ( SA661 ) ]	
MCM6264 [ ( SA630 ) ]	MCM6264@SOIC28
MCM6264C	MCM6264C@SOIC28

[ ( SA630 ) ]	
MCM6268	
MCM6269	
MCM6287	MCM6287@SOJ24
[ ( SA646 ) ]	
MCM6288	MCM6288@SOJ22
[ ( SA646 ) ]	
MCM6288B	MCM6288B@SOJ22
[ ( SA646 ) ]	
MCM6288C	MCM6288C@SOJ22
[ ( SA646 ) ]	
MCM6290	MCM6290@SOJ24
[ ( SA646 ) ]	
MCM6290B	MCM6290B@SOJ24
[ ( SA646 ) ]	
MCM6290C	MCM6290C@SOJ24
[ ( SA646 ) ]	
MCM62L07	MCM62L07@SOJ24
[ ( SA646 ) ]	
MCM62L08	MCM62L08@SOJ24
[ ( SA646 ) ]	
MCM62L09	MCM62L09@SOJ28
[ ( SA646 ) ]	
MCM6706	MCM6706@SOIC28
[ ( SA630 ) ]	
MCM6706A	MCM6706A@SOJ28
[ ( SA646 ) ]	
MCM6708A	MCM6708A@SOJ24
[ ( SA646 ) ]	
MCM6709A	MCM6709A@SOJ28
[ ( SA646 ) ]	

## MICROCONTROLLER

MC56F8011VF AE@QFP32	[ ( SA663+B005 ) ]
MC56F8013VF AE@QFP32	[ ( SA663+B005 ) ]
MC56F8014VF AE@QFP32	[ ( SA663+B005 ) ]
MC56F8023MF AE@QFP32	[ ( SA663+B005 ) ]
MC56F8023VF AE@QFP32	[ ( SA663+B005 ) ]
MC56F8025VLD@QFP44	[ ( SA245A+B005 ) ]
MC56F8036MF AE@QFP48	[ ( SA248+B005 ) ]
MC56F8036VF AE@QFP48	[ ( SA248+B005 ) ]

MC56F8037VLH@QFP64 [(PEP+S616)]  
MC68HC908AP16CB(S)@SDIP42 [(SA028)]  
MC68HC908AP16CB@SDIP42 [(SA028)]  
MC68HC908AP16CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP16CFA@LQFP48 [(SA248)]  
MC68HC908AP16CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP16CFB@TQFP44 [(SA675)]  
MC68HC908AP32CB(S)@SDIP42 [(SA028)]  
MC68HC908AP32CB@SDIP42 [(SA028)]  
MC68HC908AP32CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP32CFA@LQFP48 [(SA248)]  
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP32CFB@TQFP44 [(SA675)]  
MC68HC908AP64CB@SDIP42 [(SA028)]  
MC68HC908AP64CFA@LQFP48 [(SA248)]  
MC68HC908AP64CFB@TQFP44 [(SA675)]  
MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
MC68HC908AP8CB@SDIP42 [(SA028)]  
MC68HC908AP8CFA(S)@@LQFP48 [(SA248)]  
MC68HC908AP8CFA@@LQFP48 [(SA248)]  
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP8CFB@TQFP44 [(SA675)]  
MC68HC908EY16CFA@TQFP32 [(SA663)]  
MC68HC908EY16MFA@TQFP32 [(SA663)]  
MC68HC908EY16VFA@TQFP32 [(SA663)]  
MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32  
[(SA663)]  
MC68HC908EY8VFA@TQFP32 [(SA663)]  
MC68HC908GP32  
MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44  
[(SA675)]  
MC68HC908GR16CFA@TQFP48 [(SA248)]  
MC68HC908GR16CFJ@TQFP32 [(SA663)]  
MC68HC908GR16MFA@TQFP48 [(SA248)]  
MC68HC908GR16MFJ@TQFP32 [(SA663)]  
MC68HC908GR16VFA@TQFP48 [(SA248)]  
MC68HC908GR16VFJ@TQFP32 [(SA663)]  
MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32  
[(SA663)]  
MC68HC908GR4CP MC68HC908GR4MDW@SOIC28  
[(SA404)]  
MC68HC908GR4MFA@TQFP32 [(SA663)]  
MC68HC908GR4MP



MC68HC908GR4VDW@SOIC28 [(SA404)]	MC68HC908GR4VFA@TQFP32
[(SA663)]	
MC68HC908GR4VP	MC68HC908GR8CDW@SOIC28
[(SA404)]	
MC68HC908GR8CFA@TQFP32 [(SA663)]	
MC68HC908GR8CP	
MC68HC908GR8MDW@SOIC28 [(SA404)]	MC68HC908GR8MFA@TQFP32
[(SA663)]	
MC68HC908GR8MP	MC68HC908GR8VDW@SOIC28
[(SA404)]	
MC68HC908GR8VFA@TQFP32 [(SA663)]	
MC68HC908GR8VP	
MC68HC908JK1CDW@SOIC20 [(SA404)]	
MC68HC908JK1CP	
MC68HC908JK1ECDW@SOIC20 [(SA404)]	
MC68HC908JK1ECP	
MC68HC908JK1EMDW@SOIC20 [(SA404)]	
MC68HC908JK1EMP	MC68HC908JK1MDW@SOIC20
[(SA404)]	
MC68HC908JK1MP	MC68HC908JK3CDW@SOIC20
[(SA404)]	
MC68HC908JK3CP	
MC68HC908JK3ECDW@SOIC20 [(SA404)]	
MC68HC908JK3ECP	
MC68HC908JK3EMDW@SOIC20 [(SA404)]	
MC68HC908JK3EMP	MC68HC908JK3MDW@SOIC20
[(SA404)]	
MC68HC908JK3MP	MC68HC908JL3CDW@SOIC28
[(SA404)]	
MC68HC908JL3CFA@TQFP48 [(SA248)]	
MC68HC908JL3CP	
MC68HC908JL3ECDW@SOIC28 [(SA404)]	
MC68HC908JL3ECFA@TQFP48 [(SA248)]	
MC68HC908JL3ECP	
MC68HC908JL3EMDW@SOIC28 [(SA404)]	
MC68HC908JL3EMFA@TQFP48 [(SA248)]	
MC68HC908JL3EMP	MC68HC908JL3MDW@SOIC28
[(SA404)]	
MC68HC908JL3MFA@TQFP48 [(SA248)]	
MC68HC908JL3MP	
MC68HC908LB8CDWE(S)@SOIC20	MC68HC908LB8CPE
(S)	
MC68HC908LB8MDWE(S)@SOIC20	MC68HC908LB8MPE

( S )

MC68HC908LB8VDWE ( S ) @SOIC20

MC68HC908LB8VPE

( S )

MC68HC908QT1ACFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT1AMFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT1AVFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT1CDW@SOIC8 [ ( SA605A ) ]

MC68HC908QT1CFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT1CP

MC68HC908QT1MDW@SOIC8

[ ( SA605A ) ]

MC68HC908QT1MFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT1MP

MC68HC908QT1VDW@SOIC8

[ ( SA605A ) ]

MC68HC908QT1VFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT1VP

MC68HC908QT2ACFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT2AMFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT2AVFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT2CDW@SOIC8 [ ( SA605A ) ]

MC68HC908QT2CFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT2CP

MC68HC908QT2MDW@SOIC8

[ ( SA605A ) ]

MC68HC908QT2MFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT2MP

MC68HC908QT2VDW@SOIC8

[ ( SA605A ) ]

MC68HC908QT2VFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT2VP

MC68HC908QT4ACFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT4AMFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT4AVFQE@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT4CDW@SOIC8 [ ( SA605A ) ]

MC68HC908QT4CFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT4CP

MC68HC908QT4MDW@SOIC8

[ ( SA605A ) ]

MC68HC908QT4MFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT4MP

MC68HC908QT4VDW@SOIC8

[ ( SA605A ) ]

MC68HC908QT4VFQ@DFN8 [ ( SA744-B006 ) ]

MC68HC908QT4VP

MC68HC908QY1CDT@TSSOP16 [ ( SA026 ) ]

MC68HC908QY1CDW@SOIC16 [ ( SA404 ) ]

MC68HC908QY1CP

MC68HC908QY1MDT@TSSOP16 [ ( SA026 ) ]

MC68HC908QY1MDW@SOIC16 [ ( SA404 ) ]  
MC68HC908QY1MP  
MC68HC908QY1VDT@TSSOP16 [ ( SA026 ) ]  
MC68HC908QY1VDW@SOIC16 [ ( SA404 ) ]  
MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [ ( SA026 ) ]  
MC68HC908QY2CDW@SOIC16 [ ( SA404 ) ]  
MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [ ( SA026 ) ]  
MC68HC908QY2MDW@SOIC16 [ ( SA404 ) ]  
MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [ ( SA026 ) ]  
MC68HC908QY2VDW@SOIC16 [ ( SA404 ) ]  
MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [ ( SA026 ) ]  
MC68HC908QY4CDW@SOIC16 [ ( SA404 ) ]  
MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [ ( SA026 ) ]  
MC68HC908QY4MDW@SOIC16 [ ( SA404 ) ]  
MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [ ( SA026 ) ]  
MC68HC908QY4VDW@SOIC16 [ ( SA404 ) ]  
MC68HC908QY4VP  
MC68HRC908JK1CDW@SOIC20 [ ( SA404 ) ]  
MC68HRC908JK1CP  
MC68HRC908JK1ECDW@SOIC20 [ ( SA404 ) ]  
MC68HRC908JK1ECP  
MC68HRC908JK1EMDW@SOIC20 [ ( SA404 ) ]  
MC68HRC908JK1EMP  
MC68HRC908JK1MDW@SOIC20 [ ( SA404 ) ]  
MC68HRC908JK1MP  
MC68HRC908JK3CDW@SOIC20 [ ( SA404 ) ]  
MC68HRC908JK3CP  
MC68HRC908JK3ECDW@SOIC20 [ ( SA404 ) ]  
MC68HRC908JK3ECP  
MC68HRC908JK3EMDW@SOIC20 [ ( SA404 ) ]  
MC68HRC908JK3EMP  
MC68HRC908JK3MDW@SOIC20 [ ( SA404 ) ]  
MC68HRC908JK3MP  
MC68HRC908JL3CDW@SOIC28 [ ( SA404 ) ]  
MC68HRC908JL3CFA@TQFP48 [ ( SA248 ) ]  
MC68HRC908JL3CP  
MC68HRC908JL3ECDW@SOIC28 [ ( SA404 ) ]

MC68HRC908JL3ECFA@TQFP48 [(SA248)]  
MC68HRC908JL3ECP  
MC68HRC908JL3EMDW@SOIC28 [(SA404)]  
MC68HRC908JL3EMFA@TQFP48 [(SA248)]  
MC68HRC908JL3EMP  
MC68HRC908JL3MDW@SOIC28 [(SA404)]  
MC68HRC908JL3MFA@TQFP48 [(SA248)]  
MC68HRC908JL3MP  
[(SA028)]  
MC908AP16CFAE@LQFP48 [(SA248)]  
[(SA675)]  
MC908AP32CBE@SDIP42 [(SA028)]  
[(SA248)]  
MC908AP32CFBE@TQFP44 [(SA675)]  
[(SA028)]  
MC908AP64CFAE@LQFP48 [(SA248)]  
[(SA675)]  
MC908AP8CBE@SDIP42 [(SA028)]  
[(SA248)]  
MC908AP8CFBE@TQFP44 [(SA675)]  
[(SA663)]  
MC908EY16AKFJE@TQFP32 [(SA663)]  
[(SA663)]  
MC908EY16AVFJE@TQFP32 [(SA663)]  
[(SA663)]  
MC908EY8AKFJE@TQFP32 [(SA663)]  
[(SA663)]  
MC908EY8AVFJE@TQFP32 [(SA663)]  
[(SA404)]  
MC908JL16CFJE@LQFP32 [(SA663)]  
MC908JL16CPE  
MC908JL16CSPE@SDIP32 [(SA653)]  
[(SA605A)]  
MC908QT1ACPE  
[(SA605A)]  
MC908QT1AMPE  
[(SA605A)]  
MC908QT1AVPE  
[(SA605A)]  
MC908QT2ACPE  
[(SA605A)]  
MC908QT2AMPE  
[(SA605A)]  
MC908AP16CBE@SDIP42  
MC908AP16CFBE@TQFP44  
MC908AP32CFAE@LQFP48  
MC908AP64CBE@SDIP42  
MC908AP64CFBE@TQFP44  
MC908AP8CFAE@@LQFP48  
MC908EY16ACFJE@TQFP32  
MC908EY16AMFJE@TQFP32  
MC908EY8ACFJE@TQFP32  
MC908EY8AMFJE@TQFP32  
MC908JL16CDWE@SOIC28  
MC908QT1ACDWE@SOIC8  
MC908QT1AMDWE@SOIC8  
MC908QT1AVDWE@SOIC8  
MC908QT2ACDWE@SOIC8  
MC908QT2AMDWE@SOIC8  
MC908QT2AVDWE@SOIC8

MC908QT2AVPE [ (SA605A) ]	MC908QT4ACDWE@SOIC8
MC908QT4ACPE [ (SA605A) ]	MC908QT4AMDWE@SOIC8
MC908QT4AMPE [ (SA605A) ]	MC908QT4AVDWE@SOIC8
MC908QT4AVPE [ (SA026) ]	MC908QY1ACDTE@TSSOP16
MC908QY1ACDWE@SOIC16 [ (SA404) ]	
MC908QY1ACPE	
MC908QY1AMDTE@TSSOP16 [ (SA026) ] [ (SA404) ]	MC908QY1AMDWE@SOIC16
MC908QY1AMPE [ (SA026) ]	MC908QY1AVDTE@TSSOP16
MC908QY1AVDWE@SOIC16 [ (SA404) ]	
MC908QY1AVPE	
MC908QY2ACDTE@TSSOP16 [ (SA026) ] [ (SA404) ]	MC908QY2ACDWE@SOIC16
MC908QY2ACPE [ (SA026) ]	MC908QY2AMDTE@TSSOP16
MC908QY2AMDWE@SOIC16 [ (SA404) ]	
MC908QY2AMPE	
MC908QY2AVDTE@TSSOP16 [ (SA026) ] [ (SA404) ]	MC908QY2AVDWE@SOIC16
MC908QY2AVPE [ (SA026) ]	MC908QY4ACDTE@TSSOP16
MC908QY4ACDWE@SOIC16 [ (SA404) ]	
MC908QY4ACPE	
MC908QY4AMDTE@TSSOP16 [ (SA026) ] [ (SA404) ]	MC908QY4AMDWE@SOIC16
MC908QY4AMPE [ (SA026) ]	MC908QY4AVDTE@TSSOP16
MC908QY4AVDWE@SOIC16 [ (SA404) ]	
MC908QY4AVPE	
MC9S08GT16ACB@SDIP42 [ (SA028-B167) ]	
MC9S08GT16ACFB@LQFP44 [ (SA675-B168) ]	
MC9S08GT16ACFD@QFN48 [ (SA696-B166) ]	
MC9S08GT16AMB@SDIP42 [ (SA028-B167) ]	
MC9S08GT16AMFB@LQFP44 [ (SA675-B168) ]	
MC9S08GT16AMFD@QFN48 [ (SA696-B166) ]	
MC9S08GT16CB@SDIP42 [ (SA028-B167) ]	
MC9S08GT16CBE@SDIP42 [ (SA028-B167) ]	
MC9S08GT16CFB@LQFP44 [ (SA675-B168) ]	

MC9S08GT16CFBE@LQFP44 [ (SA675-B168) ]  
MC9S08GT16CFD@QFN48 [ (SA696-B166) ]  
MC9S08GT16CFDE@QFN48 [ (SA696-B166) ]  
MC9S08GT32ACFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT32ACFBE@LQFP44 [ (SA675-B168) ]  
MC9S08GT32ACFD@QFN48 [ (SA696-B166) ]  
MC9S08GT32ACFDE@QFN48 [ (SA696-B166) ]  
MC9S08GT32CB@SDIP42 [ (SA028-B167) ]  
MC9S08GT32CBE@SDIP42 [ (SA028-B167) ]  
MC9S08GT32CFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT32CFBE@LQFP44 [ (SA675-B168) ]  
MC9S08GT32CFD@QFN48 [ (SA696-B166) ]  
MC9S08GT32CFDE@QFN48 [ (SA696-B166) ]  
MC9S08GT8ACB@SDIP42 [ (SA028-B167) ]  
MC9S08GT8ACFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT8ACFD@QFN48 [ (SA696-B166) ]  
MC9S08GT8AMB@SDIP42 [ (SA028-B167) ]  
MC9S08GT8AMFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT8AMFD@QFN48 [ (SA696-B166) ]  
PC56F8011VF AE@QFP32 [ (SA663+B005) ]  
PC56F8013VF AE@QFP32 [ (SA663+B005) ]  
PC56F8014VF AE@QFP32 [ (SA663+B005) ]

## MYSON

### MICROCONTROLLER

MTV212MN32  
MTV212MN64I  
MTV212MS32@SDIP42 [ (SA028) ]                      MTV212MS64I@SDIP42  
[ (SA028) ]  
MTV212MV32@PLCC44 [ (SA244) ]                      MTV212MV64I@PLCC44  
[ (SA244) ]

## NEC

### E ( E ) PROM / FRAM / NVRAM

D2716D  
uPD271000

uPD271000@PLCC32 [(SA015A1T)]	uPD271000@TSOP32
[(SA410T)]	
uPD27128	uPD27128
(C)	
uPD27128(D)	
uPD2716	
uPD27256	uPD27256
(C)	
uPD27256(D)	
uPD27256A	
uPD27256A(C)	uPD27256A
(D)	
uPD2732	
uPD2732A	
uPD27512	
uPD27512ACT	
uPD27512AD	
uPD2764	
uPD2764C	
uPD2764D	
uPD27C1000	uPD27C1000@PLCC32
[(SA015A1T)]	
uPD27C1000@TSOP32 [(SA410T)]	
uPD27C1000A	
uPD27C1000A@PLCC32 [(SA015A1T)]	uPD27C1000A@TSOP32
[(SA410T)]	
uPD27C1000AD	uPD27C1000AD@PLCC32
[(SA015A1T)]	
uPD27C1000AD@TSOP32 [(SA410T)]	
uPD27C1001	
uPD27C1001@PLCC32 [(SA015A1T)]	uPD27C1001@TSOP32
[(SA410T)]	
uPD27C1001A	uPD27C1001A@PLCC32
[(SA015A1T)]	
uPD27C1001A@TSOP32 [(SA410T)]	
uPD27C1001D	
uPD27C1001D@PLCC32 [(SA015A1T)]	uPD27C1001D@TSOP32
[(SA410T)]	
uPD27C1024	
uPD27C1024A	
uPD27C2001	uPD27C2001@PLCC32
[(SA015A1T)]	
uPD27C2001@TSOP32 [(SA410T)]	

uPD27C2001D  
uPD27C2001D@PLCC32 [(SA015A1T)] uPD27C2001D@TSOP32  
[(SA410T)]  
uPD27C210  
uPD27C256  
uPD27C256A  
uPD27C400  
uPD27C4001 uPD27C4001@PLCC32  
[(SA015A1T)]  
uPD27C4001@TSOP32 [(SA410T)]  
uPD27C4096  
uPD27C512 uPD27C64  
(C)  
uPD27C64(D)  
uPD27C8000  
uPD27C8001 uPD27C8001@PLCC32  
[(SA015A1T)]  
uPD27C8001@TSOP32 [(SA410T)]  
uPD28C04  
uPD28C04@SOIC24 [(SA404)]  
uPD28C05  
uPD28C05@SOIC24 [(SA404)]  
uPD28C256  
uPD28C64 uPD28C64@SOIC28  
[(SA404)]  
uPD29F008CB@TSOP40 [(SA409T)] uPD29F008CT@TSOP40  
[(SA409T)]

## DRAM & SRAM

PD4361B PD4361B@SOJ24  
[(SA646)]

## NEXFLASH

### E(E) PROM/FRAM/NVRAM

NX25B40(Bottom Boot)@MLP8 [(SA683)]  
NX25B40(Bottom Boot)@SOIC8 [(SA602A)]  
NX25B40(Top Boot)@MLP8 [(SA683)]  
NX25B40(Top Boot)@SOIC8 [(SA602A)]



NX25P10@MLP8 [(SA683)]	NX25P10@SOIC8
[(SA602A)]	
NX25P16@MLP8 [(SA683)]	NX25P16@MLP8(ISP) [ISP-
HEADER01]	
NX25P16@SOIC16 [(SA404)]	
NX25P16@SOIC16(ISP) [ISP-HEADER01]	
NX25P16@SOIC8 [(SA023A)]	
NX25P16@SOIC8(ISP) [ISP-HEADER01]	
NX25P20@MLP8 [(SA683)]	NX25P20@SOIC8
[(SA602A)]	
NX25P32@MLP8 [(SA683)]	NX25P32@MLP8(ISP) [ISP-
HEADER01]	
NX25P32@SOIC16 [(SA404)]	
NX25P32@SOIC16(ISP) [ISP-HEADER01]	
NX25P40@MLP8 [(SA683)]	NX25P40@SOIC8
[(SA602A)]	
NX25P64@MLP8 [(SA683)]	NX25P64@MLP8(ISP) [ISP-
HEADER01]	
NX25P64@SOIC16 [(SA404)]	
NX25P64@SOIC16(ISP) [ISP-HEADER01]	
NX25P80@MLP8 [(SA683)]	NX25P80@SOIC8
[(SA602A)]	
NX29F010	NX29F010@PLCC32
[(SA015A1T)]	
NX29F010@TSOP32 [(SA410T)]	

## NJRC

### E(E) PROM/FRAM/NVRAM

NJU26040V	NJU26040V@SSOP32
[(SA626A)]	

## NOVATEK

### MICROCONTROLLER

NT68F631@PLCC44 [(SA244)]	NT68F631@SDIP42
[(SA028)]	
NT68F631ALG@PLCC44 [(SA244)]	NT68F631AUG@SDIP42

[ ( SA028 ) ]	
NT68F631L@PLCC44 [ ( SA244 ) ]	NT68F631LG@PLCC44
[ ( SA244 ) ]	
NT68F631U@SDIP42 [ ( SA028 ) ]	NT68F631UG@SDIP42
[ ( SA028 ) ]	
NT68F632@PLCC44 [ ( SA244 ) ]	NT68F632@SDIP42
[ ( SA028 ) ]	
NT68F632ALG@PLCC44 [ ( SA244 ) ]	NT68F632AUG@SDIP42
[ ( SA028 ) ]	
NT68F632L@PLCC44 [ ( SA244 ) ]	NT68F632LG@PLCC44
[ ( SA244 ) ]	
NT68F632U@SDIP42 [ ( SA028 ) ]	NT68F632UG@SDIP42
[ ( SA028 ) ]	
NT68F633@PLCC44 [ ( SA244 ) ]	NT68F633@SDIP42
[ ( SA028 ) ]	
NT68F633L@PLCC44 [ ( SA244 ) ]	NT68F633LG@PLCC44
[ ( SA244 ) ]	
NT68F633U@SDIP42 [ ( SA028 ) ]	NT68F633UG@SDIP42
[ ( SA028 ) ]	
NT68F636@PLCC44 [ ( SA244 ) ]	NT68F636@SDIP42
[ ( SA028 ) ]	
NT68F636L@PLCC44 [ ( SA244 ) ]	NT68F636LG@PLCC44
[ ( SA244 ) ]	
NT68F636U@SDIP42 [ ( SA028 ) ]	NT68F636UG@SDIP42
[ ( SA028 ) ]	
NT68F63L(0444)@PLCC44 [ ( SA244 ) ]	NT68F63L(0444)@SDIP42
[ ( SA028 ) ]	
NT68F63L(0448)@PLCC44 [ ( SA244 ) ]	NT68F63L(0448)@SDIP42
[ ( SA028 ) ]	
NT68F63L(0523)@PLCC44 [ ( SA244 ) ]	NT68F63L(0523)@SDIP42
[ ( SA028 ) ]	
NT68F63L@PLCC44 [ ( SA244 ) ]	NT68F63LA@PLCC44
[ ( SA244 ) ]	
NT68F63LG@PLCC44 [ ( SA244 ) ]	NT68F63LGG@PLCC44
[ ( SA244 ) ]	
NT68F63U@SDIP42 [ ( SA028 ) ]	NT68F63UA@SDIP42
[ ( SA028 ) ]	
NT68F63UG@SDIP42 [ ( SA028 ) ]	NT68F63UGG@SDIP42
[ ( SA028 ) ]	

**NSC**

**E ( E ) PROM / FRAM / NVRAM**

2864	
MM2716	
MM2716E	
NM24C02	
NM24C02@SOIC8 [ ( SA602A ) ]	NM24C02@TSOP8
[ ( SA026 ) ]	
NM24C02L	
NM24C02L@SOIC8	NM24C02L@SOIC8
[ ( SA602A ) ]	
NM24C02L@TSOP8 [ ( SA026 ) ]	
NM24C03	
NM24C03@SOIC8 [ ( SA602A ) ]	NM24C03@TSOP8
[ ( SA026 ) ]	
NM24C04	
NM24C04@SOIC8	NM24C04@SOIC8
[ ( SA602A ) ]	
NM24C04@TSOP8 [ ( SA026 ) ]	
NM24C05	
NM24C05@SOIC8 [ ( SA602A ) ]	NM24C05@TSOP8
[ ( SA026 ) ]	
NM24C08	
NM24C08@SOIC8	NM24C08@SOIC8
[ ( SA602A ) ]	
NM24C09	
NM24C09@SOIC8	NM24C09@SOIC8
[ ( SA602A ) ]	
NM24C16	
NM24C16@SOIC8	NM24C16@SOIC8
[ ( SA602A ) ]	
NM24C17	
NM24C17@SOIC8	NM24C17@SOIC8
[ ( SA602A ) ]	
NM25C04	
NM25C04@SOIC16	NM25C04@SOIC16
[ ( SA602 ) ]	
NM25C04@SOIC8 [ ( SA602A ) ]	NM25C04@TSSOP14
[ ( SA026 ) ]	
NM25C04@TSSOP8 [ ( SA026 ) ]	
NM27C010	
NM27C010@PLCC32 [ ( SA015A1T ) ]	NM27C010@TSOP32
[ ( SA410T ) ]	
NM27C010Q	
NM27C010Q@PLCC32	NM27C010Q@PLCC32
[ ( SA015A1T ) ]	
NM27C010Q@TSOP32 [ ( SA410T ) ]	
NM27C020	
NM27C020@PLCC32 [ ( SA015A1T ) ]	NM27C020@TSOP32
[ ( SA410T ) ]	
NM27C020Q	
NM27C020Q@PLCC32	NM27C020Q@PLCC32

[ (SA015A1T) ]  
NM27C020Q@TSOP32 [ (SA410T) ]  
NM27C040  
NM27C040@PLCC32 [ (SA015A1T) ] NM27C040@TSOP32  
[ (SA410T) ]  
NM27C1023  
NM27C128  
NM27C128@PLCC32 [ (SA015A1T) ]  
NM27C210  
NM27C210@PLCC44 [ (SA244) ]  
NM27C210Q  
NM27C210Q@PLCC44 [ (SA244) ]  
NM27C240  
NM27C240@PLCC44 [ (SA244) ]  
NM27C256  
NM27C256@PLCC32 [ (SA015A1T) ]  
NM27C400  
NM27C512 NM27C512@PLCC32  
[ (SA015A1T) ]  
NM27C512Q NM27C512Q@PLCC32  
[ (SA015A1T) ]  
NM27C64Q NM27C64Q@PLCC32  
[ (SA015A1T) ]  
NM27CP256 NM27CP256@PLCC32  
[ (SA015A1T) ]  
NM27LC010 NM27LC010@PLCC32  
[ (SA015A1T) ]  
NM27LC010@TSOP32 [ (SA410T) ]  
NM27LC256  
NM27LC256@PLCC32 [ (SA015A1T) ]  
NM27LC512  
NM27LC512@PLCC32 [ (SA015A1T) ]  
NM27LC64  
NM27LC64@PLCC32 [ (SA015A1T) ]  
NM27LV010  
NM27LV010@PLCC32 [ (SA015A1T) ] NM27LV010@TSOP32  
[ (SA410T) ]  
NM27LV210 NM27LV210@PLCC44  
[ (SA244) ]  
NM27LV512 NM27LV512@PLCC32  
[ (SA015A1T) ]  
NM27LV512@TSOP32 [ (SA410T) ]  
NM27P040

NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32
[(SA410T)]	
NM27P210	NM27P210@PLCC44
[(SA244)]	
NM27P512	NM27P512@PLCC32
[(SA015A1T)]	
NM59C11	NM59C11@SOIC8
[(SA602A)]	
NM93C06(08bit)	NM93C06(08bit)@SOIC8
[(SA602A)]	
NM93C06(16bit)	NM93C06(16bit)@SOIC8
[(SA602A)]	
NM93C46	NM93C46@SOIC8
[(SA602A)]	
NM93C46A(08bit)	NM93C46A(08bit)@SOIC8
[(SA602A)]	
NM93C46A(16bit)	NM93C46A(16bit)@SOIC8
[(SA602A)]	
NM93C46AL(08bit)	
NM93C46AL(08bit)@SOIC8 [(SA602A)]	
NM93C46AL(16bit)	
NM93C46AL(16bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(08bit)	
NM93C46ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(16bit)	
NM93C46ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C46L	NM93C46L@SOIC8
[(SA602A)]	
NM93C46LZ	NM93C46LZ@SOIC8
[(SA602A)]	
NM93C56	NM93C56@SOIC8
[(SA602A)]	
NM93C56A(08bit)	NM93C56A(08bit)@SOIC8
[(SA602A)]	
NM93C56A(16bit)	NM93C56A(16bit)@SOIC8
[(SA602A)]	
NM93C56AL(08bit)	
NM93C56AL(08bit)@SOIC8 [(SA602A)]	
NM93C56AL(16bit)	
NM93C56AL(16bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(08bit)	
NM93C56ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(16bit)	

NM93C56ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C56L	NM93C56L@SOIC8
[(SA602A)]	
NM93C56LZ	NM93C56LZ@SOIC8
[(SA602A)]	
NM93C66	NM93C66@SOIC8
[(SA602A)]	
NM93C66A	NM93C66A
(08bit)	
NM93C66A(08bit)@SOIC8 [(SA602A)]	NM93C66A@SOIC8
[(SA602A)]	
NM93C66AL(08bit)	
NM93C66AL(08bit)@SOIC8 [(SA602A)]	
NM93C66AL(16bit)	
NM93C66AL(16bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(08bit)	
NM93C66ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(16bit)	
NM93C66ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C66L	NM93C66L@SOIC8
[(SA602A)]	
NM93C66LZ	NM93C66LZ@SOIC8
[(SA602A)]	
NM93C86(16bit)	NM93C86(16bit)@SOIC8
[(SA602A)]	
NM93C86A	NM93C86A
(08bit)	
NM93C86A(08bit)@SOIC8 [(SA602A)]	NM93C86A@SOIC8
[(SA602A)]	
NM93C86AL(08bit)	
NM93C86AL(08bit)@SOIC8 [(SA602A)]	
NM93C86AL(16bit)	
NM93C86AL(16bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(08bit)	
NM93C86ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(16bit)	
NM93C86ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C86L	NM93C86L@SOIC8
[(SA602A)]	
NM93C86LZ	NM93C86LZ@SOIC8
[(SA602A)]	
NM93CS06(M8)@SOIC8 [(SA602A)]	NM93CS06(MT8)@TSSOP8
[(SA026)]	

NM93CS06(N) [(SA602A)]	NM93CS46(M8)@SOIC8
NM93CS46(MT8)@TSSOP8 [(SA026)] (N)	NM93CS46
NM93CS56(M8)@SOIC8 [(SA602A)] [(SA026)]	NM93CS56(MT8)@TSSOP8
NM93CS56(N) [(SA602A)]	NM93CS66(M8)@SOIC8
NM93CS66(MT8)@TSSOP8 [(SA026)] (N)	NM93CS66
NMC2732	
NMC2732B	
NMC2732H	
NMC27C010	
NMC27C010@PLCC32 [(SA015A1T)] [(SA410T)]	NMC27C010@TSOP32
NMC27C1024 [(SA244)]	NMC27C1024@PLCC44
NMC27C128B [(SA015A1T)]	NMC27C128B@PLCC32
NMC27C128BN [(SA015A1T)]	NMC27C128BN@PLCC32
NMC27C128BQ [(SA015A1T)]	NMC27C128BQ@PLCC32
NMC27C128CQ	
NMC27C128Q	
NMC27C16	
NMC27C16BQ	
NMC27C16BQE	
NMC27C16H	
NMC27C16HQ	
NMC27C16Q	
NMC27C210 [(SA244)]	NMC27C210@PLCC44
NMC27C210Q [(SA244)]	NMC27C210Q@PLCC44
NMC27C256B [(SA015A1T)]	NMC27C256B@PLCC32
NMC27C256BN	
NMC27C256BQE	
NMC27C256BQM	
NMC27C256Q	
NMC27C256Q@PLCC32 [(SA015A1T)]	

NMC27C32  
NMC27C32B  
NMC27C32BQ  
NMC27C32E  
NMC27C32EH  
NMC27C32H  
NMC27C512  
NMC27C512@PLCC32 [(SA015A1T)]  
NMC27C512A  
NMC27C512A@PLCC32 [(SA015A1T)]  
NMC27C512AN  
NMC27C512AN@PLCC32 [(SA015A1T)]  
NMC27C64  
NMC27C64@PLCC32 [(SA015A1T)]  
NMC27C64BN  
NMC27C64N  
NMC27CP128  
NMC27CP256  
NMC27CP64  
NMC59C11 NMC59C11@SOIC8  
[(SA602A)]  
NMC87C257Q  
NMC87C257Q@PLCC32  
NMC87C257V  
NMC87C257V@PLCC32  
NMC9306 NMC9306@SOIC8  
[(SA602A)]  
NMC9307 NMC9307@SOIC8  
[(SA602A)]  
NMC9346 NMC9346@SOIC8  
[(SA602A)]  
NMC93C56 NMC93C56@SOIC14  
[(SA602)]  
NMC93C56@SOIC8 [(SA602A)]  
NMC93C66  
NMC93C66@SOIC14 [(SA602)]  
NMC93C86A  
NMC93C86A@SOIC14 [(SA602)] NMC93C86A@SOIC8  
[(SA602A)]  
NMC93CS06(M14)@SOIC14 [(SA602)] NMC93CS06  
(N)  
NMC93CS46(M14)@SOIC14 [(SA602)] NMC93CS46  
(N)



NMC93CS56 (M14)@SOIC14 [ (SA602) ] (N)	NMC93CS56
NMC93CS66 (M14)@SOIC14 [ (SA602) ] (N)	NMC93CS66
NMC93S06 (M14)@SOIC14 [ (SA602) ] (N)	NMC93S06
NMC9817	
NMC9817A	
NS2816A	
NS9816A	

## PLD

GAL16V8 [ (SA001A) ]	GAL16V8@PLCC20
GAL16V8A [ (SA001A) ]	GAL16V8A@PLCC20
GAL20V8 [ (SA008A) ]	GAL20V8@PLCC28
GAL20V8A [ (SA008A) ]	GAL20V8A@PLCC28
GAL20V8QS [ (SA008A) ]	GAL20V8QS@PLCC28

## NTE

### E (E) PROM/FRAM/NVRAM

NTE2532  
NTE2532A  
NTE25L32

## NUMONYX

### E (E) PROM/FRAM/NVRAM

M25PX32@SOIC16 [ (SA404) ] [ (SA023A) ]	M25PX32@SOIC8
M25PX32@VFQFPN8 [ (SA683) ]	M25PX64@SOIC16

[ ( SA404 ) ]  
M25PX64@VDFPN8 [ ( SA684 ) ]

## NUVOTON

### MICROCONTROLLER

N79E342AKG [ ( SA404 ) ] N79E342RAKG [ ( SA404 ) ] N79E352AEG [ ( SA245 ) ] N79E352ALG@TQFP48 [ ( SA248 ) ] [ ( SA244 ) ] N79E8213AKG [ ( SA404 ) ] N79E8213RAKG [ ( SA404 ) ] W78E051DDG [ ( SA245A ) ] W78E051DLG@TQFP48 [ ( SA248A-B005 ) ] W78E051DPG@PLCC44 [ ( SA244 ) ] W78E052DDG W78E052DFG@TQFP44 [ ( SA245A ) ] W78E052DLG@TQFP48 [ ( SA248A-B005 ) ] W78E052DPG@PLCC44 [ ( SA244 ) ] W78E054DDG W78E054DFG@TQFP44 [ ( SA245A ) ] W78E054DLG@TQFP48 [ ( SA248A-B005 ) ] W78E054DPG@PLCC44 [ ( SA244 ) ] W78E058DDG W78E058DFG@TQFP44 [ ( SA245A ) ] W78E058DLG@TQFP48 [ ( SA248A-B005 ) ] W78E058DPG@PLCC44 [ ( SA244 ) ] W78E516DDG W78E516DFG@TQFP44 [ ( SA245A ) ] W78E516DLG@TQFP48 [ ( SA248A-B005 ) ] W78E516DPG@PLCC44 [ ( SA244 ) ] W78I051DDG W78I051DFG@TQFP44 [ ( SA245A ) ] W78I051DLG@TQFP48 [ ( SA248A-B005 ) ]	N79E342ASG@SOP16  N79E342RASG@SOP16  N79E352AFG@TQFP44  N79E352APG@PLCC44  N79E8213ASG@SOP20  N79E8213RASG@SOP20  W78E051DFG@TQFP44
--	---

W78I051DPG@PLCC44 [ ( SA244 ) ]  
W78I052DDG  
W78I052DFG@TQFP44 [ ( SA245A ) ]  
W78I052DLG@TQFP48 [ ( SA248A-B005 ) ]  
W78I052DPG@PLCC44 [ ( SA244 ) ]  
W78I054DDG  
W78I054DFG@TQFP44 [ ( SA245A ) ]  
W78I054DLG@TQFP48 [ ( SA248A-B005 ) ]  
W78I054DPG@PLCC44 [ ( SA244 ) ]

## NXP

### MICROCONTROLLER

P83C660X2@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	P83C660X2@TQFP44
P83C661X2@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	P83C661X2@TQFP44
P87C51 [ ( SA244 ) ]	P87C51@PLCC44
P87C51@TQFP44 [ ( SA245A ) ]	
P87C51FA P87C51FA@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	P87C51FA@TQFP44
P87C51FB [ ( SA244 ) ]	P87C51FB@PLCC44
P87C51FB@TQFP44 [ ( SA245A ) ]	
P87C51FC P87C51FC@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	P87C51FC@TQFP44
P87C51MA2@PLCC44 [ ( SA244 ) ] [ ( SA244 ) ]	P87C51MB2@PLCC44
P87C51MC2@PLCC44 [ ( SA244 ) ]	P87C51RA
+ P87C51RA+@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	P87C51RA+@TQFP44
P87C51RA2 [ ( SA244 ) ]	P87C51RA2@PLCC44
P87C51RA2@TQFP44 [ ( SA245A ) ]	P87C51RB
+ P87C51RB+@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	P87C51RB+@TQFP44

P87C51RB2 [ (SA244) ]	P87C51RB2@PLCC44
P87C51RB2@TQFP44 [ (SA245A) ] +	P87C51RC
P87C51RC+@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C51RC+@TQFP44
P87C51RC2 [ (SA244) ]	P87C51RC2@PLCC44
P87C51RC2@TQFP44 [ (SA245A) ] +	P87C51RD
P87C51RD+@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C51RD+@TQFP44
P87C51RD2 [ (SA244) ]	P87C51RD2@PLCC44
P87C51RD2@TQFP44 [ (SA245A) ]	
P87C51SB P87C51SB@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C51SB@TQFP44
P87C51SF [ (SA244) ]	P87C51SF@PLCC44
P87C51SF@TQFP44 [ (SA245A) ]	
P87C51UB P87C51UB@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C51UB@TQFP44
P87C51UF [ (SA244) ]	P87C51UF@PLCC44
P87C51UF@TQFP44 [ (SA245A) ]	
P87C51X2 P87C51X2@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C51X2@TQFP44
P87C52 [ (SA244) ]	P87C52@PLCC44
P87C52@TQFP44 [ (SA245A) ]	
P87C524 P87C524@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C524@TQFP44
P87C528 [ (SA244) ]	P87C528@PLCC44
P87C528@TQFP44 [ (SA245A) ]	
P87C52SB P87C52SB@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C52SB@TQFP44
P87C52SF	P87C52SF@PLCC44

[ ( SA244 ) ]  
P87C52SF@TQFP44 [ ( SA675 ) ]  
P87C52UB  
P87C52UB@PLCC44 [ ( SA244 ) ] P87C52UB@TQFP44  
[ ( SA245A ) ]  
P87C52UF P87C52UF@PLCC44  
[ ( SA244 ) ]  
P87C52UF@TQFP44 [ ( SA245A ) ]  
P87C52X2  
P87C52X2@PLCC44 [ ( SA244 ) ] P87C52X2@TQFP44  
[ ( SA245A ) ]  
P87C54 P87C54@PLCC44  
[ ( SA244 ) ]  
P87C54@TQFP44 [ ( SA245A ) ]  
P87C54SB  
P87C54SB@PLCC44 [ ( SA244 ) ] P87C54SB@TQFP44  
[ ( SA245A ) ]  
P87C54SF P87C54SF@PLCC44  
[ ( SA244 ) ]  
P87C54SF@TQFP44 [ ( SA245A ) ]  
P87C54UB  
P87C54UB@PLCC44 [ ( SA244 ) ] P87C54UB@TQFP44  
[ ( SA245A ) ]  
P87C54UF P87C54UF@PLCC44  
[ ( SA244 ) ]  
P87C54UF@TQFP44 [ ( SA245A ) ]  
P87C54X2  
P87C54X2@PLCC44 [ ( SA244 ) ] P87C54X2@TQFP44  
[ ( SA245A ) ]  
P87C550 P87C550@PLCC44  
[ ( SA244 ) ]  
P87C552@PLCC68 ( \* ) [ ( SA648-B6806 ) ]  
P87C554@PLCC68 ( \* ) [ ( SA648-B6806 ) ]  
P87C575 P87C575@PLCC44  
[ ( SA244 ) ]  
P87C575@TQFP44 [ ( SA245A ) ]  
P87C576  
P87C576@PLCC44 [ ( SA244 ) ] P87C576@TQFP44  
[ ( SA245A ) ]  
P87C58 P87C58@PLCC44  
[ ( SA244 ) ]  
P87C58@TQFP44 [ ( SA245A ) ]  
P87C58SB

P87C58SB@PLCC44 [(SA244)]	P87C58SB@TQFP44
[(SA245A)]	
P87C58UB	P87C58UB@PLCC44
[(SA244)]	
P87C58UB@TQFP44 [(SA245A)]	
P87C58X2	
P87C58X2@PLCC44 [(SA244)]	P87C58X2@TQFP44
[(SA245A)]	
P87C591@PLCC44 [(SA244)]	P87C591@TQFP44
[(SA245A)]	
P87C652	P87C652@PLCC44
[(SA244)]	
P87C652@TQFP44 [(SA245A)]	
P87C654	
P87C654@PLCC44 [(SA244)]	P87C654@TQFP44
[(SA245A)]	
P87C660X2@PLCC44 [(SA244)]	P87C660X2@TQFP44
[(SA245A)]	
P87C661X2@PLCC44 [(SA244)]	P87C661X2@TQFP44
[(SA245A)]	
P87C748	P87C748@PLCC28
[(SA008A)]	
P87C749	P87C749@PLCC28
[(SA008A)]	
P87C750	P87C750@PLCC28
[(SA008A)]	
P87C750@SSOP24 [(SA626A)]	
P87C751	
P87C751@PLCC28 [(SA008A)]	P87C751@SSOP24
[(SA626A)]	
P87C752	P87C752@PLCC28
[(SA008A)]	
P87C752@SSOP28 [(SA626A)]	
P87C754	
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28
[(SA626A)]	
P87CL52X2	P87CL52X2@PLCC44
[(SA244)]	
P87CL52X2@TQFP44 [(SA245A)]	
P87CL54X2	
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44
[(SA245A)]	
P87L51FA	P87L51FA@PLCC44

[ (SA244) ]  
P87L51FA@TQFP44 [ (SA245A) ]  
P87L51FB  
P87L51FB@PLCC44 [ (SA244) ] P87L51FB@TQFP44  
[ (SA245A) ]  
P87LPC759 P87LPC759 (ISP) [ ISP-  
HEADER01 ]  
P87LPC760 P87LPC760 (ISP) [ ISP-  
HEADER01 ]  
P87LPC760@TSSOP14 [ (SA026) ]  
P87LPC760@TSSOP14 (ISP) [ ISP-HEADER01 ]  
P87LPC761 P87LPC761 (ISP) [ ISP-  
HEADER01 ]  
P87LPC762 P87LPC762 (ISP) [ ISP-  
HEADER01 ]  
P87LPC762@PLCC44 [ (SA244) ]  
P87LPC762@PLCC44 (ISP) [ ISP-HEADER01 ]  
P87LPC762@SOIC20 [ (SA404) ]  
P87LPC762@SOIC20 (ISP) [ ISP-HEADER01 ]  
P87LPC764 P87LPC764 (ISP) [ ISP-  
HEADER01 ]  
P87LPC764@PLCC44 [ (SA244) ]  
P87LPC764@PLCC44 (ISP) [ ISP-HEADER01 ]  
P87LPC764@SOIC20 [ (SA404) ]  
P87LPC764@SOIC20 (ISP) [ ISP-HEADER01 ]  
P87LPC764@TSSOP20 [ (SA643) ]  
P87LPC764@TSSOP20 (ISP) [ ISP-HEADER01 ]  
P87LPC767 P87LPC767 (ISP) [ ISP-  
HEADER01 ]  
P87LPC767@PLCC44 [ (SA244) ]  
P87LPC767@PLCC44 (ISP) [ ISP-HEADER01 ]  
P87LPC767@SOIC20 [ (SA404) ]  
P87LPC767@SOIC20 (ISP) [ ISP-HEADER01 ]  
P87LPC768 P87LPC768 (ISP) [ ISP-  
HEADER01 ]  
P87LPC768@SOIC20 [ (SA404) ]  
P87LPC768@SOIC20 (ISP) [ ISP-HEADER01 ]  
P87LPC769 P87LPC769 (ISP) [ ISP-  
HEADER01 ]  
P87LPC769@PLCC44 [ (SA244) ]  
P87LPC769@PLCC44 (ISP) [ ISP-HEADER01 ]  
P87LPC769@SOIC20 [ (SA404) ]  
P87LPC769@SOIC20 (ISP) [ ISP-HEADER01 ]

P87LPC778 HEADER01 ]	P87LPC778 ( ISP ) [ ISP-
P87LPC778@TSSOP20 [ ( SA026 ) ]	
P87LPC778@TSSOP20 ( ISP ) [ ISP-HEADER01 ]	
P87LPC779 HEADER01 ]	P87LPC779 ( ISP ) [ ISP-
P87LPC779@TSSOP20 [ ( SA643 ) ]	
P87LPC779@TSSOP20 ( ISP ) [ ISP-HEADER01 ]	
P89C138 [ ( SA244 ) ]	P89C138@PLCC44
P89C138@TQFP44 [ ( SA245A ) ]	
P89C238 P89C238@PLCC44 [ ( SA244 ) ]	P89C238@TQFP44
[ ( SA245A ) ]	
P89C51B [ ( SA244 ) ]	P89C51B@PLCC44
P89C51B@TQFP44 [ ( SA245A ) ]	P89C51RA
+	
P89C51RA+@PLCC44 [ ( SA244 ) ]	P89C51RA+@TQFP44
[ ( SA245A ) ]	
P89C51RA2B [ ( SA244 ) ]	P89C51RA2B@PLCC44
P89C51RA2B@TQFP44 [ ( SA245A ) ]	P89C51RB
+	
P89C51RB+@PLCC44 [ ( SA244 ) ]	P89C51RB+@TQFP44
[ ( SA245A ) ]	
P89C51RB2B [ ( SA244 ) ]	P89C51RB2B@PLCC44
P89C51RB2B@TQFP44 [ ( SA245A ) ]	
P89C51RB2H P89C51RB2H@PLCC44 [ ( SA244 ) ]	P89C51RB2H@TQFP44
[ ( SA245A ) ]	
P89C51RC+ [ ( SA244 ) ]	P89C51RC+@PLCC44
P89C51RC+@TQFP44 [ ( SA245A ) ]	
P89C51RC2B P89C51RC2B@PLCC44 [ ( SA244 ) ]	P89C51RC2B@TQFP44
[ ( SA245A ) ]	
P89C51RC2H [ ( SA244 ) ]	P89C51RC2H@PLCC44
P89C51RC2H@TQFP44 [ ( SA245A ) ]	P89C51RD
+	
P89C51RD+@PLCC44 [ ( SA244 ) ]	P89C51RD+@TQFP44



[ (SA245A) ]  
P89C51RD2B P89C51RD2B@PLCC44  
[ (SA244) ]  
P89C51RD2B@TQFP44 [ (SA245A) ]  
P89C51RD2H  
P89C51RD2H@PLCC44 [ (SA244) ] P89C51RD2H@TQFP44  
[ (SA245A) ]  
P89C51UB P89C51UB@PLCC44  
[ (SA244) ]  
P89C51UB@TQFP44 [ (SA245A) ]  
P89C51UF  
P89C51UF@PLCC44 [ (SA244) ] P89C51UF@TQFP44  
[ (SA245A) ]  
P89C51X2 P89C51X2@PLCC44  
[ (SA244) ]  
P89C51X2@TQFP44 [ (SA245A) ]  
P89C51X2B  
P89C51X2B@PLCC44 [ (SA244) ] P89C51X2B@TQFP44  
[ (SA245A) ]  
P89C51X2F P89C51X2F@PLCC44  
[ (SA244) ]  
P89C51X2F@TQFP44 [ (SA245A) ]  
P89C52  
P89C52@PLCC44 [ (SA244) ] P89C52@TQFP44  
[ (SA245A) ]  
P89C52B P89C52B@PLCC44  
[ (SA244) ]  
P89C52B@TQFP44 [ (SA245A) ]  
P89C52UB  
P89C52UB@PLCC44 [ (SA244) ] P89C52UB@TQFP44  
[ (SA245A) ]  
P89C52UF P89C52UF@PLCC44  
[ (SA244) ]  
P89C52UF@TQFP44 [ (SA245A) ]  
P89C52X2  
P89C52X2@PLCC44 [ (SA244) ] P89C52X2@TQFP44  
[ (SA245A) ]  
P89C52X2B P89C52X2B@PLCC44  
[ (SA244) ]  
P89C52X2B@TQFP44 [ (SA245A) ]  
P89C52X2F  
P89C52X2F@PLCC44 [ (SA244) ] P89C52X2F@TQFP44  
[ (SA245A) ]

P89C536@PLCC44 [(SA244)]	P89C538@PLCC44
[(SA244)]	
P89C54	P89C54@PLCC44
[(SA244)]	
P89C54@TQFP44 [(SA245A)]	
P89C54B	
P89C54B@PLCC44 [(SA244)]	P89C54B@TQFP44
[(SA245A)]	
P89C54UB	P89C54UB@PLCC44
[(SA244)]	
P89C54UB@TQFP44 [(SA245A)]	
P89C54UF	
P89C54UF@PLCC44 [(SA244)]	P89C54UF@TQFP44
[(SA245A)]	
P89C54X2	P89C54X2@PLCC44
[(SA244)]	
P89C54X2@TQFP44 [(SA245A)]	
P89C54X2B	
P89C54X2B@PLCC44 [(SA244)]	P89C54X2B@TQFP44
[(SA245A)]	
P89C54X2F	P89C54X2F@PLCC44
[(SA244)]	
P89C54X2F@TQFP44 [(SA245A)]	
P89C58	
P89C58@PLCC44 [(SA244)]	P89C58@TQFP44
[(SA245A)]	
P89C58B	P89C58B@PLCC44
[(SA244)]	
P89C58B@TQFP44 [(SA245A)]	
P89C58UB	
P89C58UB@PLCC44 [(SA244)]	P89C58UB@TQFP44
[(SA245A)]	
P89C58UF	P89C58UF@PLCC44
[(SA244)]	
P89C58UF@TQFP44 [(SA245A)]	
P89C58X2	
P89C58X2@PLCC44 [(SA244)]	P89C58X2@TQFP44
[(SA245A)]	
P89C58X2B	P89C58X2B@PLCC44
[(SA244)]	
P89C58X2B@TQFP44 [(SA245A)]	
P89C58X2F	
P89C58X2F@PLCC44 [(SA244)]	P89C58X2F@TQFP44

[ ( SA245A ) ]  
P89C60X2 P89C60X2@PLCC44  
[ ( SA244 ) ]  
P89C60X2@TQFP44 [ ( SA245A ) ]  
P89C61X2  
P89C61X2@PLCC44 [ ( SA244 ) ] P89C61X2@TQFP44  
[ ( SA245A ) ]  
P89C660 P89C660@PLCC44  
[ ( SA244 ) ]  
P89C660@TQFP44 [ ( SA245A ) ]  
P89C662  
P89C662@PLCC44 [ ( SA244 ) ] P89C662@TQFP44  
[ ( SA245A ) ]  
P89C664 P89C664@PLCC44  
[ ( SA244 ) ]  
P89C664@TQFP44 [ ( SA245A ) ]  
P89C668  
P89C668@PLCC44 [ ( SA244 ) ] P89C668@TQFP44  
[ ( SA245A ) ]  
P89C669 P89C669@LQFP44  
[ ( SA245A ) ]  
P89C669@PLCC44 [ ( SA244 ) ]  
P89C738  
P89C738@PLCC44 [ ( SA244 ) ] P89C738@TQFP44  
[ ( SA245A ) ]  
P89C838 P89C838@PLCC44  
[ ( SA244 ) ]  
P89C838@TQFP44 [ ( SA245A ) ] P89CV51RB2@PLCC44  
[ ( SA244 ) ]  
P89CV51RB2@TQFP44 [ ( SA245A ) ] P89CV51RC2@PLCC44  
[ ( SA244 ) ]  
P89CV51RC2@TQFP44 [ ( SA245A ) ] P89CV51RD2@PLCC44  
[ ( SA244 ) ]  
P89CV51RD2@TQFP44 [ ( SA245A ) ] P89LPC901 ( FD )  
[ ( SA602A ) ]  
P89LPC901 ( FD ) ( ISP ) [ ISP-HEADER01 ]  
P89LPC901 ( FN )  
P89LPC901 ( FN ) ( ISP ) [ ISP-HEADER01 ]  
P89LPC902 ( FD ) [ ( SA602A ) ]  
P89LPC902 ( FD ) ( ISP ) [ ISP-HEADER01 ]  
P89LPC902 ( FN )  
P89LPC902 ( FN ) ( ISP ) [ ISP-HEADER01 ]  
P89LPC903 ( FD ) [ ( SA602A ) ]

P89LPC903(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FD) [(SA605A)]  
P89LPC904(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FN)  
P89LPC904(FN)(ISP) [ISP-HEADER01]  
P89LPC906(FD) [(SA605A)]  
P89LPC906(FD)(ISP) [ISP-HEADER01]  
P89LPC907(FD) [(SA605A)]  
P89LPC907(FD)(ISP) [ISP-HEADER01]  
P89LPC908(FD) [(SA605A)]  
P89LPC908(FD)(ISP) [ISP-HEADER01]  
P89LPC9102(FTK)@HVSON10 [(SA695A)]  
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9103(FTK)@HVSON10 [(SA695A)]  
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9107(FDH)@TSSOP14 [(SA643)]  
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC9107(FN)  
P89LPC9107(FN)(ISP) [ISP-HEADER01]  
P89LPC912(FDH)@TSSOP14 [(SA643)]  
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC913(FDH)@TSSOP14 [(SA643)]  
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC914(FDH)@TSSOP14 [(SA643)]  
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC915(FDH)@TSSOP14 [(SA643)]  
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC916(FDH)@TSSOP16 [(SA643)]  
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920(FN)  
P89LPC920(FN)(ISP) [ISP-HEADER01]  
P89LPC9201(FDH)@TSSOP20 [(SA643)]  
P89LPC9201(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9201(FN)  
P89LPC9201(FN)(ISP) [ISP-HEADER01]  
P89LPC920A1(FDH)@TSSOP20 [(SA643)]  
P89LPC920A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920A1(FN)  
P89LPC920A1(FN)(ISP) [ISP-HEADER01]

P89LPC921(FDH)@TSSOP20 [(SA643)]  
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921(FN)  
P89LPC921(FN)(ISP) [ISP-HEADER01]  
P89LPC9211(FDH)@TSSOP20 [(SA643)]  
P89LPC9211(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9211(FN)  
P89LPC9211(FN)(ISP) [ISP-HEADER01]  
P89LPC921A1(FDH)@TSSOP20 [(SA643)]  
P89LPC921A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921A1(FN)  
P89LPC921A1(FN)(ISP) [ISP-HEADER01]  
P89LPC922(FDH)@TSSOP20 [(SA643)]  
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922(FN)  
P89LPC922(FN)(ISP) [ISP-HEADER01]  
P89LPC9221(FDH)@TSSOP20 [(SA643)]  
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221(FN)  
P89LPC9221(FN)(ISP) [ISP-HEADER01]  
P89LPC9221A1(FDH)@TSSOP20 [(SA643)]  
P89LPC9221A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221A1(FN)  
P89LPC9221A1(FN)(ISP) [ISP-HEADER01]  
P89LPC922A1(FDH)@TSSOP20 [(SA643)]  
P89LPC922A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922A1(FN)  
P89LPC922A1(FN)(ISP) [ISP-HEADER01]  
P89LPC924(FDH)@TSSOP20 [(SA643)]  
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924(FN)  
P89LPC924(FN)(ISP) [ISP-HEADER01]  
P89LPC9241(FDH)@TSSOP20 [(SA643)]  
P89LPC9241(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9241(FN)  
P89LPC9241(FN)(ISP) [ISP-HEADER01]  
P89LPC924A1(FDH)@TSSOP20 [(SA643)]  
P89LPC924A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924A1(FN)  
P89LPC924A1(FN)(ISP) [ISP-HEADER01]  
P89LPC925(FDH)@TSSOP20 [(SA643)]  
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925(FN)

P89LPC925(FN)(ISP) [ISP-HEADER01]  
P89LPC9251(FDH)@TSSOP20 [(SA643)]  
P89LPC9251(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9251(FN)  
P89LPC9251(FN)(ISP) [ISP-HEADER01]  
P89LPC925A1(FDH)@TSSOP20 [(SA643)]  
P89LPC925A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925A1(FN)  
P89LPC925A1(FN)(ISP) [ISP-HEADER01]  
P89LPC930(BA)@PLCC28 [(SA008A)]  
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC930(BDH)@TSSOP28 [(SA643)]  
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9301(BA)@PLCC28 [(SA008A)]  
P89LPC9301(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BA)@PLCC28 [(SA008A)]  
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC931(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9311(BA)@PLCC28 [(SA008A)]  
P89LPC9311(BDH)@TSSOP28 [(SA643)]  
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28  
[(SA643)]  
P89LPC93201(BA)@PLCC28 [(SA008A)]  
P89LPC93201(BDH)@TSSOP28 [(SA643)]  
P89LPC93201(FA)@PLCC28 [(SA008A)]  
P89LPC93201(FDH)@TSSOP28 [(SA643)]  
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9321(BA)@PLCC28 [(SA008A)]  
P89LPC9321(BDH)@TSSOP28 [(SA643)]  
P89LPC9321(FA)@PLCC28 [(SA008A)]  
P89LPC9321(FDH)@TSSOP28 [(SA643)]  
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(BA)@PLCC28 [(SA008A)]  
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC932A1(BDH)@TSSOP28 [(SA643)]  
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FDH)@TSSOP28 [(SA643)]  
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC933(BDH)@TSSOP28 [(SA643)]  
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]

P89LPC933(FDH)@TSSOP28 [(SA643)]  
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(HDH)@TSSOP28 [(SA643)]  
P89LPC9331(BDH)@TSSOP28 [(SA643)]  
P89LPC9331(FDH)@TSSOP28 [(SA643)]  
P89LPC9331(HDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC93401(FDH)@TSSOP28 [(SA643)]  
P89LPC93401V  
P89LPC9341(BDH)@TSSOP28 [(SA643)]  
P89LPC9341(FDH)@TSSOP28 [(SA643)]  
P89LPC9341V P89LPC935(BA)@PLCC28  
[(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9361(FA)@PLCC28 [(SA008A)]  
P89LPC9361(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]

P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]  
P89LPC9381(BDH)@TSSOP28 [(SA643)]  
P89LPC9381(FA)@PLCC28 [(SA008A)]  
P89LPC9381(FDH)@TSSOP28 [(SA643)]  
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC952@LQFP44 [(SA245A)]  
P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
P89LPC952@LQFP48 [(SA248)]  
P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
P89LPC952@PLCC44 [(SA244)]  
P89LPC952@PLCC44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP44 [(SA245A)]  
P89LPC954@LQFP44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP48 [(SA248)]  
P89LPC954@LQFP48(ISP) [ISP-HEADER01]  
P89LPC954@PLCC44 [(SA244)]  
P89LPC954@PLCC44(ISP) [ISP-HEADER01]  
P89LV51RB2 P89LV51RB2@PLCC44  
[(SA244)]  
P89LV51RB2@TQFP44 [(SA245A)]  
P89LV51RC2 P89LV51RC2@TQFP44  
P89LV51RC2@PLCC44 [(SA244)]  
[(SA245A)]  
P89LV51RD2 P89LV51RD2  
(new)  
P89LV51RD2(new)@PLCC44 [(SA244)]  
P89LV51RD2(new)@TQFP44 [(SA245A)]  
P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44  
[(SA245A)]  
P89LV51RD2BA(new)@PLCC44 [(SA244)]  
P89LV51RD2BA@PLCC44 [(SA244)]  
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]



P89LV51RD2BBC@TQFP44 [(SA245A)]  
P89LV51RD2BN  
P89LV51RD2BN(new)  
P89LV51RD2FA(new)@PLCC44 [(SA244)]  
P89LV51RD2FA@PLCC44 [(SA244)]  
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2FBC@TQFP44 [(SA245A)]  
P89LV51RD2FN  
P89LV51RD2FN(new)  
P89V51RB2  
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44  
[(SA245A)]  
P89V51RC2 P89V51RC2@PLCC44  
[(SA244)]  
P89V51RC2@TQFP44 [(SA245A)]  
P89V51RD2  
P89V51RD2(new) P89V51RD2(new)@PLCC44  
[(SA244)]  
P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44  
[(SA244)]  
P89V51RD2@TQFP44 [(SA245A)]  
P89V51RD2BA(new)@PLCC44 [(SA244)]  
P89V51RD2BA@PLCC44 [(SA244)]  
P89V51RD2BBC(new)@TQFP44 [(SA245A)]  
P89V51RD2BBC@TQFP44 [(SA245A)]  
P89V51RD2BN  
P89V51RD2BN(new)  
P89V51RD2FA(new)@PLCC44 [(SA244)]  
P89V51RD2FA@PLCC44 [(SA244)]  
P89V51RD2FBC(new)@TQFP44 [(SA245A)]  
P89V51RD2FBC@TQFP44 [(SA245A)]  
P89V51RD2FN  
P89V51RD2FN(new)  
P89V52X2  
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44  
[(SA244)]  
P89V52X2@PLCC44(ISP) [ISP-HEADER01]  
P89V52X2@TQFP44 [(SA245A)]  
P89V52X2@TQFP44(ISP) [ISP-HEADER01]  
P89V660@PLCC44 [(SA244)] P89V660@TQFP44  
[(SA245A)]  
P89V662@PLCC44 [(SA244)] P89V662@TQFP44  
[(SA245A)]

P89V664@PLCC44 [ ( SA244 ) ]  
 [ ( SA245A ) ]  
 PXAC37@PLCC44 [ ( SA244 ) ]  
 [ ( SA245A ) ]  
 PXAG17@PLCC44 [ ( SA244 ) ]  
 [ ( SA245A ) ]  
 PXAG27@PLCC44 [ ( SA244 ) ]  
 [ ( SA245A ) ]  
 PXAG37@PLCC44 [ ( SA244 ) ]  
 [ ( SA245A ) ]  
 PXAG39@PLCC44 [ ( SA244 ) ]  
 [ ( SA245A ) ]  
 PXAG49@PLCC44 [ ( SA244 ) ]  
 [ ( SA245A ) ]

P89V664@TQFP44  
 PXAC37@TQFP44  
 PXAG17@TQFP44  
 PXAG27@TQFP44  
 PXAG37@TQFP44  
 PXAG39@TQFP44  
 PXAG49@TQFP44

## OKI

### E ( E ) PROM / FRAM / NVRAM

MR27C1602B  
 [ ( SA638 ) ]  
 MR27V1602D  
 [ ( SA638 ) ]  
 MR27V1602D@TSOP44 [ ( SA645 ) ]  
 B005 ) ]  
 MR27V1602E  
 [ ( SA638 ) ]  
 MR27V1602E@TSOP44 [ ( SA645 ) ]  
 B005 ) ]  
 MR27V1602F  
 [ ( SA638 ) ]  
 MR27V1602F@TSOP44 [ ( SA645 ) ]  
 B005 ) ]  
 MR27V1652D  
 [ ( SA638 ) ]  
 MR27V1652D@TSOP44 [ ( SA645 ) ]  
 B005 ) ]  
 MR27V3202F@TSOP44 [ ( SA645 ) ]  
 B005 ) ]  
 MR27V401D  
 [ ( SA638 ) ]  
 MR27V401D@TSOP32 [ ( SA620 ) ]

MR27C1602B@PSOP44  
 MR27V1602D@PSOP44  
 MR27V1602D@TSOP48 [ ( SA247-  
 MR27V1602E@PSOP44  
 MR27V1602E@TSOP48 [ ( SA247-  
 MR27V1602F@PSOP44  
 MR27V1602F@TSOP48 [ ( SA247-  
 MR27V1652D@PSOP44  
 MR27V1652D@TSOP48 [ ( SA247-  
 MR27V3202F@TSOP48 [ ( SA247-  
 MR27V401D@PSOP32

MR27V401E	
MR27V401E@PSOP32 [(SA638)]	MR27V401E@TSOP32
[(SA620)]	
MR27V402D	MR27V402D@PSOP40
[(SA661)]	
MR27V402D@TSOP44 [(SA645)]	
MR27V402E	
MR27V402E@PSOP40 [(SA661)]	MR27V402E@TSOP44
[(SA645)]	
MR27V402F@SOJ42 [(SA661)]	MR27V6402D@PSOP44
[(SA638)]	
MR27V6402D@TSOP44 [(SA645)]	MR27V6402D@TSOP48 [(SA247-
B005)]	
MR27V6402G@PSOP44 [(SA638)]	MR27V6402G@TSOP44
[(SA645)]	
MR27V6402G@TSOP48 [(SA247-B005)]	
MR27V802D	
MR27V802D@PSOP44 [(SA638)]	MR27V802D@TSOP44
[(SA645)]	
MR27V802F@PSOP44 [(SA638)]	MR27V802F@TSOP44
[(SA645)]	
MR27V802F@TSOP48 [(SA247-B005)]	
MR27V852D	
MR27V852D@PSOP44 [(SA638)]	MR27V852D@TSOP44
[(SA645)]	
MR27V852E	MR27V852E@SOJ42
[(SA661)]	
MSM16812(08bit)	MSM16812(08bit)@SOIC8
[(SA602A)]	
MSM271000	MSM271000@PLCC32
[(SA015A1T)]	
MSM271000@TSOP32 [(SA410T)]	
MSM27128	
MSM27128A	
MSM27128AS	
MSM27128AZB-RS	
MSM2716	
MSM27256	
MSM27256AS	
MSM27256ZB-RS	
MSM2732	
MSM2732A	
MSM27512	

MSM27512AS	MSM27512ZB-
RS	
MSM2764	
MSM2764A	
MSM2764AS	MSM2764AZB-
RS	
MSM2764RS	
MSM27C1024	
MSM27C1024AS	
MSM27C128	
MSM27C128AZB-RS	
MSM27C1602CZ	
MSM27C1602CZ@PSOP44 [(SA638)]	
MSM27C1602CZ@TSOP48 [(SA247-B005)]	
MSM27C1652CZ	MSM27C1652CZ@PSOP44
[(SA638)]	
MSM27C1652CZ@TSOP48 [(SA247-B005)]	
MSM27C256	
MSM27C256A	
MSM27C256H	
MSM27C256HZB	
MSM27C256ZB	
MSM27C64AS	
MSM27C802CZ	MSM27C802CZ@PSOP44
[(SA638)]	
MSM27C802CZ@TSOP44 [(SA645)]	
MSM27C852CZ	
MSM27C852CZ@PSOP44 [(SA638)]	MSM27C852CZ@TSOP44
[(SA645)]	
MSM2816A(RS)	
MSM28C16A	

## DRAM & SRAM

MSM51256	MSM51256@SOIC28
[(SA630)]	
MSM51257AL	MSM51257AL@SOIC28
[(SA630)]	
MSM51257ALL	MSM51257ALL@SOIC28
[(SA630)]	
MSM5165AL	MSM5165AL@SOIC28
[(SA630)]	

MSM5188  
[ ( SA646 ) ]

MSM5188@SOJ22

## ON Semiconductor

### E ( E ) PROM / FRAM / NVRAM

CAT1320 [ ( SA602A ) ]	CAT1320@SOIC8
CAT1320@TDFN8 [ ( SA026 ) ]	CAT1320@TSSOP8
CAT1321 [ ( SA602A ) ]	CAT1321@SOIC8
CAT1321@TDFN8 [ ( SA026 ) ]	CAT1321@TSSOP8
CAT14002@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	CAT14004@SOIC8
CAT14008@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	CAT14016@SOIC8
CAT15002@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	CAT15004@SOIC8
CAT15008@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	CAT15016@SOIC8
CAT1640 [ ( SA602A ) ]	CAT1640@SOIC8
CAT1640@TDFN8 [ ( SA026 ) ]	CAT1640@TSSOP8
CAT1641 [ ( SA602A ) ]	CAT1641@SOIC8
CAT1641@TDFN8 [ ( SA026 ) ]	CAT1641@TSSOP8

## PARALLAX

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [ ( SA626A ) ] [ ( SA626A ) ]	SX20AC/SS@SSOP20
SX28AC/DP G	SX28AC/DP /

SX28AC/SS/G@SSOP28 [(SA626A)]  
[(SA626A)]  
SX48BD/G@TQFP48 [(SA248)]  
[(SA248)]

SX28AC/SS@SSOP28  
  
SX48BD@TQFP48

## PFLASH(MSTAR)

### E (E) PROM/FRAM/NVRAM

PS25LV010A@SOIC8 [(SA602A)]  
[(SA683)]  
PS25LV020@SOIC8 [(SA602A)]  
[(SA683)]  
PS25LV040@SOIC8 [(SA605A)]  
[(SA683)]  
PS25LV080@SOIC8 [(SA605A)]  
[(SA683)]

PS25LV010A@WSON8  
  
PS25LV020@WSON8  
  
PS25LV040@WSON8  
  
PS25LV080@WSON8

## PHILIPS

### E (E) PROM/FRAM/NVRAM

27C010  
[(SA015A1T)]  
27C010@TSOP32 [(SA410T)]  
27C040  
27C040@PLCC32 [(SA015A1T)]  
[(SA410T)]  
27C210  
[(SA244)]  
27C240  
[(SA244)]  
27C256  
[(SA015A1T)]  
27C32  
27C512  
27C512@PLCC32 [(SA015A1T)]  
27C64  
27C64@PLCC32 [(SA015A1T)]  
27C64A

27C010@PLCC32  
  
  
27C040@TSOP32  
  
27C210@PLCC44  
  
27C240@PLCC44  
  
27C256@PLCC32

27C64A@PLCC32 [(SA015A1T)]	
27C64AF	
27C64AF@PLCC32 [(SA015A1T)]	
27HC641	
27HC641@PLCC28 [(SA008A)]	
27PC32	
PCA24S08@SOIC8 [(SA602A)]	PCA24S08@TSSOP8
[(SA026)]	
PCA8574(P)	PCA8574(T)@SOIC16
[(SA404)]	
PCA8574(TS)@SSOP20 [(SA026)]	PCA8574A
(P)	
PCA8574A(T)@SOIC16 [(SA404)]	PCA8574A(TS)@SSOP20
[(SA026)]	
PCA8581	PCA8581@SOIC8
[(SA602A)]	
PCA8581C	PCA8581C@SOIC8
[(SA602A)]	
PCA8582A	PCA8582A@SOIC8
[(SA602A)]	
PCA8582B	PCA8582B@SOIC8
[(SA602A)]	
PCA8582C	PCA8582C@SOIC8
[(SA602A)]	
PCA8582D	PCA8582D@SOIC8
[(SA602A)]	
PCA8582E	PCA8582E@SOIC8
[(SA602A)]	
PCA9500@HQVFN16	PCA9500@SOIC16
[(SA404)]	
PCA9500@TSSOP16 [(SA026)]	
PCA9501@HQVFN20	
PCA9501@SOIC20 [(SA404)]	PCA9501@TSSOP20
[(SA026)]	
PCA9561D@SOP20 [(SA404)]	PCA9561W@TSSOP20
[(SA026)]	
PCD8581	PCD8581@SOIC8
[(SA602A)]	
PCD8581C	PCD8581C@SOIC8
[(SA602A)]	
PCD8582A	PCD8582A@SOIC8
[(SA602A)]	
PCD8582B	PCD8582B@SOIC8

[ ( SA602A ) ]	
PCD8582C	PCD8582C@SOIC8
[ ( SA602A ) ]	
PCD8582D	PCD8582D@SOIC8
[ ( SA602A ) ]	
PCD8582E	PCD8582E@SOIC8
[ ( SA602A ) ]	
PCF85102C	PCF85102C@SOIC8
[ ( SA602A ) ]	
PCF85103C	PCF85103C@SOIC8
[ ( SA602A ) ]	
PCF85116	PCF85116@SOIC8
[ ( SA602A ) ]	
PCF8581	PCF8581@SOIC8
[ ( SA602A ) ]	
PCF8581C	PCF8581C@SOIC8
[ ( SA602A ) ]	
PCF8582A	PCF8582A@SOIC8
[ ( SA602A ) ]	
PCF8582B	PCF8582B@SOIC8
[ ( SA602A ) ]	
PCF8582C	PCF8582C@SOIC8
[ ( SA602A ) ]	
PCF8582D	PCF8582D@SOIC8
[ ( SA602A ) ]	
PCF8582E	PCF8582E@SOIC8
[ ( SA602A ) ]	
PCF8594	PCF8594@SOIC8
[ ( SA602A ) ]	
PCF8594C	PCF8594C@SOIC8
[ ( SA602A ) ]	
PCF8594D	PCF8594D@SOIC8
[ ( SA602A ) ]	
PCF8594E	PCF8594E@SOIC8
[ ( SA602A ) ]	
PCF8598	PCF8598@SOIC8
[ ( SA605A ) ]	
PCF8598C	PCF8598C@SOIC8
[ ( SA605A ) ]	
PCF8598D	PCF8598D@SOIC8
[ ( SA605A ) ]	
PCF8598E	PCF8598E@SOIC8
[ ( SA605A ) ]	



**MICROCONTROLLER**

P83C660X2@PLCC44 [(SA244)]	P83C660X2@TQFP44
[(SA245A)]	
P83C661X2@PLCC44 [(SA244)]	P83C661X2@TQFP44
[(SA245A)]	
P87C51	P87C51@PLCC44
[(SA244)]	
P87C51@TQFP44 [(SA245A)]	
P87C51FA	
P87C51FA@PLCC44 [(SA244)]	P87C51FA@TQFP44
[(SA245A)]	
P87C51FB	P87C51FB@PLCC44
[(SA244)]	
P87C51FB@TQFP44 [(SA245A)]	
P87C51FC	
P87C51FC@PLCC44 [(SA244)]	P87C51FC@TQFP44
[(SA245A)]	
P87C51MA2@PLCC44 [(SA244)]	P87C51MB2@PLCC44
[(SA244)]	
P87C51MC2@PLCC44 [(SA244)]	P87C51RA
+	
P87C51RA+@PLCC44 [(SA244)]	P87C51RA+@TQFP44
[(SA245A)]	
P87C51RA2	P87C51RA2@PLCC44
[(SA244)]	
P87C51RA2@TQFP44 [(SA245A)]	P87C51RB
+	
P87C51RB+@PLCC44 [(SA244)]	P87C51RB+@TQFP44
[(SA245A)]	
P87C51RB2	P87C51RB2@PLCC44
[(SA244)]	
P87C51RB2@TQFP44 [(SA245A)]	P87C51RC
+	
P87C51RC+@PLCC44 [(SA244)]	P87C51RC+@TQFP44
[(SA245A)]	
P87C51RC2	P87C51RC2@PLCC44
[(SA244)]	
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD
+	
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44

[ (SA245A) ]	
P87C51RD2	P87C51RD2@PLCC44
[ (SA244) ]	
P87C51RD2@TQFP44 [ (SA245A) ]	
P87C51SB	
P87C51SB@PLCC44 [ (SA244) ]	P87C51SB@TQFP44
[ (SA245A) ]	
P87C51SF	P87C51SF@PLCC44
[ (SA244) ]	
P87C51SF@TQFP44 [ (SA245A) ]	
P87C51UB	
P87C51UB@PLCC44 [ (SA244) ]	P87C51UB@TQFP44
[ (SA245A) ]	
P87C51UF	P87C51UF@PLCC44
[ (SA244) ]	
P87C51UF@TQFP44 [ (SA245A) ]	
P87C51X2	
P87C51X2@PLCC44 [ (SA244) ]	P87C51X2@TQFP44
[ (SA245A) ]	
P87C52	P87C52@PLCC44
[ (SA244) ]	
P87C52@TQFP44 [ (SA245A) ]	
P87C524	
P87C524@PLCC44 [ (SA244) ]	P87C524@TQFP44
[ (SA245A) ]	
P87C528	P87C528@PLCC44
[ (SA244) ]	
P87C528@TQFP44 [ (SA245A) ]	
P87C52SB	
P87C52SB@PLCC44 [ (SA244) ]	P87C52SB@TQFP44
[ (SA245A) ]	
P87C52SF	P87C52SF@PLCC44
[ (SA244) ]	
P87C52SF@TQFP44 [ (SA675) ]	
P87C52UB	
P87C52UB@PLCC44 [ (SA244) ]	P87C52UB@TQFP44
[ (SA245A) ]	
P87C52UF	P87C52UF@PLCC44
[ (SA244) ]	
P87C52UF@TQFP44 [ (SA245A) ]	
P87C52X2	
P87C52X2@PLCC44 [ (SA244) ]	P87C52X2@TQFP44
[ (SA245A) ]	

P87C54	P87C54@PLCC44
[ (SA244) ]	
P87C54@TQFP44 [ (SA245A) ]	
P87C54SB	
P87C54SB@PLCC44 [ (SA244) ]	P87C54SB@TQFP44
[ (SA245A) ]	
P87C54SF	P87C54SF@PLCC44
[ (SA244) ]	
P87C54SF@TQFP44 [ (SA245A) ]	
P87C54UB	
P87C54UB@PLCC44 [ (SA244) ]	P87C54UB@TQFP44
[ (SA245A) ]	
P87C54UF	P87C54UF@PLCC44
[ (SA244) ]	
P87C54UF@TQFP44 [ (SA245A) ]	
P87C54X2	
P87C54X2@PLCC44 [ (SA244) ]	P87C54X2@TQFP44
[ (SA245A) ]	
P87C550	P87C550@PLCC44
[ (SA244) ]	
P87C552@PLCC68 ( * ) [ (SA648-B6806) ]	
P87C554@PLCC68 ( * ) [ (SA648-B6806) ]	
P87C575	P87C575@PLCC44
[ (SA244) ]	
P87C575@TQFP44 [ (SA245A) ]	
P87C576	
P87C576@PLCC44 [ (SA244) ]	P87C576@TQFP44
[ (SA245A) ]	
P87C58	P87C58@PLCC44
[ (SA244) ]	
P87C58@TQFP44 [ (SA245A) ]	
P87C58SB	
P87C58SB@PLCC44 [ (SA244) ]	P87C58SB@TQFP44
[ (SA245A) ]	
P87C58UB	P87C58UB@PLCC44
[ (SA244) ]	
P87C58UB@TQFP44 [ (SA245A) ]	
P87C58X2	
P87C58X2@PLCC44 [ (SA244) ]	P87C58X2@TQFP44
[ (SA245A) ]	
P87C591@PLCC44 [ (SA244) ]	P87C591@TQFP44
[ (SA245A) ]	
P87C652	P87C652@PLCC44

[ ( SA244 ) ]  
P87C652@TQFP44 [ ( SA245A ) ]  
P87C654  
P87C654@PLCC44 [ ( SA244 ) ] P87C654@TQFP44  
[ ( SA245A ) ]  
P87C660X2@PLCC44 [ ( SA244 ) ] P87C660X2@TQFP44  
[ ( SA245A ) ]  
P87C661X2@PLCC44 [ ( SA244 ) ] P87C661X2@TQFP44  
[ ( SA245A ) ]  
P87C748 P87C748@PLCC28  
[ ( SA008A ) ]  
P87C749 P87C749@PLCC28  
[ ( SA008A ) ]  
P87C750 P87C750@PLCC28  
[ ( SA008A ) ]  
P87C750@SSOP24 [ ( SA626A ) ]  
P87C751  
P87C751@PLCC28 [ ( SA008A ) ] P87C751@SSOP24  
[ ( SA626A ) ]  
P87C752 P87C752@PLCC28  
[ ( SA008A ) ]  
P87C752@SSOP28 [ ( SA626A ) ]  
P87C754  
P87C754@PLCC28 [ ( SA008A ) ] P87C754@SSOP28  
[ ( SA626A ) ]  
P87CL52X2 P87CL52X2@PLCC44  
[ ( SA244 ) ]  
P87CL52X2@TQFP44 [ ( SA245A ) ]  
P87CL54X2  
P87CL54X2@PLCC44 [ ( SA244 ) ] P87CL54X2@TQFP44  
[ ( SA245A ) ]  
P87L51FA P87L51FA@PLCC44  
[ ( SA244 ) ]  
P87L51FA@TQFP44 [ ( SA245A ) ]  
P87L51FB  
P87L51FB@PLCC44 [ ( SA244 ) ] P87L51FB@TQFP44  
[ ( SA245A ) ]  
P87LPC759 P87LPC759 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC760 P87LPC760 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC760@TSSOP14 [ ( SA026 ) ]  
P87LPC760@TSSOP14 ( ISP ) [ ISP-HEADER01 ]

P87LPC761 P87LPC761 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC762 P87LPC762 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC762@PLCC44 [ ( SA244 ) ]  
P87LPC762@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
P87LPC762@SOIC20 [ ( SA404 ) ]  
P87LPC762@SOIC20 ( ISP ) [ ISP-HEADER01 ]  
P87LPC764 P87LPC764 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC764@PLCC44 [ ( SA244 ) ]  
P87LPC764@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
P87LPC764@SOIC20 [ ( SA404 ) ]  
P87LPC764@SOIC20 ( ISP ) [ ISP-HEADER01 ]  
P87LPC764@TSSOP20 [ ( SA643 ) ]  
P87LPC764@TSSOP20 ( ISP ) [ ISP-HEADER01 ]  
P87LPC767 P87LPC767 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC767@PLCC44 [ ( SA244 ) ]  
P87LPC767@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
P87LPC767@SOIC20 [ ( SA404 ) ]  
P87LPC767@SOIC20 ( ISP ) [ ISP-HEADER01 ]  
P87LPC768 P87LPC768 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC768@SOIC20 [ ( SA404 ) ]  
P87LPC768@SOIC20 ( ISP ) [ ISP-HEADER01 ]  
P87LPC769 P87LPC769 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC769@PLCC44 [ ( SA244 ) ]  
P87LPC769@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
P87LPC769@SOIC20 [ ( SA404 ) ]  
P87LPC769@SOIC20 ( ISP ) [ ISP-HEADER01 ]  
P87LPC778 P87LPC778 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC778@TSSOP20 [ ( SA026 ) ]  
P87LPC778@TSSOP20 ( ISP ) [ ISP-HEADER01 ]  
P87LPC779 P87LPC779 ( ISP ) [ ISP-  
HEADER01 ]  
P87LPC779@TSSOP20 [ ( SA643 ) ]  
P87LPC779@TSSOP20 ( ISP ) [ ISP-HEADER01 ]  
P89C138 P89C138@PLCC44  
[ ( SA244 ) ]  
P89C138@TQFP44 [ ( SA245A ) ]

P89C238	
P89C238@PLCC44 [(SA244)]	P89C238@TQFP44
[(SA245A)]	
P89C51B	P89C51B@PLCC44
[(SA244)]	
P89C51B@TQFP44 [(SA245A)]	P89C51RA
+	
P89C51RA+@PLCC44 [(SA244)]	P89C51RA+@TQFP44
[(SA245A)]	
P89C51RA2B	P89C51RA2B@PLCC44
[(SA244)]	
P89C51RA2B@TQFP44 [(SA245A)]	P89C51RB
+	
P89C51RB+@PLCC44 [(SA244)]	P89C51RB+@TQFP44
[(SA245A)]	
P89C51RB2B	P89C51RB2B@PLCC44
[(SA244)]	
P89C51RB2B@TQFP44 [(SA245A)]	
P89C51RB2H	
P89C51RB2H@PLCC44 [(SA244)]	P89C51RB2H@TQFP44
[(SA245A)]	
P89C51RC+	P89C51RC+@PLCC44
[(SA244)]	
P89C51RC+@TQFP44 [(SA245A)]	
P89C51RC2B	
P89C51RC2B@PLCC44 [(SA244)]	P89C51RC2B@TQFP44
[(SA245A)]	
P89C51RC2H	P89C51RC2H@PLCC44
[(SA244)]	
P89C51RC2H@TQFP44 [(SA245A)]	P89C51RD
+	
P89C51RD+@PLCC44 [(SA244)]	P89C51RD+@TQFP44
[(SA245A)]	
P89C51RD2B	P89C51RD2B@PLCC44
[(SA244)]	
P89C51RD2B@TQFP44 [(SA245A)]	
P89C51RD2H	
P89C51RD2H@PLCC44 [(SA244)]	P89C51RD2H@TQFP44
[(SA245A)]	
P89C51UB	P89C51UB@PLCC44
[(SA244)]	
P89C51UB@TQFP44 [(SA245A)]	
P89C51UF	

P89C51UF@PLCC44 [(SA244)]	P89C51UF@TQFP44
[(SA245A)]	
P89C51X2	P89C51X2@PLCC44
[(SA244)]	
P89C51X2@TQFP44 [(SA245A)]	
P89C51X2B	
P89C51X2B@PLCC44 [(SA244)]	P89C51X2B@TQFP44
[(SA245A)]	
P89C51X2F	P89C51X2F@PLCC44
[(SA244)]	
P89C51X2F@TQFP44 [(SA245A)]	
P89C52	
P89C52@PLCC44 [(SA244)]	P89C52@TQFP44
[(SA245A)]	
P89C52B	P89C52B@PLCC44
[(SA244)]	
P89C52B@TQFP44 [(SA245A)]	
P89C52UB	
P89C52UB@PLCC44 [(SA244)]	P89C52UB@TQFP44
[(SA245A)]	
P89C52UF	P89C52UF@PLCC44
[(SA244)]	
P89C52UF@TQFP44 [(SA245A)]	
P89C52X2	
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44
[(SA245A)]	
P89C52X2B	P89C52X2B@PLCC44
[(SA244)]	
P89C52X2B@TQFP44 [(SA245A)]	
P89C52X2F	
P89C52X2F@PLCC44 [(SA244)]	P89C52X2F@TQFP44
[(SA245A)]	
P89C536@PLCC44 [(SA244)]	P89C538@PLCC44
[(SA244)]	
P89C54	P89C54@PLCC44
[(SA244)]	
P89C54@TQFP44 [(SA245A)]	
P89C54B	
P89C54B@PLCC44 [(SA244)]	P89C54B@TQFP44
[(SA245A)]	
P89C54UB	P89C54UB@PLCC44
[(SA244)]	
P89C54UB@TQFP44 [(SA245A)]	

P89C54UF	
P89C54UF@PLCC44 [(SA244)]	P89C54UF@TQFP44
[(SA245A)]	
P89C54X2	P89C54X2@PLCC44
[(SA244)]	
P89C54X2@TQFP44 [(SA245A)]	
P89C54X2B	
P89C54X2B@PLCC44 [(SA244)]	P89C54X2B@TQFP44
[(SA245A)]	
P89C54X2F	P89C54X2F@PLCC44
[(SA244)]	
P89C54X2F@TQFP44 [(SA245A)]	
P89C58	
P89C58@PLCC44 [(SA244)]	P89C58@TQFP44
[(SA245A)]	
P89C58B	P89C58B@PLCC44
[(SA244)]	
P89C58B@TQFP44 [(SA245A)]	
P89C58UB	
P89C58UB@PLCC44 [(SA244)]	P89C58UB@TQFP44
[(SA245A)]	
P89C58UF	P89C58UF@PLCC44
[(SA244)]	
P89C58UF@TQFP44 [(SA245A)]	
P89C58X2	
P89C58X2@PLCC44 [(SA244)]	P89C58X2@TQFP44
[(SA245A)]	
P89C58X2B	P89C58X2B@PLCC44
[(SA244)]	
P89C58X2B@TQFP44 [(SA245A)]	
P89C58X2F	
P89C58X2F@PLCC44 [(SA244)]	P89C58X2F@TQFP44
[(SA245A)]	
P89C60X2	P89C60X2@PLCC44
[(SA244)]	
P89C60X2@TQFP44 [(SA245A)]	
P89C61X2	
P89C61X2@PLCC44 [(SA244)]	P89C61X2@TQFP44
[(SA245A)]	
P89C660	P89C660@PLCC44
[(SA244)]	
P89C660@TQFP44 [(SA245A)]	
P89C662	



P89C662@PLCC44 [(SA244)]	P89C662@TQFP44
[(SA245A)]	
P89C664	P89C664@PLCC44
[(SA244)]	
P89C664@TQFP44 [(SA245A)]	
P89C668	
P89C668@PLCC44 [(SA244)]	P89C668@TQFP44
[(SA245A)]	
P89C669	P89C669@LQFP44
[(SA245A)]	
P89C669@PLCC44 [(SA244)]	
P89C738	
P89C738@PLCC44 [(SA244)]	P89C738@TQFP44
[(SA245A)]	
P89C838	P89C838@PLCC44
[(SA244)]	
P89C838@TQFP44 [(SA245A)]	P89CV51RB2@PLCC44
[(SA244)]	
P89CV51RB2@TQFP44 [(SA245A)]	P89CV51RC2@PLCC44
[(SA244)]	
P89CV51RC2@TQFP44 [(SA245A)]	P89CV51RD2@PLCC44
[(SA244)]	
P89CV51RD2@TQFP44 [(SA245A)]	P89LPC901(FD)
[(SA602A)]	
P89LPC901(FD)(ISP) [ISP-HEADER01]	
P89LPC901(FN)	
P89LPC901(FN)(ISP) [ISP-HEADER01]	
P89LPC902(FD) [(SA602A)]	
P89LPC902(FD)(ISP) [ISP-HEADER01]	
P89LPC902(FN)	
P89LPC902(FN)(ISP) [ISP-HEADER01]	
P89LPC903(FD) [(SA602A)]	
P89LPC903(FD)(ISP) [ISP-HEADER01]	
P89LPC904(FD) [(SA605A)]	
P89LPC904(FD)(ISP) [ISP-HEADER01]	
P89LPC904(FN)	
P89LPC904(FN)(ISP) [ISP-HEADER01]	
P89LPC906(FD) [(SA605A)]	
P89LPC906(FD)(ISP) [ISP-HEADER01]	
P89LPC907(FD) [(SA605A)]	
P89LPC907(FD)(ISP) [ISP-HEADER01]	
P89LPC908(FD) [(SA605A)]	
P89LPC908(FD)(ISP) [ISP-HEADER01]	

P89LPC9102(FTK)@HVSON10 [(SA695A)]  
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9103(FTK)@HVSON10 [(SA695A)]  
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9107(FDH)@TSSOP14 [(SA643)]  
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC9107(FN)  
P89LPC9107(FN)(ISP) [ISP-HEADER01]  
P89LPC912(FDH)@TSSOP14 [(SA643)]  
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC913(FDH)@TSSOP14 [(SA643)]  
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC914(FDH)@TSSOP14 [(SA643)]  
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC915(FDH)@TSSOP14 [(SA643)]  
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC916(FDH)@TSSOP16 [(SA643)]  
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920(FN)  
P89LPC920(FN)(ISP) [ISP-HEADER01]  
P89LPC9201(FDH)@TSSOP20 [(SA643)]  
P89LPC9201(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9201(FN)  
P89LPC9201(FN)(ISP) [ISP-HEADER01]  
P89LPC920A1(FDH)@TSSOP20 [(SA643)]  
P89LPC920A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920A1(FN)  
P89LPC920A1(FN)(ISP) [ISP-HEADER01]  
P89LPC921(FDH)@TSSOP20 [(SA643)]  
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921(FN)  
P89LPC921(FN)(ISP) [ISP-HEADER01]  
P89LPC9211(FDH)@TSSOP20 [(SA643)]  
P89LPC9211(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9211(FN)  
P89LPC9211(FN)(ISP) [ISP-HEADER01]  
P89LPC921A1(FDH)@TSSOP20 [(SA643)]  
P89LPC921A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921A1(FN)

P89LPC921A1(FN)(ISP) [ISP-HEADER01]  
P89LPC922(FDH)@TSSOP20 [(SA643)]  
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922(FN)  
P89LPC922(FN)(ISP) [ISP-HEADER01]  
P89LPC9221(FDH)@TSSOP20 [(SA643)]  
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221(FN)  
P89LPC9221(FN)(ISP) [ISP-HEADER01]  
P89LPC9221A1(FDH)@TSSOP20 [(SA643)]  
P89LPC9221A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221A1(FN)  
P89LPC9221A1(FN)(ISP) [ISP-HEADER01]  
P89LPC922A1(FDH)@TSSOP20 [(SA643)]  
P89LPC922A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922A1(FN)  
P89LPC922A1(FN)(ISP) [ISP-HEADER01]  
P89LPC924(FDH)@TSSOP20 [(SA643)]  
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924(FN)  
P89LPC924(FN)(ISP) [ISP-HEADER01]  
P89LPC9241(FDH)@TSSOP20 [(SA643)]  
P89LPC9241(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9241(FN)  
P89LPC9241(FN)(ISP) [ISP-HEADER01]  
P89LPC924A1(FDH)@TSSOP20 [(SA643)]  
P89LPC924A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924A1(FN)  
P89LPC924A1(FN)(ISP) [ISP-HEADER01]  
P89LPC925(FDH)@TSSOP20 [(SA643)]  
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925(FN)  
P89LPC925(FN)(ISP) [ISP-HEADER01]  
P89LPC9251(FDH)@TSSOP20 [(SA643)]  
P89LPC9251(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9251(FN)  
P89LPC9251(FN)(ISP) [ISP-HEADER01]  
P89LPC925A1(FDH)@TSSOP20 [(SA643)]  
P89LPC925A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925A1(FN)  
P89LPC925A1(FN)(ISP) [ISP-HEADER01]  
P89LPC930(BA)@PLCC28 [(SA008A)]  
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]

P89LPC930(BDH)@TSSOP28 [(SA643)]  
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9301(BA)@PLCC28 [(SA008A)]  
P89LPC9301(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BA)@PLCC28 [(SA008A)]  
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC931(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9311(BA)@PLCC28 [(SA008A)]  
P89LPC9311(BDH)@TSSOP28 [(SA643)]  
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28  
[(SA643)]  
P89LPC93201(BA)@PLCC28 [(SA008A)]  
P89LPC93201(BDH)@TSSOP28 [(SA643)]  
P89LPC93201(FA)@PLCC28 [(SA008A)]  
P89LPC93201(FDH)@TSSOP28 [(SA643)]  
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9321(BA)@PLCC28 [(SA008A)]  
P89LPC9321(BDH)@TSSOP28 [(SA643)]  
P89LPC9321(FA)@PLCC28 [(SA008A)]  
P89LPC9321(FDH)@TSSOP28 [(SA643)]  
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(BA)@PLCC28 [(SA008A)]  
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC932A1(BDH)@TSSOP28 [(SA643)]  
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FDH)@TSSOP28 [(SA643)]  
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC933(BDH)@TSSOP28 [(SA643)]  
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(FDH)@TSSOP28 [(SA643)]  
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(HDH)@TSSOP28 [(SA643)]  
P89LPC9331(BDH)@TSSOP28 [(SA643)]  
P89LPC9331(FDH)@TSSOP28 [(SA643)]  
P89LPC9331(HDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC93401(FDH)@TSSOP28 [(SA643)]

P89LPC93401V  
P89LPC9341(BDH)@TSSOP28 [(SA643)]  
P89LPC9341(FDH)@TSSOP28 [(SA643)]  
P89LPC9341V P89LPC935(BA)@PLCC28  
[(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9361(FA)@PLCC28 [(SA008A)]  
P89LPC9361(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]  
P89LPC9381(BDH)@TSSOP28 [(SA643)]

P89LPC9381(FA)@PLCC28 [(SA008A)]  
P89LPC9381(FDH)@TSSOP28 [(SA643)]  
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC952@LQFP44 [(SA245A)]  
P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
P89LPC952@LQFP48 [(SA248)]  
P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
P89LPC952@PLCC44 [(SA244)]  
P89LPC952@PLCC44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP44 [(SA245A)]  
P89LPC954@LQFP44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP48 [(SA248)]  
P89LPC954@LQFP48(ISP) [ISP-HEADER01]  
P89LPC954@PLCC44 [(SA244)]  
P89LPC954@PLCC44(ISP) [ISP-HEADER01]  
P89LV51RB2 P89LV51RB2@PLCC44  
[(SA244)]  
P89LV51RB2@TQFP44 [(SA245A)]  
P89LV51RC2  
P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44  
[(SA245A)]  
P89LV51RD2 P89LV51RD2  
(new)  
P89LV51RD2(new)@PLCC44 [(SA244)]  
P89LV51RD2(new)@TQFP44 [(SA245A)]  
P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44  
[(SA245A)]  
P89LV51RD2BA(new)@PLCC44 [(SA244)]  
P89LV51RD2BA@PLCC44 [(SA244)]  
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2BBC@TQFP44 [(SA245A)]  
P89LV51RD2BN  
P89LV51RD2BN(new)  
P89LV51RD2FA(new)@PLCC44 [(SA244)]  
P89LV51RD2FA@PLCC44 [(SA244)]  
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2FBC@TQFP44 [(SA245A)]  
P89LV51RD2FN  
P89LV51RD2FN(new)  
P89V51RB2  
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44

[ (SA245A) ]	
P89V51RC2	P89V51RC2@PLCC44
[ (SA244) ]	
P89V51RC2@TQFP44 [ (SA245A) ]	
P89V51RD2	
P89V51RD2 (new)	P89V51RD2 (new)@PLCC44
[ (SA244) ]	
P89V51RD2 (new)@TQFP44 [ (SA245A) ]	P89V51RD2@PLCC44
[ (SA244) ]	
P89V51RD2@TQFP44 [ (SA245A) ]	
P89V51RD2BA (new)@PLCC44 [ (SA244) ]	
P89V51RD2BA@PLCC44 [ (SA244) ]	
P89V51RD2BBC (new)@TQFP44 [ (SA245A) ]	
P89V51RD2BBC@TQFP44 [ (SA245A) ]	
P89V51RD2BN	
P89V51RD2BN (new)	
P89V51RD2FA (new)@PLCC44 [ (SA244) ]	
P89V51RD2FA@PLCC44 [ (SA244) ]	
P89V51RD2FBC (new)@TQFP44 [ (SA245A) ]	
P89V51RD2FBC@TQFP44 [ (SA245A) ]	
P89V51RD2FN	
P89V51RD2FN (new)	
P89V52X2	
P89V52X2 (ISP) [ ISP-HEADER01 ]	P89V52X2@PLCC44
[ (SA244) ]	
P89V52X2@PLCC44 (ISP) [ ISP-HEADER01 ]	
P89V52X2@TQFP44 [ (SA245A) ]	
P89V52X2@TQFP44 (ISP) [ ISP-HEADER01 ]	
P89V660@PLCC44 [ (SA244) ]	P89V660@TQFP44
[ (SA245A) ]	
P89V662@PLCC44 [ (SA244) ]	P89V662@TQFP44
[ (SA245A) ]	
P89V664@PLCC44 [ (SA244) ]	P89V664@TQFP44
[ (SA245A) ]	
PXAC37@PLCC44 [ (SA244) ]	PXAC37@TQFP44
[ (SA245A) ]	
PXAG17@PLCC44 [ (SA244) ]	PXAG17@TQFP44
[ (SA245A) ]	
PXAG27@PLCC44 [ (SA244) ]	PXAG27@TQFP44
[ (SA245A) ]	
PXAG37@PLCC44 [ (SA244) ]	PXAG37@TQFP44
[ (SA245A) ]	
PXAG39@PLCC44 [ (SA244) ]	PXAG39@TQFP44

[ ( SA245A ) ]  
PXAG49@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]

PXAG49@TQFP44

## PJ

### E ( E ) PROM / FRAM / NVRAM

PJ24C02  
[ ( SA602A ) ]  
PJ24C02@TSSOP8 [ ( SA026 ) ]

PJ24C02@SOIC8

## PMC

### E ( E ) PROM / FRAM / NVRAM

PM24C64  
[ ( SA602A ) ]  
PM24C64@TSOP8 [ ( SA026 ) ]  
[ ( SA023A ) ]  
PM25LV010(Q)@WSON8 [ ( SA683 ) ]  
[ ( SA602A ) ]  
PM25LV010A@SOIC8 [ ( SA602A ) ]  
[ ( SA683 ) ]  
PM25LV016@SOIC8 [ ( SA605A ) ]  
[ ( SA683 ) ]  
PM25LV016A@SOIC8 [ ( SA605A ) ]  
[ ( SA683 ) ]  
PM25LV020(B)@SOIC8 [ ( SA023A ) ]  
[ ( SA683 ) ]  
PM25LV020(S)@SOIC8 [ ( SA602A ) ]  
[ ( SA023A ) ]  
PM25LV040(Q)@WSON8 [ ( SA683 ) ]  
[ ( SA602A ) ]  
PM25LV080@SOIC8 [ ( SA605A ) ]  
[ ( SA683 ) ]  
PM25LV080A@SOIC8 [ ( SA605A ) ]  
[ ( SA683 ) ]  
PM25LV512(B)@SOIC8 [ ( SA023A ) ]  
[ ( SA683 ) ]

PM24C64@SOIC8  
PM25LV010(B)@SOIC8  
PM25LV010(S)@SOIC8  
PM25LV010A@WSON8  
PM25LV016@WSON8  
PM25LV016A@WSON8  
PM25LV020(Q)@WSON8  
PM25LV040(B)@SOIC8  
PM25LV040(S)@SOIC8  
PM25LV080@WSON8  
PM25LV080A@WSON8  
PM25LV512(Q)@WSON8



PM25LV512(S)@SOIC8 [(SA602A)]	PM25LV512A(B)@SOIC8
[(SA023A)]	
PM25LV512A(Q)@WSON8 [(SA683)]	PM25LV512A(S)@SOIC8
[(SA602A)]	
PM29F002B	PM29F002B@PLCC32
[(SA015A1T)]	
PM29F002T	PM29F002T@PLCC32
[(SA015A1T)]	
PM29F004B	PM29F004B@PLCC32
[(SA015A1T)]	
PM29F004T	PM29F004T@PLCC32
[(SA015A1T)]	
PM29LV002B	PM29LV002B@PLCC32
[(SA015A1T)]	
PM29LV002B@VSOP32 [(SA620)]	
PM29LV002T	
PM29LV002T@PLCC32 [(SA015A1T)]	PM29LV002T@VSOP32
[(SA620)]	
PM29LV004B@PLCC32 [(SA015A1T)]	PM29LV004B@VSOP32
[(SA620)]	
PM29LV004T@PLCC32 [(SA015A1T)]	PM29LV004T@VSOP32
[(SA620)]	
PM29LV104RB@PLCC32 [(SA015A1T)]	PM29LV104RB@VSOP32
[(SA620)]	
PM29LV104RT@PLCC32 [(SA015A1T)]	PM29LV104RT@VSOP32
[(SA620)]	
PM37LV512	PM37LV512@PLCC32
[(SA015A1T)]	
PM37LV512@VSOP32 [(SA620)]	
PM39F010	
PM39F010@PLCC32 [(SA015A1T)]	PM39F010@VSOP32
[(SA620)]	
PM39F020	PM39F020@PLCC32
[(SA015A1T)]	
PM39F020@VSOP32 [(SA620)]	
PM39F040	
PM39F040@PLCC32 [(SA015A1T)]	PM39F040@VSOP32
[(SA620)]	
PM39LV010@PLCC32 [(SA015A1T)]	PM39LV010@VSOP32
[(SA620)]	
PM39LV010R@PLCC32 [(SA015A1T)]	PM39LV010R@VSOP32
[(SA620)]	
PM39LV020@PLCC32 [(SA015A1T)]	PM39LV020@VSOP32

[ (SA620) ]	
PM39LV040@PLCC32 [ (SA015A1T) ]	PM39LV040@VSOP32
[ (SA620) ]	
PM39LV512@PLCC32 [ (SA015A1T) ]	PM39LV512@VSOP32
[ (SA620) ]	
PM39LV512R@PLCC32 [ (SA015A1T) ]	PM39LV512R@VSOP32
[ (SA620) ]	
PM49FL002T@PLCC32 [ (SA015A1T) ]	PM49FL002T@VSOP32
[ (SA620) ]	
PM49FL004T(Low)@PLCC32 [ (SA015A1T-B001) ]	
PM49FL004T(Low)@VSOP32 [ (SA620-B005) ]	
PM49FL004T@PLCC32 [ (SA015A1T) ]	PM49FL004T@VSOP32
[ (SA620) ]	
PM49FL008T@PLCC32 [ (SA015A1T) ]	PM49FL008T@VSOP32
[ (SA620) ]	
PM49LP002T@PLCC32 [ (SA015A1T) ]	PM49LP002T@VSOP32
[ (SA620) ]	

## PSS

### E (E) PROM/FRAM/NVRAM

PS24C256	PS24C256@SOIC8
[ (SA602A) ]	
PS29FS001	PS29FS001@PLCC32
[ (SA015A1T) ]	
PS29FS001@TSOP32 [ (SA410T) ]	PS29FS001@VSOP32
[ (SA620) ]	
PS29LP001	PS29LP001@PLCC32
[ (SA015A1T) ]	
PS29LP001@VSOP32 [ (SA620) ]	

## PTC

### E (E) PROM/FRAM/NVRAM

PT28C020	PT28C020@PLCC32
[ (SA015A1T) ]	
PT28C040	PT28C040@PLCC32
[ (SA015A1T) ]	

PT29C020  
[ (SA015A1T) ]  
PT29C040  
[ (SA015A1T) ]

PT29C020@PLCC32  
  
PT29C040@PLCC32

## **MICROCONTROLLER**

PT89316  
[ (SA244) ]  
PT89316@TQFP44 [ (SA245A) ]  
PT8932  
PT8932@PLCC44 [ (SA244) ]  
[ (SA245) ]  
PT8936  
[ (SA244) ]  
PT8936@TQFP44 [ (SA245A) ]  
PT8956  
PT8956@PLCC44 [ (SA244) ]  
[ (SA245A) ]

PT89316@PLCC44  
  
  
PT8932@TQFP44  
  
PT8936@PLCC44  
  
PT8956@TQFP44

## **QIXIN**

### **MICROCONTROLLER**

LS2051  
[ (SA404) ]

LS2051@SOIC20

## **Quick Pulse**

### **E ( E ) PROM / FRAM / NVRAM**

27010  
27011  
27040  
27128A  
27210  
27256  
27512  
2764A

# RAMTRON

## E ( E ) PROM / FRAM / NVRAM

FM1208 [ ( SA404 ) ]	FM1208@SOIC24
FM1608 [ ( SA404 ) ]	FM1608@SOIC28
FM1808 [ ( SA404 ) ]	FM1808@SOIC28
FM18L08 [ ( SA404 ) ]	FM18L08@SOIC28
FM24164 [ ( SA602A ) ]	FM24164@SOIC8
FM24C04 ( P ) [ ( SA602A ) ]	FM24C04 ( S ) @SOP8
FM24C04A ( P ) [ ( SA602A ) ]	FM24C04A ( S ) @SOP8
FM24C16 ( P ) [ ( SA602A ) ]	FM24C16 ( S ) @SOP8
FM24C16A ( P ) [ ( SA602A ) ]	FM24C16A ( S ) @SOP8
FM24C256@SOIC8 [ ( SA605A ) ] [ ( SA602A ) ]	FM24C512@SOIC8
FM24C64 [ ( SA602A ) ]	FM24C64@SOIC8
FM24CL04 [ ( SA602A ) ]	FM24CL04@SOIC8
FM24CL16 [ ( SA602A ) ]	FM24CL16@SOIC8
FM24CL64@SOIC8 [ ( SA602A ) ]	
FM25040	
FM25040@SOIC8 [ ( SA602A ) ]	
FM25160	
FM25160@SOIC8 [ ( SA602A ) ]	
FM25640	
FM25640@SOIC8 [ ( SA602A ) ]	
FM25C160	
FM25C160@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	FM25CL04@SOIC8
FM25CL64	FM25CL64@SOIC8

[ (SA602A) ]	
FM25L16	FM25L16@SOIC8
[ (SA602A) ]	
FM25L256	FM25L256@SOIC8
[ (SA602A) ]	
FM25L256@TDFN8 [ (BBBB) ]	
FM25L512	
FM25L512@SOIC8 [ (SA602A) ]	FM25W256@SOIC8
[ (SA602A) ]	
FM30C256@SOIC20 [ (SA404) ]	FM3104@SOIC14
[ (SA602) ]	
FM3116@SOIC14 [ (SA602) ]	FM31256@SOIC14
[ (SA602) ]	
FM3164@SOIC14 [ (SA602) ]	FM32256G@SOIC14
[ (SA602) ]	
FM32256S@SOIC14 [ (SA602) ]	FM3264G@SOIC14
[ (SA602) ]	
FM3264S@SOIC14 [ (SA602) ]	
FM3808	
FM3808@TSOP32 [ (SA620) ]	

## MICROCONTROLLER

VMX51C900	VMX51C900@PLCC44
[ (SA244) ]	
VMX51C900@TQFP44 [ (SA245A) ]	
VRS1000	
VRS1000@PLCC44 [ (SA244) ]	VRS1000@TQFP44
[ (SA245A) ]	
VRS1100	VRS1100@PLCC44
[ (SA244) ]	
VRS1100@TQFP44 [ (SA245A) ]	
VRS51C1000	
VRS51C1000@PLCC44 [ (SA244) ]	VRS51C1000@TQFP44
[ (SA245A) ]	
VRS51C1100	VRS51C1100@PLCC44
[ (SA244) ]	
VRS51C1100@TQFP44 [ (SA245A) ]	
VRS51C540	
VRS51C540@PLCC44 [ (SA244) ]	VRS51C540@TQFP44
[ (SA245A) ]	
VRS51C550	VRS51C550@PLCC44

[ ( SA244 ) ]  
VRS51C550@TQFP44 [ ( SA245A ) ]  
VRS51C560  
VRS51C560@PLCC44 [ ( SA244 ) ] VRS51C560@TQFP44  
[ ( SA245A ) ]  
VRS51C570 VRS51C570@PLCC44  
[ ( SA244 ) ]  
VRS51C570@TQFP44 [ ( SA245A ) ]  
VRS51C580  
VRS51C580@PLCC44 [ ( SA244 ) ] VRS51C580@TQFP44  
[ ( SA245A ) ]  
VRS51C700 VRS51C700@PLCC44  
[ ( SA244 ) ]  
VRS51C700@TQFP44 [ ( SA245A ) ]  
VRS51L1050  
VRS51L1050@PLCC44 [ ( SA244 ) ] VRS51L1050@TQFP44  
[ ( SA245A ) ]  
VRS51L540 VRS51L540@PLCC44  
[ ( SA244 ) ]  
VRS51L540@TQFP44 [ ( SA245A ) ]  
VRS51L550  
VRS51L550@PLCC44 [ ( SA244 ) ] VRS51L550@TQFP44  
[ ( SA245A ) ]  
VRS51L560 VRS51L560@PLCC44  
[ ( SA244 ) ]  
VRS51L560@TQFP44 [ ( SA245A ) ]  
VRS51L570  
VRS51L570@PLCC44 [ ( SA244 ) ] VRS51L570@TQFP44  
[ ( SA245A ) ]  
VRS51L580 VRS51L580@PLCC44  
[ ( SA244 ) ]  
VRS51L580@TQFP44 [ ( SA245A ) ]  
VRS51X540  
VRS51X540@PLCC44 [ ( SA244 ) ] VRS51X540@TQFP44  
[ ( SA245A ) ]  
VRS51X550 VRS51X550@PLCC44  
[ ( SA244 ) ]  
VRS51X550@TQFP44 [ ( SA245A ) ]  
VRS51X560  
VRS51X560@PLCC44 [ ( SA244 ) ] VRS51X560@TQFP44  
[ ( SA245A ) ]  
VRS51X570 VRS51X570@PLCC44  
[ ( SA244 ) ]

VRS51X570@TQFP44 [(SA245A)]	
VRS51X580	
VRS51X580@PLCC44 [(SA244)]	VRS51X580@TQFP44
[(SA245A)]	
VRS540	VRS540@PLCC44
[(SA244)]	
VRS540@TQFP44 [(SA245A)]	
VRS550	
VRS550@PLCC44 [(SA244)]	VRS550@TQFP44
[(SA245A)]	
VRS560	VRS560@PLCC44
[(SA244)]	
VRS560@TQFP44 [(SA245A)]	
VRS570	
VRS570@PLCC44 [(SA244)]	VRS570@TQFP44
[(SA245A)]	
VRS580	VRS580@PLCC44
[(SA244)]	
VRS580@TQFP44 [(SA245A)]	
VRS700	
VRS700@PLCC44 [(SA244)]	VRS700@TQFP44
[(SA245A)]	
VRS900	VRS900@PLCC44
[(SA244)]	
VRS900@TQFP44 [(SA245A)]	

## RATO

### E (E) PROM/FRAM/NVRAM

RT24A02	RT24A02@SOIC8
[(SA602A)]	
RT24A02@TSSOP8 [(SA026)]	
RT24A04	
RT24A04@SOIC8 [(SA602A)]	RT24A04@TSSOP8
[(SA026)]	
RT24A08	RT24A08@SOIC8
[(SA602A)]	
RT24A08@TSSOP8 [(SA026)]	
RT24A16	
RT24A16@SOIC8 [(SA602A)]	RT24A16@TSSOP8
[(SA026)]	

RT93C46B(16bit) [(SA602A)]	RT93C46B(16bit)@SOIC8
RT93C46B(16bit)@TSSOP8 [(SA026)] (08bit)	RT93LC46
RT93LC46(08bit)@SOIC8 [(SA602A)] [(SA026)]	RT93LC46(08bit)@TSSOP8
RT93LC46(16bit) [(SA602A)]	RT93LC46(16bit)@SOIC8
RT93LC46(16bit)@TSSOP8 [(SA026)]	

## RAYDIUM

### E ( E ) PROM / FRAM / NVRAM

RM24C02@SOP8 [(SA602A)] [(SA602A)]	RM24C04@SOP8
RM24C08@SOP8 [(SA602A)] [(SA602A)]	RM24C128@SOP8
RM24C16@SOP8 [(SA602A)] [(SA602A)]	RM24C32@SOP8
RM24C64@SOP8 [(SA602A)]	

## RENESAS

### E ( E ) PROM / FRAM / NVRAM

HN58C256A(FP)@SOP28 [(SA630)] (P)	HN58C256A
HN58C256A(T)@TSOP28 [(SA643)] [(SA620)]	HN58C257A(T)@TSOP32
HN58V24256 [(SA602A)]	HN58V24256@SOIC8
HN58V24256@TSSOP14 [(SA026)]	
HN58V24512	
HN58V24512@SOIC8 [(SA602A)]	
HN58W241000	
HN58W241000@SOIC8 [(SA602A)]	
HN58X2402	
HN58X2402@SOIC8 [(SA602A)] [(SA026)]	HN58X2402@TSSOP8



HN58X2404	HN58X2404@SOIC8
[ (SA602A) ]	
HN58X2404@TSSOP8 [ (SA026) ]	
HN58X2408	
HN58X2408@SOIC8 [ (SA602A) ]	HN58X2408@TSSOP8
[ (SA026) ]	
HN58X24128	HN58X24128@SOIC8
[ (SA602A) ]	
HN58X2416	HN58X2416@SOIC8
[ (SA602A) ]	
HN58X2416@TSSOP8 [ (SA026) ]	
HN58X24256	
HN58X24256@SOIC8 [ (SA602A) ]	
HN58X2432	
HN58X2432@SOIC8 [ (SA602A) ]	HN58X2432@TSSOP8
[ (SA026) ]	
HN58X24512	HN58X24512@SOIC8
[ (SA602A) ]	
HN58X2464	HN58X2464@SOIC8
[ (SA602A) ]	
HN58X2464@TSSOP8 [ (SA026) ]	HN58X2502@SOIC8
[ (SA602A) ]	
HN58X2502@TSSOP8 [ (SA026) ]	HN58X2504@SOIC8
[ (SA602A) ]	
HN58X2504@TSSOP8 [ (SA026) ]	HN58X25128@SOIC8
[ (SA602A) ]	
HN58X25128@TSSOP14 [ (SA026) ]	HN58X25256@SOIC8
[ (SA602A) ]	
HN58X25256@TSSOP14 [ (SA026) ]	HN58X2532@SOIC8
[ (SA602A) ]	
HN58X2532@TSSOP8 [ (SA026) ]	HN58X2564@SOIC8
[ (SA602A) ]	
HN58X2564@TSSOP8 [ (SA026) ]	
M5L2732	
M5L2732A	
M5M29KB331 (AVP)@TSOP48 [ (SA247-B005) ]	
M5M29KB641 (AVP)@TSOP48 [ (SA247-B005) ]	
M5M29KE131BTP@TSOP52 [ (SA657-B117) ]	
M5M29KE131BV@TSOP48 [ (SA247-B005) ]	
M5M29KT331 (AVP)@TSOP48 [ (SA247-B005) ]	
M5M29KT641 (AVP)@TSOP48 [ (SA247-B005) ]	
M6MG3B641S16TP@TSOP52 [ (SA657-B036) ]	
M6MG3T641S16TP@TSOP52 [ (SA657-B036) ]	

M6MGB321S4TP@TSOP52 [(SA657-B036)]  
 M6MGB321S8TP@TSOP52 [(SA657-B036)]  
 M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGB331S8KT@TSOP52 [(SA657-B036)]  
 M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGB641S16TP@TSOP52 [(SA657-B036)]  
 M6MGB641S4TP@TSOP52 [(SA657-B036)]  
 M6MGB641S8TP@TSOP52 [(SA657-B036)]  
 M6MGB647M34CKT@TSOP52 [(SA657-B036)]  
 M6MGB64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]  
 M6MGB64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]  
 M6MGB64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]  
 M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
 M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]  
 M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]  
 M6MGD13TW34DWG@CSP72 [(SA642F-B064A-T064F001)]  
 M6MGE157S4KT@TSOP52 [(SA657-B055)]  
 M6MGT321S4TP@TSOP52 [(SA657-B036)]  
 M6MGT321S8TP@TSOP52 [(SA657-B036)]  
 M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGT331S8KT@TSOP52 [(SA657-B036)]  
 M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGT641S16TP@TSOP52 [(SA657-B036)]  
 M6MGT641S4TP@TSOP52 [(SA657-B036)]  
 M6MGT641S8TP@TSOP52 [(SA657-B036)]  
 M6MGT647M34CKT@TSOP52 [(SA657-B036)]  
 M6MGT64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]  
 M6MGT64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]  
 M6MGT64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]  
 M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
 M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]

## DRAM & SRAM

R1LV0408C@SOP32 [(SA438T)]                      R1LV0408C@STSOP32  
 [(SA620)]  
 R1LV0408C@TSOP32 [(SA410T)]

## MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)]	HD4074344@SOIC28
[(SA404)]	
HD4074394@SDIP28 [(SA022A)]	HD4074394@SOIC28
[(SA404)]	
HD64F3694FX@TQFP48 [(SA671)]	HD64F3694FY@TQFP48
[(SA248)]	
HD64F3694GFX@TQFP48 [(SA671)]	HD64F3694GFY@TQFP48
[(SA248)]	
M34282E2GP [(SA026)]	M34283G2GP
[(SA026)]	
M34283G2GP(ISP) [ISP-HEADER01]	M37544G2A(GP)@LQFP32
[(SA663)]	
M37544G2A(GP)@LQFP32(ISP) [ISP-HEADER01]	
M37544G2A(SP)@SDIP32 [(SA653)]	
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]	
M37545G4(GP)@LQFP32 [(SA663)]	M37545G6(GP)@LQFP32
[(SA663)]	
M37545G8(GP)@LQFP32 [(SA663)]	M37546G2(FP)@SSOP36
[(SA645)]	
M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]	
M37546G2(GP)@LQFP32 [(SA663)]	
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]	
M37546G2(SP)@SDIP32 [(SA653)]	
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]	
M37546G4(FP)@SSOP36 [(SA645)]	
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]	
M37546G4(GP)@LQFP32 [(SA663)]	
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]	
M37546G4(SP)@SDIP32 [(SA653)]	
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]	
M37547G2(FP)@SSOP36 [(SA645)]	
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]	
M37547G4(FP)@SSOP36 [(SA645)]	
M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]	
M37548G1(FP)@TSSOP20 [(SA026)]	M37548G2(FP)@TSSOP20
[(SA026)]	
M37548G3(FP)@TSSOP20 [(SA026)]	M37549G1FP@SDIP24
[(SA653)]	
M37549G2FP@SDIP24 [(SA653)]	M37549G3FP@SDIP24
[(SA653)]	
R5F21102DFP@TQFP32 [(SA663+B005)]	
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]	

R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103DFP@TQFP32 [(SA663+B005)]  
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103FP@TQFP32 [(SA663+B005)]  
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104DFP@TQFP32 [(SA663+B005)]  
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104FP@TQFP32 [(SA663+B005)]  
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112DFP@TQFP32 [(SA663+B005)]  
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112FP@TQFP32 [(SA663+B005)]  
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113DFP@TQFP32 [(SA663+B005)]  
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113FP@TQFP32 [(SA663+B005)]  
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114DFP@TQFP32 [(SA663+B005)]  
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114FP@TQFP32 [(SA663+B005)]  
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122DFP@TQFP32 [(SA663+B005)]  
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122FP@TQFP32 [(SA663+B005)]  
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123DFP@TQFP32 [(SA663+B005)]  
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123FP@TQFP32 [(SA663+B005)]  
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124DFP@TQFP32 [(SA663+B005)]  
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124FP@TQFP32 [(SA663+B005)]  
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132DFP@TQFP32 [(SA663+B005)]  
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132FP@TQFP32 [(SA663+B005)]  
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]

R5F21134DFP@TQFP32( ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32( ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725-B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725-B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026-B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026-B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725-B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725-B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026-B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697-B006)]  
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697-B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026-B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725-B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725-B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]

R5F21183DSP@TSSOP20 [(SA026-B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697-B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697-B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026-B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725-B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725-B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026-B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697-B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697-B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026-B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725-B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026-B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]

R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026-B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725-B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026-B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697-B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026-B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725-B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026-B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697-B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026-B001)]

R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725-B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026-B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697-B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026-B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725-B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026-B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026-B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725-B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]



R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026-B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697-B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697-B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026-B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725-B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026-B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697-B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697-B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026-B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725-B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026-B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]

R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697-B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697-B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026-B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725-B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026-B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026-B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725-B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026-B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697-B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]

R5F211B2SP@TSSOP20 [(SA026-B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725-B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026-B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697-B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026-B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725-B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026-B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697-B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026-B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]

R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21206JFP@TQFP48 [(SA248-B005)]  
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21206KFP@TQFP48 [(SA248-B005)]  
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207JFP@TQFP48 [(SA248-B005)]  
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207KFP@TQFP48 [(SA248-B005)]  
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208JFP@TQFP48 [(SA248-B005)]  
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208KFP@TQFP48 [(SA248-B005)]  
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AJFP@TQFP48 [(SA248-B005)]  
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AKFP@TQFP48 [(SA248-B005)]  
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CJFP@TQFP48 [(SA248-B005)]  
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CKFP@TQFP48 [(SA248-B005)]  
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216JFP@TQFP48 [(SA248-B005)]  
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216KFP@TQFP48 [(SA248-B005)]  
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217JFP@TQFP48 [(SA248-B005)]  
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217KFP@TQFP48 [(SA248-B005)]  
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]

R5F21217KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218JFP@TQFP48 [(SA248-B005)]  
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218KFP@TQFP48 [(SA248-B005)]  
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AJFP@TQFP48 [(SA248-B005)]  
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AKFP@TQFP48 [(SA248-B005)]  
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CJFP@TQFP48 [(SA248-B005)]  
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CKFP@TQFP48 [(SA248-B005)]  
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226JFP@TQFP48 [(SA248-B005)]  
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226KFP@TQFP48 [(SA248-B005)]  
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227JFP@TQFP48 [(SA248-B005)]  
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227KFP@TQFP48 [(SA248-B005)]  
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228JFP@TQFP48 [(SA248-B005)]  
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228KFP@TQFP48 [(SA248-B005)]  
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122AJFP@TQFP48 [(SA248-B005)]  
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122AKFP@TQFP48 [(SA248-B005)]  
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]

R5F21222CJFP@TQFP48 [(SA248-B005)]  
R5F21222CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21222CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F21222CKFP@TQFP48 [(SA248-B005)]  
R5F21222CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21222CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21236JFP@TQFP48 [(SA248-B005)]  
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21236KFP@TQFP48 [(SA248-B005)]  
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21237JFP@TQFP48 [(SA248-B005)]  
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21237KFP@TQFP48 [(SA248-B005)]  
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21238JFP@TQFP48 [(SA248-B005)]  
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21238KFP@TQFP48 [(SA248-B005)]  
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123AJFP@TQFP48 [(SA248-B005)]  
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123AKFP@TQFP48 [(SA248-B005)]  
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123CJFP@TQFP48 [(SA248-B005)]  
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123CKFP@TQFP48 [(SA248-B005)]  
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]

R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32 [(SA663)]  
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]  
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]  
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]  
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]  
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]  
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]  
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]  
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]



R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]  
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]  
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]

R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]

R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]  
R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(single wire) [(SA663)]  
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]  
R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]

R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]  
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]  
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]  
R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]  
R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]  
R5F21274NFP@QFP32 [(SA663)]  
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]  
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]  
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(single wire) [(SA663)]  
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21274SJFP@QFP32(UART mode) [(SA663)]  
R5F21274SKFP@QFP32 [(SA663)]  
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(single wire) [(SA663)]  
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(UART mode) [(SA663)]  
R5F21274SNFP@QFP32 [(SA663)]  
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(single wire) [(SA663)]  
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(UART mode) [(SA663)]  
R5F21275DFP@QFP32 [(SA663)]  
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(single wire) [(SA663)]  
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]  
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]  
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]  
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]

R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]  
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]  
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]  
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]

R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]

R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(single wire) [(SA026)]  
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]



R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]  
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]  
R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]  
R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]  
R5F21292SKSP@SOIC20 [(SA026)]  
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]  
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]  
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]  
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]  
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]  
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]  
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]

R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]

R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]

R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32 [(SA663)]  
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]  
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]  
R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026-B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H1SNSP@TSSOP20 [(SA026-B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H2SDSP@TSSOP20 [(SA725-B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H2SNSP@TSSOP20 [(SA725-B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J0SDSP@TSSOP20 [(SA026-B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J0SNSP@TSSOP20 [(SA026-B001)]  
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J1SDSP@TSSOP20 [(SA026-B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J1SNSP@TSSOP20 [(SA026-B001)]

R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire) [(SA026-B001)]  
R5F212K2SDFP@QFP32 [(SA663-B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SDFP@QFP32(single wire) [(SA663-B005)]  
R5F212K2SNFP@QFP32 [(SA663-B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SNFP@QFP32(single wire) [(SA663-B005)]  
R5F212K4SDFP@QFP32 [(SA663-B005)]  
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SDFP@QFP32(single wire) [(SA663-B005)]  
R5F212K4SNFP@QFP32 [(SA663-B005)]  
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SNFP@QFP32(single wire) [(SA663-B005)]  
R5F212L2SDFP@QFP32 [(SA663-B005)]  
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212L2SNFP@QFP32 [(SA663-B005)]  
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]  
R5F212L4SDFP@QFP32 [(SA663-B005)]  
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212L4SNFP@QFP32 [(SA663-B005)]  
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]

## **RICOH**

### **E ( E ) PROM / FRAM / NVRAM**

RD27C256  
RD27C32  
RD27C64

## **ROCKWELL**

### **E ( E ) PROM / FRAM / NVRAM**

R2764

R2764C  
 R2764P  
 R27C64  
 R2816  
 R5213  
 R52B13  
 R52B33

## ROHM

### E (E) PROM / FRAM / NVRAM

BR24A01A(F) [(SA602A)]	BR24A01A(FJ)
[(SA602A)]	
BR24A02(F) [(SA602A)]	BR24A02(FJ)
[(SA602A)]	
BR24A04(F) [(SA602A)]	BR24A04(FJ)
[(SA602A)]	
BR24A08(F) [(SA602A)]	BR24A08(FJ)
[(SA602A)]	
BR24A16(F) [(SA602A)]	BR24A16(FJ)
[(SA602A)]	
BR24A32(F) [(SA602A)]	BR24A32(FJ)
[(SA602A)]	
BR24A64(F) [(SA602A)]	BR24A64(FJ)
[(SA602A)]	
BR24C01@SOP8 [(SA602A)]	BR24C01@TSSOP8
[(SA026)]	
BR24C01@TSSOP8(3*3mm) [(SA666)]	
BR24C01A	
BR24C01A(F) [(SA602A)]	BR24C01A(FJ)
[(SA602A)]	
BR24C01A(FV) [(SA026)]	
BR24C02	
BR24C02(F) [(SA602A)]	BR24C02(FJ)
[(SA602A)]	
BR24C02(FV) [(SA026)]	BR24C02@SOP8
[(SA602A)]	
BR24C02@TSSOP8 [(SA026)]	BR24C02@TSSOP8(3*3mm)
[(SA666)]	
BR24C04	BR24C04(F)
[(SA602A)]	

BR24C04(FJ) [(SA602A)]	BR24C04(FV)
[(SA026)]	
BR24C04@SOP8 [(SA602A)]	BR24C04@TSSOP8
[(SA026)]	
BR24C04@TSSOP8(3*3mm) [(SA666)]	
BR24C08	
BR24C08(F) [(SA602A)]	BR24C08(FJ)
[(SA602A)]	
BR24C08(FV) [(SA026)]	BR24C08@SOP8
[(SA602A)]	
BR24C08@TSSOP8 [(SA026)]	BR24C08@TSSOP8(3*3mm)
[(SA666)]	
BR24C16	BR24C16(F)
[(SA602A)]	
BR24C16(FJ) [(SA602A)]	BR24C16(FV)
[(SA026)]	
BR24C21	BR24C21(F)
[(SA602A)]	
BR24C21(FJ) [(SA602A)]	BR24C21(FV)
[(SA026)]	
BR24C32	BR24C32(F)
[(SA602A)]	
BR24C64	BR24C64(F)
[(SA602A)]	
BR24E16	BR24E16(F)
[(SA602A)]	
BR24E16(FJ) [(SA602A)]	BR24E16(FV)
[(SA026)]	
BR24G32	BR24G32(F)
[(SA602A)]	
BR24G32(FJ) [(SA602A)]	BR24G32(FV)
[(SA026)]	
BR24G32(FVT) [(SA026)]	
BR24L01A	
BR24L01A(F) [(SA602A)]	BR24L01A(FJ)
[(SA602A)]	
BR24L01A(FV) [(SA026)]	BR24L01A(FVM)
[(SA666)]	
BR24L02	BR24L02(F)
[(SA602A)]	
BR24L02(FJ) [(SA602A)]	BR24L02(FV)
[(SA026)]	
BR24L02(FVM) [(SA666)]	



BR24L04	
BR24L04(F) [(SA602A)]	BR24L04(FJ)
[(SA602A)]	
BR24L04(FV) [(SA026)]	BR24L04(FVM)
[(SA666)]	
BR24L08	BR24L08(F)
[(SA602A)]	
BR24L08(FJ) [(SA602A)]	BR24L08(FV)
[(SA026)]	
BR24L08(FVM) [(SA666)]	
BR24L16	
BR24L16(F) [(SA602A)]	BR24L16(FJ)
[(SA602A)]	
BR24L16(FV) [(SA026)]	BR24L16(FVM)
[(SA666)]	
BR24L32	BR24L32(F)
[(SA602A)]	
BR24L32(FJ) [(SA602A)]	BR24L32(FV)
[(SA026)]	
BR24L64	BR24L64(F)
[(SA602A)]	
BR24L64(FJ) [(SA602A)]	BR24L64(FV)
[(SA026)]	
BR24S08(F) [(SA602A)]	BR24S08(FJ)
[(SA602A)]	
BR24S08(FV) [(SA026)]	BR24S08(FVJ)
[(SA026)]	
BR24S08(FVM) [(SA666)]	BR24S08(FVT)
[(SA026)]	
BR24S128	BR24S128(F)
[(SA602A)]	
BR24S128(FJ) [(SA602A)]	BR24S128(FV)
[(SA026)]	
BR24S16	BR24S16(F)
[(SA602A)]	
BR24S16(FJ) [(SA602A)]	BR24S16(FV)
[(SA026)]	
BR24S16(FVM) [(SA666)]	
BR24S256	
BR24S256(F) [(SA602A)]	BR24S256(FJ)
[(SA602A)]	
BR24S256(FV) [(SA026)]	
BR24S32	

BR24S32(F) [(SA602A)]	BR24S32(FJ)
[(SA602A)]	
BR24S32(FV) [(SA026)]	
BR24S64	
BR24S64(F) [(SA602A)]	BR24S64(FJ)
[(SA602A)]	
BR24S64(FV) [(SA026)]	BR25010@SOIC8
[(SA602A)]	
BR25010@TSSOP8 [(SA026)]	BR25020@SOIC8
[(SA602A)]	
BR25020@TSSOP8 [(SA026)]	BR25040@SOIC8
[(SA602A)]	
BR25040@TSSOP8 [(SA026)]	BR25080@SOIC8
[(SA602A)]	
BR25080@TSSOP8 [(SA026)]	BR25160@SOIC8
[(SA602A)]	
BR25160@TSSOP8 [(SA026)]	BR25320@SOIC8
[(SA602A)]	
BR25H010(F) [(SA602A)]	BR25H010(FJ)
[(SA602A)]	
BR25H020(F) [(SA602A)]	BR25H020(FJ)
[(SA602A)]	
BR25H040(F) [(SA602A)]	BR25H040(FJ)
[(SA602A)]	
BR25H080(F) [(SA602A)]	BR25H080(FJ)
[(SA602A)]	
BR25H080(FVT) [(SA026)]	BR25H160(F)
[(SA602A)]	
BR25H160(FJ) [(SA602A)]	BR25H160(FVT)
[(SA026)]	
BR25H320(F) [(SA602A)]	BR25H320(FJ)
[(SA602A)]	
BR25H320(FVT) [(SA026)]	
BR25L010	
BR25L010(F) [(SA602A)]	BR25L010(FJ)
[(SA602A)]	
BR25L010(FV) [(SA026)]	BR25L010(FVM)
[(SA666)]	
BR25L020	BR25L020(F)
[(SA602A)]	
BR25L020(FJ) [(SA602A)]	BR25L020(FV)
[(SA026)]	
BR25L020(FVM) [(SA666)]	

BR25L040	
BR25L040(F) [(SA602A)]	BR25L040(FJ)
[(SA602A)]	
BR25L040(FV) [(SA026)]	BR25L040(FVM)
[(SA666)]	
BR25L080	BR25L080(F)
[(SA602A)]	
BR25L080(FJ) [(SA602A)]	BR25L080(FV)
[(SA026)]	
BR25L160	BR25L160(F)
[(SA602A)]	
BR25L160(FJ) [(SA602A)]	BR25L160(FV)
[(SA026)]	
BR25L320	BR25L320(F)
[(SA602A)]	
BR25L320(FJ) [(SA602A)]	BR25L320(FV)
[(SA026)]	
BR25L640	BR25L640(F)
[(SA602A)]	
BR25L640(FJ) [(SA602A)]	BR25L640(FV)
[(SA026)]	
BR34C02A [(SA026)]	
BR34L02	
BR34L02(F) [(SA602A)]	BR34L02(FJ)
[(SA602A)]	
BR34L02(FV) [(SA026)]	BR34L02(FVM)
[(SA666)]	
BR9010	BR9010(F)
[(SA602A)]	
BR9010(FV) [(SA026)]	BR9010(RFV)
[(SA026)]	
BR9010(RFVM) [(SA666)]	
BR9016	
BR9016(F) [(SA602A)]	BR9016(RFV)
[(SA026)]	
BR9016A(F) [(SA602A)]	BR9016A(RFV)
[(SA026)]	
BR9016A(RFVM) [(SA666)]	
BR9020	
BR9020(F) [(SA602A)]	BR9020(FV)
[(SA026)]	
BR9020(RFV) [(SA026)]	BR9020(RFVM)
[(SA666)]	

BR9040	BR9040 (F)
[(SA602A)]	
BR9040(FV) [(SA026)]	BR9040(RFV)
[(SA026)]	
BR9040(RFVM) [(SA666)]	
BR9080	
BR9080(F) [(SA602A)]	BR9080(RFV)
[(SA026)]	
BR9080A	BR9080A(F)
[(SA602A)]	
BR9080A(FV) [(SA026)]	BR9080A(RFV)
[(SA026)]	
BR9080A(RFVM) [(SA666)]	BR93A46(F)
[(SA602A)]	
BR93A46(FJ) [(SA602A)]	BR93A46(RF)
[(SA602A)]	
BR93A46(RFJ) [(SA602A)]	BR93A56(F)
[(SA602A)]	
BR93A56(FJ) [(SA602A)]	BR93A56(RF)
[(SA602A)]	
BR93A56(RFJ) [(SA602A)]	BR93A66(F)
[(SA602A)]	
BR93A66(FJ) [(SA602A)]	BR93A66(RF)
[(SA602A)]	
BR93A66(RFJ) [(SA602A)]	BR93A76(F)
[(SA602A)]	
BR93A76(FJ) [(SA602A)]	BR93A76(RF)
[(SA602A)]	
BR93A76(RFJ) [(SA602A)]	BR93A86(F)
[(SA602A)]	
BR93A86(FJ) [(SA602A)]	BR93A86(RF)
[(SA602A)]	
BR93A86(RFJ) [(SA602A)]	
BR93C46	
BR93C46(F) [(SA602A)]	BR93C46(FJ)
[(SA602A)]	
BR93C46(FV) [(SA026)]	BR93C46(RF)
[(SA602A)]	
BR93C46(RFJ) [(SA602A)]	
BR93C56	
BR93C56(F) [(SA602A)]	BR93C56(FJ)
[(SA602A)]	
BR93C56(FV) [(SA026)]	BR93C56(RF)

[ ( SA602A ) ]	
BR93C56 ( RFJ ) [ ( SA602A ) ]	
BR93C66	
BR93C66 ( F ) [ ( SA602A ) ]	BR93C66 ( FJ )
[ ( SA602A ) ]	
BR93C66 ( FV ) [ ( SA026 ) ]	BR93C66 ( RF )
[ ( SA602A ) ]	
BR93C66 ( RFJ ) [ ( SA602A ) ]	BR93H46 ( RF )
[ ( SA602A ) ]	
BR93H46 ( RFJ ) [ ( SA602A ) ]	BR93H56 ( RF )
[ ( SA602A ) ]	
BR93H56 ( RFJ ) [ ( SA602A ) ]	BR93H66 ( RF )
[ ( SA602A ) ]	
BR93H66 ( RFJ ) [ ( SA602A ) ]	BR93H76 ( RF )
[ ( SA602A ) ]	
BR93H76 ( RFJ ) [ ( SA602A ) ]	BR93H86 ( RF )
[ ( SA602A ) ]	
BR93H86 ( RFJ ) [ ( SA602A ) ]	
BR93L46	
BR93L46 ( F ) [ ( SA602A ) ]	BR93L46 ( FJ )
[ ( SA602A ) ]	
BR93L46 ( FV ) [ ( SA026 ) ]	BR93L46 ( RF )
[ ( SA602A ) ]	
BR93L46 ( RFJ ) [ ( SA602A ) ]	
BR93L56	
BR93L56 ( F ) [ ( SA602A ) ]	BR93L56 ( FJ )
[ ( SA602A ) ]	
BR93L56 ( FV ) [ ( SA026 ) ]	BR93L56 ( RF )
[ ( SA602A ) ]	
BR93L56 ( RFJ ) [ ( SA602A ) ]	
BR93L66	
BR93L66 ( F ) [ ( SA602A ) ]	BR93L66 ( FJ )
[ ( SA602A ) ]	
BR93L66 ( FV ) [ ( SA026 ) ]	BR93L66 ( RF )
[ ( SA602A ) ]	
BR93L66 ( RFJ ) [ ( SA602A ) ]	BR93L76 ( F )
[ ( SA602A ) ]	
BR93L76 ( FJ ) [ ( SA602A ) ]	BR93L76 ( RF )
[ ( SA602A ) ]	
BR93L76 ( RFJ ) [ ( SA602A ) ]	BR93L76 ( RFV )
[ ( SA026A ) ]	
BR93L76 ( RFVJ ) [ ( SA666A ) ]	BR93L76 ( RFVM )
[ ( SA666A ) ]	

BR93L76(RFVT) [(SA026A)]	BR93L86(F)
[(SA602A)]	
BR93L86(FJ) [(SA602A)]	BR93L86(RF)
[(SA602A)]	
BR93L86(RFJ) [(SA602A)]	BR93L86(RFV)
[(SA026A)]	
BR93L86(RFVJ) [(SA666A)]	BR93L86(RFVM)
[(SA666A)]	
BR93L86(RFVT) [(SA026A)]	
BR93LC46	
BR93LC46(F) [(SA602A)]	BR93LC46(FJ)
[(SA602A)]	
BR93LC46(FV) [(SA026)]	BR93LC46(RF)
[(SA602A)]	
BR93LC46(RFJ) [(SA602A)]	
BR93LC56	
BR93LC56(F) [(SA602A)]	BR93LC56(FJ)
[(SA602A)]	
BR93LC56(FV) [(SA026)]	BR93LC56(RF)
[(SA602A)]	
BR93LC56(RFJ) [(SA602A)]	
BR93LC66	
BR93LC66(F) [(SA602A)]	BR93LC66(FJ)
[(SA602A)]	
BR93LC66(FV) [(SA026)]	BR93LC66(RF)
[(SA602A)]	
BR93LC66(RFJ) [(SA602A)]	BR93LL46(F)
[(SA602A)]	
BR93LL46(FV) [(SA026)]	BR95010(3*3)@TSSOP8
[(SA666)]	
BR95010@SO8 [(SA602A)]	BR95010@TSSOP8
[(SA026)]	
BR95020(3*3)@TSSOP8 [(SA666)]	BR95020@SO8
[(SA602A)]	
BR95020@TSSOP8 [(SA026)]	BR95040(3*3)@TSSOP8
[(SA666)]	
BR95040@SO8 [(SA602A)]	BR95040@TSSOP8
[(SA026)]	
BR95080@SO8 [(SA602A)]	BR95080@TSSOP8
[(SA026)]	
BR95160@SO8 [(SA602A)]	BR95160@TSSOP8
[(SA026)]	

**SAIFUN****E (E) PROM/FRAM/NVRAM**

SA24C1024 [ (SA602A) ]	SA24C1024@SOIC8
SA24C512 [ (SA602A) ]	SA24C512@SOIC8
SA24C512@TSSOP8 [ (SA026) ]	
SA25C020 SA25C020@MLF8 [ (SA683) ] [ (SA602A) ]	SA25C020@SOIC8
SA25C040 [ (SA683) ]	SA25C040@MLF8
SA25C040@SOIC8 [ (SA602A) ]	
SA25C080 SA25C080@MLF8 [ (SA683) ] [ (SA602A) ]	SA25C080@SOIC8
SA25C1024(H) [ (SA683) ]	SA25C1024(H)@CSP8
SA25C1024(H)@SOIC8 [ (SA602A) ] (L)	SA25C1024
SA25C1024(L)@CSP8 [ (SA683) ] [ (SA602A) ]	SA25C1024(L)@SOIC8
SA25C512(H) [ (SA683) ]	SA25C512(H)@CSP8
SA25C512(H)@SOIC8 [ (SA602A) ] (L)	SA25C512
SA25C512(L)@CSP8 [ (SA683) ] [ (SA602A) ]	SA25C512(L)@SOIC8
SA25F005 [ (SA683) ]	SA25F005@MLF8
SA25F005@SOIC8 [ (SA602A) ]	
SA25F010 SA25F010@MLF8 [ (SA683) ] [ (SA602A) ]	SA25F010@SOIC8
SA25F020 [ (SA683) ]	SA25F020@MLF8
SA25F020@SOIC8 [ (SA602A) ]	
SA25F040 SA25F040@MLF8 [ (SA683) ] [ (SA602A) ]	SA25F040@SOIC8

SA25F080 SA25F080@MLF8  
[ (SA683) ]  
SA25F080@SOIC8 [ (SA602A) ]  
SA25F160  
SA25F160(ISP) [ ISP-HEADER01 ] SA25F160@MLF8  
[ (SA683) ]  
SA25F160@MLF8(ISP) [ ISP-HEADER01 ]  
SA25F160@SOIC16 [ (SA602) ]  
SA25F160@SOIC16(ISP) [ ISP-HEADER01 ]

## SAMSUNG

### E ( E ) PROM / FRAM / NVRAM

K5A3240CBM@TFBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A3240CTM@TFBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A3240YBB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3240YBC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3240YTB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3240YTC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3280YBB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3280YBC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3280YTB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3280YTC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3281CBM@TFBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A3281CTM@TFBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A3340YBB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3340YBC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3340YTB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3340YTC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3380YBB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3380YBC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3380YTB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3380YTC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A6317CBM@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A6317CTM@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5D1257DCMD090@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5D5613HCMD075@FBGA137 [ (SA700E-B153-M137F001Y) ]  
K5D5613VCMD075@FBGA137 [ (SA700E-B153-M137F001Y) ]  
K5D5629ACCD090@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5D5657ACAD090@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5D5657ACBD090@FBGA107 [ (SA642V-B133-T096F001Y) ]



K5D5657DCAD090@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5J6316CBM@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
K5J6316CTM@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
K5J6332CBM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5J6332CTM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5L2864ABM@FBGA115 [ ( SA664A-B189A-W115F001Y ) ]  
K5L2864ATM@FBGA115 [ ( SA664A-B189A-W115F001Y ) ]  
K5L3216CAM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5L3316CAM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5L6331CAA@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
K5L6631CAA@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
K5N3217ABM@FBGA56 [ ( SA733A-B212A-M056F001Y ) ]  
K5N3217ATM@FBGA56 [ ( SA733A-B212A-M056F001Y ) ]  
K5N5629ABA@FBGA56 [ ( SA733A-B212A-M056F001Y ) ]  
K5N5629ATA@FBGA56 [ ( SA733A-B212A-M056F001Y ) ]  
K8D1716UBC@FBGA48 [ ( SA642N-B026A-W048F001N ) ]  
K8D1716UBC@TSOP48 [ ( SA247-B005 ) ]  
K8D1716UTC@FBGA48 [ ( SA642N-B026A-W048F001N ) ]  
K8D1716UTC@TSOP48 [ ( SA247-B005 ) ]  
K8D3216UBB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D3216UBB@TSOP48 [ ( SA247-B005 ) ]  
K8D3216UBC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D3216UBC@TSOP48 [ ( SA247-B005 ) ]  
K8D3216UTB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D3216UTB@TSOP48 [ ( SA247-B005 ) ]  
K8D3216UTC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D3216UTC@TSOP48 [ ( SA247-B005 ) ]  
K8D3316UBC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D3316UBC@TSOP48 [ ( SA247-B005 ) ]  
K8D3316UTC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D3316UTC@TSOP48 [ ( SA247-B005 ) ]  
K8D6316UBM@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D6316UBM@TSOP48 [ ( SA247-B005 ) ]  
K8D6316UTM@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D6316UTM@TSOP48 [ ( SA247-B005 ) ]  
K8P3215UQB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
K8P3215UQB@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
K8P3215UQB@TSOP48 [ ( SA247-B005 ) ]  
K8P6415UQB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
K8P6415UQB@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
K8P6415UQB@TSOP48 [ ( SA247-B005 ) ] K8Q2815UQB@TSOP56 [ ( SA628  
+B102 ) ]  
K9F1208R0B@TSOP48 [ ( SA247-B005 ) ]

K9F1208R0C@FBGA63 [ ( SA642LL-B280-M063F001N ) ]  
K9F1208U0A@TSOP48 [ ( SA247-B005 ) ]  
K9F1208U0B@FBGA63 [ ( SA642LL-B026-M063F001N ) ]  
K9F1208U0B@TSOP48 [ ( SA247-B005 ) ]  
K9F1208U0C@FBGA63 [ ( SA642LL-B026-M063F001N ) ]  
K9F1208U0C@TSOP48 [ ( SA247-B005 ) ] K9F1208U0M@TSOP48 [ ( SA247-B005 ) ]  
K9F1216U0A@TSOP48 [ ( SA247-B005 ) ] K9F1G08Q0M@TSOP48 [ ( SA247-B005 ) ]  
K9F1G08U0A@TSOP48 [ ( SA247-B005 ) ] K9F1G08U0M@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16D0M(PCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16D0M(PIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16D0M(YCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16D0M(YIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16Q0M(PCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16Q0M(PIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16Q0M(YCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16Q0M(YIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16U0M(PCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16U0M(PIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16U0M(YCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16U0M(YIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F2808U0C@TSOP48 [ ( SA247-B005 ) ]  
K9F2G08R0A@FBGA63 [ ( SA642V-B280A-T096F001 ) ]  
K9F2G08U0A@TSOP48 [ ( SA247-B005 ) ] K9F2G08U0M@TSOP48 [ ( SA247-B005 ) ]  
K9F4008W0A@TSOP44 [ ( SA645 ) ] K9F4G08U0A@TSOP48 [ ( SA247-B005 ) ]  
K9F4G08U0M@TSOP48 [ ( SA247-B005 ) ]  
K9F5608R0D@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
K9F5608U0B(partition)@TSOP48 [ ( SA247-B005 ) ]  
K9F5608U0B@TSOP48 [ ( SA247-B005 ) ]  
K9F5608U0C(partition)@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
K9F5608U0C(partition)@TSOP48 [ ( SA247-B005 ) ]  
K9F5608U0C@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
K9F5608U0C@TSOP48 [ ( SA247-B005 ) ]  
K9F5608U0D(partition)@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
K9F5608U0D(partition)@TSOP48 [ ( SA247-B005 ) ]  
K9F5608U0D@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
K9F5608U0D@TSOP48 [ ( SA247-B005 ) ] K9F6408U0C@TSOP44 [ ( SA645-B005 ) ]  
K9F8G08U0A@TSOP48 [ ( SA247-B005 ) ] K9F8G08U0M@TSOP48 [ ( SA247-

B005) ]  
K9G4G08U0A@TSOP48 [ (SA247-B005) ]      K9G8G08U0M@TSOP48 [ (SA247-B005) ]  
K9GAG08U0M@TSOP48 [ (SA247-B005) ]      K9HBG08U1M@TSOP48 [ (SA247-B005) ]  
K9K1208D0C@FBGA63 [ (SA642KK-B026-W048F001Y) ]  
K9K1208U0A@TSOP48 [ (SA247-B005) ]      K9K1208U0M@TSOP48 [ (SA247-B005) ]  
K9K1216Q0C@FBGA63 [ (SA664A-B114-W115F001) ]  
K9K1G08U0M@TSOP48 [ (SA247-B005) ]  
K9K2G08Q0M(PCB0)(no ST)@TSOP48 [ (SA247-B005) ]  
K9K2G08Q0M(PIB0)(no ST)@TSOP48 [ (SA247-B005) ]  
K9K2G08Q0M(YCB0)(no ST)@TSOP48 [ (SA247-B005) ]  
K9K2G08Q0M(YIB0)(no ST)@TSOP48 [ (SA247-B005) ]  
K9K2G08Q0M@TSOP48 [ (SA247-B005) ]  
K9K2G08U0M(PCB0)(no ST)@TSOP48 [ (SA247-B005) ]  
K9K2G08U0M(PIB0)(no ST)@TSOP48 [ (SA247-B005) ]  
K9K2G08U0M(YCB0)(no ST)@TSOP48 [ (SA247-B005) ]  
K9K2G08U0M(YIB0)(no ST)@TSOP48 [ (SA247-B005) ]  
K9K2G08U0M@TSOP48 [ (SA247-B005) ]      K9K4G08Q0M@TSOP48 [ (SA247-B005) ]  
K9K4G08U0M@TSOP48 [ (SA247-B005) ]  
K9K4G16Q0M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9K4G16Q0M(PIB0)@TSOP48 [ (SA247-B005) ]  
K9K4G16Q0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9K4G16Q0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9K4G16U0M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9K4G16U0M(PIB0)@TSOP48 [ (SA247-B005) ]  
K9K4G16U0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9K4G16U0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9K8G08U0A@TSOP48 [ (SA247-B005) ]      K9L8G08U0M@TSOP48 [ (SA247-B005) ]  
K9LAG08U0M@TSOP48 [ (SA247-B005) ]      K9LAG08U1M@TSOP48 [ (SA247-B005) ]  
K9LBG08U0M@TSOP48 [ (SA247-B005) ]      K9T1G08U0M@TSOP48 [ (SA247-B005) ]  
K9W8G08U1M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9W8G08U1M(PIB0)@TSOP48 [ (SA247-B005) ]  
KAD060300B@TBGA69 [ (SA642A-B039A-Y096F001) ]  
KAD060300C@TBGA69 [ (SA642A-B039A-Y096F001) ]  
KAD060700D@TBGA69 [ (SA642A-B039A-Y096F001Y) ]  
KAD070300B@TBGA69 [ (SA642A-B039A-Y096F001) ]  
KAD070300C@TBGA69 [ (SA642A-B039A-Y096F001) ]

KAD070700D@TBGA69 [ ( SA642A-B039A-Y096F001Y ) ]  
KAD090300B@TBGA69 [ ( SA642A-B039A-Y096F001 ) ]  
KAD100300B@TBGA69 [ ( SA642A-B039A-Y096F001 ) ]  
KBE00500AM-D437@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
KBE00F003A-D411@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
KBE00G005M-D411@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
KBE00S005M-D411@FBGA137 [ ( SA700D-B153A-Y130F001Y ) ]  
KBE00S00AM-D411@FBGA137 [ ( SA700D-B153A-Y130F001Y ) ]  
KFG1216Q2B-DEB8@FBGA63 [ ( SA664L-B266-W063F001Y ) ]  
KFG1216U2A-DIB5@FBGA63 [ ( SA664L-B266-W063F001Y ) ]  
KFG1216U2A-DIB6@FBGA63 [ ( SA664L-B266-W063F001Y ) ]  
KFG1216U2B-DIB5@FBGA63 [ ( SA664L-B266-W063F001Y ) ]  
KFG1216U2B-DIB6@FBGA63 [ ( SA664L-B266-W063F001Y ) ]  
KFG5616D1M@FBGA63 [ ( SA642A-B026A-Y096N001 ) ]  
KFG5616Q1M@FBGA63 [ ( SA642A-B026A-Y096N001 ) ]  
KFG5616U1M@FBGA63 [ ( SA642A-B026A-Y096N001 ) ]  
KM2816A  
KM2816AI  
KM2817A  
KM2817AI  
KM2864A  
KM2864AH  
KM2865A  
KM2865AH  
KM28C16  
KM28C16@PLCC32  
[ ( SA015A1T ) ]  
KM28C16I  
KM28C16I@PLCC32  
[ ( SA015A1T ) ]  
KM28C17  
KM28C17@PLCC32  
[ ( SA015A1T ) ]  
KM28C17I  
KM28C17I@PLCC32  
[ ( SA015A1T ) ]  
KM28C256  
KM28C256@PLCC32  
[ ( SA015A1T ) ]  
KM28C256I  
KM28C256I@PLCC32  
[ ( SA015A1T ) ]  
KM28C64  
KM28C64@PLCC32  
[ ( SA015A1T ) ]  
KM28C64A  
KM28C64A@PLCC32  
[ ( SA015A1T ) ]  
KM28C64B  
KM28C64B@PLCC32  
[ ( SA015A1T ) ]  
KM28C64I  
KM28C64I@PLCC32

[ (SA015A1T) ]	
KM28C65	KM28C65@PLCC32
[ (SA015A1T) ]	
KM28C65A	KM28C65A@PLCC32
[ (SA015A1T) ]	
KM28C65I	KM28C65I@PLCC32
[ (SA015A1T) ]	
KM29U128T@TSOP48 [ (SA247-B005) ]	KM29W32000AIT@TSOP44
[ (SA645) ]	
KM29W32000AT@TSOP44 (DWB) [ (SA645) ]	
KM29W32000AT@TSOP44 (ZMQ) [ (SA645) ]	
KM93C06 (08bit)	KM93C06
(16bit)	
KM93C06 (G) (08bit)@SOIC8 [ (SA602A) ]	
KM93C06 (G) (16bit)@SOIC8 [ (SA602A) ]	
KM93C06 (GD) (08bit)@SOIC8 [ (SA602A) ]	
KM93C06 (GD) (16bit)@SOIC8 [ (SA602A) ]	
KM93C07 (08bit)	KM93C07
(16bit)	
KM93C07 (G) (08bit)@SOIC8 [ (SA602A) ]	
KM93C07 (G) (16bit)@SOIC8 [ (SA602A) ]	
KM93C07 (GD) (08bit)@SOIC8 [ (SA602A) ]	
KM93C07 (GD) (16bit)@SOIC8 [ (SA602A) ]	
KM93C46V	KM93C46V (G)@SOIC8
[ (SA602A) ]	
KM93C46V (GD)@SOIC8 [ (SA602A) ]	
KM93C47V	
KM93C47V (G)@SOIC8 [ (SA602A) ]	KM93C47V (GD)@SOIC8
[ (SA602A) ]	
KM93C56V	KM93C56V (G)@SOIC8
[ (SA602A) ]	
KM93C56V (GD)@SOIC8 [ (SA602A) ]	
KM93C57V	
KM93C57V (G)@SOIC8 [ (SA602A) ]	KM93C57V (GD)@SOIC8
[ (SA602A) ]	
KM93C66V	KM93C66V (G)@SOIC8
[ (SA602A) ]	
KM93C66V (GD)@SOIC8 [ (SA602A) ]	
KM93C67V	
KM93C67V (G)@SOIC8 [ (SA602A) ]	KM93C67V (GD)@SOIC8
[ (SA602A) ]	
KS24C010	KS24C010@SOIC8
[ (SA602A) ]	

KS24C010@TSSOP8 [(SA026)]	
KS24C011	
KS24C011@SOIC8 [(SA602A)]	KS24C011@TSSOP8
[(SA026)]	
KS24C020	KS24C020@SOIC8
[(SA602A)]	
KS24C020@TSSOP8 [(SA026)]	
KS24C021	
KS24C021@SOIC8 [(SA602A)]	KS24C021@TSSOP8
[(SA026)]	
KS24C040	KS24C040@SOIC8
[(SA602A)]	
KS24C040@TSSOP8 [(SA026)]	
KS24C041	
KS24C041@SOIC8 [(SA602A)]	KS24C041@TSSOP8
[(SA026)]	
KS24C080	KS24C080@SOIC8
[(SA602A)]	
KS24C080@TSSOP8 [(SA026)]	
KS24C081	
KS24C081@SOIC8 [(SA602A)]	KS24C081@TSSOP8
[(SA026)]	
S524A40X10	S524A40X10@SOP8
[(SA602A)]	
S524A40X10@TSSOP8 [(SA026)]	
S524A40X11	
S524A40X11@SOP8 [(SA602A)]	S524A40X11@TSSOP8
[(SA026)]	
S524A40X20	S524A40X20@SOP8
[(SA602A)]	
S524A40X20@TSSOP8 [(SA026)]	
S524A40X21	
S524A40X21@SOP8 [(SA602A)]	S524A40X21@TSSOP8
[(SA026)]	
S524A40X40	S524A40X40@SOP8
[(SA602A)]	
S524A40X40@TSSOP8 [(SA026)]	
S524A40X41	
S524A40X41@SOP8 [(SA602A)]	S524A40X41@TSSOP8
[(SA026)]	
S524A60X51	S524A60X51@SOP8
[(SA602A)]	
S524A60X51@TSSOP8 [(SA026)]	

S524A60X81	
S524A60X81@SOP8 [(SA602A)]	S524A60X81@TSSOP8
[(SA026)]	
S524AB0X91	S524AB0X91@SOP8
[(SA602A)]	
S524AB0X91@TSSOP8 [(SA026)]	
S524AB0XB1	
S524AB0XB1@SOP8 [(SA602A)]	S524AB0XB1@TSSOP8
[(SA026)]	
S524AD0XD1	S524AD0XD1@SOP8
[(SA602A)]	
S524AD0XD1@TSSOP8 [(SA026)]	
S524AD0XF1	
S524AD0XF1@SOP8 [(SA602A)]	S524AD0XF1@TSSOP8
[(SA026)]	
S524C20D11	S524C20D11@SOP8
[(SA602A)]	
S524C20D11@TSSOP8 [(SA026)]	
S524C20D21	
S524C20D21@SOP8 [(SA602A)]	S524C20D21@TSSOP8
[(SA026)]	
S524C80D41	S524C80D41@SOP8
[(SA602A)]	
S524C80D41@TSSOP8 [(SA026)]	
S524C80D81	
S524C80D81@SOP8 [(SA602A)]	S524C80D81@TSSOP8
[(SA026)]	
S524L50X51	S524L50X51@SOP8
[(SA602A)]	
S524L50X51@TSSOP8 [(SA026)]	
S524LB0X91	
S524LB0X91@SOP8 [(SA602A)]	S524LB0X91@TSSOP8
[(SA026)]	
S524LB0XB1	S524LB0XB1@SOP8
[(SA602A)]	
S524LB0XB1@TSSOP8 [(SA026)]	

## DRAM & SRAM

KM61257	KM61257@SOJ24
[(SA646)]	
KM61257L	KM61257L@SOJ24

[ (SA646) ]	
KM6165	KM6165@SOJ24
[ (SA646) ]	
KM6165L	KM6165L@SOJ24
[ (SA646) ]	
KM62256A	KM62256A@SOIC28
[ (SA630) ]	
KM62256AL	KM62256AL@SOIC28
[ (SA630) ]	
KM6264A	KM6264A@SOIC28
[ (SA630) ]	
KM6264AL	KM6264AL@SOIC28
[ (SA630) ]	
KM64257	KM64257@SOJ24
[ (SA646) ]	
KM64257L	KM64257L@SOJ24
[ (SA646) ]	
KM6465LP	KM6465LP@SOJ22
[ (SA646) ]	
KM6465P	
KM68257LP	
KM68257LP@SOIC28 [ (SA630) ]	
KM68257P	
KM68257P@SOIC28 [ (SA630) ]	
KM6865LP	
KM6865LP@SOIC28 [ (SA630) ]	
KM6865P	
KM6865P@SOIC28 [ (SA630) ]	

## PLD

CPL16L8	CPL16L8@PLCC20
[ (SA001A) ]	
CPL16L8L	CPL16L8L@PLCC20
[ (SA001A) ]	
CPL16R4	CPL16R4@PLCC20
[ (SA001A) ]	
CPL16R4L	CPL16R4L@PLCC20
[ (SA001A) ]	
CPL16R6	CPL16R6@PLCC20
[ (SA001A) ]	
CPL16R6L	CPL16R6L@PLCC20



[ (SA001A) ]	
CPL16R8	CPL16R8@PLCC20
[ (SA001A) ]	
CPL16R8L	CPL16R8L@PLCC20
[ (SA001A) ]	

## MICROCONTROLLER

S3F84I8@QFP44 [ (SA769) ]	S3F84I8@SDIP42
[ (SA028) ]	
S3F84I9@QFP44 [ (SA769) ]	S3F84I9@SDIP42
[ (SA028) ]	
S3F84P4	S3F84P4@SOP8 [ (SA602A
+B003) ]	
S3F9444	S3F9444@SOP8 [ (SA602A
+B003) ]	
S3F9454(dip16)	S3F9454
(dip20)	
S3F9454@SOP20 [ (SA404+B005) ]	S3F9488@QFP44
[ (SA245A) ]	
S3F9488@SDIP32 [ (SA653) ]	S3F9488@SDIP42
[ (SA028) ]	
S3F9488@SOP32 [ (SA630) ]	S3F9498@SDIP30
[ (SA653) ]	
S3F9498@SDIP32 [ (SA653) ]	S3F9498@SOP28
[ (SA630) ]	
S3F9498@SOP32 [ (SA630) ]	

## SAMSUNG-CUSTOMER

### E (E) PROM / FRAM / NVRAM

K9F1208U0B(LM)@TSOP48 [ (SA247-B005) ]
K9F1G08U0A(AMLOGIC)@TSOP48 [ (SA247-B005) ]
K9F1G08U0M(DD5)@TSOP48 [ (SA247+B005) ]
K9F2G08U0A(YYD)@TSOP48 [ (SA247-B005) ]
K9F2G08U0A(ZX)@TSOP48 [ (SA247-B005) ]
K9F2G08U0M(YYD)@TSOP48 [ (SA247-B005) ]
K9F4G08U0A(WS)@TSOP48 [ (SA247-B005) ]
K9F4G08U0M(DD5)@TSOP48 [ (SA247+B005) ]
K9F5608U0B(QJ)@TSOP48 [ (SA247-B005) ]

K9F5608U0D(RS)@TSOP48 [(SA247-B005)]  
 K9F8G08U0A(ZX)@TSOP48 [(SA247-B005)]  
 K9G4G08U0A(OMB)@TSOP48 [(SA247-B005)]  
 K9G8G08U0M(DD5)@TSOP48 [(SA247-B005)]  
 K9GAG08U0M(DD)@TSOP48 [(SA247-B005)]  
 K9GAG08U0M(DD5)@TSOP48 [(SA247-B005)]  
 K9GAG08U0M(Malata)@TSOP48 [(SA247-B005)]  
 K9HBG08U1A(CH)@TSOP48 [(SA247-B005)]  
 K9HBG08U1M(CH)@TSOP48 [(SA247-B005)]  
 K9K4G08U0M(YYD)@TSOP48 [(SA247-B005)]  
 K9K8G08U0A(DD5)@TSOP48 [(SA247+B005)]  
 K9K8G08U0A(FX)@TSOP48 [(SA247+B005)]  
 K9WAG08U1M(DD5)@TSOP48 [(SA247+B005)]

## SANYO

### E (E) PROM/FRAM/NVRAM

LE24C041 [(SA654)]	LE24C041@MFP8
LE24C042 [(SA654)]	LE24C042@MFP8
LE24C081 [(SA654)]	LE24C081@MFP8
LE24C082 [(SA654)]	LE24C082@MFP8
LE24C161 [(SA654)]	LE24C161@MFP8
LE24C162 [(SA654)]	LE24C162@MFP8
LE24C322@MFP8 [(SA654)] [(SA698)]	LE24C322@WLP6
LE24L322@MFP8 [(SA654)] [(SA654)]	LE25FU106BMA@MFP8
LE25FU106BTT@MSOP8 [(SA654)] [(SA602A)]	LE25FU406BMA@MFP8
LE25FU406BTT@MSOP8 [(SA654)] [(SA654)]	LE25FV055T@MSOP8
LE25FV101T@MSOP8 [(SA654)] [(SA654)]	LE25FV105T@MSOP8
LE25FV201T@MSOP8 [(SA654)] [(SA654)]	LE25FV401T@MSOP8

LE25FV411T@MSOP8 [(SA654)]	LE25FV451T@VSOP32
[(SA620)]	
LE25FW056FN@VSON8 [(SA683)]	LE25FW056MA@MFP8
[(SA602A)]	
LE25FW106M@SOP8 [(SA602A)]	LE25FW106T@MSOP8
[(SA654)]	
LE25FW1606FN@VSON8 [(SA683)]	LE25FW203ATT@MSOP8
[(SA654)]	
LE25FW206M@SOP8 [(SA602A)]	LE25FW206T@MSOP8
[(SA654)]	
LE25FW406BMA@MFP8 [(SA602A)]	LE25FW406BTT@MSOP8
[(SA654)]	
LE25FW406M@SOP8 [(SA602A)]	LE25FW406T@MSOP8
[(SA654)]	
LE25FW806M@SOP8 [(SA602A)]	LE25FW806T@MSOP8
[(SA654)]	
LE26CW006@WLP6 [(SA698)]	LE28BW168T@TSOP48 [(SA247-
B005)]	
LE28C1001AM@SOP32 [(SA687)]	LE28C1001AT@TSOP32
[(SA410T)]	
LE28C1001ATS@VSOP32 [(SA620)]	LE28C1001DT@TSOP32
[(SA410T)]	
LE28C1001DTS@VSOP32 [(SA620)]	LE28CV1001AT@TSOP32
[(SA410T)]	
LE28CV1001ATS@VSOP32 [(SA620)]	LE28CV1001DT@TSOP32
[(SA410T)]	
LE28CV1001DTS@VSOP32 [(SA620)]	LE28CW1001DT@TSOP32
[(SA410T)]	
LE28CW1001DTS@VSOP32 [(SA620)]	
LE28DW1621T@FBGA63 [(SA642A-B026A-Y096F001)]	
LE28DW1621T@TSOP48 [(SA247-B005)]	
LE28DW8102T@TSOP48 [(SA637)]	
LE28DW8163T@TSOP48 [(SA247-B005)]	
LE28F1101T@TSOP40 [(SA623)]	LE28F1601T@TSOP40
[(SA409T)]	
LE28F2001ATS@TSOP32 [(SA410T)]	LE28F4001ATS@TSOP32
[(SA410T)]	
LE28F4001M@SSOP32 [(SA438T)]	LE28F8001T@TSOP40
[(SA409T)]	
LE28FU4101T@TSOP48 [(SA247-B005)]	
LE28FV1101T@TSOP40 [(SA623)]	LE28FV1601T@TSOP40
[(SA409T)]	
LE28FV2001ATS@TSOP32 [(SA410T)]	LE28FV4001ATS@TSOP32

[ (SA410T) ]  
LE28FV4001CTS@TSOP32 [ (SA410T) ]            LE28FV4001M@SSOP32  
[ (SA438T) ]  
LE28FV4001T@TSOP40 [ (SA409T) ]  
LE28FV4101T@TSOP48 [ (SA247-B005) ]  
LE28FV8001T@TSOP40 [ (SA409T) ]  
LE28FW1633FB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
LE28FW1633FT@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
LE28FW1633TB@TSOP48 [ (SA247-B005) ]  
LE28FW1633TT@TSOP48 [ (SA247-B005) ]  
LE28FW4101T@TSOP48 [ (SA247-B005) ]  
LE28FW8201T@TSOP48 [ (SA247-B005) ]  
LE28FW8203TB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
LE28FW8203TB@TSOP48 [ (SA247-B005) ]  
LE28FW8203TT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
LE28FW8203TT@TSOP48 [ (SA247-B005) ]

## SCENIX

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [ (SA626A) ]            SX20AC/SS@SSOP20  
[ (SA626A) ]  
SX28AC/DP                                    SX28AC/DP/  
G  
SX28AC/SS/G@SSOP28 [ (SA626A) ]            SX28AC/SS@SSOP28  
[ (SA626A) ]  
SX48BD/G@TQFP48 [ (SA248) ]                SX48BD@TQFP48  
[ (SA248) ]

## SEEQ

### E (E) PROM/FRAM/NVRAM

27128  
27256  
2764  
27C256  
2804  
2804A

2816A  
2816AH  
5213  
52B13  
52B13H  
52B23  
52B23H  
52B33  
52B33H  
5516A  
5516AH  
5517A  
5517AH  
DE2817A  
DE2817A@PLCC32 [(SA015A1T)]  
DE2817AH  
DE2817AH@PLCC32 [(SA015A1T)]  
DQ2817A  
DQ2817A@PLCC32 [(SA015A1T)]  
DQ2817AH  
DQ2817AH@PLCC32 [(SA015A1T)]  
DQ2864  
DQ2864@PLCC32 [(SA015A1T)]  
DQ2864H  
DQ2864H@PLCC32 [(SA015A1T)]  
DQ28C256  
DQ28C256@PLCC32 [(SA015A1T)]  
DQ28C64  
DQ28C64@PLCC32 [(SA015A1T)]  
DQ28C64A  
DQ28C64A@PLCC32 [(SA015A1T)]  
DQ28C65  
DQ28C65@PLCC32 [(SA015A1T)]  
DQ52B13  
DQ52B13H  
E28C64  
E28C64@PLCC32 [(SA015A1T)]  
E52B13  
E52B13H  
E52B23  
E52B23H  
E52B33  
E52B33H

M28C64  
 M28C64@PLCC32 [ (SA015A1T) ]  
 M52B13  
 M52B13H  
 M52B23  
 M52B23H  
 M52B33  
 M52B33H  
 PQ2864  
 PQ2864@PLCC32 [ (SA015A1T) ]  
 PQ2864H  
 PQ2864H@PLCC32 [ (SA015A1T) ]  
 PQ28C64  
 PQ28C64@PLCC32 [ (SA015A1T) ]  
 PQ28C65  
 PQ28C65@PLCC32 [ (SA015A1T) ]

## SEIKO

### E (E) PROM / FRAM / NVRAM

S-22H10 [ (SA404) ]	S-22H10@SOP18
S-22H12 [ (SA404) ]	S-22H12@SOP18
S-22S10 [ (SA404) ]	S-22S10@SOP18
S-22S12 [ (SA404) ]	S-22S12@SOP18
S-24C01A(DP) (DPA)	S-24C01A
S-24C01A(FJA)@SOIC8 [ (SA602A) ] (DP)	S-24C01B
S-24C01B(FJ)@SOIC8 [ (SA602A) ] (DP)	S-24C02A
S-24C02A(DPA) [ (SA602A) ]	S-24C02A(FJA)@SOIC8
S-24C02B(DP) [ (SA602A) ]	S-24C02B(FJ)@SOIC8
S-24C04A(DP) (DPA)	S-24C04A
S-24C04A(FJA)@SOIC8 [ (SA602A) ]	S-24C04B

(DP)	
S-24C04B(FJ)@SOIC8 [(SA602A)]	S-24C08A
(DPA)	
S-24C08A(FJA)@SOIC8 [(SA602A)]	S-24C16A
(DPA)	
S-24C16A(FJA)@SOIC8 [(SA602A)]	S-24CS01A
(DP)	
S-24CS01A(FJ)@SOIC8 [(SA602A)]	S-24CS01A(FT)@TSSOP8
[(SA026)]	
S-24CS02A(DP)	S-24CS02A(FJ)@SOIC8
[(SA602A)]	
S-24CS02A(FT)@TSSOP8 [(SA026)]	S-24CS04A
(DP)	
S-24CS04A(FJ)@SOIC8 [(SA602A)]	S-24CS04A(FT)@TSSOP8
[(SA026)]	
S-24CS08A(DP)	S-24CS08A(FJ)@SOIC8
[(SA602A)]	
S-24CS08A(FT)@TSSOP8 [(SA026)]	S-24CS16A
(DP)	
S-24CS16A(FJ)@SOIC8 [(SA602A)]	S-24CS16A(FT)@TSSOP8
[(SA026)]	
S-24CS64A(FJ)@SOIC8 [(SA602A)]	S-24CS64A(FT)@TSSOP8
[(SA026)]	
S-24H45	S-24H45@SOP8
[(SA605A)]	
S-24S45	S-24S45@SOP8
[(SA605A)]	
S-25A010A@SOP8 [(SA602A)]	S-25A020A@SOP8
[(SA602A)]	
S-25A040A@SOP8 [(SA602A)]	S-25A080A@SOP8
[(SA602A)]	
S-25A160A@SOP8 [(SA602A)]	S-25A320A@SOP8
[(SA602A)]	
S-25A640A@SOP8 [(SA602A)]	S-25C010A@SOP8
[(SA602A)]	
S-25C010A@TSSOP8 [(SA026)]	S-25C020A@SOP8
[(SA602A)]	
S-25C020A@TSSOP8 [(SA026)]	S-25C040A@SOP8
[(SA602A)]	
S-25C040A@TSSOP8 [(SA026)]	S-25C080A@SOP8
[(SA602A)]	
S-25C080A@TSSOP8 [(SA026)]	S-25C160A@SOP8
[(SA602A)]	

S-25C160A@TSSOP8 [(SA026)] [(SA602A)]	S-25C320A@SOP8
S-25C320A@TSSOP8 [(SA026)] [(SA602A)]	S-25C640A@SOP8
S-25C640A@TSSOP8 [(SA026)] [(SA630)]	S-2817A@SOP28
S-29130A(DFJA)@SOIC8 [(SA602A)] (DPA)	S-29130A
S-29130A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29131A
S-29131A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29190A
S-29190A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29191A
S-29191A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29194A
S-29194A(FJA)@SOIC8 [(SA602A)] [(SA602A)]	S-29220A(DFJA)@SOIC8
S-29220A(DPA) [(SA602A)]	S-29220A(FJA)@SOIC8
S-29221A(DPA) [(SA602A)]	S-29221A(FJA)@SOIC8
S-29230A(DFJA)@SOIC8 [(SA602A)] (DPA)	S-29230A
S-29230A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29231A
S-29231A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29290A
S-29290A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29291A
S-29291A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29294A
S-29294A(FJA)@SOIC8 [(SA602A)] [(SA602A)]	S-29330A(DFJA)@SOIC8
S-29330A(DPA) [(SA602A)]	S-29330A(FJA)@SOIC8
S-29331A(DPA) [(SA602A)]	S-29331A(FJA)@SOIC8
S-29390A(DPA) [(SA602A)]	S-29390A(FJA)@SOIC8
S-29391A(DPA) [(SA602A)]	S-29391A(FJA)@SOIC8
S-29394A(DPA)	S-29394A(FJA)@SOIC8



[ (SA602A) ]	
S-29430A	S-29430A@SOIC8
[ (SA602A) ]	
S-29530A	S-29530A@SOIC8
[ (SA602A) ]	
S-29630A	S-29630A@SOIC8
[ (SA602A) ]	
S-29L130A(DFE)@SOIC8 [ (SA602A) ]	S-29L130A(FE)@SOIC8
[ (SA602A) ]	
S-29L130A(FS)@SSOP8 [ (SA026) ]	S-29L131A(DFE)@SOIC8
[ (SA602A) ]	
S-29L131A(FS)@SSOP8 [ (SA026) ]	S-29L194A(DFE)@SOIC8
[ (SA602A) ]	
S-29L194A(FS)@TSSOP8 [ (SA026) ]	S-29L220A(DFE)@SOIC8
[ (SA602A) ]	
S-29L220A(FE)@SOIC8 [ (SA602A) ]	S-29L220A(FS)@SSOP8
[ (SA026) ]	
S-29L221A(DFE)@SOIC8 [ (SA602A) ]	S-29L221A(FS)@SSOP8
[ (SA026) ]	
S-29L294A(DFE)@SOIC8 [ (SA602A) ]	S-29L294A(FS)@TSSOP8
[ (SA026) ]	
S-29L330A(DFE)@SOIC8 [ (SA602A) ]	S-29L330A(FE)@SOIC8
[ (SA602A) ]	
S-29L330A(FS)@SSOP8 [ (SA026) ]	S-29L331A(DFE)@SOIC8
[ (SA602A) ]	
S-29L331A(FS)@SSOP8 [ (SA026) ]	S-29L394A(DFE)@SOIC8
[ (SA602A) ]	
S-29L394A(FS)@TSSOP8 [ (SA026) ]	S-29U130A(DFE)@SOIC8
[ (SA602A) ]	
S-29U130A(FS)@SSOP8 [ (SA026) ]	S-29U131A(DFE)@SOIC8
[ (SA602A) ]	
S-29U131A(FS)@SSOP8 [ (SA026) ]	S-29U194A(DFE)@SOIC8
[ (SA602A) ]	
S-29U194A(FS)@TSSOP8 [ (SA026) ]	S-29U220A(DFE)@SOIC8
[ (SA602A) ]	
S-29U220A(FS)@SSOP8 [ (SA026) ]	S-29U221A(DFE)@SOIC8
[ (SA602A) ]	
S-29U221A(FS)@SSOP8 [ (SA026) ]	S-29U294A(DFE)@SOIC8
[ (SA602A) ]	
S-29U294A(FS)@TSSOP8 [ (SA026) ]	S-29U330A(DFE)@SOIC8
[ (SA602A) ]	
S-29U330A(FS)@SSOP8 [ (SA026) ]	S-29U331A(DFE)@SOIC8
[ (SA602A) ]	

S-29U331A(FS)@SSOP8 [(SA026)] [(SA602A)]	S-29U394A(DFE)@SOIC8
S-29U394A(FS)@TSSOP8 [(SA026)] [(SA602A)]	S-29Z330A(DFJA)@SOIC8
S-29Z330A(FS)@SSOP8 [(SA026)] [(SA602A)]	S-29Z430A(DFJA)@SOIC8
S-29Z430A(FS)@SSOP8 [(SA026)] [(SA602A)]	S-93A46A(D0A)@SOIC8
S-93A56A(D0A)@SOIC8 [(SA602A)] [(SA602A)]	S-93A66A(D0A)@SOIC8
S-93A66A(FJ)@SOIC8 [(SA602A)] [(SA602A)]	S-93A86A@SOIC8
S-93C46A(DFJ)@SOIC8 [(SA602A)] (DP)	S-93C46A
S-93C46A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C46A(FT)@TSSOP8
S-93C46B(DP) [(SA602A)]	S-93C46B(FJ)@SOIC8
S-93C46B(FT)@TSSOP8 [(SA026)] [(SA602A)]	S-93C56A(DFJ)@SOIC8
S-93C56A(DP) [(SA602A)]	S-93C56A(FJ)@SOIC8
S-93C56A(FT)@TSSOP8 [(SA026)] (DP)	S-93C56B
S-93C56B(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C56B(FT)@TSSOP8
S-93C66A(DFJ)@SOIC8 [(SA602A)] (DP)	S-93C66A
S-93C66A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C66A(FT)@TSSOP8
S-93C66B(DP) [(SA602A)]	S-93C66B(FJ)@SOIC8
S-93C66B(FT)@TSSOP8 [(SA026)] (DP)	S-93C76A
S-93C76A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C76A(FT)@TSSOP8
S-93C86A(DP) [(SA602A)]	S-93C86A(FJ)@SOIC8
S-93C86A(FT)@TSSOP8 [(SA026)] [(SA602A)]	S-93C86B@SOIC8
S-93C86B@TSSOP8 [(SA026)] [(SA602A)]	S-93L46A(D0I)@SOIC8
S-93L56A(D0I)@SOIC8 [(SA602A)]	S-93L66A(D0I)@SOIC8

[ ( SA602A ) ]  
S-93L76A(D0I)@SOIC8 [ ( SA602A ) ]

## SGS-THOMSON

### E ( E ) PROM / FRAM / NVRAM

ET2716	
ETC2716	
ETC2732	
M24128	
M24128@SOIC8 [ ( SA602A ) ]	
M24164	
M24164@SOIC8 [ ( SA602A ) ]	
M24256	
M24256[3.9]@SOIC8 [ ( SA602A ) ]	M24256[5.5]@SOIC8
[ ( SA605A ) ]	
M24512	M24512@SOIC8
[ ( SA605A ) ]	
M24512@TSOP8 [ ( SA026 ) ]	
M24C04	
M24C04@SOIC8 [ ( SA602A ) ]	
M24C08	
M24C08@SOIC8 [ ( SA602A ) ]	
M24C08W	
M24C08W@SOIC8 [ ( SA602A ) ]	M24C08W@TSOP8
[ ( SA026 ) ]	
M24C64 ( BN )	M24C64 ( DL ) @TSSOP14
[ ( SA026 ) ]	
M24C64 ( DW ) @TSSOP8 [ ( SA602A ) ]	M24C64 ( MN ) @SOIC8
[ ( SA605A ) ]	
M24C64 ( MW ) @SOIC8 [ ( SA602A ) ]	
M27128A	
M2716	
M27256	
M27256A	
M2732A	
M27512	
M2764	
M2764A	
M27C1000	
M27C1000@PLCC32 [ ( SA015A1T ) ]	M27C1000@TSOP32

[ (SA410T) ]	
M27C1001	M27C1001@PLCC32
[ (SA015A1T) ]	
M27C1001@TSOP32 [ (SA410T) ]	
M27C1024	
M27C1024@PLCC44 [ (SA244) ]	
M27C160	
M27C160@PLCC44 [ (SA244) ]	M27C160@PSOP44
[ (SA638) ]	
M27C2001	M27C2001@PLCC32
[ (SA015A1T) ]	
M27C2001@TSOP32 [ (SA410T) ]	
M27C202	
M27C202@PLCC44 [ (SA244) ]	M27C202@TSOP40
[ (SA409T) ]	
M27C256B	M27C256B@PLCC32
[ (SA015A1T) ]	
M27C400	
M27C4001	
M27C4001@PLCC32 [ (SA015A1T) ]	M27C4001@TSOP32
[ (SA410T) ]	
M27C4002	M27C4002@PLCC44
[ (SA244) ]	
M27C405	M27C405@PLCC32
[ (SA015A1T) ]	
M27C405@TSOP32 [ (SA410T) ]	
M27C512	
M27C512@PLCC32 [ (SA015A1T) ]	
M27C516	
M27C516@PLCC44 [ (SA244) ]	
M27C64A	
M27C64A@PLCC32 [ (SA015A1T) ]	
M27C800	
M27C800@PLCC44 [ (SA244) ]	M27C800@PSOP44
[ (SA638) ]	
M27C801	M27C801@PLCC32
[ (SA015A1T) ]	
M27C801@TSOP32 [ (SA410T) ]	
M27HC641	
M27HC641@PLCC28 [ (SA008A) ]	
M27HC642	
M27HC642@PLCC28 [ (SA008A) ]	
M27V101	

M27V101@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M27V101@TSOP32
M27V201 [ (SA015A1T) ]	M27V201@PLCC32
M27V201@TSOP32 [ (SA410T) ]	
M27V401 M27V401@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M27V401@TSOP32
M27V402 [ (SA244) ]	M27V402@PLCC44
M27V402@TSOP40 [ (SA409T) ]	
M27V512 M27V512@PLCC32 [ (SA015A1T) ] [ (SA430T) ]	M27V512@TSOP28
M27V800 [ (SA244) ]	M27V800@PLCC44
M27V801 [ (SA015A1T) ]	M27V801@PLCC32
M27V801@TSOP32 [ (SA410T) ]	
M27W201 M27W201@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M27W201@TSOP32
M28010 [ (SA015A1T) ]	M28010@PLCC32
M28010@TSOP32 [ (SA410T) ] [ (SA015A1T) ]	M28C16@PLCC32
M28C64C [ (SA015A1T) ]	M28C64C@PLCC32
M28C64C@SOIC28 [ (SA404) ] [ (SA430T) ]	M28C64C@TSOP28
M28F101 [ (SA015A1T) ]	M28F101@PLCC32
M28F101@TSOP32 [ (SA410T) ]	
M28F102 M28F102@PLCC44 [ (SA244) ] [ (SA409T) ]	M28F102@TSOP40
M28F201 [ (SA015A1T) ]	M28F201@PLCC32
M28F201@TSOP32 [ (SA410T) ] [ (SA409T) ]	M28F211@TSOP40
M28F220@PSOP44 [ (SA638) ] B005) ]	M28F220@TSOP48 [ (SA247-
M28F256	M28F256@PLCC32

[ (SA015A1T) ]	
M28F256@TSOP32 [ (SA410T) ]	M28F411@TSOP40
[ (SA409T) ]	
M28F512	M28F512@PLCC32
[ (SA015A1T) ]	
M28F512@TSOP32 [ (SA410T) ]	
M29F002B	
M29F002B@PLCC32 [ (SA015A1T) ]	M29F002B@TSOP32
[ (SA410T) ]	
M29F002T	M29F002T@PLCC32
[ (SA015A1T) ]	
M29F002T@TSOP32 [ (SA410T) ]	
M29F040	
M29F040@PLCC32 [ (SA015A1T) ]	M29F040@TSOP32
[ (SA410T) ]	
M29F040B	M29F040B@PLCC32
[ (SA015A1T) ]	
M29F040B@TSOP32 [ (SA410T) ]	M29F100B@PSOP44 [ (SA638-
B006) ]	
M29F100B@TSOP48 [ (SA247-B005) ]	M29F100T@PSOP44 [ (SA638-
B006) ]	
M29F100T@TSOP48 [ (SA247-B005) ]	M29F102B@PLCC44
[ (SA244) ]	
M29F102B@TSOP40 [ (SA623) ]	M29F102BB@PLCC44
[ (SA244) ]	
M29F102BB@TSOP40 [ (SA623) ]	M29F200B@PSOP44 [ (SA638-
B006) ]	
M29F200B@TSOP48 [ (SA247-B005) ]	M29F200T@PSOP44 [ (SA638-
B006) ]	
M29F200T@TSOP48 [ (SA247-B005) ]	M29F400B@PSOP44 [ (SA638-
B006) ]	
M29F400B@TSOP48 [ (SA247-B005) ]	M29F400T@PSOP44 [ (SA638-
B006) ]	
M29F400T@TSOP48 [ (SA247-B005) ]	M29V040@PLCC32
[ (SA015A1T) ]	
M29V040@TSOP32 [ (SA410T) ]	M29W008B@TSOP40
[ (SA409T) ]	
M29W008T@TSOP40 [ (SA409T) ]	M29W040@PLCC32
[ (SA015A1T) ]	
M29W040@TSOP32 [ (SA410T) ]	M29W400B@PSOP44
[ (SA638) ]	
M29W400B@TSOP48 [ (SA247-B005) ]	M29W400T@PLCC44
[ (SA638) ]	

M29W400T@TSOP48 [(SA247-B005)] [(SA015A1T)]	M29W512B@PLCC32
M29W512B@TSOP32 [(SA620)] [(SA638)]	M29W800B@PSOP44
M29W800B@TSOP48 [(SA247-B005)] [(SA638)]	M29W800T@PSOP44
M29W800T@TSOP48 [(SA247-B005)] M48T35	
M48T35@SOIC28 [(SA404)] M48T35Y	
M48T35Y@SOIC28 [(SA404)] M48T59	
M48T59@SOIC28 [(SA404)] M48T59Y	
M48T59Y@SOIC28 [(SA404)] M48Z128	
M48Z128Y M48Z30	
M48Z30Y M48Z32	
M48Z32Y [(SA015A1T)]	M50FW080@PLCC32
M50FW080@TSOP40 [(SA409T)] [(SA620)]	M50FW080@VSOP32
M87C257 [(SA015A1T)]	M87C257@PLCC32
M93C06(08bit) [(SA602A)]	M93C06(08bit)@SOIC8
M93C06(16bit) [(SA602A)]	M93C06(16bit)@SOIC8
M93S46 [(SA602A)]	M93S46@SOIC8
M93S46@TSSOP8 [(SA026)] M95P02	
M95P02@SOIC8 [(SA602A)] M95P04	
M95P04@SOIC8 [(SA602A)] M95P08	
M95P08@SOIC8 [(SA602A)] MK48C02	
MK48C02B MK48C12	
MK48C12B	

MK48T02  
MK48T02B  
MK48T08  
MK48T12  
MK48T12B  
MK48T18  
MK48Z02  
MK48Z02B  
MK48Z08  
MK48Z12  
MK48Z12B  
MK48Z18  
MKI48Z02  
MKI48Z02B  
MKI48Z12  
MKI48Z12B  
MKI48Z18  
ST24C01 ST24C01@SOIC8  
[ (SA602A) ]  
ST24C02A ST24C02A@SOIC8  
[ (SA602A) ]  
ST24C16 ST24C16@SOIC8  
[ (SA602A) ]  
ST24W01 ST24W01@SOIC8  
[ (SA602A) ]  
ST24W02 ST24W02@SOIC8  
[ (SA602A) ]  
ST24W04C ST24W04C@SOIC8  
[ (SA602A) ]  
ST27128A  
ST27256  
ST2764A  
ST27C256  
ST93C06(08bit) ST93C06(08bit)@SOIC8  
[ (SA602A) ]  
ST93C06(16bit) ST93C06(16bit)@SOIC8  
[ (SA602A) ]  
ST93CS46 ST93CS46@SOIC8  
[ (SA602A) ]  
TS27C256  
TS27C64  
TS27C64@PLCC32 [ (SA015A1T) ]  
TS27C64A



TS27C64A@PLCC32 [ (SA015A1T) ]

TS28C16A

TS28C17A

## PLD

GAL16V8

GAL16V8A

GAL20V8

GAL20V8A

## SHARP

### E ( E ) PROM / FRAM / NVRAM

LH28F002SCHN@PSOP44 [ (SA638) ]  
[ (SA409T) ]

LH28F002SCHT@TSOP40

LH28F002SCN@PSOP44 [ (SA638) ]  
[ (SA409T) ]

LH28F002SCT@TSOP40

LH28F004BVE(BT)@TSOP40 [ (SA409T) ]

LH28F004BVE(TT)@TSOP40 [ (SA409T) ]

LH28F004BVHS(BT)@VSOP40 [ (SA623) ]

LH28F004BVHS(TT)@VSOP40 [ (SA623) ]

LH28F004BVT(BT)@TSOP40 [ (SA409T) ]

LH28F004BVT(TT)@TSOP40 [ (SA409T) ]

LH28F004SCHN@PSOP44 [ (SA638) ]  
[ (SA623) ]

LH28F004SCHS@VSOP40

LH28F004SCHT@TSOP40 [ (SA409T) ]  
[ (SA638) ]

LH28F004SCN@PSOP44

LH28F004SCS@VSOP40 [ (SA623) ]  
[ (SA409T) ]

LH28F004SCT@TSOP40

LH28F008BJT(BTLZ1)@TSOP40 [ (SA409T) ]

LH28F008BJT(TB)@TSOP40 [ (SA409T) ]

LH28F008BJT(TT)@TSOP40 [ (SA409T) ]

LH28F008BJT(TTLZ2)@TSOP40 [ (SA409T) ]

LH28F008BVT(BT)@TSOP40 [ (SA409T) ]

LH28F008BVT(TT)@TSOP40 [ (SA409T) ]

LH28F008SAN@PSOP44 [ (SA638) ]  
[ (SA409T) ]

LH28F008SAR@RTSOP40

LH28F008SAT@TSOP40 [ (SA409T) ]

LH28F008SCH(L85)@RTSOP40 [ (SA409T) ]

LH28F008SCH-L@TSOP40 [(SA409T)]            LH28F008SCHN@PSOP44  
[(SA638)]  
LH28F008SCH-V@TSOP40 [(SA409T)]  
LH28F008SCH-ZU-120@TSOP40 [(SA409T)]  
LH28F008SCN@PSOP44 [(SA638)]            LH28F008SCN-L@PSOP44  
[(SA638)]  
LH28F008SCT@TSOP40 [(SA409T)]            LH28F008SCT-L@TSOP40  
[(SA409T)]  
LH28F008SCT-V@TSOP40 [(SA409T)]            LH28F008SCV@TSOP40  
[(SA409T)]  
LH28F016SA@TSOP56 [(SA628-B011)]            LH28F016SC@PSOP44  
[(SA638)]  
LH28F016SCR(L95)@RTSOP40 [(SA409T)]  
LH28F016SCT-L95@TSOP40 [(SA409T)]  
LH28F016SUT@TSOP56 [(SA628-B011)]  
LH28F128BFHBD@CSP72 [(SA642E-B052A-T072F001)]  
LH28F128BFHE@TSOP48 [(SA247-B005)]  
LH28F128BFHT(PBTL70\_75A)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PTTL70\_75A)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PTTLITA)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PWTL80)@TSOP56 [(SA628-B045)]  
LH28F128BFND@PSOP44 [(SA638)]  
LH28F128SPHTD@TSOP56 [(SA628-B018)]  
LH28F160BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BGE(B)@TSOP48 [(SA247-B005)]  
LH28F160BGE(T)@TSOP48 [(SA247-B005)]  
LH28F160BJBB@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJBT@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJD  
LH28F160BJEB@TSOP48 [(SA247-B005)]  
LH28F160BJET@TSOP48 [(SA247-B005)]  
LH28F160BJHBB@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJHBT@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJHEB@TSOP48 [(SA247-B005)]  
LH28F160BJHET@TSOP48 [(SA247-B005)]  
LH28F160BVE(BTL)@TSOP48 [(SA247-B005)]  
LH28F160BVE(TTL)@TSOP48 [(SA247-B005)]  
LH28F160BVEB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BVEB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BVHE(BTL)@TSOP48 [(SA247-B005)]  
LH28F160BVHE(TTL)@TSOP48 [(SA247-B005)]  
LH28F160S3HNS@SSOP56 [(SA629A-B013)]

LH28F160S3HT@TSOP56 [(SA628-B011)]  
LH28F160S3NS@SSOP56 [(SA629A-B013)]  
LH28F160S3T@TSOP56 [(SA628-B011)]  
LH28F160S5HNS@SSOP56 [(SA629A-B013)]  
LH28F160S5HT@TSOP56 [(SA628-B011)]  
LH28F160S5NS@SSOP56 [(SA629A-B013)]  
LH28F160S5T@TSOP56 [(SA628-B011)]  
LH28F160SKT@TSOP56 [(SA628-B011)]  
LH28F320BFE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BFE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BFHB(PB)@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F320BFHB(PT)@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F320BFHE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PBTLZ2)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PTTLZ1)@TSOP48 [(SA247-B005)]  
LH28F320BFHG(PBTLZL)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PBTLZN)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZ3)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZK)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZM)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BJD  
LH28F320BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJN@PSOP44 [(SA638)]  
LH28F320S3HNS@SSOP56 [(SA629A-B013)]  
LH28F320S3HT@TSOP56 [(SA628-B011)]  
LH28F320S3NS@SSOP56 [(SA629A-B013)]  
LH28F320S3T@TSOP56 [(SA628-B011)]  
LH28F320S3TD@TSOP56 [(SA628-B011)]  
LH28F320S5HNS@SSOP56 [(SA629A-B013)]  
LH28F320S5HT@TSOP56 [(SA628-B011)]  
LH28F320S5NS@SSOP56 [(SA629A-B013)]  
LH28F320S5T@TSOP56 [(SA628-B011)]  
LH28F320SKTD@TSOP56 [(SA628-B011)]  
LH28F400BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGE(B)@TSOP48 [(SA247-B005)]  
LH28F400BGE(T)@TSOP48 [(SA247-B005)]

LH28F400BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGHE(B)@TSOP48 [(SA247-B005)]  
LH28F400BGHE(T)@TSOP48 [(SA247-B005)]  
LH28F400BGN(B)@PSOP44 [(SA638)] LH28F400BGN(T)@PSOP44  
[(SA638)]  
LH28F400BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVE(B)@TSOP48 [(SA247-B005)]  
LH28F400BVE(T)@TSOP48 [(SA247-B005)]  
LH28F400BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVHE(B)@TSOP48 [(SA247-B005)]  
LH28F400BVHE(T)@TSOP48 [(SA247-B005)]  
LH28F400BVN(B)@PSOP44 [(SA638)] LH28F400BVN(T)@PSOP44  
[(SA638)]  
LH28F640BFE(PB)@TSOP48 [(SA247-B005)]  
LH28F640BFE(PT)@TSOP48 [(SA247-B005)]  
LH28F640BFHB(PB)@FBGA60 [(SA642B-B029A-Y072F001)]  
LH28F640BFHB(PT)@FBGA60 [(SA642B-B029A-Y072F001)]  
LH28F640BFHE(PB)@TSOP48 [(SA247-B005)]  
LH28F640BFHE(PT)@TSOP48 [(SA247-B005)]  
LH28F640BFHE(PTTLHIA)@TSOP48 [(SA247-B005)]  
LH28F640BFHG@FBGA48 [(SA714D-B026A-W048F001Y)]  
LH28F640BNHG@CSP56 [(SA644A-B025A-Y056F001)]  
LH28F640SPHT@TSOP56 [(SA628-B018)]  
LH28F800BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGE(B)@TSOP48 [(SA247-B005)]  
LH28F800BGE(T)@TSOP48 [(SA247-B005)]  
LH28F800BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGHE(B)@TSOP48 [(SA247-B005)]  
LH28F800BGHE(T)@TSOP48 [(SA247-B005)]  
LH28F800BGN(B)@PSOP44 [(SA638)] LH28F800BGN(T)@PSOP44  
[(SA638)]  
LH28F800BH-B@TSOP48 [(SA247-B005)]  
LH28F800BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PB)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PT)@TSOP48 [(SA247-B005)]  
LH28F800BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]

LH28F800BJHG(PB)(OTP)@CSP48 [(SA634A-B005A-Y048F001)]  
 LH28F800BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BV-B@TSOP48 [(SA247-B005)]  
 LH28F800BVE(B)@TSOP48 [(SA247-B005)]  
 LH28F800BVE(T)@TSOP48 [(SA247-B005)]  
 LH28F800BVE(TV85)@TSOP48 [(SA247-B005)]  
 LH28F800BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVHB@TSOP48 [(SA247-B005)]  
 LH28F800BVHE(B)@TSOP48 [(SA247-B005)]  
 LH28F800BVHE(T)@TSOP48 [(SA247-B005)]  
 LH28F800BVHT@TSOP48 [(SA247-B005)]  
 LH28F800BVN(B)@PSOP44 [(SA638)]      LH28F800BVN(T)@PSOP44  
 [(SA638)]  
 LH28F800BVN(TV85)@PSOP44 [(SA638)]  
 LH28F800BV-T@TSOP48 [(SA247-B005)]  
 LH28F800SG(L100)@TSOP48 [(SA247)]  
 LH28F800SG(L120)@TSOP48 [(SA247)]  
 LH28F800SG(L70)@TSOP48 [(SA247)]      LH28F800SG(L80)@TSOP48  
 [(SA247)]  
 LH28F800SG(L85)@TSOP48 [(SA247)]  
 LH28F800SGH(L100)@TSOP48 [(SA247)]  
 LH28F800SGH(L120)@TSOP48 [(SA247)]  
 LH28F800SGH(L70)@TSOP48 [(SA247)]  
 LH28F800SGH(L80)@TSOP48 [(SA247)]  
 LH28F800SGH(L85)@TSOP48 [(SA247)]  
 LH28F800SUT@TSOP56 [(SA628-B011)]  
 LHF00L03@PLCC32 [(SA015A1T)]      LHF00L04@TSOP40  
 [(SA409T)]  
 LHF00L06@TSOP40 [(SA409T)]      LHF00L07@PLCC32  
 [(SA015A1T)]  
 LHF00L08(LH28F320T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L09(LH28F320B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L10(LH28F320T)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
 LHF00L11(LH28F320B)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
 LHF00L12(LH28F320T)@TSOP48 [(SA247-B005)]  
 LHF00L13(LH28F320B)@TSOP48 [(SA247-B005)]  
 LHF00L14(LH28F320T)@TSOP48 [(SA247-B005)]  
 LHF00L15(LH28F320B)@TSOP48 [(SA247-B005)]  
 LHF00L24(LH28F160T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L25(LH28F160B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L28(LH28F160T)@TSOP48 [(SA247-B005)]

LHF00L29(LH28F160B)@TSOP48 [(SA247-B005)]  
LHF00L30(LH28F160T)@TSOP48 [(SA247-B005)]  
LHF00L31(LH28F160B)@TSOP48 [(SA247-B005)]  
LRS1311@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1311A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1315@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1316@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1317@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1320@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1320A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1329@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1329A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1330A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331B@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331C@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1336@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1339@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1341@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1342@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1348B@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1350@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1356@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1360@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1360C@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1370@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1370B@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1380@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1381@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1382@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383C@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383F@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1384@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1385@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1386@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1387@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1391@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1392A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1393A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1393C@FBGA72 [(SA642E-B023A-T072F001N)]  
LRS1395@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1396@TSOP56 [(SA628-B178)]

LRS13A0@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS13A1@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A2@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A3@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A4@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A5@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A6@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A8@TSOP56 [ ( SA628-B216 ) ]  
LRS1805A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1806A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1806F@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1807A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1808A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1811@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1812@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1816@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1816A@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1822@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1825@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1826@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1826A@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1827@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1828@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1829@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1832@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1844@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1845@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1850@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1851@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1852@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1853@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1871@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1872@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1875@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1876@FBGA72 [ ( SA642B-B023A-Y072F001Y ) ]  
LRS18B0@FBGA72 [ ( SA642E-B141A-T072F001Y ) ]  
LRS18BK@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
LRS18BL@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
LRS18BS@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]

## SHARP-CUSTOMER

## E ( E ) PROM / FRAM / NVRAM

LH28F640BFHE ( PT ) @ TSOP48 [ ( SA247 - B005 ) ]

## SIEMENS

### E ( E ) PROM / FRAM / NVRAM

SDA2526 [ ( SA602A ) ]	SDA2526@SOIC8
SDA2546 [ ( SA602A ) ]	SDA2546@SOIC8
SDA25X26 [ ( SA602A ) ]	SDA25X26@SOIC8
SDA25X46 [ ( SA602A ) ]	SDA25X46@SOIC8
SDE2526 [ ( SA602A ) ]	SDE2526@SOIC8
SDE2546 [ ( SA602A ) ]	SDE2546@SOIC8
SDE25X26 [ ( SA602A ) ]	SDE25X26@SOIC8
SDE25X46 [ ( SA602A ) ]	SDE25X46@SOIC8
SLA24C01 [ ( SA602A ) ]	SLA24C01@SOIC8
SLA24C02 [ ( SA602A ) ]	SLA24C02@SOIC8
SLA24C04 [ ( SA602A ) ]	SLA24C04@SOIC8
SLA24C08 [ ( SA602A ) ]	SLA24C08@SOIC8
SLA24C16 [ ( SA602A ) ]	SLA24C16@SOIC8
SLA24C164 [ ( SA602A ) ]	SLA24C164@SOIC8
SLA24C32 [ ( SA602A ) ]	SLA24C32@SOIC8
SLA24C64 [ ( SA602A ) ]	SLA24C64@SOIC8
SLA25010 [ ( SA602A ) ]	SLA25010@SOIC8



SLA25020 [ ( SA602A ) ]	SLA25020@SOIC8
SLA25040 [ ( SA602A ) ]	SLA25040@SOIC8
SLA25080 [ ( SA602A ) ]	SLA25080@SOIC8
SLA25160 [ ( SA602A ) ]	SLA25160@SOIC8
SLE24C01 [ ( SA602A ) ]	SLE24C01@SOIC8
SLE24C02 [ ( SA602A ) ]	SLE24C02@SOIC8
SLE24C04 [ ( SA602A ) ]	SLE24C04@SOIC8
SLE24C08 [ ( SA602A ) ]	SLE24C08@SOIC8
SLE24C16 [ ( SA602A ) ]	SLE24C16@SOIC8
SLE24C164 [ ( SA602A ) ]	SLE24C164@SOIC8
SLE24C32 [ ( SA602A ) ]	SLE24C32@SOIC8
SLE24C64 [ ( SA602A ) ]	SLE24C64@SOIC8
SLE25010 [ ( SA602A ) ]	SLE25010@SOIC8
SLE25020 [ ( SA602A ) ]	SLE25020@SOIC8
SLE25040 [ ( SA602A ) ]	SLE25040@SOIC8
SLE25080 [ ( SA602A ) ]	SLE25080@SOIC8
SLE25160 [ ( SA602A ) ]	SLE25160@SOIC8

## **SIGNETICS**

### **E ( E ) PROM / FRAM / NVRAM**

27C010 [ ( SA015A1T ) ]	27C010@PLCC32
27C010@TSOP32 [ ( SA410T ) ]	

27C040	27C040@TSOP32
27C040@PLCC32 [(SA015A1T)]	
[(SA410T)]	
27C210	27C210@PLCC44
[(SA244)]	
27C240	27C240@PLCC44
[(SA244)]	
27C256	27C256@PLCC32
[(SA015A1T)]	
27C512	27C512@PLCC32
[(SA015A1T)]	
27C64A	27C64A@PLCC32
[(SA015A1T)]	
27HC641	27HC641@PLCC28
[(SA008A)]	
27HC642	27HC642@PLCC28
[(SA008A)]	
PCA8582A	PCA8582A@SOIC8
[(SA602A)]	
PCA8582B	PCA8582B@SOIC8
[(SA602A)]	
PCA8582C	PCA8582C@SOIC8
[(SA602A)]	
PCA8582D	PCA8582D@SOIC8
[(SA602A)]	
PCA8582E	PCA8582E@SOIC8
[(SA602A)]	
PCD8582A	PCD8582A@SOIC8
[(SA602A)]	
PCD8582B	PCD8582B@SOIC8
[(SA602A)]	
PCD8582C	PCD8582C@SOIC8
[(SA602A)]	
PCD8582D	PCD8582D@SOIC8
[(SA602A)]	
PCD8582E	PCD8582E@SOIC8
[(SA602A)]	
PCF8582A	PCF8582A@SOIC8
[(SA602A)]	
PCF8582B	PCF8582B@SOIC8
[(SA602A)]	
PCF8582C	PCF8582C@SOIC8
[(SA602A)]	

PCF8582D [ (SA602A) ]	PCF8582D@SOIC8
PCF8582E [ (SA602A) ]	PCF8582E@SOIC8
PCF8594 [ (SA602A) ]	PCF8594@SOIC8
PCF8594C [ (SA602A) ]	PCF8594C@SOIC8
PCF8594D [ (SA602A) ]	PCF8594D@SOIC8
PCF8594E [ (SA602A) ]	PCF8594E@SOIC8
PCF8598 [ (SA605A) ]	PCF8598@SOIC8
PCF8598C [ (SA605A) ]	PCF8598C@SOIC8
PCF8598D [ (SA605A) ]	PCF8598D@SOIC8
PCF8598E [ (SA605A) ]	PCF8598E@SOIC8

## MICROCONTROLLER

S87C51 [ (SA244) ]	S87C51@PLCC44
S87C51@TQFP44 [ (SA245A) ]	
S87C51FA S87C51FA@PLCC44 [ (SA244) ]	S87C51FA@TQFP44
[ (SA245A) ]	
S87C51FB [ (SA244) ]	S87C51FB@PLCC44
S87C51FB@TQFP44 [ (SA245A) ]	
S87C51FC S87C51FC@PLCC44 [ (SA244) ]	S87C51FC@TQFP44
[ (SA245A) ]	
S87C52 [ (SA244) ]	S87C52@PLCC44
S87C52@TQFP44 [ (SA245A) ]	
S87C524 S87C524@PLCC44 [ (SA244) ]	S87C524@TQFP44
[ (SA245A) ]	
S87C528	S87C528@PLCC44

[ ( SA244 ) ]	
S87C528@TQFP44 [ ( SA245A ) ]	
S87C54	
S87C54@PLCC44 [ ( SA244 ) ]	S87C54@TQFP44
[ ( SA245A ) ]	
S87C550	
[ ( SA244 ) ]	
S87C552@PLCC68 ( * ) [ ( SA648-B6806 ) ]	
S87C554@PLCC68 ( * ) [ ( SA648-B6806 ) ]	
S87C575	S87C575@PLCC44
[ ( SA244 ) ]	
S87C575@TQFP44 [ ( SA245A ) ]	
S87C576	
S87C576@PLCC44 [ ( SA244 ) ]	S87C576@TQFP44
[ ( SA245A ) ]	
S87C58	S87C58@PLCC44
[ ( SA244 ) ]	
S87C58@TQFP44 [ ( SA245A ) ]	S87C591@PLCC44
[ ( SA244 ) ]	
S87C591@TQFP44 [ ( SA245A ) ]	
S87C652	
S87C652@PLCC44 [ ( SA244 ) ]	S87C652@TQFP44
[ ( SA245A ) ]	
S87C654	S87C654@PLCC44
[ ( SA244 ) ]	
S87C654@TQFP44 [ ( SA245A ) ]	
S87C748	
S87C748@PLCC28 [ ( SA008A ) ]	
S87C749	
S87C749@PLCC28 [ ( SA008A ) ]	
S87C750	
S87C750@PLCC28 [ ( SA008A ) ]	S87C750@SSOP24
[ ( SA626A ) ]	
S87C751	S87C751@PLCC28
[ ( SA008A ) ]	
S87C751@SSOP24 [ ( SA626A ) ]	
S87C752	
S87C752@PLCC28 [ ( SA008A ) ]	S87C752@SSOP28
[ ( SA626A ) ]	
S87C754	S87C754@PLCC28
[ ( SA008A ) ]	
S87C754@SSOP28 [ ( SA626A ) ]	
S87L51FA	

S87L51FA@PLCC44 [(SA244)]  
[(SA245A)]  
S87L51FB  
[(SA244)]  
S87L51FB@TQFP44 [(SA245A)]

S87L51FA@TQFP44  
  
S87L51FB@PLCC44

## Silicon Laboratories

### MICROCONTROLLER

C8051F000@TQFP64(ISP) [(PEP+S616)]

C8051F001@TQFP48 [(SA248)]  
[(SA248)]

C8051F001@TQFP48(ISP)

C8051F002@TQFP32 [(SA663)]  
[(SA663)]

C8051F002@TQFP32(ISP)

C8051F005@TQFP64(ISP) [(PEP+S616)]

C8051F006@TQFP48 [(SA248)]  
[(SA248)]

C8051F006@TQFP48(ISP)

C8051F007@TQFP32 [(SA663)]  
[(SA663)]

C8051F007@TQFP32(ISP)

C8051F010@TQFP64(ISP) [(PEP+S616)]

C8051F011@TQFP48 [(SA248)]  
[(SA248)]

C8051F011@TQFP48(ISP)

C8051F012@TQFP32 [(SA663)]  
[(SA663)]

C8051F012@TQFP32(ISP)

C8051F015@TQFP64(ISP) [(PEP+S616)]

C8051F016@TQFP48 [(SA248)]  
[(SA248)]

C8051F016@TQFP48(ISP)

C8051F017@TQFP32 [(SA663)]  
[(SA663)]

C8051F017@TQFP32(ISP)

C8051F018@TQFP64(ISP) [(PEP+S616)]

C8051F019@TQFP48 [(SA248)]  
[(SA248)]

C8051F019@TQFP48(ISP)

C8051F020@TQFP100(ISP) [ISP-HEADER01]

C8051F021@TQFP64(ISP) [ISP-HEADER01]

C8051F022@TQFP100(ISP) [ISP-HEADER01]

C8051F023@TQFP64(ISP) [ISP-HEADER01]

C8051F040@TQFP100(ISP) [ISP-HEADER01]

C8051F041@TQFP64(ISP) [ISP-HEADER01]

C8051F042@TQFP100(ISP) [ISP-HEADER01]

C8051F043@TQFP64(ISP) [ISP-HEADER01]

C8051F044@TQFP100(ISP) [ISP-HEADER01]

C8051F045@TQFP64(ISP) [ISP-HEADER01]  
C8051F046@TQFP100(ISP) [ISP-HEADER01]  
C8051F047@TQFP64(ISP) [ISP-HEADER01]  
C8051F206@TQFP48 [(SA248)] C8051F220@TQFP48  
[(SA248)]  
C8051F221@TQFP32 [(SA663)] C8051F226@TQFP48  
[(SA248)]  
C8051F230@TQFP48 [(SA248)] C8051F231@TQFP32  
[(SA663)]  
C8051F236@TQFP48 [(SA248)] C8051F300  
[(SA695A)]  
C8051F301 [(SA695A)] C8051F302  
[(SA695A)]  
C8051F303 [(SA695A)] C8051F304  
[(SA695A)]  
C8051F305 [(SA695A)] C8051F310@TQFP32  
[(SA663)]  
C8051F310-GQ@TQFP32 [(SA663)] C8051F311@QFN28 [(SA697-  
B006)]  
C8051F311-GM@QFN28 [(SA697-B006)]  
C8051F312@TQFP32 [(SA663)] C8051F312-GQ@TQFP32  
[(SA663)]  
C8051F313@QFN28 [(SA697-B006)]  
C8051F313-GM@QFN28 [(SA697-B006)]  
C8051F314@TQFP32 [(SA663)] C8051F314-GQ@TQFP32  
[(SA663)]  
C8051F315@QFN28 [(SA697-B006)]  
C8051F315-GM@QFN28 [(SA697-B006)]  
C8051F316-GM@QFN24 [(SA710-B006)]  
C8051F317-GM@QFN24 [(SA710-B006)]  
C8051F320@TQFP32 [(SA663)] C8051F321@QFN28 [(SA697-  
B006)]  
C8051F326@QFN28 [(SA697-B006)]  
C8051F326-GQ@QFN28 [(SA697-B006)]  
C8051F327@QFN28 [(SA697-B006)]  
C8051F327-GQ@QFN28 [(SA697-B006)]  
C8051F330@MLP20 [(SA692)]  
C8051F330D  
C8051F331@MLP20 [(SA692)] C8051F332-GM@MLP20  
[(SA692)]  
C8051F333-GM@MLP20 [(SA692)] C8051F334-GM@MLP20  
[(SA692)]  
C8051F335-GM@MLP20 [(SA692)] C8051F336-GM@QFN20

[ (SA692) ]	
C8051F337-GM@QFN20 [ (SA692) ]	C8051F338-GM@QFN24
[ (SA710) ]	
C8051F339-GM@QFN24 [ (SA710) ]	C8051F340-GQ@TQFP48
[ (SA248) ]	
C8051F341-GQ@TQFP48 [ (SA248) ]	C8051F342-GQ@LQFP32
[ (SA663) ]	
C8051F343-GQ@LQFP32 [ (SA663) ]	C8051F344-GQ@TQFP48
[ (SA248) ]	
C8051F345-GQ@TQFP48 [ (SA248) ]	C8051F346-GQ@LQFP32
[ (SA663) ]	
C8051F347-GQ@LQFP32 [ (SA663) ]	C8051F350-GQ@LQFP32
[ (SA663) ]	
C8051F351-GM@QFN28 [ (SA697-B006) ]	
C8051F352-GQ@LQFP32 [ (SA663) ]	
C8051F353-GM@QFN28 [ (SA697-B006) ]	
C8051F360@QFP48 [ (SA248) ]	C8051F361@QFP32
[ (SA663) ]	
C8051F362@QFN28 [ (SA697) ]	C8051F363@QFP48
[ (SA248) ]	
C8051F364@QFP32 [ (SA663) ]	C8051F365@QFN28
[ (SA697) ]	
C8051F366@QFP32 [ (SA663) ]	C8051F367@QFN28
[ (SA697) ]	
C8051F368@QFP32 [ (SA663) ]	C8051F369@QFN28
[ (SA697) ]	
C8051F410-GQ@LQFP32 [ (SA663) ]	C8051F411-GM@QFN28
[ (SA697) ]	
C8051F412-GQ@LQFP32 [ (SA663) ]	C8051F413-GM@QFN28
[ (SA697) ]	
C8051F520-IM@QFN10 [ (SA695A) ]	C8051F521-IM@QFN10
[ (SA695A) ]	
C8051F523-IM@QFN10 [ (SA695A) ]	C8051F524-IM@QFN10
[ (SA695A) ]	
C8051F526-IM@QFN10 [ (SA695A) ]	C8051F527-IM@QFN10
[ (SA695A) ]	
C8051F530-IM@QFN20 [ (SA692) ]	C8051F530-IT@TSSOP20
[ (SA026) ]	
C8051F531-IM@QFN20 [ (SA692) ]	C8051F531-IT@TSSOP20
[ (SA026) ]	
C8051F533-IM@QFN20 [ (SA692) ]	C8051F533-IT@TSSOP20
[ (SA026) ]	
C8051F534-IM@QFN20 [ (SA692) ]	C8051F534-IT@TSSOP20

[ (SA026) ]	
C8051F536-IM@QFN20 [ (SA692) ]	C8051F536-IT@TSSOP20
[ (SA026) ]	
C8051F537-IM@QFN20 [ (SA692) ]	C8051F537-IT@TSSOP20
[ (SA026) ]	
C8051F610-GQ@QFP32 [ (SA663) ]	
C8051F611-GM@QFN28 [ (SA697-B006) ]	
C8051F612-GQ@QFP32 [ (SA663) ]	
C8051F613-GM@QFN28 [ (SA697-B006) ]	
C8051F614-GQ@QFP32 [ (SA663) ]	
C8051F615-GM@QFN28 [ (SA697-B006) ]	
C8051F616-GM@QFN24 [ (SA710-B006) ]	
C8051F617-GM@QFN24 [ (SA710-B006) ]	
C8051T600@QFN11 [ (SA695A) ]	C8051T600@SOIC14
[ (SA602) ]	
C8051T601@QFN11 [ (SA695A) ]	C8051T601@SOIC14
[ (SA602) ]	
C8051T602@SOIC14 [ (SA602) ]	C8051T603@SOIC14
[ (SA602) ]	
C8051T604@QFN11 [ (SA695A) ]	C8051T604@SOIC14
[ (SA602) ]	
C8051T605@QFN11 [ (SA695A) ]	C8051T605@SOIC14
[ (SA602) ]	
SI8250@LQFP32 [ (SA663) ]	SI8250@QFN28
[ (SA697) ]	
SI8251@LQFP32 [ (SA663) ]	SI8251@QFN28
[ (SA697) ]	
SI8252@LQFP32 [ (SA663) ]	SI8252@QFN28
[ (SA697) ]	

## SILICON7

### E ( E ) PROM / FRAM / NVRAM

SV4E1602UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1602UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1604UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1604UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1608UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1608UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E3204UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E3204UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]



SV4E3208UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4E3208UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4E3216UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4E3216UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4F1602UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1602UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1604UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1604UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1608UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1608UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3204UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3204UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3208UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3208UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3216UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3216UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV5C2832UCR@FBGA72 [ (SA642E-B052A-T072F001) ]  
SV5C3238UBA(NO EFP)@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UTA(NO EFP)@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C6416UBB(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBB@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBR@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTB(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTB@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTR@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6432UBR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6432UTR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5D2832UCA@FBGA88 [ (SA642A-B081A-Y096F001) ]  
SV6C2832UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C2832UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6416UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6416UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6432UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6432UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6D2832UBA@FBGA88 [ (SA642A-B124A-Y096F001Y) ]  
SV6D2832UTA@FBGA88 [ (SA642A-B124A-Y096F001Y) ]  
SV7C1602UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C1602UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C1604UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]

SV7C1604UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7C1608UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7C1608UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7C3204UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7C3204UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7C3208UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7C3208UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7C3216UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7C3216UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
 SV7E1602UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1602UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1604UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1604UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1608UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1608UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3204UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3204UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3208UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3208UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3216UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3216UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]

## SIMTEK

### E (E) PROM / FRAM / NVRAM

STK10C48  
 STK10C48@SOIC28(300 mil) [(SA404)]  
 STK10C48@SOIC28(350 mil) [(SA630)]  
 STK10C68 STK10C68@PLCC28  
 [(SA008A)]  
 STK10C68@SOIC28(350 mil) [(SA630)]  
 STK11C48  
 STK11C48@SOIC28(300 mil) [(SA404)]  
 STK11C48@SOIC28(350 mil) [(SA630)]  
 STK11C68 STK11C68@PLCC28  
 [(SA008A)]  
 STK11C68@SOIC28(350 mil) [(SA630)]  
 STK11C88 STK11C88  
 (3V)  
 STK11C88(3V)@SOIC28(300 mil) [(SA404)]  
 STK11C88(3V)@SOIC28(350 mil) [(SA630)]

STK11C88@SOIC28(300 mil) [(SA404)]  
STK11C88@SOIC28(350 mil) [(SA630)]  
STK12C68  
[(SA008A)]  
STK12C68@SOIC28(350 mil) [(SA630)]  
STK14C88  
(3V)  
STK14C88(3V)@PLCC32 [(SA015A1T)]  
STK14C88(3V)@SOIC32(300 mil) [(SA715)]  
STK14C88(3V)@SOIC32(350 mil) [(SA630)]  
STK14C88@PLCC32 [(SA015A1T)]  
STK14C88@SOIC32(300 mil) [(SA715)]  
STK14C88@SOIC32(350 mil) [(SA630)]  
STK14CA8  
[(SA715)]  
STK14CA8@SSOP48 [(SA669)]  
[(SA715)]  
STK14D88@SSOP48 [(SA669)]  
STK15C68  
STK15C68@SOIC28(350 mil) [(SA630)]  
STK15C88  
STK15C88@SOIC28(300 mil) [(SA404)]  
STK15C88@SOIC28(350 mil) [(SA630)]  
STK16C68  
STK16C88  
STK16C88(3V)  
STK16CA8  
STK20C04  
STK22C48  
STK22C48@SOIC28(300 mil) [(SA404)]  
STK22C48@SOIC28(350 mil) [(SA630)]  
STK25C48

STK12C68@PLCC28

STK14C88

STK14CA8@SOIC32

STK14D88@SOIC32

## SMOS

### E (E) PROM / FRAM / NVRAM

SPM27128  
SPM27128C  
SPM27C256  
SPM27C64  
SPM27C64H

# SONIX

## MICROCONTROLLER

SN8P1504 [ (SA404) ]	SN8P1504@SOP18
SN8P1504@SOP28 [ (SA404) ]	
SN8P1506	
SN8P1507@TQFP44 [ (SA245A) ]	
SN8P1602	
SN8P1602@SOP18 [ (SA404) ]	SN8P1602@SSOP20 [ (SA674- B005) ]
SN8P1603 [ (SA404) ]	SN8P1603@SOP18
SN8P1603@SSOP20 [ (SA674-B005) ]	
SN8P1604	
SN8P1604@SOP28 [ (SA404) ]	
SN8P1702	
SN8P1702@SOP18 [ (SA404) ]	SN8P1702@SSOP20 [ (SA674- B005) ]
SN8P1704A [ (SA404) ]	SN8P1704A@SOP28
SN8P1704B [ (SA404) ]	SN8P1704B@SOP28
SN8P1706A	
SN8P1706B	
SN8P1707A [ (SA245A) ]	SN8P1707A@TQFP44
SN8P1707B@TQFP44 [ (SA245A) ]	
SN8P1708A	
SN8P1708A@SSOP48 [ (SA669) ]	
SN8P1708B	
SN8P1708B@SSOP48 [ (SA669) ]	
SN8P1714	
SN8P1714@SOP18 [ (SA404) ]	SN8P1714@SOP28
[ (SA404) ]	
SN8P1716 [ (SA245A) ]	SN8P1717@TQFP44
SN8P2501AP [ (SA602) ]	SN8P2501AS@SOP14
SN8P2501AX@TSSOP16 [ (SA026) ]	

SN8P2501BP	
SN8P2501BS@SOP14 [(SA602)]	SN8P2501BX@TSSOP16
[(SA026)]	
SN8P2502AP	SN8P2502AS@SOP14
[(SA602)]	
SN8P2502AX@TSSOP16 [(SA026)]	
SN8P2502BP	
SN8P2502BS@SOP14 [(SA602)]	SN8P2502BX@TSSOP16
[(SA026)]	
SN8P2504AP	SN8P2504AS@SOP14
[(SA602)]	
SN8P2504AX@TSSOP16 [(SA026)]	
SN8P2504BP	
SN8P2504BS@SOP14 [(SA602)]	SN8P2504BX@TSSOP16
[(SA026)]	
SN8P2602AP	SN8P2602AS@SOP18
[(SA023A)]	
SN8P2602AX@SSOP20 [(SA674)]	
SN8P2602BP	
SN8P2602BS@SOP18 [(SA023A)]	SN8P2602BX@SSOP20
[(SA674)]	
SN8P2603AP	SN8P2603AS@SOP18
[(SA023A)]	
SN8P2603AX@SSOP20 [(SA674)]	
SN8P2603BP	
SN8P2603BS@SOP18 [(SA023A)]	SN8P2603BX@SSOP20
[(SA674)]	
SN8P26042AP	SN8P26042AS@SOP20
[(SA023A)]	
SN8P26042AX@SSOP20 [(SA674)]	
SN8P26042BP	
SN8P26042BS@SOP20 [(SA023A)]	SN8P26042BX@SSOP20
[(SA674)]	
SN8P26042P	SN8P26042S@SOP20
[(SA023A)]	
SN8P26042X@SSOP20 [(SA674)]	
SN8P2604AK	
SN8P2604AS@SOP28 [(SA404)]	SN8P2604AX@SSOP28
[(SA626A)]	
SN8P2604BK	SN8P2604BS@SOP28
[(SA404)]	
SN8P2604BX@SSOP28 [(SA626A)]	
SN8P2604K	

SN8P2604S@SOP28 [(SA404)]	SN8P2604X@SSOP28
[(SA626A)]	
SN8P2606P	
SN8P2608P	
SN8P2608X@SSOP48 [(SA669)]	
SN8P2622P	
SN8P2622S@SOP18 [(SA023A)]	SN8P2622X@SSOP20
[(SA674)]	
SN8P2624K	SN8P2624S@SOP28
[(SA404)]	
SN8P2624X@SSOP28 [(SA626A)]	SN8P2704AK@SDIP28
[(SA653)]	
SN8P2704AP	SN8P2704AS@SOP28
[(SA723)]	
SN8P2705AP	SN8P2705AS@SOP32
[(SA687)]	
SN8P2706AP	SN8P2707AQ@QFP44
[(SA245A)]	
SN8P2708AP	SN8P2708AQ@LQFP48
[(SA248)]	
SN8P2708AX@TSOP48 [(SA669)]	
SN8P2722P	
SN8P2722S@SOP20 [(SA023A)]	SN8P2722X@SSOP20
[(SA674)]	

## SONY

### E (E) PROM / FRAM / NVRAM

CXK1011M@SOIC8 [(SA602A)]  
CXK1011P  
CXK1012P  
CXK1013P  
CXK1023P  
CXK27C4001

### DRAM & SRAM

CXK581000	CXK581000@SOIC32
[(SA630)]	

## SPACE ELECTRONICS[SEI]

### E ( E ) PROM / FRAM / NVRAM

28C010 [ ( SA015A1T ) ]	28C010@PLCC32
28C010@TSOP32 [ ( SA410T ) ]	
28C010T 28C010T@PLCC32 [ ( SA015A1T ) ]	28C010T@TSOP32
[ ( SA410T ) ]	
28C011 [ ( SA015A1T ) ]	28C011@PLCC32
28C011@TSOP32 [ ( SA410T ) ]	
28C011T 28C011T@PLCC32 [ ( SA015A1T ) ]	28C011T@TSOP32
[ ( SA410T ) ]	

## SPANSION

### E ( E ) PROM / FRAM / NVRAM

AM29BL162CB@SSOP56 [ ( SA629A-B022 ) ]  
 AM29BL802CB@SSOP56 [ ( SA629A-B022 ) ]  
 AM29DL161DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL161DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL161DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL161DB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL161DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL161DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL161DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL161DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL161DT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL161DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL162CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL162CB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL162CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL162CT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL162DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL162DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL162DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]

AM29DL162DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL320GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL320GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL320GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL320GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL320GT@TSOP48 [ ( SA247-B005 ) ]



AM29DL321CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL322GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL322GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL322GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL322GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL323GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL323GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL323GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL323GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]

AM29DL324GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL324GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL324GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL324GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL324GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BT@PLCC44 [ ( SA638-B006 ) ]  
AM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL640D@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL640G@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL640G@TSOP48 [ ( SA247-B005 ) ]  
AM29DL642G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL800B@PSOP44 [ ( SA638-B006 ) ]      AM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29DL800BB@PSOP44 [ ( SA638 ) ]  
AM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29DL800BT@PSOP44 [ ( SA638 ) ]  
AM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800T@PSOP44 [ ( SA638-B006 ) ]      AM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
AM29DS163CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DS163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DS163DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DS163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DS163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DS163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DS323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DS323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DS323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DS323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29F002B      AM29F002B@PLCC32  
[ ( SA015A1T ) ]  
AM29F002B@TSOP32 [ ( SA410T ) ]  
AM29F002BB  
AM29F002BB@PLCC32 [ ( SA015A1T ) ]      AM29F002BB@TSOP32  
[ ( SA410T ) ]

AM29F002BT [ (SA015A1T) ]	AM29F002BT@PLCC32
AM29F002BT@TSOP32 [ (SA410T) ]	
AM29F002NB AM29F002NB@PLCC32 [ (SA015A1T) ]	AM29F002NB@TSOP32
[ (SA410T) ]	
AM29F002NBB [ (SA015A1T) ]	AM29F002NBB@PLCC32
AM29F002NBB@TSOP32 [ (SA410T) ]	
AM29F002NBT AM29F002NBT@PLCC32 [ (SA015A1T) ]	AM29F002NBT@TSOP32
[ (SA410T) ]	
AM29F002NT [ (SA015A1T) ]	AM29F002NT@PLCC32
AM29F002NT@TSOP32 [ (SA410T) ]	
AM29F002T AM29F002T@PLCC32 [ (SA015A1T) ]	AM29F002T@TSOP32
[ (SA410T) ]	
AM29F004BB@PLCC32 [ (SA015A1T) ]	AM29F004BB@TSOP32
[ (SA410T) ]	
AM29F004BT@PLCC32 [ (SA015A1T) ]	AM29F004BT@TSOP32
[ (SA410T) ]	
AM29F010 [ (SA015A1T) ]	AM29F010@PLCC32
AM29F010@TSOP32 [ (SA410T) ]	
AM29F010A AM29F010A@PLCC32 [ (SA015A1T) ]	AM29F010A@TSOP32
[ (SA410T) ]	
AM29F010B [ (SA015A1T) ]	AM29F010B@PLCC32
AM29F010B@TSOP32 [ (SA410T) ]	AM29F016@PSOP44
[ (SA638) ]	
AM29F016@TSOP40 [ (SA409T) ]	AM29F016@TSOP48 [ (SA247-
B005) ]	
AM29F016B@PSOP44 [ (SA638) ]	AM29F016B@TSOP40
[ (SA409T) ]	
AM29F016B@TSOP48 [ (SA247-B005) ]	
AM29F016D(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016D@PSOP44 [ (SA638) ]	AM29F016D@TSOP40
[ (SA409T) ]	
AM29F016D@TSOP48 [ (SA247-B005) ]	AM29F017B@TSOP48 [ (SA247-
B005) ]	
AM29F017D@TSOP40 [ (SA409T) ]	AM29F017D@TSOP48 [ (SA247-

B005 ) ]	
AM29F032B@PSOP44 [ ( SA638 ) ]	AM29F032B@TSOP40
[ ( SA409T ) ]	
AM29F040	AM29F040@PLCC32
[ ( SA015A1T ) ]	
AM29F040@TSOP32 [ ( SA410T ) ]	
AM29F040A	
AM29F040A@PLCC32 [ ( SA015A1T ) ]	AM29F040A@TSOP32
[ ( SA410T ) ]	
AM29F040B	
AM29F040B(Reverse)@TSOP32 [ ( SA410T ) ]	
AM29F040B@PLCC32 [ ( SA015A1T ) ]	AM29F040B@TSOP32
[ ( SA410T ) ]	
AM29F080@PSOP44 [ ( SA638 ) ]	AM29F080@TSOP40
[ ( SA409T ) ]	
AM29F080B@PSOP44 [ ( SA638 ) ]	AM29F080B@TSOP40
[ ( SA409T ) ]	
AM29F100BE@PSOP44 [ ( SA638-B006 ) ]	AM29F100BE@TSOP48 [ ( SA247-
B005 ) ]	
AM29F100BS@PSOP44 [ ( SA638-B006 ) ]	AM29F100BS@TSOP48 [ ( SA247-
B005 ) ]	
AM29F100TE@PSOP44 [ ( SA638-B006 ) ]	AM29F100TE@TSOP48 [ ( SA247-
B005 ) ]	
AM29F100TS@PSOP44 [ ( SA638-B006 ) ]	AM29F100TS@TSOP48 [ ( SA247-
B005 ) ]	
AM29F160DB@TSOP48 [ ( SA247-B005 ) ]	AM29F160DT@TSOP48 [ ( SA247-
B005 ) ]	
AM29F200AB@PSOP44 [ ( SA638-B006 ) ]	AM29F200AB@TSOP48 [ ( SA247-
B005 ) ]	
AM29F200AT@PSOP44 [ ( SA638-B006 ) ]	AM29F200AT@TSOP48 [ ( SA247-
B005 ) ]	
AM29F200BB@PSOP44 [ ( SA638-B006 ) ]	AM29F200BB@TSOP48 [ ( SA247-
B005 ) ]	
AM29F200BE@PSOP44 [ ( SA638-B006 ) ]	AM29F200BE@TSOP48 [ ( SA247-
B005 ) ]	
AM29F200BS@PSOP44 [ ( SA638-B006 ) ]	AM29F200BS@TSOP48 [ ( SA247-
B005 ) ]	
AM29F200BT@PSOP44 [ ( SA638-B006 ) ]	AM29F200BT@TSOP48 [ ( SA247-
B005 ) ]	
AM29F200TE@PSOP44 [ ( SA638-B006 ) ]	AM29F200TE@TSOP48 [ ( SA247-
B005 ) ]	
AM29F200TS@PSOP44 [ ( SA638-B006 ) ]	AM29F200TS@TSOP48 [ ( SA247-
B005 ) ]	

AM29F400AB@PSOP44 [ ( SA638-B006 ) ]	AM29F400AB@TSOP48 [ ( SA247-B005 ) ]
AM29F400AT@PSOP44 [ ( SA638-B006 ) ]	AM29F400AT@TSOP48 [ ( SA247-B005 ) ]
AM29F400BB@PSOP44 [ ( SA638-B006 ) ]	AM29F400BB@TSOP48 [ ( SA247-B005 ) ]
AM29F400BBE@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BBE@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BBF@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BBF@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BBS@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BBS@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BE@PSOP44 [ ( SA638-B006 ) ]	AM29F400BE@TSOP48 [ ( SA247-B005 ) ]
AM29F400BF@PSOP44 [ ( SA638-B006 ) ]	AM29F400BF@TSOP48 [ ( SA247-B005 ) ]
AM29F400BS@PSOP44 [ ( SA638-B006 ) ]	AM29F400BS@TSOP48 [ ( SA247-B005 ) ]
AM29F400BT@PSOP44 [ ( SA638-B006 ) ]	AM29F400BT@TSOP48 [ ( SA247-B005 ) ]
AM29F400BTE@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BTE@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BTF@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BTF@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BTS@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BTS@TSOP48 [ ( SA247-B005 ) ]	
AM29F800B@PSOP44 [ ( SA638-B006 ) ]	AM29F800B@TSOP48 [ ( SA247-B005 ) ]
AM29F800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]	
AM29F800BB@PSOP44 [ ( SA638-B006 ) ]	AM29F800BB@TSOP48 [ ( SA247-B005 ) ]
AM29F800BBF@PSOP44 [ ( SA638-B006 ) ]	
AM29F800BBF@TSOP48 [ ( SA247-B005 ) ]	
AM29F800BF@PSOP44 [ ( SA638-B006 ) ]	AM29F800BF@TSOP48 [ ( SA247-B005 ) ]
AM29F800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]	
AM29F800BT@PSOP44 [ ( SA638-B006 ) ]	AM29F800BT@TSOP48 [ ( SA247-B005 ) ]
AM29F800BTF@PSOP44 [ ( SA638-B006 ) ]	
AM29F800BTF@TSOP48 [ ( SA247-B005 ) ]	
AM29F800T@PSOP44 [ ( SA638-B006 ) ]	AM29F800T@TSOP48 [ ( SA247-B005 ) ]
AM29F800TB@PSOP44 [ ( SA638-B006 ) ]	AM29F800TB@TSOP48 [ ( SA247-B005 ) ]

B005) ]  
 AM29F800TF@PSOP44 [ (SA638-B006) ]      AM29F800TF@TSOP48 [ (SA247-B005) ]  
 AM29LL800B@TSOP48 [ (SA247-B005) ]  
 AM29LL800BB@TSOP48 [ (SA247-B005) ]  
 AM29LL800BT@TSOP48 [ (SA247-B005) ]  
 AM29LL800T@TSOP48 [ (SA247-B005) ]      AM29LV001BB@PLCC32  
 [ (SA015A1T) ]  
 AM29LV001BB@TSOP32 [ (SA410T) ]      AM29LV001BT@PLCC32  
 [ (SA015A1T) ]  
 AM29LV001BT@TSOP32 [ (SA410T) ]      AM29LV002@TSOP40  
 [ (SA409T) ]  
 AM29LV002B@TSOP40 [ (SA409T) ]      AM29LV002BB@TSOP40  
 [ (SA409T) ]  
 AM29LV002BT@TSOP40 [ (SA409T) ]      AM29LV004B@PSOP44  
 [ (SA638) ]  
 AM29LV004B@TSOP40 [ (SA409T) ]      AM29LV004BB@TSOP40  
 [ (SA409T) ]  
 AM29LV004BT@TSOP40 [ (SA409T) ]      AM29LV004T@PSOP44  
 [ (SA638) ]  
 AM29LV004T@TSOP40 [ (SA409T) ]      AM29LV008B@PSOP44  
 [ (SA638) ]  
 AM29LV008B@TSOP40 [ (SA409T) ]      AM29LV008BB@TSOP40  
 [ (SA409T) ]  
 AM29LV008BT@TSOP40 [ (SA409T) ]      AM29LV008T@PSOP44  
 [ (SA638) ]  
 AM29LV008T@TSOP40 [ (SA409T) ]      AM29LV010B@PLCC32  
 [ (SA015A1T) ]  
 AM29LV010B@TSOP32 [ (SA410T) ]      AM29LV017B@TSOP40  
 [ (SA409T) ]  
 AM29LV017D@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29LV017D@TSOP40 [ (SA409T) ]      AM29LV020B@PLCC32  
 [ (SA015A1T) ]  
 AM29LV020B@TSOP32 [ (SA410T) ]  
 AM29LV033C@FBGA63 [ (SA642A-B026A-Y096N001) ]  
 AM29LV033C@TSOP40 [ (SA409T) ]  
 AM29LV033MU@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29LV033MU@TSOP40 [ (SA409T) ]      AM29LV040B@PLCC32  
 [ (SA015A1T) ]  
 AM29LV040B@TSOP32 [ (SA410T) ]      AM29LV040E@PLCC32  
 [ (SA015A1T) ]  
 AM29LV040E@TSOP32 [ (SA410T) ]      AM29LV040J@PLCC32  
 [ (SA015A1T) ]

AM29LV040J@TSOP32 [ ( SA410T ) ]  
AM29LV065D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV065D@TSOP48 [ ( SA247-B005 ) ]  
AM29LV065MU@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV065MU@TSOP48 [ ( SA247-B005 ) ]  
AM29LV080@TSOP40 [ ( SA409T ) ] AM29LV081@TSOP40  
[ ( SA409T ) ]  
AM29LV081B@TSOP40 [ ( SA409T ) ] AM29LV116BB@TSOP40  
[ ( SA409T ) ]  
AM29LV116BT@TSOP40 [ ( SA409T ) ] AM29LV116DB@TSOP40  
[ ( SA409T ) ]  
AM29LV116DT@TSOP40 [ ( SA409T ) ]  
AM29LV128MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV128MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV128ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV128ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV160BB@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160BB@PSOP44 [ ( SA638 ) ]  
AM29LV160BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160BT@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160BT@PSOP44 [ ( SA638 ) ]  
AM29LV160BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DB(REVERSE)@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DB@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160DB@PSOP44 [ ( SA638 ) ]  
AM29LV160DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DT(REVERSE)@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DT@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160DT@PSOP44 [ ( SA638 ) ]  
AM29LV160DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160MB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV160MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV160MB@PSOP44 [ ( SA638 ) ]  
AM29LV160MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160MT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV160MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV160MT@PSOP44 [ ( SA638 ) ]  
AM29LV160MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200B@PSOP44 [ ( SA638-B006 ) ] AM29LV200B@TSOP48 [ ( SA247-  
B005 ) ]  
AM29LV200BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BE@PSOP44 [ ( SA638-B006 ) ]

AM29LV200BE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200T@PSOP44 [ ( SA638-B006 ) ]      AM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV256MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV256ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MB@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29LV320MB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MH@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320ML@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320MT@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29LV320MT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400B@PSOP44 [ ( SA638-B006 ) ]      AM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BT@TSOP48 [ ( SA247-B005 ) ]



AM29LV400T@PSOP44 [ ( SA638-B006 ) ]      AM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640DH@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DL@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640DU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640GU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640GU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640MB@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MH@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640ML@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640MT@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MU@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV641DH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641MH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641ML@TSOP48 [ ( SA247-B005 ) ]  
AM29LV642G@FBGA64 [ ( SA655A-B038A-T064N001 ) ]  
AM29LV652D@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV800B@PSOP44 [ ( SA638-B006 ) ]      AM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800DB(WB)@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800DB(WC)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29LV800DB@PSOP44 [ ( SA638 ) ]

AM29LV800DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800DT(WB)@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800DT(WC)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29LV800DT@PSOP44 [ ( SA638 ) ]  
AM29LV800DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800T@PSOP44 [ ( SA638-B006 ) ]      AM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
AM29PDS322DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29PDS322DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29PL160CB@PSOP44 [ ( SA638-B006 ) ]  
AM29PL160CB@TSOP48 [ ( SA247-B005 ) ]  
AM29PL160CT@PSOP44 [ ( SA638-B006 ) ]  
AM29PL160CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL160CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29SL160CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL160CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29SL160CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL400CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL400CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DBUF@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DBVG@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DBVU@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29SL800DBWA@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29SL800DBWC@FBGA48 [ ( SA642R-B026A-W080F001N ) ]  
AM29SL800DT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DTUF@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DTVG@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DTVU@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29SL800DTWA@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29SL800DTWC@FBGA48 [ ( SA642R-B026A-W080F001N ) ]  
DS42514 (AM29DL163DB)@FBGA69 [ ( SA642B-B032A-Y072F001 ) ]  
DS42515 (AM29DL164)@FBGA69 [ ( SA642B-B032A-Y072F001 ) ]  
DS42516 (AM29DL324)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
DS42546 (AM29DL163)@FBGA69 [ ( SA642B-B032A-Y072F001 ) ]  
DS42553 (AM29DL323)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
DS42585 (AM29DL323D)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
DS42587 (AM29DL324D)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
DS42629 (AM29DL640G)@VFBGA48 [ ( SA634A-B005A-Y048F001 ) ]

DS42677(AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]  
DS42678(AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]  
DS42689(AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42690(AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42695(AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42696(AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42701(AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]  
DS42725(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
DS42772A(AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]  
M420000070(AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000071(AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000072(AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000073(AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000074(AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000075(AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000076(AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000077(AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]  
M490000030(AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M490000031(AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M4900000K(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M4900000L(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182EM@FBGA56 [(SA642C-B032A-Y056F001)]

MB84VD21183DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD22180FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22180FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22181A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22181EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22182A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22182EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22182EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22183EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22184EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22190FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22190FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22191A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22191EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22192A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22192EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22192EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

MB84VD22193A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22193EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22194EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22280FE@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22282EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22283EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22284EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22290FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22292EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22293EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22294EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22386EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22387EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22388EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22396EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22397EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22398EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23180FM@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD23280EA@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280EE@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280FA@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381EJ@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381HJ@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23481FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VF5F5FF4J2@BGA107 [ ( SA642D-B062A-Y088F001 ) ]  
MB84VP23481FK@FBGA65 [ ( SA642JJ-B032A-W064F001Y ) ]  
MB84VP24481HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MB84VP24491HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MBM29DL161BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL161BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL161TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BE@TSOP48 [ ( SA247-B005 ) ]

MBM29DL162TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL321TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]

MBM29DL323BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400BC@PSOP44 [ ( SA638 ) ]  
MBM29DL400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400TC@PSOP44 [ ( SA638 ) ]  
MBM29DL400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL640E@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29DL640E@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL64DF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
MBM29DL64DF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800BB@TSOP48 [ ( SA247-B005 ) ]

MBM29DL800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800TA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29DS163BE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
MBM29DS163BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DS163TE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
MBM29DS163TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29F001B [ ( SA015A1T ) ] MBM29F001B@PLCC32  
MBM29F001B@TSOP32 [ ( SA410T ) ]  
MBM29F001T [ ( SA015A1T ) ] MBM29F001T@TSOP32  
MBM29F001T@PLCC32 [ ( SA410T ) ]  
MBM29F002B [ ( SA015A1T ) ] MBM29F002B@PLCC32  
MBM29F002B@TSOP32 [ ( SA410T ) ]  
MBM29F002NB [ ( SA015A1T ) ] MBM29F002NB@TSOP32  
MBM29F002NB@PLCC32 [ ( SA410T ) ]  
MBM29F002NT [ ( SA015A1T ) ] MBM29F002NT@PLCC32  
MBM29F002NT@TSOP32 [ ( SA410T ) ]  
MBM29F002T [ ( SA015A1T ) ] MBM29F002T@TSOP32  
MBM29F002T@PLCC32 [ ( SA410T ) ]  
MBM29F010 [ ( SA015A1T ) ] MBM29F010@PLCC32  
MBM29F010@TSOP32 [ ( SA410T ) ]  
MBM29F010A [ ( SA015A1T ) ] MBM29F010A@TSOP32  
MBM29F010A@PLCC32 [ ( SA410T ) ]  
MBM29F016@PSOP44 [ ( SA638 ) ] MBM29F016@TSOP40  
MBM29F016@TSOP48 [ ( SA247-B005 ) ] MBM29F016A@PSOP44  
MBM29F016A@TSOP40 [ ( SA409T ) ] MBM29F016A@TSOP48 [ ( SA247-B005 ) ]  
MBM29F016B@PSOP44 [ ( SA638 ) ] MBM29F016B@TSOP40  
MBM29F016B@TSOP48 [ ( SA247-B005 ) ] MBM29F017B@TSOP48 [ ( SA247-



B005) ]	
MBM29F017D@TSOP40 [ (SA409T) ]	MBM29F017D@TSOP48 [ (SA247-
B005) ]	
MBM29F032B@PSOP44 [ (SA638) ]	MBM29F032B@TSOP40
[ (SA409T) ]	
MBM29F033C@TSOP40 [ (SA409T) ]	
MBM29F040	
MBM29F040@PLCC32 [ (SA015A1T) ]	MBM29F040@TSOP32
[ (SA410T) ]	
MBM29F040B	
[ (SA015A1T) ]	MBM29F040B@PLCC32
MBM29F040B@TSOP32 [ (SA410T) ]	
[ (SA015A1T) ]	MBM29F040C@PLCC32
MBM29F040C@TSOP32 [ (SA410T) ]	
[ (SA638) ]	MBM29F080@PSOP44
MBM29F080@TSOP40 [ (SA409T) ]	
B005) ]	MBM29F080A@TSOP48 [ (SA247-
MBM29F080B@PSOP44 [ (SA638) ]	
[ (SA409T) ]	MBM29F080B@TSOP40
MBM29F100B@PSOP44 [ (SA638-B006) ]	
B005) ]	MBM29F100B@TSOP48 [ (SA247-
MBM29F100T@PSOP44 [ (SA638-B006) ]	
B005) ]	MBM29F100T@TSOP48 [ (SA247-
MBM29F160BE@TSOP48 [ (SA247-B005) ]	
MBM29F160TE@TSOP48 [ (SA247-B005) ]	
MBM29F200AB@PSOP44 [ (SA638-B006) ]	
MBM29F200AB@TSOP48 [ (SA247-B005) ]	
MBM29F200AT@PSOP44 [ (SA638-B006) ]	
MBM29F200AT@TSOP48 [ (SA247-B005) ]	
MBM29F200B@PSOP44 [ (SA638-B006) ]	MBM29F200B@TSOP48 [ (SA247-
B005) ]	
MBM29F200T@PSOP44 [ (SA638-B006) ]	MBM29F200T@TSOP48 [ (SA247-
B005) ]	
MBM29F400AB@PSOP44 [ (SA638-B006) ]	
MBM29F400AB@TSOP48 [ (SA247-B005) ]	
MBM29F400AT@PSOP44 [ (SA638-B006) ]	
MBM29F400AT@TSOP48 [ (SA247-B005) ]	
MBM29F400B@PSOP44 [ (SA638-B006) ]	MBM29F400B@TSOP48 [ (SA247-
B005) ]	
MBM29F400BB@PSOP44 [ (SA638-B006) ]	
MBM29F400BB@TSOP48 [ (SA247-B005) ]	
MBM29F400BT@PSOP44 [ (SA638-B006) ]	
MBM29F400BT@TSOP48 [ (SA247-B005) ]	

MBM29F400T@PSOP44 [(SA638-B006)]	MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)]	MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BB@PSOP44 [(SA638-B006)]	
MBM29F800BB@TSOP48 [(SA247-B005)]	
MBM29F800BT@PSOP44 [(SA638-B006)]	
MBM29F800BT@TSOP48 [(SA247-B005)]	
MBM29F800T@PSOP44 [(SA638-B006)]	MBM29F800T@TSOP48 [(SA247-B005)]
MBM29LL800B@TSOP48 [(SA247-B005)]	
MBM29LL800BB@TSOP48 [(SA247-B005)]	
MBM29LL800BT@TSOP48 [(SA247-B005)]	
MBM29LL800T@TSOP48 [(SA247-B005)]	
MBM29LV001B@PLCC32 [(SA015A1T)]	MBM29LV001BB@PLCC32
[(SA015A1T)]	
MBM29LV001BB@TSOP32 [(SA410T)]	MBM29LV001BC@PLCC32
[(SA015A1T)]	
MBM29LV001BC@TSOP32 [(SA410T)]	MBM29LV001BT@PLCC32
[(SA015A1T)]	
MBM29LV001BT@TSOP32 [(SA410T)]	MBM29LV001T@TSOP32
[(SA410T)]	
MBM29LV001TC@PLCC32 [(SA015A1T)]	MBM29LV001TC@TSOP32
[(SA410T)]	
MBM29LV002B@TSOP40 [(SA409T)]	MBM29LV002T@TSOP40
[(SA409T)]	
MBM29LV004B@PSOP44 [(SA638)]	MBM29LV004B@TSOP40
[(SA409T)]	
MBM29LV004BB@TSOP40 [(SA409T)]	MBM29LV004BT@TSOP40
[(SA409T)]	
MBM29LV004T@PSOP44 [(SA638)]	MBM29LV004T@TSOP40
[(SA409T)]	
MBM29LV008B@PSOP44 [(SA638)]	MBM29LV008B@TSOP40
[(SA409T)]	
MBM29LV008BB@TSOP40 [(SA409T)]	MBM29LV008BT@TSOP40
[(SA409T)]	
MBM29LV008T@PSOP44 [(SA638)]	MBM29LV008T@TSOP40
[(SA409T)]	
MBM29LV016/B@TSOP40 [(SA409T)]	MBM29LV016/T@TSOP40
[(SA409T)]	
MBM29LV016B@TSOP40 [(SA409T)]	
MBM29LV017@FBGA48 [(SA642O-B026A-T064F001)]	
MBM29LV017@TSOP40 [(SA409T)]	MBM29LV017B@TSOP40

[ ( SA409T ) ]  
MBM29LV017E@TSOP40 [ ( SA409T ) ] MBM29LV033C@TSOP40  
[ ( SA409T ) ]  
MBM29LV080@TSOP40 [ ( SA409T ) ] MBM29LV081@TSOP40  
[ ( SA409T ) ]  
MBM29LV081B@TSOP40 [ ( SA409T ) ] MBM29LV116B@TSOP40  
[ ( SA409T ) ]  
MBM29LV160B@SON46 [ ( SA631 ) ] MBM29LV160B@SON46  
( \* )  
MBM29LV160BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV160BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160BM@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160BM@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV160BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160T@SON46 [ ( SA631 ) ] MBM29LV160T@SON46  
( \* )  
MBM29LV160TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160TM@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160TM@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BC@PSOP44 [ ( SA638 ) ]  
MBM29LV200BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200TC@PSOP44 [ ( SA638 ) ]  
MBM29LV200TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BB@TSOP48 [ ( SA247-B005 ) ]

MBM29LV400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400BC@PSOP44 [ ( SA638 ) ]  
MBM29LV400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400TC@PSOP44 [ ( SA638 ) ]  
MBM29LV400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV650UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV651UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV652UE@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29LV800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800B@SON46 [ ( SA631 ) ] MBM29LV800B@SON46  
( \* )  
MBM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BA@PSOP44 [ ( SA638 ) ]  
MBM29LV800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BE@PSOP44 [ ( SA638 ) ]  
MBM29LV800BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800T@SON46 [ ( SA631 ) ] MBM29LV800T@SON46  
( \* )  
MBM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TA@PSOP44 [ ( SA638 ) ]  
MBM29LV800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TE@PSOP44 [ ( SA638 ) ]  
MBM29LV800TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29PDS323B@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PDS323T@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PL12LM@TSOP56 [ ( SA628-B102 ) ]  
MBM29PL160BD@PSOP44 [ ( SA638 ) ]  
MBM29PL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL160TD@PSOP44 [ ( SA638 ) ]

MBM29PL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32BM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32BM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32TM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32TM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP56 [ ( SA628-B067 ) ]  
MBM29QM12DH@FBGA88 [ ( SA642J-B101A-W080F001 ) ]  
MBM29QM12DH@TSOP56 [ ( SA628-B097 ) ]  
MBM29SL160BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL160TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BT@TSOP48 [ ( SA247-B005 ) ]  
PDL127H53V(AM29PDL127H53)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H63V(AM29PDL127H63)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H68V(AM29PDL127H68)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H88V(AM29PDL127H88)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H53V(AM29PDL129H53)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H63V(AM29PDL129H63)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H68V(AM29PDL129H68)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H88V(AM29PDL129H88)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PL032J55BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BFI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BFI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BFW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BFW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BFI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BFI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BFW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BFW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J70BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J70BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]

PL032J70BFI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J70BFI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J70BFW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J70BFW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J55BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J55BAI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J55BAW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J55BAW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J55BFI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J55BFI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J55BFW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J55BFW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J60BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J60BAI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J60BAW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J60BAW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J60BFI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J60BFI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J60BFW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J60BFW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J70BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J70BAI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J70BAW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J70BAW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J70BFI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J70BFI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J70BFW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J70BFW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL127J55BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J55BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J55BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J55BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J55BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J55BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J55BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J55BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J60BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J60BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J60BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J60BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J60BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J60BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J60BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]

PL127J60BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S19MN02GP30TFP00@TSOP48 [(SA247-B005)]  
S19MN256P30TFP00@TSOP48 [(SA247-B005)]  
S19MN512P30TFP00@TSOP48 [(SA247-B005)]  
S25FL001D@SOIC8 [(SA602A)] S25FL001D@USON8  
[(SA683)]  
S25FL002A@SOIC8 [(SA605A)] S25FL002A@USON8  
[(SA683)]  
S25FL002D@SOIC8 [(SA602A)] S25FL002D@USON8  
[(SA683)]  
S25FL004A@SOIC8 [(SA605A)] S25FL004A@USON8  
[(SA683)]  
S25FL004D@SOIC8 [(SA602A)] S25FL004D@USON8  
[(SA683)]  
S25FL008A@SOIC8 [(SA605A)] S25FL008A@USON8  
[(SA683)]  
S25FL008D@SOIC8 [(SA602A)] S25FL008D@USON8  
[(SA683)]  
S25FL016A@SOIC16 [(SA404)]

S25FL016A@SOIC16(ISP) [ISP-HEADER01]  
S25FL016A@SOIC8 [(SA605A)]  
S25FL016A@SOIC8(ISP) [ISP-HEADER01]  
S25FL016A@WSON8 [(SA684)]  
S25FL016A@WSON8(ISP) [ISP-HEADER01]  
S25FL020A@SOIC8(4.0) [(SA602A)] S25FL020A@SOIC8(5.4)  
[(SA605A)]  
S25FL020A@USON8 [(SA683)] S25FL032A@SOIC16  
[(SA404)]  
S25FL032A@SOIC16(ISP) [ISP-HEADER01]  
S25FL032A@WSON8 [(SA684)]  
S25FL032A@WSON8(ISP) [ISP-HEADER01]  
S25FL040A(Bottom Boot)@SOP8(4.0) [(SA602A)]  
S25FL040A(Bottom Boot)@SOP8(5.4) [(SA605A)]  
S25FL040A(Bottom Boot)@USON8 [(SA683)]  
S25FL040A(Top Boot)@SOP8(4.0) [(SA602A)]  
S25FL040A(Top Boot)@SOP8(5.4) [(SA605A)]  
S25FL040A(Top Boot)@USON8 [(SA683)]  
S25FL040A@SOP8(4.0) [(SA602A)] S25FL040A@SOP8(5.4)  
[(SA605A)]  
S25FL040A@USON8 [(SA683)] S25FL064A@SOIC16  
[(SA404)]  
S25FL064A@SOIC16(ISP) [ISP-HEADER01]  
S25FL064A@WSON8 [(SA684)]  
S25FL064A@WSON8(ISP) [ISP-HEADER01]  
S25FL080A@SOIC8(4.0) [(SA602A)] S25FL080A@SOIC8(5.4)  
[(SA605A)]  
S25FL080A@USON8 [(SA683)]  
S25FL128P(256 KB)@SOIC16 [(SA404)]  
S25FL128P(256 KB)@SOIC16(ISP) [ISP-HEADER01]  
S25FL128P(256 KB)@WSON8 [(SA684)]  
S25FL128P(256 KB)@WSON8(ISP) [ISP-HEADER01]  
S25FL128P(64 KB)@SOIC16 [(SA404)]  
S25FL128P(64 KB)@SOIC16(ISP) [ISP-HEADER01]  
S25FL128P(64 KB)@WSON8 [(SA684)]  
S25FL128P(64 KB)@WSON8(ISP) [ISP-HEADER01]  
S25FLK05D@SOIC8 [(SA602A)] S25FLK05D@USON8  
[(SA683)]  
S29AD016DBFA01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFA02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFB01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFB02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]



S29AD016DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AD016DBFV01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AD016DBFV02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AD016DMFA01@PSOP44 [ ( SA638 ) ] S29AD016DMFA02@PSOP44  
[ ( SA638 ) ]  
S29AD016DMFB01@PSOP44 [ ( SA638 ) ] S29AD016DMFB02@PSOP44  
[ ( SA638 ) ]  
S29AD016DMFI01@PSOP44 [ ( SA638 ) ] S29AD016DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AD016DMFV01@PSOP44 [ ( SA638 ) ] S29AD016DMFV02@PSOP44  
[ ( SA638 ) ]  
S29AD016DTFA01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFA02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFB01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFB02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFV01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFV02@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BMAI01@PSOP44 [ ( SA638 ) ] S29AL002BMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL002BMFI01@PSOP44 [ ( SA638 ) ] S29AL002BMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL002BTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BMAI01@PSOP44 [ ( SA638 ) ] S29AL004BMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL004BMFI01@PSOP44 [ ( SA638 ) ] S29AL004BMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL004BTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTFI02@TSOP48 [ ( SA247-B005 ) ]

S29AL004DBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBAN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBAN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBANR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBANR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFNR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFNR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DMAI01@PSOP44 [ ( SA638 ) ] S29AL004DMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL004DMAN01@PSOP44 [ ( SA638 ) ] S29AL004DMAN02@PSOP44  
[ ( SA638 ) ]  
S29AL004DMANR1@PSOP44 [ ( SA638 ) ] S29AL004DMANR2@PSOP44  
[ ( SA638 ) ]  
S29AL004DMFI01@PSOP44 [ ( SA638 ) ] S29AL004DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL004DMFN01@PSOP44 [ ( SA638 ) ] S29AL004DMFN02@PSOP44  
[ ( SA638 ) ]  
S29AL004DMFNR1@PSOP44 [ ( SA638 ) ] S29AL004DMFNR2@PSOP44  
[ ( SA638 ) ]  
S29AL004DTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTAN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTAN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTANR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTANR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFNR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFNR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBAN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBAN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBANR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBANR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]

S29AL008DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFN1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFN2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DMAI01@PSOP44 [ ( SA638 ) ] S29AL008DMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMAN01@PSOP44 [ ( SA638 ) ] S29AL008DMAN02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMANR1@PSOP44 [ ( SA638 ) ] S29AL008DMANR2@PSOP44  
[ ( SA638 ) ]  
S29AL008DMFI01@PSOP44 [ ( SA638 ) ] S29AL008DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMFN01@PSOP44 [ ( SA638 ) ] S29AL008DMFN02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMFNR1@PSOP44 [ ( SA638 ) ] S29AL008DMFNR2@PSOP44  
[ ( SA638 ) ]  
S29AL008DTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTANR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTANR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFNR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFNR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFI03@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFI04@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFIR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFIR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFNR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JBFNR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008JTTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JTTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JTTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JTTFI04@TSOP48 [ ( SA247-B005 ) ]

S29AL008JTFIR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JTFIR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JTFNR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL008JTFNR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DMAI01@PSOP44 [ ( SA638 ) ] S29AL016DMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMAN01@PSOP44 [ ( SA638 ) ] S29AL016DMAN02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMFI01@PSOP44 [ ( SA638 ) ] S29AL016DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMFN01@PSOP44 [ ( SA638 ) ] S29AL016DMFN02@PSOP44  
[ ( SA638 ) ]  
S29AL016DTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFI03@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFI04@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFIR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFIR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFNR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JBFNR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016JTTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JTTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JTTFI03@TSOP48 [ ( SA247-B005 ) ]

S29AL016JTTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JTTFIR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JTTFIR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JTTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JTTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JTTFNR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL016JTTFNR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MBAI01@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBAI02@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBAIR1@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBAIR2@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFI01@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFI02@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFIR1@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFIR2@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MFAI01@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAI02@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFI01@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFI02@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAIR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAIR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFIR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFIR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DBAI00@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBAI03@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBAI04@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI00@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI03@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI04@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DTAI00@TSOP40 [ ( SA409T ) ]  
S29AL032DTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTFI00@TSOP40 [ ( SA409T ) ]  
S29AL032DTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTFI04@TSOP48 [ ( SA247-B005 ) ]

S29GL016ABAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI03@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI04@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIW1@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016ABAIW2@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016ABFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI03@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI04@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIW1@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016ABFIW2@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016AFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016ATAI01@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI02@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR1@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR2@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFI01@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFI02@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFI03@TSOP48 [ ( SA247-B005 ) ]

S29GL016ATFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFIR1@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFIR2@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032ABAIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL032ABAIR4 (Normal)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL032ABAIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL032ABAIW3@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL032ABAIW4@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL032ABFIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL032ABFIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL032ABFIW3@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL032ABFIW4@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL032AFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFAIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFAIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFAIS1 ( 29LV320MT)@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFAIS2 ( 29LV320MB)@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFAIS3 ( 29LV320MT)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
S29GL032AFAIS4 ( 29LV320MB)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
S29GL032AFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFFIS1 ( 29LV320MT)@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFFIS2 ( 29LV320MB)@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032AFFIS3 ( 29LV320MT)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
S29GL032AFFIS4 ( 29LV320MB)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
S29GL032ATAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032ATAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032ATAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL032ATAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032ATFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032ATFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032ATFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL032ATFIR4 (Normal)@TSOP48 [ ( SA247-B005 ) ]  
S29GL032ATFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032MBACR0 (Mirror)@FBGA48 [ ( SA642AA-B026A-W064F001N ) ]  
S29GL032MBACR0@FBGA48 [ ( SA642AA-B026A-W064F001N ) ]  
S29GL032MBACR3 (Mirror)@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29GL032MBACR3@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]

S29GL032MBACR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBAIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBAIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MFACR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFACS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]



S29GL032MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MTACR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTACR0@TSOP40 [(SA409T)]  
S29GL032MTACR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR1@TSOP56 [(SA628-B067)]  
S29GL032MTACR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR2@TSOP56 [(SA628-B067)]  
S29GL032MTACR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR3@TSOP48 [(SA247-B005)]  
S29GL032MTACR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR4@TSOP48 [(SA247-B005)]  
S29GL032MTAIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTAIR0@TSOP40 [(SA409T)]  
S29GL032MTAIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR1@TSOP56 [(SA628-B067)]

S29GL032MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2@TSOP56 [(SA628-B067)]  
S29GL032MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR3@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4@TSOP48 [(SA247-B005)]  
S29GL032MTFCR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFCR0@TSOP40 [(SA409T)]  
S29GL032MTFCR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFCR1@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2@TSOP56 [(SA628-B067)]  
S29GL032MTFCR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR3@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4@TSOP48 [(SA247-B005)]  
S29GL032MTFIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFIR0@TSOP40 [(SA409T)]  
S29GL032MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR1@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2@TSOP56 [(SA628-B067)]  
S29GL032MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR3@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4@TSOP48 [(SA247-B005)]  
S29GL032NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIO3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIO4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL032NFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFAIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFAIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFI03@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFI04@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064ABAIR3@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABAIR4@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABAIR5@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABFIR3@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]

S29GL064ABFIR4@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABFIR5@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064AFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIR5@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIS1 ( 29LV640MT )@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIS2 ( 29LV640MB )@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIS3 ( 29LV640MT )@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
S29GL064AFAIS4 ( 29LV640MB )@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
S29GL064AFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFFIR5@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFFIS1 ( 29LV640MT )@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFFIS2 ( 29LV640MB )@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFFIS3 ( 29LV640MT )@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
S29GL064AFFIS4 ( 29LV640MB )@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
S29GL064ATAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064ATAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064ATAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATAIR6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATAIR7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATAIR8@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATAIR9@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064ATFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064ATFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATFIR6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATFIR7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATFIR8@TSOP48 [ ( SA247-B005 ) ]  
S29GL064ATFIR9@TSOP48 [ ( SA247-B005 ) ]  
S29GL064MBAIR0 ( Mirror )@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29GL064MBAIR0@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29GL064MBAIR3 ( Mirror )@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29GL064MBAIR3@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29GL064MBAIR4 ( Mirror )@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29GL064MBAIR4@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29GL064MBAIR5 ( Mirror )@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]

S29GL064MBAIR5@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR0(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR0@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR3(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR3@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR4(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR4@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR5@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFAIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(Normal)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MTAIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR0@TSOP48 [(SA247-B005)]  
S29GL064MTAIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTAIR1@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2(Mirror)@TSOP56 [(SA628-B067)]

S29GL064MTAIR2@TSOP56 [(SA628-B067)]  
S29GL064MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR3@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0@TSOP48 [(SA247-B005)]  
S29GL064MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR1@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2@TSOP56 [(SA628-B067)]  
S29GL064MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR3@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7@TSOP48 [(SA247-B005)]  
S29GL064NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIO3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIO4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]

S29GL064NFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFI03@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFI04@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL064NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL064NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI06@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI07@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIV6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIV7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI04 (Low)@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI06@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI07@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR4@TSOP48 [ ( SA247-B005 ) ]

S29GL064NTFIR6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIV6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIV7@TSOP48 [ ( SA247-B005 ) ]  
S29GL128MFAIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MFAIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MFFIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MFFIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MTAIR1@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTAIR2@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTFIR1@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTFIR2@TSOP56 [ ( SA628-B067 ) ]  
S29GL128NFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIIH@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFAIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAW01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAW02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAWIH@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIIH@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFW01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFW02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAI02@TSOP56 [ ( SA628-B102 ) ]



S29GL128NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAW01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAW02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFW01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFW02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PFACR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFACR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFCR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFCR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PTACR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTACR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTFCR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTFCR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTFIR1@TSOP56 [ ( SA628-B102 ) ]

S29GL128PTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256MR1@TSOP56 [ ( SA628-B067 ) ]  
S29GL256MR2@TSOP56 [ ( SA628-B067 ) ]  
S29GL256NFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFAIIH@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL256NFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFFIIH@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL256NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PFACR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFACR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFCR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFCR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]

S29GL256PFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PTACR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTACR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFCR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFCR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NFA01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFA02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFF01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFF02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NTA01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTA02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTAV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTAV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTF01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTF02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTFV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTFV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]

S29GL512PFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29JL032HBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI21@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI22@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI31@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI32@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI41@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI42@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI21@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI22@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI31@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI32@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI41@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI42@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI21@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI22@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI31@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI32@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI41@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI42@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI21@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI22@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI31@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI32@TSOP48 [ ( SA247-B005 ) ]

S29JL032HTFI41@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI42@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HBAI00@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29JL064HBFI00@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29JL064HTAI00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTAN00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTFI00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTFN00@TSOP48 [ ( SA247-B005 ) ]  
S29PL127J55TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TFW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TFW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TFW13@TSOP56 [ ( SA628-B097 ) ]  
S29VS016K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29WS064J0PBAI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI02@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI03@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW02@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW03@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]

S29WS064J0PBFW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAI02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAI03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAW02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAW03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1ABAI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1ABAI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1ABAW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1ABAW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS128J0PBAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFI00@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFI01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFI10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFI11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW00@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAI02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAI03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]

S29WS128J0SBAW02@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAW03@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFI00@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFI01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFW00@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAI00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAI01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAW00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAW01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S30ML01GP30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP50TFE01@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP50TFE51@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP50TFE01@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP50TFE51@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML128P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30ML256P30TFE00@TSOP48 [ ( SA247-B005 ) ]

S30ML256P30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML256P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML256P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30ML512P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML512P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30MS01GP25TFW00@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW010@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW50@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW510@TSOP48 [ ( SA247-B005 ) ]  
S70PL254J00BAW91@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BAW93@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BAWA1@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BAWA3@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFW91@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFW93@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFWA1@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFWA3@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71AL016D02BAWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BAWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BFWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BFWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BAWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BAWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BFWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BFWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71GL016A40BAW1J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BAW3J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BFW1J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BFW3J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032AA0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032AA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]



S71GL032AA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032AA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032M40BAIBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032N40BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N40BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N40BHW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N40BHW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N80BHW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N80BHW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032NA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032NA0BFW0Z ( LOW ) @FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032NA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032NA0BHW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032NA0BHW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]

S71GL064A0ABFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NA0BHW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NA0BHW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BFW0Z ( LOW )@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BHW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BHW0Z ( HX )@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BHW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL128NB0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAW9J@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]

S71GL128NB0BAW9K@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9N@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9T@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9Y@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFPEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFW9J@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9K@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9N@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9T@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9Y@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]

S71GL128NB0BFWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFW EY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFW EZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NC0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAZAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BF EAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BF EAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BF EAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BF EAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]

S71GL256NB0BFWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFW EJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW ET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NC0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF EAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF EAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF EAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF EAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL512NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFW EJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFW EK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFW EN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFW EP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFW ET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFW EU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]

S71GL512NB0BFWWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71JL064H80BAW01 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW02 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW03 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW04 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW10 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW11 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW12 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW01 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW02 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW10 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW11 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW12 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HB0BAW00 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HB0BAW01 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HB0BAW02 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL128HB0BAW00 (DL128BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
S71JL128HB0BAW01 (DL128BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
S71JL128HB0BAW02 (DL128BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
S71JL128HB0BAW03 (DL128BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
S71JL128HC0BAW00 (DL128CH)@FBGA73 [ ( SA642A-B062A-Y096F001 ) ]  
S71JL128HC0BAW01 (DL128CH)@FBGA73 [ ( SA642A-B062A-Y096F001 ) ]  
S71JL128HC0BAW02 (DL128CH)@FBGA73 [ ( SA642A-B062A-Y096F001 ) ]  
S71JL128HC0BAW03 (DL128CH)@FBGA73 [ ( SA642A-B062A-Y096F001 ) ]  
S71PL032J04BAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J04BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J08BAE0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J08BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J08BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J08BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J08BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J40BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]

S71PL032J40BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J40BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J40BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J40BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J40BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BAI05@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BAW05@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BAWQ7@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BAWQF@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BFI05@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BFW05@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BFWQ7@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032J80BFWQF@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BAE07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BAE0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BAWQF@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL032JA0BFWQF@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064J08BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]

S71PL064J08BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J0ABAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J0ABAW0S@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J0ABFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J0ABFW0S@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]



S71PL064JB0BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAI9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BAW9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BFI9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BFW9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BAI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BAW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BFI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BFW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]

S71PL127JC0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127NB0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JA0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JA0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL191HB0BAI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BAW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BFI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BFW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BAI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BAW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BFI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BFW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL193HB0BAI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]

S71PL193HB0BAW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HB0BFI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HB0BFW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BAI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BAW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BFI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BFW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL254HC0BAW00@FBGA84 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL254JB0BAIT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAWT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFIT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFWT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAITZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAWTZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFITZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFWTZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JD0BAWTB@FBGA84 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL254JD0BFWTB@FBGA84 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL256NC0HAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HAW5U@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HFW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HFW5U@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0GAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0GFW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0HAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0HFW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL258HC0BAW00@FBGA84 [ ( SA642A-B088A-Y096N001 ) ]  
S71PL512ND0JAW5B@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71PL512ND0JFW5B@FBGA84 [ ( SA642A-B158A-Y096F001Y ) ]  
S71VS032K80ZJK01@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032K80ZJK03@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK09@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK0B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK11@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK13@BGA44 [ ( SA733D-B212A-M044F001Y ) ]

S71VS032KA0ZJK19@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK1B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK01@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK03@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK09@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK0B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK11@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK13@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK19@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK1B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71WS064JA0BAI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BAI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BAW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BAW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BFI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BFI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BFW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BFW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BAI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BAI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BAW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BAW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BFI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BFI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BFW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BFW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS128JA0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JA0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JA0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JA0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JB0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JB0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]

S71WS128JB0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BAE9A@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BAWA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BFE9A@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BFIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BFWA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128NB0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]

S71WS128NC0BFWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256JC0BAIA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAIT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAITJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAITY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAWA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAWT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWTJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWTY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFIA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFIT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFITJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFITY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFWA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFWT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWTJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWTY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256NC0BAIAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAA@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAE@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]

S71WS256NC0BAWAZ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFIAB@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFIAF@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFIAK@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFIAP@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFIAU@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFIAZ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAA@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAB@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAE@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAF@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAU@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAZ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256ND0BAIE3@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIE7@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIEK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIEP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIEU@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWE3@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWE7@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWEK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWEP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWEU@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYH@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYJ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYM@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYN@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIE3@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIE7@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIEK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIEP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIEU@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]

S71WS256ND0BFWE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYH@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYJ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYM@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYN@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS512NC0BAIAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTA@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTE@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTH@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTJ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTM@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTN@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFWAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFWAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFWAK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFWAP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFWAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFWAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFWTA@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]



S71WS512NC0BFWTE@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTH@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTJ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTM@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTN@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512ND0BAIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S75PL127JBDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]

S75PL127JCDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S99-50001(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
S99-50003(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
S99-50005(2\*S29WS128H)@FBGA88 [(SA642A-B123A-Y096F001Y)]  
S99-50011(2\*S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]  
S99-50031(AM29BDS320)@FBGA56 [(SA644B-B025B-Y056F001Y)]  
S99-50034-9N(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50034-9P(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50034-9Y(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50034-9Z(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50048(S29GL064N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99-50052(S29GL128N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99-50057(S29GL032A)@FBGA88 [(SA642W-B116A-W088F001Y)]  
S99-50059(S29GL064A)@FBGA88 [(SA642A-B116A-Y096N001N)]  
S99-50066(S29GL032M)@FBGA88 [(SA642A-B116A-Y096N001N)]  
S99-50073(S29WS256N)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
S99-50074(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]  
S99-50076(S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]  
S99-50080(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]  
S99-50080-LF(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]  
S99-50085(S29WS256N)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
S99-50089(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]  
S99-50109(2\*S29WS256N)@FBGA88 [(SA642A-B138A-Y096F001Y)]  
S99-50111(S29AL016DFFI02)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S99-50121-9Y@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Y-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Z@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Z-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50134(S29GL128N)@FBGA88 [(SA642R-B199A-T096F001Y)]  
S99-50158(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]  
S99-50158-LF(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]  
S99-50183(S29GL256N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99PL128JC0BAWFC0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWNB0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWT10@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWUB0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL193JB0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JB0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]

S99PL193JB0BAWFC@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S99PL193JB0BAWUC@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S99PL193JC0BAEFC@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S99PL193JC0BAEUC@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S99PL193JC0BAWFC@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S99PL193JC0BAWUC@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]

## SPANSION-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

S71PL129JB0BFW9U ( ZX ) @FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S75PL127JBEBAWKB ( DX ) @FBGA84 [ ( SA642CC-B135A-W080F001Y ) ]  
S75PL127JBEBAWKU ( DX ) @FBGA84 [ ( SA642CC-B135A-W080F001Y ) ]  
S75PL127JBEBFWKB ( DX ) @FBGA84 [ ( SA642CC-B135A-W080F001Y ) ]  
S75PL127JBEBFWKU ( DX ) @FBGA84 [ ( SA642CC-B135A-W080F001Y ) ]

## SSSC

### MICROCONTROLLER

SSU7301 SSU7301@PLCC44  
[ ( SA244 ) ]  
SSU7301@TQFP44 [ ( SA245A ) ]

## SST

### E ( E ) PROM / FRAM / NVRAM

SST25LF010@SOIC8 ( 4.0 ) [ ( SA602A ) ] SST25LF010@SOIC8 ( 5.4 )  
[ ( SA605B ) ]  
SST25LF010@WSON8 [ ( SA683 ) ]  
SST25LF010A@SOIC8 ( 4.0 ) [ ( SA602A ) ]  
SST25LF010A@SOIC8 ( 5.4 ) [ ( SA605B ) ]  
SST25LF010A@WSON8 [ ( SA683 ) ]  
SST25LF016A@SOIC8 ( 4.0 ) [ ( SA602A ) ]  
SST25LF016A@SOIC8 ( 5.4 ) [ ( SA605A ) ]  
SST25LF016A@WSON8 [ ( SA683 ) ]  
SST25LF016B@SOIC8 ( 4.0 ) [ ( SA602A ) ]

SST25LF016B@SOIC8(5.4) [(SA605A)]	
SST25LF016B@WSON8 [(SA683)]	SST25LF020@SOIC8(4.0)
[(SA602A)]	
SST25LF020@SOIC8(5.4) [(SA605B)]	SST25LF020@WSON8
[(SA683)]	
SST25LF020A@SOIC8(4.0) [(SA602A)]	
SST25LF020A@SOIC8(5.4) [(SA605B)]	
SST25LF020A@WSON8 [(SA683)]	SST25LF040@SOIC8(4.0)
[(SA602A)]	
SST25LF040@SOIC8(5.4) [(SA605B)]	SST25LF040@WSON8
[(SA683)]	
SST25LF040A@SOIC8(4.0) [(SA602A)]	
SST25LF040A@SOIC8(5.4) [(SA605B)]	
SST25LF040A@WSON8 [(SA683)]	SST25LF080@SOIC8(4.0)
[(SA602A)]	
SST25LF080@SOIC8(5.4) [(SA605B)]	SST25LF080@WSON8
[(SA683)]	
SST25LF080A@SOIC8(4.0) [(SA602A)]	
SST25LF080A@SOIC8(5.4) [(SA605B)]	
SST25LF080A@WSON8 [(SA683)]	SST25VF010@SOIC8(4.0)
[(SA602A)]	
SST25VF010@SOIC8(5.4) [(SA605B)]	SST25VF010@WSON8
[(SA683)]	
SST25VF010A@SOIC8(4.0) [(SA602A)]	
SST25VF010A@SOIC8(5.4) [(SA605B)]	
SST25VF010A@WSON8 [(SA683)]	
SST25VF016B@SOIC8(4.0) [(SA602A)]	
SST25VF016B@SOIC8(5.4) [(SA605A)]	
SST25VF016B@WSON8 [(SA683)]	SST25VF020@SOIC8(4.0)
[(SA602A)]	
SST25VF020@SOIC8(5.4) [(SA605B)]	SST25VF020@WSON8
[(SA683)]	
SST25VF032B@SOIC8(4.0) [(SA602A)]	
SST25VF032B@SOIC8(5.4) [(SA605A)]	
SST25VF032B@WSON8 [(SA683)]	SST25VF040@SOIC8(4.0)
[(SA602A)]	
SST25VF040@SOIC8(5.4) [(SA605B)]	SST25VF040@WSON8
[(SA683)]	
SST25VF040B@SOIC8(4.0) [(SA602A)]	
SST25VF040B@SOIC8(5.4) [(SA605A)]	
SST25VF040B@WSON8 [(SA683)]	SST25VF080@SOIC8(4.0)
[(SA602A)]	
SST25VF080@SOIC8(5.4) [(SA605B)]	SST25VF080@WSON8

[ (SA683) ]	
SST25VF080B@SOIC8(4.0) [ (SA602A) ]	
SST25VF080B@SOIC8(5.4) [ (SA605A) ]	
SST25VF080B@WSON8 [ (SA683) ]	SST25VF512@SOIC8(4.0)
[ (SA602A) ]	
SST25VF512@SOIC8(5.4) [ (SA605B) ]	SST25VF512@WSON8
[ (SA683) ]	
SST25VF512A@SOIC8(4.0) [ (SA602A) ]	
SST25VF512A@SOIC8(5.4) [ (SA605B) ]	
SST25VF512A@WSON8 [ (SA683) ]	SST25WF010@SOIC8
[ (SA602A) ]	
SST25WF020@SOIC8 [ (SA602A) ]	SST25WF040@SOIC8
[ (SA602A) ]	
SST25WF080@SOIC8 [ (SA602A) ]	SST25WF512@SOIC8
[ (SA602A) ]	
SST27SF010	SST27SF010@PLCC32
[ (SA015A1T) ]	
SST27SF010@TSOP32 [ (SA410T) ]	
SST27SF020	
SST27SF020@PLCC32 [ (SA015A1T) ]	SST27SF020@TSOP32
[ (SA410T) ]	
SST27SF256	SST27SF256@PLCC32
[ (SA015A1T) ]	
SST27SF256@VSOP32 [ (SA620) ]	
SST27SF512	
SST27SF512@PLCC32 [ (SA015A1T) ]	SST27SF512@VSOP32
[ (SA620) ]	
SST27VF010	SST27VF010@PLCC32
[ (SA015A1T) ]	
SST27VF010@TSOP32 [ (SA410T) ]	
SST27VF020	
SST27VF020@PLCC32 [ (SA015A1T) ]	SST27VF020@TSOP32
[ (SA410T) ]	
SST27VF040	SST27VF040@PLCC32
[ (SA015A1T) ]	
SST27VF040@TSOP32 [ (SA410T) ]	
SST27VF256	
SST27VF256@PLCC32 [ (SA015A1T) ]	SST27VF256@VSOP32
[ (SA620) ]	
SST27VF512	SST27VF512@PLCC32
[ (SA015A1T) ]	
SST27VF512@VSOP32 [ (SA620) ]	
SST28EE011	

SST28EE011@PLCC32 [(SA015A1T)]	SST28EE011@TSOP32
[(SA410T)]	
SST28LE011	SST28LE011@PLCC32
[(SA015A1T)]	
SST28LE011@TSOP32 [(SA410T)]	
SST28LF040	
SST28LF040@PLCC32 [(SA015A1T)]	SST28LF040@TSOP32
[(SA410T)]	
SST28SF040	SST28SF040@PLCC32
[(SA015A1T)]	
SST28SF040@TSOP32 [(SA410T)]	
SST28SF040A	
SST28SF040A@PLCC32 [(SA015A1T)]	SST28SF040A@TSOP32
[(SA410T)]	
SST28VE011	SST28VE011@PLCC32
[(SA015A1T)]	
SST28VE011@TSOP32 [(SA410T)]	
SST28VF040	
SST28VF040@PLCC32 [(SA015A1T)]	SST28VF040@TSOP32
[(SA410T)]	
SST28VF040A	SST28VF040A@PLCC32
[(SA015A1T)]	
SST28VF040A@TSOP32 [(SA410T)]	
SST29EE010	
SST29EE010@PLCC32 [(SA015A1T)]	SST29EE010@TSOP32
[(SA410T)]	
SST29EE020	SST29EE020@PLCC32
[(SA015A1T)]	
SST29EE020@TSOP32 [(SA410T)]	
SST29EE512	
SST29EE512@PLCC32 [(SA015A1T)]	SST29EE512@TSOP32
[(SA410T)]	
SST29LE010	SST29LE010@PLCC32
[(SA015A1T)]	
SST29LE010@TSOP32 [(SA410T)]	
SST29LE020	
SST29LE020@PLCC32 [(SA015A1T)]	SST29LE020@TSOP32
[(SA410T)]	
SST29LE512	SST29LE512@PLCC32
[(SA015A1T)]	
SST29LE512@TSOP32 [(SA410T)]	
SST29SF010	
SST29SF010@PLCC32 [(SA015A1T)]	SST29SF010@VSOP32

[ ( SA620 ) ]  
 SST29SF020 SST29SF020@PLCC32  
 [ ( SA015A1T ) ]  
 SST29SF020@VSOP32 [ ( SA620 ) ]  
 SST29SF040  
 SST29SF040@PLCC32 [ ( SA015A1T ) ] SST29SF040@VSOP32  
 [ ( SA620 ) ]  
 SST29SF512 SST29SF512@PLCC32  
 [ ( SA015A1T ) ]  
 SST29SF512@VSOP32 [ ( SA620 ) ]  
 SST29VE010  
 SST29VE010@PLCC32 [ ( SA015A1T ) ] SST29VE010@TSOP32  
 [ ( SA410T ) ]  
 SST29VE020 SST29VE020@PLCC32  
 [ ( SA015A1T ) ]  
 SST29VE020@TSOP32 [ ( SA410T ) ]  
 SST29VE512  
 SST29VE512@PLCC32 [ ( SA015A1T ) ] SST29VE512@TSOP32  
 [ ( SA410T ) ]  
 SST29VF010 SST29VF010@PLCC32  
 [ ( SA015A1T ) ]  
 SST29VF010@VSOP32 [ ( SA620 ) ]  
 SST29VF020  
 SST29VF020@PLCC32 [ ( SA015A1T ) ] SST29VF020@VSOP32  
 [ ( SA620 ) ]  
 SST29VF040 SST29VF040@PLCC32  
 [ ( SA015A1T ) ]  
 SST29VF040@VSOP32 [ ( SA620 ) ]  
 SST29VF512  
 SST29VF512@PLCC32 [ ( SA015A1T ) ] SST29VF512@VSOP32  
 [ ( SA620 ) ]  
 SST31LF021@VSOP32 [ ( SA620 ) ] SST31LF041@VSOP40  
 [ ( SA623 ) ]  
 SST31LF041A@VSOP32 [ ( SA620 ) ] SST31LF043@VSOP40  
 [ ( SA623 ) ]  
 SST31LF043A@VSOP32 [ ( SA620 ) ]  
 SST32HF162@LFBGA48 [ ( SA655E-B026A-T064F001 ) ]  
 SST32HF162@LFBGA48 ( SST adapter ) SST32HF162@TSOP48 [ ( SA247-  
 B005 ) ]  
 SST32HF1621C@LFBGA62 [ ( SA642R-B083A-T096F001Y ) ]  
 SST32HF1621C@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
 SST32HF1622C@LFBGA62 [ ( SA642R-B083A-T096F001Y ) ]  
 SST32HF1622C@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]

SST32HF164@LFBGA48 [ (SA655E-B026A-T064F001) ]  
SST32HF164@LFBGA48(SST adapter)            SST32HF164@TSOP48 [ (SA247-B005) ]  
SST32HF1641@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF1641@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1641C@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF1641C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1642@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF1642@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1642C@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF1642C@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1681@LFBGA62 [ (SA642R-B083A-T096F001Y) ]  
SST32HF1681@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1682@LFBGA62 [ (SA642R-B083A-T096F001Y) ]  
SST32HF1682@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF200@LFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST32HF201@LFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST32HF202@LFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST32HF324@LFBGA62 [ (SA642E-B023A-T072F001) ]  
SST32HF324@LFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF324@TFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF3241@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3241@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3241C@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3241C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3242@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3242@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3242C@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3242C@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3244C@FBGA56 [ (SA642R-B032A-T096F001Y) ]  
SST32HF324C@LFBGA62 [ (SA642E-B023A-T072F001) ]  
SST32HF324C@LFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF324C@TFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF328@LFBGA62 [ (SA642E-B023A-T072F001) ]  
SST32HF328@LFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF328@TFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF3281@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3281@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3281C@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3281C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3282@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3282@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3282C@FBGA62 [ (SA642R-B023A-T096F001Y) ]



SST32HF3282C@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3284@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF328C@LFBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST32HF328C@LFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF328C@TFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF32A1@LFBGA62 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF32A1@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF32A4@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF400@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF401@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF402@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF64161@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF64161C@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6481@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6481C@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6482@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF6482@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF6482C@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF6482C@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64A1@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64A1@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64A2@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF64A2@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64A2@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64B1@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64B1@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64B2@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64B2@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF800@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF802@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST32HF802@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF802@LFBGA48(SST adapter)  
SST34HF1601B@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1601B@TSOP48 [ ( SA247-B005 ) ]  
SST34HF1601C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1601C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1602C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1602C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1621@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1621A@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1621A@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1621C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1621C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]

SST34HF1621S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1622@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1622C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1622C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1622S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF162C@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF162G@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF162G@LFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST34HF1641@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1641A@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1641A@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1641C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1641C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1641D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1641D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1641J@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1641J@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1641S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1642C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1642D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1642S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF164C@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF164G@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF164G@LFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST34HF1681@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1681@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1681D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1681D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1681J@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1681J@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1682D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1682D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF3243C@FBGA56 [ ( SA642I-B032A-W080F001Y ) ]  
SST34HF3243C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3244@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3244@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3244C@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3244C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3282@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3282@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]

SST34HF3283@FBGA56 [ (SA642I-B032A-W080F001Y) ]  
SST34HF3283@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST34HF3284@FBGA56 [ (SA642R-B032A-T096F001Y) ]  
SST34HF3284@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST34HF32A4@FBGA56 [ (SA642R-B032A-T096F001Y) ]  
SST34HF32A4@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST34WA1601@FBGA44 [ (SA733D-B206A-M044F001Y) ]  
SST34WA1602@FBGA44 [ (SA733D-B206A-M044F001Y) ]  
SST36VF1601(B3K)@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST36VF1601(BK)@TFBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST36VF1601@TSOP48 [ (SA247-B005) ]  
SST36VF1601C@FBGA48 [ (SA642G-B026A-T048F001) ]  
SST36VF1601C@TSOP48 [ (SA247-B005) ]  
SST36VF1601E@FBGA48 [ (SA642G-B026A-T048F001) ]  
SST36VF1601E@TSOP48 [ (SA247-B005) ]  
SST36VF1601G@LFBGA56 [ (SA642A-B032A) ]  
SST36VF1601G@TFBGA48 [ (SA642G-B026A-T048F001) ]  
SST36VF1601G@TSOP48 [ (SA247-B005) ]  
SST36VF1602(B3K)@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST36VF1602(BK)@TFBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST36VF1602@TSOP48 [ (SA247-B005) ]  
SST36VF1602C@FBGA48 [ (SA642G-B026A-T048F001) ]  
SST36VF1602C@TSOP48 [ (SA247-B005) ]  
SST36VF1602E@FBGA48 [ (SA642G-B026A-T048F001) ]  
SST36VF1602E@TSOP48 [ (SA247-B005) ]  
SST36VF1602G@LFBGA56 [ (SA642A-B032A) ]  
SST36VF1602G@TFBGA48 [ (SA642G-B026A-T048F001) ]  
SST36VF1602G@TSOP48 [ (SA247-B005) ]  
SST36VF3203@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST36VF3203@TSOP48 [ (SA247-B005) ]  
SST36VF3204@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST36VF3204@TSOP48 [ (SA247-B005) ]  
SST37VF010 [ (SA015A1T) ] SST37VF010@PLCC32  
SST37VF010@VSOP32 [ (SA620) ]  
SST37VF020 [ (SA015A1T) ] SST37VF020@VSOP32  
[ (SA620) ]  
SST37VF040 [ (SA015A1T) ] SST37VF040@PLCC32  
SST37VF040@VSOP32 [ (SA620) ]  
SST37VF512 [ (SA015A1T) ] SST37VF512@VSOP32

[ ( SA620 ) ]  
SST38VF6401@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST38VF6401@TSOP48 [ ( SA247-B005 ) ]  
SST38VF6402@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST38VF6402@TSOP48 [ ( SA247-B005 ) ]  
SST38VF6403@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST38VF6403@TSOP48 [ ( SA247-B005 ) ]  
SST38VF6404@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST38VF6404@TSOP48 [ ( SA247-B005 ) ]  
SST39LF010@PLCC32 [ ( SA015A1T ) ]  
SST39LF010@TFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST39LF010@VSOP32 [ ( SA620 ) ]  
SST39LF010@WFBGA48 [ ( SA716A-B120A-M048F001Y ) ]  
SST39LF016@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST39LF016@TSOP40 [ ( SA409T ) ] SST39LF020@PLCC32  
[ ( SA015A1T ) ]  
SST39LF020@TFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST39LF020@VSOP32 [ ( SA620 ) ]  
SST39LF020@WFBGA48 [ ( SA716A-B120A-M048F001Y ) ]  
SST39LF040@PLCC32 [ ( SA015A1T ) ] SST39LF040@VSOP32  
[ ( SA620 ) ]  
SST39LF080@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST39LF080@TSOP40 [ ( SA409T ) ] SST39LF080Q@TSOP40  
[ ( SA409T ) ]  
SST39LF100@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST39LF100@VSOP40 [ ( SA623 ) ]  
SST39LF160@TFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST39LF160@TSOP48 [ ( SA247-B005 ) ]  
SST39LF200A@TFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST39LF200A@TSOP48 [ ( SA247-B005 ) ]  
SST39LF200A@WFBGA48 [ ( SA716B-B119B-T048F001Y ) ]  
SST39LF400A@TFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST39LF400A@TSOP48 [ ( SA247-B005 ) ]  
SST39LF400A@WFBGA48 [ ( SA716B-B119B-T048F001Y ) ]  
SST39LF512@PLCC32 [ ( SA015A1T ) ] SST39LF512@VSOP32  
[ ( SA620 ) ]  
SST39LF800A@TFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST39LF800A@TSOP48 [ ( SA247-B005 ) ]  
SST39LF800A@WFBGA48 [ ( SA716B-B119B-T048F001Y ) ]  
SST39LH010 SST39LH010@PLCC32  
[ ( SA015A1T ) ]  
SST39LH010@TSOP32 [ ( SA410T ) ]  
SST39LH040

SST39LH040@PLCC32 [ (SA015A1T) ]	SST39LH040@TSOP32
[ (SA410T) ]	
SST39LH512	SST39LH512@PLCC32
[ (SA015A1T) ]	
SST39LH512@TSOP32 [ (SA410T) ]	
SST39SF010	
SST39SF010@PLCC32 [ (SA015A1T) ]	SST39SF010@VSOP32
[ (SA620) ]	
SST39SF010A	SST39SF010A@PLCC32
[ (SA015A1T) ]	
SST39SF010A@VSOP32 [ (SA620) ]	
SST39SF020	
SST39SF020@PLCC32 [ (SA015A1T) ]	SST39SF020@VSOP32
[ (SA620) ]	
SST39SF020A	SST39SF020A@PLCC32
[ (SA015A1T) ]	
SST39SF020A@VSOP32 [ (SA620) ]	
SST39SF020P	
SST39SF020P@PLCC32 [ (SA015A1T) ]	SST39SF020P@VSOP32
[ (SA620) ]	
SST39SF040	SST39SF040@PLCC32
[ (SA015A1T) ]	
SST39SF040@VSOP32 [ (SA620) ]	
SST39SF040P	
SST39SF040P@PLCC32 [ (SA015A1T) ]	SST39SF040P@VSOP32
[ (SA620) ]	
SST39SF512	SST39SF512@PLCC32
[ (SA015A1T) ]	
SST39SF512@VSOP32 [ (SA620) ]	
SST39SF512A	
SST39SF512A@PLCC32 [ (SA015A1T) ]	SST39SF512A@VSOP32
[ (SA620) ]	
SST39VF010	SST39VF010@PLCC32
[ (SA015A1T) ]	
SST39VF010@TFBGA48 [ (SA642G-B026A-T048F001) ]	
SST39VF010@VSOP32 [ (SA620) ]	
SST39VF016@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
SST39VF016@TSOP40 [ (SA409T) ]	SST39VF016Q@TSOP40
[ (SA409T) ]	
SST39VF020	SST39VF020@PLCC32
[ (SA015A1T) ]	
SST39VF020@TFBGA48 [ (SA642G-B026A-T048F001) ]	
SST39VF020@VSOP32 [ (SA620) ]	

SST39VF020P

SST39VF020P@PLCC32 [ (SA015A1T) ]                    SST39VF020P@VSOP32  
[ (SA620) ]

SST39VF040    SST39VF040@PLCC32  
[ (SA015A1T) ]

SST39VF040@VSOP32 [ (SA620) ]

SST39VF040P

SST39VF040P@PLCC32 [ (SA015A1T) ]                    SST39VF040P@VSOP32  
[ (SA620) ]

SST39VF080@FBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF080@TSOP40 [ (SA409T) ]                    SST39VF080Q@TSOP40  
[ (SA409T) ]

SST39VF088@TSOP48 [ (SA247-B005) ]

SST39VF100@FBGA48 [ (SA642B-B026A-Y072F001) ]

SST39VF100@VSOP40 [ (SA623) ]

SST39VF160@TFBGA48 [ (SA642B-B026A-Y072F001) ]

SST39VF160@TSOP48 [ (SA247-B005) ]

SST39VF1601@TFBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF1601@TSOP48 [ (SA247-B005) ]

SST39VF1601C@FBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF1601C@TSOP48 [ (SA247-B005) ]

SST39VF1602@TFBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF1602@TSOP48 [ (SA247-B005) ]

SST39VF1602C@FBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF1602C@TSOP48 [ (SA247-B005) ]

SST39VF160Q@TSOP48 [ (SA247-B005) ]

SST39VF1681@TFBGA48 [ (SA642B-B026A-Y072F001) ]

SST39VF1681@TSOP48 [ (SA247-B005) ]

SST39VF1682@TFBGA48 [ (SA642B-B026A-Y072F001) ]

SST39VF1682@TSOP48 [ (SA247-B005) ]

SST39VF200A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF200A@TSOP48 [ (SA247-B005) ]

SST39VF200A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]

SST39VF320@TFBGA48 [ (SA642G-B026A-T048F001) ]

SST39VF320@TSOP48 [ (SA247-B005) ]

SST39VF3201@TFBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF3201@TSOP48 [ (SA247-B005) ]

SST39VF3201B@FBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF3201B@TSOP48 [ (SA247-B005) ]

SST39VF3202@TFBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF3202@TSOP48 [ (SA247-B005) ]

SST39VF3202B@FBGA48 [ (SA642G-B026A-T048F001Y) ]

SST39VF3202B@TSOP48 [ (SA247-B005) ]

SST39VF400@TSOP48 [(SA247-B005)]  
 SST39VF400A(Low)@TSOP48 [(SA247)]  
 SST39VF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF400A@TSOP48 [(SA247-B005)]  
 SST39VF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39VF400Q@TSOP48 [(SA247-B005)]  
 SST39VF512 SST39VF512@PLCC32  
 [(SA015A1T)]  
 SST39VF512@VSOP32 [(SA620)]  
 SST39VF6401@TFBGA48 [(SA642R-B026A-T096F001Y)]  
 SST39VF6401@TSOP48 [(SA247-B005)]  
 SST39VF6401B@FBGA48 [(SA642R-B026A-T096F001Y)]  
 SST39VF6401B@TSOP48 [(SA247-B005)]  
 SST39VF6402@TFBGA48 [(SA642R-B026A-T096F001Y)]  
 SST39VF6402@TSOP48 [(SA247-B005)]  
 SST39VF6402B@FBGA48 [(SA642R-B026A-T096F001Y)]  
 SST39VF6402B@TSOP48 [(SA247-B005)]  
 SST39VF800@TSOP48 [(SA247-B005)]  
 SST39VF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF800A@TSOP48 [(SA247)]  
 SST39VF800A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39VF800Q@TSOP48 [(SA247-B005)]  
 SST39WF1601@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF1601@WFBGA48 [(SA716C-B119A-T048F001Y)]  
 SST39WF1602@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF1602@WFBGA48 [(SA716C-B119A-T048F001Y)]  
 SST39WF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800A(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]  
 SST39WF800A(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF800B(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]  
 SST39WF800B(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800B@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST45LF010@SOIC8 [(SA602A)] SST45LF010@WSON8  
 [(SA683)]  
 SST45VF010@SOIC8 [(SA602A)] SST45VF020@SOIC8  
 [(SA602A)]  
 SST45VF512@SOIC8 [(SA602A)] SST49LF002@PLCC32  
 [(SA015A1T)]  
 SST49LF002@VSOP32 [(SA620)] SST49LF002A@PLCC32  
 [(SA015A1T)]  
 SST49LF002A@VSOP32 [(SA620)] SST49LF002B@PLCC32

[ (SA015A1T) ]	
SST49LF003A@PLCC32 [ (SA015A1T) ]	SST49LF003A@VSOP32
[ (SA620) ]	
SST49LF003B@PLCC32 [ (SA015A1T) ]	SST49LF004@PLCC32
[ (SA015A1T) ]	
SST49LF004@VSOP32 [ (SA620) ]	SST49LF004A@PLCC32
[ (SA015A1T) ]	
SST49LF004A@VSOP32 [ (SA620) ]	SST49LF004B@PLCC32
[ (SA015A1T) ]	
SST49LF004B@VSOP32 [ (SA620) ]	SST49LF004B@VSOP40
[ (SA409T) ]	
SST49LF004C@PLCC32 [ (SA015A1T) ]	SST49LF004C@VSOP32
[ (SA620) ]	
SST49LF008@PLCC32 [ (SA015A1T) ]	SST49LF008@VSOP32
[ (SA620) ]	
SST49LF008A@PLCC32 [ (SA015A1T) ]	SST49LF008A@TSOP40
[ (SA409T) ]	
SST49LF008A@VSOP32 [ (SA620) ]	SST49LF008C@PLCC32
[ (SA015A1T) ]	
SST49LF008C@VSOP32 [ (SA620) ]	SST49LF016C@PLCC32
[ (SA015A1T) ]	
SST49LF016C@TSOP40 [ (SA409T) ]	SST49LF016C@VSOP32
[ (SA620) ]	
SST49LF020@PLCC32 [ (SA015A1T) ]	SST49LF020@VSOP32
[ (SA620) ]	
SST49LF020A@PLCC32 [ (SA015A1T) ]	SST49LF020A@VSOP32
[ (SA620) ]	
SST49LF030A@PLCC32 [ (SA015A1T) ]	SST49LF030A@VSOP32
[ (SA620) ]	
SST49LF040@PLCC32 [ (SA015A1T) ]	SST49LF040@VSOP32
[ (SA620) ]	
SST49LF040A@PLCC32 [ (SA015A1T) ]	SST49LF040A@VSOP32
[ (SA620) ]	
SST49LF040B@PLCC32 [ (SA015A1T) ]	SST49LF040B@TSOP40
[ (SA409T) ]	
SST49LF040B@VSOP32 [ (SA620) ]	SST49LF080A@PLCC32
[ (SA015A1T) ]	
SST49LF080A@VSOP32 [ (SA620) ]	SST49LF160C@PLCC32
[ (SA015A1T) ]	
SST49LF160C@TSOP32 [ (SA620) ]	

## MICROCONTROLLER



SST65P542R@SOIC28 [(SA404)]	
SST89C54	
SST89C54@PLCC44 [(SA244)]	SST89C54@TQFP44
[(SA245A)]	
SST89C58	SST89C58@PLCC44
[(SA244)]	
SST89C58@TQFP44 [(SA245A)]	SST89C58RC@PLCC44
[(SA244)]	
SST89C58RC@TQFP44 [(SA245A)]	SST89C58RC@WQFN40
[(SA245A)]	
SST89E516RD	SST89E516RD@PLCC44
[(SA244)]	
SST89E516RD@TQFP44 [(SA245A)]	
SST89E516RD2	
SST89E516RD2@PLCC44 [(SA244)]	SST89E516RD2@TQFP44
[(SA245A)]	
SST89E52RC	SST89E52RC@PLCC44
[(SA244)]	
SST89E52RC@TQFP44 [(SA245A)]	
SST89E52RD	
SST89E52RD@PLCC44 [(SA244)]	SST89E52RD@TQFP44
[(SA245A)]	
SST89E52RD2	SST89E52RD2@PLCC44
[(SA244)]	
SST89E52RD2@TQFP44 [(SA245A)]	
SST89E54RC	
SST89E54RC@PLCC44 [(SA244)]	SST89E54RC@TQFP44
[(SA245A)]	
SST89E54RD	SST89E54RD@PLCC44
[(SA244)]	
SST89E54RD@TQFP44 [(SA245A)]	
SST89E54RD2	
SST89E54RD2@PLCC44 [(SA244)]	SST89E54RD2@TQFP44
[(SA245A)]	
SST89E554RC	SST89E554RC@PLCC44
[(SA244)]	
SST89E554RC@TQFP44 [(SA245A)]	
SST89E564RD	
SST89E564RD@PLCC44 [(SA244)]	SST89E564RD@TQFP44
[(SA245A)]	
SST89E58RD	SST89E58RD@PLCC44
[(SA244)]	

SST89E58RD@TQFP44 [ (SA245A) ]	
SST89E58RD2	
SST89E58RD2@PLCC44 [ (SA244) ]	SST89E58RD2@TQFP44
[ (SA245A) ]	
SST89V516RD	SST89V516RD@PLCC44
[ (SA244) ]	
SST89V516RD@TQFP44 [ (SA245A) ]	
SST89V516RD2	
SST89V516RD2@PLCC44 [ (SA244) ]	SST89V516RD2@TQFP44
[ (SA245A) ]	
SST89V52RD	SST89V52RD@PLCC44
[ (SA244) ]	
SST89V52RD@TQFP44 [ (SA245A) ]	
SST89V52RD2	
SST89V52RD2@PLCC44 [ (SA244) ]	SST89V52RD2@TQFP44
[ (SA245A) ]	
SST89V54RD2	SST89V54RD2@PLCC44
[ (SA244) ]	
SST89V54RD2@TQFP44 [ (SA245A) ]	
SST89V554RC	
SST89V554RC@PLCC44 [ (SA244) ]	SST89V554RC@TQFP44
[ (SA245A) ]	
SST89V564RD	SST89V564RD@PLCC44
[ (SA244) ]	
SST89V564RD@TQFP44 [ (SA245A) ]	
SST89V58RD2	
SST89V58RD2@PLCC44 [ (SA244) ]	SST89V58RD2@TQFP44
[ (SA245A) ]	

## ST

### E ( E ) PROM / FRAM / NVRAM

ET2716	
ETC2716	
ETC2732	
M24128	
M24128@MLP8 [ (SA724) ]	M24128@SOIC8
[ (SA602A) ]	
M24128@TSOP8 [ (SA026) ]	
M24164	
M24164@SOIC8 [ (SA602A) ]	

M24256	M24256@TSOP8
M24256@MLP8 [(SA724)]	
[(SA026)]	
M24256[3.9]@SOIC8 [(SA602A)]	M24256[5.5]@SOIC8
[(SA605A)]	
M24512	M24512@SOIC8
[(SA605A)]	
M24512@TSOP8 [(SA026)]	
M24C01	
M24C01@MLP8 [(SA724)]	M24C01@SOIC8
[(SA602A)]	
M24C01R	M24C01R@MLP8
[(SA724)]	
M24C01R@SOIC8 [(SA602A)]	M24C01R@TSOP8
[(SA026)]	
M24C01W	M24C01W@MLP8
[(SA724)]	
M24C01W@SOIC8 [(SA602A)]	M24C01W@TSOP8
[(SA026)]	
M24C02	M24C02@MLP8
[(SA724)]	
M24C02@SOIC8 [(SA602A)]	
M24C02R	
M24C02R@MLP8 [(SA724)]	M24C02R@SOIC8
[(SA602A)]	
M24C02R@TSOP8 [(SA026)]	
M24C02W	
M24C02W@MLP8 [(SA724)]	M24C02W@SOIC8
[(SA602A)]	
M24C02W@TSOP8 [(SA026)]	
M24C04	
M24C04@MLP8 [(SA724)]	M24C04@SOIC8
[(SA602A)]	
M24C04R	M24C04R@MLP8
[(SA724)]	
M24C04R@SOIC8 [(SA602A)]	M24C04R@TSOP8
[(SA026)]	
M24C04W	M24C04W@MLP8
[(SA724)]	
M24C04W@SOIC8 [(SA602A)]	M24C04W@TSOP8
[(SA026)]	
M24C08	M24C08@MLP8
[(SA724)]	

M24C08@MSOP8 [(SA695A)]	M24C08@SOIC8
[(SA602A)]	
M24C08@TSOP8 [(SA026)]	
M24C08R	
M24C08R@MLP8 [(SA724)]	M24C08R@MSOP8
[(SA695A)]	
M24C08R@SOIC8 [(SA602A)]	M24C08R@TSOP8
[(SA026)]	
M24C08W	M24C08W@MLP8
[(SA724)]	
M24C08W@MSOP8 [(SA695A)]	M24C08W@SOIC8
[(SA602A)]	
M24C08W@TSOP8 [(SA026)]	M24C128
(BN)	
M24C128(MN)@SOIC8 [(SA605A)]	M24C128(MW)@SOIC8
[(SA602A)]	
M24C128@MLP8 [(SA724)]	M24C128B
(BN)	
M24C128B(MN)@SOIC8 [(SA605A)]	M24C128B(MW)@SOIC8
[(SA602A)]	
M24C128B@MLP8 [(SA724)]	
M24C16	
M24C16@MLP8 [(SA724)]	M24C16@SOIC8
[(SA602A)]	
M24C16R	M24C16R@MLP8
[(SA724)]	
M24C16R@SOIC8 [(SA602A)]	M24C16R@TSOP8
[(SA026)]	
M24C16W	M24C16W@MLP8
[(SA724)]	
M24C16W@SOIC8 [(SA602A)]	M24C16W@TSOP8
[(SA026)]	
M24C256(BN)	M24C256(MN)@SOIC8
[(SA605A)]	
M24C256(MW)@SOIC8 [(SA602A)]	M24C256@MLP8
[(SA724)]	
M24C256A(BN)	M24C256A(MN)@SOIC8
[(SA605A)]	
M24C256A(MW)@SOIC8 [(SA602A)]	M24C256A@MLP8
[(SA724)]	
M24C256B(BN)	M24C256B(MN)@SOIC8
[(SA605A)]	
M24C256B(MW)@SOIC8 [(SA602A)]	M24C256B@MLP8

[ (SA724) ]	
M24C256W(BN)	M24C256W(MN)@SOIC8
[ (SA605A) ]	
M24C256W(MW)@SOIC8 [ (SA602A) ]	M24C256W@MLP8
[ (SA724) ]	
M24C32(BN)	M24C32(DL)@TSSOP14
[ (SA026) ]	
M24C32(DW)@TSSOP8 [ (SA602A) ]	M24C32(MN)@SOIC8
[ (SA605A) ]	
M24C32(MW)@SOIC8 [ (SA602A) ]	M24C32@MLP8
[ (SA724) ]	
M24C32W(BN)	M24C32W(DL)@TSSOP14
[ (SA026) ]	
M24C32W(DW)@TSSOP8 [ (SA602A) ]	M24C32W(MN)@SOIC8
[ (SA605A) ]	
M24C32W(MW)@SOIC8 [ (SA602A) ]	M24C32W@MLP8
[ (SA724) ]	
M24C64(BN)	M24C64(DL)@TSSOP14
[ (SA026) ]	
M24C64(DW)@TSSOP8 [ (SA602A) ]	M24C64(MN)@SOIC8
[ (SA605A) ]	
M24C64(MW)@SOIC8 [ (SA602A) ]	M24C64@MLP8
[ (SA724) ]	
M24C64W(BN)	M24C64W(DL)@TSSOP14
[ (SA026) ]	
M24C64W(DW)@TSSOP8 [ (SA602A) ]	M24C64W(MN)@SOIC8
[ (SA605A) ]	
M24C64W(MW)@SOIC8 [ (SA602A) ]	M24C64W@MLP8
[ (SA724) ]	
M24CL04B	M24CL04B@MLP8
[ (SA724) ]	
M24CL04B@SOIC8 [ (SA602A) ]	M24CL04B@TSOP8
[ (SA026) ]	
M24E16	M24E32
(BN)	
M24E32(DW)@TSSOP8 [ (SA602A) ]	M24E32(MN)@SOIC8
[ (SA605A) ]	
M24E32(MW)@SOIC8 [ (SA602A) ]	
M24W01	
M24W01@SOIC8 [ (SA602A) ]	
M24W02	
M24W02@SOIC8 [ (SA602A) ]	
M24W04	

M24W04@SOIC8 [(SA602A)]  
M24W08  
M24W08@SOIC8 [(SA602A)]  
M24W16  
M24W16@SOIC8 [(SA602A)]  
M25C01  
M25C02  
M25C04  
M25C08  
M25C16  
M25E16 M25P05@SOIC8  
[(SA602A)]  
M25P05@VQFPN8 [(SA683)] M25P05-A@SOIC8  
[(SA602A)]  
M25P05-A@TSSOP8 [(SA605A)] M25P05-A@VDFPN8  
[(SA684)]  
M25P10@SOIC8 [(SA602A)] M25P10@VQFPN8  
[(SA683)]  
M25P10-A@SOIC8 [(SA602A)] M25P10-A@VFQFPN8  
[(SA684)]  
M25P128@SOIC16 [(SA404)]  
M25P128@SOIC16(ISP) [ISP-HEADER01]  
M25P128@VDFPN8 [(SA684)]  
M25P128@VDFPN8(ISP) [ISP-HEADER01]  
M25P16@SOIC16 [(SA404)]  
M25P16@SOIC16(ISP) [ISP-HEADER01]  
M25P16@SOIC8(150mil) [(SA602A)]  
M25P16@SOIC8(150mil)(ISP) [ISP-HEADER01]  
M25P16@SOIC8(200mil) [(SA605A)]  
M25P16@SOIC8(200mil)(ISP) [ISP-HEADER01]  
M25P16@VDFPN8 [(SA684)]  
M25P16@VDFPN8(ISP) [ISP-HEADER01]  
M25P16@VFQFPN8 [(SA683)]  
M25P16@VFQFPN8(ISP) [ISP-HEADER01]  
M25P20@SOIC8 [(SA602A)] M25P20@SOIC8(ISP) [ISP-  
HEADER01]  
M25P20@VFQFPN8 [(SA683)]  
M25P20@VFQFPN8(ISP) [ISP-HEADER01]  
M25P32(Fast Mode)@SOIC16 [(SA404)]  
M25P32(Fast Mode)@VQFPN8 [(SA684)]  
M25P32@SOIC16 [(SA404)]  
M25P32@SOIC16(ISP) [ISP-HEADER01]  
M25P32@SOIC8 [(SA605A)] M25P32@SOIC8(ISP) [ISP-

HEADER01 ]  
M25P32@VDFPN8 [ (SA684) ]  
M25P32@VDFPN8(ISP) [ ISP-HEADER01 ]  
M25P32@VFQFPN8 [ (SA683) ]  
M25P32@VFQFPN8(ISP) [ ISP-HEADER01 ]  
M25P40@SOIC8 [ (SA602A) ] M25P40@SOIC8(ISP) [ ISP-  
HEADER01 ]  
M25P40@VFQFPN8 [ (SA683) ]  
M25P40@VFQFPN8(ISP) [ ISP-HEADER01 ]  
M25P64(Fast Mode)@SOIC16 [ (SA404) ]  
M25P64(Fast Mode)@VDFPN8 [ (SA684) ]  
M25P64@SOIC16 [ (SA404) ]  
M25P64@SOIC16(ISP) [ ISP-HEADER01 ]  
M25P64@VDFPN8 [ (SA684) ]  
M25P64@VDFPN8(ISP) [ ISP-HEADER01 ]  
M25P80@SOIC16 [ (SA404) ]  
M25P80@SOIC16(ISP) [ ISP-HEADER01 ]  
M25P80@SOIC8 [ (SA605A) ] M25P80@SOIC8(ISP) [ ISP-  
HEADER01 ]  
M25P80@VFQFPN8 [ (SA683) ]  
M25P80@VFQFPN8(ISP) [ ISP-HEADER01 ]  
M25PE10@SOIC8 [ (SA602A) ]  
M25PE10@SOIC8(ISP) [ ISP-HEADER01 ]  
M25PE10@VQFPN8 [ (SA683) ]  
M25PE10@VQFPN8(ISP) [ ISP-HEADER01 ]  
M25PE16@SOIC8 [ (SA023A) ] M25PE16@VQFPN8  
[ (SA683) ]  
M25PE20@SOIC8 [ (SA602A) ]  
M25PE20@SOIC8(ISP) [ ISP-HEADER01 ]  
M25PE20@VQFPN8 [ (SA683) ]  
M25PE20@VQFPN8(ISP) [ ISP-HEADER01 ]  
M25PE40@SOIC8 [ (SA023A) ]  
M25PE40@SOIC8(ISP) [ ISP-HEADER01 ]  
M25PE40@VQFPN8 [ (SA683) ]  
M25PE40@VQFPN8(ISP) [ ISP-HEADER01 ]  
M25PE80@SOIC8 [ (SA023A) ]  
M25PE80@SOIC8(ISP) [ ISP-HEADER01 ]  
M25PE80@VQFPN8 [ (SA683) ]  
M25PE80@VQFPN8(ISP) [ ISP-HEADER01 ]  
M25PX32@SOIC16 [ (SA404) ] M25PX32@SOIC8  
[ (SA023A) ]  
M25PX32@VFQFPN8 [ (SA683) ] M25PX64@SOIC16  
[ (SA404) ]

M25PX64@VDFPN8 [ ( SA684 ) ]  
M25W01  
M25W02  
M25W04  
M25W08  
M25W16  
M25W166  
M27128A  
M2716  
M2716F1  
M27256  
M27256A  
M2732A  
M27512  
M2764  
M2764A  
M27C1000 M27C1000@PLCC32  
[ ( SA015A1T ) ]  
M27C1000@TSOP32 [ ( SA410T ) ]  
M27C1001  
M27C1001@PLCC32 [ ( SA015A1T ) ] M27C1001@TSOP32  
[ ( SA410T ) ]  
M27C1024 M27C1024@PLCC44  
[ ( SA244 ) ]  
M27C128B  
M27C16  
M27C160 M27C160@PLCC44  
[ ( SA244 ) ]  
M27C160@PSOP44 [ ( SA638 ) ]  
M27C160K  
M27C160K@PLCC44 [ ( SA244 ) ] M27C160K@PSOP44  
[ ( SA638 ) ]  
M27C2001 M27C2001@PLCC32  
[ ( SA015A1T ) ]  
M27C2001@TSOP32 [ ( SA410T ) ]  
M27C202  
M27C202@PLCC44 [ ( SA244 ) ] M27C202@TSOP40  
[ ( SA409T ) ]  
M27C256B M27C256B@PLCC32  
[ ( SA015A1T ) ]  
M27C32  
M27C322  
M27C322@SDIP42 [ ( SA028 ) ]



M27C400  
M27C4001 M27C4001@PLCC32  
[ (SA015A1T) ]  
M27C4001@TSOP32 [ (SA410T) ]  
M27C4002  
M27C4002@PLCC44 [ (SA244) ]  
M27C405  
M27C405@PLCC32 [ (SA015A1T) ] M27C405@TSOP32  
[ (SA410T) ]  
M27C512 M27C512@PLCC32  
[ (SA015A1T) ]  
M27C513  
M27C516  
M27C516@PLCC44 [ (SA244) ]  
M27C64A  
M27C64A@PLCC32 [ (SA015A1T) ]  
M27C800  
M27C800@PLCC44 [ (SA244) ] M27C800@PSOP44  
[ (SA638) ]  
M27C801 M27C801@PLCC32  
[ (SA015A1T) ]  
M27C801@TSOP32 [ (SA410T) ]  
M27HC641  
M27HC641@PLCC28 [ (SA008A) ]  
M27HC642  
M27HC642@PLCC28 [ (SA008A) ]  
M27V101  
M27V101@PLCC32 [ (SA015A1T) ] M27V101@TSOP32  
[ (SA410T) ]  
M27V102 M27V102@PLCC44  
[ (SA244) ]  
M27V160 M27V160@PLCC44  
[ (SA244) ]  
M27V160@PSOP44 [ (SA638) ]  
M27V160K  
M27V160K@PLCC44 [ (SA244) ] M27V160K@PSOP44  
[ (SA638) ]  
M27V201 M27V201@PLCC32  
[ (SA015A1T) ]  
M27V201@TSOP32 [ (SA410T) ]  
M27V256  
M27V322 M27V322@SDIP42  
[ (SA028) ]

M27V401 [ (SA015A1T) ]	M27V401@PLCC32
M27V401@TSOP32 [ (SA410T) ]	
M27V402 M27V402@PLCC44 [ (SA244) ]	M27V402@TSOP40
[ (SA409T) ]	
M27V405 [ (SA015A1T) ]	M27V405@PLCC32
M27V405@TSOP32 [ (SA410T) ]	
M27V512 M27V512@PLCC32 [ (SA015A1T) ]	M27V512@TSOP28
[ (SA430T) ]	
M27V800 [ (SA244) ]	M27V800@PLCC44
M27V801 [ (SA015A1T) ]	M27V801@PLCC32
M27V801@TSOP32 [ (SA410T) ]	M27W016@PSOP44
[ (SA638) ]	
M27W016@TSOP48 [ (SA247-B005) ]	M27W032@PSOP44
[ (SA638) ]	
M27W032@TSOP48 [ (SA247-B005) ]	M27W064@PSOP44
[ (SA638) ]	
M27W064@TSOP48 [ (SA247-B005) ]	
M27W101 M27W101@PLCC32 [ (SA015A1T) ]	M27W101@TSOP32
[ (SA410T) ]	
M27W102 [ (SA244) ]	M27W102@PLCC44
M27W160 [ (SA244) ]	M27W160@PLCC44
M27W160@PSOP44 [ (SA638) ]	
M27W201 M27W201@PLCC32 [ (SA015A1T) ]	M27W201@TSOP32
[ (SA410T) ]	
M27W202 [ (SA244) ]	M27W202@PLCC44
M27W202@TSOP40 [ (SA409T) ]	
M27W400 M27W400@PLCC44 [ (SA244) ]	
M27W401 M27W401@PLCC32 [ (SA015A1T) ]	M27W401@TSOP32
[ (SA410T) ]	
M27W402	M27W402@PLCC44

[ (SA244) ]	
M27W402@TSOP40 [ (SA409T) ]	
M27W512	
M27W512@PLCC32 [ (SA015A1T) ]	M27W512@TSOP28
[ (SA430T) ]	
M27W800	
[ (SA244) ]	M27W800@PLCC44
M27W801	
[ (SA015A1T) ]	M27W801@PLCC32
M27W801@TSOP32 [ (SA410T) ]	
M28010	
M28010@PLCC32 [ (SA015A1T) ]	M28010@TSOP32
[ (SA410T) ]	
M28010R	
[ (SA015A1T) ]	M28010R@PLCC32
M28010R@TSOP32 [ (SA410T) ]	
M28010W	
M28010W@PLCC32 [ (SA015A1T) ]	M28010W@TSOP32
[ (SA410T) ]	
M28256	
[ (SA015A1T) ]	M28256@PLCC32
M28256@TSOP28 [ (SA430T) ]	
M28C010	
M28C010@PLCC32 [ (SA015A1T) ]	M28C010@TSOP32
[ (SA410T) ]	
M28C010R	
[ (SA015A1T) ]	M28C010R@PLCC32
M28C010R@TSOP32 [ (SA410T) ]	
M28C010W	
M28C010W@PLCC32 [ (SA015A1T) ]	M28C010W@TSOP32
[ (SA410T) ]	
M28C16@PLCC32 [ (SA015A1T) ]	M28C17@SOIC28
[ (SA404) ]	
M28C64	
[ (SA015A1T) ]	M28C64@PLCC32
M28C64@TSOP28 [ (SA430T) ]	
M28C64C	
M28C64C@PLCC32 [ (SA015A1T) ]	M28C64C@SOIC28
[ (SA404) ]	
M28C64C@TSOP28 [ (SA430T) ]	
M28C64X	
M28C64X@PLCC32 [ (SA015A1T) ]	M28C64X@TSOP28
[ (SA430T) ]	

M28F101 [ (SA015A1T) ]	M28F101@PLCC32
M28F101@TSOP32 [ (SA410T) ]	
M28F102 M28F102@PLCC44 [ (SA244) ]	M28F102@TSOP40
[ (SA409T) ]	
M28F151 [ (SA015A1T) ]	M28F151@PLCC32
M28F151@TSOP32 [ (SA410T) ]	
M28F201 M28F201@PLCC32 [ (SA015A1T) ]	M28F201@TSOP32
[ (SA410T) ]	
M28F211@TSOP40 [ (SA409T) ]	M28F220@PSOP44
[ (SA638) ]	
M28F220@TSOP48 [ (SA247-B005) ]	M28F221@TSOP40
[ (SA409T) ]	
M28F256 [ (SA015A1T) ]	M28F256@PLCC32
M28F256@TSOP32 [ (SA410T) ]	M28F411@TSOP40
[ (SA409T) ]	
M28F421@TSOP40 [ (SA409T) ]	
M28F512 M28F512@PLCC32 [ (SA015A1T) ]	M28F512@TSOP32
[ (SA410T) ]	
M28LV64 [ (SA015A1T) ]	M28LV64@PLCC32
M28LV64@TSOP28 [ (SA430T) ]	
M28R400CB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28R400CT@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28V411@TSOP40 [ (SA409T) ]	M28V421@TSOP40
[ (SA409T) ]	
M28W160B@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160B@TSOP48 [ (SA247-B005) ]	
M28W160BB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160BB@TSOP48 [ (SA247-B005) ]	
M28W160BT@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160BT@TSOP48 [ (SA247-B005) ]	
M28W160CB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160CB@TSOP48 [ (SA247-B005) ]	
M28W160CT@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160CT@TSOP48 [ (SA247-B005) ]	
M28W160ECB@FBGA48 [ (SA634A-B005A-Y048F001Y) ]	
M28W160ECB@TSOP48 [ (SA247-B005) ]	

M28W160ECT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W160ECT@TSOP48 [ ( SA247-B005 ) ]  
M28W160T@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W160T@TSOP48 [ ( SA247-B005 ) ]  
M28W320CB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W320CB@TSOP48 [ ( SA247-B005 ) ]  
M28W320CT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W320CT@TSOP48 [ ( SA247-B005 ) ]  
M28W320ECB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W320ECB@TSOP48 [ ( SA247-B005 ) ]  
M28W320ECT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W320ECT@TSOP48 [ ( SA247-B005 ) ]  
M28W320FCB@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W320FCB@TSOP48 [ ( SA247-B005 ) ]  
M28W320FCT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W320FCT@TSOP48 [ ( SA247-B005 ) ]  
M28W320FSB@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320FSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320FST@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320FST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320FSU(Double)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320FSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HSB@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HST@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HSU(Double)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HSU@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640ECB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W640ECB@TSOP48 [ ( SA247-B005 ) ]  
M28W640ECT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W640ECT@TSOP48 [ ( SA247-B005 ) ]  
M28W640FCB@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W640FCB@TSOP48 [ ( SA247-B005 ) ]  
M28W640FCT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W640FCT@TSOP48 [ ( SA247-B005 ) ]  
M28W640FSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640FST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640FSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HSB@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640HSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HST@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]

M28W640HST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HSU@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640HSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W800B@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800B@TSOP48 [ ( SA247-B005 ) ]  
M28W800BB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800BB@TSOP48 [ ( SA247-B005 ) ]  
M28W800BT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800BT@TSOP48 [ ( SA247-B005 ) ]  
M28W800CB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800CB@TSOP48 [ ( SA247-B005 ) ]  
M28W800CT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800CT@TSOP48 [ ( SA247-B005 ) ]  
M28W800T@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800T@TSOP48 [ ( SA247-B005 ) ]  
M29DW128F@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29DW128F@TSOP56 [ ( SA628-B102 ) ]  
M29DW323DB@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DB@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DB@TSOP48 [ ( SA247-B005 ) ]  
M29DW323DT@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DT@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DT@TSOP48 [ ( SA247-B005 ) ]  
M29DW324DB@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW324DB@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW324DB@TSOP48 [ ( SA247-B005 ) ]  
M29DW324DT@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW324DT@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW324DT@TSOP48 [ ( SA247-B005 ) ]  
M29DW640D@FBGA63 [ ( SA642E-B026A-T072F001N ) ]  
M29DW640D@TSOP48 [ ( SA247-B005 ) ]  
M29DW640F@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29DW640F@TSOP48 [ ( SA247-B005 ) ]  
M29DW641F@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29DW641F@TSOP48 [ ( SA247-B005 ) ]  
M29F002B  
M29F002B@PLCC32 [ ( SA015A1T ) ]                      M29F002B@TSOP32  
[ ( SA410T ) ]  
M29F002BB    M29F002BB@PLCC32  
[ ( SA015A1T ) ]  
M29F002BB@TSOP32 [ ( SA410T ) ]  
M29F002BNT  
M29F002BNT@PLCC32 [ ( SA015A1T ) ]                      M29F002BNT@TSOP32

[ (SA410T) ]	
M29F002BT	M29F002BT@PLCC32
[ (SA015A1T) ]	
M29F002BT@TSOP32 [ (SA410T) ]	
M29F002T	
M29F002T@PLCC32 [ (SA015A1T) ]	M29F002T@TSOP32
[ (SA410T) ]	
M29F010B	M29F010B@PLCC32
[ (SA015A1T) ]	
M29F010B@TSOP32 [ (SA410T) ]	M29F016B@PSOP44
[ (SA638) ]	
M29F016B@TSOP40 [ (SA409T) ]	M29F016D@PSOP44
[ (SA638) ]	
M29F016D@TSOP40 [ (SA409T) ]	M29F032D@TSOP40
[ (SA409T) ]	
M29F040	M29F040@PLCC32
[ (SA015A1T) ]	
M29F040@TSOP32 [ (SA410T) ]	
M29F040B	
M29F040B@PLCC32 [ (SA015A1T) ]	M29F040B@TSOP32
[ (SA410T) ]	
M29F080A@PSOP44 [ (SA638) ]	M29F080A@TSOP40
[ (SA409T) ]	
M29F080D@PSOP44 [ (SA638) ]	M29F080D@TSOP40
[ (SA409T) ]	
M29F100B@PSOP44 [ (SA638-B006) ]	M29F100B@TSOP48 [ (SA247-
B005) ]	
M29F100T@PSOP44 [ (SA638-B006) ]	M29F100T@TSOP48 [ (SA247-
B005) ]	
M29F102B@PLCC44 [ (SA244) ]	M29F102B@TSOP40
[ (SA623) ]	
M29F102BB@PLCC44 [ (SA244) ]	M29F102BB@TSOP40
[ (SA623) ]	
M29F160BB@TSOP48 [ (SA247-B005) ]	M29F160BT@TSOP48 [ (SA247-
B005) ]	
M29F200B@PSOP44 [ (SA638-B006) ]	M29F200B@TSOP48 [ (SA247-
B005) ]	
M29F200BB@PSOP44 [ (SA638-B006) ]	M29F200BB@TSOP48 [ (SA247-
B005) ]	
M29F200BT@PSOP44 [ (SA638-B006) ]	M29F200BT@TSOP48 [ (SA247-
B005) ]	
M29F200T@PSOP44 [ (SA638-B006) ]	M29F200T@TSOP48 [ (SA247-
B005) ]	

M29F400B@PSOP44 [(SA638-B006)] B005]	M29F400B@TSOP48 [(SA247-
M29F400BB@PSOP44 [(SA638-B006)] B005]	M29F400BB@TSOP48 [(SA247-
M29F400BT@PSOP44 [(SA638-B006)] B005]	M29F400BT@TSOP48 [(SA247-
M29F400T@PSOP44 [(SA638-B006)] B005]	M29F400T@TSOP48 [(SA247-
M29F512B@PLCC32 [(SA015A1T)] [(SA620)]	M29F512B@TSOP32
M29F800AB@PSOP44 [(SA638-B006)] B005]	M29F800AB@TSOP48 [(SA247-
M29F800AT@PSOP44 [(SA638-B006)] B005]	M29F800AT@TSOP48 [(SA247-
M29F800DB@PSOP44 [(SA638)] B005]	M29F800DB@TSOP48 [(SA247-
M29F800DT@PSOP44 [(SA638)] B005]	M29F800DT@TSOP48 [(SA247-
M29KW016E@PSOP44 [(SA638)]	
M29KW016E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW016E@TSOP48 [(SA247-B005)]	
M29KW032E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW032E@TSOP48 [(SA247-B005)]	
M29KW064E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW064E@TSOP48 [(SA247-B005)]	M29V040@PLCC32
[(SA015A1T)]	
M29V040@TSOP32 [(SA410T)] [(SA409T)]	M29W004B@TSOP40
M29W004BB@TSOP40 [(SA409T)] [(SA409T)]	M29W004BT@TSOP40
M29W004T@TSOP40 [(SA409T)] [(SA409T)]	M29W008AB@TSOP40
M29W008AT@TSOP40 [(SA409T)] [(SA409T)]	M29W008B@TSOP40
M29W008T@TSOP40 [(SA409T)] [(SA015A1T)]	M29W010B@PLCC32
M29W010B@TSOP32 [(SA410T)]	
M29W017D@TFBGA48 [(SA642B-B026A-Y072F001)]	
M29W017D@TSOP40 [(SA409T)]	
M29W022BB	
M29W022BB@PLCC32 [(SA015A1T)] [(SA410T)]	M29W022BB@TSOP32
M29W022BT	M29W022BT@PLCC32



[ ( SA015A1T ) ]  
 M29W022BT@TSOP32 [ ( SA410T ) ] M29W040@PLCC32  
 [ ( SA015A1T ) ]  
 M29W040@TSOP32 [ ( SA410T ) ] M29W040B@PLCC32  
 [ ( SA015A1T ) ]  
 M29W040B@TSOP32 [ ( SA410T ) ] M29W102BB@TSOP40  
 [ ( SA623 ) ]  
 M29W102BT@TSOP40 [ ( SA623 ) ] M29W116BB@TSOP40  
 [ ( SA409T ) ]  
 M29W116BT@TSOP40 [ ( SA409T ) ]  
 M29W128FH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
 M29W128FH@TSOP56 [ ( SA628-B102 ) ]  
 M29W128FL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
 M29W128FL@TSOP56 [ ( SA628-B102 ) ]  
 M29W128GH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
 M29W128GH@TSOP56 [ ( SA628-B102 ) ]  
 M29W128GL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
 M29W128GL@TSOP56 [ ( SA628-B102 ) ]  
 M29W128GSH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
 M29W128GSH@TSOP56 [ ( SA628-B102 ) ]  
 M29W128GSL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
 M29W128GSL@TSOP56 [ ( SA628-B102 ) ]  
 M29W160BB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W160BB@PSOP44 [ ( SA638 ) ] M29W160BB@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W160BT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W160BT@PSOP44 [ ( SA638 ) ] M29W160BT@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W160DB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W160DB@PSOP44 [ ( SA638 ) ] M29W160DB@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W160DT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W160DT@PSOP44 [ ( SA638 ) ] M29W160DT@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W160EB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W160EB@LBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
 M29W160EB@PSOP44 [ ( SA638 ) ] M29W160EB@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W160ET@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W160ET@LBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
 M29W160ET@PSOP44 [ ( SA638 ) ] M29W160ET@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W160FB@TSOP48 [ ( SA247-B005 ) ] M29W160FT@TSOP48 [ ( SA247-

B005) ]  
 M29W200BB@PSOP44 [ ( SA638 ) ] M29W200BB@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W200BT@PSOP44 [ ( SA638 ) ] M29W200BT@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W320DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W320DB@FBGA63 [ ( SA642DD-B026A-W063F001Y ) ]  
 M29W320DB@TSOP48 [ ( SA247-B005 ) ]  
 M29W320DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W320DT@FBGA63 [ ( SA642DD-B026A-W063F001Y ) ]  
 M29W320DT@TSOP48 [ ( SA247-B005 ) ]  
 M29W320EB@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 M29W320EB@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
 M29W320EB@TSOP48 [ ( SA247-B005 ) ]  
 M29W320ET@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 M29W320ET@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
 M29W320ET@TSOP48 [ ( SA247-B005 ) ] M29W400B@PSOP44  
 [ ( SA638 ) ]  
 M29W400B@TSOP48 [ ( SA247-B005 ) ]  
 M29W400BB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W400BB@PSOP44 [ ( SA638 ) ] M29W400BB@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W400BT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W400BT@PSOP44 [ ( SA638 ) ] M29W400BT@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W400DB( ZA )@LBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 M29W400DB( ZE )@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W400DB@PSOP44 [ ( SA638 ) ] M29W400DB@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W400DT( ZA )@LBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 M29W400DT( ZE )@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W400DT@PSOP44 [ ( SA638 ) ] M29W400DT@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W400T@PSOP44 [ ( SA638 ) ] M29W400T@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W512B@PLCC32 [ ( SA015A1T ) ] M29W512B@TSOP32  
 [ ( SA620 ) ]  
 M29W640DB@FBGA63 [ ( SA642E-B026A-T072F001 ) ]  
 M29W640DB@TSOP48 [ ( SA247-B005 ) ]  
 M29W640DT@FBGA63 [ ( SA642E-B026A-T072F001 ) ]  
 M29W640DT@TSOP48 [ ( SA247-B005 ) ]  
 M29W640FB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W640FB@TSOP48 [ ( SA247-B005 ) ]

M29W640FT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640FT@TSOP48 [ ( SA247-B005 ) ]  
M29W640GB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GB@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GB@TSOP48 [ ( SA247-B005 ) ] M29W640GB@TSOP56 [ ( SA628-B102 ) ]  
M29W640GH@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GH@TSOP48 [ ( SA247-B005 ) ] M29W640GH@TSOP56 [ ( SA628-B102 ) ]  
M29W640GL@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GL@TSOP48 [ ( SA247-B005 ) ] M29W640GL@TSOP56 [ ( SA628-B102 ) ]  
M29W640GSB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GSB@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GSB@TSOP48 [ ( SA247-B005 ) ] M29W640GSB@TSOP56 [ ( SA628-B102 ) ]  
M29W640GSH@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GSH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GSH@TSOP48 [ ( SA247-B005 ) ] M29W640GSH@TSOP56 [ ( SA628-B102 ) ]  
M29W640GSL@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GSL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GSL@TSOP48 [ ( SA247-B005 ) ] M29W640GSL@TSOP56 [ ( SA628-B102 ) ]  
M29W640GST@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GST@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GST@TSOP48 [ ( SA247-B005 ) ] M29W640GST@TSOP56 [ ( SA628-B102 ) ]  
M29W640GT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GT@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GT@TSOP48 [ ( SA247-B005 ) ] M29W640GT@TSOP56 [ ( SA628-B102 ) ]  
M29W641DH@TSOP48 [ ( SA247-B005 ) ] M29W641DL@TSOP48 [ ( SA247-B005 ) ]  
M29W641DU@FBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29W800AB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W800AB@PSOP44 [ ( SA638 ) ] M29W800AB@TSOP48 [ ( SA247-B005 ) ]  
M29W800AT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W800AT@PSOP44 [ ( SA638 ) ] M29W800AT@TSOP48 [ ( SA247-B005 ) ]

M29W800B@PSOP44 [(SA638)] M29W800B@TSOP48 [(SA247-B005)]  
M29W800DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800DB@PSOP44 [(SA638)] M29W800DB@TSOP48 [(SA247-B005)]  
M29W800DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800DT@PSOP44 [(SA638)] M29W800DT@TSOP48 [(SA247-B005)]  
M29W800T@PSOP44 [(SA638)] M29W800T@TSOP48 [(SA247-B005)]  
M30L0R7000B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R7000T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R8000B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R8000T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30W0R6600T0@LFBGA88 [(SA642A-B061A-Y096F001)]  
M30WR128B@LFBGA88 [(SA642A-B061A-Y096F001)]  
M34C02 M34C02@MSOP8  
[(SA666)]  
M34C02@SOIC8 [(SA602A)] M34C02@TSOP8  
[(SA026)]  
M34D32 M34D32@SOIC8  
[(SA602A)]  
M34D32@TSSOP8 [(SA026)]  
M34D64 M34D64@TSSOP8  
M34D64@SOIC8 [(SA602A)]  
[(SA026)]  
M34E02 M34E02@MSOP8  
[(SA666)]  
M34E02@SOIC8 [(SA602A)] M34E02@TSOP8  
[(SA026)]  
M35080 M35080@SOIC8  
[(SA602A)]  
M36A0W5020B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5020T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5030B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5030T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040B1@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040T1@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36D0R5030B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030B0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]

M36D0R5030T0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040B0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040T0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R6040B0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040B0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36DR232A@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR232B@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432AD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432BD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36L0R7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B2@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T2@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050B3@FBGA88 [(SA642R-B124A-T096F001Y)]

M36L0T8050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050T3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36LLR8760B1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760D1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760M1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760T1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860B1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860D1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860M1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860T1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870B0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870B1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870D0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870D1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870M0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870M1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870T0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870T1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36W0R5020B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040B5@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0R5040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040T5@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0R5040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040U4@TFBGA88 [(SA642R-B180-T096F001Y)]

M36W0R5040U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B3@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T3@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040U4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050B1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050B3@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050L0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T3@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050U0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050U4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0T5040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T5040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B3@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T3@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6050B3@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6050T3@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36W0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]

M36W216BI@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W216TI@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W432BG@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W432TG@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W864BE@LFBGA67 [(SA642E-B041A-T072F001)]  
M36W864TE@LFBGA67 [(SA642E-B041A-T072F001)]  
M36WWR6650B0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M36WWR6650D0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M36WWR6650T0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M45PE10@SOIC8 [(SA602A)] M45PE10@VQFPN8  
[(SA683)]  
M45PE16@SOIC8 [(SA023A)] M45PE16@VQFPN8  
[(SA683)]  
M45PE20@SOIC8 [(SA602A)]  
M45PE20@SOIC8(ISP) [ISP-HEADER01]  
M45PE20@VQFPN8 [(SA683)]  
M45PE20@VQFPN8(ISP) [ISP-HEADER01]  
M45PE40@SOIC8 [(SA023A)]  
M45PE40@SOIC8(ISP) [ISP-HEADER01]  
M45PE40@VQFPN8 [(SA683)]  
M45PE40@VQFPN8(ISP) [ISP-HEADER01]  
M45PE80@SOIC16 [(SA023A)]  
M45PE80@SOIC16(ISP) [ISP-HEADER01]  
M45PE80@SOIC8 [(SA023A)]  
M45PE80@SOIC8(ISP) [ISP-HEADER01]  
M45PE80@VQFPN8 [(SA683)]  
M45PE80@VQFPN8(ISP) [ISP-HEADER01]  
M48C02  
M48C02B  
M48C12  
M48C12B  
M48T02  
M48T02B  
M48T08  
M48T12  
M48T128V  
M48T128Y  
M48T129V  
M48T129Y  
M48T12B  
M48T18  
M48T30  
M48T30Y



M48T32	
M48T32Y	
M48T35	M48T35@SOIC28
[ ( SA404 ) ]	
M48T35AV	M48T35AV@SOIC28
[ ( SA630 ) ]	
M48T35AY	M48T35AY@SOIC28
[ ( SA630 ) ]	
M48T35Y	M48T35Y@SOIC28
[ ( SA404 ) ]	
M48T512AV	
M48T512AY	
M48T512V	
M48T512Y	
M48T513V	
M48T513Y	
M48T559	M48T559@SOIC28
[ ( SA630 ) ]	
M48T559Y	M48T559Y@SOIC28
[ ( SA630 ) ]	
M48T58	M48T58@SOIC28
[ ( SA404 ) ]	
M48T58Y	M48T58Y@SOIC28
[ ( SA404 ) ]	
M48T59	M48T59@SOIC28
[ ( SA404 ) ]	
M48T59V	M48T59V@SOIC28
[ ( SA404 ) ]	
M48T59Y	M48T59Y@SOIC28
[ ( SA404 ) ]	
M48Z02	
M48Z02B	
M48Z08	
M48Z09	
M48Z12	
M48Z128	
M48Z128V	
M48Z128Y	
M48Z129V	
M48Z129Y	
M48Z12B	
M48Z18	
M48Z19	

M48Z30	
M48Z30Y	
M48Z32	
M48Z32Y	
M48Z35	
M48Z35@SOIC28 [(SA630)]	
M48Z35Y	
M48Z35Y@SOIC28 [(SA630)]	
M48Z512AV	
M48Z512AY	
M48Z512V	
M48Z512Y	
M48Z513V	
M48Z513Y	
M48Z58	
M48Z58@SOIC28 [(SA404)]	
M48Z58Y	
M48Z58Y@SOIC28 [(SA404)]	
M48Z59	
M48Z59@SOIC28 [(SA404)]	
M48Z59W	
M48Z59W@SOIC28 [(SA404)]	
M48Z59Y	
M48Z59Y@SOIC28 [(SA404)]	M50FLW040A@PLCC32
[(SA015A1T)]	
M50FLW040A@TSOP40 [(SA409T)]	M50FLW040A@VSOP32
[(SA620)]	
M50FLW040B@PLCC32 [(SA015A1T)]	M50FLW040B@TSOP40
[(SA409T)]	
M50FLW040B@VSOP32 [(SA620)]	M50FLW080A@PLCC32
[(SA015A1T)]	
M50FLW080A@TSOP40 [(SA409T)]	M50FLW080A@VSOP32
[(SA620)]	
M50FLW080B@PLCC32 [(SA015A1T)]	M50FLW080B@TSOP40
[(SA409T)]	
M50FLW080B@VSOP32 [(SA620)]	M50FW002@PLCC32
[(SA015A1T)]	
M50FW016@TSOP40 [(SA409T)]	M50FW020@PLCC32
[(SA015A1T)]	
M50FW040@PLCC32 [(SA015A1T)]	M50FW040@TSOP40
[(SA409T)]	
M50FW080@PLCC32 [(SA015A1T)]	M50FW080@TSOP40
[(SA409T)]	

M50FW080@VSOP32 [ (SA620) ] M50LPW002@PLCC32  
[ (SA015A1T) ]  
M50LPW012@PLCC32 [ (SA015A1T) ] M50LPW020@PLCC32  
[ (SA015A1T) ]  
M50LPW040@PLCC32 [ (SA015A1T) ] M50LPW040@TSOP40  
[ (SA409T) ]  
M50LPW041@PLCC32 [ (SA015A1T) ] M50LPW041@TSOP40  
[ (SA409T) ]  
M50LPW080@PLCC32 [ (SA015A1T) ] M50LPW080@TSOP40  
[ (SA409T) ]  
M50LPW116@TSOP40 [ (SA409T) ]  
M58LR128FB@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
M58LR128FT@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
M58LR128GB@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
M58LR128GT@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
M58LT128GB@FBGA56 [ (SA644A-B025B-Y072F001Y) ]  
M58LT128GSB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT128GST@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT128GT@FBGA56 [ (SA644A-B025B-Y072F001Y) ]  
M58LT256GB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT256GT@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT256JSB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT256JST@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LW032A@TSOP56 [ (SA628-B031) ]  
M58LW032C@FBGA64 [ (SA655A-B054A-T064F001) ]  
M58LW032C@TSOP56 [ (SA628-B031) ]  
M58LW032D@FBGA64 [ (SA655A-B054A-T064F001) ]  
M58LW032D@TSOP56 [ (SA628-B018) ]  
M58LW064C@FBGA64 [ (SA655A-B054A-T064F001) ]  
M58LW064C@TSOP56 [ (SA628-B063) ]  
M58LW064D@FBGA64 [ (SA655A-B054A-T064F001) ]  
M58LW064D@TSOP56 [ (SA628-B018) ] M58LW128A@TSOP56 [ (SA628-  
B018) ]  
M58WR016QB(EFP)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR016QB(Q\_Word)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR016QL@FBGA44 [ (SA733A-B206A-M056F001N) ]  
M58WR016QT(EFP)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR016QT(Q\_Word)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR016QU@FBGA44 [ (SA733A-B206A-M056F001N) ]  
M58WR032EB(EFP)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032EB(Q\_Word)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032ET(EFP)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032ET(Q\_Word)@FBGA56 [ (SA644A-B025B-Y072F001) ]

M58WR032FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QB(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QL@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR032QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QT(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QU@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR064EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064EB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR064HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR128FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M59DR008E@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008E@TSOP48 [(SA247-B005)]  
M59DR008F@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008F@TSOP48 [(SA247-B005)]  
M59DR016C@FBGA48 [(SA634A-B005A-Y048N001N)]  
M59DR016D@FBGA48 [(SA634A-B005A-Y048N001N)]  
M59PW016@PSOP44 [(SA638)] M59PW016@SDIP42  
[(SA028)]  
M59PW016@TSOP48 [(SA247-B005)] M59PW032@PSOP44  
[(SA638)]  
M59PW032@PSOP44(Fast) [(SA638+B006)]  
M59PW032@TSOP48 [(SA247-B005)] M59PW064@PSOP44  
[(SA638)]  
M59PW1282@PSOP44 [(SA638)]  
M72DW64000B@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M72DW75000C@FBGA73 [(SA642A-B039A-Y096F001Y)]  
M72DW75001C@FBGA73 [(SA642A-B032A-Y096F001Y)]

M72DW76001D@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW52003BA@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW52003TA@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW52004BA@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW52004TA@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW62000A@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW63000A@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M87C257	M87C257@PLCC32
[(SA015A1T)]	
M93C06(08bit)	M93C06(08bit)@SOIC8
[(SA602A)]	
M93C06(16bit)	M93C06(16bit)@SOIC8
[(SA602A)]	
M93C46(08bit)	M93C46(08bit)@MLP8
[(SA694)]	
M93C46(08bit)@MSOP8 [(SA666)]	M93C46(08bit)@SOIC8
[(SA602A)]	
M93C46(08bit)@TSSOP8 [(SA026)]	M93C46
(16bit)	
M93C46(16bit)@MLP8 [(SA694)]	M93C46(16bit)@MSOP8
[(SA666)]	
M93C46(16bit)@SOIC8 [(SA602A)]	M93C46(16bit)@TSSOP8
[(SA026)]	
M93C46R(08bit)	M93C46R(08bit)@MLP8
[(SA694)]	
M93C46R(08bit)@MSOP8 [(SA666)]	M93C46R(08bit)@SOIC8
[(SA602A)]	
M93C46R(08bit)@TSSOP8 [(SA026)]	M93C46R
(16bit)	
M93C46R(16bit)@MLP8 [(SA694)]	M93C46R(16bit)@MSOP8
[(SA666)]	
M93C46R(16bit)@SOIC8 [(SA602A)]	M93C46R(16bit)@TSSOP8
[(SA026)]	
M93C46W(08bit)	M93C46W(08bit)@MLP8
[(SA694)]	
M93C46W(08bit)@MSOP8 [(SA666)]	M93C46W(08bit)@SOIC8
[(SA602A)]	
M93C46W(08bit)@TSSOP8 [(SA026)]	M93C46W
(16bit)	
M93C46W(16bit)@MLP8 [(SA694)]	M93C46W(16bit)@MSOP8
[(SA666)]	
M93C46W(16bit)@SOIC8 [(SA602A)]	M93C46W(16bit)@TSSOP8
[(SA026)]	

M93C56(08bit) [(SA694)]	M93C56(08bit)@MLP8
M93C56(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C56(08bit)@SOIC8
M93C56(08bit)@TSSOP8 [(SA026)] (16bit)	M93C56
M93C56(16bit)@MLP8 [(SA694)] [(SA666)]	M93C56(16bit)@MSOP8
M93C56(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C56(16bit)@TSSOP8
M93C56R(08bit) [(SA694)]	M93C56R(08bit)@MLP8
M93C56R(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C56R(08bit)@SOIC8
M93C56R(08bit)@TSSOP8 [(SA026)] (16bit)	M93C56R
M93C56R(16bit)@MLP8 [(SA694)] [(SA666)]	M93C56R(16bit)@MSOP8
M93C56R(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C56R(16bit)@TSSOP8
M93C56W(08bit) [(SA694)]	M93C56W(08bit)@MLP8
M93C56W(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C56W(08bit)@SOIC8
M93C56W(08bit)@TSSOP8 [(SA026)] (16bit)	M93C56W
M93C56W(16bit)@MLP8 [(SA694)] [(SA666)]	M93C56W(16bit)@MSOP8
M93C56W(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C56W(16bit)@TSSOP8
M93C66(08bit) [(SA694)]	M93C66(08bit)@MLP8
M93C66(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C66(08bit)@SOIC8
M93C66(08bit)@TSSOP8 [(SA026)] (16bit)	M93C66
M93C66(16bit)@MLP8 [(SA694)] [(SA666)]	M93C66(16bit)@MSOP8
M93C66(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C66(16bit)@TSSOP8
M93C66R(08bit) [(SA694)]	M93C66R(08bit)@MLP8
M93C66R(08bit)@MSOP8 [(SA666)]	M93C66R(08bit)@SOIC8

[ (SA602A) ]

M93C66R(08bit)@TSSOP8 [ (SA026) ]  
(16bit)

M93C66R

M93C66R(16bit)@MLP8 [ (SA694) ]  
[ (SA666) ]

M93C66R(16bit)@MSOP8

M93C66R(16bit)@SOIC8 [ (SA602A) ]  
[ (SA026) ]

M93C66R(16bit)@TSSOP8

M93C66W(08bit)  
[ (SA694) ]

M93C66W(08bit)@MLP8

M93C66W(08bit)@MSOP8 [ (SA666) ]  
[ (SA602A) ]

M93C66W(08bit)@SOIC8

M93C66W(08bit)@TSSOP8 [ (SA026) ]  
(16bit)

M93C66W

M93C66W(16bit)@MLP8 [ (SA694) ]  
[ (SA666) ]

M93C66W(16bit)@MSOP8

M93C66W(16bit)@SOIC8 [ (SA602A) ]  
[ (SA026) ]

M93C66W(16bit)@TSSOP8

M93C76(08bit)  
[ (SA694) ]

M93C76(08bit)@MLP8

M93C76(08bit)@MSOP8 [ (SA666) ]  
[ (SA602A) ]

M93C76(08bit)@SOIC8

M93C76(08bit)@TSSOP8 [ (SA026) ]  
(16bit)

M93C76

M93C76(16bit)@MLP8 [ (SA694) ]  
[ (SA666) ]

M93C76(16bit)@MSOP8

M93C76(16bit)@SOIC8 [ (SA602A) ]  
[ (SA026) ]

M93C76(16bit)@TSSOP8

M93C76R(08bit)  
[ (SA694) ]

M93C76R(08bit)@MLP8

M93C76R(08bit)@MSOP8 [ (SA666) ]  
[ (SA602A) ]

M93C76R(08bit)@SOIC8

M93C76R(08bit)@TSSOP8 [ (SA026) ]  
(16bit)

M93C76R

M93C76R(16bit)@MLP8 [ (SA694) ]  
[ (SA666) ]

M93C76R(16bit)@MSOP8

M93C76R(16bit)@SOIC8 [ (SA602A) ]  
[ (SA026) ]

M93C76R(16bit)@TSSOP8

M93C76W(08bit)  
[ (SA694) ]

M93C76W(08bit)@MLP8

M93C76W(08bit)@MSOP8 [ (SA666) ]  
[ (SA602A) ]

M93C76W(08bit)@SOIC8

M93C76W(08bit)@TSSOP8 [ (SA026) ]  
(16bit)

M93C76W

M93C76W(16bit)@MLP8 [(SA694)] [(SA666)]	M93C76W(16bit)@MSOP8
M93C76W(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C76W(16bit)@TSSOP8
M93C86(08bit) [(SA694)]	M93C86(08bit)@MLP8
M93C86(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C86(08bit)@SOIC8
M93C86(08bit)@TSSOP8 [(SA026)] (16bit)	M93C86
M93C86(16bit)@MLP8 [(SA694)] [(SA666)]	M93C86(16bit)@MSOP8
M93C86(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C86(16bit)@TSSOP8
M93C86R(08bit) [(SA694)]	M93C86R(08bit)@MLP8
M93C86R(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C86R(08bit)@SOIC8
M93C86R(08bit)@TSSOP8 [(SA026)] (16bit)	M93C86R
M93C86R(16bit)@MLP8 [(SA694)] [(SA666)]	M93C86R(16bit)@MSOP8
M93C86R(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C86R(16bit)@TSSOP8
M93C86W(08bit) [(SA694)]	M93C86W(08bit)@MLP8
M93C86W(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C86W(08bit)@SOIC8
M93C86W(08bit)@TSSOP8 [(SA026)] (16bit)	M93C86W
M93C86W(16bit)@MLP8 [(SA694)] [(SA666)]	M93C86W(16bit)@MSOP8
M93C86W(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C86W(16bit)@TSSOP8
M93CS566 [(SA602A)]	M93CS566@SOIC8
M93S46 [(SA602A)]	M93S46@SOIC8
M93S46@TSSOP8 [(SA026)]	
M93S46R	
M93S46R@SOIC8 [(SA602A)] [(SA026)]	M93S46R@TSSOP8
M93S46W	M93S46W@SOIC8



[ (SA602A) ]	
M93S46W@TSSOP8 [ (SA026) ]	
M93S56	
M93S56@SOIC8 [ (SA602A) ]	M93S56@TSSOP8
[ (SA026) ]	
M93S56R	
M93S56R@SOIC8 [ (SA602A) ]	M93S56R@SOIC8
[ (SA026) ]	
M93S56R@TSSOP8 [ (SA026) ]	
M93S56W	
M93S56W@SOIC8 [ (SA602A) ]	M93S56W@TSSOP8
[ (SA026) ]	
M93S66	
M93S66@SOIC8 [ (SA602A) ]	M93S66@SOIC8
[ (SA026) ]	
M93S66@TSSOP8 [ (SA026) ]	
M93S66R	
M93S66R@SOIC8 [ (SA602A) ]	M93S66R@TSSOP8
[ (SA026) ]	
M93S66W	
M93S66W@SOIC8 [ (SA602A) ]	M93S66W@SOIC8
[ (SA026) ]	
M95010	
M95010(ISP) [ ISP-HEADER01 ]	M95010@SOIC8
[ (SA602A) ]	
M95010@SOIC8(ISP) [ ISP-HEADER01 ]	M95010@TSSOP8
[ (SA026) ]	
M95010@TSSOP8(ISP) [ ISP-HEADER01 ]	
M95020	
M95020@SOIC8 [ (SA602A) ]	M95020(ISP) [ ISP-
HEADER01 ]	
M95020@TSSOP8 [ (SA026) ]	M95020@SOIC8(ISP) [ ISP-
M95020@TSSOP8(ISP) [ ISP-HEADER01 ]	HEADER01 ]
M95040	
M95040@SOIC8 [ (SA602A) ]	M95040(ISP) [ ISP-
HEADER01 ]	
M95040@TSSOP8 [ (SA026) ]	M95040@SOIC8(ISP) [ ISP-
M95040@TSSOP8(ISP) [ ISP-HEADER01 ]	HEADER01 ]
M95080	
M95080@SOIC8 [ (SA602A) ]	M95080(ISP) [ ISP-
HEADER01 ]	
M95080@TSSOP14 [ (SA026) ]	M95080@SOIC8(ISP) [ ISP-
	HEADER01 ]

M95080@TSSOP14( ISP) [ ISP-HEADER01 ]  
M95080@TSSOP8 [ (SA026) ]  
M95080@TSSOP8( ISP) [ ISP-HEADER01 ]  
M95128 M95128( ISP) [ ISP-  
HEADER01 ]  
M95128@TSSOP14 [ (SA026) ]  
M95128@TSSOP14( ISP) [ ISP-HEADER01 ]  
M95128@TSSOP8 [ (SA026) ]  
M95128@TSSOP8( ISP) [ ISP-HEADER01 ]  
M95128[150mil]@SOIC8 [ (SA602A) ]  
M95128[150mil]@SOIC8( ISP) [ ISP-HEADER01 ]  
M95128[200mil]@SOIC8 [ (SA023A) ]  
M95128[200mil]@SOIC8( ISP) [ ISP-HEADER01 ]  
M95160 M95160( ISP) [ ISP-  
HEADER01 ]  
M95160@SOIC8 [ (SA602A) ] M95160@SOIC8( ISP) [ ISP-  
HEADER01 ]  
M95160@TSSOP14 [ (SA026) ]  
M95160@TSSOP14( ISP) [ ISP-HEADER01 ]  
M95160@TSSOP8 [ (SA026) ]  
M95160@TSSOP8( ISP) [ ISP-HEADER01 ]  
M95256 M95256( ISP) [ ISP-  
HEADER01 ]  
M95256@TSSOP14 [ (SA026) ]  
M95256@TSSOP14( ISP) [ ISP-HEADER01 ]  
M95256@TSSOP8 [ (SA026) ]  
M95256@TSSOP8( ISP) [ ISP-HEADER01 ]  
M95256[150mil]@SOIC8 [ (SA602A) ]  
M95256[150mil]@SOIC8( ISP) [ ISP-HEADER01 ]  
M95256[200mil]@SOIC8 [ (SA023A) ]  
M95256[200mil]@SOIC8( ISP) [ ISP-HEADER01 ]  
M95320 M95320( ISP) [ ISP-  
HEADER01 ]  
M95320@SOIC8 [ (SA602A) ] M95320@SOIC8( ISP) [ ISP-  
HEADER01 ]  
M95320@TSSOP14 [ (SA026) ]  
M95320@TSSOP14( ISP) [ ISP-HEADER01 ]  
M95320@TSSOP8 [ (SA026) ]  
M95320@TSSOP8( ISP) [ ISP-HEADER01 ]  
M95512@SOIC8 [ (SA602A) ] M95512@SOIC8( ISP) [ ISP-  
HEADER01 ]  
M95512@TSSOP8 [ (SA026) ]  
M95512@TSSOP8( ISP) [ ISP-HEADER01 ]

M95640 M95640(ISP) [ISP-  
HEADER01]  
M95640@SOIC8 [(SA602A)] M95640@SOIC8(ISP) [ISP-  
HEADER01]  
M95640@TSSOP14 [(SA026)]  
M95640@TSSOP14(ISP) [ISP-HEADER01]  
M95640@TSSOP8 [(SA026)]  
M95640@TSSOP8(ISP) [ISP-HEADER01]  
M95M01[150mil]@SOIC8 [(SA602A)]  
M95P02  
M95P02@SOIC8 [(SA602A)]  
M95P04  
M95P04@SOIC8 [(SA602A)]  
M95P08  
M95P08@SOIC8 [(SA602A)]  
MK48C02  
MK48C02B  
MK48C12  
MK48C12B  
MK48T02  
MK48T02B  
MK48T08  
MK48T12  
MK48T12B  
MK48T18  
MK48T32  
MK48T32Y  
MK48T35  
MK48T35@SOIC28 [(SA630)]  
MK48T35Y  
MK48T35Y@SOIC28 [(SA630)]  
MK48T512V  
MK48T512Y  
MK48Z02  
MK48Z02B  
MK48Z08  
MK48Z12  
MK48Z12B  
MK48Z18  
MK48Z32  
MK48Z32Y  
MK48Z35  
MK48Z35@SOIC28 [(SA630)]

MK48Z35Y  
MK48Z35Y@SOIC28 [(SA630)]  
MK48Z512V  
MK48Z512Y  
MKI48Z02  
MKI48Z02B  
MKI48Z12  
MKI48Z12B  
MKI48Z18  
NAND01GR3B2BZA6@FBGA63 [(SA642KK-B280-W048F001Y)]  
NAND01GW3A0AN6@TSOP48 [(SA247-B005)]  
NAND01GW3B2AN6E@TSOP48 [(SA247-B005)]  
NAND01GW3B2BN6E@TSOP48 [(SA247-B005)]  
NAND01GW3B2BZA6@FBGA63 [(SA642KK-B026-W048F001Y)]  
NAND02GR3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]  
NAND02GR3B2DZA6@FBGA63 [(SA642KK-B280A-W048F001Y)]  
NAND02GW3B2AN6@TSOP48 [(SA247-B005)]  
NAND02GW3B2CN6@TSOP48 [(SA247-B005)]  
NAND02GW3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]  
NAND04GW3B2BN6@TSOP48 [(SA247-B005)]  
NAND04GW3C2AN1@TSOP48 [(SA247-B005)]  
NAND08GW3B2AN6@TSOP48 [(SA247-B005)]  
NAND128W3A0AN6@TSOP48 [(SA247-B005)]  
NAND128W3A2BN6@TSOP48 [(SA247-B005)]  
NAND256R3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256R3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A0AN6@TSOP48 [(SA247-B005)]  
NAND256W3A0AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A2BN6@TSOP48 [(SA247-B005)]  
NAND256W3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND512R3A2AZB6@TFBGA63 [(SA642KK-B026-W048F001Y)]  
NAND512R3A2AZB6E@TFBGA55 [(SA642R-B026-T096F001Y)]  
NAND512R3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]  
NAND512W3A0AN6@TSOP48 [(SA247-B005)]  
NAND512W3A2BN6@TSOP48 [(SA247-B005)]  
NAND512W3A2CN6@TSOP48 [(SA247-B005)]  
NAND512W3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]  
NAND99R4M2AZBA5@BGA149 [(SA664G-B279-Y149F001Y)]  
ST24C01 ST24C01@SOIC8  
[(SA602A)]  
ST24C02A ST24C02A@SOIC8  
[(SA602A)]

ST24C16 [ (SA602A) ]	ST24C16@SOIC8
ST24FC21 [ (SA602A) ]	ST24FC21@SOIC8
ST24FW21 [ (SA602A) ]	ST24FW21@SOIC8
ST24LC21B [ (SA602A) ]	ST24LC21B@SOIC8
ST24LW21 [ (SA602A) ]	ST24LW21@SOIC8
ST24W01 [ (SA602A) ]	ST24W01@SOIC8
ST24W02 [ (SA602A) ]	ST24W02@SOIC8
ST24W04C [ (SA602A) ]	ST24W04C@SOIC8
ST26C201 [ (SA015A1T) ]	ST26C201@PLCC32
ST26C201@TSOP32 [ (SA410T) ]	
ST27128A	
ST27256	
ST2764A	
ST27C256 (08bit)	ST93C06
ST93C06(08bit)@SOIC8 [ (SA602A) ] (16bit)	ST93C06
ST93C06(16bit)@SOIC8 [ (SA602A) ] (08bit)	ST93C46
ST93C46(08bit)@SOIC8 [ (SA602A) ] (16bit)	ST93C46
ST93C46(16bit)@SOIC8 [ (SA602A) ] (08bit)	ST93C46A
ST93C46A(08bit)@SOIC8 [ (SA602A) ] (16bit)	ST93C46A
ST93C46A(16bit)@SOIC8 [ (SA602A) ] (08bit)	ST93C46C
ST93C46C(08bit)@SOIC8 [ (SA602A) ] (16bit)	ST93C46C
ST93C46C(16bit)@SOIC8 [ (SA602A) ] (08bit)	ST93C46T
ST93C46T(08bit)@SOIC8 [ (SA602A) ] (16bit)	ST93C46T
ST93C46T(16bit)@SOIC8 [ (SA602A) ]	ST93C47C

(08bit)	
ST93C47C(08bit)@SOIC8 [(SA602A)]	ST93C47C
(16bit)	
ST93C47C(16bit)@SOIC8 [(SA602A)]	ST93C47T
(08bit)	
ST93C47T(08bit)@SOIC8 [(SA602A)]	ST93C47T
(16bit)	
ST93C47T(16bit)@SOIC8 [(SA602A)]	ST93C56
(08bit)	
ST93C56(08bit)@SOIC8 [(SA602A)]	ST93C56
(16bit)	
ST93C56(16bit)@SOIC8 [(SA602A)]	ST93C56B
(08bit)	
ST93C56B(08bit)@SOIC8 [(SA602A)]	ST93C56B
(16bit)	
ST93C56B(16bit)@SOIC8 [(SA602A)]	ST93C56C
(08bit)	
ST93C56C(08bit)@SOIC8 [(SA602A)]	ST93C56C
(16bit)	
ST93C56C(16bit)@SOIC8 [(SA602A)]	ST93C57C
(08bit)	
ST93C57C(08bit)@SOIC8 [(SA602A)]	ST93C57C
(16bit)	
ST93C57C(16bit)@SOIC8 [(SA602A)]	ST93C66
(08bit)	
ST93C66(08bit)@SOIC8 [(SA602A)]	ST93C66
(16bit)	
ST93C66(16bit)@SOIC8 [(SA602A)]	ST93C67
(08bit)	
ST93C67(08bit)@SOIC8 [(SA602A)]	ST93C67
(16bit)	
ST93C67(16bit)@SOIC8 [(SA602A)]	ST93C76
(08bit)	
ST93C76(08bit)@SOIC8 [(SA602A)]	ST93C76
(16bit)	
ST93C76(16bit)@SOIC8 [(SA602A)]	ST93C86
(08bit)	
ST93C86(08bit)@SOIC8 [(SA602A)]	ST93C86
(16bit)	
ST93C86(16bit)@SOIC8 [(SA602A)]	
ST93CS46	
ST93CS46@SOIC8 [(SA602A)]	
ST93CS47	

ST93CS47@SOIC8 [(SA602A)]  
ST93CS56  
ST93CS56@SOIC8 [(SA602A)]  
ST93CS566  
ST93CS566@SOIC8 [(SA602A)]  
ST93CS57  
ST93CS57@SOIC8 [(SA602A)]  
ST93CS66  
ST93CS66@SOIC14 [(SA602)]  
ST93CS67  
ST93CS67@SOIC14 [(SA602)]  
TS27C256  
TS27C64  
[(SA015A1T)]  
TS27C64A  
[(SA015A1T)]  
TS28C16A  
TS28C17A

TS27C64@PLCC32  
TS27C64A@PLCC32

## MICROCONTROLLER

ST62E01  
[(SA404)]  
ST62E01CF1  
ST62E18CF1  
ST62E20  
[(SA404)]  
ST62E20CF1  
ST62E25  
ST62E25@SOIC28 [(SA404)]  
ST62E25CF1  
ST62E28CF1  
ST62E30BF1  
ST62E32BF1@SDIP42 [(SA028)]  
ST62E60B  
ST62E60B@SOIC20 [(SA404)]  
ST62E62CF1  
ST62E65B  
[(SA404)]  
ST62E65CF1  
ST62T00  
ST62T00@SOIC16 [(SA404)]

ST62E01@SOIC16  
ST62E20@SOIC20  
ST62E65B@SOIC28  
ST62T00C

(B6)	
ST62T00C(M6)@SOIC16 [(SA404)]	ST62T00C(N6)@SSOP16
[(SA626A)]	
ST62T01	ST62T01@SOIC16
[(SA404)]	
ST62T01C(B3)	ST62T01C
(B6)	
ST62T01C(M3)@SOIC16 [(SA404)]	ST62T01C(M6)@SOIC16
[(SA404)]	
ST62T01C(N3)@SSOP16 [(SA626A)]	ST62T01C(N6)@SSOP16
[(SA626A)]	
ST62T03	ST62T03@SOIC16
[(SA404)]	
ST62T03C(B6)	ST62T03C(M3)@SOIC16
[(SA404)]	
ST62T03C(M6)@SOIC16 [(SA404)]	ST62T03C(N6)@SSOP16
[(SA626A)]	
ST62T08	ST62T08@SOIC20
[(SA404)]	
ST62T08C(B6)	ST62T08C(M6)@SOIC20
[(SA404)]	
ST62T09	ST62T09@SOIC20
[(SA404)]	
ST62T09C(B3)	ST62T09C
(B6)	
ST62T09C(M3)@SOIC20 [(SA404)]	ST62T09C(M6)@SOIC20
[(SA404)]	
ST62T10	ST62T10@SOIC20
[(SA404)]	
ST62T10C(B6)	ST62T10C(M6)@SOIC20
[(SA404)]	
ST62T15	ST62T15@SOIC28
[(SA404)]	
ST62T15C(B6)	ST62T15C(M6)@SOIC28
[(SA404)]	
ST62T18C(B6)	ST62T18C(M3)@SOIC20
[(SA404)]	
ST62T18C(M6)@SOIC20 [(SA404)]	
ST62T20	
ST62T20@SOIC20 [(SA404)]	ST62T20C
(B3)	
ST62T20C(B6)	ST62T20C(M3)@SOIC20
[(SA404)]	



ST62T20C(M6)@SOIC20 [(SA404)]	
ST62T25	
ST62T25@SOIC28 [(SA404)]	ST62T25C
(B3)	
ST62T25C(B6)	ST62T25C(M3)@SOIC28
[(SA404)]	
ST62T25C(M6)@SOIC28 [(SA404)]	ST62T25C(N6)@SSOP28
[(SA626A)]	
ST62T28C(B6)	ST62T28C(M3)@SOIC28
[(SA404)]	
ST62T28C(M6)@SOIC28 [(SA404)]	ST62T28C(N6)@SSOP28
[(SA626A)]	
ST62T30B(B3)	ST62T30B
(B6)	
ST62T30B(M6)@SOIC28 [(SA404)]	ST62T32B(B6)@SDIP42
[(SA028)]	
ST62T52C(B6)	ST62T52C(M3)@SOIC16
[(SA404)]	
ST62T52C(M6)@SOIC16 [(SA404)]	ST62T52C(N3)@SSOP16
[(SA626A)]	
ST62T52C(N6)@SSOP16 [(SA626A)]	
ST62T53B	
ST62T53B@SOIC20 [(SA404)]	ST62T53C
(B6)	
ST62T53C(M6)@SOIC20 [(SA404)]	ST62T55C
(B6)	
ST62T55C(M6)@SOIC28 [(SA404)]	ST62T55C(N6)@SSOP28
[(SA626A)]	
ST62T60B	ST62T60B@SOIC20
[(SA404)]	
ST62T60C6	ST62T62C
(B6)	
ST62T62C(M3)@SOIC16 [(SA404)]	ST62T62C(M6)@SOIC16
[(SA404)]	
ST62T62C(N3)@SSOP16 [(SA626A)]	ST62T62C(N6)@SSOP16
[(SA626A)]	
ST62T63B	ST62T63B@SOIC20
[(SA404)]	
ST62T63C(B6)	ST62T63C(M6)@SOIC20
[(SA404)]	
ST62T65B	ST62T65B@SOIC28
[(SA404)]	
ST62T65C(B3)	ST62T65C

(B6)

ST62T65C(M3)@SOIC28 [(SA404)]	ST62T65C(M6)@SOIC28
[(SA404)]	
ST62T65C(N6)@SSOP28 [(SA626A)]	ST63E73@SDIP42
[(SA028)]	
ST63T73@SDIP42 [(SA028)]	ST72C104G1B@SDIP32
[(SA653)]	
ST72C104G1M@SOIC28 [(SA404)]	ST72C104G2B@SDIP32
[(SA653)]	
ST72C104G2M@SOIC28 [(SA404)]	ST72C124J2B@SDIP42
[(SA028)]	
ST72C124J2T@TQFP44 [(SA245A)]	ST72C124J4B@SDIP42
[(SA028)]	
ST72C124J4T@TQFP44 [(SA245A)]	ST72C215G1B@SDIP32
[(SA653)]	
ST72C215G1M@SOIC28 [(SA404)]	ST72C215G2B@SDIP32
[(SA653)]	
ST72C215G2M@SOIC28 [(SA404)]	ST72C216G1B@SDIP32
[(SA653)]	
ST72C216G1M@SOIC28 [(SA404)]	ST72C216G2B@SDIP32
[(SA653)]	
ST72C216G2M@SOIC28 [(SA404)]	ST72C254G1B@SDIP32
[(SA653)]	
ST72C254G1M@SOIC28 [(SA404)]	ST72C254G2B@SDIP32
[(SA653)]	
ST72C254G2M@SOIC28 [(SA404)]	ST72C314J2B@SDIP42
[(SA028)]	
ST72C314J2T@TQFP44 [(SA245A)]	ST72C314J4B@SDIP42
[(SA028)]	
ST72C314J4T@TQFP44 [(SA245A)]	ST72C334J2B@SDIP42
[(SA028)]	
ST72C334J2T@TQFP44 [(SA245A)]	ST72C334J4B@SDIP42
[(SA028)]	
ST72C334J4T@TQFP44 [(SA245A)]	ST72F260G1B6@SDIP32
[(SA653)]	
ST72F260G1M6@SOIC28 [(SA404)]	ST72F262G1B6@SDIP32
[(SA653)]	
ST72F262G1M6@SOIC28 [(SA404)]	ST72F262G2B6@SDIP32
[(SA653)]	
ST72F262G2M6@SOIC28 [(SA404)]	ST72F264G1B6@SDIP32
[(SA653)]	
ST72F264G1M6@SOIC28 [(SA404)]	ST72F264G2B6@SDIP32
[(SA653)]	

ST72F264G2H1@LFBGA36 [(SA642G-B026A-T048F001N)]  
ST72F264G2H6@LFBGA36 [(SA642G-B026A-T048F001N)]  
ST72F264G2M6@SOIC28 [(SA404)] ST72F324BJ2B5@SDIP42  
[(SA028)]  
ST72F324BJ2B6@SDIP42 [(SA028)] ST72F324BJ2T3@TQFP44  
[(SA245A)]  
ST72F324BJ2T5@TQFP44 [(SA245A)] ST72F324BJ2T6@TQFP44  
[(SA245A)]  
ST72F324BJ4B5@SDIP42 [(SA028)] ST72F324BJ4B6@SDIP42  
[(SA028)]  
ST72F324BJ4T3@TQFP44 [(SA245A)] ST72F324BJ4T6@TQFP44  
[(SA245A)]  
ST72F324BJ6B5@SDIP42 [(SA028)] ST72F324BJ6B6@SDIP42  
[(SA028)]  
ST72F324BJ6T3@TQFP44 [(SA245A)] ST72F324BJ6T6@TQFP44  
[(SA245A)]  
ST72F324BK2B5@SDIP32 [(SA653)] ST72F324BK2B6@SDIP32  
[(SA653)]  
ST72F324BK2T3@TQFP32 [(SA663)] ST72F324BK2T5@TQFP32  
[(SA663)]  
ST72F324BK2T6@TQFP32 [(SA663)] ST72F324BK4B5@SDIP32  
[(SA653)]  
ST72F324BK4B6@SDIP32 [(SA653)] ST72F324BK4T3@TQFP32  
[(SA663)]  
ST72F324BK4T6@TQFP32 [(SA663)] ST72F324BK6B5@SDIP32  
[(SA653)]  
ST72F324BK6B6@SDIP32 [(SA653)] ST72F324BK6T3@TQFP32  
[(SA663)]  
ST72F324BK6T6@TQFP32 [(SA663)] ST72F324J2B5@SDIP42  
[(SA028)]  
ST72F324J2B5@SDIP42(ISP) [ISP-HEADER01]  
ST72F324J2T6@TQFP44 [(SA245A)]  
ST72F324J2T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J2TA@TQFP44 [(SA245A)]  
ST72F324J2TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J4B5@SDIP42 [(SA028)]  
ST72F324J4B5@SDIP42(ISP) [ISP-HEADER01]  
ST72F324J4T6@TQFP44 [(SA245A)]  
ST72F324J4T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J4TA@TQFP44 [(SA245A)]  
ST72F324J4TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6B5@SDIP42 [(SA028)]  
ST72F324J6B5@SDIP42(ISP) [ISP-HEADER01]

ST72F324J6T3@TQFP44 [(SA245A)]  
ST72F324J6T3@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6T5@TQFP44 [(SA245A)]  
ST72F324J6T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6T6@TQFP44 [(SA245A)]  
ST72F324J6T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6TA@TQFP44 [(SA245A)]  
ST72F324J6TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6TC@TQFP44 [(SA245A)]  
ST72F324J6TC@TQFP44(ISP) [ISP-HEADER01]  
ST72F324K2B5@SDIP32 [(SA653)]  
ST72F324K2B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K2B6@SDIP32 [(SA653)]  
ST72F324K2B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K2T6@TQFP32 [(SA663)]  
ST72F324K2T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K2TA@TQFP32 [(SA663)]  
ST72F324K2TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K4B5@SDIP32 [(SA653)]  
ST72F324K4B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K4B6@SDIP32 [(SA653)]  
ST72F324K4B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K4T6@TQFP32 [(SA663)]  
ST72F324K4T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K4TA@TQFP32 [(SA663)]  
ST72F324K4TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6B5@SDIP32 [(SA653)]  
ST72F324K6B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K6B6@SDIP32 [(SA653)]  
ST72F324K6B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K6T5@TQFP32 [(SA663)]  
ST72F324K6T5@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6T6@TQFP32 [(SA663)]  
ST72F324K6T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6TA@TQFP32 [(SA663)]  
ST72F324K6TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6TC@TQFP32 [(SA663)]  
ST72F324K6TC@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LJ2T5@TQFP44 [(SA245A)]  
ST72F324LJ2T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ2T6@TQFP44 [(SA245A)]  
ST72F324LJ2T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ4T5@TQFP44 [(SA245A)]

ST72F324LJ4T5@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LJ4T6@TQFP44 [(SA245A)]  
ST72F324LJ4T6@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LJ6T5@TQFP44 [(SA245A)]  
ST72F324LJ6T5@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LJ6T6@TQFP44 [(SA245A)]  
ST72F324LJ6T6@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LJ6TA@TQFP44 [(SA245A)]  
ST72F324LJ6TA@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LK2T5@TQFP32 [(SA663)]  
ST72F324LK2T5@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK2T6@TQFP32 [(SA663)]  
ST72F324LK2T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK4T5@TQFP32 [(SA663)]  
ST72F324LK4T5@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK4T6@TQFP32 [(SA663)]  
ST72F324LK4T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6B5@SDIP32 [(SA653)]  
ST72F324LK6B5@SDIP32 (ISP) [ISP-HEADER01]  
ST72F324LK6T5@TQFP32 [(SA663)]  
ST72F324LK6T5@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6T6@TQFP32 [(SA663)]  
ST72F324LK6T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6TA@TQFP32 [(SA663)]  
ST72F324LK6TA@TQFP32 (ISP) [ISP-HEADER01]  
ST72F325C4T6@TQFP48 [(SA248)] ST72F325C6T6@TQFP48  
[(SA248)]  
ST72F325C7T6@TQFP48 [(SA248)] ST72F325C9T6@TQFP48  
[(SA248)]  
ST72F325J4T6@TQFP44 [(SA245A)] ST72F325J6B5@SDIP42  
[(SA028)]  
ST72F325J6B6@SDIP42 [(SA028)]  
ST72F325J6B6@SDIP42 (ISP) [ISP-HEADER01]  
ST72F325J6T6@TQFP44 [(SA245A)] ST72F325J7T6@TQFP44  
[(SA245A)]  
ST72F325J9T6@TQFP44 [(SA245A)] ST72F325K4B5@SDIP32  
[(SA653)]  
ST72F325K4T6@TQFP32 [(SA663)] ST72F325K6B5@SDIP32  
[(SA653)]  
ST72F325K6B6@SDIP32 [(SA653)]  
ST72F325K6B6@SDIP32 (ISP) [ISP-HEADER01]  
ST72F325K6T6@TQFP32 [(SA663)] ST72F32AJ1B5@SDIP42  
[(SA028)]

ST72F32AJ1B6@SDIP42 [(SA028)] ST72F32AJ1T5@TQFP44  
[(SA245A)]  
ST72F32AJ1T6@TQFP44 [(SA245A)] ST72F32AJ2B5@SDIP42  
[(SA028)]  
ST72F32AJ2B6@SDIP42 [(SA028)] ST72F32AJ2T5@TQFP44  
[(SA245A)]  
ST72F32AJ2T6@TQFP44 [(SA245A)] ST72F32AJ2TA@TQFP44  
[(SA245A)]  
ST72F32AJ2TB@TQFP44 [(SA245A)] ST72F32AJ2TC@TQFP44  
[(SA245A)]  
ST72F32AK1B5@SDIP32 [(SA653)] ST72F32AK1B6@SDIP32  
[(SA653)]  
ST72F32AK1T5@TQFP32 [(SA663)] ST72F32AK1T6@TQFP32  
[(SA663)]  
ST72F32AK2B5@SDIP32 [(SA653)] ST72F32AK2B6@SDIP32  
[(SA653)]  
ST72F32AK2T5@TQFP32 [(SA663)] ST72F32AK2T6@TQFP32  
[(SA663)]  
ST72F32AK2TA@TQFP32 [(SA663)] ST72F32AK2TB@TQFP32  
[(SA663)]  
ST72F32AK2TC@TQFP32 [(SA663)] ST72F60D4U1@QFN40  
[(SA750)]  
ST72F60D4U1@QFN40 (ISP) [ISP-HEADER01]  
ST72F60D6U1@QFN40 [(SA750)]  
ST72F60D6U1@QFN40 (ISP) [ISP-HEADER01]  
ST72F60E1M1@SOIC24 [(SA404)]  
ST72F60E1M1@SOIC24 (ISP) [ISP-HEADER01]  
ST72F60E2M1@SOIC24 [(SA404)]  
ST72F60E2M1@SOIC24 (ISP) [ISP-HEADER01]  
ST72F60E4M1@SOIC24 [(SA404)]  
ST72F60E4M1@SOIC24 (ISP) [ISP-HEADER01]  
ST72F60E6M1@SOIC24 [(SA404)]  
ST72F60E6M1@SOIC24 (ISP) [ISP-HEADER01]  
ST72F60K1U1@QFN40 [(SA750)]  
ST72F60K1U1@QFN40 (ISP) [ISP-HEADER01]  
ST72F60K2U1@QFN40 [(SA750)]  
ST72F60K2U1@QFN40 (ISP) [ISP-HEADER01]  
ST72F621J4B1@SDIP42 [(SA028)] ST72F621J4T1@TQFP44  
[(SA245A)]  
ST72F621K4B1@SDIP32 [(SA653)] ST72F621L4M1@SOIC34  
[(SA658)]  
ST72F622L2M1@SOIC34 [(SA658)]  
ST72F623F2B1

ST72F623F2M1@SOIC20 [(SA404)] ST72F63BD4U1@QFN40  
[(SA750)]  
ST72F63BD4U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BD6U1@QFN40 [(SA750)]  
ST72F63BD6U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BE1M1@SOP24 [(SA404)]  
ST72F63BE1M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE2M1@SOP24 [(SA404)]  
ST72F63BE2M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE4M1@SOP24 [(SA404)]  
ST72F63BE4M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE6M1@SOP24 [(SA404)]  
ST72F63BE6M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BH1T1@QFP48 [(SA248)]  
ST72F63BH1T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BH2T1@QFP48 [(SA248)]  
ST72F63BH2T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BH4T1@QFP48 [(SA248)]  
ST72F63BH4T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BH6T1@QFP48 [(SA248)]  
ST72F63BH6T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BK1B1@SOIC34 [(SA653)]  
ST72F63BK1B1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK1M1@SOIC34 [(SA658)]  
ST72F63BK1M1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK1U1@QFN40 [(SA750)]  
ST72F63BK1U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BK2B1@SOIC34 [(SA653)]  
ST72F63BK2B1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK2M1@SOIC34 [(SA658)]  
ST72F63BK2M1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK2U1@QFN40 [(SA750)]  
ST72F63BK2U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BK4B1@SOIC34 [(SA653)]  
ST72F63BK4B1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK4M1@SOIC34 [(SA658)]  
ST72F63BK4M1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK6B1@SOIC34 [(SA653)]  
ST72F63BK6B1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK6M1@SOIC34 [(SA658)]  
ST72F63BK6M1@SOIC34(ISP) [ISP-HEADER01]  
ST72T101G1B@SDIP32 [(SA653)] ST72T101G1M@SOIC28  
[(SA404)]

ST72T101G2B@SDIP32 [(SA653)] [(SA404)]	ST72T101G2M@SOIC28
ST72T121J2B@SDIP42 [(SA028)] [(SA245A)]	ST72T121J2T@TQFP44
ST72T121J4B@SDIP42 [(SA028)] [(SA245A)]	ST72T121J4T@TQFP44
ST72T141K2B@SDIP32 [(SA653)] [(SA658)]	ST72T141K2M@SSOP34
ST72T212G2B@SDIP32 [(SA653)] [(SA404)]	ST72T212G2M@SOIC28
ST72T213G1B@SDIP32 [(SA653)] [(SA404)]	ST72T213G1M@SOIC28
ST72T251G1B@SDIP32 [(SA653)] [(SA404)]	ST72T251G1M@SOIC28
ST72T251G2B@SDIP32 [(SA653)] [(SA404)]	ST72T251G2M@SOIC28
ST72T272K4B@SDIP32 [(SA653)] [(SA658)]	ST72T272K4M@SSOP34
ST72T311J2B@SDIP42 [(SA028)] [(SA245A)]	ST72T311J2T@TQFP44
ST72T311J4B@SDIP42 [(SA028)] [(SA245A)]	ST72T311J4T@TQFP44
ST72T331J2B@SDIP42 [(SA028)] [(SA245A)]	ST72T331J2T@TQFP44
ST72T331J4B@SDIP42 [(SA028)] [(SA245A)]	ST72T331J4T@TQFP44
ST72T371N4B@SDIP56(*) [(SA627-B5601)]	
ST72T372J4B@SDIP42 [(SA028)] [(SA653)]	ST72T631K4B1@SDIP32
ST72T631K4M1@SSOP34 [(SA658)] [(SA653)]	ST72T632K2B1@SDIP32
ST72T632K2M1@SSOP34 [(SA658)] [(SA653)]	ST72T633K1B1@SDIP32
ST72T633K1M1@SSOP34 [(SA658)]	
ST72T671N6B@SDIP56(*) [(SA627-B5601)]	
ST72T751N9B@SDIP56(*) [(SA627-B5601)]	
ST72T752J6B@SDIP42 [(SA028)] [(SA658)]	ST72T753L6M@SSOP34
ST72T771N9B@SDIP56(*) [(SA627-B5601)]	
ST7FDALIF2M6@SOIC20 [(SA404)]	
ST7FDALIF2M6@SOIC20(ISP) [ISP-HEADER01]	
ST7FLIT10BF0B3	
ST7FLIT10BF0B6	



ST7FLIT10BF0M3@SOIC20 [(SA404)]	ST7FLIT10BF0M6@SOIC20
[(SA404)]	
ST7FLIT10BF1B3	
ST7FLIT10BF1B6	
ST7FLIT10BF1M3@SOIC20 [(SA404)]	ST7FLIT10BF1M6@SOIC20
[(SA404)]	
ST7FLIT10BY0B3	
ST7FLIT10BY0B6	
ST7FLIT10BY0M3@SOIC16 [(SA602)]	ST7FLIT10BY0M6@SOIC16
[(SA602)]	
ST7FLIT10BY1B3	
ST7FLIT10BY1B6	
ST7FLIT10BY1M3@SOIC16 [(SA602)]	ST7FLIT10BY1M6@SOIC16
[(SA602)]	
ST7FLIT15BF0B3	
ST7FLIT15BF0B6	
ST7FLIT15BF0M3@SOIC20 [(SA404)]	ST7FLIT15BF0M6@SOIC20
[(SA404)]	
ST7FLIT15BF1B3	
ST7FLIT15BF1B6	
ST7FLIT15BF1M3@SOIC20 [(SA404)]	ST7FLIT15BF1M6@SOIC20
[(SA404)]	
ST7FLIT15BF1U6TR@QFN20 [(BBBB)]	
ST7FLIT15BY0B3	
ST7FLIT15BY0B6	ST7FLIT15BY0M3@SOIC16
[(SA602)]	
ST7FLIT15BY0M6@SOIC16 [(SA602)]	
ST7FLIT15BY1B3	
ST7FLIT15BY1B6	ST7FLIT15BY1M3@SOIC16
[(SA602)]	
ST7FLIT15BY1M6@SOIC16 [(SA602)]	
ST7FLIT19BF0B3	
ST7FLIT19BF0B6	ST7FLIT19BF0M3@SOIC20
[(SA404)]	
ST7FLIT19BF0M6@SOIC20 [(SA404)]	
ST7FLIT19BF1B3	
ST7FLIT19BF1B6	ST7FLIT19BF1M3@SOIC20
[(SA404)]	
ST7FLIT19BF1M6@SOIC20 [(SA404)]	ST7FLIT19BF1U6TR@QFN20
[(BBBB)]	
ST7FLIT19BY0B3	
ST7FLIT19BY0B6	
ST7FLIT19BY0M3@SOIC16 [(SA602)]	ST7FLIT19BY0M6@SOIC16

[ (SA602) ]  
ST7FLIT19BY1B3  
ST7FLIT19BY1B6  
ST7FLIT19BY1M3@SOIC16 [ (SA602) ] ST7FLIT19BY1M6@SOIC16  
[ (SA602) ]  
ST7FLITE02B6 ST7FLITE02B6 (ISP) [ ISP-  
HEADER01 ]  
ST7FLITE02M6@SOIC16 [ (SA602) ]  
ST7FLITE02M6@SOIC16 (ISP) [ ISP-HEADER01 ]  
ST7FLITE02Y0B6  
ST7FLITE02Y0B6 (ISP) [ ISP-HEADER01 ]  
ST7FLITE02Y0M6@SOIC16 [ (SA602) ]  
ST7FLITE02Y0M6@SOIC16 (ISP) [ ISP-HEADER01 ]  
ST7FLITE05B6 ST7FLITE05B6 (ISP) [ ISP-  
HEADER01 ]  
ST7FLITE05M6@SOIC16 [ (SA602) ]  
ST7FLITE05M6@SOIC16 (ISP) [ ISP-HEADER01 ]  
ST7FLITE05Y0B6  
ST7FLITE05Y0B6 (ISP) [ ISP-HEADER01 ]  
ST7FLITE05Y0M6@SOIC16 [ (SA602) ]  
ST7FLITE05Y0M6@SOIC16 (ISP) [ ISP-HEADER01 ]  
ST7FLITE09B6 ST7FLITE09B6 (ISP) [ ISP-  
HEADER01 ]  
ST7FLITE09M6@SOIC16 [ (SA602) ]  
ST7FLITE09M6@SOIC16 (ISP) [ ISP-HEADER01 ]  
ST7FLITE09Y0B6  
ST7FLITE09Y0B6 (ISP) [ ISP-HEADER01 ]  
ST7FLITE09Y0M6@SOIC16 [ (SA602) ]  
ST7FLITE09Y0M6@SOIC16 (ISP) [ ISP-HEADER01 ]  
ST7FLITE10F1B6  
ST7FLITE10F1B6 (ISP) [ ISP-HEADER01 ]  
ST7FLITE10F1M6@SOIC20 [ (SA404) ]  
ST7FLITE10F1M6@SOIC20 (ISP) [ ISP-HEADER01 ]  
ST7FLITE15F1B6  
ST7FLITE15F1B6 (ISP) [ ISP-HEADER01 ]  
ST7FLITE15F1M6@SOIC20 [ (SA404) ]  
ST7FLITE15F1M6@SOIC20 (ISP) [ ISP-HEADER01 ]  
ST7FLITE19F1B6  
ST7FLITE19F1B6 (ISP) [ ISP-HEADER01 ]  
ST7FLITE19F1M6@SOIC20 [ (SA404) ]  
ST7FLITE19F1M6@SOIC20 (ISP) [ ISP-HEADER01 ]  
ST7FLITE20F2B6  
ST7FLITE20F2B6 (ISP) [ ISP-HEADER01 ]

ST7FLITE20F2M6@SOIC20 [(SA404)]  
ST7FLITE20F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE25F2B6  
ST7FLITE25F2B6(ISP) [ISP-HEADER01]  
ST7FLITE25F2M6@SOIC20 [(SA404)]  
ST7FLITE25F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE29F2B6  
ST7FLITE29F2B6(ISP) [ISP-HEADER01]  
ST7FLITE29F2M6@SOIC20 [(SA404)]  
ST7FLITE29F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE30F2B6  
ST7FLITE30F2B6(ISP) [ISP-HEADER01]  
ST7FLITE30F2M6@SOIC20 [(SA404)]  
ST7FLITE30F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE35F2B6  
ST7FLITE35F2B6(ISP) [ISP-HEADER01]  
ST7FLITE35F2M6@SOIC20 [(SA404)]  
ST7FLITE35F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE39F2B6  
ST7FLITE39F2B6(ISP) [ISP-HEADER01]  
ST7FLITE39F2M6@SOIC20 [(SA404)]  
ST7FLITE39F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITEBC ST7FLITEBCM6@SOIC16  
[(SA602)]  
ST7FLITES0 ST7FLITES0@SOIC16  
[(SA602)]  
ST7FLITES2B6 ST7FLITES2B6(ISP) [ISP-  
HEADER01]  
ST7FLITES2M6@SOIC16 [(SA602)]  
ST7FLITES2M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES2Y0B6  
ST7FLITES2Y0B6(ISP) [ISP-HEADER01]  
ST7FLITES2Y0M6@SOIC16 [(SA602)]  
ST7FLITES2Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES5B6 ST7FLITES5B6(ISP) [ISP-  
HEADER01]  
ST7FLITES5M6@SOIC16 [(SA602)]  
ST7FLITES5M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES5Y0B6  
ST7FLITES5Y0B6(ISP) [ISP-HEADER01]  
ST7FLITES5Y0M6@SOIC16 [(SA602)]  
ST7FLITES5Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITEUS2B6 ST7FLITEUS2M6@SOIC8

[ (SA602A) ]  
ST7FLITEUS2M6TR@SOIC8 [ (SA602A) ] ST7FLITEUS2U6TR@DFN8  
[ (BBBB) ]  
ST7FLITEUS5B6 ST7FLITEUS5M6@SOIC8  
[ (SA602A) ]  
ST7FLITEUS5M6TR@SOIC8 [ (SA602A) ] ST7FLITEUS5U6TR@DFN8  
[ (BBBB) ]  
ST7FLU05B6  
ST7FLU05BAE  
ST7FLU05BATRE  
ST7FLU05BCE  
ST7FLU05BCTRE ST7FLU05M6@SOIC8  
[ (SA602A) ]  
ST7FLU05MAE@SOIC8 [ (SA602A) ] ST7FLU05MATRE@SOIC8  
[ (SA602A) ]  
ST7FLU05MCE@SOIC8 [ (SA602A) ] ST7FLU05MCTRE@SOIC8  
[ (SA602A) ]  
ST7FLU09B6  
ST7FLU09BAE  
ST7FLU09BATRE  
ST7FLU09BCE  
ST7FLU09BCTRE ST7FLU09M6@SOIC8  
[ (SA602A) ]  
ST7FLU09MAE@SOIC8 [ (SA602A) ] ST7FLU09MATRE@SOIC8  
[ (SA602A) ]  
ST7FLU09MCE@SOIC8 [ (SA602A) ] ST7FLU09MCTRE@SOIC8  
[ (SA602A) ]  
ST7FLUS5B6  
ST7FLUS5BAE  
ST7FLUS5BATRE  
ST7FLUS5BCE  
ST7FLUS5BCTRE ST7FLUS5M6@SOIC8  
[ (SA602A) ]  
ST7FLUS5MAE@SOIC8 [ (SA602A) ] ST7FLUS5MATRE@SOIC8  
[ (SA602A) ]  
ST7FLUS5MCE@SOIC8 [ (SA602A) ] ST7FLUS5MCTRE@SOIC8  
[ (SA602A) ]  
ST7FSCR1E4M1@SOIC24( \* ) [ (SA404-B140) ]

## STC

### MICROCONTROLLER

STC89C516RD [ ( SA244 ) ]	STC89C516RD@PLCC44
STC89C516RD@TQFP44 [ ( SA245A ) ]	
STC89C58RD STC89C58RD@PLCC44 [ ( SA244 ) ]	STC89C58RD@TQFP44
[ ( SA245A ) ]	
STC89LE516AD [ ( SA244 ) ]	STC89LE516AD@PLCC44
STC89LE516AD@TQFP44 [ ( SA245A ) ]	
STC89LE516X2 STC89LE516X2@PLCC44 [ ( SA244 ) ]	STC89LE516X2@TQFP44
[ ( SA245A ) ]	
STC89LE52AD [ ( SA244 ) ]	STC89LE52AD@PLCC44
STC89LE52AD@TQFP44 [ ( SA675 ) ]	
STC89LE54AD STC89LE54AD@PLCC44 [ ( SA244 ) ]	STC89LE54AD@TQFP44
[ ( SA675 ) ]	
STC89LE556AD [ ( SA244 ) ]	STC89LE556AD@PLCC44
STC89LE556AD@TQFP44 [ ( SA245A ) ]	
STC89LE556X2 STC89LE556X2@PLCC44 [ ( SA244 ) ]	STC89LE556X2@TQFP44
[ ( SA245A ) ]	
STC89LE58AD [ ( SA244 ) ]	STC89LE58AD@PLCC44
STC89LE58AD@TQFP44 [ ( SA675 ) ]	
STC89LV516RD STC89LV516RD@PLCC44 [ ( SA244 ) ]	STC89LV516RD@TQFP44
[ ( SA245A ) ]	
STC89LV58RD [ ( SA244 ) ]	STC89LV58RD@PLCC44
STC89LV58RD@TQFP44 [ ( SA245A ) ]	

## ST-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

M36L0R7050B0\_B1 ( HZ ) @FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0R7050T0\_T1 ( HZ ) @FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0R8060B3 ( HZ ) @FBGA88 [ ( SA642A-B124A-Y096F001Y ) ]

M36L0R8060B5ZAQ(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
M58LR128FB\_GB(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128FT\_GT(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
NAND01GW3B2BZA6(ASUS)@FBGA63 [(SA642KK-B026-W048F001Y)]  
NAND04GW3B2BN6(WS)@TSOP48 [(SA247-B005)]  
NAND512R3A2(MLT)@FBGA63 [(SA642KK-B026-W0638F001Y)]

## SUMMIT

### E(E) PROM/FRAM/NVRAM

S24022 [(SA602A)]	S24022@SOIC8
S24023 [(SA602A)]	S24023@SOIC8
S24042 [(SA602A)]	S24042@SOIC8
S24043 [(SA602A)]	S24043@SOIC8
S24162 [(SA602A)]	S24162@SOIC8
S24VP02 [(SA602A)]	S24VP02@SOIC8
S24VP04 [(SA602A)]	S24VP04@SOIC8
S24VP08 [(SA602A)]	S24VP08@SOIC8
S24VP16 [(SA602A)]	S24VP16@SOIC8
S93462(08bit) [(SA602A)]	S93462(08bit)@SOIC8
S93462(16bit) [(SA602A)]	S93462(16bit)@SOIC8
S93463(08bit) [(SA602A)]	S93463(08bit)@SOIC8
S93463(16bit) [(SA602A)]	S93463(16bit)@SOIC8
S93662(08bit) [(SA602A)]	S93662(08bit)@SOIC8
S93662(16bit) [(SA602A)]	S93662(16bit)@SOIC8
S93663(08bit)	S93663(08bit)@SOIC8

[ (SA602A) ]  
S93663(16bit) S93663(16bit)@SOIC8  
[ (SA602A) ]  
S93WD462(08bit) S93WD462(08bit)@SOIC8  
[ (SA602A) ]  
S93WD462(16bit) S93WD462(16bit)@SOIC8  
[ (SA602A) ]  
S93WD463(08bit) S93WD463(08bit)@SOIC8  
[ (SA602A) ]  
S93WD463(16bit) S93WD463(16bit)@SOIC8  
[ (SA602A) ]  
S93WD662(08bit) S93WD662(08bit)@SOIC8  
[ (SA602A) ]  
S93WD662(16bit) S93WD662(16bit)@SOIC8  
[ (SA602A) ]  
S93WD663(08bit) S93WD663(08bit)@SOIC8  
[ (SA602A) ]  
S93WD663(16bit) S93WD663(16bit)@SOIC8  
[ (SA602A) ]

## MICROCONTROLLER

I-SMM465F-249@TQFP48 (ISP) [ ISP-HEADER01 ]  
SMM465F-249@TQFP48 [ (SA248) ] SMM665BFC-266@TQFP48  
[ (SA248) ]  
SMM665BFC-266@TQFP48 (ISP) [ ISP-HEADER01 ]

## SUNPLUS

### E (E) PROM/FRAM/NVRAM

SPHE6400A SPHE6400A@SOIC8  
[ (SA602A) ]

## MICROCONTROLLER

SPMC65P2102A(dip18)  
SPMC65P2102A(dip18)(ISP) [ ISP-HEADER01 ]  
SPMC65P2102A@SOP18 [ (SA404) ]  
SPMC65P2102A@SOP18 (ISP) [ ISP-HEADER01 ]

SPMC65P2104A(dip18)  
SPMC65P2104A(dip18)(ISP) [ISP-HEADER01]  
SPMC65P2104A@SOP18 [(SA404)]  
SPMC65P2104A@SOP18(ISP) [ISP-HEADER01]  
SPMC65P2202A(dip16)  
SPMC65P2202A(dip16)(ISP) [ISP-HEADER01]  
SPMC65P2202A(dip20)  
SPMC65P2202A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2202A@SOP16 [(SA404)]  
SPMC65P2202A@SOP16(ISP) [ISP-HEADER01]  
SPMC65P2202A@SOP20 [(SA404)]  
SPMC65P2202A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2204A(dip16)  
SPMC65P2204A(dip16)(ISP) [ISP-HEADER01]  
SPMC65P2204A(dip20)  
SPMC65P2204A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2204A@SOP16 [(SA404)]  
SPMC65P2204A@SOP16(ISP) [ISP-HEADER01]  
SPMC65P2204A@SOP20 [(SA404)]  
SPMC65P2204A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2404A(dip20)  
SPMC65P2404A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2404A(dip28)  
SPMC65P2404A(dip28)(ISP) [ISP-HEADER01]  
SPMC65P2404A@SOP20 [(SA404)]  
SPMC65P2404A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2404A@SOP28 [(SA404)]  
SPMC65P2404A@SOP28(ISP) [ISP-HEADER01]  
SPMC65P2408A(dip28)  
SPMC65P2408A(dip28)(ISP) [ISP-HEADER01]  
SPMC65P2408A(dip32)  
SPMC65P2408A(dip32)(ISP) [ISP-HEADER01]  
SPMC65P2408A@SOP28 [(SA404)]  
SPMC65P2408A@SOP28(ISP) [ISP-HEADER01]  
SPMC65P2408A@SOP32 [(SA603)]  
SPMC65P2408A@SOP32(ISP) [ISP-HEADER01]

## SYNCMOS

### E ( E ) PROM / FRAM / NVRAM

F29C31004B

F29C31004B@PLCC32



[ (SA015A1T) ]	
F29C31004B@TSOP32 [ (SA410T) ]	
F29C31004T	
F29C31004T@PLCC32 [ (SA015A1T) ]	F29C31004T@TSOP32
[ (SA410T) ]	
F29C51000B	F29C51000B@PLCC32
[ (SA015A1T) ]	
F29C51000T	F29C51000T@PLCC32
[ (SA015A1T) ]	
F29C51001B	F29C51001B@PLCC32
[ (SA015A1T) ]	
F29C51001B@TSOP32 [ (SA410T) ]	
F29C51001T	
F29C51001T@PLCC32 [ (SA015A1T) ]	F29C51001T@TSOP32
[ (SA410T) ]	
F29C51002B	F29C51002B@PLCC32
[ (SA015A1T) ]	
F29C51002B@TSOP32 [ (SA410T) ]	
F29C51002T	
F29C51002T@PLCC32 [ (SA015A1T) ]	F29C51002T@TSOP32
[ (SA410T) ]	
F29C51004B	F29C51004B@PLCC32
[ (SA015A1T) ]	
F29C51004B@TSOP32 [ (SA410T) ]	
F29C51004T	
F29C51004T@PLCC32 [ (SA015A1T) ]	F29C51004T@TSOP32
[ (SA410T) ]	
F29LC51000	F29LC51000@PLCC32
[ (SA015A1T) ]	
F29LC51001	F29LC51001@PLCC32
[ (SA015A1T) ]	
F29LC51002	F29LC51002@PLCC32
[ (SA015A1T) ]	
S29C31001B	S29C31001B@PLCC32
[ (SA015A1T) ]	
S29C31001B@TSOP32 [ (SA410T) ]	
S29C31001T	
S29C31001T@PLCC32 [ (SA015A1T) ]	S29C31001T@TSOP32
[ (SA410T) ]	
S29C31002B	S29C31002B@PLCC32
[ (SA015A1T) ]	
S29C31002B@TSOP32 [ (SA410T) ]	
S29C31002T	

S29C31002T@PLCC32 [(SA015A1T)]	S29C31002T@TSOP32
[(SA410T)]	
S29C31004B	S29C31004B@PLCC32
[(SA015A1T)]	
S29C31004B@TSOP32 [(SA410T)]	
S29C31004T	
S29C31004T@PLCC32 [(SA015A1T)]	S29C31004T@TSOP32
[(SA410T)]	
S29C51001B	S29C51001B@PLCC32
[(SA015A1T)]	
S29C51001B@TSOP32 [(SA410T)]	
S29C51001T	
S29C51001T@PLCC32 [(SA015A1T)]	S29C51001T@TSOP32
[(SA410T)]	
S29C51002B	S29C51002B@PLCC32
[(SA015A1T)]	
S29C51002B@TSOP32 [(SA410T)]	
S29C51002T	
S29C51002T@PLCC32 [(SA015A1T)]	S29C51002T@TSOP32
[(SA410T)]	
S29C51004B	S29C51004B@PLCC32
[(SA015A1T)]	
S29C51004B@TSOP32 [(SA410T)]	
S29C51004T	
S29C51004T@PLCC32 [(SA015A1T)]	S29C51004T@TSOP32
[(SA410T)]	

## MICROCONTROLLER

MSU1958	MSU1958@PLCC44
[(SA244)]	
MSU1958@TQFP44 [(SA245A)]	
MSU2952	
MSU2952@PLCC44 [(SA244)]	MSU2952@TQFP44
[(SA245A)]	
MSU2964	MSU2964@PLCC44
[(SA244)]	
MSU2964@TQFP44 [(SA245A)]	
SM2958	
SM2958@PLCC44 [(SA244)]	SM2958@TQFP44
[(SA245A)]	
SM2965	SM2965@PLCC44

[ ( SA244 ) ]	
SM2965@TQFP44 [ ( SA245A ) ]	
SM59064	
SM59064@PLCC44 [ ( SA244 ) ]	SM59064@TQFP44
[ ( SA245A ) ]	
SM59128C	SM59128C@PLCC44
[ ( SA244 ) ]	
SM59128C@TQFP44 [ ( SA245A ) ]	
SM59128L	
SM59128L@PLCC44 [ ( SA244 ) ]	SM59128L@TQFP44
[ ( SA245A ) ]	
SM59164	SM59164@PLCC44
[ ( SA244 ) ]	
SM59164@TQFP44 [ ( SA245A ) ]	
SM59264	
SM59264@PLCC44 [ ( SA244 ) ]	SM59264@TQFP44
[ ( SA245A ) ]	
SM5964	SM5964@PLCC44
[ ( SA244 ) ]	
SM5964@TQFP44 [ ( SA245A ) ]	
SM5964A	
SM5964A@PLCC44 [ ( SA244 ) ]	SM5964A@TQFP44
[ ( SA245A ) ]	
SM5964AC	SM5964AC@PLCC44
[ ( SA244 ) ]	
SM5964AC@TQFP44 [ ( SA245A ) ]	
SM5964AL	
SM5964AL@PLCC44 [ ( SA244 ) ]	SM5964AL@TQFP44
[ ( SA245A ) ]	
SM5964C	SM5964C@PLCC44
[ ( SA244 ) ]	
SM5964C@TQFP44 [ ( SA245A ) ]	
SM5964D0	
SM5964D0@PLCC44 [ ( SA244 ) ]	SM5964D0@TQFP44
[ ( SA245A ) ]	
SM5964D0A	SM5964D0A@PLCC44
[ ( SA244 ) ]	
SM5964D0A@TQFP44 [ ( SA245A ) ]	
SM5964D1A	
SM5964D1A@PLCC44 [ ( SA244 ) ]	SM5964D1A@TQFP44
[ ( SA245A ) ]	
SM59D02G2C	SM59D02G2C ( ISP ) [ ISP-
HEADER01 ]	

SM59D02G2C@LQFP44 [(SA675-B005)]  
 SM59D02G2C@LQFP44(ISP) [ISP-HEADER01]  
 SM59D02G2C@PLCC44 [(SA244-B002)]  
 SM59D02G2C@PLCC44(ISP) [ISP-HEADER01]  
 SM59D02G2L SM59D02G2L(ISP) [ISP-  
 HEADER01]  
 SM59D02G2L@LQFP44 [(SA675-B005)]  
 SM59D02G2L@LQFP44(ISP) [ISP-HEADER01]  
 SM59D02G2L@PLCC44 [(SA244-B002)]  
 SM59D02G2L@PLCC44(ISP) [ISP-HEADER01]  
 SM59D03G2C SM59D03G2C(ISP) [ISP-  
 HEADER01]  
 SM59D03G2C@LQFP44 [(SA675-B005)]  
 SM59D03G2C@LQFP44(ISP) [ISP-HEADER01]  
 SM59D03G2C@PLCC44 [(SA244-B002)]  
 SM59D03G2C@PLCC44(ISP) [ISP-HEADER01]  
 SM59D03G2L SM59D03G2L(ISP) [ISP-  
 HEADER01]  
 SM59D03G2L@LQFP44 [(SA675-B005)]  
 SM59D03G2L@LQFP44(ISP) [ISP-HEADER01]  
 SM59D03G2L@PLCC44 [(SA244-B002)]  
 SM59D03G2L@PLCC44(ISP) [ISP-HEADER01]  
 SM59D04G2C SM59D04G2C(ISP) [ISP-  
 HEADER01]  
 SM59D04G2C@LQFP44 [(SA675-B005)]  
 SM59D04G2C@LQFP44(ISP) [ISP-HEADER01]  
 SM59D04G2C@PLCC44 [(SA244-B002)]  
 SM59D04G2C@PLCC44(ISP) [ISP-HEADER01]  
 SM59D04G2L SM59D04G2L(ISP) [ISP-  
 HEADER01]  
 SM59D04G2L@LQFP44 [(SA675-B005)]  
 SM59D04G2L@LQFP44(ISP) [ISP-HEADER01]  
 SM59D04G2L@PLCC44 [(SA244-B002)]  
 SM59D04G2L@PLCC44(ISP) [ISP-HEADER01]  
 SM59R08A2@TQFP64(\*) [(SA732-B292)]  
 SM59R16A2@TQFP64(\*) [(SA732-B292)]  
 SM7908 SM7908@PLCC44  
 [(SA244)]  
 SM7908@TQFP44 [(SA245A)]  
 SM79108  
 SM79108@PLCC44 [(SA244)] SM79108@TQFP44  
 [(SA245A)]  
 SM79164 SM79164@PLCC44

[ ( SA244 ) ]	
SM79164@TQFP44 [ ( SA245A ) ]	
SM79164L	
SM79164L@PLCC44 [ ( SA244 ) ]	SM79164L@TQFP44
[ ( SA245A ) ]	
SM79164V	
[ ( SA244 ) ]	
SM79164V@TQFP44 [ ( SA245A ) ]	SM79164V@PLCC44
SM7932	
SM7932@PLCC44 [ ( SA244 ) ]	SM7932@TQFP44
[ ( SA245A ) ]	
SM7964	
[ ( SA244 ) ]	
SM7964@TQFP44 [ ( SA245A ) ]	SM7964@PLCC44
SM894051	
SM894051@SOIC20 [ ( SA023A ) ]	
SM8951	
SM8951@PLCC44 [ ( SA244 ) ]	SM8951@TQFP44
[ ( SA245A ) ]	
SM89516	
[ ( SA244 ) ]	
SM89516@TQFP44 [ ( SA245A ) ]	SM89516@PLCC44
SM89516A	
SM89516A@PLCC44 [ ( SA244 ) ]	SM89516A@TQFP44
[ ( SA245A ) ]	
SM89516AL	
[ ( SA244 ) ]	
SM89516AL@TQFP44 [ ( SA245A ) ]	SM89516AL@PLCC44
SM89516B	
SM89516B@PLCC44 [ ( SA244 ) ]	SM89516B@TQFP44
[ ( SA245A ) ]	
SM89516BL	
[ ( SA244 ) ]	
SM89516BL@TQFP44 [ ( SA245A ) ]	SM89516BL@PLCC44
SM89516L	
SM89516L@PLCC44 [ ( SA244 ) ]	SM89516L@TQFP44
[ ( SA245A ) ]	
SM8951A	
[ ( SA244 ) ]	
SM8951A@TQFP44 [ ( SA245A ) ]	SM8951A@PLCC44
SM8951AL	
SM8951AL@PLCC44 [ ( SA244 ) ]	SM8951AL@TQFP44
[ ( SA245A ) ]	

SM8951B	SM8951B@PLCC44
[ ( SA244 ) ]	
SM8951B@TQFP44 [ ( SA245A ) ]	
SM8951BL	
SM8951BL@PLCC44 [ ( SA244 ) ]	SM8951BL@TQFP44
[ ( SA245A ) ]	
SM8951L	
[ ( SA244 ) ]	SM8951L@PLCC44
SM8951L@TQFP44 [ ( SA245A ) ]	
SM8952	
SM8952@PLCC44 [ ( SA244 ) ]	SM8952@TQFP44
[ ( SA245A ) ]	
SM8952A	
[ ( SA244 ) ]	SM8952A@PLCC44
SM8952A@TQFP44 [ ( SA245A ) ]	
SM8952AL	
SM8952AL@PLCC44 [ ( SA244 ) ]	SM8952AL@TQFP44
[ ( SA245A ) ]	
SM8952B	
[ ( SA244 ) ]	SM8952B@PLCC44
SM8952B@TQFP44 [ ( SA245A ) ]	
SM8952BL	
SM8952BL@PLCC44 [ ( SA244 ) ]	SM8952BL@TQFP44
[ ( SA245A ) ]	
SM8952L	
[ ( SA244 ) ]	SM8952L@PLCC44
SM8952L@TQFP44 [ ( SA245A ) ]	
SM8954	
SM8954@PLCC44 [ ( SA244 ) ]	SM8954@TQFP44
[ ( SA245A ) ]	
SM8954A	
[ ( SA244 ) ]	SM8954A@PLCC44
SM8954A@TQFP44 [ ( SA245A ) ]	
SM8954AL	
SM8954AL@PLCC44 [ ( SA244 ) ]	SM8954AL@TQFP44
[ ( SA245A ) ]	
SM8954B	
[ ( SA244 ) ]	SM8954B@PLCC44
SM8954B@TQFP44 [ ( SA245A ) ]	
SM8954BL	
SM8954BL@PLCC44 [ ( SA244 ) ]	SM8954BL@TQFP44
[ ( SA245A ) ]	
SM8954L	
	SM8954L@PLCC44

[ ( SA244 ) ]	
SM8954L@TQFP44 [ ( SA245A ) ]	
SM8958	
SM8958@PLCC44 [ ( SA244 ) ]	SM8958@TQFP44
[ ( SA245A ) ]	
SM8958A	
[ ( SA244 ) ]	
SM8958A@TQFP44 [ ( SA245A ) ]	
SM8958AL	
SM8958AL@PLCC44 [ ( SA244 ) ]	SM8958AL@TQFP44
[ ( SA245A ) ]	
SM8958B	
[ ( SA244 ) ]	
SM8958B@TQFP44 [ ( SA245A ) ]	
SM8958BL	
SM8958BL@PLCC44 [ ( SA244 ) ]	SM8958BL@TQFP44
[ ( SA245A ) ]	
SM8958L	
[ ( SA244 ) ]	
SM8958L@TQFP44 [ ( SA245A ) ]	
SM89S16R1C	
SM89S16R1C@PLCC44 [ ( SA244 ) ]	SM89S16R1C@TQFP44
[ ( SA245A ) ]	
SM89T04R1C	
[ ( SA244 ) ]	
SM89T04R1C@TQFP44 [ ( SA245A ) ]	
SM89T04R1L	
SM89T04R1L@PLCC44 [ ( SA244 ) ]	SM89T04R1L@TQFP44
[ ( SA245A ) ]	
SM89T08R1C	
[ ( SA244 ) ]	
SM89T08R1C@TQFP44 [ ( SA245A ) ]	
SM89T08R1L	
SM89T08R1L@PLCC44 [ ( SA244 ) ]	SM89T08R1L@TQFP44
[ ( SA245A ) ]	
SM89T16R1C	
[ ( SA244 ) ]	
SM89T16R1C@TQFP44 [ ( SA245A ) ]	
SM89T16R1L	
SM89T16R1L@PLCC44 [ ( SA244 ) ]	SM89T16R1L@TQFP44
[ ( SA245A ) ]	

# SYNERTEK

## E ( E ) PROM / FRAM / NVRAM

SY2716

# SYNTEK

## MICROCONTROLLER

STK6011BP1-3V@PLCC44 [ ( SA244 ) ] [ ( SA244 ) ]	STK6011BP21-5V@PLCC44
STK6011BP5-3V@TQFP44 [ ( SA245A ) ] [ ( SA248 ) ]	STK6011P10-5V@LQFP48
STK6011P1-3V@PLCC44 [ ( SA244 ) ] [ ( SA244 ) ]	STK6011P2-5V@PLCC44
STK6011P3-3V@SDIP42 [ ( SA028 ) ] [ ( SA028 ) ]	STK6011P4-5V@SDIP42
STK6011P5-3V@PQFP44 [ ( SA245A ) ] [ ( SA245A ) ]	STK6011P6-5V@PQFP44
STK6011P7-3V 5V	STK6011P8-
STK6011P9-3V@LQFP48 [ ( SA248 ) ] [ ( SA244 ) ]	STK6012BP1-3V@PLCC44
STK6012BP22-5V@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	STK6012BP5-3V@TQFP44
STK6012P10-5V@LQFP48 [ ( SA248 ) ] [ ( SA244 ) ]	STK6012P1-3V@PLCC44
STK6012P2-5V@PLCC44 [ ( SA244 ) ] [ ( SA028 ) ]	STK6012P3-3V@SDIP42
STK6012P4-5V@SDIP42 [ ( SA028 ) ] [ ( SA245A ) ]	STK6012P5-3V@PQFP44
STK6012P6-5V@PQFP44 [ ( SA245A ) ] 3V	STK6012P7-
STK6012P8-5V [ ( SA248 ) ]	STK6012P9-3V@LQFP48
STK6031@LQFP48 [ ( SA248 ) ] [ ( SA244 ) ]	STK6031@PLCC44
STK6031@QFP44 [ ( SA245A ) ]	
STK6032	
STK6032@LQFP48 [ ( SA248 ) ]	STK6032@PLCC44



[ ( SA244 ) ]  
STK6032@QFP44 [ ( SA245A ) ]  
STK6033  
STK6033@LQFP48 [ ( SA248 ) ] STK6033@PLCC44  
[ ( SA244 ) ]  
STK6033@QFP44 [ ( SA245A ) ]

## TECHCODE

### MICROCONTROLLER

T89C516 T89C516@PLCC44  
[ ( SA244 ) ]  
T89C516@TQFP44 [ ( SA245A ) ]  
T89C52  
T89C52@PLCC44 [ ( SA244 ) ] T89C52@TQFP44  
[ ( SA245A ) ]  
T89C58 T89C58@PLCC44  
[ ( SA244 ) ]  
T89C58@TQFP44 [ ( SA245A ) ]

## TEKMOS

### E ( E ) PROM / FRAM / NVRAM

TK17LV040@PLCC20 [ ( SA001A ) ]

## TEMIC

### MICROCONTROLLER

T89C51RD2 T89C51RD2@PLCC44  
[ ( SA244 ) ]  
T89C51RD2@TQFP44 [ ( SA245A ) ]  
T89F64  
T89F64@PLCC44 [ ( SA244 ) ] T89F64@TQFP44  
[ ( SA245A ) ]  
TS87C51RB2 TS87C51RB2@PLCC44  
[ ( SA244 ) ]

TS87C51RB2@TQFP44 [(SA245A)]	
TS87C51RC2	
TS87C51RC2@PLCC44 [(SA244)]	TS87C51RC2@TQFP44
[(SA245A)]	
TS87C51RD2	TS87C51RD2@PLCC44
[(SA244)]	
TS87C51RD2@TQFP44 [(SA245A)]	
TS87C51U2	
TS87C51U2@PLCC44 [(SA244)]	TS87C51U2@TQFP44
[(SA245A)]	
TS87C52X2	TS87C52X2@PLCC44
[(SA244)]	
TS87C52X2@TQFP44 [(SA245A)]	
TS87C54X2	
TS87C54X2@PLCC44 [(SA244)]	TS87C54X2@TQFP44
[(SA245A)]	
TS87C58X2	TS87C58X2@PLCC44
[(SA244)]	
TS87C58X2@TQFP44 [(SA245A)]	
TSC71RBX2	
TSC71RBX2@PLCC44 [(SA244)]	TSC71RBX2@TQFP44
[(SA245A)]	
TSC71RCX2	TSC71RCX2@PLCC44
[(SA244)]	
TSC71RCX2@TQFP44 [(SA245A)]	
TSC71RDX2	
TSC71RDX2@PLCC44 [(SA244)]	TSC71RDX2@TQFP44
[(SA245A)]	
TSC87251A1@PLCC44 [(SA244)]	
TSC87251G1	
TSC87251G1@PLCC44 [(SA244)]	
TSC87251G1A	
TSC87251G1A@PLCC44 [(SA244)]	
TSC87251G2D	
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44
[(SA245A)]	
TSC87C51	TSC87C51@PLCC44
[(SA244)]	
TSC87C51@TQFP44 [(SA245A)]	
TSC87C52	
TSC87C52@PLCC44 [(SA244)]	TSC87C52@TQFP44
[(SA245A)]	
TSC87C54	TSC87C54@PLCC44

[ ( SA244 ) ]

TSC87C54@TQFP44 [ ( SA245A ) ]

TSC87C58

TSC87C58@PLCC44 [ ( SA244 ) ]

TSC87C58@TQFP44

[ ( SA245A ) ]

## TI

### E ( E ) PROM / FRAM / NVRAM

BQ4010

BQ4010Y

BQ4011

BQ4011Y

BQ4013

BQ4013Y

BQ4014

BQ4014Y

BQ4015

BQ4015Y

SMJ2516

SMJ2532

SMJ2532A

SMJ2564

SMJ2564@PLCC32 [ ( SA015A1T ) ]

SMJ2716

SMJ27C256

SMJ27C256@PLCC32

[ ( SA015A1T ) ]

SMJ27C512

SMJ27C512@PLCC32

[ ( SA015A1T ) ]

TMS2516

TMS2516JLW

TMS2532

TMS2532A

TMS2564

TMS2564@PLCC32

[ ( SA015A1T ) ]

TMS25L32

TMS27128

TMS27128A

TMS2716

TMS2732

TMS2732A

TMS2764	
TMS27C010	
TMS27C010@PLCC32 [(SA015A1T)]	TMS27C010@TSOP32
[(SA410T)]	
TMS27C010A	TMS27C010A@PLCC32
[(SA015A1T)]	
TMS27C010A@TSOP32 [(SA410T)]	
TMS27C020	
TMS27C020@PLCC32 [(SA015A1T)]	TMS27C020@TSOP32
[(SA410T)]	
TMS27C040	TMS27C040@PLCC32
[(SA015A1T)]	
TMS27C040@TSOP32 [(SA410T)]	
TMS27C128	
TMS27C128@PLCC32 [(SA015A1T)]	
TMS27C2001	
TMS27C2001@PLCC32 [(SA015A1T)]	TMS27C2001@TSOP32
[(SA410T)]	
TMS27C210	TMS27C210@PLCC44
[(SA244)]	
TMS27C210A	TMS27C210A@PLCC44
[(SA244)]	
TMS27C240	TMS27C240@PLCC44
[(SA244)]	
TMS27C256	TMS27C256@PLCC32
[(SA015A1T)]	
TMS27C291	TMS27C291@PLCC28
[(SA008A)]	
TMS27C292	TMS27C292@PLCC28
[(SA008A)]	
TMS27C32	
TMS27C512	
TMS27C512@PLCC32 [(SA015A1T)]	
TMS27C64	
TMS27LV010A	TMS27LV010A@PLCC32
[(SA015A1T)]	
TMS27LV010A@TSOP32 [(SA410T)]	
TMS27P32A	
TMS27P64	
TMS27PC010	
TMS27PC010@PLCC32 [(SA015A1T)]	TMS27PC010@TSOP32
[(SA410T)]	
TMS27PC010A	TMS27PC010A@PLCC32

[ (SA015A1T) ]  
 TMS27PC010A@TSOP32 [ (SA410T) ]  
 TMS27PC020  
 TMS27PC020@PLCC32 [ (SA015A1T) ]                      TMS27PC020@TSOP32  
 [ (SA410T) ]  
 TMS27PC040    TMS27PC040@PLCC32  
 [ (SA015A1T) ]  
 TMS27PC040@TSOP32 [ (SA410T) ]  
 TMS27PC128  
 TMS27PC128@PLCC32 [ (SA015A1T) ]  
 TMS27PC210  
 TMS27PC210@PLCC44 [ (SA244) ]  
 TMS27PC210A  
 TMS27PC210A@PLCC44 [ (SA244) ]  
 TMS27PC240  
 TMS27PC240@PLCC44 [ (SA244) ]  
 TMS27PC256  
 TMS27PC256@PLCC32 [ (SA015A1T) ]  
 TMS27PC291  
 TMS27PC291@PLCC28 [ (SA008A) ]  
 TMS27PC32  
 TMS27PC32A  
 TMS27PC512  
 TMS27PC512@PLCC32 [ (SA015A1T) ]  
 TMS27PC64  
 TMS28F010    TMS28F010@PLCC32  
 [ (SA015A1T) ]  
 TMS28F010@TSOP32 [ (SA410T) ]  
 TMS28F020  
 TMS28F020@PLCC32 [ (SA015A1T) ]                      TMS28F020@TSOP32  
 [ (SA410T) ]  
 TMS28F200AF-B@PSOP44 [ (SA638) ]  
 TMS28F200AF-B@TSOP48 [ (SA247-B005) ]  
 TMS28F200AF-T@PSOP44 [ (SA638) ]  
 TMS28F200AF-T@TSOP48 [ (SA247-B005) ]  
 TMS28F200BZ-B@PSOP44 [ (SA638) ]                      TMS28F200BZ-T@PSOP44  
 [ (SA638) ]  
 TMS28F210    TMS28F210@PLCC44  
 [ (SA244) ]  
 TMS28F210@TSOP40 [ (SA409T) ]                              TMS28F400AF-B@PSOP44  
 [ (SA638) ]  
 TMS28F400AF-T@PSOP44 [ (SA638) ]                      TMS28F400AS-B@PSOP44  
 [ (SA638) ]

TMS28F400AS-T@PSOP44 [(SA638)]	TMS28F400BZ-B@PSOP44
[(SA638)]	
TMS28F400BZ-T@PSOP44 [(SA638)]	
TMS28F512	
TMS28F512@PLCC32 [(SA015A1T)]	TMS28F512@TSOP32
[(SA410T)]	
TMS29F040	TMS29F040@PLCC32
[(SA015A1T)]	
TMS29F040@TSOP32 [(SA410T)]	
TMS29F259	
TMS29F259@PLCC32 [(SA015A1T)]	TMS29F259@TSOP32
[(SA410T)]	
TMS29F512	TMS29F512@PLCC32
[(SA015A1T)]	
TMS29F512@TSOP32 [(SA410T)]	
TMS87C257	
TMS87C257@PLCC32 [(SA015A1T)]	

## PLD

EP330	EP330@PLCC20
[(SA001A)]	
EP910	EP910-P44
[(SA244)]	

## MICROCONTROLLER

MSP430F1122@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1122@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F1132@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1132@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F1222@SOIC28(ISP) [ISP-HEADER01]  
MSP430F1222@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F1232@SOIC28(ISP) [ISP-HEADER01]  
MSP430F1232@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F133@QFN64(ISP) [ISP-HEADER01]  
MSP430F133@TQFP64(ISP) [ISP-HEADER01]  
MSP430F135@QFN64(ISP) [ISP-HEADER01]  
MSP430F135@TQFP64(ISP) [ISP-HEADER01]  
MSP430F147@QFN64(ISP) [ISP-HEADER01]  
MSP430F147@TQFP64(ISP) [ISP-HEADER01]

MSP430F1471@QFN64(ISP) [ISP-HEADER01]  
MSP430F1471@TQFP64(ISP) [ISP-HEADER01]  
MSP430F148@QFN64(ISP) [ISP-HEADER01]  
MSP430F148@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1481@QFN64(ISP) [ISP-HEADER01]  
MSP430F1481@TQFP64(ISP) [ISP-HEADER01]  
MSP430F149@QFN64(ISP) [ISP-HEADER01]  
MSP430F149@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1491@QFN64(ISP) [ISP-HEADER01]  
MSP430F1491@TQFP64(ISP) [ISP-HEADER01]  
MSP430F155@QFN64(ISP) [ISP-HEADER01]  
MSP430F155@TQFP64(ISP) [ISP-HEADER01]  
MSP430F156@QFN64(ISP) [ISP-HEADER01]  
MSP430F156@TQFP64(ISP) [ISP-HEADER01]  
MSP430F157@QFN64(ISP) [ISP-HEADER01]  
MSP430F157@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1610@QFN64(ISP) [ISP-HEADER01]  
MSP430F1610@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1611@QFN64(ISP) [ISP-HEADER01]  
MSP430F1611@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1612@QFN64(ISP) [ISP-HEADER01]  
MSP430F1612@TQFP64(ISP) [ISP-HEADER01]  
MSP430F167@QFN64(ISP) [ISP-HEADER01]  
MSP430F167@TQFP64(ISP) [ISP-HEADER01]  
MSP430F168@QFN64(ISP) [ISP-HEADER01]  
MSP430F168@TQFP64(ISP) [ISP-HEADER01]  
MSP430F169@QFN64(ISP) [ISP-HEADER01]  
MSP430F169@TQFP64(ISP) [ISP-HEADER01]  
MSP430F412@QFN64(ISP) [ISP-HEADER01]  
MSP430F412@TQFP64(ISP) [ISP-HEADER01]  
MSP430F413@QFN64(ISP) [ISP-HEADER01]  
MSP430F413@TQFP64(ISP) [ISP-HEADER01]  
MSP430F435@TQFP100(ISP) [ISP-HEADER01]  
MSP430F435@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4351@TQFP100(ISP) [ISP-HEADER01]  
MSP430F4351@TQFP80(ISP) [ISP-HEADER01]  
MSP430F436@TQFP100(ISP) [ISP-HEADER01]  
MSP430F436@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4361@TQFP100(ISP) [ISP-HEADER01]  
MSP430F4361@TQFP80(ISP) [ISP-HEADER01]  
MSP430F437@TQFP100(ISP) [ISP-HEADER01]  
MSP430F437@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4371@TQFP100(ISP) [ISP-HEADER01]

MSP430F4371@TQFP80 ( ISP ) [ ISP-HEADER01 ]  
MSP430F447@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
MSP430F448@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
MSP430F449@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG4250@QFN48 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG4260@QFN48 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG4270@QFN48 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG437@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG437@TQFP80 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG438@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG438@TQFP80 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG439@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
MSP430FG439@TQFP80 ( ISP ) [ ISP-HEADER01 ]

## TMC

### E ( E ) PROM / FRAM / NVRAM

24A01 [ ( SA602A ) ] 24A01@TSSOP8 [ ( SA026 ) ]	24A01@SOIC8
24A02 24A02@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ]	24A02@TSSOP8
24A04 [ ( SA602A ) ] 24A04@TSSOP8 [ ( SA026 ) ]	24A04@SOIC8
24A08 24A08@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ]	24A08@TSSOP8
24A16 [ ( SA602A ) ] 24A16@TSSOP8 [ ( SA026 ) ]	24A16@SOIC8
( 08bit ) 93LC46 ( 08bit ) @SOIC8 [ ( SA602A ) ] [ ( SA026 ) ]	93LC46
93LC46 ( 16bit ) [ ( SA602A ) ]	93LC46 ( 16bit ) @SOIC8
93LC46 ( 16bit ) @TSSOP8 [ ( SA026 ) ] ( 08bit )	93LC56
93LC56 ( 08bit ) @SOIC8 [ ( SA602A ) ] [ ( SA026 ) ]	93LC56 ( 08bit ) @TSSOP8



93LC56(16bit) [(SA602A)]	93LC56(16bit)@SOIC8
93LC56(16bit)@TSSOP8 [(SA026)]	
93LC57	
93LC57@SOIC8 [(SA602A)] [(SA026)]	93LC57@TSSOP8
93LC66(08bit) [(SA602A)]	93LC66(08bit)@SOIC8
93LC66(08bit)@TSSOP8 [(SA026)] (16bit)	93LC66
93LC66(16bit)@SOIC8 [(SA602A)] [(SA026)]	93LC66(16bit)@TSSOP8
93LC86(08bit) [(SA602A)]	93LC86(08bit)@SOIC8
93LC86(08bit)@TSSOP8 [(SA026)] (16bit)	93LC86
93LC86(16bit)@SOIC8 [(SA602A)] [(SA026)]	93LC86(16bit)@TSSOP8

## TOPRO

### MICROCONTROLLER

TP2804H [(SA244)]	TP2804H@PLCC44
TP2804H@TQFP44 [(SA245A)]	
TP2804L	
TP2804L@PLCC44 [(SA244)] [(SA245A)]	TP2804L@TQFP44
TP2808H [(SA244)]	TP2808H@PLCC44
TP2808H@TQFP44 [(SA245A)]	
TP2808L	
TP2808L@PLCC44 [(SA244)] [(SA245A)]	TP2808L@TQFP44
TP2851 [(SA244)]	TP2851@PLCC44
TP2851@TQFP44 [(SA245A)]	
TP2852	
TP2852@PLCC44 [(SA244)] [(SA245A)]	TP2852@TQFP44

# TOSHIBA

## E ( E ) PROM / FRAM / NVRAM

TC541000AF@PLCC32 [ ( SA015A1T ) ]  
TC541000AP  
TC541001AF@PLCC32 [ ( SA015A1T ) ]  
TC541001AP  
TC54256AF TC54256AF@SOIC28  
[ ( SA404 ) ]  
TC54256AP TC54256AP@SOIC28  
[ ( SA404 ) ]  
TC544000P  
TC54512AF  
TC54512AP  
TC571000  
TC571000AD  
TC571000D  
TC571001AD  
TC571001D  
TC571024D  
TC57256  
TC57256A  
TC57256AD  
TC57256ADI  
TC57256D  
TC574000D  
TC574096D  
TC574200D  
TC57512  
TC57512AD  
TC578200D  
TC57H1000AD  
TC57H1001AD  
TC57H256D TC58128AFT@TSOP48 [ ( SA247-  
B005 ) ]  
TC58512FT@TSOP48 [ ( SA247-B005 ) ]  
TC58DVG02A1FT00@TSOP48 [ ( SA247-B005 ) ]  
TC58DVG02A2FT00@TSOP48 [ ( SA247-B005 ) ]  
TC58DVM72A1FT00@TSOP48 [ ( SA247-B005 ) ]  
TC58DVM72A1TG00@TSOP48 [ ( SA247-B005 ) ]  
TC58DVM82A1FT00@TSOP48 [ ( SA247-B005 ) ]

TC58DVM82A1XBJ1@TFBGA56 [(SA642U-B197-T064F001Y)]  
TC58DVM92A1FT00@TSOP48 [(SA247-B005)]  
TC58F400@PSOP44 [(SA638-B006)] TC58F400@TSOP48 [(SA247-B005)]  
TC58F401@PSOP44 [(SA638-B006)] TC58F401@TSOP48 [(SA247-B005)]  
TC58FVB004FT@TSOP40 [(SA409T)] TC58FVB008FT@TSOP40 [(SA409T)]  
TC58FVB016FT@TSOP40 [(SA409T)]  
TC58FVB160AFT@TSOP48 [(SA247-B005)]  
TC58FVB160AXB@TFBGA48 [(SA642B\_B026A-Y072F001)]  
TC58FVB160FT@TSOP48 [(SA247-B005)]  
TC58FVB321FT@TSOP48 [(SA247-B005)]  
TC58FVB321XB@TFBGA56 [(SA642A-B026A-Y096F001)]  
TC58FVB400F@PSOP44 [(SA638)]  
TC58FVB400FT@TSOP48 [(SA247-B005)]  
TC58FVB641FT@TSOP48 [(SA247-B005)]  
TC58FVB641XB@TFBGA63 [(SA642A-B026A-Y096N001)]  
TC58FVB800F@PSOP44 [(SA638)]  
TC58FVB800FT@TSOP48 [(SA247-B005)]  
TC58FVM5B2AFT@TSOP48 [(SA247-B005)]  
TC58FVM5B2ATG@TSOP48 [(SA247-B005)]  
TC58FVM5B2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5B2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5B3AFT@TSOP48 [(SA247-B005)]  
TC58FVM5B3ATG@TSOP48 [(SA247-B005)]  
TC58FVM5B3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5B3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T2AFT@TSOP48 [(SA247-B005)]  
TC58FVM5T2ATG@TSOP48 [(SA247-B005)]  
TC58FVM5T2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T3AFT@TSOP48 [(SA247-B005)]  
TC58FVM5T3ATG@TSOP48 [(SA247-B005)]  
TC58FVM5T3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM6B2AFT@TSOP48 [(SA247-B005)]  
TC58FVM6B2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]  
TC58FVM6B5BTG@TSOP48 [(SA247-B005)]  
TC58FVM6B5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]  
TC58FVM6T2AFT@TSOP48 [(SA247-B005)]  
TC58FVM6T2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]  
TC58FVM6T5BTG@TSOP48 [(SA247-B005)]

TC58FVM6T5BXG@TFBGA56 [ (SA642U-B026A-T064F001Y) ]  
TC58FVM7B2AFT@TSOP56 [ (SA628-B045) ]  
TC58FVM7B5BTG@TSOP56 [ (SA628-B102) ]  
TC58FVM7B5BXG@FBGA80 [ (SA642R-B099A-T096F001Y) ]  
TC58FVM7T2AFT@TSOP56 [ (SA628-B045) ]  
TC58FVM7T5BTG@TSOP56 [ (SA628-B102) ]  
TC58FVM7T5BXG@FBGA80 [ (SA642R-B099A-T096F001Y) ]  
TC58FVT004FT@TSOP40 [ (SA409T) ] TC58FVT008FT@TSOP40  
[ (SA409T) ]  
TC58FVT016FT@TSOP40 [ (SA409T) ]  
TC58FVT160AFT@TSOP48 [ (SA247-B005) ]  
TC58FVT160AXB@TFBGA48 [ (SA642B\_B026A-Y072F001) ]  
TC58FVT160FT@TSOP48 [ (SA247-B005) ]  
TC58FVT321FT@TSOP48 [ (SA247-B005) ]  
TC58FVT321XB@TFBGA56 [ (SA642A-B026A-Y096F001) ]  
TC58FVT400F@PSOP44 [ (SA638) ]  
TC58FVT400FT@TSOP48 [ (SA247-B005) ]  
TC58FVT641FT@TSOP48 [ (SA247-B005) ]  
TC58FVT641XB@TFBGA63 [ (SA642A-B026A-Y096N001) ]  
TC58FVT800F@PSOP44 [ (SA638) ]  
TC58FVT800FT@TSOP48 [ (SA247-B005) ]  
TC58FYB160FT@TSOP48 [ (SA247-B005) ]  
TC58FYT160FT@TSOP48 [ (SA247-B005) ]  
TC58NVG0S3AFT05@TSOP48 [ (SA247-B005) ]  
TC58V64BFT@TSOP44 [ (SA645-B005) ] TC89101  
(08bit)  
TC89101(16bit) TC89102  
(08bit)  
TC89102(16bit)  
TC89121  
TC89121@SOIC8 [ (SA602A) ]  
TC89122  
TC89122@SOIC8 [ (SA602A) ]  
TC97101  
TC9WMA1FK@US8 [ (BBBB) ] TC9WMA2FK@US8  
[ (BBBB) ]  
TC9WMB1AFK@US8 [ (BBBB) ] TC9WMB1AFU@SM8  
[ (SA666) ]  
TC9WMB1FK@US8 [ (BBBB) ] TC9WMB2AFK@US8  
[ (BBBB) ]  
TC9WMB2AFU@SM8 [ (SA666) ] TC9WMB2FK@US8  
[ (BBBB) ]  
TC9WMB4FU@SM8 [ (SA666) ] TC9WMB8FU@SM8

[ ( SA666 ) ]  
TC9WMC1FK@US8 [ ( BBBB ) ] TC9WMC1FU@SM8  
[ ( SA666 ) ]  
TC9WMC2FK@US8 [ ( BBBB ) ] TC9WMC2FU@SM8  
[ ( SA666 ) ]  
TC9WMC4FK@US8 [ ( BBBB ) ] TC9WMC4FU@SM8  
[ ( SA602A ) ]  
TH50VPF5582ADSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VPF5583ADSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VPF5682CDSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VPF5683CDSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VPF5782AASB@FBGA73 [ ( SA664A-B096A-W115F001Y ) ]  
TH50VPF5783AASB@FBGA73 [ ( SA664A-B096A-W115F001Y ) ]  
TH50VPF6782AASB@FBGA73 [ ( SA664A-B096A-W115F001Y ) ]  
TH50VPF6783AASB@FBGA73 [ ( SA664A-B096A-W115F001Y ) ]  
TH50VSF1480AASB@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF1481AASB@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF2480AASB@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF2481AASB@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF2580AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2581AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2582AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2582ADSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2582BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2583AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2583ADSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2583BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2590AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2682BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2683BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF3580AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3581AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3582AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3582BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF3583AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3583BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF3680AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3681AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3682AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3682BDSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VSF3683AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3683BDSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VSF4682AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]

TH50VSF4683AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TMM24128  
TMM24128A  
TMM24128AP  
TMM24256  
TMM24256A  
TMM24256AP  
TMM24256B  
TMM24512  
TMM24512A  
TMM24512P  
TMM2464AP  
TMM27128  
TMM27128A  
TMM27128ADI  
TMM27128AP  
TMM27256  
TMM27256A  
TMM27256AD  
TMM27256ADI  
TMM27256BD  
TMM27256BDI  
TMM27256D  
TMM27256DI  
TMM2732  
TMM2732A  
TMM2732D  
TMM27512  
TMM27512AD  
TMM27512ADI  
TMM27512D  
TMM27512DI  
TMM2764  
TMM2764AD  
TMM2764ADI  
TMM2764AP  
TMM2764D  
TMM2764DI  
TV00560002ADBB@FBGA73 [ ( SA642U-B095A-W064F001Y ) ]  
TV00560002DDGB@FBGA81 [ ( SA642R-B079A-T096F001N ) ]  
TV00560002EDGB@FBGA81 [ ( SA642R-B079A-T096F001N ) ]  
TV00560003ADBB@FBGA73 [ ( SA642U-B095A-W064F001Y ) ]  
TV00569002AABD(NAND)@FBGA107 [ ( SA664A-B128A-W115F001Y ) ]

TV00569002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569002BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569002BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569003BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569003BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00570002AABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00570002ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]  
TV00570002CDGB@FBGA81 [(SA642R-B039A-Y096F001Y)]  
TV00570003AABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00570003ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]  
TV00570003CDGB@FBGA81 [(SA642R-B039A-Y096F001Y)]  
TV00578002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578002CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578002CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578003CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578003CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579002AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579003AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A002CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A002CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A003CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A003CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00670002ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00670002CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670002CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670002CDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00670003ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00670003CABB@FBGA73 [(SA664A-B096A-W115F001Y)]

TV00670003CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TV00670003CDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
 TV0067A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0067A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV0067A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0067A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TY00679002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TY00679003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TY8000A010AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY9000A000CMHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TY9000A000GMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY9000A400AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TYA000AC00EOGG@TFBGA225 [(SA678L-B294-Y225F001Y)]

## DRAM & SRAM

TC518128 [(SA630)]	TC518128@SOIC32
TC518129 [(SA630)]	TC518129@SOIC32
TC51832 [(SA630)]	TC51832@SOIC28
TC518512 [(SA630)]	TC518512@SOIC32
TC551001FL [(SA630)]	TC551001FL@SOIC32
TC551001PL [(SA630)]	TC551001PL@SOIC32
TC55257 [(SA630)]	TC55257@SOIC28
TC55257L [(SA630)]	TC55257L@SOIC28
TC55258 [(SA630)]	TC55258@SOIC28
TC55258L [(SA630)]	TC55258L@SOIC28
TC55328 [(SA630)]	TC55328@SOIC28
TC5561P [(SA646)]	TC5561P@SOJ24
TC5562P [(SA646)]	TC5562P@SOJ24



TC5563APL [ (SA630) ]	TC5563APL@SOIC28
TC5564APL [ (SA630) ]	TC5564APL@SOIC28
TC5565AFL [ (SA630) ]	TC5565AFL@SOIC28
TC5565APL [ (SA630) ]	TC5565APL@SOIC28
TC5588 [ (SA630) ]	TC5588@SOIC28
TC55B88 [ (SA630) ]	TC55B88@SOIC28
TMM2018 [ (SA015A1T) ]	TMM2018@PLCC32
TMM2063 [ (SA630) ]	TMM2063@SOIC28

## MICROCONTROLLER

TMP87P808LM@SOP28(Toshiba) [ (BM11116) ]  
 TMP87P808LN@SDIP28(Toshiba) [ (BM11122) ]  
 TMP87P808M@SOP28(Toshiba) [ (BM11116) ]  
 TMP87P808N@SDIP28(Toshiba) [ (BM11122) ]  
 TMP87P844N@SDIP42(Toshiba) [ (BM11108) ]  
 TMP87P844NG@SDIP42(Toshiba) [ (BM11108) ]  
 TMP87PH00DF@QFP64(Toshiba) [ (BM1173) ]  
 TMP87PH00F@QFP64(Toshiba) [ (BM1137) ]  
 TMP87PH00LF@QFP64(Toshiba) [ (BM1173) ]  
 TMP87PH00N@SDIP64(Toshiba) [ (BM1136) ]  
 TMP87PH20F@QFP80(Toshiba) [ (BM1138) ]  
 TMP87PH40AF@PQFP64(Toshiba) [ (BM1137) ]  
 TMP87PH40AN@SDIP64(Toshiba) [ (BM1136) ]  
 TMP87PH46N@SDIP42(Toshiba) [ (BM1193) ]  
 TMP87PH47LU@QFP44(Toshiba) [ (BM1194C) ]  
 TMP87PH47U@QFP44(Toshiba) [ (BM1194C) ]  
 TMP87PM14F@QFP64(Toshiba) [ (BM1199) ]  
 TMP87PM14N@SDIP64(Toshiba) [ (BM1198) ]  
 TMP87PM20F@QFP80(Toshiba) [ (BM1138) ]  
 TMP87PM29U@LQFP64(Toshiba) [ (BM11117) ]  
 TMP87PM34AN@SDIP42(Toshiba) [ (BM1183A) ]  
 TMP87PM36N@SDIP42(Toshiba) [ (BM1183A) ]  
 TMP87PM40AF@PQFP64(Toshiba) [ (BM1137) ]

TMP87PM40AN@SDIP64(Toshiba) [(BM1136)]  
TMP87PM41F@QFP64(Toshiba) [(BM1137)]  
TMP87PM41N@SDIP64(Toshiba) [(BM1136)]  
TMP87PM41U@LQFP64(Toshiba) [(BM1121)]  
TMP87PM43N@SDIP42(Toshiba) [(BM1163)]  
TMP87PM70F@QFP80(Toshiba) [(BM1150B)]  
TMP87PM74F@QFP80(Toshiba) [(BM11120)]  
TMP87PM75F@QFP100(Toshiba) [(BM11124)]  
TMP87PM78F@QFP100(Toshiba) [(BM1188)]  
TMP87PP21DF@LQFP80(Toshiba) [(BM11105)]  
TMP87PP21F@QFP80(Toshiba) [(BM11104)]  
TMP87PP23F@QFP100(Toshiba) [(BM1185A)]  
TMP87PP24F@LQFP100(Toshiba) [(BM11127)]  
TMP87PP71F@QFP80(Toshiba) [(BM11107)]  
TMP87PS38F@QFP44(Toshiba) [(BM11136)]  
TMP87PS38N@SDIP42(Toshiba) [(BM11112)]  
TMP87PS39F@QFP64(Toshiba) [(BM11138)]  
TMP87PS39N@SDIP64(Toshiba) [(BM11118)]  
TMP87PS64F@QFP100(Toshiba) [(BM1185A)]  
TMP87PS71F@QFP80(Toshiba) [(BM11107)]

## TOSHIBA-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

TC58DAM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM82A1@FBGA63 [(SA642B-B026A-Y072F001)]  
TC58DVM82A1@TSOP48 [(SA247-B005)]

## TURBO IC

### E ( E ) PROM / FRAM / NVRAM

TU24C01 [(SA602A)]	TU24C01@SOIC8
TU24C02 [(SA602A)]	TU24C02@SOIC8
TU24C04 [(SA602A)]	TU24C04@SOIC8

TU24C08 [ (SA602A) ]	TU24C08@SOIC8
TU24C128 [ (SA602A) ]	TU24C128@SOIC8
TU24C16 [ (SA602A) ]	TU24C16@SOIC8
TU24C16@TSSOP8 [ (SA026) ]	
TU24C256 TU24C256@SOIC8 [ (SA602A) ]	
TU24C32 TU24C32@SOIC8 [ (SA602A) ]	
TU24C64 TU24C64@SOIC8 [ (SA602A) ]	

## UBICOM

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [ (SA626A) ] [ (SA626A) ]	SX20AC/SS@SSOP20
SX28AC/DP G	SX28AC/DP/
SX28AC/SS/G@SSOP28 [ (SA626A) ] [ (SA626A) ]	SX28AC/SS@SSOP28
SX48BD/G@TQFP48 [ (SA248) ] [ (SA248) ]	SX48BD@TQFP48

## UMC

### E (E) PROM / FRAM / NVRAM

2732  
2764

### DRAM & SRAM

UM6116 [ (SA015A1T) ]	UM6116@PLCC32
UM6116A	UM6116A@PLCC32

[ (SA015A1T) ]

UM61256

UM61256@SOIC28

[ (SA630) ]

UM61257

UM61512

UM61512@SOIC32 [ (SA630) ]

UM6164

UM6164@SOIC28 [ (SA630) ]

UM6167

UM621024

UM621024@SOIC32

[ (SA630) ]

UM62256

UM62256@SOIC28

[ (SA630) ]

UM62256A

UM62256A@SOIC28

[ (SA630) ]

UM6264

UM6264@SOIC28

[ (SA630) ]

UM6264A

UM6264A@SOIC28

[ (SA630) ]

## UTRON

### E ( E ) PROM / FRAM / NVRAM

UT61256C

UT61256C@SOIC28

[ (SA630) ]

UT61256C@TSOP28 [ (SA430T) ]

UT6164C@SOIC28

[ (SA630) ]

UT6164C@TSOP28 [ (SA430T) ]

UT61L256C

UT61L256C@SOIC28 [ (SA630) ]

UT61L256C@TSOP28

[ (SA430T) ]

UT62256C

UT62256C@SOIC28

[ (SA630) ]

UT62256C@TSOP28 [ (SA430T) ]

UT62256CE

UT62256CE@SOIC28 [ (SA630) ]

UT62256CE@TSOP28

[ (SA430T) ]

UT62257C

UT62257C@SOIC28

[ (SA630) ]

UT62257C@TSOP28 [ (SA430T) ]

UT6264C

UT6264C@SOIC28 [(SA630)]

UT62L256C

UT62L256C@SOIC28 [(SA630)]

[(SA430T)]

UT62L64C

[(SA630)]

UT62W256C

[(SA630)]

UT62W256C@TSOP28 [(SA430T)]

UT62W64C

UT62W64C@SOIC28 [(SA630)]

UT62L256C@TSOP28

UT62L64C@SOIC28

UT62W256C@SOIC28

## VANTIS

### PLD

PALCE20RA10

[(SA008A)]

PALCE20RA10@SOIC24 [(SA404)]

PALCE20RA10H

PALCE20RA10H@PLCC28 [(SA008A)]

[(SA404)]

PALCE20RA10Q

[(SA008A)]

PALCE20RA10Q@SOIC24 [(SA404)]

PALCE20RA10@PLCC28

PALCE20RA10H@SOIC24

PALCE20RA10Q@PLCC28

## VERSACHIPS

### MICROCONTROLLER

V87C54

[(SA244)]

V87C54@TQFP44 [(SA245A)]

V87C58

V87C58@PLCC44 [(SA244)]

[(SA245A)]

V87C54@PLCC44

V87C58@TQFP44

## VLSI

## E ( E ) PROM / FRAM / NVRAM

VT27C128  
VT27C256  
VT27C512  
VT27C64  
VT28H64  
VT28HC64

## PLD

GAL16V8

## WELTREND

### MICROCONTROLLER

WT61P4K420@SDIP42 [ ( SA028 ) ] [ ( SA028 ) ]	WT61P4K421@SDIP42
WT61P4K422@SDIP42 [ ( SA028 ) ] [ ( SA244 ) ]	WT61P4L440@PLCC44
WT61P4N400	
WT61P4N401	
WT61P6K420@SDIP42 [ ( SA028 ) ] [ ( SA244 ) ]	WT61P6L440@PLCC44
WT61P6L441@PLCC44 [ ( SA244 ) ] [ ( SA028 ) ]	WT62P1-K42@SDIP42
WT62P1-N28(dip28) (dip40)	WT62P1-N40
WT62P1-N42(dip42) [ ( SA638 ) ]	WT62P1-S44@PSOP44
WT62P2-K42@SDIP42 [ ( SA028 ) ] [ ( SA244 ) ]	WT62P2-L44@PLCC44
WT62P2-N40(dip40) (dip42)	WT62P2-N42
WT62P2-S44@PSOP44 [ ( SA638 ) ] [ ( SA404 ) ]	WT65F1@SOIC28
WT65F1@TQFP48 [ ( SA248 ) ] [ ( SA602 ) ]	WT6702F@SOP16
WT6702F@SOP20 [ ( SA404 ) ] [ ( SA404 ) ]	WT6702F@SOP24

WT6702F@SSOP20 [ (SA674) ]  
[ (SA404) ]

WT6703F@SOP20

WT6703F@SOP24 [ (SA404) ]  
[ (SA404) ]

WT6703F@SOP28

WT6703F@SSOP24 [ (SA674) ]  
[ (SA602) ]

WT6703FS161@SSOP16

WT6703FS163@SSOP16 [ (SA602) ]

## WHITE ELECTRONIC DESIGNS

### E (E) PROM / FRAM / NVRAM

WE128K8

WE256K8

WE512K8

WF256K8

WF256K8@CLCC32 [ (SA015A1T) ]  
[ (SA661) ]

WF256K8@CSOJ32

WF512K8  
[ (SA015A1T) ]

WF512K8@CLCC32

WF512K8@CSOJ32 [ (SA661) ]

WME128K8

WME128K8@CLCC32 [ (SA015A1T) ]  
[ (SA661) ]

WME128K8@CSOJ32

WMF128K8  
[ (SA015A1T) ]

WMF128K8@CLCC32

WMF128K8@CSOJ32 [ (SA661) ]

WMF256K8

WMF256K8@CLCC32 [ (SA015A1T) ]  
[ (SA661) ]

WMF256K8@CSOJ32

WMF512K8  
[ (SA015A1T) ]

WMF512K8@CLCC32

WMF512K8@CSOJ32 [ (SA661) ]

WMS128K8

WMS128K8@CLCC32 [ (SA015A1T) ]  
[ (SA661) ]

WMS128K8@CSOJ32

WMS256K8  
[ (SA015A1T) ]

WMS256K8@CLCC32

WMS256K8@CSOJ32 [ (SA661) ]

WMS512K8

WMS512K8@CLCC32 [ (SA015A1T) ]  
[ (SA661) ]

WMS512K8@CSOJ32

# WINBOND

## E ( E ) PROM / FRAM / NVRAM

W15B020L	W15B020L@SOIC8
[ ( SA602A ) ]	
W15B020M	W15B020M@SOIC8
[ ( SA602A ) ]	
W15B040L	W15B040L@SOIC8
[ ( SA602A ) ]	
W15B040M	W15B040M@SOIC8
[ ( SA602A ) ]	
W19B160BB@FBGA48	[ ( SA642G-B026A-T048F001Y ) ]
W19B160BB@TSOP48	[ ( SA247-B005 ) ]
W19B160BT@FBGA48	[ ( SA642G-B026A-T048F001Y ) ]
W19B160BT@TSOP48	[ ( SA247-B005 ) ]
W19B320AB@FBGA48	[ ( SA642A-B026A-Y096F001Y ) ]
W19B320AB@TSOP48	[ ( SA247-B005 ) ]
W19B320AT@FBGA48	[ ( SA642A-B026A-Y096F001Y ) ]
W19B320AT@TSOP48	[ ( SA247-B005 ) ]
W19B320BB@FBGA48	[ ( SA642G-B026A-T048F001Y ) ]
W19B320BB@TSOP48	[ ( SA247-B005 ) ]
W19B320BT@FBGA48	[ ( SA642G-B026A-T048F001Y ) ]
W19B320BT@TSOP48	[ ( SA247-B005 ) ]
W19B320SB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B320SB@TSOP48	[ ( SA247-B005 ) ]
W19B320ST@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B320ST@TSOP48	[ ( SA247-B005 ) ]
W19B322MB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B322MB@TSOP48	[ ( SA247-B005 ) ]
W19B322MT@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B322MT@TSOP48	[ ( SA247-B005 ) ]
W19B323MB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B323MB@TSOP48	[ ( SA247-B005 ) ]
W19B323MT@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B323MT@TSOP48	[ ( SA247-B005 ) ]
W19B324MB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B324MB@TSOP48	[ ( SA247-B005 ) ]
W19B324MT@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B324MT@TSOP48	[ ( SA247-B005 ) ]
W19L320SB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]



W19L320SB@TSOP48 [(SA247-B005)]	
W19L320ST@FBGA48 [(SA642F-B026A-T064F001)]	
W19L320ST@TSOP48 [(SA247-B005)]	
W25B40(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40(Bottom Boot)@WSON8 [(SA683)]	
W25B40(Top Boot)@SOIC8 [(SA602A)]	
W25B40(Top Boot)@WSON8 [(SA683)]	
W25B40A(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40A(Bottom Boot)@WSON8 [(SA683)]	
W25B40A(Top Boot)@SOIC8 [(SA602A)]	
W25B40A(Top Boot)@WSON8 [(SA683)]	
W25D10 [(SA602A)]	W25D10(SN)@SOIC8
W25D10(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D10(ZP)@WSON8
W25D20 [(SA602A)]	W25D20(SN)@SOIC8
W25D20(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D20(ZP)@WSON8
W25D40 [(SA602A)]	W25D40(SN)@SOIC8
W25D40(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D40(ZP)@WSON8
W25D80 [(SA602A)]	W25D80(SN)@SOIC8
W25D80(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D80(ZP)@WSON8
W25P10@SOIC8 [(SA602A)] [(SA683)]	W25P10@WSON8
W25P16@SOIC16 [(SA404)]	
W25P16@SOIC16(ISP) [ISP-HEADER01]	
W25P16@SOIC8 [(SA023A)] [ISP-HEADER01]	W25P16@SOIC8(ISP) [ISP-HEADER01]
W25P16@WSON8 [(SA683)] [ISP-HEADER01]	W25P16@WSON8(ISP) [ISP-HEADER01]
W25P20@SOIC8 [(SA602A)] [(SA683)]	W25P20@WSON8
W25P32@SOIC16 [(SA404)]	
W25P32@SOIC16(ISP) [ISP-HEADER01]	
W25P32@WSON8 [(SA683)] [ISP-HEADER01]	W25P32@WSON8(ISP) [ISP-HEADER01]
W25P40@SOIC8 [(SA602A)] [(SA683)]	W25P40@WSON8

W25P64@SOIC16 [(SA404)]	
W25P64@SOIC16(ISP) [ISP-HEADER01]	
W25P64@WSON8 [(SA683)]	W25P64@WSON8(ISP) [ISP-HEADER01]
W25P80@SOIC8 [(SA602A)]	W25P80@WSON8
[(SA683)]	
W25Q16@SOIC16 [(SA404)]	
W25Q16@SOIC16(ISP) [ISP-HEADER01]	
W25Q16@SOIC8 [(SA023A)]	W25Q16@SOIC8(ISP) [ISP-HEADER01]
W25Q16@WSON8 [(SA683)]	W25Q16@WSON8(ISP) [ISP-HEADER01]
W25Q16BV@SOIC16 [(SA404)]	W25Q16BV@SOIC8
[(SA023A)]	
W25Q16BV@WSON8 [(SA683)]	W25Q16V@SOIC16
[(SA404)]	
W25Q16V@SOIC8 [(SA023A)]	W25Q16V@WSON8
[(SA683)]	
W25Q32@SOIC16 [(SA404)]	
W25Q32@SOIC16(ISP) [ISP-HEADER01]	
W25Q32@WSON8 [(SA683)]	W25Q32@WSON8(ISP) [ISP-HEADER01]
W25Q32BV@SOIC16 [(SA404)]	W25Q32BV@WSON8
[(SA683)]	
W25Q32V@SOIC16 [(SA404)]	W25Q32V@WSON8
[(SA683)]	
W25Q64BV@SOIC16 [(SA404)]	W25Q64BV@SOIC8
[(SA023A)]	
W25Q80@SOIC8 [(SA602A)]	W25Q80@WSON8
[(SA683)]	
W25X10	W25X10(SN)@SOIC8
[(SA602A)]	
W25X10(SS)@SOIC8 [(SA023A)]	W25X10(ZP)@WSON8
[(SA683)]	
W25X10AV	W25X10AV(SN)@SOIC8
[(SA602A)]	
W25X10AV(SS)@SOIC8 [(SA023A)]	W25X10AV(ZP)@WSON8
[(SA683)]	
W25X10L	W25X10L(SN)@SOIC8
[(SA602A)]	
W25X10L(ZP)@WSON8 [(SA683)]	
W25X10V	
W25X10V(SN)@SOIC8 [(SA602A)]	W25X10V(SS)@SOIC8

[ (SA023A) ]	
W25X10V(ZP)@WSON8 [ (SA683) ]	W25X16@SOIC16
[ (SA404) ]	
W25X16@SOIC16(ISP) [ ISP-HEADER01 ]	
W25X16@SOIC8 [ (SA023A) ]	W25X16@SOIC8(ISP) [ ISP-
HEADER01 ]	
W25X20	W25X20(SN)@SOIC8
[ (SA602A) ]	
W25X20(SS)@SOIC8 [ (SA023A) ]	W25X20(ZP)@WSON8
[ (SA683) ]	
W25X20AV	W25X20AV(SN)@SOIC8
[ (SA602A) ]	
W25X20AV(SS)@SOIC8 [ (SA023A) ]	W25X20AV(ZP)@WSON8
[ (SA683) ]	
W25X20L	W25X20L(SN)@SOIC8
[ (SA602A) ]	
W25X20L(ZP)@WSON8 [ (SA683) ]	
W25X20V	
W25X20V(SN)@SOIC8 [ (SA602A) ]	W25X20V(SS)@SOIC8
[ (SA023A) ]	
W25X20V(ZP)@WSON8 [ (SA683) ]	W25X32@SOIC16
[ (SA404) ]	
W25X32@SOIC16(ISP) [ ISP-HEADER01 ]	
W25X32@SOIC8 [ (SA023A) ]	W25X32@SOIC8(ISP) [ ISP-
HEADER01 ]	
W25X40	W25X40(SN)@SOIC8
[ (SA602A) ]	
W25X40(SS)@SOIC8 [ (SA023A) ]	W25X40(ZP)@WSON8
[ (SA683) ]	
W25X40AV	W25X40AV(SN)@SOIC8
[ (SA602A) ]	
W25X40AV(SS)@SOIC8 [ (SA023A) ]	W25X40AV(ZP)@WSON8
[ (SA683) ]	
W25X40L	W25X40L(SN)@SOIC8
[ (SA602A) ]	
W25X40L(SS)@SOIC8 [ (SA023A) ]	W25X40L(ZP)@WSON8
[ (SA683) ]	
W25X40V	W25X40V(SN)@SOIC8
[ (SA602A) ]	
W25X40V(SS)@SOIC8 [ (SA023A) ]	W25X40V(ZP)@WSON8
[ (SA683) ]	
W25X64@SOIC16 [ (SA404) ]	
W25X64@SOIC16(ISP) [ ISP-HEADER01 ]	

W25X64@SOIC8 [(SA023A)]	W25X64@SOIC8(ISP) [ISP-
HEADER01]	
W25X80	W25X80(SN)@SOIC8
[(SA602A)]	
W25X80(SS)@SOIC8 [(SA023A)]	W25X80(ZP)@WSON8
[(SA683)]	
W25X80AV	W25X80AV(SN)@SOIC8
[(SA602A)]	
W25X80AV(SS)@SOIC8 [(SA023A)]	W25X80AV(ZP)@WSON8
[(SA683)]	
W25X80L	W25X80L(SS)@SOIC8
[(SA023A)]	
W25X80L(ZP)@WSON8 [(SA683)]	
W25X80V	
W25X80V(SN)@SOIC8 [(SA602A)]	W25X80V(SS)@SOIC8
[(SA023A)]	
W25X80V(ZP)@WSON8 [(SA683)]	
W27C01	
W27C01@PLCC32 [(SA015A1T)]	W27C01@VSOP32
[(SA620)]	
W27C010	W27C010@PLCC32
[(SA015A1T)]	
W27C010@SOIC32 [(SA438T)]	
W27C02	
W27C02@PLCC32 [(SA015A1T)]	W27C02@VSOP32
[(SA620)]	
W27C020	W27C020@PLCC32
[(SA015A1T)]	
W27C020M	W27C020M@PLCC32
[(SA015A1T)]	
W27C257	W27C257@PLCC32
[(SA015A1T)]	
W27C4096	W27C4096@PLCC44
[(SA244)]	
W27C4096@TSOP40 [(SA409T)]	
W27C512	
W27C512@PLCC32 [(SA015A1T)]	W27C512@TSOP28
[(SA430T)]	
W27C520@SOIC20 [(SA404)]	W27C520@TSSOP20
[(SA026)]	
W27E01	W27E01@PLCC32
[(SA015A1T)]	
W27E01@VSOP32 [(SA620)]	

W27E010  
 W27E010@PLCC32 [ (SA015A1T) ]                      W27E010@SOIC32  
 [ (SA438T) ]  
 W27E02    W27E02@PLCC32  
 [ (SA015A1T) ]  
 W27E02@VSOP32 [ (SA620) ]  
 W27E020  
 W27E020@PLCC32 [ (SA015A1T) ]  
 W27E040  
 W27E040@PLCC32 [ (SA015A1T) ]                      W27E040@SOIC32  
 [ (SA438T) ]  
 W27E257    W27E257@PLCC32  
 [ (SA015A1T) ]  
 W27E4096    W27E4096@PLCC44  
 [ (SA244) ]  
 W27E4096@TSOP40 [ (SA409T) ]  
 W27E512  
 W27E512@PLCC32 [ (SA015A1T) ]                      W27E512@TSOP28  
 [ (SA430T) ]  
 W27E520@SOIC20 [ (SA404) ]                              W27E520@TSSOP20  
 [ (SA026) ]  
 W27L01    W27L01@PLCC32  
 [ (SA015A1T) ]  
 W27L01@VSOP32 [ (SA620) ]  
 W27L010  
 W27L010@PLCC32 [ (SA015A1T) ]  
 W27L02  
 W27L02@PLCC32 [ (SA015A1T) ]                              W27L02@VSOP32  
 [ (SA620) ]  
 W27L520@SOIC20 [ (SA404) ]                              W27L520@TSSOP20  
 [ (SA026) ]  
 W28F321BB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
 W28F321BT@TSOP48 [ (SA247-B005) ]  
 W28F321TB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
 W28F321TT@TSOP48 [ (SA247-B005) ]  
 W28F641BB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
 W28F641BT@TSOP48 [ (SA247-B005) ]  
 W28F641TB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
 W28F641TT@TSOP48 [ (SA247-B005) ]                      W28J160BT@TSOP48 [ (SA247-  
 B005) ]  
 W28J160TT@TSOP48 [ (SA247-B005) ]  
 W28J161BB@TFBGA48 [ (SA634A-B005A-Y048F001) ]  
 W28J161TB@TFBGA48 [ (SA634A-B005A-Y048F001) ]

W28J320BT@TSOP48 [(SA247-B005)]	W28J320TT@TSOP48 [(SA247-B005)]
W28J321BB@TFBGA48 [(SA634A-B005A-Y048F001)]	
W28J321TB@TFBGA48 [(SA634A-B005A-Y048F001)]	
W28J800BT@TSOP48 [(SA247-B005)]	W28J800TT@TSOP48 [(SA247-B005)]
W28V400BT@TSOP48 [(SA247-B005)]	W28V400TT@TSOP48 [(SA247-B005)]
W29C010 [(SA015A1T)]	W29C010@PLCC32
W29C011A [(SA015A1T)]	W29C011A@PLCC32
W29C020 [(SA015A1T)]	W29C020@PLCC32
W29C020@SOIC32 [(SA438T)] [(SA410T)]	W29C020@TSOP32
W29C020C W29C020C@PLCC32 [(SA015A1T-B001)]	
W29C020C@TSOP32 [(SA410T-B003)]	W29C020C@VSOP32 [(SA620-B005)]
W29C040 B001]	W29C040@PLCC32 [(SA015A1T-B001)]
W29C040@TSOP32 [(SA410T-B003)] B005)]	W29C040@VSOP32 [(SA620-B005)]
W29C101 [(SA244)]	W29C101@PLCC44
W29C101@TSOP40 [(SA409T)]	
W29C102 W29C102@PLCC44 [(SA244)]	W29C102@TSOP40
[(SA409T)]	
W29EE010 [(SA015A1T)]	W29EE010@PLCC32
W29EE010@SOIC32 [(SA438T)] [(SA410T)]	W29EE010@TSOP32
W29EE011 [(SA015A1T)]	W29EE011@PLCC32
W29EE011@SOIC32 [(SA438T)]	
W29EE012 W29EE012@PLCC32 [(SA015A1T)]	W29EE012@SOIC32
[(SA438T)]	
W29EE512 [(SA015A1T)]	W29EE512@PLCC32
W29EE512@SOIC32 [(SA438T)]	W29EE512@TSOP32

[ (SA410T) ]	
W29F040	W29F040@PLCC32
[ (SA015A1T) ]	
W29F040@TSOP32 [ (SA410T) ]	W29F102@PLCC44
[ (SA244) ]	
W29F102@TSOP40 [ (SA623) ]	W29L102@PLCC44
[ (SA244) ]	
W29L102@TSOP40 [ (SA623) ]	
W39F010	
W39F010@PLCC32 [ (SA015A1T-B001) ]	
W39F010@TSOP32[12.4mm] [ (SA620-B005) ]	
W39F010@TSOP32[18.4mm] [ (SA410T-B003) ]	
W39L010@PLCC32 [ (SA015A1T-B001) ]	W39L010@TSOP32 [ (SA620-B005) ]
W39L020@PLCC32 [ (SA015A1T-B001) ]	
W39L020@TSOP32[12.4mm] [ (SA620-B005) ]	
W39L020@TSOP32[18.4mm] [ (SA410T-B003) ]	
W39L040@PLCC32 [ (SA015A1T-B001) ]	
W39L040@TSOP32[12.4mm] [ (SA620-B005) ]	
W39L040@TSOP32[18.4mm] [ (SA410T-B003) ]	
W39L040A	W39L040A@PLCC32
[ (SA015A1T) ]	
W39L040A@TSOP32 [ (SA410T) ]	W39L040A@VSOP32
[ (SA620) ]	
W39L512@PLCC32 [ (SA015A1T-B001) ]	W39L512@TSOP32 [ (SA620-B005) ]
W39V040AP@PLCC32 [ (SA015A1T) ]	W39V040AQ@VSOP32
[ (SA620) ]	
W39V040B(P)@PLCC32 [ (SA015A1T) ]	W39V040B(Q)@VSOP32
[ (SA620) ]	
W39V040CP@PLCC32 [ (SA015A1T) ]	W39V040CPZ@PLCC32
[ (SA015A1T) ]	
W39V040CQ@VSOP32 [ (SA620) ]	W39V040CQZ@VSOP32
[ (SA620) ]	
W39V040FAP@PLCC32 [ (SA015A1T) ]	W39V040FAQ@VSOP32
[ (SA620) ]	
W39V040FAT@TSOP40 [ (SA409T) ]	W39V040FB(P)@PLCC32
[ (SA015A1T) ]	
W39V040FB(Q)@VSOP32 [ (SA620) ]	W39V040FCP@PLCC32
[ (SA015A1T) ]	
W39V040FCPZ@PLCC32 [ (SA015A1T) ]	W39V040FCQ@VSOP32
[ (SA620) ]	
W39V040FCQZ@VSOP32 [ (SA620) ]	W39V080A(P)@PLCC32

[ (SA015A1T) ]	
W39V080A(Q)@VSOP32 [ (SA620) ]	W39V080A(T)@TSOP40
[ (SA409T) ]	
W39V080FA(P)@PLCC32 [ (SA015A1T) ]	W39V080FA(Q)@VSOP32
[ (SA620) ]	
W39V080FA(T)@TSOP40 [ (SA409T) ]	W45B012@PLCC32
[ (SA015A1T) ]	
W45B012@SON8 [ (SA683) ]	W45B512@PLCC32
[ (SA015A1T) ]	
W45B512@SON8 [ (SA683) ]	
W49F002	
W49F002@PLCC32 [ (SA015A1T-B001) ]	W49F002@TSOP32 [ (SA410T-
B003) ]	
W49F002B	
W49F002B@PLCC32 [ (SA015A1T-B001) ]	
W49F002B@TSOP32 [ (SA410T-B003) ]	
W49F002N	
W49F002N@PLCC32 [ (SA015A1T-B001) ]	
W49F002N@TSOP32 [ (SA410T-B003) ]	
W49F002U	
W49F002U@PLCC32 [ (SA015A1T-B001) ]	
W49F002U@TSOP32 [ (SA410T-B003) ]	
W49F020	
W49F020@PLCC32 [ (SA015A1T) ]	W49F020@TSOP32
[ (SA410T) ]	
W49F102@PLCC44 [ (SA244) ]	W49F102@TSOP40
[ (SA623) ]	
W49F201@PSOP44 [ (SA638) ]	W49F201@TSOP48 [ (SA247-
B005) ]	
W49L102@PLCC44 [ (SA244) ]	W49L102@TSOP40
[ (SA623) ]	
W49L201@PSOP44 [ (SA638) ]	W49L201@TSOP48 [ (SA247-
B005) ]	
W49L401@PSOP44 [ (SA638) ]	W49L401@TSOP48 [ (SA247-
B005) ]	
W49L401T@PSOP44 [ (SA638) ]	W49L401T@TSOP48 [ (SA247-
B005) ]	
W49V002A@PLCC32 [ (SA015A1T) ]	W49V002A@VSOP32
[ (SA620) ]	
W49V002FA@PLCC32 [ (SA015A1T) ]	W49V002FA@VSOP32
[ (SA620) ]	
W49V002FP@PLCC32 [ (SA015A1T) ]	W49V002FP@VSOP32
[ (SA620) ]	



W49V002P@PLCC32 [(SA015A1T)]  
[(SA620)]  
W55F05  
W55F10A  
W55F20

W49V002P@VSOP32

## MICROCONTROLLER

N79E342AKG  
[(SA404)]  
N79E342RAKG  
[(SA404)]  
N79E352AEG  
[(SA245)]  
N79E352ALG@TQFP48 [(SA248)]  
[(SA244)]  
N79E8213AKG  
[(SA404)]  
N79E8213RAKG  
[(SA404)]  
W77E058  
[(SA244)]  
W77E058@TQFP44 [(SA245A)]  
W77E516  
W77E516@PLCC44 [(SA244)]  
[(SA245A)]  
W77E532  
[(SA244)]  
W77E532@TQFP44 [(SA245A)]  
W77E532A  
W77E532A@PLCC44 [(SA244)]  
[(SA245A)]  
W77E58  
[(SA244)]  
W77E58@TQFP44 [(SA245A)]  
W77E58A  
W77E58A@PLCC44 [(SA244)]  
[(SA245A)]  
W77IE58  
[(SA244)]  
W77IE58@TQFP44 [(SA245A)]  
W77L058

N79E342ASG@SOP16  
N79E342RASG@SOP16  
N79E352AFG@TQFP44  
N79E352APG@PLCC44  
N79E8213ASG@SOP20  
N79E8213RASG@SOP20  
W77E058@PLCC44  
W77E516@TQFP44  
W77E532@PLCC44  
W77E532A@TQFP44  
W77E58@PLCC44  
W77E58A@TQFP44  
W77IE58@PLCC44

W77L058@PLCC44 [(SA244)]	W77L058@TQFP44
[(SA245A)]	
W77L516A	W77L516A@PLCC44
[(SA244)]	
W77L516A@TQFP44 [(SA245A)]	
W77L532A	
W77L532A@PLCC44 [(SA244)]	W77L532A@TQFP44
[(SA245A)]	
W77LE516	W77LE516@PLCC44
[(SA244)]	
W77LE516@TQFP44 [(SA245A)]	
W77LE532	
W77LE532@PLCC44 [(SA244)]	W77LE532@TQFP44
[(SA245A)]	
W77LE58	W77LE58@PLCC44
[(SA244)]	
W77LE58@TQFP44 [(SA245A)]	
W78E051B	
W78E051B@PLCC44 [(SA244)]	W78E051B@TQFP44
[(SA245A)]	
W78E051C	W78E051C@PLCC44
[(SA244)]	
W78E051C@TQFP44 [(SA245A)]	
W78E051DDG	
W78E051DFG@TQFP44 [(SA245A)]	
W78E051DLG@TQFP48 [(SA248A-B005)]	
W78E051DPG@PLCC44 [(SA244)]	
W78E052B	
W78E052B@PLCC44 [(SA244)]	W78E052B@TQFP44
[(SA245A)]	
W78E052C	W78E052C@PLCC44
[(SA244)]	
W78E052C@TQFP44 [(SA245A)]	
W78E052DDG	
W78E052DFG@TQFP44 [(SA245A)]	
W78E052DLG@TQFP48 [(SA248A-B005)]	
W78E052DPG@PLCC44 [(SA244)]	
W78E054B	
W78E054B@PLCC44 [(SA244)]	W78E054B@TQFP44
[(SA245A)]	
W78E054C	W78E054C@PLCC44
[(SA244)]	
W78E054C@TQFP44 [(SA245A)]	

W78E054DDG  
W78E054DFG@TQFP44 [(SA245A)]  
W78E054DLG@TQFP48 [(SA248A-B005)]  
W78E054DPG@PLCC44 [(SA244)]  
W78E058B  
W78E058B@PLCC44 [(SA244)] W78E058B@TQFP44  
[(SA245A)]  
W78E058DDG W78E058DFG@TQFP44  
[(SA245A)]  
W78E058DLG@TQFP48 [(SA248A-B005)]  
W78E058DPG@PLCC44 [(SA244)]  
W78E065  
W78E065@PLCC44 [(SA244)] W78E065@TQFP44  
[(SA245A)]  
W78E354(dip40) W78E354  
(dip48)  
W78E365 W78E365@PLCC44  
[(SA244)]  
W78E365@TQFP44 [(SA245A)]  
W78E374B  
W78E378  
W78E378E  
W78E378P@PLCC44 [(SA244)]  
W78E51  
W78E51@PLCC44 [(SA244)] W78E51@TQFP44  
[(SA245A)]  
W78E516 W78E516@PLCC44  
[(SA244)]  
W78E516@TQFP44 [(SA245A)]  
W78E516B  
W78E516B@PLCC44 [(SA244)] W78E516B@TQFP44  
[(SA245A)]  
W78E516DDG W78E516DFG@TQFP44  
[(SA245A)]  
W78E516DLG@TQFP48 [(SA248A-B005)]  
W78E516DPG@PLCC44 [(SA244)]  
W78E51B  
W78E51B@PLCC44 [(SA244)] W78E51B@TQFP44  
[(SA245A)]  
W78E51C W78E51C@PLCC44  
[(SA244)]  
W78E51C@TQFP44 [(SA245A)]  
W78E52

W78E52@PLCC44 [(SA244)]	W78E52@TQFP44
[(SA245A)]	
W78E52B	W78E52B@PLCC44
[(SA244)]	
W78E52B@TQFP44 [(SA245A)]	
W78E52C	
W78E52C@PLCC44 [(SA244)]	W78E52C@TQFP44
[(SA245A)]	
W78E54	W78E54@PLCC44
[(SA244)]	
W78E54@TQFP44 [(SA245A)]	
W78E54B	
W78E54B@PLCC44 [(SA244)]	W78E54B@TQFP44
[(SA245A)]	
W78E54C	W78E54C@PLCC44
[(SA244)]	
W78E54C@TQFP44 [(SA245A)]	
W78E58	
W78E58@PLCC44 [(SA244)]	W78E58@TQFP44
[(SA245A)]	
W78E58B	W78E58B@PLCC44
[(SA244)]	
W78E58B@TQFP44 [(SA245A)]	
W78E62B	
W78E62B@PLCC44 [(SA244)]	W78E62B@TQFP44
[(SA245A)]	
W78E65	W78E65@PLCC44
[(SA244)]	
W78E65@TQFP44 [(SA245A)]	
W78E858	
W78E858@PLCC44 [(SA244)]	W78E858@TQFP44
[(SA245A)]	
W78ERD2	W78ERD2@PLCC44
[(SA244)]	
W78ERD2@TQFP44 [(SA245A)]	
W78I051DDG	
W78I051DFG@TQFP44 [(SA245A)]	
W78I051DLG@TQFP48 [(SA248A-B005)]	
W78I051DPG@PLCC44 [(SA244)]	
W78I052	
W78I052@PLCC44 [(SA244)]	
W78I052DDG	
W78I052DFG@TQFP44 [(SA245A)]	

W78I052DLG@TQFP48 [(SA248A-B005)]  
W78I052DPG@PLCC44 [(SA244)]  
W78I054  
W78I054@PLCC44 [(SA244)]  
W78I054DDG  
W78I054DFG@TQFP44 [(SA245A)]  
W78I054DLG@TQFP48 [(SA248A-B005)]  
W78I054DPG@PLCC44 [(SA244)]  
W78IE52  
W78IE52@PLCC44 [(SA244)]  
W78IE54  
W78IE54@PLCC44 [(SA244)]  
W78IRD2  
W78IRD2@PLCC44 [(SA244)] W78IRD2@TQFP44  
[(SA245A)]  
W78L051 W78L051@PLCC44  
[(SA244)]  
W78L051@TQFP44 [(SA245A)]  
W78L051C  
W78L051C@PLCC44 [(SA244)] W78L051C@TQFP44  
[(SA245A)]  
W78L052 W78L052@PLCC44  
[(SA244)]  
W78L052@TQFP44 [(SA245A)]  
W78L052C  
W78L052C@PLCC44 [(SA244)] W78L052C@TQFP44  
[(SA245A)]  
W78L054 W78L054@PLCC44  
[(SA244)]  
W78L054@TQFP44 [(SA245A)]  
W78L054C  
W78L054C@PLCC44 [(SA244)] W78L054C@TQFP44  
[(SA245A)]  
W78L058 W78L058@PLCC44  
[(SA244)]  
W78L058@TQFP44 [(SA245A)]  
W78L365  
W78L365@PLCC44 [(SA244)] W78L365@TQFP44  
[(SA245A)]  
W78L365@TQFP48 [(SA248A-B005)]  
W78L516  
W78L516@PLCC44 [(SA244)] W78L516@TQFP44  
[(SA245A)]

W78L516A [ (SA244) ]	W78L516A@PLCC44
W78L516A@TQFP44 [ (SA245A) ]	
W78L812 W78L812@PLCC44 [ (SA244) ] [ (SA245A) ]	W78L812@TQFP44
W78LE365 [ (SA244) ]	W78LE365@PLCC44
W78LE365@TQFP44 [ (SA245A) ] B005) ]	W78LE365@TQFP48 [ (SA248A-
W78LE51 [ (SA244) ]	W78LE51@PLCC44
W78LE51@TQFP44 [ (SA245A) ]	
W78LE516 W78LE516@PLCC44 [ (SA244) ] [ (SA675) ]	W78LE516@TQFP44
W78LE51C [ (SA244) ]	W78LE51C@PLCC44
W78LE51C@TQFP44 [ (SA245A) ]	
W78LE52 W78LE52@PLCC44 [ (SA244) ] [ (SA245A) ]	W78LE52@TQFP44
W78LE52C [ (SA244) ]	W78LE52C@PLCC44
W78LE52C@TQFP44 [ (SA245A) ]	
W78LE54 W78LE54@PLCC44 [ (SA244) ] [ (SA245A) ]	W78LE54@TQFP44
W78LE54C [ (SA244) ]	W78LE54C@PLCC44
W78LE54C@TQFP44 [ (SA245A) ]	
W78LE58 W78LE58@PLCC44 [ (SA244) ] [ (SA245A) ]	W78LE58@TQFP44
W78LE812 [ (SA244) ]	W78LE812@PLCC44
W78LE812@TQFP44 [ (SA245A) ]	
W79E201 W79E201@PLCC44 [ (SA244) ] [ (SA245A) ]	W79E201@TQFP44
W79E2051(dip14) (dip16)	W79E2051
W79E2051(dip20)	W79E2051@SOP20

[ (SA404A) ]	
W79E2051@SSOP14 [ (SA626A) ]	W79E2051@SSOP16
[ (SA626A) ]	
W79E2051@SSOP20 [ (SA626A) ]	W79E2051R
(dip20)	
W79E2051R@SOP20 [ (SA404A) ]	
W79E216AFG@PQFP100(*) [ (SA741-B226) ]	
W79E217AFG@PQFP100(*) [ (SA741-B226) ]	
W79E225A@LQFP48 [ (SA248) ]	W79E225A@PLCC44
[ (SA244) ]	
W79E226A@LQFP48 [ (SA248) ]	W79E226A@PLCC44
[ (SA244) ]	
W79E227A@LQFP48 [ (SA248) ]	W79E227A@PLCC44
[ (SA244) ]	
W79E4051(dip14)	W79E4051
(dip16)	
W79E4051(dip20)	W79E4051@SOP20
[ (SA404A) ]	
W79E4051@SSOP14 [ (SA626A) ]	W79E4051@SSOP16
[ (SA626A) ]	
W79E4051@SSOP20 [ (SA626A) ]	W79E4051R
(dip20)	
W79E4051R@SOP20 [ (SA404A) ]	
W79E532	
W79E532@PLCC44 [ (SA244) ]	W79E532@TQFP44
[ (SA245A) ]	
W79E532A	W79E532A@PLCC44
[ (SA244) ]	
W79E532A@TQFP44 [ (SA245A) ]	
W79E632	
W79E632@PLCC44 [ (SA244) ]	W79E632@TQFP44
[ (SA245A) ]	
W79E633@PLCC44 [ (SA244) ]	
W79E648A@PLCC68(*) [ (SA648-B6809) ]	
W79E649A@PLCC68(*) [ (SA648-B6809) ]	
W79E659A@PQFP100(*) [ (SA741-B233) ]	
W79E801A	W79E801A@SOIC20
[ (SA404) ]	
W79E802A	W79E802A@SOIC20
[ (SA404) ]	
W79E803A	W79E803A@SOIC20
[ (SA404) ]	
W79E804A	W79E804A@SOIC20

[ (SA404) ]	
W79E821A	W79E821A@SOIC20
[ (SA404) ]	
W79E822A	W79E822A@SOIC20
[ (SA404) ]	
W79E822B	W79E822B@SOIC20
[ (SA404) ]	
W79E823A	W79E823A@SOIC20
[ (SA404) ]	
W79E823B	W79E823B@SOIC20
[ (SA404) ]	
W79E824A	W79E824A@SOIC20
[ (SA404) ]	
W79E825A	W79E825A@SOIC20
[ (SA404) ]	
W79E831A	W79E831A@SOIC28
[ (SA404) ]	
W79E832A	W79E832A@SOIC28
[ (SA404) ]	
W79E833A	W79E833A@SOIC28
[ (SA404) ]	
W79E834A	W79E834A@SOIC28
[ (SA404) ]	
W79L532	W79L532@PLCC44
[ (SA244) ]	
W79L532@TQFP44 [ (SA245A) ]	
W79L632	
W79L632@PLCC44 [ (SA244) ]	W79L632@TQFP44
[ (SA245A) ]	
W79L633@PLCC44 [ (SA244) ]	
W79L648A@PLCC68(*) [ (SA648-B6809) ]	
W79L649A@PLCC68(*) [ (SA648-B6809) ]	
W79L659A@PQFP100(*) [ (SA741-B233) ]	
W925EP01@PQFP100(*) [ (TA041-B006) ]	
W99100DG@TQFP48 [ (SA248A-B005) ]	

## WSI

### E (E) PROM/FRAM/NVRAM

WS27C010L	WS27C010L@PLCC32
[ (SA015A1T) ]	



WS27C010L@TSOP32 [ (SA410T) ]  
WS27C010R  
WS27C010R@PLCC32 [ (SA015A1T) ] WS27C010R@TSOP32  
[ (SA410T) ]  
WS27C040L WS27C040L@PLCC32  
[ (SA015A1T) ]  
WS27C040L@TSOP32 [ (SA410T) ]  
WS27C128F  
WS27C128F@PLCC32 [ (SA015A1T) ]  
WS27C128L  
WS27C128L@PLCC32 [ (SA015A1T) ]  
WS27C210L  
WS27C210L@PLCC44 [ (SA244) ]  
WS27C256F  
WS27C256F@PLCC32 [ (SA015A1T) ]  
WS27C256L  
WS27C256L@PLCC32 [ (SA015A1T) ]  
WS27C512F  
WS27C512F@PLCC32 [ (SA015A1T) ]  
WS27C512L  
WS27C512L@PLCC32 [ (SA015A1T) ]  
WS27C64  
WS27C64@PLCC32 [ (SA015A1T) ]  
WS27C64F  
WS27C64F@PLCC32 [ (SA015A1T) ]  
WS27C64L  
WS27C64L@PLCC32 [ (SA015A1T) ]  
WS57C128  
WS57C128@PLCC32 [ (SA015A1T) ]  
WS57C128F  
WS57C128F@PLCC32 [ (SA015A1T) ]  
WS57C128FB  
WS57C128FB@PLCC32 [ (SA015A1T) ]  
WS57C191  
WS57C191@PLCC28 [ (SA008A) ]  
WS57C191B  
WS57C191B@PLCC28 [ (SA008A) ]  
WS57C191C  
WS57C191C@PLCC28 [ (SA008A) ]  
WS57C256F  
WS57C256F@PLCC32 [ (SA015A1T) ]  
WS57C256FB  
WS57C256FB@PLCC32 [ (SA015A1T) ]

WS57C257  
WS57C257@PLCC44 [ (SA244) ]  
WS57C291  
WS57C291@PLCC28 [ (SA008A) ]  
WS57C291B  
WS57C291B@PLCC28 [ (SA008A) ]  
WS57C291C  
WS57C291C@PLCC28 [ (SA008A) ]  
WS57C43  
WS57C43@PLCC28 [ (SA008A) ]  
WS57C43B  
WS57C43B@PLCC28 [ (SA008A) ]  
WS57C43C  
WS57C43C@PLCC28 [ (SA008A) ]  
WS57C45  
WS57C45@PLCC28 [ (SA008A) ]  
WS57C49  
WS57C49@PLCC28 [ (SA008A) ]  
WS57C49B  
WS57C49B@PLCC28 [ (SA008A) ]  
WS57C49C  
WS57C49C@PLCC28 [ (SA008A) ]  
WS57C51  
WS57C51@PLCC32 [ (SA015A1T) ]  
WS57C51B  
WS57C51B@PLCC32 [ (SA015A1T) ]  
WS57C51C  
WS57C51C@PLCC32 [ (SA015A1T) ]  
WS57C64F  
WS57C64F@PLCC32 [ (SA015A1T) ]  
WS57C71C  
WS57C71C@PLCC32 [ (SA015A1T) ]  
WS57LV191C  
WS57LV191C@PLCC28 [ (SA008A) ]  
WS57LV291C  
WS57LV291C@PLCC28 [ (SA008A) ]

## **XELTEK**

### **E (E) PROM / FRAM / NVRAM**

S29GL032NTAI03@TSOP48 [ (SA247-B005) ]

S29GL032NTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI06@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI07@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI06@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI07@TSOP48 [ ( SA247-B005 ) ]  
S29GL128N10TAI01@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N10TAI02@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N10TFI01@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N10TFI02@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N11TAI01@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N11TAI02@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N11TAIV1@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N11TAIV2@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N11TFI01@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N11TFI02@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N11TFIV1@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N11TFIV2@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N90TAIR1@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N90TAIR2@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N90TFIR1@TSOP56 [ ( SA628-B334 ) ]  
S29GL128N90TFIR2@TSOP56 [ ( SA628-B334 ) ]

## MICROCONTROLLER

#####1111111111111111  
#####2222222222222222  
#####3333333333333333  
#####4444444444444444  
#####9999999999999999 ATMEGA168@TQFP32  
[ ( SA636 ) ]  
ATMEGA48@TQFP32 [ ( SA636 ) ] ATMEGA88@TQFP32  
[ ( SA636 ) ]  
ATMEGA8L( fast )@TQFP32 [ ( SA636 ) ] ATMEGA8L@TQFP32  
[ ( SA636 ) ]  
MK68F15P MK68F15S@SOP18  
[ ( SA023A ) ]

MK68F15X@SSOP20 [ (SA674) ]  
MK68F30K  
MK68F30S@SOP28 [ (SA404) ]  
[ (SA626A) ]

MK68F30X@SSOP28

## XICOR

### E ( E ) PROM / FRAM / NVRAM

X2004 [ (SA015A1T) ]	X2004@PLCC32
X2004D [ (SA015A1T) ]	X2004D@PLCC32
X2004I [ (SA015A1T) ]	X2004I@PLCC32
X2210 [ (SA404) ]	X2210@SOIC16
X2210A [ (SA404) ]	X2210A@SOIC16
X2210I [ (SA404) ]	X2210I@SOIC16
X2212 [ (SA404) ]	X2212@SOIC20
X2212A [ (SA404) ]	X2212A@SOIC20
X2212I [ (SA404) ]	X2212I@SOIC20
X22C10 [ (SA404) ]	X22C10@SOIC16
X22C10I [ (SA404) ]	X22C10I@SOIC16
X22C12 [ (SA404) ]	X22C12@SOIC20
X22C12I [ (SA404) ]	X22C12I@SOIC20
X24012 [ (SA602A) ]	X24012@SOIC8
X24022 [ (SA602A) ]	X24022@SOIC8
X24026 [ (SA602A) ]	X24026@SOIC8
X24042	X24042@SOIC8

[ (SA602A) ]	
X24164	X24164@SOIC8
[ (SA602A) ]	
X24165	X24165@SOIC8
[ (SA602A) ]	
X24325	X24325@SOIC8
[ (SA602A) ]	
X24645	X24645@SOIC8
[ (SA602A) ]	
X24C01	X24C01@MSOP8
[ (SA666) ]	
X24C01@SOIC8 [ (SA602A) ]	
X24C01A	
X24C01A@SOIC8 [ (SA602A) ]	
X24C01I	
X24C01I@SOIC8 [ (SA602A) ]	
X24C02	
X24C02@SOIC8 [ (SA602A) ]	
X24C02I	
X24C02I@SOIC8 [ (SA602A) ]	
X24C04	
X24C04@SOIC14 [ (SA602) ]	X24C04@SOIC8
[ (SA602A) ]	
X24C04I	X24C04I@SOIC14
[ (SA602) ]	
X24C04I@SOIC8 [ (SA602A) ]	
X24C08	
X24C08@SOIC14 [ (SA602) ]	X24C08@SOIC8
[ (SA602A) ]	
X24C08I	X24C08I@SOIC14
[ (SA602) ]	
X24C08I@SOIC8 [ (SA602A) ]	
X24C16	
X24C16@SOIC14 [ (SA602) ]	X24C16@SOIC8
[ (SA602A) ]	
X24C16I	X24C16I@SOIC14
[ (SA602) ]	
X24C16I@SOIC8 [ (SA602A) ]	
X24C44	
X24C44@SOIC8 [ (SA602A) ]	
X24C44I	
X24C44I@SOIC8 [ (SA602A) ]	
X24C45	

X24C45@SOIC8 [(SA602A)]	
X24C45I	
X24C45I@SOIC8 [(SA602A)]	X24F008
(3V)	
X24F008(3V)@SOIC8 [(SA602A)]	X24F008(3V)@TSSOP14
[(SA602)]	
X24F008(5V)	X24F008(5V)@SOIC8
[(SA602A)]	
X24F008(5V)@TSSOP14 [(SA602)]	X24F016
(3V)	
X24F016(3V)@SOIC8 [(SA602A)]	X24F016(3V)@TSSOP14
[(SA602)]	
X24F016(5V)	X24F016(5V)@SOIC8
[(SA602A)]	
X24F016(5V)@TSSOP14 [(SA602)]	X24F032
(3V)	
X24F032(3V)@SOIC8 [(SA602A)]	X24F032(3V)@TSSOP14
[(SA602)]	
X24F032(5V)	X24F032(5V)@SOIC8
[(SA602A)]	
X24F032(5V)@TSSOP14 [(SA602)]	X24F064
(3V)	
X24F064(3V)@SOIC8 [(SA602A)]	X24F064(3V)@TSSOP20
[(SA404)]	
X24F064(5V)	X24F064(5V)@SOIC8
[(SA602A)]	
X24F064(5V)@TSSOP20 [(SA404)]	
X25020	
X25020@SOIC8 [(SA602A)]	
X25021	
X25021@SOIC8 [(SA602A)]	
X25040	
X25040@SOIC8 [(SA602A)]	
X25041	
X25041@SOIC8 [(SA602A)]	
X25043	
X25043@MSOP8 [(SA666)]	X25043@SOIC8
[(SA602A)]	
X25043@TSSOP14 [(SA026)]	
X25045	
X25045@MSOP8 [(SA666)]	X25045@SOIC8
[(SA602A)]	
X25045@TSSOP14 [(SA026)]	X25057@MSOP8

[ (SA666) ]	
X25057@TSSOP8 [ (SA026) ]	
X25080	
X25080@SOIC8 [ (SA602A) ]	X25080@TSSOP14
[ (SA026) ]	
X25097@MSOP8 [ (SA666) ]	X25097@SOIC8
[ (SA602A) ]	
X25097@TSSOP8 [ (SA026) ]	
X25128	
X25128@SOIC16 [ (SA602) ]	
X25138	
X25138@SOIC14 [ (SA602) ]	X25138@SOIC16
[ (SA602) ]	
X25138@SOIC8 [ (SA602A) ]	X25138@TSSOP8
[ (SA026) ]	
X25160	X25160@SOIC8
[ (SA602A) ]	
X25160@TSSOP14 [ (SA026) ]	
X25163	
X25163@SOIC8 [ (SA602A) ]	X25163@TSSOP14
[ (SA026) ]	
X25164	X25164@SOIC8
[ (SA602A) ]	
X25164@TSSOP14 [ (SA026) ]	
X25165	
X25165@SOIC8 [ (SA602A) ]	X25165@TSSOP14
[ (SA026) ]	
X25166	X25166@SOIC8
[ (SA602A) ]	
X25166@TSSOP14 [ (SA026) ]	
X25168	
X25168@SOIC8 [ (SA602A) ]	X25168@TSSOP14
[ (SA026) ]	
X25169	X25169@SOIC8
[ (SA602A) ]	
X25169@TSSOP14 [ (SA026) ]	
X25256	
X25256@SOIC8 [ (SA602A) ]	X25256@TSSOP20
[ (SA026) ]	
X25320	X25320@SOIC8
[ (SA602A) ]	
X25323@SOIC8 [ (SA602A) ]	X25323@TSSOP14
[ (SA026) ]	

X25324@SOIC8 [(SA602A)]	X25324@TSSOP14
[(SA026)]	
X25325@SOIC8 [(SA602A)]	X25325@TSSOP14
[(SA026)]	
X25326@SOIC8 [(SA602A)]	X25328@SOIC8
[(SA602A)]	
X25328@TSSOP14 [(SA026)]	X25329@SOIC8
[(SA602A)]	
X25329@TSSOP14 [(SA026)]	X25330@SOIC8
[(SA602A)]	
X25330@TSSOP14 [(SA026)]	
X25401	
X25401@SOIC8 [(SA602A)]	
X25640	
X25640@SOIC14 [(SA602)]	
X25642	
X25642@SOIC14 [(SA602)]	X25642@SOIC8
[(SA602A)]	
X25642@TSSOP20 [(SA026)]	X25643@SOIC14
[(SA602)]	
X25644@SOIC14 [(SA602)]	
X25645	
X25645@SOIC14 [(SA602)]	X25645@SOIC8
[(SA602A)]	
X25645@TSSOP20 [(SA026)]	X25648@SOIC14
[(SA602)]	
X25649@SOIC14 [(SA602)]	
X25650	
X25650@SOIC14 [(SA602)]	X25650@SOIC8
[(SA602A)]	
X25650@TSSOP20 [(SA026)]	
X25C02	
X25C02@SOIC8 [(SA602A)]	X25C02@TSSOP8
[(SA026)]	
X25F008(3V)	X25F008(3V)@SOIC8
[(SA602A)]	
X25F008(3V)@TSSOP14 [(SA602)]	X25F008(3V)@TSSOP20
[(SA404)]	
X25F008(5V)	X25F008(5V)@SOIC8
[(SA602A)]	
X25F008(5V)@TSSOP14 [(SA602)]	X25F008(5V)@TSSOP20
[(SA404)]	
X25F016(3V)	X25F016(3V)@SOIC8



[ (SA602A) ]	
X25F016 (3V)@TSSOP14 [ (SA602) ]	X25F016 (3V)@TSSOP20
[ (SA404) ]	
X25F016 (5V)	X25F016 (5V)@SOIC8
[ (SA602A) ]	
X25F016 (5V)@TSSOP14 [ (SA602) ]	X25F016 (5V)@TSSOP20
[ (SA404) ]	
X25F032 (3V)	X25F032 (3V)@SOIC8
[ (SA602A) ]	
X25F032 (3V)@TSSOP14 [ (SA602) ]	X25F032 (3V)@TSSOP20
[ (SA404) ]	
X25F032 (5V)	X25F032 (5V)@SOIC8
[ (SA602A) ]	
X25F032 (5V)@TSSOP14 [ (SA602) ]	X25F032 (5V)@TSSOP20
[ (SA404) ]	
X25F047 (3V)	X25F047 (3V)@MSOP8
[ (SA666) ]	
X25F047 (3V)@SOIC8 [ (SA602A) ]	X25F047 (3V)@TSSOP8
[ (SA026) ]	
X25F047 (5V)	X25F047 (5V)@MSOP8
[ (SA666) ]	
X25F047 (5V)@SOIC8 [ (SA602A) ]	X25F047 (5V)@TSSOP8
[ (SA026) ]	
X25F064 (3V)	X25F064 (3V)@SOIC8
[ (SA602A) ]	
X25F064 (3V)@TSSOP14 [ (SA602) ]	X25F064 (3V)@TSSOP20
[ (SA404) ]	
X25F064 (5V)	X25F064 (5V)@SOIC8
[ (SA602A) ]	
X25F064 (5V)@TSSOP14 [ (SA602) ]	X25F064 (5V)@TSSOP20
[ (SA404) ]	
X25F087 (3V)	X25F087 (3V)@MSOP8
[ (SA666) ]	
X25F087 (3V)@SOIC8 [ (SA602A) ]	X25F087 (3V)@TSSOP8
[ (SA026) ]	
X25F087 (5V)	X25F087 (5V)@MSOP8
[ (SA666) ]	
X25F087 (5V)@SOIC8 [ (SA602A) ]	X25F087 (5V)@TSSOP8
[ (SA026) ]	
X25F128 (3V)	X25F128 (3V)@SOIC16
[ (SA602) ]	
X25F128 (5V)	X25F128 (5V)@SOIC16
[ (SA602) ]	

X28010	X28010@PLCC32
[ (SA015A1T) ]	
X28010@TSOP32 [ (SA410T) ]	
X2804A	
X2804A(I)	X2804A
(MB)	
X2816A	X2816A@PLCC32
[ (SA015A1T) ]	
X2816B	X2816B@PLCC32
[ (SA015A1T) ]	
X2816BI	X2816BI@PLCC32
[ (SA015A1T) ]	
X2816BMB	
X2816C	
X2816C@PLCC32 [ (SA015A1T) ]	
X28256	
X28256@PLCC32 [ (SA015A1T) ]	
X28256I	
X28256I@PLCC32 [ (SA015A1T) ]	
X2864A	
X2864A(I)	X2864A(I)@PLCC32
[ (SA015A1T) ]	
X2864A(M)	X2864A(M)@PLCC32
[ (SA015A1T) ]	
X2864A(MB)	X2864A(MB)@PLCC32
[ (SA015A1T) ]	
X2864A(T)	X2864A(T)@PLCC32
[ (SA015A1T) ]	
X2864A@PLCC32 [ (SA015A1T) ]	
X2864B	
X2864B(I)	X2864B(I)@PLCC32
[ (SA015A1T) ]	
X2864B(M)	X2864B(M)@PLCC32
[ (SA015A1T) ]	
X2864B@PLCC32 [ (SA015A1T) ]	
X2864H	
X2864H(I)	X2864H(I)@PLCC32
[ (SA015A1T) ]	
X2864H@PLCC32 [ (SA015A1T) ]	
X28C010	
X28C010@PLCC32 [ (SA015A1T) ]	
X28C16A	
X28C16A@PLCC32 [ (SA015A1T) ]	

X28C16B	
X28C16B@PLCC32 [(SA015A1T)]	
X28C16C	
X28C16C@PLCC32 [(SA015A1T)]	
X28C256	
X28C256@PLCC32 [(SA015A1T)]	X28C256@TSOP28
[(SA430T)]	
X28C512	X28C512@PLCC32
[(SA015A1T)]	
X28C513	X28C513@PLCC32
[(SA015A1T)]	
X28C64	X28C64@PLCC32
[(SA015A1T)]	
X28C64@SOIC28 [(SA404)]	X28C64@TSOP28
[(SA430T)]	
X28HC16	X28HC16@PLCC32
[(SA015A1T)]	
X28HC16@SOIC24 [(SA404)]	
X28HC256	
X28HC256@PLCC32 [(SA015A1T)]	X28HC256@TSOP28
[(SA430T)]	
X28HC64	X28HC64@PLCC32
[(SA015A1T)]	
X28HC64@SOIC28 [(SA404)]	X28HC64@TSOP28
[(SA430T)]	
X28LC512	X28LC512@PLCC32
[(SA015A1T)]	
X28LC513	X28LC513@PLCC32
[(SA015A1T)]	
X28VC256	X28VC256@PLCC32
[(SA015A1T)]	
X28VC256@TSOP28 [(SA430T)]	X40231@SOIC16
[(SA404)]	
X40233@SOIC16 [(SA404)]	X40235@SOIC16
[(SA404)]	
X40237@SOIC16 [(SA404)]	X40239@SOIC16
[(SA404)]	
X40430@SOIC14 [(SA404)]	X40430@TSSOP14
[(SA026)]	
X40431@SOIC14 [(SA404)]	X40431@TSSOP14
[(SA026)]	
X40434@SOIC14 [(SA404)]	X40434@TSSOP14
[(SA026)]	

X40435@SOIC14 [(SA404)]	X40435@TSSOP14
[(SA026)]	
X4C105@TSSOP20 [(SA026)]	
X5043	
X5043@MSOP8 [(SA666)]	X5043@SOIC8
[(SA602A)]	
X5043@TSSOP14 [(SA026)]	
X5045	
X5045@MSOP8 [(SA666)]	X5045@SOIC8
[(SA602A)]	
X5045@TSSOP14 [(SA026)]	
X5083	
X5083@SOIC8 [(SA602A)]	X5083@TSSOP8
[(SA026)]	
X5163	X5163@SOIC8
[(SA602A)]	
X5163@TSSOP14 [(SA026)]	
X51638	
X51638@SOIC8 [(SA602A)]	X51638@TSSOP14
[(SA026)]	
X5165	X5165@SOIC8
[(SA602A)]	
X5165@TSSOP14 [(SA026)]	
X5168	
X5168@SOIC8 [(SA602A)]	X5168@TSSOP14
[(SA026)]	
X5169	X5169@SOIC8
[(SA602A)]	
X5169@TSSOP14 [(SA026)]	
X5323	
X5323@SOIC8 [(SA602A)]	X5323@TSSOP14
[(SA026)]	
X5325	X5325@SOIC8
[(SA602A)]	
X5325@TSSOP14 [(SA026)]	
X5328	
X5328@SOIC8 [(SA602A)]	X5328@TSSOP14
[(SA026)]	
X5329	X5329@SOIC8
[(SA602A)]	
X5329@TSSOP14 [(SA026)]	
X5643	
X5643@SOIC14 [(SA602)]	X5643@SOIC8

[ (SA602A) ]	
X5643@TSSOP20 [ (SA026) ]	
X5645	
X5645@SOIC14 [ (SA602) ]	X5645@SOIC8
[ (SA602A) ]	
X5645@TSSOP20 [ (SA026) ]	
X5648	
X5648@SOIC14 [ (SA602) ]	
X5649	
X5649@SOIC14 [ (SA602) ]	
X76F041	
X76F041(3)	X76F041(3)@SOIC8
[ (SA605) ]	
X76F041@SOIC8 [ (SA605) ]	
X76F101	
X76F101@SOIC8 [ (SA602A) ]	X76F400@SOIC8
[ (SA602A) ]	
X76F400@TSSOP8 [ (SA026) ]	
X84041	
X84041@SOIC14 [ (SA602) ]	X84041@SOIC8
[ (SA602A) ]	
X84047	X84047@TSSOP8
[ (SA026) ]	
X84087	X84087@TSSOP8
[ (SA026) ]	
X84128	X84128@SOIC14
[ (SA602) ]	
X84128@TSSOP28 [ (SA643) ]	X84128@XBGA8
[ (SA683) ]	
X84129	X84129@SOIC16
[ (SA602) ]	
X84160	X84160@SOIC8
[ (SA602A) ]	
X84160@TSSOP8 [ (SA026) ]	
X84161	
X84161@SOIC8 [ (SA602A) ]	X84161@TSSOP8
[ (SA026) ]	
X84256	X84256@SOIC8
[ (SA602A) ]	
X84256@TSSOP14 [ (SA026) ]	X84256@XBGA8
[ (SA683) ]	
X84640	X84640@SOIC8
[ (SA602A) ]	

X84640@TSSOP20 [(SA026)]	X84640@XBGA8
[(SA683)]	
X84641	X84641@SOIC8
[(SA602A)]	
X84641@TSSOP20 [(SA026)]	X84641@XBGA8
[(SA683)]	
XD2210	XD2210@SOIC16
[(SA404)]	
XM28C010	
XM28C020	
XM28C040	

## XILINX

### E(E) PROM/FRAM/NVRAM

XC1701	XC1701@PLCC20
[(SA001A)]	
XC1701@PLCC44 [(SA244)]	XC1701@SOIC20
[(SA404)]	
XC1701L	XC1701L@PLCC20
[(SA001A)]	
XC1701L@PLCC44 [(SA244)]	XC1701L@SOIC20
[(SA404)]	
XC1702L@PLCC44 [(SA244)]	XC1702L@TQFP44
[(SA245A)]	
XC1704L@PLCC44 [(SA244)]	XC1704L@TQFP44
[(SA245A)]	
XC17128	XC17128@SOIC8
[(SA602A)]	
XC17128D	XC17128D@PLCC20
[(SA001A)]	
XC17128D@SOIC8 [(SA602A)]	XC17128D@VOIC8
[(SA602A)]	
XC17128E	XC17128E@PLCC20
[(SA001A)]	
XC17128E@VOIC8 [(SA602A)]	
XC17128EL	
XC17128EL@PLCC20 [(SA001A)]	XC17128EL@VOIC8
[(SA602A)]	
XC17128L	XC17128L@PLCC20
[(SA001A)]	

XC17128L@SOIC8 [(SA602A)]	XC17128L@VOIC8
[(SA602A)]	
XC17128X	XC17128X@PLCC20
[(SA001A)]	
XC17128X@SOIC8 [(SA602A)]	XC17128X@VOIC8
[(SA602A)]	
XC1718D	XC1718D@PLCC20
[(SA001A)]	
XC1718D@SOIC8 [(SA602A)]	XC1718D@VOIC8
[(SA602A)]	
XC1718L	XC1718L@PLCC20
[(SA001A)]	
XC1718L@SOIC8 [(SA602A)]	XC1718L@VOIC8
[(SA602A)]	
XC17256D	XC17256D@PLCC20
[(SA001A)]	
XC17256D@SOIC8 [(SA602A)]	XC17256D@VOIC8
[(SA602A)]	
XC17256E	XC17256E@PLCC20
[(SA001A)]	
XC17256E@VOIC8 [(SA602A)]	
XC17256EL	
XC17256EL@PLCC20 [(SA001A)]	XC17256EL@VOIC8
[(SA602A)]	
XC17256L	XC17256L@PLCC20
[(SA001A)]	
XC17256L@SOIC8 [(SA602A)]	XC17256L@VOIC8
[(SA602A)]	
XC17256X	XC17256X@PLCC20
[(SA001A)]	
XC17256X@SOIC8 [(SA602A)]	XC17256X@VOIC8
[(SA602A)]	
XC1736	XC1736@SOIC8
[(SA602A)]	
XC1736A	XC1736A@SOIC8
[(SA602A)]	
XC1736D	XC1736D@PLCC20
[(SA001A)]	
XC1736D@SOIC8 [(SA602A)]	XC1736D@VOIC8
[(SA602A)]	
XC1736E	XC1736E@PLCC20
[(SA001A)]	
XC1736E@SOIC8 [(SA602A)]	XC1736E@VOIC8

[ (SA602A) ]	
XC17512L	XC17512L@PLCC20
[ (SA001A) ]	
XC17512L@PLCC44 [ (SA244) ]	XC17512L@SOIC20
[ (SA404) ]	
XC1765	XC1765@SOIC8
[ (SA602A) ]	
XC1765D	XC1765D@PLCC20
[ (SA001A) ]	
XC1765D@SOIC8 [ (SA602A) ]	XC1765D@VOIC8
[ (SA602A) ]	
XC1765E	XC1765E@PLCC20
[ (SA001A) ]	
XC1765E@SOIC8 [ (SA602A) ]	XC1765E@VOIC8
[ (SA602A) ]	
XC1765EL	XC1765EL@PLCC20
[ (SA001A) ]	
XC1765EL@SOIC8 [ (SA602A) ]	XC1765EL@VOIC8
[ (SA602A) ]	
XC1765L	XC1765L@PLCC20
[ (SA001A) ]	
XC1765L@SOIC8 [ (SA602A) ]	XC1765L@VOIC8
[ (SA602A) ]	
XC1765X	XC1765X@PLCC20
[ (SA001A) ]	
XC1765X@SOIC8 [ (SA602A) ]	XC1765X@VOIC8
[ (SA602A) ]	
XC17S05	XC17S05@SOIC8
[ (SA602A) ]	
XC17S05XL(L)	XC17S05XL(L)@SOIC8
[ (SA602A) ]	
XC17S10	XC17S10@SOIC8
[ (SA602A) ]	
XC17S100A	XC17S100A@SOIC20
[ (SA404) ]	
XC17S100A@SOIC8 [ (SA602A) ]	XC17S100XL
(L)	
XC17S100XL(L)@SOIC20 [ (SA404) ]	XC17S10XL
(L)	
XC17S10XL(L)@SOIC8 [ (SA602A) ]	
XC17S150A	
XC17S150A@SOIC20 [ (SA404) ]	XC17S150A@SOIC8
[ (SA602A) ]	



XC17S150XL(L) [(SA404)]	XC17S150XL(L)@SOIC20
XC17S15A [(SA404)]	XC17S15A@SOIC20
XC17S15A@SOIC8 [(SA602A)]	
XC17S20	
XC17S20@SOIC8 [(SA602A)]	
XC17S200A	
XC17S200A@SOIC8 [(SA602A)]	XC17S200A@TQFP44
[(SA245A)]	
XC17S20XL(L) [(SA602A)]	XC17S20XL(L)@SOIC8
XC17S30 [(SA602A)]	XC17S30@SOIC8
XC17S300A@TQFP44 [(SA245A)]	
XC17S30A	
XC17S30A@SOIC20 [(SA404)]	XC17S30A@SOIC8
[(SA602A)]	
XC17S30XL(L) [(SA602A)]	XC17S30XL(L)@SOIC8
XC17S40 [(SA404)]	XC17S40@SOIC20
XC17S40XL(L) [(SA404)]	XC17S40XL(L)@SOIC20
XC17S50A [(SA404)]	XC17S50A@SOIC20
XC17S50A@SOIC8 [(SA602A)]	XC17S50XL
(L)	
XC17S50XL(L)@SOIC20 [(SA404)]	XC17V01@PLCC20
[(SA001A)]	
XC17V01@SOIC20 [(SA404)]	XC17V01@SOIC8
[(SA602A)]	
XC17V02@PLCC20 [(SA001A)]	XC17V02@PLCC44
[(SA244)]	
XC17V02@TQFP44 [(SA245A)]	XC17V04@PLCC20
[(SA001A)]	
XC17V04@PLCC44 [(SA244)]	XC17V04@TQFP44
[(SA245A)]	
XC17V08@PLCC44 [(SA244)]	XC17V08@TQFP44
[(SA245A)]	
XC17V16@PLCC44 [(SA244)]	XC17V16@TQFP44
[(SA245A)]	
XCF01S(VO)@TSSOP20 [(SA026)]	XCF01S(VOG)@TSSOP20

[ (SA026) ]  
XCF02S(VO)@TSSOP20 [ (SA026) ] XCF02S(VOG)@TSSOP20  
[ (SA026) ]  
XCF04S(VO)@TSSOP20 [ (SA026) ] XCF04S(VOG)@TSSOP20  
[ (SA026) ]  
XCF08P(FS)@FBGA48 [ (SA642E-B026A-T072F001N) ]  
XCF08P(FS)@FBGA48(ISP) [ (SA642E-B026A-T072F001N) ]  
XCF08P(FSG)@FBGA48 [ (SA642E-B026A-T072F001N) ]  
XCF08P(FSG)@FBGA48(ISP) [ (SA642E-B026A-T072F001N) ]  
XCF08P(VO)@TSOP48 [ (SA247-B005) ]  
XCF08P(VO)@TSOP48(ISP) [ ISP-HEADER01 ]  
XCF08P(VOG)@TSOP48 [ (SA247-B005) ]  
XCF08P(VOG)@TSOP48(ISP) [ ISP-HEADER01 ]  
XCF16P(FS)@FBGA48 [ (SA642E-B026A-T072F001N) ]  
XCF16P(FS)@FBGA48(ISP) [ (SA642E-B026A-T072F001N) ]  
XCF16P(FSG)@FBGA48 [ (SA642E-B026A-T072F001N) ]  
XCF16P(FSG)@FBGA48(ISP) [ (SA642E-B026A-T072F001N) ]  
XCF16P(VO)@TSOP48 [ (SA247-B005) ]  
XCF16P(VO)@TSOP48(ISP) [ ISP-HEADER01 ]  
XCF16P(VOG)@TSOP48 [ (SA247-B005) ]  
XCF16P(VOG)@TSOP48(ISP) [ ISP-HEADER01 ]  
XCF32P(FS)@FBGA48 [ (SA642E-B026A-T072F001N) ]  
XCF32P(FS)@FBGA48(ISP) [ (SA642E-B026A-T072F001N) ]  
XCF32P(FSG)@FBGA48 [ (SA642E-B026A-T072F001N) ]  
XCF32P(FSG)@FBGA48(ISP) [ (SA642E-B026A-T072F001N) ]  
XCF32P(VO)@TSOP48 [ (SA247-B005) ]  
XCF32P(VO)@TSOP48(ISP) [ ISP-HEADER01 ]  
XCF32P(VOG)@TSOP48 [ (SA247-B005) ]  
XCF32P(VOG)@TSOP48(ISP) [ ISP-HEADER01 ]

## PLD

XC2C32@PLCC44 [ (SA244) ] XC2C32@QFG32  
[ (SA686) ]  
XC2C32@VQFP44 [ (SA245A) ] XC2C32A@PLCC44  
[ (SA244) ]  
XC2C32A@QFG32 [ (SA686) ] XC2C32A@VQFP44  
[ (SA245A) ]  
XC2C64@CSP56(\*) [ (SA699A-B136B-W056F001Y) ]  
XC2C64@PLCC44 [ (SA244) ] XC2C64@VQFP44  
[ (SA245A) ]  
XC2C64A@5QFG48C [ (SA696) ] XC2C64A@5QFG48I

[ (SA696) ]	
XC2C64A@7QFG48C [ (SA696) ]	XC2C64A@7QFG48I
[ (SA696) ]	
XC2C64A@CSP56( * ) [ (SA699A-B136B-W056F001Y) ]	
XC2C64A@PLCC44 [ (SA244) ]	XC2C64A@VQFP44
[ (SA245A) ]	
XC9536@PLCC44 [ (SA244) ]	XC9536@TQFP44
[ (SA245A) ]	
XC9536XL@BCSP48 [ (SA642QQ+B339) ]	XC9536XL@PLCC44
[ (SA244) ]	
XC9536XL@VQFP44 [ (SA245A) ]	XC9536XV@BCSP48 [ (SA642QQ
+B339) ]	
XC9536XV@PLCC44 [ (SA244) ]	XC9536XV@TQFP44
[ (SA245A) ]	
XC9572@PLCC44 [ (SA244) ]	XC9572@TQFP44
[ (SA245A) ]	
XC9572XL@BCSP48 [ (SA642QQ+B339) ]	XC9572XL@PLCC44
[ (SA244) ]	
XC9572XL@TQFP44 [ (SA245A) ]	XC9572XV@BCSP48 [ (SA642QQ
+B339) ]	
XC9572XV@PLCC44 [ (SA244) ]	XC9572XV@TQFP44
[ (SA245A) ]	

## XILINX-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

XC17S100A	XC17S100A@SOIC20
[ (SA404) ]	
XC17S100A@SOIC8 [ (SA602A) ]	
XC17S150A	
XC17S150A@SOIC20 [ (SA404) ]	XC17S150A@SOIC8
[ (SA602A) ]	
XC17S15A	XC17S15A@SOIC20
[ (SA404) ]	
XC17S15A@SOIC8 [ (SA602A) ]	
XC17S200A	
XC17S200A@SOIC8 [ (SA602A) ]	XC17S200A@TQFP44
[ (SA245A) ]	
XC17S300A@TQFP44 [ (SA245A) ]	
XC17S30A	
XC17S30A@SOIC20 [ (SA404) ]	XC17S30A@SOIC8

[ (SA602A) ]	
XC17S50A	XC17S50A@SOIC20
[ (SA404) ]	
XC17S50A@SOIC8 [ (SA602A) ]	XC17V01@PLCC20
[ (SA001A) ]	
XC17V01@SOIC20 [ (SA404) ]	XC17V01@SOIC8
[ (SA602A) ]	
XC17V02@PLCC20 [ (SA001A) ]	XC17V02@PLCC44
[ (SA244) ]	
XC17V02@TQFP44 [ (SA245A) ]	XC17V04@PLCC20
[ (SA001A) ]	
XC17V04@PLCC44 [ (SA244) ]	XC17V04@TQFP44
[ (SA245A) ]	
XC17V08@PLCC44 [ (SA244) ]	XC17V08@TQFP44
[ (SA245A) ]	
XC17V16@PLCC44 [ (SA244) ]	XC17V16@TQFP44
[ (SA245A) ]	

## YMC

### E (E) PROM/FRAM/NVRAM

Y24LC01	Y24LC01@SOIC8
[ (SA602A) ]	
Y24LC01@TSSOP8 [ (SA026) ]	
Y24LC02	
Y24LC02@SOIC8 [ (SA602A) ]	Y24LC02@TSSOP8
[ (SA026) ]	
Y24LC02A	Y24LC02A@SOIC8
[ (SA602A) ]	
Y24LC02A@TSSOP8 [ (SA026) ]	
Y24LC04	
Y24LC04@SOIC8 [ (SA602A) ]	Y24LC04@TSSOP8
[ (SA026) ]	
Y24LC08	Y24LC08@SOIC8
[ (SA602A) ]	
Y24LC08@TSSOP8 [ (SA026) ]	
Y24LC16	
Y24LC16@SOIC8 [ (SA602A) ]	Y24LC16@TSSOP8
[ (SA026) ]	
Y24LC32	Y24LC32@SOIC8
[ (SA602A) ]	

Y24LC32@TSSOP8 [(SA026)]	
Y24LC64	
Y24LC64@SOIC8 [(SA602A)]	Y24LC64@TSSOP8
[(SA026)]	
Y54LC64	Y54LC64@SOIC8
[(SA602A)]	
Y54LC64@TSSOP8 [(SA026)]	Y93LC46
(08bit)	
Y93LC46(08bit)@SOIC8 [(SA602A)]	Y93LC46(08bit)@TSSOP8
[(SA026)]	
Y93LC46(16bit)	Y93LC46(16bit)@SOIC8
[(SA602A)]	
Y93LC46(16bit)@TSSOP8 [(SA026)]	Y93LC66
(08bit)	
Y93LC66(08bit)@SOIC8 [(SA602A)]	Y93LC66(08bit)@TSSOP8
[(SA026)]	
Y93LC66(16bit)	Y93LC66(16bit)@SOIC8
[(SA602A)]	
Y93LC66(16bit)@TSSOP8 [(SA026)]	Y93LC86
(08bit)	
Y93LC86(08bit)@SOIC8 [(SA602A)]	Y93LC86(08bit)@TSSOP8
[(SA026)]	
Y93LC86(16bit)	Y93LC86(16bit)@SOIC8
[(SA602A)]	
Y93LC86(16bit)@TSSOP8 [(SA026)]	

## YSS

### E (E) PROM/FRAM/NVRAM

Y25F05@SOP8 [(SA602A)]	Y25F05@VQFN8
[(SA683)]	
Y25F10@SOP8 [(SA602A)]	Y25F10@VQFN8
[(SA683)]	

## ZHIXIN

### E (E) PROM/FRAM/NVRAM

PC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]

PC28F128P33T@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]

# ZILOG

## MICROCONTROLLER

Z86733 [ ( SA008A ) ]	Z86733@PLCC28
Z86733@SOIC28 [ ( SA404 ) ]	
Z86743 Z86743@PLCC44 [ ( SA244 ) ]	
Z86C0208PEC Z86C0208PSC [ ( SA404 ) ]	Z86C0208SEC@SOIC18
Z86C0208SSC@SOIC18 [ ( SA404 ) ]	
Z86E02 Z86E02@SOIC18 [ ( SA404 ) ]	
Z86E03 Z86E03@SOIC18 [ ( SA404 ) ]	
Z86E04 Z86E04@SOIC18 [ ( SA404 ) ]	
Z86E0412PEC Z86E0412PEC1903 Z86E0412PSC1866 Z86E0412PSC1903 [ ( SA404 ) ]	Z86E0412SEC
Z86E0412SEC1903 [ ( SA404 ) ] [ ( SA404 ) ]	Z86E0412SSC1866
Z86E0412SSC1903 [ ( SA404 ) ]	
Z86E06 Z86E06@SOIC18 [ ( SA404 ) ]	
Z86E07 Z86E07@SOIC18 [ ( SA404 ) ]	
Z86E08 Z86E08@SOIC18 [ ( SA404 ) ]	
Z86E0812PEC Z86E0812PEC1903 Z86E0812PSC1866 Z86E0812PSC1903 [ ( SA404 ) ]	Z86E0812SEC
Z86E0812SEC1903 [ ( SA404 ) ] [ ( SA404 ) ]	Z86E0812SSC1866

Z86E0812SSC1903 [(SA404)]  
Z86E122  
Z86E122@SOIC20 [(SA404)]  
Z86E123  
Z86E123@SOIC20 [(SA404)]  
Z86E124  
Z86E124@SOIC20 [(SA404)]  
Z86E125  
Z86E125@SOIC20 [(SA404)]  
Z86E126  
Z86E126@SOIC20 [(SA404)]  
Z86E132  
Z86E132@SOIC28 [(SA404)]  
Z86E133  
Z86E133@SOIC28 [(SA404)]  
Z86E134  
Z86E134@SOIC28 [(SA404)]  
Z86E135  
Z86E135@SOIC28 [(SA404)]  
Z86E136  
Z86E136@SOIC28 [(SA404)]  
Z86E142  
Z86E142@TQFP44 [(SA245A)]  
Z86E143  
Z86E143@TQFP44 [(SA245A)]  
Z86E144  
Z86E144@TQFP44 [(SA245A)]  
Z86E145  
Z86E145@TQFP44 [(SA245A)]  
Z86E146  
Z86E146@TQFP44 [(SA245A)]  
Z86E15  
Z86E21  
[(SA244)]  
Z86E21@TQFP44 [(SA245A)]  
Z86E2112  
Z86E2112@PLCC44 [(SA244)]  
[(SA245A)]  
Z86E2116  
[(SA244)]  
Z86E2116@TQFP44 [(SA245A)]  
Z86E23  
Z86E23@PLCC44 [(SA244)]

Z86E21@PLCC44

Z86E2112@TQFP44

Z86E2116@PLCC44

Z86E23@TQFP44

[ (SA245A) ]	
Z86E2312	Z86E2312@PLCC44
[ (SA244) ]	
Z86E2312@TQFP44 [ (SA245A) ]	
Z86E2316	
Z86E2316@PLCC44 [ (SA244) ]	Z86E2316@TQFP44
[ (SA245A) ]	
Z86E3016PEC	
Z86E3016PSC	
Z86E3016SEC@SOIC28 [ (SA404) ]	Z86E3016SSC@SOIC28
[ (SA404) ]	
Z86E3016VEC@PLCC28 [ (SA008A) ]	Z86E3016VSC@PLCC28
[ (SA008A) ]	
Z86E3016VSG@PLCC28 [ (SA008A) ]	
Z86E3116PEC	
Z86E3116PSC	Z86E3116SEC@SOIC28
[ (SA404) ]	
Z86E3116SSC@SOIC28 [ (SA404) ]	Z86E3116VEC@PLCC28
[ (SA008A) ]	
Z86E3116VSC@PLCC28 [ (SA008A) ]	Z86E3116VSG@PLCC28
[ (SA008A) ]	
Z86E33	Z86E33@PLCC28
[ (SA008A) ]	
Z86E33@SOIC28 [ (SA404) ]	
Z86E34	
Z86E34@PLCC28 [ (SA008A) ]	Z86E34@SOIC28
[ (SA404) ]	
Z86E4016FEC@TQFP44 [ (SA245A) ]	Z86E4016FSC@TQFP44
[ (SA245A) ]	
Z86E4016PEC	
Z86E4016PSC	
Z86E4016VEC@PLCC44 [ (SA244) ]	Z86E4016VSC@PLCC44
[ (SA244) ]	
Z86E4016VSG@PLCC44 [ (SA244) ]	
Z86E43	
Z86E43@PLCC44 [ (SA244) ]	Z86E43@TQFP44
[ (SA245A) ]	
Z86E44	Z86E44@PLCC44
[ (SA244) ]	
Z86E44@TQFP44 [ (SA245A) ]	Z86E6116ASG@TQFP44
[ (SA245A) ]	
Z86E6116PSC	Z86E6116VSC@PLCC44
[ (SA244) ]	



Z86E6120ASG@TQFP44 [(SA245A)]  
Z86E6120PSC  
Z86E6120VSC@PLCC44 [(SA244)] Z86E61FSC@TQFP44  
[(SA245A)]  
Z86E61PSC Z86E61VSC@PLCC44  
[(SA244)]  
Z86E6316ASG@TQFP44 [(SA245A)]  
Z86E6316PSC  
Z86E6316VSC@PLCC44 [(SA244)] Z86E6320ASG@TQFP44  
[(SA245A)]  
Z86E6320PSC Z86E6320VSC@PLCC44  
[(SA244)]  
Z86E63FSC@TQFP44 [(SA245A)]  
Z86E63PSC  
Z86E63VSC@PLCC44 [(SA244)]  
Z86E72  
Z86E72@PLCC44 [(SA244)] Z86E72@TQFP44  
[(SA245A)]  
Z86E73 Z86E73@PLCC44  
[(SA244)]  
Z86E73@TQFP44 [(SA245A)]  
Z86E83  
Z86E83@PLCC28 [(SA008A)] Z86E83@SOIC28  
[(SA404)]  
Z86L0208PEC  
Z86L0208PSC  
Z86L0208SEC@SOIC18 [(SA404)] Z86L0208SSC@SOIC18  
[(SA404)]  
Z89371 Z89371@PLCC44  
[(SA244)]  
Z89371@TQFP44 [(SA245A)]  
Z89371B  
Z89371B@PLCC44 [(SA244)] Z89371B@TQFP44  
[(SA245A)]  
Z8F0113HH005EC@SSOP20 [(SA626A)] Z8F0113HH005EG@SSOP20  
[(SA626A)]  
Z8F0113HH005SC@SSOP20 [(SA626A)] Z8F0113HH005SG@SSOP20  
[(SA626A)]  
Z8F0113HJ005EC@SSOP28 [(SA626A)] Z8F0113HJ005EG@SSOP28  
[(SA626A)]  
Z8F0113HJ005SC@SSOP28 [(SA626A)] Z8F0113HJ005SG@SSOP28  
[(SA626A)]  
Z8F0113PB005EC

Z8F0113PB005EG  
Z8F0113PB005SC  
Z8F0113PB005SG  
Z8F0113PH005EC  
Z8F0113PH005EG  
Z8F0113PH005SC  
Z8F0113PH005SG  
Z8F0113PJ005EC  
Z8F0113PJ005EG  
Z8F0113PJ005SC  
Z8F0113PJ005SG  
Z8F0113QB005EC@QFN8 [(SA683)]  
[(SA683)]  
Z8F0113QB005SC@QFN8 [(SA683)]  
[(SA683)]  
Z8F0113SB005EC@SOIC8 [(SA602A)]  
[(SA602A)]  
Z8F0113SB005SC@SOIC8 [(SA602A)]  
[(SA602A)]  
Z8F0113SH005EC@SOIC20 [(SA404)]  
[(SA404)]  
Z8F0113SH005SC@SOIC20 [(SA404)]  
[(SA404)]  
Z8F0113SJ005EC@SOIC28 [(SA404)]  
[(SA404)]  
Z8F0113SJ005SC@SOIC28 [(SA404)]  
[(SA404)]  
Z8F011AHH020EC@SSOP20 [(SA626A)]  
[(SA626A)]  
Z8F011AHH020SC@SSOP20 [(SA626A)]  
[(SA626A)]  
Z8F011AHJ020EC@SSOP28 [(SA626A)]  
[(SA626A)]  
Z8F011AHJ020SC@SSOP28 [(SA626A)]  
[(SA626A)]  
Z8F011APB020EC  
Z8F011APB020EG  
Z8F011APB020SC  
Z8F011APB020SG  
Z8F011APH020EC  
Z8F011APH020EG  
Z8F011APH020SC  
Z8F011APH020SG

Z8F0113QB005EG@QFN8  
Z8F0113QB005SG@QFN8  
Z8F0113SB005EG@SOIC8  
Z8F0113SB005SG@SOIC8  
Z8F0113SH005EG@SOIC20  
Z8F0113SH005SG@SOIC20  
Z8F0113SJ005EG@SOIC28  
Z8F0113SJ005SG@SOIC28  
Z8F011AHH020EG@SSOP20  
Z8F011AHH020SG@SSOP20  
Z8F011AHJ020EG@SSOP28  
Z8F011AHJ020SG@SSOP28

Z8F011APJ020EC	
Z8F011APJ020EG	
Z8F011APJ020SC	
Z8F011APJ020SG	
Z8F011AQB020EC@QFN8 [(SA683)]	Z8F011AQB020EG@QFN8
[(SA683)]	
Z8F011AQB020SC@QFN8 [(SA683)]	Z8F011AQB020SG@QFN8
[(SA683)]	
Z8F011ASB020EC@SOIC8 [(SA602A)]	Z8F011ASB020EG@SOIC8
[(SA602A)]	
Z8F011ASB020SC@SOIC8 [(SA602A)]	Z8F011ASB020SG@SOIC8
[(SA602A)]	
Z8F011ASH020EC@SOIC20 [(SA404)]	Z8F011ASH020EG@SOIC20
[(SA404)]	
Z8F011ASH020SC@SOIC20 [(SA404)]	Z8F011ASH020SG@SOIC20
[(SA404)]	
Z8F011ASJ020EC@SOIC28 [(SA404)]	Z8F011ASJ020EG@SOIC28
[(SA404)]	
Z8F011ASJ020SC@SOIC28 [(SA404)]	Z8F011ASJ020SG@SOIC28
[(SA404)]	
Z8F0123HH005EC@SSOP20 [(SA626A)]	Z8F0123HH005EG@SSOP20
[(SA626A)]	
Z8F0123HH005SC@SSOP20 [(SA626A)]	Z8F0123HH005SG@SSOP20
[(SA626A)]	
Z8F0123HJ005EC@SSOP28 [(SA626A)]	Z8F0123HJ005EG@SSOP28
[(SA626A)]	
Z8F0123HJ005SC@SSOP28 [(SA626A)]	Z8F0123HJ005SG@SSOP28
[(SA626A)]	
Z8F0123PB005EC	
Z8F0123PB005EG	
Z8F0123PB005SC	
Z8F0123PB005SG	
Z8F0123PH005EC	
Z8F0123PH005EG	
Z8F0123PH005SC	
Z8F0123PH005SG	
Z8F0123PJ005EC	
Z8F0123PJ005EG	
Z8F0123PJ005SC	
Z8F0123PJ005SG	
Z8F0123QB005EC@QFN8 [(SA683)]	Z8F0123QB005EG@QFN8
[(SA683)]	
Z8F0123QB005SC@QFN8 [(SA683)]	Z8F0123QB005SG@QFN8

[ (SA683) ]	
Z8F0123SB005EC@SOIC8 [ (SA602A) ]	Z8F0123SB005EG@SOIC8
[ (SA602A) ]	
Z8F0123SB005SC@SOIC8 [ (SA602A) ]	Z8F0123SB005SG@SOIC8
[ (SA602A) ]	
Z8F0123SH005EC@SOIC20 [ (SA404) ]	Z8F0123SH005EG@SOIC20
[ (SA404) ]	
Z8F0123SH005SC@SOIC20 [ (SA404) ]	Z8F0123SH005SG@SOIC20
[ (SA404) ]	
Z8F0123SJ005EC@SOIC28 [ (SA404) ]	Z8F0123SJ005EG@SOIC28
[ (SA404) ]	
Z8F0123SJ005SC@SOIC28 [ (SA404) ]	Z8F0123SJ005SG@SOIC28
[ (SA404) ]	
Z8F012AHH020EC@SSOP20 [ (SA626A) ]	Z8F012AHH020EG@SSOP20
[ (SA626A) ]	
Z8F012AHH020SC@SSOP20 [ (SA626A) ]	Z8F012AHH020SG@SSOP20
[ (SA626A) ]	
Z8F012AHJ020EC@SSOP28 [ (SA626A) ]	Z8F012AHJ020EG@SSOP28
[ (SA626A) ]	
Z8F012AHJ020SC@SSOP28 [ (SA626A) ]	Z8F012AHJ020SG@SSOP28
[ (SA626A) ]	
Z8F012APB020EC	
Z8F012APB020EG	
Z8F012APB020SC	
Z8F012APB020SG	
Z8F012APH020EC	
Z8F012APH020EG	
Z8F012APH020SC	
Z8F012APH020SG	
Z8F012APJ020EC	
Z8F012APJ020EG	
Z8F012APJ020SC	
Z8F012APJ020SG	
Z8F012AQB020EC@QFN8 [ (SA683) ]	Z8F012AQB020EG@QFN8
[ (SA683) ]	
Z8F012AQB020SC@QFN8 [ (SA683) ]	Z8F012AQB020SG@QFN8
[ (SA683) ]	
Z8F012ASB020EC@SOIC8 [ (SA602A) ]	Z8F012ASB020EG@SOIC8
[ (SA602A) ]	
Z8F012ASB020SC@SOIC8 [ (SA602A) ]	Z8F012ASB020SG@SOIC8
[ (SA602A) ]	
Z8F012ASH020EC@SOIC20 [ (SA404) ]	Z8F012ASH020EG@SOIC20
[ (SA404) ]	

Z8F012ASH020SC@SOIC20 [(SA404)] [(SA404)]	Z8F012ASH020SG@SOIC20
Z8F012ASJ020EC@SOIC28 [(SA404)] [(SA404)]	Z8F012ASJ020EG@SOIC28
Z8F012ASJ020SC@SOIC28 [(SA404)] [(SA404)]	Z8F012ASJ020SG@SOIC28
Z8F0130HH020EG@SSOP20 [(SA626A)] [(SA626A)]	Z8F0130HH020SG@SSOP20
Z8F0130HJ020EG@SSOP28 [(SA626A)] [(SA626A)]	Z8F0130HJ020SG@SSOP28
Z8F0130PH020EG	
Z8F0130PH020SG	
Z8F0130PJ020EG	
Z8F0130PJ020SG	
Z8F0130QH020EG@QFN20 [(SA759)] [(SA759)]	Z8F0130QH020SG@QFN20
Z8F0130QJ020EG@QFN28 [(SA697)] [(SA697)]	Z8F0130QJ020SG@QFN28
Z8F0130SH020EG@SOIC20 [(SA404)] [(SA404)]	Z8F0130SH020SG@SOIC20
Z8F0130SJ020EG@SOIC28 [(SA404)] [(SA404)]	Z8F0130SJ020SG@SOIC28
Z8F0131HH020EG@SSOP20 [(SA626A)] [(SA626A)]	Z8F0131HH020SG@SSOP20
Z8F0131HJ020EG@SSOP28 [(SA626A)] [(SA626A)]	Z8F0131HJ020SG@SSOP28
Z8F0131PH020EG	
Z8F0131PH020SG	
Z8F0131PJ020EG	
Z8F0131PJ020SG	
Z8F0131QH020EG@QFN20 [(SA759)] [(SA759)]	Z8F0131QH020SG@QFN20
Z8F0131QJ020EG@QFN28 [(SA697)] [(SA697)]	Z8F0131QJ020SG@QFN28
Z8F0131SH020EG@SOIC20 [(SA404)] [(SA404)]	Z8F0131SH020SG@SOIC20
Z8F0131SJ020EG@SOIC28 [(SA404)] [(SA404)]	Z8F0131SJ020SG@SOIC28
Z8F0213HH005EC@SSOP20 [(SA626A)] [(SA626A)]	Z8F0213HH005EG@SSOP20
Z8F0213HH005SC@SSOP20 [(SA626A)] [(SA626A)]	Z8F0213HH005SG@SSOP20
Z8F0213HJ005EC@SSOP28 [(SA626A)] [(SA626A)]	Z8F0213HJ005EG@SSOP28

[ ( SA626A ) ]  
Z8F0213HJ005SC@SSOP28 [ ( SA626A ) ]            Z8F0213HJ005SG@SSOP28  
[ ( SA626A ) ]  
Z8F0213PB005EC  
Z8F0213PB005EG  
Z8F0213PB005SC  
Z8F0213PB005SG  
Z8F0213PH005EC  
Z8F0213PH005EG  
Z8F0213PH005SC  
Z8F0213PH005SG  
Z8F0213PJ005EC  
Z8F0213PJ005EG  
Z8F0213PJ005SC  
Z8F0213PJ005SG  
Z8F0213QB005EC@QFN8 [ ( SA683 ) ]            Z8F0213QB005EG@QFN8  
[ ( SA683 ) ]  
Z8F0213QB005SC@QFN8 [ ( SA683 ) ]            Z8F0213QB005SG@QFN8  
[ ( SA683 ) ]  
Z8F0213SB005EC@SOIC8 [ ( SA602A ) ]            Z8F0213SB005EG@SOIC8  
[ ( SA602A ) ]  
Z8F0213SB005SC@SOIC8 [ ( SA602A ) ]            Z8F0213SB005SG@SOIC8  
[ ( SA602A ) ]  
Z8F0213SH005EC@SOIC20 [ ( SA404 ) ]            Z8F0213SH005EG@SOIC20  
[ ( SA404 ) ]  
Z8F0213SH005SC@SOIC20 [ ( SA404 ) ]            Z8F0213SH005SG@SOIC20  
[ ( SA404 ) ]  
Z8F0213SJ005EC@SOIC28 [ ( SA404 ) ]            Z8F0213SJ005EG@SOIC28  
[ ( SA404 ) ]  
Z8F0213SJ005SC@SOIC28 [ ( SA404 ) ]            Z8F0213SJ005SG@SOIC28  
[ ( SA404 ) ]  
Z8F021AHH020EC@SSOP20 [ ( SA626A ) ]            Z8F021AHH020EG@SSOP20  
[ ( SA626A ) ]  
Z8F021AHH020SC@SSOP20 [ ( SA626A ) ]            Z8F021AHH020SG@SSOP20  
[ ( SA626A ) ]  
Z8F021AHJ020EC@SSOP28 [ ( SA626A ) ]            Z8F021AHJ020EG@SSOP28  
[ ( SA626A ) ]  
Z8F021AHJ020SC@SSOP28 [ ( SA626A ) ]            Z8F021AHJ020SG@SSOP28  
[ ( SA626A ) ]  
Z8F021APB020EC  
Z8F021APB020EG  
Z8F021APB020SC  
Z8F021APB020SG

Z8F021APH020EC  
Z8F021APH020EG  
Z8F021APH020SC  
Z8F021APH020SG  
Z8F021APJ020EC  
Z8F021APJ020EG  
Z8F021APJ020SC  
Z8F021APJ020SG  
Z8F021AQB020EC@QFN8 [(SA683)]  
[(SA683)]  
Z8F021AQB020SC@QFN8 [(SA683)]  
[(SA683)]  
Z8F021ASB020EC@SOIC8 [(SA602A)]  
[(SA602A)]  
Z8F021ASB020SC@SOIC8 [(SA602A)]  
[(SA602A)]  
Z8F021ASH020EC@SOIC20 [(SA404)]  
[(SA404)]  
Z8F021ASH020SC@SOIC20 [(SA404)]  
[(SA404)]  
Z8F021ASJ020EC@SOIC28 [(SA404)]  
[(SA404)]  
Z8F021ASJ020SC@SOIC28 [(SA404)]  
[(SA404)]  
Z8F0223HH005EC@SSOP20 [(SA626A)]  
[(SA626A)]  
Z8F0223HH005SC@SSOP20 [(SA626A)]  
[(SA626A)]  
Z8F0223HJ005EC@SSOP28 [(SA626A)]  
[(SA626A)]  
Z8F0223HJ005SC@SSOP28 [(SA626A)]  
[(SA626A)]  
Z8F0223PB005EC  
Z8F0223PB005EG  
Z8F0223PB005SC  
Z8F0223PB005SG  
Z8F0223PH005EC  
Z8F0223PH005EG  
Z8F0223PH005SC  
Z8F0223PH005SG  
Z8F0223PJ005EC  
Z8F0223PJ005EG  
Z8F0223PJ005SC

Z8F021AQB020EG@QFN8  
  
Z8F021AQB020SG@QFN8  
  
Z8F021ASB020EG@SOIC8  
  
Z8F021ASB020SG@SOIC8  
  
Z8F021ASH020EG@SOIC20  
  
Z8F021ASH020SG@SOIC20  
  
Z8F021ASJ020EG@SOIC28  
  
Z8F021ASJ020SG@SOIC28  
  
Z8F0223HH005EG@SSOP20  
  
Z8F0223HH005SG@SSOP20  
  
Z8F0223HJ005EG@SSOP28  
  
Z8F0223HJ005SG@SSOP28

Z8F0223PJ005SG

Z8F0223QB005EC@QFN8 [(SA683)]  
[(SA683)]

Z8F0223QB005SC@QFN8 [(SA683)]  
[(SA683)]

Z8F0223SB005EC@SOIC8 [(SA602A)]  
[(SA602A)]

Z8F0223SB005SC@SOIC8 [(SA602A)]  
[(SA602A)]

Z8F0223SH005EC@SOIC20 [(SA404)]  
[(SA404)]

Z8F0223SH005SC@SOIC20 [(SA404)]  
[(SA404)]

Z8F0223SJ005EC@SOIC28 [(SA404)]  
[(SA404)]

Z8F0223SJ005SC@SOIC28 [(SA404)]  
[(SA404)]

Z8F022AHH020EC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F022AHH020SC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F022AHJ020EC@SSOP28 [(SA626A)]  
[(SA626A)]

Z8F022AHJ020SC@SSOP28 [(SA626A)]  
[(SA626A)]

Z8F022APB020EC

Z8F022APB020EG

Z8F022APB020SC

Z8F022APB020SG

Z8F022APH020EC

Z8F022APH020EG

Z8F022APH020SC

Z8F022APH020SG

Z8F022APJ020EC

Z8F022APJ020EG

Z8F022APJ020SC

Z8F022APJ020SG

Z8F022AQB020EC@QFN8 [(SA683)]  
[(SA683)]

Z8F022AQB020SC@QFN8 [(SA683)]  
[(SA683)]

Z8F022ASB020EC@SOIC8 [(SA602A)]  
[(SA602A)]

Z8F0223QB005EG@QFN8

Z8F0223QB005SG@QFN8

Z8F0223SB005EG@SOIC8

Z8F0223SB005SG@SOIC8

Z8F0223SH005EG@SOIC20

Z8F0223SH005SG@SOIC20

Z8F0223SJ005EG@SOIC28

Z8F0223SJ005SG@SOIC28

Z8F022AHH020EG@SSOP20

Z8F022AHH020SG@SSOP20

Z8F022AHJ020EG@SSOP28

Z8F022AHJ020SG@SSOP28

Z8F022AQB020EG@QFN8

Z8F022AQB020SG@QFN8

Z8F022ASB020EG@SOIC8



Z8F022ASB020SC@SOIC8 [(SA602A)]	Z8F022ASB020SG@SOIC8
[(SA602A)]	
Z8F022ASH020EC@SOIC20 [(SA404)]	Z8F022ASH020EG@SOIC20
[(SA404)]	
Z8F022ASH020SC@SOIC20 [(SA404)]	Z8F022ASH020SG@SOIC20
[(SA404)]	
Z8F022ASJ020EC@SOIC28 [(SA404)]	Z8F022ASJ020EG@SOIC28
[(SA404)]	
Z8F022ASJ020SC@SOIC28 [(SA404)]	Z8F022ASJ020SG@SOIC28
[(SA404)]	
Z8F0230HH020EG@SSOP20 [(SA626A)]	Z8F0230HH020SG@SSOP20
[(SA626A)]	
Z8F0230HJ020EG@SSOP28 [(SA626A)]	Z8F0230HJ020SG@SSOP28
[(SA626A)]	
Z8F0230PH020EG	
Z8F0230PH020SG	
Z8F0230PJ020EG	
Z8F0230PJ020SG	
Z8F0230QH020EG@QFN20 [(SA759)]	Z8F0230QH020SG@QFN20
[(SA759)]	
Z8F0230QJ020EG@QFN28 [(SA697)]	Z8F0230QJ020SG@QFN28
[(SA697)]	
Z8F0230SH020EG@SOIC20 [(SA404)]	Z8F0230SH020SG@SOIC20
[(SA404)]	
Z8F0230SJ020EG@SOIC28 [(SA404)]	Z8F0230SJ020SG@SOIC28
[(SA404)]	
Z8F0231HH020EG@SSOP20 [(SA626A)]	Z8F0231HH020SG@SSOP20
[(SA626A)]	
Z8F0231HJ020EG@SSOP28 [(SA626A)]	Z8F0231HJ020SG@SSOP28
[(SA626A)]	
Z8F0231PH020EG	
Z8F0231PH020SG	
Z8F0231PJ020EG	
Z8F0231PJ020SG	
Z8F0231QH020EG@QFN20 [(SA759)]	Z8F0231QH020SG@QFN20
[(SA759)]	
Z8F0231QJ020EG@QFN28 [(SA697)]	Z8F0231QJ020SG@QFN28
[(SA697)]	
Z8F0231SH020EG@SOIC20 [(SA404)]	Z8F0231SH020SG@SOIC20
[(SA404)]	
Z8F0231SJ020EG@SOIC28 [(SA404)]	Z8F0231SJ020SG@SOIC28
[(SA404)]	
Z8F0411HH020EC@SSOP20 [(SA626A)]	Z8F0411HH020EG@SSOP20

[ ( SA626A ) ]  
Z8F0411HH020SC@SSOP20 [ ( SA626A ) ]            Z8F0411HH020SG@SSOP20  
[ ( SA626A ) ]  
Z8F0411PH020EC  
Z8F0411PH020EG  
Z8F0411PH020SC  
Z8F0411PH020SG  
Z8F0412PJ020EC  
Z8F0412PJ020EG  
Z8F0412PJ020SC  
Z8F0412PJ020SG  
Z8F0412SJ020EC@SOIC28 [ ( SA404 ) ]            Z8F0412SJ020EG@SOIC28  
[ ( SA404 ) ]  
Z8F0412SJ020SC@SOIC28 [ ( SA404 ) ]            Z8F0412SJ020SG@SOIC28  
[ ( SA404 ) ]  
Z8F0413HH005EC@SSOP20 [ ( SA626A ) ]            Z8F0413HH005EG@SSOP20  
[ ( SA626A ) ]  
Z8F0413HH005SC@SSOP20 [ ( SA626A ) ]            Z8F0413HH005SG@SSOP20  
[ ( SA626A ) ]  
Z8F0413HJ005EC@SSOP28 [ ( SA626A ) ]            Z8F0413HJ005EG@SSOP28  
[ ( SA626A ) ]  
Z8F0413HJ005SC@SSOP28 [ ( SA626A ) ]            Z8F0413HJ005SG@SSOP28  
[ ( SA626A ) ]  
Z8F0413PB005EC  
Z8F0413PB005EG  
Z8F0413PB005SC  
Z8F0413PB005SG  
Z8F0413PH005EC  
Z8F0413PH005EG  
Z8F0413PH005SC  
Z8F0413PH005SG  
Z8F0413PJ005EC  
Z8F0413PJ005EG  
Z8F0413PJ005SC  
Z8F0413PJ005SG  
Z8F0413QB005EC@QFN8 [ ( SA683 ) ]            Z8F0413QB005EG@QFN8  
[ ( SA683 ) ]  
Z8F0413QB005SC@QFN8 [ ( SA683 ) ]            Z8F0413QB005SG@QFN8  
[ ( SA683 ) ]  
Z8F0413SB005EC@SOIC8 [ ( SA602A ) ]            Z8F0413SB005EG@SOIC8  
[ ( SA602A ) ]  
Z8F0413SB005SC@SOIC8 [ ( SA602A ) ]            Z8F0413SB005SG@SOIC8  
[ ( SA602A ) ]

Z8F0413SH005EC@SOIC20 [(SA404)]	Z8F0413SH005EG@SOIC20
[(SA404)]	
Z8F0413SH005SC@SOIC20 [(SA404)]	Z8F0413SH005SG@SOIC20
[(SA404)]	
Z8F0413SJ005EC@SOIC28 [(SA404)]	Z8F0413SJ005EG@SOIC28
[(SA404)]	
Z8F0413SJ005SC@SOIC28 [(SA404)]	Z8F0413SJ005SG@SOIC28
[(SA404)]	
Z8F041AHH020EC@SSOP20 [(SA626A)]	Z8F041AHH020EG@SSOP20
[(SA626A)]	
Z8F041AHH020SC@SSOP20 [(SA626A)]	Z8F041AHH020SG@SSOP20
[(SA626A)]	
Z8F041AHJ020EC@SSOP28 [(SA626A)]	Z8F041AHJ020EG@SSOP28
[(SA626A)]	
Z8F041AHJ020SC@SSOP28 [(SA626A)]	Z8F041AHJ020SG@SSOP28
[(SA626A)]	
Z8F041APB020EC	
Z8F041APB020EG	
Z8F041APB020SC	
Z8F041APB020SG	
Z8F041APH020EC	
Z8F041APH020EG	
Z8F041APH020SC	
Z8F041APH020SG	
Z8F041APJ020EC	
Z8F041APJ020EG	
Z8F041APJ020SC	
Z8F041APJ020SG	
Z8F041AQB020EC@QFN8 [(SA683)]	Z8F041AQB020EG@QFN8
[(SA683)]	
Z8F041AQB020SC@QFN8 [(SA683)]	Z8F041AQB020SG@QFN8
[(SA683)]	
Z8F041ASB020EC@SOIC8 [(SA602A)]	Z8F041ASB020EG@SOIC8
[(SA602A)]	
Z8F041ASB020SC@SOIC8 [(SA602A)]	Z8F041ASB020SG@SOIC8
[(SA602A)]	
Z8F041ASH020EC@SOIC20 [(SA404)]	Z8F041ASH020EG@SOIC20
[(SA404)]	
Z8F041ASH020SC@SOIC20 [(SA404)]	Z8F041ASH020SG@SOIC20
[(SA404)]	
Z8F041ASJ020EC@SOIC28 [(SA404)]	Z8F041ASJ020EG@SOIC28
[(SA404)]	
Z8F041ASJ020SC@SOIC28 [(SA404)]	Z8F041ASJ020SG@SOIC28

[ ( SA404 ) ]  
Z8F0421HH020EC@SSOP20 [ ( SA626A ) ] Z8F0421HH020EG@SSOP20  
[ ( SA626A ) ]  
Z8F0421HH020SC@SSOP20 [ ( SA626A ) ] Z8F0421HH020SG@SSOP20  
[ ( SA626A ) ]  
Z8F0421PH020EC  
Z8F0421PH020EG  
Z8F0421PH020SC  
Z8F0421PH020SG  
Z8F0422PJ020EC  
Z8F0422PJ020EG  
Z8F0422PJ020SC  
Z8F0422PJ020SG  
Z8F0422SJ020EC@SOIC28 [ ( SA404 ) ] Z8F0422SJ020EG@SOIC28  
[ ( SA404 ) ]  
Z8F0422SJ020SC@SOIC28 [ ( SA404 ) ] Z8F0422SJ020SG@SOIC28  
[ ( SA404 ) ]  
Z8F0423HH005EC@SSOP20 [ ( SA626A ) ] Z8F0423HH005EG@SSOP20  
[ ( SA626A ) ]  
Z8F0423HH005SC@SSOP20 [ ( SA626A ) ] Z8F0423HH005SG@SSOP20  
[ ( SA626A ) ]  
Z8F0423HJ005EC@SSOP28 [ ( SA626A ) ] Z8F0423HJ005EG@SSOP28  
[ ( SA626A ) ]  
Z8F0423HJ005SC@SSOP28 [ ( SA626A ) ] Z8F0423HJ005SG@SSOP28  
[ ( SA626A ) ]  
Z8F0423PB005EC  
Z8F0423PB005EG  
Z8F0423PB005SC  
Z8F0423PB005SG  
Z8F0423PH005EC  
Z8F0423PH005EG  
Z8F0423PH005SC  
Z8F0423PH005SG  
Z8F0423PJ005EC  
Z8F0423PJ005EG  
Z8F0423PJ005SC  
Z8F0423PJ005SG  
Z8F0423QB005EC@QFN8 [ ( SA683 ) ] Z8F0423QB005EG@QFN8  
[ ( SA683 ) ]  
Z8F0423QB005SC@QFN8 [ ( SA683 ) ] Z8F0423QB005SG@QFN8  
[ ( SA683 ) ]  
Z8F0423SB005EC@SOIC8 [ ( SA602A ) ] Z8F0423SB005EG@SOIC8  
[ ( SA602A ) ]

Z8F0423SB005SC@SOIC8 [(SA602A)]	Z8F0423SB005SG@SOIC8
[(SA602A)]	
Z8F0423SH005EC@SOIC20 [(SA404)]	Z8F0423SH005EG@SOIC20
[(SA404)]	
Z8F0423SH005SC@SOIC20 [(SA404)]	Z8F0423SH005SG@SOIC20
[(SA404)]	
Z8F0423SJ005EC@SOIC28 [(SA404)]	Z8F0423SJ005EG@SOIC28
[(SA404)]	
Z8F0423SJ005SC@SOIC28 [(SA404)]	Z8F0423SJ005SG@SOIC28
[(SA404)]	
Z8F042AHH020EC@SSOP20 [(SA626A)]	Z8F042AHH020EG@SSOP20
[(SA626A)]	
Z8F042AHH020SC@SSOP20 [(SA626A)]	Z8F042AHH020SG@SSOP20
[(SA626A)]	
Z8F042AHJ020EC@SSOP28 [(SA626A)]	Z8F042AHJ020EG@SSOP28
[(SA626A)]	
Z8F042AHJ020SC@SSOP28 [(SA626A)]	Z8F042AHJ020SG@SSOP28
[(SA626A)]	
Z8F042APB020EC	
Z8F042APB020EG	
Z8F042APB020SC	
Z8F042APB020SG	
Z8F042APH020EC	
Z8F042APH020EG	
Z8F042APH020SC	
Z8F042APH020SG	
Z8F042APJ020EC	
Z8F042APJ020EG	
Z8F042APJ020SC	
Z8F042APJ020SG	
Z8F042AQB020EC@QFN8 [(SA683)]	Z8F042AQB020EG@QFN8
[(SA683)]	
Z8F042AQB020SC@QFN8 [(SA683)]	Z8F042AQB020SG@QFN8
[(SA683)]	
Z8F042ASB020EC@SOIC8 [(SA602A)]	Z8F042ASB020EG@SOIC8
[(SA602A)]	
Z8F042ASB020SC@SOIC8 [(SA602A)]	Z8F042ASB020SG@SOIC8
[(SA602A)]	
Z8F042ASH020EC@SOIC20 [(SA404)]	Z8F042ASH020EG@SOIC20
[(SA404)]	
Z8F042ASH020SC@SOIC20 [(SA404)]	Z8F042ASH020SG@SOIC20
[(SA404)]	
Z8F042ASJ020EC@SOIC28 [(SA404)]	Z8F042ASJ020EG@SOIC28

[ ( SA404 ) ]  
Z8F042ASJ020SC@SOIC28 [ ( SA404 ) ] Z8F042ASJ020SG@SOIC28  
[ ( SA404 ) ]  
Z8F0430HH020EG@SSOP20 [ ( SA626A ) ] Z8F0430HH020SG@SSOP20  
[ ( SA626A ) ]  
Z8F0430HJ020EG@SSOP28 [ ( SA626A ) ] Z8F0430HJ020SG@SSOP28  
[ ( SA626A ) ]  
Z8F0430PH020EG  
Z8F0430PH020SG  
Z8F0430PJ020EG  
Z8F0430PJ020SG  
Z8F0430QH020EG@QFN20 [ ( SA759 ) ] Z8F0430QH020SG@QFN20  
[ ( SA759 ) ]  
Z8F0430QJ020EG@QFN28 [ ( SA697 ) ] Z8F0430QJ020SG@QFN28  
[ ( SA697 ) ]  
Z8F0430SH020EG@SOIC20 [ ( SA404 ) ] Z8F0430SH020SG@SOIC20  
[ ( SA404 ) ]  
Z8F0430SJ020EG@SOIC28 [ ( SA404 ) ] Z8F0430SJ020SG@SOIC28  
[ ( SA404 ) ]  
Z8F0431HH020EG@SSOP20 [ ( SA626A ) ] Z8F0431HH020SG@SSOP20  
[ ( SA626A ) ]  
Z8F0431HJ020EG@SSOP28 [ ( SA626A ) ] Z8F0431HJ020SG@SSOP28  
[ ( SA626A ) ]  
Z8F0431PH020EG  
Z8F0431PH020SG  
Z8F0431PJ020EG  
Z8F0431PJ020SG  
Z8F0431QH020EG@QFN20 [ ( SA759 ) ] Z8F0431QH020SG@QFN20  
[ ( SA759 ) ]  
Z8F0431QJ020EG@QFN28 [ ( SA697 ) ] Z8F0431QJ020SG@QFN28  
[ ( SA697 ) ]  
Z8F0431SH020EG@SOIC20 [ ( SA404 ) ] Z8F0431SH020SG@SOIC20  
[ ( SA404 ) ]  
Z8F0431SJ020EG@SOIC28 [ ( SA404 ) ] Z8F0431SJ020SG@SOIC28  
[ ( SA404 ) ]  
Z8F0811HH020EC@SSOP20 [ ( SA626A ) ] Z8F0811HH020EG@SSOP20  
[ ( SA626A ) ]  
Z8F0811HH020SC@SSOP20 [ ( SA626A ) ] Z8F0811HH020SG@SSOP20  
[ ( SA626A ) ]  
Z8F0811PH020EC  
Z8F0811PH020EG  
Z8F0811PH020SC  
Z8F0811PH020SG

Z8F0812PJ020EC  
Z8F0812PJ020EG  
Z8F0812PJ020SC  
Z8F0812PJ020SG  
Z8F0812SJ020EC@SOIC28 [(SA404)] Z8F0812SJ020EG@SOIC28  
[(SA404)]  
Z8F0812SJ020SC@SOIC28 [(SA404)] Z8F0812SJ020SG@SOIC28  
[(SA404)]  
Z8F0813HH005EC@SSOP20 [(SA626A)] Z8F0813HH005EG@SSOP20  
[(SA626A)]  
Z8F0813HH005SC@SSOP20 [(SA626A)] Z8F0813HH005SG@SSOP20  
[(SA626A)]  
Z8F0813HJ020EC@SSOP28 [(SA626A)] Z8F0813HJ020EG@SSOP28  
[(SA626A)]  
Z8F0813HJ020SC@SSOP28 [(SA626A)] Z8F0813HJ020SG@SSOP28  
[(SA626A)]  
Z8F0813PB005EC  
Z8F0813PB005EG  
Z8F0813PB005SC  
Z8F0813PB005SG  
Z8F0813PH005EC  
Z8F0813PH005EG  
Z8F0813PH005SC  
Z8F0813PH005SG  
Z8F0813PJ020EC  
Z8F0813PJ020EG  
Z8F0813PJ020SC  
Z8F0813PJ020SG  
Z8F0813QB005EC@QFN8 [(SA683)] Z8F0813QB005EG@QFN8  
[(SA683)]  
Z8F0813QB005SC@QFN8 [(SA683)] Z8F0813QB005SG@QFN8  
[(SA683)]  
Z8F0813SB005EC@SOIC8 [(SA602A)] Z8F0813SB005EG@SOIC8  
[(SA602A)]  
Z8F0813SB005SC@SOIC8 [(SA602A)] Z8F0813SB005SG@SOIC8  
[(SA602A)]  
Z8F0813SH005EC@SOIC20 [(SA404)] Z8F0813SH005EG@SOIC20  
[(SA404)]  
Z8F0813SH005SC@SOIC20 [(SA404)] Z8F0813SH005SG@SOIC20  
[(SA404)]  
Z8F0813SJ020EC@SOIC28 [(SA404)] Z8F0813SJ020EG@SOIC28  
[(SA404)]  
Z8F0813SJ020SC@SOIC28 [(SA404)] Z8F0813SJ020SG@SOIC28

[ ( SA404 ) ]  
Z8F081AHH005EC@SSOP20 [ ( SA626A ) ] Z8F081AHH005EG@SSOP20  
[ ( SA626A ) ]  
Z8F081AHH005SC@SSOP20 [ ( SA626A ) ] Z8F081AHH005SG@SSOP20  
[ ( SA626A ) ]  
Z8F081AHJ020EC@SSOP28 [ ( SA626A ) ] Z8F081AHJ020EG@SSOP28  
[ ( SA626A ) ]  
Z8F081AHJ020SC@SSOP28 [ ( SA626A ) ] Z8F081AHJ020SG@SSOP28  
[ ( SA626A ) ]  
Z8F081APB020EC  
Z8F081APB020EG  
Z8F081APB020SC  
Z8F081APB020SG  
Z8F081APH005EC  
Z8F081APH005EG  
Z8F081APH005SC  
Z8F081APH005SG  
Z8F081APJ020EC  
Z8F081APJ020EG  
Z8F081APJ020SC  
Z8F081APJ020SG  
Z8F081AQB020EC@QFN8 [ ( SA683 ) ] Z8F081AQB020EG@QFN8  
[ ( SA683 ) ]  
Z8F081AQB020SC@QFN8 [ ( SA683 ) ] Z8F081AQB020SG@QFN8  
[ ( SA683 ) ]  
Z8F081ASB020EC@SOIC8 [ ( SA602A ) ] Z8F081ASB020EG@SOIC8  
[ ( SA602A ) ]  
Z8F081ASB020SC@SOIC8 [ ( SA602A ) ] Z8F081ASB020SG@SOIC8  
[ ( SA602A ) ]  
Z8F081ASH005EC@SOIC20 [ ( SA404 ) ] Z8F081ASH005EG@SOIC20  
[ ( SA404 ) ]  
Z8F081ASH005SC@SOIC20 [ ( SA404 ) ] Z8F081ASH005SG@SOIC20  
[ ( SA404 ) ]  
Z8F081ASJ020EC@SOIC28 [ ( SA404 ) ] Z8F081ASJ020EG@SOIC28  
[ ( SA404 ) ]  
Z8F081ASJ020SC@SOIC28 [ ( SA404 ) ] Z8F081ASJ020SG@SOIC28  
[ ( SA404 ) ]  
Z8F0821HH020EC@SSOP20 [ ( SA626A ) ] Z8F0821HH020EG@SSOP20  
[ ( SA626A ) ]  
Z8F0821HH020SC@SSOP20 [ ( SA626A ) ] Z8F0821HH020SG@SSOP20  
[ ( SA626A ) ]  
Z8F0821PH020EC  
Z8F0821PH020EG



Z8F0821PH020SC  
Z8F0821PH020SG  
Z8F0822PJ020EC  
Z8F0822PJ020EG  
Z8F0822PJ020SC  
Z8F0822PJ020SG  
Z8F0822SJ020EC@SOIC28 [(SA404)] Z8F0822SJ020EG@SOIC28  
[(SA404)]  
Z8F0822SJ020SC@SOIC28 [(SA404)] Z8F0822SJ020SG@SOIC28  
[(SA404)]  
Z8F0823HH005EC@SSOP20 [(SA626A)] Z8F0823HH005EG@SSOP20  
[(SA626A)]  
Z8F0823HH005SC@SSOP20 [(SA626A)] Z8F0823HH005SG@SSOP20  
[(SA626A)]  
Z8F0823HJ020EC@SSOP28 [(SA626A)] Z8F0823HJ020EG@SSOP28  
[(SA626A)]  
Z8F0823HJ020SC@SSOP28 [(SA626A)] Z8F0823HJ020SG@SSOP28  
[(SA626A)]  
Z8F0823PB005EC  
Z8F0823PB005EG  
Z8F0823PB005SC  
Z8F0823PB005SG  
Z8F0823PH005EC  
Z8F0823PH005EG  
Z8F0823PH005SC  
Z8F0823PH005SG  
Z8F0823PJ020EC  
Z8F0823PJ020EG  
Z8F0823PJ020SC  
Z8F0823PJ020SG  
Z8F0823QB005EC@QFN8 [(SA683)] Z8F0823QB005EG@QFN8  
[(SA683)]  
Z8F0823QB005SC@QFN8 [(SA683)] Z8F0823QB005SG@QFN8  
[(SA683)]  
Z8F0823SB005EC@SOIC8 [(SA602A)] Z8F0823SB005EG@SOIC8  
[(SA602A)]  
Z8F0823SB005SC@SOIC8 [(SA602A)] Z8F0823SB005SG@SOIC8  
[(SA602A)]  
Z8F0823SH005EC@SOIC20 [(SA404)] Z8F0823SH005EG@SOIC20  
[(SA404)]  
Z8F0823SH005SC@SOIC20 [(SA404)] Z8F0823SH005SG@SOIC20  
[(SA404)]  
Z8F0823SJ020EC@SOIC28 [(SA404)] Z8F0823SJ020EG@SOIC28

[ ( SA404 ) ]  
Z8F0823SJ020SC@SOIC28 [ ( SA404 ) ]                    Z8F0823SJ020SG@SOIC28  
[ ( SA404 ) ]  
Z8F082AHH005EC@SSOP20 [ ( SA626A ) ]                    Z8F082AHH005EG@SSOP20  
[ ( SA626A ) ]  
Z8F082AHH005SC@SSOP20 [ ( SA626A ) ]                    Z8F082AHH005SG@SSOP20  
[ ( SA626A ) ]  
Z8F082AHJ020EC@SSOP28 [ ( SA626A ) ]                    Z8F082AHJ020EG@SSOP28  
[ ( SA626A ) ]  
Z8F082AHJ020SC@SSOP28 [ ( SA626A ) ]                    Z8F082AHJ020SG@SSOP28  
[ ( SA626A ) ]  
Z8F082APB020EC  
Z8F082APB020EG  
Z8F082APB020SC  
Z8F082APB020SG  
Z8F082APH005EC  
Z8F082APH005EG  
Z8F082APH005SC  
Z8F082APH005SG  
Z8F082APJ020EC  
Z8F082APJ020EG  
Z8F082APJ020SC  
Z8F082APJ020SG  
Z8F082AQB020EC@QFN8 [ ( SA683 ) ]                    Z8F082AQB020EG@QFN8  
[ ( SA683 ) ]  
Z8F082AQB020SC@QFN8 [ ( SA683 ) ]                    Z8F082AQB020SG@QFN8  
[ ( SA683 ) ]  
Z8F082ASB020EC@SOIC8 [ ( SA602A ) ]                    Z8F082ASB020EG@SOIC8  
[ ( SA602A ) ]  
Z8F082ASB020SC@SOIC8 [ ( SA602A ) ]                    Z8F082ASB020SG@SOIC8  
[ ( SA602A ) ]  
Z8F082ASH005EC@SOIC20 [ ( SA404 ) ]                    Z8F082ASH005EG@SOIC20  
[ ( SA404 ) ]  
Z8F082ASH005SC@SOIC20 [ ( SA404 ) ]                    Z8F082ASH005SG@SOIC20  
[ ( SA404 ) ]  
Z8F082ASJ020EC@SOIC28 [ ( SA404 ) ]                    Z8F082ASJ020EG@SOIC28  
[ ( SA404 ) ]  
Z8F082ASJ020SC@SOIC28 [ ( SA404 ) ]                    Z8F082ASJ020SG@SOIC28  
[ ( SA404 ) ]  
Z8F0830HH020EG@SSOP20 [ ( SA626A ) ]                    Z8F0830HH020SG@SSOP20  
[ ( SA626A ) ]  
Z8F0830HJ020EG@SSOP28 [ ( SA626A ) ]                    Z8F0830HJ020SG@SSOP28  
[ ( SA626A ) ]

Z8F0830PH020EG	
Z8F0830PH020SG	
Z8F0830PJ020EG	
Z8F0830PJ020SG	
Z8F0830QH020EG@QFN20 [(SA759)]	Z8F0830QH020SG@QFN20
[(SA759)]	
Z8F0830QJ020EG@QFN28 [(SA697)]	Z8F0830QJ020SG@QFN28
[(SA697)]	
Z8F0830SH020EG@SOIC20 [(SA404)]	Z8F0830SH020SG@SOIC20
[(SA404)]	
Z8F0830SJ020EG@SOIC28 [(SA404)]	Z8F0830SJ020SG@SOIC28
[(SA404)]	
Z8F0831HH020EG@SSOP20 [(SA626A)]	Z8F0831HH020SG@SSOP20
[(SA626A)]	
Z8F0831HJ020EG@SSOP28 [(SA626A)]	Z8F0831HJ020SG@SSOP28
[(SA626A)]	
Z8F0831PH020EG	
Z8F0831PH020SG	
Z8F0831PJ020EG	
Z8F0831PJ020SG	
Z8F0831QH020EG@QFN20 [(SA759)]	Z8F0831QH020SG@QFN20
[(SA759)]	
Z8F0831QJ020EG@QFN28 [(SA697)]	Z8F0831QJ020SG@QFN28
[(SA697)]	
Z8F0831SH020EG@SOIC20 [(SA404)]	Z8F0831SH020SG@SOIC20
[(SA404)]	
Z8F0831SJ020EG@SOIC28 [(SA404)]	Z8F0831SJ020SG@SOIC28
[(SA404)]	
Z8F1232HH020EG@SSOP20 [(SA626A)]	Z8F1232HH020SG@SSOP20
[(SA626A)]	
Z8F1232HJ020EG@SSOP28 [(SA626A)]	Z8F1232HJ020SG@SSOP28
[(SA626A)]	
Z8F1232PH020EG	
Z8F1232PH020SG	
Z8F1232PJ020EG	
Z8F1232PJ020SG	
Z8F1232QH020EG@QFN20 [(SA759)]	Z8F1232QH020SG@QFN20
[(SA759)]	
Z8F1232QJ020EG@QFN28 [(SA697)]	Z8F1232QJ020SG@QFN28
[(SA697)]	
Z8F1232SH020EG@SOIC20 [(SA404)]	Z8F1232SH020SG@SOIC20
[(SA404)]	
Z8F1232SJ020EG@SOIC28 [(SA404)]	Z8F1232SJ020SG@SOIC28

[ ( SA404 ) ]

Z8F1233HH020EG@SSOP20 [ ( SA626A ) ]

Z8F1233HH020SG@SSOP20

[ ( SA626A ) ]

Z8F1233HJ020EG@SSOP28 [ ( SA626A ) ]

Z8F1233HJ020SG@SSOP28

[ ( SA626A ) ]

Z8F1233PH020EG

Z8F1233PH020SG

Z8F1233PJ020EG

Z8F1233PJ020SG

Z8F1233QH020EG@QFN20 [ ( SA759 ) ]

Z8F1233QH020SG@QFN20

[ ( SA759 ) ]

Z8F1233QJ020EG@QFN28 [ ( SA697 ) ]

Z8F1233QJ020SG@QFN28

[ ( SA697 ) ]

Z8F1233SH020EG@SOIC20 [ ( SA404 ) ]

Z8F1233SH020SG@SOIC20

[ ( SA404 ) ]

Z8F1233SJ020EG@SOIC28 [ ( SA404 ) ]

Z8F1233SJ020SG@SOIC28

[ ( SA404 ) ]

Z8F4801AN@TQFP44 [ ( SA245A ) ]

Z8F4801PM

Z8F4801VN@PLCC44 [ ( SA244 ) ]

Z8F6401AN@TQFP44

[ ( SA245A ) ]

Z8F6401PM

Z8F6401VN@PLCC44

[ ( SA244 ) ]

Z8F6421AN020EC@LQFP44 [ ( SA245A ) ]

Z8F6421AN020SC@LQFP44

[ ( SA245A ) ]

Z8F6421PM020EC

Z8F6421PM020SC

Z8F6421VN020EC@PLCC44 [ ( SA244 ) ]

Z8F6421VN020SC@PLCC44

[ ( SA244 ) ]

ZGP323HAH2004C@SSOP20 [ ( SA626A ) ]

ZGP323HAH2004G@SSOP20

[ ( SA626A ) ]

ZGP323HAH2008C@SSOP20 [ ( SA626A ) ]

ZGP323HAH2008G@SSOP20

[ ( SA626A ) ]

ZGP323HAH2016C@SSOP20 [ ( SA626A ) ]

ZGP323HAH2016G@SSOP20

[ ( SA626A ) ]

ZGP323HAH2032C@SSOP20 [ ( SA626A ) ]

ZGP323HAH2032G@SSOP20

[ ( SA626A ) ]

ZGP323HAH2804C@SSOP28 [ ( SA626A ) ]

ZGP323HAH2804G@SSOP28

[ ( SA626A ) ]

ZGP323HAH2808C@SSOP28 [ ( SA626A ) ]

ZGP323HAH2808G@SSOP28

[ ( SA626A ) ]

ZGP323HAH2816C@SSOP28 [ ( SA626A ) ]

ZGP323HAH2816G@SSOP28

[ ( SA626A ) ]

ZGP323HAH2832C@SSOP28 [(SA626A)]	ZGP323HAH2832G@SSOP28
[(SA626A)]	
ZGP323HAH4804C@SSOP48 [(SA669)]	ZGP323HAH4804G@SSOP48
[(SA669)]	
ZGP323HAH4808C@SSOP48 [(SA669)]	ZGP323HAH4808G@SSOP48
[(SA669)]	
ZGP323HAH4816C@SSOP48 [(SA669)]	ZGP323HAH4816G@SSOP48
[(SA669)]	
ZGP323HAH4832C@SSOP48 [(SA669)]	ZGP323HAH4832G@SSOP48
[(SA669)]	
ZGP323HAP2004C	
ZGP323HAP2004G	
ZGP323HAP2008C	
ZGP323HAP2008G	
ZGP323HAP2016C	
ZGP323HAP2016G	
ZGP323HAP2032C	
ZGP323HAP2032G	
ZGP323HAP2804C	
ZGP323HAP2804G	
ZGP323HAP2808C	
ZGP323HAP2808G	
ZGP323HAP2816C	
ZGP323HAP2816G	
ZGP323HAP2832C	
ZGP323HAP2832G	
ZGP323HAP4004C	
ZGP323HAP4004G	
ZGP323HAP4008C	
ZGP323HAP4008G	
ZGP323HAP4016C	
ZGP323HAP4016G	
ZGP323HAP4032C	
ZGP323HAP4032G	
ZGP323HAS2004C@SOIC20 [(SA404)]	ZGP323HAS2004G@SOIC20
[(SA404)]	
ZGP323HAS2008C@SOIC20 [(SA404)]	ZGP323HAS2008G@SOIC20
[(SA404)]	
ZGP323HAS2016C@SOIC20 [(SA404)]	ZGP323HAS2016G@SOIC20
[(SA404)]	
ZGP323HAS2032C@SOIC20 [(SA404)]	ZGP323HAS2032G@SOIC20
[(SA404)]	
ZGP323HAS2804C@SOIC28 [(SA404)]	ZGP323HAS2804G@SOIC28

[ ( SA404 ) ]

ZGP323HAS2808C@SOIC28 [ ( SA404 ) ]

ZGP323HAS2808G@SOIC28

[ ( SA404 ) ]

ZGP323HAS2816C@SOIC28 [ ( SA404 ) ]

ZGP323HAS2816G@SOIC28

[ ( SA404 ) ]

ZGP323HAS2832C@SOIC28 [ ( SA404 ) ]

ZGP323HAS2832G@SOIC28

[ ( SA404 ) ]

ZGP323HEH2004C@SSOP20 [ ( SA626A ) ]

ZGP323HEH2004G@SSOP20

[ ( SA626A ) ]

ZGP323HEH2008C@SSOP20 [ ( SA626A ) ]

ZGP323HEH2008G@SSOP20

[ ( SA626A ) ]

ZGP323HEH2016C@SSOP20 [ ( SA626A ) ]

ZGP323HEH2016G@SSOP20

[ ( SA626A ) ]

ZGP323HEH2032C@SSOP20 [ ( SA626A ) ]

ZGP323HEH2032G@SSOP20

[ ( SA626A ) ]

ZGP323HEH2804C@SSOP28 [ ( SA626A ) ]

ZGP323HEH2804G@SSOP28

[ ( SA626A ) ]

ZGP323HEH2808C@SSOP28 [ ( SA626A ) ]

ZGP323HEH2808G@SSOP28

[ ( SA626A ) ]

ZGP323HEH2816C@SSOP28 [ ( SA626A ) ]

ZGP323HEH2816G@SSOP28

[ ( SA626A ) ]

ZGP323HEH2832C@SSOP28 [ ( SA626A ) ]

ZGP323HEH2832G@SSOP28

[ ( SA626A ) ]

ZGP323HEH4804C@SSOP48 [ ( SA669 ) ]

ZGP323HEH4804G@SSOP48

[ ( SA669 ) ]

ZGP323HEH4808C@SSOP48 [ ( SA669 ) ]

ZGP323HEH4808G@SSOP48

[ ( SA669 ) ]

ZGP323HEH4816C@SSOP48 [ ( SA669 ) ]

ZGP323HEH4816G@SSOP48

[ ( SA669 ) ]

ZGP323HEH4832C@SSOP48 [ ( SA669 ) ]

ZGP323HEH4832G@SSOP48

[ ( SA669 ) ]

ZGP323HEP2004C

ZGP323HEP2004G

ZGP323HEP2008C

ZGP323HEP2008G

ZGP323HEP2016C

ZGP323HEP2016G

ZGP323HEP2032C

ZGP323HEP2032G

ZGP323HEP2804C

ZGP323HEP2804G

ZGP323HEP2808C

ZGP323HEP2808G

ZGP323HEP2816C  
ZGP323HEP2816G  
ZGP323HEP2832C  
ZGP323HEP2832G  
ZGP323HEP4004C  
ZGP323HEP4004G  
ZGP323HEP4008C  
ZGP323HEP4008G  
ZGP323HEP4016C  
ZGP323HEP4016G  
ZGP323HEP4032C  
ZGP323HEP4032G  
ZGP323HES2004C@SOIC20 [ ( SA404 ) ] ZGP323HES2004G@SOIC20  
[ ( SA404 ) ]  
ZGP323HES2008C@SOIC20 [ ( SA404 ) ] ZGP323HES2008G@SOIC20  
[ ( SA404 ) ]  
ZGP323HES2016C@SOIC20 [ ( SA404 ) ] ZGP323HES2016G@SOIC20  
[ ( SA404 ) ]  
ZGP323HES2032C@SOIC20 [ ( SA404 ) ] ZGP323HES2032G@SOIC20  
[ ( SA404 ) ]  
ZGP323HES2804C@SOIC28 [ ( SA404 ) ] ZGP323HES2804G@SOIC28  
[ ( SA404 ) ]  
ZGP323HES2808C@SOIC28 [ ( SA404 ) ] ZGP323HES2808G@SOIC28  
[ ( SA404 ) ]  
ZGP323HES2816C@SOIC28 [ ( SA404 ) ] ZGP323HES2816G@SOIC28  
[ ( SA404 ) ]  
ZGP323HES2832C@SOIC28 [ ( SA404 ) ] ZGP323HES2832G@SOIC28  
[ ( SA404 ) ]  
ZGP323HSH2004C@SSOP20 [ ( SA626A ) ] ZGP323HSH2004G@SSOP20  
[ ( SA626A ) ]  
ZGP323HSH2008C@SSOP20 [ ( SA626A ) ] ZGP323HSH2008G@SSOP20  
[ ( SA626A ) ]  
ZGP323HSH2016C@SSOP20 [ ( SA626A ) ] ZGP323HSH2016G@SSOP20  
[ ( SA626A ) ]  
ZGP323HSH2032C@SSOP20 [ ( SA626A ) ] ZGP323HSH2032G@SSOP20  
[ ( SA626A ) ]  
ZGP323HSH2804C@SSOP28 [ ( SA626A ) ] ZGP323HSH2804G@SSOP28  
[ ( SA626A ) ]  
ZGP323HSH2808C@SSOP28 [ ( SA626A ) ] ZGP323HSH2808G@SSOP28  
[ ( SA626A ) ]  
ZGP323HSH2816C@SSOP28 [ ( SA626A ) ] ZGP323HSH2816G@SSOP28  
[ ( SA626A ) ]  
ZGP323HSH2832C@SSOP28 [ ( SA626A ) ] ZGP323HSH2832G@SSOP28

[ ( SA626A ) ]

ZGP323HSH4804C@SSOP48 [ ( SA669 ) ]

ZGP323HSH4804G@SSOP48

[ ( SA669 ) ]

ZGP323HSH4808C@SSOP48 [ ( SA669 ) ]

ZGP323HSH4808G@SSOP48

[ ( SA669 ) ]

ZGP323HSH4816C@SSOP48 [ ( SA669 ) ]

ZGP323HSH4816G@SSOP48

[ ( SA669 ) ]

ZGP323HSH4832C@SSOP48 [ ( SA669 ) ]

ZGP323HSH4832G@SSOP48

[ ( SA669 ) ]

ZGP323HSP2004C

ZGP323HSP2004G

ZGP323HSP2008C

ZGP323HSP2008G

ZGP323HSP2016C

ZGP323HSP2016G

ZGP323HSP2032C

ZGP323HSP2032G

ZGP323HSP2804C

ZGP323HSP2804G

ZGP323HSP2808C

ZGP323HSP2808G

ZGP323HSP2816C

ZGP323HSP2816G

ZGP323HSP2832C

ZGP323HSP2832G

ZGP323HSP4004C

ZGP323HSP4004G

ZGP323HSP4008C

ZGP323HSP4008G

ZGP323HSP4016C

ZGP323HSP4016G

ZGP323HSP4032C

ZGP323HSP4032G

ZGP323HSS2004C@SOIC20 [ ( SA404 ) ]

ZGP323HSS2004G@SOIC20

[ ( SA404 ) ]

ZGP323HSS2008C@SOIC20 [ ( SA404 ) ]

ZGP323HSS2008G@SOIC20

[ ( SA404 ) ]

ZGP323HSS2016C@SOIC20 [ ( SA404 ) ]

ZGP323HSS2016G@SOIC20

[ ( SA404 ) ]

ZGP323HSS2032C@SOIC20 [ ( SA404 ) ]

ZGP323HSS2032G@SOIC20

[ ( SA404 ) ]

ZGP323HSS2804C@SOIC28 [ ( SA404 ) ]

ZGP323HSS2804G@SOIC28

[ ( SA404 ) ]



ZGP323HSS2808C@SOIC28 [(SA404)]	ZGP323HSS2808G@SOIC28
[(SA404)]	
ZGP323HSS2816C@SOIC28 [(SA404)]	ZGP323HSS2816G@SOIC28
[(SA404)]	
ZGP323HSS2832C@SOIC28 [(SA404)]	ZGP323HSS2832G@SOIC28
[(SA404)]	
ZGP323LAH2004C@SSOP20 [(SA626A)]	ZGP323LAH2004G@SSOP20
[(SA626A)]	
ZGP323LAH2008C@SSOP20 [(SA626A)]	ZGP323LAH2008G@SSOP20
[(SA626A)]	
ZGP323LAH2016C@SSOP20 [(SA626A)]	ZGP323LAH2016G@SSOP20
[(SA626A)]	
ZGP323LAH2032C@SSOP20 [(SA626A)]	ZGP323LAH2032G@SSOP20
[(SA626A)]	
ZGP323LAH2804C@SSOP28 [(SA626A)]	ZGP323LAH2804G@SSOP28
[(SA626A)]	
ZGP323LAH2808C@SSOP28 [(SA626A)]	ZGP323LAH2808G@SSOP28
[(SA626A)]	
ZGP323LAH2816C@SSOP28 [(SA626A)]	ZGP323LAH2816G@SSOP28
[(SA626A)]	
ZGP323LAH2832C@SSOP28 [(SA626A)]	ZGP323LAH2832G@SSOP28
[(SA626A)]	
ZGP323LAH4804C@SSOP48 [(SA669)]	ZGP323LAH4804G@SSOP48
[(SA669)]	
ZGP323LAH4808C@SSOP48 [(SA669)]	ZGP323LAH4808G@SSOP48
[(SA669)]	
ZGP323LAH4816C@SSOP48 [(SA669)]	ZGP323LAH4816G@SSOP48
[(SA669)]	
ZGP323LAH4832C@SSOP48 [(SA669)]	ZGP323LAH4832G@SSOP48
[(SA669)]	
ZGP323LAP2004C	
ZGP323LAP2004G	
ZGP323LAP2008C	
ZGP323LAP2008G	
ZGP323LAP2016C	
ZGP323LAP2016G	
ZGP323LAP2032C	
ZGP323LAP2032G	
ZGP323LAP2804C	
ZGP323LAP2804G	
ZGP323LAP2808C	
ZGP323LAP2808G	
ZGP323LAP2816C	

ZGP323LAP2816G  
 ZGP323LAP2832C  
 ZGP323LAP2832G  
 ZGP323LAP4004C  
 ZGP323LAP4004G  
 ZGP323LAP4008C  
 ZGP323LAP4008G  
 ZGP323LAP4016C  
 ZGP323LAP4016G  
 ZGP323LAP4032C  
 ZGP323LAP4032G  
 ZGP323LAS2004C@SOIC20 [ ( SA404 ) ]                      ZGP323LAS2004G@SOIC20  
 [ ( SA404 ) ]  
 ZGP323LAS2008C@SOIC20 [ ( SA404 ) ]                      ZGP323LAS2008G@SOIC20  
 [ ( SA404 ) ]  
 ZGP323LAS2016C@SOIC20 [ ( SA404 ) ]                      ZGP323LAS2016G@SOIC20  
 [ ( SA404 ) ]  
 ZGP323LAS2032C@SOIC20 [ ( SA404 ) ]                      ZGP323LAS2032G@SOIC20  
 [ ( SA404 ) ]  
 ZGP323LAS2804C@SOIC28 [ ( SA404 ) ]                      ZGP323LAS2804G@SOIC28  
 [ ( SA404 ) ]  
 ZGP323LAS2808C@SOIC28 [ ( SA404 ) ]                      ZGP323LAS2808G@SOIC28  
 [ ( SA404 ) ]  
 ZGP323LAS2816C@SOIC28 [ ( SA404 ) ]                      ZGP323LAS2816G@SOIC28  
 [ ( SA404 ) ]  
 ZGP323LAS2832C@SOIC28 [ ( SA404 ) ]                      ZGP323LAS2832G@SOIC28  
 [ ( SA404 ) ]  
 ZGP323LEH2004C@SSOP20 [ ( SA626A ) ]                      ZGP323LEH2004G@SSOP20  
 [ ( SA626A ) ]  
 ZGP323LEH2008C@SSOP20 [ ( SA626A ) ]                      ZGP323LEH2008G@SSOP20  
 [ ( SA626A ) ]  
 ZGP323LEH2016C@SSOP20 [ ( SA626A ) ]                      ZGP323LEH2016G@SSOP20  
 [ ( SA626A ) ]  
 ZGP323LEH2032C@SSOP20 [ ( SA626A ) ]                      ZGP323LEH2032G@SSOP20  
 [ ( SA626A ) ]  
 ZGP323LEH2804C@SSOP28 [ ( SA626A ) ]                      ZGP323LEH2804G@SSOP28  
 [ ( SA626A ) ]  
 ZGP323LEH2808C@SSOP28 [ ( SA626A ) ]                      ZGP323LEH2808G@SSOP28  
 [ ( SA626A ) ]  
 ZGP323LEH2816C@SSOP28 [ ( SA626A ) ]                      ZGP323LEH2816G@SSOP28  
 [ ( SA626A ) ]  
 ZGP323LEH2832C@SSOP28 [ ( SA626A ) ]                      ZGP323LEH2832G@SSOP28  
 [ ( SA626A ) ]

ZGP323LEH4804C@SSOP48 [(SA669)]	ZGP323LEH4804G@SSOP48
[(SA669)]	
ZGP323LEH4808C@SSOP48 [(SA669)]	ZGP323LEH4808G@SSOP48
[(SA669)]	
ZGP323LEH4816C@SSOP48 [(SA669)]	ZGP323LEH4816G@SSOP48
[(SA669)]	
ZGP323LEH4832C@SSOP48 [(SA669)]	ZGP323LEH4832G@SSOP48
[(SA669)]	
ZGP323LEP2004C	
ZGP323LEP2004G	
ZGP323LEP2008C	
ZGP323LEP2008G	
ZGP323LEP2016C	
ZGP323LEP2016G	
ZGP323LEP2032C	
ZGP323LEP2032G	
ZGP323LEP2804C	
ZGP323LEP2804G	
ZGP323LEP2808C	
ZGP323LEP2808G	
ZGP323LEP2816C	
ZGP323LEP2816G	
ZGP323LEP2832C	
ZGP323LEP2832G	
ZGP323LEP4004C	
ZGP323LEP4004G	
ZGP323LEP4008C	
ZGP323LEP4008G	
ZGP323LEP4016C	
ZGP323LEP4016G	
ZGP323LEP4032C	
ZGP323LEP4032G	
ZGP323LES2004C@SOIC20 [(SA404)]	ZGP323LES2004G@SOIC20
[(SA404)]	
ZGP323LES2008C@SOIC20 [(SA404)]	ZGP323LES2008G@SOIC20
[(SA404)]	
ZGP323LES2016C@SOIC20 [(SA404)]	ZGP323LES2016G@SOIC20
[(SA404)]	
ZGP323LES2032C@SOIC20 [(SA404)]	ZGP323LES2032G@SOIC20
[(SA404)]	
ZGP323LES2804C@SOIC28 [(SA404)]	ZGP323LES2804G@SOIC28
[(SA404)]	
ZGP323LES2808C@SOIC28 [(SA404)]	ZGP323LES2808G@SOIC28

[ ( SA404 ) ]		
ZGP323LES2816C@SOIC28 [ ( SA404 ) ]		ZGP323LES2816G@SOIC28
[ ( SA404 ) ]		
ZGP323LES2832C@SOIC28 [ ( SA404 ) ]		ZGP323LES2832G@SOIC28
[ ( SA404 ) ]		
ZGP323LSH2004C@SSOP20 [ ( SA626A ) ]		ZGP323LSH2004G@SSOP20
[ ( SA626A ) ]		
ZGP323LSH2008C@SSOP20 [ ( SA626A ) ]		ZGP323LSH2008G@SSOP20
[ ( SA626A ) ]		
ZGP323LSH2016C@SSOP20 [ ( SA626A ) ]		ZGP323LSH2016G@SSOP20
[ ( SA626A ) ]		
ZGP323LSH2032C@SSOP20 [ ( SA626A ) ]		ZGP323LSH2032G@SSOP20
[ ( SA626A ) ]		
ZGP323LSH2804C@SSOP28 [ ( SA626A ) ]		ZGP323LSH2804G@SSOP28
[ ( SA626A ) ]		
ZGP323LSH2808C@SSOP28 [ ( SA626A ) ]		ZGP323LSH2808G@SSOP28
[ ( SA626A ) ]		
ZGP323LSH2816C@SSOP28 [ ( SA626A ) ]		ZGP323LSH2816G@SSOP28
[ ( SA626A ) ]		
ZGP323LSH2832C@SSOP28 [ ( SA626A ) ]		ZGP323LSH2832G@SSOP28
[ ( SA626A ) ]		
ZGP323LSH4804C@SSOP48 [ ( SA669 ) ]		ZGP323LSH4804G@SSOP48
[ ( SA669 ) ]		
ZGP323LSH4808C@SSOP48 [ ( SA669 ) ]		ZGP323LSH4808G@SSOP48
[ ( SA669 ) ]		
ZGP323LSH4816C@SSOP48 [ ( SA669 ) ]		ZGP323LSH4816G@SSOP48
[ ( SA669 ) ]		
ZGP323LSH4832C@SSOP48 [ ( SA669 ) ]		ZGP323LSH4832G@SSOP48
[ ( SA669 ) ]		
ZGP323LSK2032E		
ZGP323LSK2032G		
ZGP323LSK2832E		
ZGP323LSK2832G		
ZGP323LSK4032E		
ZGP323LSK4032G		
ZGP323LSP2004C		
ZGP323LSP2004G		
ZGP323LSP2008C		
ZGP323LSP2008G		
ZGP323LSP2016C		
ZGP323LSP2016G		
ZGP323LSP2032C		
ZGP323LSP2032G		

ZGP323LSP2804C  
 ZGP323LSP2804G  
 ZGP323LSP2808C  
 ZGP323LSP2808G  
 ZGP323LSP2816C  
 ZGP323LSP2816G  
 ZGP323LSP2832C  
 ZGP323LSP2832G  
 ZGP323LSP4004C  
 ZGP323LSP4004G  
 ZGP323LSP4008C  
 ZGP323LSP4008G  
 ZGP323LSP4016C  
 ZGP323LSP4016G  
 ZGP323LSP4032C  
 ZGP323LSP4032G

ZGP323LSS2004C@SOIC20 [(SA404)]  
 [(SA404)]

ZGP323LSS2004G@SOIC20

ZGP323LSS2008C@SOIC20 [(SA404)]  
 [(SA404)]

ZGP323LSS2008G@SOIC20

ZGP323LSS2016C@SOIC20 [(SA404)]  
 [(SA404)]

ZGP323LSS2016G@SOIC20

ZGP323LSS2032C@SOIC20 [(SA404)]  
 [(SA404)]

ZGP323LSS2032G@SOIC20

ZGP323LSS2804C@SOIC28 [(SA404)]  
 [(SA404)]

ZGP323LSS2804G@SOIC28

ZGP323LSS2808C@SOIC28 [(SA404)]  
 [(SA404)]

ZGP323LSS2808G@SOIC28

ZGP323LSS2816C@SOIC28 [(SA404)]  
 [(SA404)]

ZGP323LSS2816G@SOIC28

ZGP323LSS2832C@SOIC28 [(SA404)]  
 [(SA404)]

ZGP323LSS2832G@SOIC28

ZLP12840H2028C@SSOP20 [(SA626A)]  
 [(SA626A)]

ZLP12840H2028G@SSOP20

ZLP12840H2032C@SSOP20 [(SA626A)]  
 [(SA626A)]

ZLP12840H2032G@SSOP20

ZLP12840H2064C@SSOP20 [(SA626A)]  
 [(SA626A)]

ZLP12840H2064G@SSOP20

ZLP12840H2096C@SSOP20 [(SA626A)]  
 [(SA626A)]

ZLP12840H2096G@SSOP20

ZLP12840H2828C@SSOP28 [(SA626A)]  
 [(SA626A)]

ZLP12840H2828G@SSOP28

ZLP12840H2832C@SSOP28 [(SA626A)]

ZLP12840H2832G@SSOP28

[ ( SA626A ) ]  
ZLP12840H2864C@SSOP28 [ ( SA626A ) ] ZLP12840H2864G@SSOP28  
[ ( SA626A ) ]  
ZLP12840H2896C@SSOP28 [ ( SA626A ) ] ZLP12840H2896G@SSOP28  
[ ( SA626A ) ]  
ZLP12840P2028C  
ZLP12840P2028G  
ZLP12840P2032C  
ZLP12840P2032G  
ZLP12840P2064C  
ZLP12840P2064G  
ZLP12840P2096C  
ZLP12840P2096G  
ZLP12840P2828C  
ZLP12840P2828G  
ZLP12840P2832C  
ZLP12840P2832G  
ZLP12840P2864C  
ZLP12840P2864G  
ZLP12840P2896C  
ZLP12840P2896G  
ZLP12840S2028C@SOIC20 [ ( SA404 ) ] ZLP12840S2028G@SOIC20  
[ ( SA404 ) ]  
ZLP12840S2032C@SOIC20 [ ( SA404 ) ] ZLP12840S2032G@SOIC20  
[ ( SA404 ) ]  
ZLP12840S2064C@SOIC20 [ ( SA404 ) ] ZLP12840S2064G@SOIC20  
[ ( SA404 ) ]  
ZLP12840S2096C@SOIC20 [ ( SA404 ) ] ZLP12840S2096G@SOIC20  
[ ( SA404 ) ]  
ZLP12840S2828C@SOIC28 [ ( SA404 ) ] ZLP12840S2828G@SOIC28  
[ ( SA404 ) ]  
ZLP12840S2832C@SOIC28 [ ( SA404 ) ] ZLP12840S2832G@SOIC28  
[ ( SA404 ) ]  
ZLP12840S2864C@SOIC28 [ ( SA404 ) ] ZLP12840S2864G@SOIC28  
[ ( SA404 ) ]  
ZLP12840S2896C@SOIC28 [ ( SA404 ) ] ZLP12840S2896G@SOIC28  
[ ( SA404 ) ]  
ZLP32300H2004C@SSOP20 [ ( SA626A ) ] ZLP32300H2004G@SSOP20  
[ ( SA626A ) ]  
ZLP32300H2008C@SSOP20 [ ( SA626A ) ] ZLP32300H2008G@SSOP20  
[ ( SA626A ) ]  
ZLP32300H2016C@SSOP20 [ ( SA626A ) ] ZLP32300H2016G@SSOP20  
[ ( SA626A ) ]

ZLP32300H2032C@SSOP20 [(SA626A)]	ZLP32300H2032G@SSOP20
[(SA626A)]	
ZLP32300H2804C@SSOP28 [(SA626A)]	ZLP32300H2804G@SSOP28
[(SA626A)]	
ZLP32300H2808C@SSOP28 [(SA626A)]	ZLP32300H2808G@SSOP28
[(SA626A)]	
ZLP32300H2816C@SSOP28 [(SA626A)]	ZLP32300H2816G@SSOP28
[(SA626A)]	
ZLP32300H2832C@SSOP28 [(SA626A)]	ZLP32300H2832G@SSOP28
[(SA626A)]	
ZLP32300H4804C@SSOP48 [(SA669)]	ZLP32300H4804G@SSOP48
[(SA669)]	
ZLP32300H4808C@SSOP48 [(SA669)]	ZLP32300H4808G@SSOP48
[(SA669)]	
ZLP32300H4816C@SSOP48 [(SA669)]	ZLP32300H4816G@SSOP48
[(SA669)]	
ZLP32300H4832C@SSOP48 [(SA669)]	ZLP32300H4832G@SSOP48
[(SA669)]	
ZLP32300P2004C	
ZLP32300P2004G	
ZLP32300P2008C	
ZLP32300P2008G	
ZLP32300P2016C	
ZLP32300P2016G	
ZLP32300P2032C	
ZLP32300P2032G	
ZLP32300P2804C	
ZLP32300P2804G	
ZLP32300P2808C	
ZLP32300P2808G	
ZLP32300P2816C	
ZLP32300P2816G	
ZLP32300P2832C	
ZLP32300P2832G	
ZLP32300P4004C	
ZLP32300P4004G	
ZLP32300P4008C	
ZLP32300P4008G	
ZLP32300P4016C	
ZLP32300P4016G	
ZLP32300P4032C	
ZLP32300P4032G	
ZLP32300S2004C@SOIC20 [(SA404)]	ZLP32300S2004G@SOIC20

[ (SA404) ]		
ZLP32300S2008C@SOIC20 [ (SA404) ]		ZLP32300S2008G@SOIC20
[ (SA404) ]		
ZLP32300S2016C@SOIC20 [ (SA404) ]		ZLP32300S2016G@SOIC20
[ (SA404) ]		
ZLP32300S2032C@SOIC20 [ (SA404) ]		ZLP32300S2032G@SOIC20
[ (SA404) ]		
ZLP32300S2804C@SOIC28 [ (SA404) ]		ZLP32300S2804G@SOIC28
[ (SA404) ]		
ZLP32300S2808C@SOIC28 [ (SA404) ]		ZLP32300S2808G@SOIC28
[ (SA404) ]		
ZLP32300S2816C@SOIC28 [ (SA404) ]		ZLP32300S2816G@SOIC28
[ (SA404) ]		
ZLP32300S2832C@SOIC28 [ (SA404) ]		ZLP32300S2832G@SOIC28
[ (SA404) ]		

## ZMD

### E (E) PROM/FRAM/NVRAM

U62256		
U6264		
U6264@SOIC28 [ (SA630) ]		
U6264A		
U6264A@SOIC28 [ (SA630) ]		U62H256A@SOIC28
[ (SA630) ]		
U62H256S@SOIC28 [ (SA630) ]		U62H64SA@SOIC28
[ (SA630) ]		
U630H16		U630H16@SOIC28
[ (SA630) ]		
U630H64		U630H64@SOIC28
[ (SA630) ]		
U631H16		U631H16@SOIC24
[ (SA404) ]		
U631H16@SOIC28 [ (SA630) ]		
U631H256		
U631H256@SOIC28 [ (SA630) ]		
U631H64		
U631H64@SOIC28 [ (SA630) ]		
U632H16		
U632H16@SOIC28 [ (SA630) ]		
U632H64		



U632H64@SOIC28 [(SA630)]

U634H256

U634H256@SOIC32 [(SA630)]

U635H16

U635H16@SOIC24 [(SA404)]

U635H256

U635H256@SOIC28 [(SA630)]

U635H64

U635H64@SOIC28 [(SA630)]

U63716

U637256

U63764

U637H256

UL62H256A@SOIC28

[(SA630)]

UL631H256@SOIC28 [(SA630)]

UL631H256@TSOP32

[(SA410T)]

UL634H256@SOIC32 [(SA630)]

UL634H256@TSOP32

[(SA410T)]

UL635H256@SOIC28 [(SA630)]

UL635H256@TSOP32

[(SA410T)]